



imageRUNNER

ADVANCE

C5255/C5250/C5240/C5235

Basic Operation Guide



How to Use This Manual

This manual describes the following functions, operations, and maintenance procedures.

- Functions that can be operated from the touch panel display of the machine
- Remote UI functions that can operate the machine from a computer
- Printing from a computer
- Routine Maintenance Procedures
- Clearing paper jams/staple jams

Store this manual next to the machine so it can be used when the user encounters trouble operating the machine.

* Some functions explained in this manual may require optional equipment.

* Screen shots used in this manual may differ from the ones you actually see.

Contents

■ Before You Start Using This Machine

What This Machine Can Do.....	10
Main Power and Energy Saver Key.....	12
Parts and Their Functions.....	14
Control Panel and Touch Panel Display.....	18
Main Menu Screen Settings.....	20
Changing Settings According to Your Needs.....	22

■ Flow of Basic Operations

How to Make a Copy.....	24
Things You Can Do with the Copy Functions.....	26
Sending a Fax.....	30
Things You Can Do with the Fax Functions.....	32
Sending Scanned Data (E-Mail/I-Fax/File Servers).....	36
Things You Can Do with the Scan and Send Functions.....	38
Storing Scanned Data.....	42
Things You Can Do with the Scan and Store Functions.....	44
Printing Stored Data.....	46
Sending Stored Data.....	48
Things You Can Do with the Access Stored Files Functions (File Operation).....	50
Things You Can Do with the Access Stored Files Functions (Print).....	51
Things You Can Do with the Access Stored Files Functions (Send).....	54
Operating the Machine from a Computer (Remote UI).....	56
Printing from a Computer.....	58

■ Routine Maintenance

Loading Paper.....	62
Loading Tab Paper Using the Tab Feeding Attachment Kit-B1 (Optional).....	70
Loading Envelopes Using the Envelope Feeder Attachment-D1 (Optional).....	73
Replacing the Stamp Cartridge (Feeder) (Optional).....	80
Replacing the Staple Cartridge (For Optional Products).....	85
Removing Punch Waste (External 2 Hole Puncher-B2/External 2/3 Hole Puncher-B2/External 2/4 Hole Puncher-B2).....	91
Replacing the Toner Cartridge.....	93
Replacing the Waste Toner Container.....	99
Routine Cleaning.....	102
Consumables.....	113

■ Troubleshooting


Clearing Paper Jams	118
Reducing the Frequency of Paper Jams	149
Clearing Staple Jams (For Optional Products).....	150
If Memory Becomes Full During Scanning	158
When an Error Message Is Displayed.....	160
When an Error Code Is Displayed.....	161
Printer/Fax Driver Troubleshooting	162
Service Call Message.....	163
Frequently Asked Questions	170

How to Use This Manual

Refer to the following manuals included with your machine according to your needs.


Before Using This Machine

- Describes precautions for using the machine.
- Includes the specifications of the machine.




Setup Guide

- Describes the settings required before using functions, such as the network settings for sending e-mail.
- Describes how to add applications and update the firmware.




Basic Operation Guide (This Manual)

- Provides an overview of the functions and describes the basic operations.
- Describes the maintenance and troubleshooting procedures for the machine.




e-Manual

- Describes all the functions of the machine. Also provided with a search function that is useful for finding and checking information.
- Includes “Practical Workflows,” which introduces flows of practical operations using functions of the machine.



Driver Installation Guide

- Provides instructions on installing the printer, fax, and other drivers.
 - Printer Driver Installation Guide
 - Mac Printer Driver Installation Guide
 - Fax Driver Installation Guide
 - Network ScanGear Installation Guide
- Included on the same CD-ROM as each driver.



Symbols Used in This Manual

The following symbols are used in this manual to explain procedures, restrictions, handling precautions, and instructions that should be observed for safety.



WARNING

Indicates a warning concerning operations that may lead to death or injury to persons if not performed correctly. To use the machine safely, always pay attention to these warnings.



CAUTION

Indicates a caution concerning operations that may lead to injury to persons if not performed correctly. To use the machine safely, always pay attention to these cautions.



IMPORTANT

Indicates operational requirements and restrictions. Be sure to read these items carefully to operate the machine correctly, and avoid damage to the machine or property.



NOTE

Indicates a clarification of an operation, or contains additional explanations for a procedure. Reading these notes is highly recommended.



Indicates an operation that must not be performed. Read these items carefully, and make sure not to perform the described operations.

How to Use This Manual (e-Manual)

Follow the procedure below to install the e-Manual.

Windows

1. Insert the e-Manual CD-ROM into your computer.
2. Select the language for the e-Manual.
3. Select [Install].
If you select [Display Manuals], the e-Manual is displayed without installation.
4. Read the License Agreement, and then click [Yes].
The e-Manual is saved in the [Documents]* folder on your computer. If the shortcut icon is created on the Desktop or if the [index. html] file is double-clicked, the e-Manual is displayed.

* The folder name differs, depending on your operating system. The folder name is [Documents] if you are using Windows Vista/7/8 and [My Documents] if you are using Windows 2000/XP.

Macintosh

1. Insert the e-Manual CD-ROM into your computer.
2. Drag-and-drop the [iRADV_C5255_Manual_eng] folder to the location you want to save it.
3. Double-click the index.html file inside the [iRADV_C5255_Manual_eng] folder to display the e-Manual.



- Depending on the operating system you are using, a security protection message may appear. In this case, allow the content to be displayed.
- When you start the e-Manual, the following page (the top page) appears.


■ If the e-Manual (CD-ROM) Does Not Start

The CD-ROM auto run function may be disabled. In this case, perform the following procedure.

- Windows 8/Server 2012
 1. Show the Desktop → click the File Explorer icon on the taskbar.
 2. Click [Computer].
 3. Double-click the e-Manual icon.
 4. Double-click [Maninst.exe].
- Windows Vista/7/Server 2008
 1. Click [Start] on the Windows taskbar → click [Computer].
 2. Double-click the e-Manual icon.
 3. Double-click [Maninst.exe].
- Windows XP/Server 2003
 1. Click [Start] on the Windows taskbar → click [My Computer].
 2. Double-click the e-Manual icon.
 3. Double-click [Maninst.exe].
- Windows 2000
 1. Double-click [My Computer] on the desktop.
 2. Double-click the e-Manual icon.
 3. Double-click [Maninst.exe].



1 Enter keyword(s) here

Enter a keyword in the search dialog box, and press . The search results page is displayed.

2 Select from functions

The instructions of each function and operation method are described.

3 [Top]

The top page of the e-Manual is displayed.

4 [Site map]

The site map of the e-Manual is displayed.

5 [Help]

The usage of the e-Manual is displayed.

6 [Glossary]

The glossary is displayed.

7 First of all...

This section describes the required information to use the machine, and the information of optional product and software.

8 Select from purpose

This section includes the introduction of functions of the machine for each purpose.

9 [Office Locations]

Inquiries for the machine are displayed.

10 [Trademarks]

The trademarks are displayed.


11 [Copyright]

The information of copyrights is displayed.

12 [Disclaimers]

The disclaimers are displayed.

■ Performing a Search

Enter a keyword in the entry field which is located at the top of the "Top page" or on the search area in the "Topic page," and then click  to display the search results.

■ Printing a Topic Page

- On a topic page, you can print by category or by topic.
- Depending on the settings of the Web browser, the background color and images of the topic page may not be printed.



MEMO

A series of horizontal lines for writing, spanning the width of the page.

Before You Start Using This Machine

What This Machine Can Do 10

Main Power and Energy Saver Key 12

Parts and Their Functions 14

External View14

Internal View16


Control Panel and Touch Panel Display..... 18

Main Menu Screen Settings 20

Changing Settings According to Your Needs..... 22

What This Machine Can Do

Revolutionary Documentation Work with an Evolving Multitasking Machine



The imageRUNNER ADVANCE C5255/C5250/C5240/C5235 incorporates a rich array of input and output features that can greatly enhance your efficiency. Equipped with features that meet the needs of document work in a digitized office, the imageRUNNER ADVANCE C5255/C5250/C5240/C5235 represents the ultimate in a color digital multitasking machines.

● Copy

You can make two-sided copies from one-sided originals or copy two pages onto one side of the paper to reduce printing cost. There are other modes, such as the Collate modes. (p. 24)

● Fax

Scanned documents as well as stored files and computer data can be sent by facsimile. You can also send documents to multiple addresses and forward received facsimile to another destination. Also, by using Remote Fax sending function, you can share the Fax function on the same network. (p. 30)

● Send Documents (E-Mail/Fax/I-Fax/File Server/Store in Mail Box)

You can send scanned documents by e-mail or I-fax, as well as store them on a network file server. You can also store sent documents in the Mail Box. (p. 36)

● Use Mail Box (Store/Print/Send)

You can store scanned documents or data from a computer in a mail box. You can print documents stored in a mail box, and sent them to other destinations. (p. 42, p. 46)

● Use Remote Scanner

You can use this machine as a remote scanner by TWAIN compatible computer software. You can scan up to A3 in size at a resolution of 600 x 600 dpi. (See e-Manual > Scanner.)

● Printing a Fax/I-Fax File in the Memory RX inbox

If Memory RX is set, files received by Fax/I-Fax function are not printed, but stored in the Memory RX Inbox. You can print the stored files whenever necessary. This can help prevent outputs being forgotten at the machine. (See e-Manual > Fax/I-Fax Inbox.)

● Use Memory Media

You can scan and store documents in the memory media connected to the USB port. You can also print stored files directly from the memory media. (p. 42, p. 46)

● Use Advanced Box

You can set a file format to the scanned document so that it can be accessed from your computer. You can also store files in the Advanced Box with a file format that can be used on your computer. The stored data can be shared by accessing it from a computer. The Advanced Box can also be accessed from other imageRUNNER ADVANCE machines for operations, such as printing stored data. (p. 42, p. 46)

● Print Secured File

You can send print data protected with a PIN/password from a computer to the machine. This data can be printed only by entering the correct PIN/password on the machine. This enables you to print without unauthorized people viewing your data. (See e-Manual > Secure Print.)

● View Web Page

You can use this machine to browse Web pages from the touch panel display of the machine or print PDF files on the Web pages. (See e-Manual > Web Access.)

* Some functions explained in this manual may require optional equipment.

Main Power and Energy Saver Key

This section describes how to use the main power switch and the Energy Saver key.




WARNING


Do not connect or disconnect the power cord with wet hands, as this may result in electrical shock.

● How to Turn ON the Main Power

Make sure that the power plug is firmly inserted into the power outlet and that the Security Key is in the ON positions (turn it to the right) if it is inserted into the machine, and then turn ON the main power of the machine following the procedure below.

1. Open the main power switch cover.
2. Press the main power switch to the "I" side.
3. Close the main power switch cover.


- 
- If you are using a login service, log in using the procedure for the login service you are using.
 - If the main power indicator on the control panel does not light even though the main power switch is ON, be sure to check the breaker to see if it is OFF.
 - If you want to turn OFF the main power and then back ON again, wait for at least 10 seconds after the main power indicator is turned OFF before turning ON the main power. However, when [Quick Startup Settings for Main Power] is enabled, if you don't wait more than 20 seconds after the main power indicator is turned OFF, quick startup is not performed.



Shutting Down the Machine


This machine performs a procedure to protect hard disk when the machine is shut down. This enables the machine to be shut down safely, even if there are any jobs being processed, or a MEAP application is running while the machine is shutting down.


1. Open the main power switch cover.
2. Press the main power switch to the "⏻" side.
3. Close the main power switch cover.



- Do not turn the main power OFF while using the Fax/I-Fax function. Sending or receiving I-fax or fax documents cannot be done when the main power is turned OFF.
- If the message <Backing up stored data from the Remote UI...> is displayed on the touch panel display, do not turn the main power OFF. This may cause the machine to fail to back up the stored data.
- Data stored in the machine may be damaged if the Advanced Box is accessed by another imageRUNNER ADVANCE machine or a computer immediately before the machine shuts down.
- The machine may take some time to completely shutdown. Do not unplug the power cord until the main power indicator of the machine is OFF.
- If the main power is turned OFF during scanning or printing, a paper jam may occur.
- If you set [Quick Startup Settings for Main Power] to 'On' in [Preferences] (Settings/Registration), the tone sounds when turning OFF the main power of the machine. (Depending on the situations, the machine does not startup quickly and the tone does not sound.)

Energy Saver Key

If the machine is idle for a certain period of time, the machine will enter the Auto Sleep mode to minimize energy consumption. Press  (Energy Saver) to cancel the Sleep mode and resume normal machine operations.




Parts and Their Functions

This section provides you with the names and functions of all the parts of the machine.

External View

When the Duplex Color Image Reader Unit-E1 and Cassette Feeding Unit-AD2 are attached



1 Feeder

Originals placed in the feeder are fed one sheet at a time to the platen glass for scanning.

2 USB Port (1)

Use the USB port to connect a USB device.

3 Security Key (Optional)

For managing the use of the machine and preventing unauthorized copies.

4 Main Power Switch

Press to the "I" side to turn the power ON.

5 Main Unit's Right Cover

Open this cover when clearing a paper jam inside the main unit.

6 Multi-Purpose Tray

Use the multi-purpose tray to feed paper manually, and for loading nonstandard paper stock, such as envelopes.

7 Paper Drawer's Right Cover

Open this cover when clearing a paper jam in Paper Drawers 1 and 2.

8 Paper Drawer 2

Holds up to 550 sheets of paper 80 g/m².

9 Paper Drawer 1

Holds up to 550 sheets of paper (80 g/m²).

10 Output Tray

Prints and copies are output to this tray.

11 Output Paper Tray Guide

Tilt the output paper tray guide up to prevent output papers from falling down.

12 Control Panel

Includes the keys, touch panel display, and indicators required for operating the machine.

13 LAN Port

Use a LAN cable to connect the machine to a network.

14 USB Port (2)

Use the USB port to connect external hard disks and other devices to the machine.

15 USB Connector

Use a USB cable to connect the machine to a computer.

16 Test Button

Press this button to test the circuit breaker.

17 Breaker

Detects excess current or leakage current.

18 LINE 4

Use this port to connect the Super G3 3rd/4th Line Fax Board to the machine.

19 LINE 3

Use this port to connect the Super G3 3rd/4th Line Fax Board to the machine.

20 LINE 2


Use this port to connect the Super G3 2nd Line Fax Board to the machine.

21 LINE 1

Use this port to connect a fax line to the machine.

Internal View

When the Duplex Color Image Reader Unit-E1 and Cassette Feeding Unit-AD2 are attached



1 Platen Glass

Use the platen glass when scanning books, thick originals, thin originals, transparencies, etc.

2 Upper Cover of the Fixing Unit

Open this cover to clear a paper jam in the fixing unit.

3 Duplexing Unit

Pull out the duplexing unit to clear a paper jam.

4 Waste Toner Container

Waste toner accumulates here.

5 Toner Replacement Cover


Open this cover to replace the toner cartridge.

6 Toner Cartridge

When toner runs out, pull out the toner cartridge, and replace it with a new one.

Control Panel and Touch Panel Display

This section provides you with the names and functions of all the parts of the control panel and touch panel display.



1 Energy Saver key

Press to set or cancel the Sleep mode. Lights when the machine enters the Sleep mode. For information on the Auto Sleep mode, see "Main Power and Energy Saver Key," on p. 12.

2 Settings/Registration key

Press to specify settings/registration. (p. 22)

3 Counter Check key

Press to display the copy and print count totals on the touch panel display.

4 Clear key

Press to clear entered values or characters.

5 Stop key

Press to stop a job in progress, such as a scan, copy, or fax (scanning only) job.

6 Edit Pen

Use when operating the touch panel display, such as to enter characters.

7 Start key

Press to start an operation.

8 Main Power Indicator

Lights when the main power is turned ON.

9 Error Indicator

Flashes or lights if there is an error in the machine.

10 Processing/Data Indicator

Flashes or blinks green when the machine is performing operations, and maintains a steady green light when fax data is stored in memory.

11 Reset key

Press to restore the standard settings of the machine.

12 ID (Log In/Out) key

Press to log in/out when a login service, such as Department ID Management or SSO-H has been set.

13 Numeric keys

Press to enter numerical values.

14 Touch Panel Display

The settings screen for each function is shown on this display. Eight function keys are displayed by default.

15 Brightness Adjustment Dial

Use to adjust the brightness of the touch panel display.

16 Volume Settings key

Press to display the screen for adjusting settings such as the transmission volume and fax sending/receiving alarm volume.

17 Status Monitor/Cancel key

Press to check the status of jobs or to cancel print jobs. Also, press to check status of the machine, such as checking the amount of paper remaining.



18 Quick Menu key

Press to retrieve favorite functions stored in Quick Menu.

19 Main Menu key



Press to return to the Main Menu screen, such as when you want to switch functions.

● Use Quick Menu

If functions that are frequently used are set in the Quick Menu beforehand, you can recall the function by pressing  (Quick Menu). If you are using a login service, Quick Menu screen set for each user appears. To register a function in the Quick Menu, set the function and press [Register to Quick Menu] from .






● Logging In/Out

If you are managing the machine with a login service, such as Department ID Management or SSO-H (Single Sign-On H), a log in screen appears. If the log in screen appears, enter the Department ID and PIN or the user name and password → press  (Log In/Out) or [Log In] on the screen. Press  (Log In/Out) or [Log Out] after you finish using the machine to log out.






● Use Help


If  (Help) is displayed on the top right of the function setting screen, press  (Help) to check the explanation of the function or how to specify settings. Press to check the explanation of the function or how to specify settings.



Main Menu Screen Settings




You can specify settings for the displayed screen by pressing  on the top right of the screen. To perform this procedure, log in to the machine as an administrator.

- The items displayed when  is pressed may differ, depending on the function.
- If authentication function is used, items displayed may differ or  may not be available, depending on the login user's privileges.




Specifying the Main Menu Settings

You can set the number of buttons and the layout displayed on the Main Menu screen.

1. Press  → [Main Menu Button Display Settings].
2. Press  or  to select the number of buttons and the layout to be displayed.
3. Select the function that appears on the list → change the order in which it is displayed.
4. Press [OK].


- Select the function that appears on the list and press [Up] or [Down] to change the order in which it is displayed.
- You can place or delete one blank button space by pressing [Add Blank] or [Delete Blank], respectively.




Example of Customized Screen

Top Buttons Settings

You can display up to two function shortcut buttons on the top of the screen.

1. Press  → [Top Buttons Settings].
2. Select the shortcut button and the function to assign to it.
3. Press [OK].


If you do not want to select a function, press [Unassigned].



Example of Registration

● Setting the Main Menu Wallpaper

You can select the wallpaper for the Main Menu screen.


1. Press  → [Main Menu Wallpaper Settings].
2. Select the wallpaper.
3. Press [OK].




Example of Customized Screen

● Other Main Menu Settings

You can set whether the shortcut buttons for modes, such as changing the displayed language or changing the paper settings for copying/printing are displayed on the Main Menu screen.

1. Press  → [Other Main Menu Settings].
2. Specify the other settings.
3. Press [OK].

If <Display [Language/Keyboard Switch]> is set to 'On',  appears on the Main Menu screen.

If <Display [Settings/Reg.Shortcut]> is set to 'On', [Settings/Reg.Shortcut] appears on the Main Menu screen.

From [Settings/Reg.Shortcut], you can select shortcut buttons to the setting screens for [Auto Adjust Gradation], [Paper Settings], and [Paper Type Management Settings].


If <Display [Show All]> is set to 'On', [Show All] appears on the Main Menu screen.




Example of Customized Screen

For more information on [Language/Keyboard Switch], [Auto Adjust Gradation], [Paper Settings], and [Paper Type Management Settings], see e-Manual > Settings/Registration.

Changing Settings According to Your Needs



The Settings/Registration screen appears when you press  (Settings/Registration) on the control panel.

The machine provides various settings that enable you to use it more conveniently and easily. You can register or change the settings according to your needs. For more information, see e-Manual > Settings/Registration.

Preferences

You can specify basic settings for using the machine, such as changing the paper size to load, changing the default screen to display, setting the date and time, setting the time it takes to enter the low power mode, and specifying the settings for connecting to a network.

Adjustment/Maintenance

You can specify settings for using the machine more comfortably, such as adjusting the density, adjusting the gradation, and cleaning the feeder.

Function Settings

You can specify and register settings for using each function more conveniently, such as registering shortcut buttons for the Copy function, setting automatic redialing for the Fax function, and setting the maximum data size to send via e-mail.

Set Destination

You can register fax and e-mail destinations in the address book. In addition to registering frequently used destinations, you can also register multiple destinations as a group, enabling you to send to those destinations at the same time. You can also register different types of destinations (e-mail and file server) as a group.

Management Settings

You can set the administrator settings for managing the machine. This enables you to set an ID and password for each department, manage confidential information, and count the number of pages printed for each ID. You can also register licenses and certificates.

Flow of Basic Operations

How to Make a Copy	24
Things You Can Do with the Copy Functions	26
Sending a Fax	30
Things You Can Do with the Fax Functions.....	32
Sending Scanned Data (E-Mail/I-Fax/File Servers).....	36
Things You Can Do with the Scan and Send Functions.....	38
Storing Scanned Data.....	42
Things You Can Do with the Scan and Store Functions.....	44
Printing Stored Data.....	46
Sending Stored Data	48
Things You Can Do with the Access Stored Files Functions (File Operation)	50
Things You Can Do with the Access Stored Files Functions (Print)	51
Things You Can Do with the Access Stored Files Functions (Send)	54
Operating the Machine from a Computer (Remote UI).....	56
Printing from a Computer.....	58



How to Make a Copy

This section describes the flow of basic copy operations.


1

Placing Originals

Place the original on the feeder or the platen glass.

Placing originals in the feeder

Adjust the slide guides to fit the size of your originals. Neatly place your originals with the side to be copied face up.




Placing originals on the platen glass

Open the feeder/platen cover.



Place your originals face down.




Gently close the feeder/platen cover.

2


Selecting Function

Select [Copy] from the Main Menu screen.


Press [Copy].




Copy Basic Features Screen is displayed.



You can set various copying functions. For more information, see from p. 26 to p. 29 in this manual.




- If a log in screen for Department ID Management or SSO-H appears, you must enter the applicable authentication information (ID, password/ PIN). If the Copy Card Reader-F1 is attached, first insert a control card.
- If a login service, such as Department ID Management or SSO-H has been set, press  (Log In/Out) to log out.

3

Setting the Number of Copies


Enter the number of copies.

Press the numeric keys to enter the desired copy quantity (1 to 999).



If you make a mistake when entering values, press **C** (Clear) → enter the correct value.

The specified copy quantity appears on the screen, as shown below.




4


Start Copying

After specifying the settings, press **Start** (Start).

Press **Start** (Start).




If the following screen appears, press **Start** (Start) to scan the next original. After all of the originals are scanned, press [Start Copying].



When copying is complete, remove your originals.

Things You Can Do with the Copy Functions

To use Copy functions, press [Copy] on the Main Menu screen. This section describes the functions you can use on the Copy Basic Features screen and the [Options] (1/3) screen. The [Options] screen is divided into three screens. Pressing ▲ or ▼ on the bottom right of the screen displays the next or previous screen.





Regular Copy Basic Features Screen

- 1 [Direct]/[Copy Ratio]**
You can specify the copy ratio for a copy job. You can change the zoom ratio by reducing/enlarging a scanned document to a preset paper size, or by entering a value to specify a desired scan ratio.
- 2 [Select Color]**
You can select the color mode for copying.
- 3 [Select Paper]**
You can select the paper size/type and the paper source. You can also set the machine to automatically recognize the original size and the copy ratio, and then copy.
- 4 [Copy Sample]**
You can check the copy result of one set before making multiple sets of copies. You can also copy a specified page.
- 5 [Check Settings]**
You can check, edit, or clear the current copy settings.
- 6 [Favorite Settings]**
You can register frequently used copy settings. You can recall the registered frequently used settings for future use.
- 7 [Previous Settings]**
You can recall the three most recent copy jobs, and make copies using the recalled copy settings.
- 8 Shortcuts to [Options]**
Press to select a [Options] mode. [Finishing], [2-Sided], [Density], and [Original Type] are set as default.
- 9 [Interrupt]**
You can temporarily stop the current copy job and give priority to a rush copy.



Quickly Make Settings and Copy

You can set the settings on the Regular Copy Basic Features screen quickly by using the Express Copy Basic Features screen. For instructions on displaying the Express Copy Basic Features Screen, see e-Manual > Settings/Registration.






[Options] 1/3

- 1 [Book ▶ 2 Pages]**
You can copy facing pages in a book onto separate sheets of paper.
- 2 [2-Sided]**
You can make one-sided copies from two-sided originals, or make two-sided copies of your originals.
- 3 [Finishing]**
You can collate copies in page order or into groups of the same page.
You can staple the printed sheets.
* To staple printed sheets, optional products are required.
- 4 [Booklet]**
You can layout the scanned documents to make a booklet. You can also print a cover sheet or make a saddle stitch booklet.
* To make a saddle stitch booklet, optional products are required.
- 5 [Insert Sheets]**
Press to insert blank sheets or chapter pages between specified pages.
- 6 [Transparency Cover Sheets]**
The machine automatically interleaves a sheet of paper between each transparency when copying onto transparencies.
- 7 [Original Type]**
Image quality for scanning is adjusted according to the type of original, such as [Text/Photo], [Map], [Printed Image], [Photo Printout], or [Text].
- 8 [Density]**
Change the exposure. You can press  to make the exposure darker or  to make the exposure lighter. You can set the machine to automatically adjust the exposure.
- 9 [Different Size Originals]**
You can make copies of different size originals at the same time without separating the documents. If the paper setting is set to Auto, the machine automatically selects the appropriate paper size.
- 10 [Job Build]**
You can scan originals that are too many to be placed at once, by dividing them into multiple batches. After all originals are scanned, copying is started.
- 11 [N on 1]**
You can reduce multiple pages of the original to copy onto a single page. You can also change the order of the page layout.
- 12 [Add Cover]**
You can add covers.



Things You Can Do with the Copy Functions

This section describes the functions you can use on the [Options] (2/3 and 3/3) screen of the Copy function. The [Options] screen is divided into three screens. Pressing ▲ or ▼ on the bottom right of the screen displays the next or previous screen.




[Options] 2/3


- 1 [Secure Watermark]**
You can embed hidden text, such as "CONFIDENTIAL" in the background of copies. The embedded text appears when the copies are printed, helping prevent unauthorized copying and information leakage.
- 2 [Document Scan Lock]**
You can embed tracking information in copies. This increases security by preventing unauthorized copies.
- 3 [Color Balance]**
This mode enables you to make color balance adjustments.
- 4 [Adjust One-Touch Color]**
This mode enables you to make fine adjustments to the image quality on copies.
- 5 [Erase Frame]**
This mode enables you to erase shadows that appear when scanning various types of originals. You can also erase shadows of the punch holes.
- 6 [Gutter]**
This mode enables you to make copies with the entire original image shifted by a designated width to create a margin on the copies. You can set different width values for the each side of the paper.
- 7 [Shift]**
This mode enables you to make copies with the entire image shifted to the center or a corner. You can use the numeric keys to specify the location.
- 8 [Print Date]**
You can copy the date (day, month, and year) onto the output. You can specify the size, position, or direction of the date.
- 9 [Watermark]**
This mode enables you to copy a watermark and user-defined text onto the output. You can specify the size, position, or direction of the watermark.
- 10 [Page Numbering]**
You can copy with page numbers. You can also specify the size, position, or direction of the page number.
- 11 [Copy Set Numbering]**
This mode enables you to print copy set numbers. You can specify the size, position, or direction of the copy set number.
- 12 [Sharpness]**
This mode enables you to adjust image quality for copying. You can use this mode when you want to soften and sharpen text, lines, or the outline of the image.



Functions with this mark require an optional product(s).



- 1 [Print & Check]**
This mode enables you to confirm scanned images page by page before copying when you scan originals on the platen glass.
- 2 [Nega/Posi]**
This mode enables you to copy the original image with the hues and gradations inverted.
- 3 [Repeat Images]**
This mode enables you to repeatedly copy the entire original image in either the vertical or horizontal direction.
- 4 [Merge Job Blocks]**
This mode enables you to scan multiple batches of originals with different copy settings and copy them as one document.
- 5 [Print on Tab]**
This mode enables you to copy onto the tabs on tab paper.
- 6 [Area Designation]**
This mode enables you make copies of a designated area.
- 7 [Superimpose Image]**
This mode superimposes an image (image form) previously scanned, registers it in the memory of the machine, and then places it on the image of the original.
- 8 [Store in Mail Box]**
You can store the scanned originals in the User Inbox. The specified copy mode is also stored.
- 9 [Job Done Notice]**
Press to have the machine notify the user through e-mail when the copy job is done.
- 10 [Mirror Image]**
This mode enables you to copy the original image reversed, as if it were a reflection in a mirror.



Sending a Fax

This section describes the flow of basic fax operations.
An optional product is required to use the Fax function.


1

Placing Originals

Place the original on the feeder or the platen glass.

Placing originals in the feeder

Adjust the slide guides to fit the size of your originals. Neatly place your originals with the side to be copied face up.




Placing originals on the platen glass

Open the feeder/platen cover.



Place your originals face down.




Gently close the feeder/platen cover.

2


Selecting Function

Select [Fax] from the Main Menu screen.


Press [Fax].



Fax Basic Features screen is displayed.



You can set various facsimile functions. For more information, see from p. 32 to p. 35 in this manual.




- If a log in screen for Department ID Management or SSO-H appears, you must enter the applicable authentication information (ID, password/PIN). If the Copy Card Reader-F1 is attached, first insert a control card.
- If a login service, such as Department ID Management or SSO-H has been set, press (Log In/Out) to log out.
- The send settings for the last send job may be retained.
 - To cancel the settings, press (Reset).
 - The specified destinations are not retained.

3


Specify the destination.

Enter the fax number.

Enter the fax number using the numeric keys.



If you want to enter two or more fax numbers, press [OK] → enter the next destination.




You can specify the destination using the one-touch buttons or [Address Book]. For more information on storing the destination, see e-Manual > Fax.

4


Start Sending the Fax

After specifying the settings, press (Start).

Press (Start).




If the following screen appears, press (Start) to scan the next original. After all of the originals are scanned, press [Start Sending].




When sending is complete, remove your originals.

After a job is sent, the send settings may be retained except the specified destinations. To cancel the settings, press (Reset). To send other jobs with the same settings, specify destinations for the jobs as the destination specified for the previous job is not retained.




Things You Can Do with the Fax Functions

To use the Fax functions, press [Fax] on the Main Menu screen. This section describes the main functions on the Fax Basic Features screen. An optional product is required to use the Fax function.



Fax Basic Features Screen

- 1 [Details]**
You can check the detailed information for the destination selected from the Address Book. You can also change the new destination.
- 2 [Delete Dest.]**
You can delete the displayed destination.
- 3 [Tone]**
Press when you want to directly call an extension line that is connected to a PBX (Private Branch eXchange) which accepts only tone signals. If you press [Tone], the letter <T> appears.
- 4 [R]**
Press to use the R-key.
- 5 [To Remote Add. Book]**
You can specify destinations registered in the one-touch buttons of a server machine by accessing from a client machine on the network.
- 6 [Previous Settings]**
You can recall the three most recent destinations or fax settings. You can send a fax using the recalled destination or settings.
- 7 Resolution**
If the resolution is high, you can send fine text and images clearly. If the resolution is low, the data size becomes smaller and you can reduce the time it takes to send.
- 8 Scan Size**
You can select the original scanning size. If you press [Auto], the machine automatically recognizes the size of the original when scanning.
- 9 Register One-Touch Button**
Press to register destinations in one-touch buttons.
- 10 [Direct Send]**
Check that the recipient can receive the facsimile, and then start scanning the originals. You can directly send without storing the original in the memory.
- 11 [On-Hook]**
When using the fax information service, you can perform operation, such as entering number while listening to the automated audio response from the speaker of the machine.
- 12 [Address Book]**
Press to select a destination from the Address Book. You can also register frequently used destinations in the Address Book.
- 13 One-Touch Buttons**
Press to recall the destinations stored in a one-touch button.



Screen for Specifying the Fax Destination

1 [Pause]

Press to insert a pause of several seconds in the fax number that you are dialing. If you insert a pause, the letter <p> appears between the numbers, and the letter <P> appears at the end of the number. When dialing an overseas number, insert a pause after the country code, and at the end of the telephone number.

2 [Backspace]

Press when you enter an incorrect number to delete the number before the cursor.



Functions with this mark require an optional product(s).


3 [Set Details]

Displayed when multiple lines are set to be used. Press to set the subaddress and password, or to select the telephone line to use for transmission.

4 [Subaddress]


You can send or receive fax documents with increased security by attaching a subaddress and a password to your fax transactions.





Things You Can Do with the Fax Functions

This section describes the functions you can use on the [Options] (1/2 and 2/2) screen of the Fax function. The [Options] screen is divided into two screens. Pressing ▲ or ▼ on the bottom right of the screen displays the next or previous screen. An optional product is required to use the Fax function.




[Options] 1/2

- 1 **[Original Type]**
Image quality for scanning is adjusted according to the type of original, such as [Text], [Map], or [Photo].
- 2 **[2-Sided Original]**
Set to send two-sided originals. You can select [Book Type] or [Calendar Type].
- 3 **[Book 2 Pages]**
You can scan facing pages, such as in a book one sheet at a time.
- 4 **[Different Size Originals]**
You can scan originals of different size fed together in one group.
- 5 **[Erase Frame]**
This mode enables you to erase shadows that appear when scanning various types of originals. You can also erase shadows of the punch holes.
- 6 **[Direct Send]**
Check that the recipient can receive the facsimile, and then start scanning the originals. You can directly send without storing the original in the memory.
- 7 **[Select Line]**
You can select the telephone line to use for sending a facsimile.
- 8 **[Sender Name (TTI)]**
You can register a department name or personal name in advance, and show this on the destination fax machine.
* Set the Sender Name after specifying the destination.
- 9 **[Job Build]**
You can scan originals that are too many to be placed at once, by dividing them into multiple batches. After all originals are scanned, sending is started.
- 10 **[Density]**
Change the exposure. You can press ► to make the exposure darker or ◀ to make the exposure lighter. You can set the machine to automatically adjust the exposure.
- 11 **[Sharpness]**
This mode enables you to scan the originals with a sharper or softer contrast. You can use this mode when you want to soften and sharpen text, lines, or the outline of the image.
- 12 **[Copy Ratio]**
Specify the desired zoom ratios. You can change the zoom ratio by reducing/enlarging a scanned document to a preset paper size, or by entering a value to specify a desired scan ratio.



Functions with this mark require an optional product(s).



[Options] 2/2

- | | |
|---|--|
| <p>1 [Delayed Send]
This mode enables you to store a send job in memory, and have it sent at a later time.</p> | <p>3 [Finished Stamp]
You can print a stamp (approximately 3 mm in diameter) on the front side of scanned and sent originals.</p> |
| <p>2 [Preview]
This mode enables you to preview the scanned data of your originals and to check the page count before sending a fax. You can also delete a specified page.</p> | <p>4 [Job Done Notice]
Press to have the machine notify the user through e-mail when the fax job is done.</p> |

Sending Scanned Data (E-Mail/I-Fax/File Servers)

This section describes the flow of basic scan and send operations.


1

Placing Originals

Place the original on the feeder or the platen glass.

Placing originals in the feeder

Adjust the slide guides to fit the size of your originals. Neatly place your originals with the side to be copied face up.




Placing originals on the platen glass

Open the feeder/platen cover.



Place your originals face down.



Gently close the feeder/platen cover.

2


Selecting Function

Select [Scan and Send] from the Main Menu screen.


Press [Scan and Send].



Scan and Send Basic Features screen is displayed.



You can set various send functions. For more information, see from p. 38 to p. 41 in this manual.




- If a log in screen for Department ID Management or SSO-H appears, you must enter the applicable authentication information (ID, password/PIN). If the Copy Card Reader-F1 is attached, first insert a control card.
- If a login service, such as Department ID Management or SSO-H has been set, press (Log In/Out) to log out.
- The send settings for the last send job may be retained.
 - To cancel the settings, press (Reset).
 - The specified destinations are not retained.

3


Specify the Destination

Press [Address Book] → select destination → press [OK].

Press [Address Book].



If you are sending to only one destination, select a destination. If you are sending to multiple destinations, select the destinations → press [OK].



For more information on storing the destination in the address book, see e-Manual > Scan and Send.


You can specify the destination using the one-touch buttons or frequently used settings. Also, if you want to send to a new destination not yet stored, press [New Destination] → enter the destination.


4


Start Sending

After specifying the settings, press  (Start).


Press  (Start).



If the following screen appears, press  (Start) to scan the next original. After all of the originals are scanned, press [Start Sending].




When sending is complete, remove your originals.

After a job is sent, the send settings may be retained except the specified destinations. To cancel the settings, press  (Reset). To send other jobs with the same settings, specify destinations for the jobs as the destination specified for the previous job is not retained.


Things You Can Do with the Scan and Send Functions

To use the Send functions, press [Scan and Send] on the Main Menu screen. This section describes the main functions on the Scan and Send Basic Features screen.



Scan and Send Basic Features Screen

- 1 **[Address Book]**
Press to select a destination from the Address Book. You can also register frequently used e-mail, I-fax, or file server destinations in the Local Address Book.
- 2 **[One-Touch]**
If a frequently used destination is stored in a one-touch button, you can specify the destination quickly. Press [To Remote Add. Book] to specify destinations registered in the one-touch buttons of a server machine by accessing from a client machine on the network.
- 3 **[New Destination]**
Press to specify a new destination not stored in the Address Book or one-touch buttons.
- 4 **[Send to Myself]**
You can specify your own e-mail address as the destination. The administrator can restrict general users to send e-mail only to their addresses.
- 5 **[Specify Destinations]**
Press to display the methods for specifying destinations or the destination list.
- 6 **[Personal Folder]**
You can specify your personal folder as the destination. You need to specify settings before using personal folders. The administrator can restrict destination for file transmission to the operator's personal folder.




Scan and Send Basic Features Screen (Destination Set)



- 1 [Previous Settings]**
You can recall the three most recent destinations or send settings. You can send using the recalled destination or settings.
- 2 [Favorite Settings]**
You can register frequently used destination and settings. You can recall the registered frequently used settings for future use.
- 3 [Select Color]**
You can select the Full Color, Grayscale, or Black-and-White mode. You can also set the machine to automatically select a color mode according to the original.
- 4 [Resolution]**
If the resolution is high, you can send fine text and images clearly. If the resolution is low, the data size becomes smaller and you can reduce the time it takes to send.
- 5 [Scan Size]**
You can select the original scanning size. If you press [Auto Size], the machine automatically recognizes the size of the original when scanning.
- 6 [File Format]**
If you are sending to an e-mail address or file server, you can specify the file format. You can select from PDF, XPS, OOXML (pptx, docx), JPEG, or TIFF.
* Sending in OOXML format requires an optional product.
- 7 [Cc Bcc]**
In addition to the destination for the documents, you can specify e-mail address destinations for the Cc and Bcc addresses.
- 8 [Delete Dest.]**
You can delete the selected destination from the destination list.
- 9 [Details]**
You can check the detailed information for the destination selected from the destination list. You can also change the new destination.


Things You Can Do with the Scan and Send Functions

This section describes the functions you can use on the [Options] (1/2 and 2/2) screen of the Scan and Send function. The [Options] screen is divided into two screens. Pressing ▲ or ▼ on the bottom right of the screen displays the next or previous screen.



[Options] 1/2

- 1 **[Original Type]**
Image quality for scanning is adjusted according to the type of original, such as [Text], [Map], or [Photo].
- 2 **[2-Sided Original]**
Set to send two-sided originals. You can select [Book Type] or [Calendar Type].
- 3 **[Book ▶ 2 Pages]**
You can scan facing pages, such as in a book one sheet at a time.
- 4 **[Different Size Originals]**
You can scan originals of different size fed together in one group.
- 5 **[Erase Frame]**
This mode enables you to erase shadows that appear when scanning various types of originals. You can also erase shadows of the punch holes.
- 6 **[Copy Ratio]**
Specify the desired zoom ratios. You can change the zoom ratio by reducing/enlarging a scanned document to a preset paper size, or by entering a value to specify a desired scan ratio.
- 7 **[Sharpness]**
This mode enables you to scan the originals with a sharper or softer contrast. You can use this mode when you want to soften and sharpen text, lines, or the outline of the image.
- 8 **[Job Build]**
You can scan originals that are too many to be placed at once, by dividing them into multiple batches. After all originals are scanned, sending is started.
- 9 **[Density]**
Change the exposure. You can press  to make the exposure darker or  to make the exposure lighter. You can set the machine to automatically adjust the exposure.



[Options] 2/2

- | | |
|--|---|
| <p>1 [Delayed Send]
This mode enables you to store a send job in memory, and have it sent at a later time. You can specify from the current time to 23:59.</p> <p>2 [Preview]
This mode enables you to preview the scanned data of your originals and to check the page count before sending your document. You can also delete a specified page.</p> <p>3 [Finished Stamp]
You can print a stamp (approximately 3 mm in diameter) on the front side of scanned and sent originals.</p> <p>4 [Job Done Notice]
Press to have the machine notify the user through e-mail when the send job is done.</p> | <p>5 [E-Mail Priority]
You can set a priority level when sending e-mail.</p> <p>6 [Reply-to]
You can specify a reply-to address when sending an e-mail or I-fax.</p> <p>7 [Subject/Message]
You can specify a subject and enter a message when sending an e-mail or I-fax. If you do not specify a subject, it will be specified automatically.</p> <p>8 [File Name]
If you set PDF(OCR), XPS(OCR), or OOXML(OCR) as the file format, you can set [Auto (OCR)] to 'On' to automatically extract the first text block in the document for use as its filename.</p> |
|--|---|



Storing Scanned Data

This section describes the flow of basic Scan and Store operations. It also describes an example of how to store scanned data in a mail box.

1

Placing Originals

Place the original on the feeder or the platen glass.

Placing originals in the feeder

Adjust the slide guides to fit the size of your originals. Neatly place your originals with the side to be copied face up.




Placing originals on the platen glass

Open the feeder/platen cover.



Place your originals face down.



Gently close the feeder/platen cover.

2


Selecting Function

Select [Scan and Store] from the Main Menu screen.

Press [Scan and Store].



Select [Mail Box] from the screen where you can select the type of storage location.




- If a log in screen for Department ID Management or SSO-H appears, you must enter the applicable authentication information (ID, password/PIN). If the Copy Card Reader-F1 is attached, first insert a control card.
- If a login service, such as Department ID Management or SSO-H has been set, press (Log In/Out) to log out.

3

Select Storage

Specify the mail box that you want to store the file in.


Select the desired mail box.



You may need to enter a PIN when specifying the mail box.




Press [Scan].



The Scan screen is displayed.

You can set various scan functions. For more information, see from p. 44 to p. 45 in this manual.




4


Start Scanning

After specifying the settings, press (Start).

Press (Start).



If the following screen appears, press (Start) to scan the next original. After all of the originals are scanned, press [Start Storing].




When scanning is complete, remove your originals.



Things You Can Do with the Scan and Store Functions


To scan the original and store it, press [Scan and Store] on the Main Menu screen. This section describes the functions you can use on the Scan and Store Basic Features screen and the [Options] screen. If you press [Scan] after selecting the storage location, the screen below appears.



Scan Screen

- 1 [Select Color]**
You can select the Full Color or Black mode. You can also set the machine to automatically select a color mode according to the original.
- 2 [Resolution]**
If the resolution is high, you can store fine text and images clearly. If the resolution is low, the data size becomes smaller.
- 3 [Direct]/[Copy Ratio]**
This mode enables you to change the copy ratio by enlarging/reducing a copy to a preset paper size, or by entering a value to specify a desired copy ratio.
- 4 [Scan Size]**
You can select the original scanning size. If you press [Auto], the machine automatically recognizes the size of the original when scanning.
- 5 [File Format]**
You can set a file format, such as a PDF format to the scanned document so that it can be accessed from your computer.
- 6 [Favorite Settings]**
You can register frequently used scan settings. You can recall the registered frequently used settings for future use.
- 7 [Restore Default Set.]**
This mode is useful if you want to clear all settings and reset the settings. All settings are cleared.
- 8 [2-Sided Original]**
Set to scan two-sided originals. You can select [Book Type] or [Calendar Type].
- 9 [Density]**
Change the exposure. You can press to make the exposure darker or to make the exposure lighter. You can set the machine to automatically adjust the exposure.
- 10 [File Name]**
You can specify a file name for the data to be scanned.
- 11 [Original Type]**
Image quality for scanning is adjusted according to the type of original, such as [Text/Photo], [Map], [Printed Image], [Photo Printout], or [Text].

The available functions may differ, depending on the storage location.



[Options]

- 1 [Book ▶ 2 Pages]**
You can scan facing pages, such as in a book one sheet at a time.
- 2 [Booklet Scan]**
You can scan with booklet settings.
- 3 [N on 1]**
You can scan multiple pages of the original and reduce the size of the images to fit onto a single page. You can also change the order of the layout.
- 4 [Erase Frame]**
This mode enables you to erase shadows that appear when scanning various types of originals. You can also erase shadows of the punch holes.
- 5 [Sharpness]**
This mode enables you to adjust image quality for copying. You can use this mode when you want to soften and sharpen text, lines, or the outline of the image.
- 6 [Nega/Posi]**
This mode enables you to scan and record the original image by inverting the hues and gradations.
- 7 [Job Build]**
You can scan originals that are too many to be placed at once, by dividing them into multiple batches. After all originals are scanned, storing is started.
- 8 [Area Designation]**
This mode enables you to frame areas to scan/copy, or areas to blank out in the scanned image.
- 9 [Different Size Originals]**
You can scan originals of different size fed together in one group.

The available functions may differ, depending on the storage location.

Printing Stored Data


This section describes the flow of basic Access Stored Files operations. The procedure for printing files stored in a mail box is used here as an example.

1

Selecting Function

Select [Access Stored Files] from the Main Menu screen.

Press [Access Stored Files].




2


Select Storage

Specify the storage location for the file.


Select [Mail Box] from the Storage Selection screen.



Select the desired mail box.



You may need to enter a PIN when specifying the mail box.


- If a log in screen for Department ID Management or SSO-H appears, you must enter the applicable authentication information (ID, password/PIN). If the Copy Card Reader-F1 is attached, first insert a control card.
- If a login service, such as Department ID Management or SSO-H has been set, press  (Log In/Out) to log out.

3


Select File

Select the file that you want to print → press [Print].

Select the file to print.



Press [Print].




The Print screen is displayed.

4


Start Printing

After specifying the settings, press [Start Printing].

Press [Start Printing].



You can set various print settings on the screen displayed when [Change Print Settings] is pressed. For more information, see from p. 51 to p. 53 in this manual.



When printing is complete, the display returns to the Mail Box Selection screen.

Sending Stored Data


This section describes the flow of basic Access Stored Files operations. The procedure for sending a file stored in a mail box is used here as an example.

1

Selecting Function

Select [Access Stored Files] from the Main Menu screen.

Press [Access Stored Files].




2


Select Storage

Select [Mail Box].


Select [Mail Box] from the Storage Selection screen.



Select the desired mail box.



You may need to enter a PIN when specifying the mail box.


- If a log in screen for Department ID Management or SSO-H appears, you must enter the applicable authentication information (ID, password/PIN). If the Copy Card Reader-F1 is attached, first insert a control card.
- If a login service, such as Department ID Management or SSO-H has been set, press  (Log In/Out) to log out.

3


Select File

Select the file that you want to send → press [Send].

Select the file to send.



Press [Send].




4


Start Sending

Specify the destination → press [Start Sending].


Press [Address Book].




Select the destinations → press [OK].



Press [Start Sending].




You can set various send functions. For more information, see p. 54 to p. 55 in this manual.



Things You Can Do with the Access Stored Files Functions (File Operation)

To perform various operations on stored files, press [Access Stored Files] on the Main Menu screen. This section describes the functions you can use to edit files stored in a mail box. Select the file that you want to edit from the list of stored files, press [Edit File], and the following screen is displayed.



File Selection Screen


Edit File Screen

- 1 [Clear Selection]**
Press to cancel the selection of a file. For a mail box, if you cancel a selection, this switches to [Select All (Max 100 Files)].
- 2 List/Thumbnail**
Press to select view settings of the files stored in a mail box.
- 3 [Print List]**
You can print a list of files stored in a mail box.
- 4 [Print]**
Press to display the Print Settings screen.
- 5 [Send]**
Press to send a file stored in the mail box.
- 6 [Edit File]**
Press to display the menu for adding or deleting a file, or displaying the detailed information of a file.
- 7 [Display Image]**
This mode enables you to preview the stored file and check the page count.
- 8 [Details]**
You can check the detailed information of the stored file.
- 9 [Delete]**
You can delete stored files. You can erase unnecessary files and arrange the storage location.
- 10 [Merge Multiple Files]**
You can combine multiple files in the mail box into one file. Then you can print the combined files as one file.
- 11 [Insert Pages]**
You can insert a specified file from the mail box in front of the specified page of another file from the same mail box.
- 12 [Delete Pages]**
This mode enables you to erase specified page from a file that is stored in a mail box.
- 13 [Add Files (Scan and Store)]**
You can scan the original and store the new file in the selected storage location.
- 14 [Change File Name]**
You can change a file name.
- 15 [Move/Duplicate]**
You can move or duplicate files stored in the mail box.

The available functions may differ, depending on the storage location.

Things You Can Do with the Access Stored Files Functions (Print)

This section describes the functions on the Print Settings screen that you can use when printing stored files. If you select the file that you want to print from the list of stored files and press [Print], the following screen is displayed.




Print Screen

- 1 [Select Color]**
You can select color mode for printing.
- 2 [Select Paper]**
You can select the paper size/type and the paper source. You can also set the machine to automatically select the paper size to match the size of the stored original.
- 3 [Print Sample]**
You can check the print result of one set before making multiple sets of prints. You can also print a specified page.
- 4 [Restore Settings]/[Change Print Settings]**
You can change or restore the print settings.
- 5 [Favorite Settings]**
This mode enables you to register frequently used print settings. You can recall the registered frequently used settings for future use.
- 6 [Merge Files and Print]**
Press to merge multiple files and print as one file. This key is displayed only when multiple files are selected.
- 7 [Delete File After Printing]**
Press to have a file automatically deleted after it is printed.
- 8 [Restore Default Set.]**
Press to cancel all settings.
- 9 [Start Printing]**
Press to start printing.
- 10 [Change No. of Copies]**
Press to set the number of prints when multiple files are selected.
* Displayed only when print settings have not been changed.
- 11 [Store Settings]**
Press to store the print settings.
* Displayed only when using the Mail Box. Cannot be used when multiple files are selected.
- 12 [2-Sided Printing]**
This mode enables you to print successive pages of a stored file on both sides of a sheet of paper.
- 13 [Finishing]**
You can collate prints in page order or into groups of the same page. You can staple the printed sheets.
* To staple printed sheets, optional products are required.
- 14 Print Range**
You can set the print range using [All Pages] or [Specify Pages].

The available functions may differ, depending on the storage location.

Things You Can Do with the Access Stored Files Functions (Print)

This section describes the functions you can use on the [Options] (1/2 and 2/2) screen of the Access Stored Files function. The [Options] screen is divided into two screens. Pressing ▲ or ▼ on the bottom right of the screen displays the next or previous screen.




[Options] (Mail Box)

- 1 **[Add Cover]**
You can add covers.
- 2 **[Insert Sheets]/[Job Separator]**
Press to insert blank sheets or chapter pages between specified pages. When multiple files are selected, job separator sheets are inserted.
- 3 **[Booklet]**
You can layout the files to print a booklet. You can also print a cover sheet or make a saddle stitch booklet.
* To make a saddle stitch booklet, optional products are required.
- 4 **[Shift]**
You can shift the position of the image to print to the desired position.
- 5 **[Gutter]**
This mode enables you to print with the entire original image shifted by a designated width to create a margin on the prints. You can set different width values for the each side of the paper.
- 6 **[Print Date]**
This mode enables you to print the date onto the output. You can specify the size, position, or direction of the date.
- 7 **[Watermark]**
This mode enables you to print a watermark and user-defined text onto the output. You can specify the size, position, or direction.
- 8 **[Copy Set Numbering]**
This mode enables you to print copy set numbers. You can specify the size, position, or direction of the copy set number.
- 9 **[Page Numbering]**
You can print with page numbers. You can also specify the size, position, or direction of the page number.
- 10 **[Secure Watermark]**
You can embed hidden text, such as "CONFIDENTIAL" in the background of prints. The embedded text appears when the copies are printed, helping prevent unauthorized copying and information leakage.
- 11 **[Document Scan Lock]**
You can embed tracking information in prints. This increases security by preventing unauthorized copies.
- 12 **[Superimpose Image]**
This mode superimposes an image (image form) previously scanned, registers it in the memory of the machine, and then combines it with the file to print.
- 13 **[Print on Tab]**
Load tab paper in the multi-purpose tray or paper drawer 2, and you can print onto the tabs using the Print on Tab mode.
- 14 **[Adjust One-Touch Color]**
You can make prints by selecting the look of the image with just one touch of a key.
- 15 **[Color Balance]**
You can make fine adjustments to the color by varying the relative strength and density of yellow, magenta, cyan, and black. The color adjustments that you make can be stored and recalled for future use.



Functions with this mark require an optional product(s).



[Options]


(Advanced Box, the Advanced Box of Another Machine on the Same Network, Memory Media)

- 1 [Resolution]**
If the resolution is high, you can print fine text and images clearly.
- 2 [Halftones]**
You can select the adjustment methods to use when printing with halftones.
- 3 [Match Paper Size]**
You can enlarge/reduce a file image to match the paper size.
- 4 [Enlarge Print Area]**
You can set the blank borders at each side of the page to 0 mm, and print all the way to the edges of the page.
- 5 [Password to Open a Doc.]**
You can print password protected PDF files by entering the password required to open them.
- 6 [Print Comments]**
You can print the PDF file and all the comments.
- 7 [Booklet]**
This mode enables you to print documents in such a way that the prints are made into a booklet.
* To make a saddle stitch booklet, optional products are required.
- 8 [N on 1]**
You can scan a file with multiple pages and reduce the size of the pages to print onto a single page. You can also specify the order in which to print.
- 9 [Enlarge/Reduce]**
You can set the machine to enlarge or reduce data from JPEG or TIFF image files to fit the desired paper size.
- 10 [Print Position]**
You can select whether to print JPEG and TIFF image data centrally or in the top left, or specify to set the print position automatically.
- 11 [Image Orientation]**
You can set the machine to compare the size of JPEG and TIFF image data and automatically change the orientation of the image to fit the desired paper size, or you can specify the orientation of the image manually for printing.

The available functions may differ, depending on the file format.


Things You Can Do with the Access Stored Files Functions (Send)

This section describes things you can do when sending a file stored in a mail box, and the modes available on the [Options] screen. Select the file that you want to send from the list of stored files, press [Send], and the following screen is displayed. An optional product is required to use the Fax function.




Send Basic Features Screen (Access Stored Files)

- 1 [Address Book]**
Press to select a destination from the Address Book. You can also register frequently used e-mail, I-fax, file server, or fax destinations in the Local Address Book.
- 2 [One-Touch]**
If a frequently used destination is stored in a one-touch button, you can specify the destination quickly. Press [To Remote Add. Book] to specify destinations registered in the one-touch buttons of a server machine by accessing from a client machine on the network.
- 3 [New Destination]**
This mode enables you to specify a new destination not stored in the Address Book or one-touch buttons.
- 4 [Send to Myself]**
You can specify your own e-mail address as the destination. The administrator can restrict general users to send e-mail only to their addresses.
- 5 [Specify Destinations]**
Press to display the methods for specifying destinations or the destination list.
- 6 [Personal Folder]**
You can specify your personal folder as the destination. You need to specify settings before using personal folders. The administrator can restrict destination for file transmission to the operator's personal folder.



Screen for Specifying the Destination (Access Stored Files)

- 7 [Details]**
You can check the detailed information for the destination selected from the address list. You can also change a new destination.
- 8 File Format**
If you are sending to an e-mail address or file server, you can specify the file format. You can select from PDF, XPS, OOXML(pptx, docx), JPEG, or TIFF.
* The optional product is required to send OOXML format.
- 9 [Delete File After Sending]**
Press to delete certain pages from a file.
- 10 [Delete Dest.]**
Press to delete a destination displayed in the destination list.
- 11 [Cc Bcc]**
Press to specify e-mail address destinations for the Cc and Bcc addresses.
- 12 [Start Sending]**
Press to start sending.




[Options]

- 1 [Delayed Send]**
This mode enables you to store a send job in memory, and have it sent at a later time.
- 2 [Job Done Notice]**
Press to have the machine notify the user through e-mail when the send job is done.
- 3 [File Name]**
If you set PDF(OCR), XPS(OCR), or OOXML(OCR) as the file format, you can set [Auto (OCR)] to 'On' to automatically extract the first text block in the document for use as its file name.
- 4 [Sender Name (TTI)]**
You can register a department name or personal name in advance, and show this on the destination fax machine.
* [Set the Sender Name after specifying the destination.](#)
- 5 [E-Mail Priority]**
You can set a priority level when sending e-mail.
- 6 [Reply-to]**
You can specify a reply-to address when sending an e-mail or I-fax.
- 7 [Subject/Message]**
You can specify a subject and enter a message when sending an e-mail or I-fax. If you do not specify a subject, it will be specified automatically.

Operating the Machine from a Computer (Remote UI)


The Remote UI (User Interface) is preinstalled software in the machine that enables you to access the machine's functions by using your computer's Web browser. For example, the Remote UI enables you to access the machine to check job status, execute jobs, and specify various settings.



To be able to use the Remote UI, all you need is a Web browser and a network connection between your computer and the machine.

The Remote UI Is Useful in the Following Situations:

- If you want to check the job status
- If you want to edit Address Book from your computer
- If you want to check the remaining amount of paper or toner from your seat




■ To enable the Remote UI:

- Log in as the administrator → specify the following settings.
 1. Press (Settings/Registration).
 2. Press [Management Settings] → [License/Other] → [Remote UI].
 3. Press [On] → [OK].
 4. Turn OFF the main power of the machine, and then turn ON the main power again.
- The [Remote UI] setting is made effective only after turning the machine's main power OFF, and then ON. For instructions on turning ON/OFF the machine, see p.12 in this manual.

1 Accessing the Remote UI from a Web Browser.

Access the Remote UI from a Web browser.


Enter the IP address of the machine in the address bar of the Web browser.



Press [ENTER] on the keyboard.

To login as the administrator, enter the System Manager ID and System PIN → click [Administrator Login].

To login as a general user, click [General User Login].



If the Log In screen is displayed, enter the user name and password → click [Log In].


If a login service, such as Department ID Management or SSO-H has been set, enter the appropriate login information.

2 Checking the Job Status and Specifying the Settings.

Check the job status and specify the settings.


To check the job status:

Click [Status Monitor/Cancel].



To specify the settings:

Click [Settings/Registration].



Printing from a Computer

If you install a printer driver in your computer, you can use the machine to print data created using application software. This section describes the flow of basic operations to print data from your computer.


1

Display Print Settings Screen

Select [Print] from the [File] menu.

From the [File] menu in the application software, click [Print].

The print dialog box is displayed.




2


Display Properties Screen of Printer Driver

Select the printer to use.

Select the printer to use in [Printer] → click [Properties].



The properties screen of the printer driver appears.



The default setting for [Print Style] is [2-sided printing]. However, for some driver versions, [1-sided printing] is the default setting.

- Printing methods may differ, depending on the applications you are using. For details, see the instruction manuals provided with the application software.
- The screens may differ, depending on the operating system, and the type and version of the printer driver you are using.

3

Specify Print Settings


Specify the print settings.

4



Start Printing

After specifying the settings, click [OK].


Specify the desired settings → click [OK].



To display detailed descriptions for each print setting, click [Help] on the bottom right of the Properties screen.



Click [OK].



When printing is complete, collect the output.

The print job status can be checked from the Remote UI. For more information, see p. 57 in this manual.



Routine Maintenance

Loading Paper 62

Loading Paper into a Paper Drawer.....	62
Adjusting a Paper Drawer to Hold a Different Paper Size.....	65
Loading Pre-Punched Paper	67
Loading Transparencies	67
Loading Paper into the Paper Deck Unit-B2 (Optional)	68

Loading Tab Paper Using the Tab Feeding Attachment Kit-B1 (Optional)..... 70

Loading Envelopes Using the Envelope Feeder Attachment-D1 (Optional)..... 73

How to Use the Envelope Feeder Attachment-D1	73
Preparing the Envelopes	74
Loading Envelopes	75
Loading the Envelope after Specifying the Size	76

Replacing the Stamp Cartridge (Feeder) (Optional) 80

Duplex Color Image Reader Unit-E1	80
Color Image Reader Unit-F1.....	83

Replacing the Staple Cartridge (For Optional Products) 85

Replacing the Staple Cartridge in the Stapler Unit (Staple Finisher-J1/Booklet Finisher-J1).....	85
Replacing the Staple Case in the Saddle Stitcher Unit (Booklet Finisher-J1)	87
Replacing the Staple Cartridge (Inner Finisher-E1).....	89

Removing Punch Waste (External 2 Hole Puncher-B2/External 2/3 Hole Puncher-B2/External 2/4 Hole Puncher-B2) 91

Replacing the Toner Cartridge..... 93

Replacing the Waste Toner Container 99

Routine Cleaning..... 102

Platen Glass and Underside of the Feeder/Platen Cover	102
Manual Feeder Cleaning	103
Automatic Feeder Cleaning	109
Cleaning the Inside of the Main Unit.....	110
Cleaning the Dust Proof Glass	111

Consumables 113



Loading Paper

This section describes how to load paper.

Loading Paper into a Paper Drawer

If the selected paper runs out, or the selected paper drawer runs out of paper during printing, a screen prompting you to load paper appears on the touch panel display.

Follow the procedure below to load paper into the paper drawers.



CAUTION

When handling paper, take care not to cut your hands on the edges of the paper.



IMPORTANT


- A screen prompting you to load paper also appears if the selected paper drawer is not fully inserted into the machine. Make sure that the paper drawer is properly in place.
- Do not load the following types of paper into the paper drawers. Doing so may cause a paper jam.
 - Severely curled or wrinkled paper
 - Thin straw paper
 - Heavy 3 (221 to 256 g/m²)
 - Paper which has been printed on using a thermal transfer printer
 - The reverse side of paper which has been printed on using a thermal transfer printer
- Make sure that you fan the sheets of paper well before placing them. Thin paper, recycled paper, pre-punched paper, heavy paper, and transparencies should be fanned particularly well before loading it.
- Never place paper or any other items in the empty part of the drawer next to the paper stack. Doing so may cause paper jams.
- When you are printing in the Staple mode, do not remove the output sheets that are waiting to be stapled. (Printing and stapling resume after you clear the paper jam.)



NOTE


- Register the size and type of the loaded paper in [Paper Settings] in [Preferences] (Settings/Registration).
- You can use custom paper sizes. For more information, see e-Manual > Settings/Registration.
- You can name, register, and edit custom paper types. For more information, see e-Manual > Settings/Registration.
- The following paper sizes can be loaded into Paper Drawers 1, 2, 3, and 4:
 - Paper Drawer 1: A4, A4R, A5R, and Custom size (139.7 mm x 182 mm to 304.8 mm x 390 mm)
 - Paper Drawer 2: 305 mm x 457 mm, A3, A4, A4R, A5R, Tab, envelopes, and Custom size (139.7 mm x 182 mm to 304.8 mm x 457.2 mm)
 - Paper Drawers 3 and 4: 305 mm x 457 mm, A3, A4, A4R, A5R, and Custom size (139.7 mm x 182 mm to 304.8 mm x 457.2 mm)
 - Tab paper can be loaded into Paper Drawer 2 only if the Tab Feeding Attachment Kit-B1 is attached.
 - Envelopes can be loaded into Paper Drawer 2 only if the Envelope Feeder Attachment-D1 is attached.
 - Paper Drawers 3 and 4 are available for use only if the Cassette Feeding Unit-AD2 is attached.
- For more information on the paper types that can be loaded in Paper Drawers 1, 2, 3, and 4, see e-Manual > Basic Operations.
- If a message prompting you to load paper appears during printing, the remaining prints are automatically made after you load the correct paper. If you select a different paper source, the remaining prints are made after you press [OK].
- Press [Cancel] to cancel printing.

1

Open the paper drawer.

1. Press the open button on the paper drawer in which you want to load paper.
2. Grip the handle, and pull out the paper drawer until it stops.

2


Prepare the paper to load.

Open the packaging for the paper, and remove the paper stack.

**NOTE**

- For high-quality printouts, use paper recommended by Canon.
- Before loading paper, always fan the sheets several times, and align the edges to facilitate feeding.

3



Load the paper stack into the paper drawer.

1. Make sure that the paper size plate of the paper drawer matches the size of the paper loaded in the paper drawer.
2. Load the paper stack against the right wall of the paper drawer.
3. Gently push the paper drawer back into the machine until it clicks into place in the closed position.

**CAUTION**


When returning the paper drawer to its original position, be careful not to get your fingers caught, as this may result in personal injury.

IMPORTANT

- Paper which is curled must be straightened out before loading it into the paper deck unit.
- You will not be able to make copies or print if you load paper that exceeds the loading limit mark () , or if the paper drawer is not completely pushed into the machine.
- Make sure that the height of the paper stack does not exceed the loading limit mark () .
- Always check that the paper drawers are in place.

NOTE

- When loading paper into the paper drawer for the first time, set the paper size dial to match the paper size being loaded. (See "Adjusting a Paper Drawer to Hold a Different Paper Size," on p. 65.)
- The number of sheets that can be loaded in the paper drawers is 550 sheets (80 g/m²).
- If there are instructions on the paper package about which side of the paper to load, follow those instructions.
- When the paper is loaded into the paper drawer, the side facing up is the one printed on.
- If problems, such as poor print quality or paper jams occur, try turning the paper stack over and reloading it.
- For more information on the print direction of preprinted paper (paper which has logos or patterns already printed on it), see e-Manual > Copy.
- Rewrap any remaining paper in its original package, and store it in a dry place, away from direct sunlight.
- If paper runs out and printing is stopped, load a new paper stack. Printing restarts after the new paper stack is loaded.



- If you print on the paper which has absorbed moisture, steam may come out from the output area of the machine. This is because the moist on the paper evaporates when the high temperature is applied when a toner is fixed to the paper. It is not a malfunction. (This especially happens in low room temperature.)

Adjusting a Paper Drawer to Hold a Different Paper Size

If you want to load a different size paper into a paper drawer, follow the procedure described below to adjust the paper drawer guides.



CAUTION

When handling paper, take care not to cut your hands on the edges of the paper.




NOTE

Only the paper drawers can be adjusted to hold different paper sizes.

Adjusting a Paper Drawer

1


Remove the paper loaded in the paper drawer.



1. Press the open button on the paper drawer for which you want to adjust the paper size.
2. Grip the handle, and pull out the paper drawer until it stops.
3. Remove all of the remaining paper.

2

Adjust the position of the paper drawer guides.



1. Slide the left guide while squeezing it on the top to align it with the mark for the desired paper size.
2. Slide the front guide while squeezing it on the top to align it with the mark for the desired paper size.




IMPORTANT

Slide the guides until they click into place. If the left guide and front guide are not aligned correctly, the paper size will not correctly appear on the touch panel display. It is also necessary to adjust the guides correctly to avoid causing a paper jam, dirty prints, or making the inside of the machine dirty.

3


Load the appropriate size paper into the paper drawer.



1. Make sure that the paper size setting of the paper drawer matches the size of the paper to load in the paper drawer.
2. Load the paper stack against the right wall of the paper drawer.

4

Change the paper drawer's paper size plate to match the new paper size.



1. Open the inside cover of the paper drawer, and lift up the plate.
2. Rotate the plate so that the new paper size is on the right side of the plate.
3. Insert the plate straight down, and close the inside cover.



NOTE

The paper size that cannot be used depending on the model and settings is also listed on the paper size plate.

5

Gently push the paper drawer back into the machine until it clicks into place in the closed position.



CAUTION

When returning the paper drawer to its original position, be careful not to get your fingers caught, as this may result in personal injury.



IMPORTANT

Only A4 transparencies can be used. Make sure that the left guide is set to 'A4' when loading transparencies in a paper drawer. If transparencies of a different size (other than A4) are loaded in a paper drawer, the paper size and remaining amount of paper will not be detected correctly.

Loading Envelopes into the Multi-Purpose Tray

Feeding direction into the multi-purpose tray differs, depending on the type of the envelopes. Preparation is required beforehand to prevent wrinkling or paper jam.

For more information, see e-Manual > Basic Operations.

Loading Pre-Punched Paper

You can load pre-punched paper in the multi-purpose tray, paper deck, or paper drawers. When loading prepunched paper, take note of the orientation of the binding holes and the image.

When the paper is loaded into the multi-purpose tray, the side facing down is the one printed on.



IMPORTANT

If you want to output prints with the printed face down, select plain paper with horizontal (landscape) orientation in [Select Paper]. (See e-Manual > Copy.)

Loading Transparencies

You can load transparencies in the multi-purpose tray and the paper drawers.

Transparencies have a front and back side. Load transparencies correctly to achieve sharp printing results.

When the paper is loaded into the multi-purpose tray, the side facing down is the one printed on.



IMPORTANT

- You can load only A4 size transparencies.
- When loading transparencies, make sure to hold only the edges of the sheets and avoid touching the print surface.
- Do not load transparencies while the machine is printing. Doing so may cause a paper jam.
- Use only transparencies intended for use with this machine. If you use other transparencies, you may cause damage to the machine.
- It is recommended that output transparencies are immediately removed from the output tray to avoid folding of the transparencies and paper jams.
- Return the remaining transparencies to their original package for storage, avoiding locations subject to high temperatures and humidity. Leaving transparencies loaded for an extended period of time may cause the sheets to stick together and result in a paper jam.
- Leaving transparencies loaded for an extended period of time may cause the sheets to stick together and result in difficulties feeding the transparencies. In this case, fan the loaded transparency sheets, or if you have loaded 50 or more sheets, reduce the number of sheets to less than 50 or use new transparencies.
- When printing on transparencies, depending on the type of image, the image may become dense. When this happens, adjust the density for the output image.



NOTE

If a paper jam occurs, fan the loaded transparency sheets well.

Loading Paper into the Paper Deck Unit-B2 (Optional)

If there is no paper in the paper deck unit when you select it, or the paper deck unit runs out of paper during printing, a screen prompting you to load paper appears on the touch panel display. Follow the procedure below to load paper into the paper deck unit.



CAUTION

When handling paper, take care not to cut your hands on the edges of the paper.



IMPORTANT

The Paper Deck Unit-B2 can only accommodate paper from 52 to 163 g/m² in weight. Use the multi-purpose tray to load paper that is heavier.

- If paper runs out and printing is stopped when you are printing in the Staple mode, do not remove the output sheets that are waiting to be stapled. (Printing and stapling resume after you clear the paper jam.)




NOTE

- Paper Deck Unit-B2 is an optional product.
- Only load A4 paper into the Paper Deck Unit-B2. Paper cannot be loaded horizontally.
- If a message prompting you to load paper appears during printing, the remaining prints are automatically made after you load the correct paper. If you select a different paper source, the remaining prints are made after you press [OK].

1

Open the paper deck unit.



1. Press the open button.
2. Open the paper deck unit.

The inside lifter automatically descends to the paper loading position.




NOTE

If the machine is in the Sleep mode (the touch panel is not displayed, and only Ⓜ (Energy Saver) is lit), you may be unable to open the paper deck unit. In this case, press Ⓜ (Energy Saver) to reactivate the machine, and then press the open button on the paper deck unit.

2

Prepare the paper to load.




Open the packaging for the paper, and remove the paper stack.



NOTE

- For high-quality printouts, use paper recommended by Canon.
- Before loading paper, always fan the sheets several times, and align the edges to facilitate feeding.

3

Load the paper stack into the paper deck unit.

1. Load the paper stack against the back left guide of the paper deck unit.
2. Close the paper deck unit.

When the paper deck unit is closed, the inside lifter automatically ascends, and the machine becomes ready for printing.

**CAUTION**


When closing the paper deck unit, be careful not to get your fingers caught, as this may result in personal injury.

**IMPORTANT**

- Do not load the following types of paper into the paper deck unit. Doing so may cause a paper jam.
 - Severely curled or wrinkled paper
 - Thin straw paper
 - Transparencies
 - Paper which has been printed on using a thermal transfer printer (Do not print on the reverse side of this paper either.)
- Paper which is curled must be straightened out before loading it into the paper deck unit.
- You will not be able to make copies or print if you load paper that exceeds the loading limit mark (), or if the paper drawer is not completely pushed into the paper deck unit.
- Make sure that the height of the paper stack does not exceed the loading limit mark ().
- Always check that the paper deck unit is closed.

**NOTE**

- The paper deck unit holds up to 2,700 sheets of paper (80 g/m²).
- Load the paper stack in stages, adding approximately 500 sheets of paper at a time. If the paper deck unit can accommodate more paper, the lifter will descend.
- If there are instructions on the paper package about which side of the paper to load, follow those instructions.
- When the paper is loaded into the paper deck unit, the side facing down is the one printed on.
- If problems, such as poor print quality or paper jams occur, try turning the paper stack over and reloading it.
- For more information on the print direction of preprinted paper (paper which has logos or patterns already printed on it), see e-Manual > Copy.
- Rewrap any remaining paper in its original package, and store it in a dry place, away from direct sunlight.
- If paper runs out and printing is stopped, load a new paper stack. Printing restarts after the new paper stack is loaded.





Loading Tab Paper Using the Tab Feeding Attachment Kit-B1 (Optional)

This section describes how to load tab paper in Paper Drawer 2 using the Tab Feeding Attachment Kit-B1.



IMPORTANT

Only A4 Tab Paper can be used.




NOTE

- When you load tab paper, make sure to register the paper type. (See e-Manual > Settings/Registration.)
- If you want to insert printed tab paper as a chapter page, insert a blank paper where the tab paper will be inserted.




Open the drawer.



1. Press and release the button on Paper Drawer 2.
2. Grip the handle, and pull out the paper drawer until it stops.




Attach the Tab Feeding Attachment Kit-B1 to Paper Drawer 2.




1. Place the Tab Feeding Attachment Kit-B1 into the holes of the paper drawer.
2. Push it in as far as possible.

3


Load the tab paper into the paper drawer.



Load the tab paper face up with the tabs to the left side, as shown in the illustration below.




IMPORTANT

- Paper which has been rolled or curled must be straightened out prior to use.
- Make sure that the height of the paper stack does not exceed the limit mark () at the back of the paper drawer.

4


Squeeze the lever on the front guide, as shown in the illustration. While squeezing the lever, slide the front guide until it fits the tab paper.



* Front Guide

5

Gently push the paper drawer back into the machine until it clicks into place in the closed position.



CAUTION

When returning the paper drawer to its original position, be careful not to get your fingers caught, as this may result in personal injury.



IMPORTANT

- Never place paper or any other items in the open part of the paper drawer next to the paper stack. Doing so may cause a paper jam.
- When you are not loading tab paper, make sure to remove the Tab Feeding Attachment Kit-B1 from the paper drawer. Using the Tab Feeding Attachment Kit-B1 for storing paper other than tab paper may cause a paper jam.



Loading Envelopes Using the Envelope Feeder Attachment-D1 (Optional)

This section explains how to use the Envelope Feeder Attachment-D1.



IMPORTANT

The Envelope Feeder Attachment-D1 can only be attached to Paper Drawer 2.

How to Use the Envelope Feeder Attachment-D1

The following types of envelopes can be loaded into the Envelope Feeder Attachment-D1: No. 10(COM10), Monarch, DL, and ISO-C5.

The setting of the machine and guide size is set to No. 10(COM10) as the default setting.



IMPORTANT

- When you attach the Envelope Feeder Attachment-D1 to the paper drawer, do not forcefully move the front guide of the paper drawer in the wrong direction. Doing so may detach the Envelope Feeder Attachment-D1 from the paper drawer.
- Do not print on both sides of an envelope. Doing so may cause paper jams, dirty prints, or make the inside of the machine dirty.
- Do not load the following types of envelopes inside the envelope cassette. Doing so may cause paper jams, dirty prints, or make the inside of the machine dirty.
 - Curled, creased, or folded envelopes
 - Very thick or thin envelopes
 - Damp or wet envelopes
 - Torn envelopes
 - Irregularly shaped envelopes
 - Envelopes with clasps or windows
 - Envelopes that have already been sealed
 - Envelopes with holes or perforations
 - Envelopes with specially coated surfaces
 - Envelopes made of surface treated colored paper
 - Envelopes that are self-sticking, which use ink, glue, or other substances that can melt, burn, vaporize, or emit smells under the heat of a fixing unit (approximately 200°C). Depending on the materials used for the seal, the glue may melt under the fixing unit's heat, sealing the envelopes.
- When the envelope cassette is attached and envelope is selected for the paper type, the envelope is ejected to the tray under the scanner unit.
- If you are printing on envelopes, empty the output tray when up to 10 printed envelopes accumulate in the tray.
- Envelopes should be stored in a place away from high-temperatures and humidity.
- If there is a temperature difference between the location where the envelopes are stored and the location where the envelopes are being printed, leave the envelopes in the printing location at room temperature before you use them.
- Correctly match the paper size dial, size switch, and [Register Envelope Drawer] in [Preferences] (Settings/Registration) with the size of the envelopes being loaded. Failure to do so may cause paper jams, dirty prints, or make the inside of the machine dirty.
- If you want to adjust the width guides to load ISO-C5 envelopes, contact your local authorized Canon dealer.



NOTE

- For more information on envelope types that can be loaded in the Envelope Feeder Attachment-D1, see e-Manual > Basic Operations.
- Sizes of the envelopes are as follows:
 - No.10(COM10): 104.7 mm × 241.3 mm
 - Monarch: 98.4 mm × 190.5 mm
 - DL: 110 mm × 220 mm
 - ISO-C5: 162 mm × 229 mm

Preparing the Envelopes

This section explains how to prepare the envelopes before loading them into the paper drawer.




IMPORTANT

Using curled, creased, or folded envelopes may cause paper jams. Load envelopes after following the procedure below.

1

Neatly align the envelopes.




1. Place the envelopes on a clean, level surface, and press all the way around the envelopes by hand, in the direction of the arrows, to remove any curls.

Repeat this step five times for each set of five envelopes.

2

Hold down the four corners of the envelopes firmly, so that they and the sealed or glued portion stay flat.



* Flap



IMPORTANT


- If you use envelopes that have glue attached to their flaps, the glue may melt due to the heat and pressure of the fixing unit.
- Take particular care to spread the envelopes out in the direction that they will be fed.
- Do not print on the back side of the envelopes (the side with the flap).
- If the envelopes become filled with air, flatten them by hand before loading them into the Envelope Feeder Attachment-D1.

Loading Envelopes

This section explains how to load envelopes into Paper Drawer 2.

1


Open the drawer.



1. Press and release the button on Paper Drawer 2.
2. Grip the handle, and pull out the paper drawer until it stops.


2

Load the envelopes into the drawer.



1. Load 10 envelopes at a time with the side you want to print on facing up. While loading the envelopes, press down on the left side of the receptacle to lock them into place.
2. Align the leading edges of the envelopes, and make sure that they are held in place under the claws.

Load the envelopes as shown below.




IMPORTANT

- Envelopes which have been rolled or curled must be straightened out prior to use.
- Make sure that the height of the envelope stack does not exceed the height limit mark (↑↑↑).
- The maximum height (quantity) of envelopes that can be loaded into the cassette is approximately 30 mm.
- The maximum height (quantity) of envelopes varies, depending on the envelope type and user operating conditions, but as a reference, 30 mm is approximately 50 envelopes.

3

Gently push the paper drawer back into the machine until it clicks into place in the closed position.



CAUTION

When returning the paper drawer to its original position, be careful not to get your fingers caught, as this may result in personal injury.



IMPORTANT

Never place paper or any other items in the empty part of the paper drawer next to the envelopes. Doing so may cause paper jams.



NOTE

If output has been stopped due to an insufficient number of envelopes, load more envelopes, and follow the instructions on the touch panel display. Printing resumes.

Loading the Envelope after Specifying the Size

This section explains how to load the envelopes that are specified in Settings/Registration into the envelope cassette.




IMPORTANT

Make sure that you change the envelope settings from the Settings/Registration screen before carrying out the following procedure. (See e-Manual > Settings/Registration.) Otherwise, the machine may not recognize the changes you have made.

1


Open the drawer.



1. Press and release the button on Paper Drawer 2.
2. Grip the handle, and pull out the paper drawer until it stops.

2


Remove the drawer and envelopes.



1. Pull and lift the paper drawer out of the machine by holding its left and right sides with both hands.
2. Remove the envelopes that are loaded in the paper drawer (several envelopes at a time).

3


Slide the left guide to align it with the mark for the desired envelope size.



* Left Guide

4


Adjust the front guide.



1. Loosen the two screws fixing the front width guide of the envelope feeder attachment.
2. Press down on the envelope receptacle, and move the front width guide to align it with the mark for the desired envelope size.
3. Fix the front width guide in place with the screws.


5

Adjust the rear width guide in the same way as in step 4.




6

Load the envelopes.



1. Load 10 envelopes at a time with the side you want to print on facing up. While loading the envelopes, press down on the left side of the receptacle to lock them into place.
2. Align the leading edges of the envelopes, and make sure that they are held in place under the claws.

Load the envelopes as shown below.



IMPORTANT

- Envelopes which have been rolled or curled must be straightened out prior to use.
- Make sure that the height of the envelope stack does not exceed the height limit mark (↑↑↑).
- The maximum height (quantity) of envelopes that can be loaded into the cassette is approximately 30 mm.
- The maximum height (quantity) of envelopes varies, depending on the envelope type and user operating conditions, but as a reference, 30 mm is approximately 50 envelopes.



NOTE

For details on how to change the registered envelope information for the drawer, see e-Manual > Settings/Registration.



Insert the drawer.

1. Gently push the paper drawer back into the machine until it clicks into place in the closed position.
2. Check the paper size dial, and then register the envelope size in Settings/Registration.

For details on how to register envelope sizes, see e-Manual > Settings/Registration.



CAUTION

When returning the paper drawer to its original position, be careful not to get your fingers caught, as this may result in personal injury.



IMPORTANT

Never place paper or any other items in the empty part of the paper drawer next to the envelopes. Doing so may cause paper jams.



NOTE

If output has been stopped due to an insufficient number of envelopes, load more envelopes, and follow the instructions on the touch panel display. Printing resumes.



Replacing the Stamp Cartridge (Feeder) (Optional)

Originals sent via the feeder can be stamped to indicate that they have been sent. Replace the stamp cartridge when the stamp mark is faint or no longer visible.



CAUTION

When replacing the stamp cartridge, take care not to allow ink to come into contact with your hands or clothing. If ink gets onto your hands or clothing, wash it off immediately with cold water.




NOTE

The feeder is an optional product.

Duplex Color Image Reader Unit-E1


1

Open the feeder.



2

Pull the lever above the feeder, and open the document scan cover.




IMPORTANT

Open the document scan cover carefully, as not to scratch the platen glass.


3

Open the stamp cover.




4

Remove the old stamp cartridge.



5

Push in the new stamp cartridge until it clicks.




IMPORTANT

- Insert the stamp cartridge so that it is not slanted.
- Insert the stamp cartridge properly, or paper jams may occur.

6

Close the stamp cover.




CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

7

Close the cover of the document scanning area until it clicks.




CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

8

Close the feeder.


**CAUTION**

- When closing the feeder, be careful not to get your fingers caught, as this may result in personal injury.
- Be aware that the light emitted from the platen glass may be very bright when closing the feeder.

Color Image Reader Unit-F1

1


Open the covers.



1. Pull the lever → open the feeder cover.
2. Open the inner cover, holding it by its tab.

2

Load the stamp cartridge.



1. Remove the old stamp cartridge, using tweezers.
2. Push in the new stamp cartridge until it clicks, using tweezers.




IMPORTANT

- Make sure that the stamp cartridge is not protruding from the surface.
- Insert the stamp cartridge properly, or paper jams may occur.

3

Close the covers.



1. Close the inner cover.
2. Close the feeder cover.



CAUTION

When closing the covers, be careful not to get your fingers caught, as this may result in personal injury.



Replacing the Staple Cartridge (For Optional Products)

This section describes how to replace the staple case and staple cartridge in the stapler unit and saddle stitcher unit.



NOTE



- The Staple Finisher-J1, Booklet Finisher-J1, and Inner Finisher-E1 are optional products.
- We recommend that you order staple cartridges from your local authorized Canon dealer before your stock runs out.
- Use only staple cartridges intended for use with this machine.

Replacing the Staple Cartridge in the Stapler Unit (Staple Finisher-J1/Booklet Finisher-J1)

When the Staple Finisher-J1 or Booklet Finisher-J1 is almost out of staples and the staple cartridge in the stapler unit must be replaced, a screen prompting you to replace the staple cartridge appears on the touch panel display. Follow the procedure described below to replace the staple cartridge.

1

Open the front cover of the finisher.





*1 Booklet Finisher-J1

*2 Staple Finisher-J1


2

Pull out the staple case, holding it by the green tab.



3


Pull out the empty staple cartridge from the staple case.



1. Press the areas indicated by **PUSH** on both sides of the staple case.
2. Once you have released the spring-loaded case, pull out the staple cartridge.

4

Insert a new staple cartridge into the staple case.



1. Insert a new staple cartridge.
2. Press the spring-loaded case down until it clicks into place.
3. Remove the seal holding the staples together, by pulling it straight out.




IMPORTANT

- Do not remove the seal that holds the staples together before you place the staple cartridge into the staple case.
- Only one staple cartridge can be inserted at a time.
- Make sure that you pull the seal straight out. If you pull it out at an angle, it may tear.

5

Gently push the staple case back into the finisher and push down firmly until it is securely in place.



6

Close the front cover of the finisher.**CAUTION**

When closing the front cover of the finisher, be careful not to get your fingers caught, as this may result in personal injury.

**NOTE**

After the cover is closed, the stapler unit may automatically perform a "dry" stapling operation to reposition the staples.

Replacing the Staple Case in the Saddle Stitcher Unit (Booklet Finisher-J1)


When the saddle stitcher unit of the Booklet Finisher-J1 is almost out of staples and the staple case must be replaced, a screen prompting you to replace the staple case appears on the touch panel display. Follow the procedure described below to replace the staple case.

**IMPORTANT**

If necessary, remove all output paper in the booklet tray before replacing the staple cartridge of the saddle stitcher unit.


**NOTE**

- This procedure is necessary only if the Booklet Finisher-J1 is attached (the Booklet Finisher-J1 is an optional product).
- We recommend that you order staple cases from your local authorized Canon dealer before your stock runs out.
- Use only staple cases intended for use with this machine.
- Remove the black part on the end before inserting the staple case.




1

Open the front cover of the finisher.



2

Pull out the saddle stitcher unit, and then push the stapler unit up.




*1 Stapler Unit
*2 Saddle Stitcher Unit

1. Grip the handle of the saddle stitcher unit, and pull out until it stops.
2. Pull the stapler unit of the saddle stitcher unit towards you, and then push it up.

3

Insert the new staple case.



1. Pull out the empty staple case, holding it by its left and right sides.
2. Push the new staple case in until it clicks into place.




NOTE

- Only one staple case can be inserted at a time.
- When replacing the staple cases, replace both the front and back staple cases.

4

Push the saddle stitcher unit back into its original position.



1. Pull the stapler unit of the saddle stitcher unit towards you, and then push it down into its original position.
2. Grip the handle of the saddle stitcher unit, and return it to its original position.



CAUTION

When pushing the saddle stitcher unit back into its original position, be careful not to get your fingers caught, as this may result in personal injury.

5

Close the front cover of the finisher.



CAUTION

When closing the front cover of the finisher, be careful not to get your fingers caught, as this may result in personal injury.



IMPORTANT


When you have replaced the staple case, be sure to manually reposition the staples in the saddle stitcher unit. (See e-Manual > Settings/Registration.)

Replacing the Staple Cartridge (Inner Finisher-E1)

When the Inner Finisher-E1 is almost out of staples and the staple cartridge must be replaced, a screen prompting you to replace the staple cartridge appears on the touch panel display. Follow the procedure described below to replace the staple cartridge.

1


Pull out the staple case from the finisher.



1. Open the front cover of the finisher.
2. Lift and pull out the staple case from the stapler unit, holding it by the green tab.

2


Pull out the empty staple cartridge from the staple case.



1. Press the areas indicated by **PUSH** on both sides of the staple case.
2. Once you have released the spring-loaded case, pull out the staple cartridge.

3

Insert a new staple cartridge into the staple case.



1. Insert a new staple cartridge.
2. Press the spring-loaded case down until it clicks into place.
3. Remove the seal holding the staples together, by pulling it straight out.




IMPORTANT

- Do not remove the seal that holds the staples together before you place the staple cartridge into the staple case.
- Only one staple cartridge can be inserted at a time.
- Make sure that you pull the seal straight out. If you pull it out at an angle, it may tear.

4

Attach the staple case to the finisher.



1. Gently push the staple case back into the finisher and push down firmly until it is securely in place.
2. Close the front cover of the finisher.



CAUTION

When closing the front cover of the finisher, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

After the cover is closed, the stapler unit may automatically perform a "dry" stapling operation to reposition the staples.



Removing Punch Waste (External 2 Hole Puncher-B2/External 2/3 Hole Puncher-B2/External 2/4 Hole Puncher-B2)

This section describes how to remove punch waste from the puncher.

When the punch waste tray of the Puncher becomes full, a screen prompting you to remove the punch waste appears on the touch panel display. Follow the procedure described below to remove the punch waste.




NOTE

- The External 2 Hole Puncher-B2/External 2/3 Hole Puncher-B2/External 2/4 Hole Puncher-B2 is an optional product.
- The External 2 Hole Puncher-B2/External 2/3 Hole Puncher-B2/External 2/4 Hole Puncher-B2 is available only when the Staple Finisher-J1 or Booklet Finisher-J1 is attached.

Pull out the punch waste tray.


1



1. Open the front cover of the puncher.
2. Pull out the punch waste tray.

Discard the punch waste.

2




NOTE

Make sure that the punch waste tray is completely emptied.

3

Return the punch waste tray to its original position.



1. Push the punch waste tray back into its original position.
2. Close the front cover of the puncher.



CAUTION


When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.




NOTE

If the punch waste tray is not securely in place, you cannot make copies or prints in the Hole Punch mode.


⇒ Replacing the Toner Cartridge

When the message <Replace toner cartridge. (Black)> is displayed on the touch panel display, press  on the bottom right and replace the toner cartridge for the displayed color.



When the Black toner or all of the toners run out completely and prints can no longer be made, a screen with instructions on how to replace the toner cartridge appears on the touch panel display. Follow the procedure described below to replace the toner cartridge.

If you press [Close], you can continue operations, such as setting modes and scanning originals, even if you do not replace the toner cartridge immediately.



WARNING

- Do not burn or throw used toner cartridges into open flames, as this may cause the toner to ignite, resulting in burns or a fire.
- If you accidentally spill or scatter toner, carefully gather the toner particles together or wipe them up with a soft, damp cloth in a way that prevents inhalation. Never use a vacuum cleaner that does not have safeguards against dust explosions to clean up spilled toner. Doing so may cause a malfunction in the vacuum cleaner, or result in a dust explosion due to static discharge.



CAUTION

- Keep toner out of the reach of small children.
- If toner is ingested, consult a physician immediately.
- If toner gets onto your hands or clothing, wash it off immediately with cold water. Washing it off with warm water will set the toner, and make it impossible to remove the toner stains.



IMPORTANT

- Use only toner cartridges intended for use with this machine.
- For information on the supported Canon genuine toner, see "Consumables," on p. 113.
- Do not replace toner cartridges until the message prompting you to do so appears.
- You can replace a toner cartridge while the machine is printing.
- The color of the toner to be replaced is displayed on the touch panel display. If multiple toner cartridges must be replaced, replace the toner cartridges in the following order: Black, Yellow, Magenta, Cyan.
- If you continue copying or printing in black-and-white after cyan, magenta, or yellow toner runs out, do not remove the depleted toner cartridges from the machine.
- You can display an error message informing the user that the remaining toner is low. For instructions on displaying the remaining toner error message, see e-Manual > Settings/Registration. For instructions on deleting the remaining toner error message, see e-Manual > Settings/Registration.



NOTE

- Complete instructions on how to replace the toner cartridge can be accessed by pressing [Previous] or [Next] on the touch panel display.
- If toner runs out during a print job, the remaining prints are made after you replace the toner cartridge.
- If black toner is left, you can continue copying and printing in black-and-white. However, if a job is interrupted because cyan, magenta, or yellow toner runs out, copying and printing in black-and-white is only possible for functions other than the function being used for the interrupted job.
- After replacing toner cartridges, if printed colors are different from the colors printed before you replaced the toner cartridges, perform an [Auto Adjust Gradation] in [Adjustment/Maintenance] (Settings/Registration). (See e-Manual > Settings/Registration.)



Press [].




NOTE

If the Black toner or all of the toners run out, this step is not necessary.




Open the toner replacement cover holding both sides.




3

Select the color of the toner you want to replace from the display on the control panel → press [Remove Toner Cartridges].




If the toner with content remaining is selected, the message <The selected toner can still be used. Do you want to replace it?> is displayed. If you want to continue replacement, press [Yes]. If you do not want to replace the toner, press [No].



4

Wait for the internal cover to open automatically, and pull the toner cartridge out of the toner supply port.



*1 Black Toner Cartridge

*2 Cyan, Magenta, or Yellow Toner Cartridge

If the internal cover does not automatically open because of reasons such as closing of the toner replacement cover, an error message is displayed. Repeat the procedure from step 1.




WARNING

Do not burn or throw used toner cartridges into open flames, as this may cause the toner remaining inside the cartridges to ignite resulting in burns or a fire.




IMPORTANT

- Do not open the internal cover by force, as doing so may damage the machine.
- Never touch the tip of the toner cartridge or subject it to shock by hitting it. Doing so may cause the toner cartridge to leak.




5

Prepare the new toner cartridge.




6

Hold the new toner cartridge in your hands, as shown below, and gently tilt it up and down 10 times.




7

Twist the red protective cap of the new toner cartridge in the direction of the arrow to remove it.



8

Push the new toner cartridge in as far as possible.



*1 Black Toner Cartridge

*2 Cyan, Magenta, or Yellow Toner Cartridge





IMPORTANT

When replacing toner cartridges, make sure that the color of the toner cartridge matches the color of label on the internal cover.

9

Close the internal cover.



*1 Black Toner Cartridge

*2 Cyan, Magenta, or Yellow Toner Cartridge

If the toner cartridge is not inserted, you cannot close the internal cover.





CAUTION

When closing the internal cover, be careful not to get your fingers caught, as this may result in personal injury.

10

Close the toner replacement cover.



The toner confirmation screen is displayed.



CAUTION

When closing the toner replacement cover, be careful not to get your fingers caught, as this may result in personal injury.



Replacing the Waste Toner Container

When the waste toner container nears capacity, a message appears on the touch panel display. In this case, you should prepare a new waste toner container.

When the waste toner container is full, a screen with instructions on how to replace the waste toner container appears on the touch panel display. Follow the procedure described below to replace the waste toner container.

Even if you do not replace the waste toner container immediately, you can perform printing for a while. The number of prints you can make depends on the content you print.

However, if you continue printing, an error will occur and you will become unable to print.



WARNING

- **Do not burn or throw used waste toner containers into open flames. Also, do not store waste toner containers in places exposed to open flames, as this may cause the toner to ignite, resulting in burns or a fire.**
- **If you accidentally spill or scatter toner, carefully gather the toner particles together or wipe them up with a soft, damp cloth in a way that prevents inhalation. Never use a vacuum cleaner that does not have safeguards against dust explosions to clean up spilled toner. Doing so may cause a malfunction in the vacuum cleaner, or result in a dust explosion due to static discharge.**



CAUTION

- **If toner is ingested, consult a physician immediately.**
- **If toner gets onto your hands or clothing, wash it off immediately with cold water. Washing it off with warm water will set the toner, and make it impossible to remove the toner stains.**



IMPORTANT

- Your local authorized Canon dealer will dispose of used waste toner containers.
- Used toner cannot be reused. Do not mix new and used toner together.
- Use only waste toner containers intended for use with this machine.
- Do not replace the waste toner container before the message prompting you to replace it appears on the touch panel display.
- When attaching the waste toner container, make sure to push it in all the way. If the container is not pushed in all the way when you remove it, it may come out with its shutter open. Since this may cause toner to fly out, close the shutter with your hand.




NOTE

- Complete instructions on how to replace the waste toner container can be accessed by pressing [Previous] or [Next] on the touch panel display.
- If the waste toner container must be replaced during a print job, the remaining prints are made after the new waste toner container is installed.

1


Open the front cover of the machine.



1. Open the front cover, holding both sides.
2. Lower the locking lever.

2

Remove the waste toner container.




CAUTION

When removing the waste toner container, be careful not to tilt it, as the toner may spill and get onto your hands or clothing. If toner gets onto your hands or clothing, wash them immediately with cold water. Washing them with warm water will set the toner, and make it impossible to remove the toner stains.

3

Put the removed waste toner container into a bag, and then tie it up at the top to prevent the toner remaining inside the cartridge from scattering.




NOTE

Use a bag in the box in which the new waste toner container is stored.


4

Insert the new waste toner container.



5

Close the front cover of the machine.



1. Return the locking lever to its original position.
2. Close the front cover of the main unit.



CAUTION

When closing the front cover of the machine, be careful not to get your fingers caught, as this may result in personal injury.



Routine Cleaning

If the original is not copied clearly or streaks appear on printed output, clean the following parts of the machine. For high-quality printouts, we recommend cleaning these parts once or twice a month.

- Platen glass
- Underside of the feeder/platen cover
- Feeder's rollers
- Inside of the main unit
- Dust proof glass



WARNING

- When cleaning the machine, first turn OFF the main power switch, and disconnect the power cord. Failure to observe these steps may result in a fire or electrical shock.
- Disconnect the power cord from the power outlet regularly, and clean the area around the base of the power plug's metal pins and the power outlet with a dry cloth to ensure that all dust and grime is removed. If the power cord is connected for a long period of time in a damp, dusty, or smoky location, dust can build up around the power plug and become damp. This may cause a short circuit and result in a fire.



IMPORTANT

- When cleaning with a cloth, do not dampen it too much, as this may damage the original or break the machine.
- Do not use alcohol, benzene, paint thinner, or other solvents for cleaning. Doing so may result in damage to the plastic parts.



NOTE


The feeder is an optional product.

Platen Glass and Underside of the Feeder/Platen Cover

If the platen glass or the underside of the feeder/platen cover is dirty, the original may not be scanned clearly, or the size of the original may be detected incorrectly. Clean the platen glass and the underside of the feeder/platen cover by following the procedure below.



Clean the platen glass and the underside of the feeder/platen cover with a cloth which is wrung after being dampened in water, and then wipe them clean with a soft, dry cloth.



1. Clean the platen glass.
2. Clean the underside of the feeder/platen cover.



NOTE

If stains won't come out, use detergent instead of water.

Manual Feeder Cleaning

If originals that have been fed through the feeder have streaks or appear dirty, clean the feeder's rollers. Clean the rollers of the feeder with a cloth which is wrung after being dampened in water, and then wipe them clean with a soft, dry cloth.




IMPORTANT

- Spin the rollers while cleaning them.
- If the document feed scanning area is dirty, documents may not be scanned clearly, and the size of the document may not be detected correctly.

Duplex Color Image Reader Unit-E1


1

Open the feeder.




2

Clean the original scanning area (thin glass strip).



3

Pull the lever above the feeder, and open the document scan cover.





IMPORTANT

Open the document scan cover carefully, as not to scratch the platen glass.



4

Open the inside cover.





5

Clean the feed scanning area (thin glass strip).



6


Close the inside cover.



CAUTION


When closing the inside cover, be careful not to get your fingers caught, as this may result in personal injury.

7

Close the document scan cover.**CAUTION**

When closing the document scan cover, be careful not to get your fingers caught, as this may result in personal injury.


8

Close the feeder.**CAUTION**

- When closing the feeder, be careful not to get your fingers caught, as this may result in personal injury.
- Be aware that the light emitted from the platen glass may be very bright when closing the feeder.
- Do not dampen the cloth too much, as this may damage the original or break the machine.

1


Clean the rollers of the feeder.



1. Pull the lever, and open the feeder cover.
2. Clean the rollers (a total of three places) inside the feeder cover.

2


Clean the rollers inside the inner cover.



1. Open the inner cover, holding it by its tab.
2. Clean the rollers (a total of three places) inside the inner cover.

3

Clean the transparent plastic area on top of the inner cover.



1. Clean the plastic area.
2. Close the inner cover.




CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

4


Clean the feed scanning area (thin glass strip).



1. Open the feeder.
2. Clean the feed scanning area.

5

Clean the resin roller and the surrounding area.



1. Turn the resin roller while turning the feed dial.
2. Clean the area while turning the resin roller.
3. Close the feeder.




CAUTION

When closing the feeder, be careful not to get your fingers caught, as this may result in personal injury.

6

Close the feeder cover.



CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

Automatic Feeder Cleaning

If your originals have black streaks or appear dirty after scanning them through the feeder, perform an automatic feeder cleaning for the rollers of the feeder.

1

Press  (Settings/Registration).

2

Press [Adjustment/Maintenance] → [Maintenance] → [Clean Feeder].

3

Place 10 sheets of blank paper into the feeder → press [Start].

It takes approximately 20 seconds to clean the feeder.

Use normal A4 size paper.

When cleaning is complete, try scanning again.



NOTE

- Feeder Cleaning cannot be performed during printing.
- To cancel feeder cleaning while it is in progress, press [Cancel].

Cleaning the Inside of the Main Unit

If streaks appear on printed output, or random parts of the printed image are missing, the inside of the main unit may be dirty. In this case, clean the inside of the main unit, as described below.

1

Press  (Settings/Registration).

2

Press [Adjustment/Maintenance] → [Maintenance] → [Clean Inside Main Unit].

3

Press [Start].


When cleaning is complete, try printing again.

Cleaning the Dust Proof Glass

If the dust proof glass is dirty, print defects may occur on the print output. Follow the procedure described below to clean the dust proof glass.


1

Open the front cover, holding both sides.



2

Remove the dust proof glass cleaner from the rear side of the front cover by sliding it to the left side.




* Dust Proof Glass Cleaner

3

Hold the dust proof glass cleaner so that the pad on the tip is facing down, push it back as far as it goes, and then slowly move it up and down.

Clean the four locations as shown below. There are marks on the main unit that indicate the cleaning locations. Check these marks when cleaning the dust proof glass.




4

When you have finished cleaning the dust proof glass, gently push the dust proof glass cleaner back onto the rear side of the front cover.

Place the dust proof glass cleaner back on the rear side of the front cover with its tip facing the left direction.

5

Close the front cover of the main unit.



CAUTION

When closing the front cover of the main unit, be careful not to get your fingers caught, as this may result in personal injury.



Consumables

The following consumables are available from Canon. For more information, contact your local authorized Canon dealer. We recommend that you order paper stock and toner from your local authorized Canon dealer before your stock runs out.

Recommended Paper

In addition to plain paper (A3, B4, A4, and B5 size), recycled paper, color paper, transparencies (recommended for this machine), tracing paper, labels, and other types of paper stock are available.



CAUTION

Do not store paper in places exposed to open flames, as this may cause the paper to ignite, resulting in burns or a fire.



IMPORTANT

- Some commercially available paper types are not suited for this machine. Contact your local authorized Canon dealer when you need to purchase paper.
- To prevent moisture build-up, tightly wrap any remaining paper in its original package for storage.



NOTE

For high-quality printouts, use paper recommended by Canon.

Toner

If a message prompting you to replace the toner cartridge appears on the touch panel display, replace the used toner cartridge with a new one.


Toner comes in four colors: black, cyan, magenta, and yellow.

Check the toner color that you need to replace before ordering toner from your local authorized Canon dealer. Also, when replacing the toner cartridge, make sure that you replace toner of the correct color.

Use only toner cartridges intended for use with this machine.

For optimum print quality, using Canon genuine toner is recommended.

Contact your local authorized Canon dealer to obtain new Canon genuine toner.



*1 Black Toner Cartridge

*2 Cyan, Magenta, or Yellow Toner Cartridge



WARNING

- Do not burn or throw used toner cartridges into open flames, as this may cause the toner remaining inside the cartridges to ignite, resulting in burns or a fire.
- Do not store toner cartridges in places exposed to open flames, as this may cause the toner to ignite, resulting in burns or a fire.
- If you accidentally spill or scatter toner, carefully gather the toner particles together or wipe them up with a soft, damp cloth in a way that prevents inhalation. Never use a vacuum cleaner that does not have safeguards against dust explosions to clean up spilled toner. Doing so may cause a malfunction in the vacuum cleaner, or result in a dust explosion due to static discharge.



CAUTION

Keep toner out of the reach of small children. If toner is ingested, consult a physician immediately.



IMPORTANT


- Store toner cartridges in a cool location, away from direct sunlight. (The recommended storage conditions are temperatures below 30°C, and humidity below 80%.)
- [Be careful of counterfeit toners]

Please be aware that there are counterfeit Canon toners in the marketplace. Use of counterfeit toner may result in poor print quality or machine performance. Canon is not responsible for any malfunction, accident or damage caused by the use of counterfeit toner.

For more information, see <http://www.canon.com/counterfeit>.



Stamp Cartridge

The stamp cartridge is used to stamp originals. Use the tweezers provided to remove and replace the stamp cartridge.



Stamp Ink Cartridge-C1

Staple Cartridge

Finisher	Staple Cartridge	
	Name	Shape
Booklet Finisher-J1	Staple Cartridge-D2	
	Staple Cartridge-D3	
Staple Finisher-J1 Booklet Finisher-J1 Inner Finisher-E1	Staple-J1	



MEMO

Troubleshooting

Clearing Paper Jams 118

Locations of Paper Jams	119
Main Unit	121
Paper Sources	124
Feeder (Optional)	132
Staple Finisher-J1/Booklet Finisher-J1 (Optional)	137
Booklet Finisher-J1 (Optional)	141
Inner Finisher-E1 (Optional)	145
Inner 2 Way Tray-F1 (Optional)	147
Copy Tray-J1 (Optional)	148

Reducing the Frequency of Paper Jams 149

Clearing Staple Jams (For Optional Products). 150

Locations of Staple Jams	150
Staple Finisher-J1/Booklet Finisher-J1	151
Saddle Stitcher Unit of the Booklet Finisher-J1	153
Inner Finisher-E1	156

If Memory Becomes Full During Scanning 158

For the Copy Function	159
For the Fax/Scan and Send Function	159
For the Scan and Store Function	159

When an Error Message Is Displayed 160

When an Error Code Is Displayed 161

Printer/Fax Driver Troubleshooting 162

Service Call Message 163


Contacting Your Local Authorized Canon Dealer	164
Setting the Limited Functions Mode from the Service Call Message Screen	166
Functions Available When the Printer/Scanner Cannot Be Used Due to an Error	168

Frequently Asked Questions 170



Clearing Paper Jams

If a paper jam occurs, a screen indicating the location of the paper jam and how to clear the jam appears on the touch panel display. Follow the instructions on the screen to clear the paper jam. The screen is displayed repeatedly until the paper jam is cleared. If you press [Close], you can continue operations, such as setting modes or scanning originals, even if the jammed paper is not removed immediately.



WARNING

Some areas inside the machine are subject to high-voltages. When removing jammed paper or when inspecting the inside of the machine, do not allow necklaces, bracelets, or other metal objects to touch the inside of the machine, as this may result in burns or electrical shock.



CAUTION

- When removing jammed originals or paper, take care not to cut your hands on the edges of the originals or paper. If you cannot remove the paper, contact your local authorized Canon dealer.
- When removing paper which has become jammed inside the machine, take care not to allow the toner on the jammed paper to come into contact with your hands or clothing, as this will dirty your hands or clothing. If they become dirty, wash them immediately with cold water. Washing them with warm water will set the toner, and make it impossible to remove the toner stains.
- When removing paper which has become jammed inside the machine, remove the jammed paper gently to prevent the toner on the paper from scattering and getting into your eyes or mouth. If the toner gets into your eyes or mouth, wash them immediately with cold water and immediately consult a physician.
- The fixing unit and its surroundings inside the machine may become hot during use. When removing jammed paper or when inspecting the inside of the machine, do not touch the fixing unit and its surroundings, as doing so may result in burns or electrical shock.
- After clearing all paper jams, remove your hands from the machine immediately. Even if the machine is not in operation, your hands, hair, or clothing may get caught in the feed rollers, which could result in personal injury or damage if the machine suddenly starts printing.



IMPORTANT

- If a paper jam occurs in the feeder, you cannot continue operating the machine. Follow the directions on the touch panel display to clear the paper jam. (See "Feeder (Optional)," on p. 132.)
- Some areas that are shown to have paper jams may not actually have paper jams. However, always check all locations indicated on the touch panel display in the order that is given.
- If a paper jam occurs and printing is stopped when you are printing in the Staple mode, do not remove the paper from the areas except those which are shown to have paper jams on the touch panel display. For example, if paper is jammed in the main unit, do not remove the output sheets on the finisher which does not have paper jams. (Printing and stapling resume after you clear the paper jam in the main unit.)




NOTE

If paper is jammed in several locations, remove the jammed paper in the order indicated on the touch panel display.


Locations of Paper Jams

Paper jams may occur in the following parts of the machine. See the applicable section to clear the paper jam.


Copy Tray-J1 (Optional) (p. 148)




Paper Drawer 1 (p. 124)
Paper Drawer 2 (p. 126)




Main Unit (p. 121)




Cassette Feeding Unit-AD2
(Optional) (p. 127)




Paper Deck Unit-B2 (Optional)
(p. 129)




External 2 Hole Puncher-B2/External
2/3 Hole Puncher-B2/External 2/4 Hole
Puncher-B2 (p. 139)




Inside the Top Cover (p. 138)



Buffer Pass Unit-G1 (p. 139)




Inside the Front Cover (p. 141)



Saddle Stitcher Unit (p. 143)




Inner 2 Way Tray-F1 (Optional) (p. 147)



Feeder (Optional) (p. 132)



Inner Finisher-E1 (Optional) (p. 145)



Main Unit

Check the location of the paper jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed paper.




NOTE

- If the Paper Deck Unit-B2 is attached, move the paper deck away from the main unit before proceeding with this procedure.
- If paper is loaded in the multi-purpose tray, remove the loaded paper.
- If the Copy Tray-J1 is attached to the main unit, remove all output paper from the tray.


1

Remove any paper jammed from the multi-purpose tray.



2


Open the lower right and upper right covers of the machine.



1. Grip the handle, and open the lower right cover of the machine.
2. Open the upper right cover of the machine.

3

Remove any jammed paper from the output unit.



1. Open the paper output unit.
2. Remove any jammed paper.
3. Push the output unit back into its original position.




IMPORTANT

The paper output unit can be opened up to 40 degrees. Forcefully opening the paper output unit may damage the machine.

4


Remove any jammed paper from the entrance of the duplexing unit.



1. Remove any jammed paper in the upper part of the duplexing unit.
2. Remove any jammed paper in the lower part of the duplexing unit.

5

Remove any jammed paper from the fixing unit.



1. Pull down the upper cover of the fixing unit by its tab.
2. Remove any jammed paper.
3. Close the upper cover of the fixing unit.



CAUTION

The fixing unit and its surroundings inside the machine may become hot during use. When removing jammed paper or when inspecting the inside of the machine, do not touch the fixing unit and its surroundings, as doing so may result in burns or electrical shock.




NOTE

If you cannot remove the jammed paper, return the upper cover of the fixing unit back to its original position, and then remove the jammed paper from the lower part of the fixing unit.


6

Remove any jammed paper from the duplex unit.




7

Remove any jammed paper from the multi-purpose tray.



8

Remove any jammed paper located between the main unit and lower right cover, if paper jam occurs during reversing.



9

Close the upper right cover and then close the lower right cover.



CAUTION

When closing the upper and lower right covers of the main unit, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

- Gently close the covers until they click into place in the closed position.
- If the Paper Deck Unit-B2 was moved away from the main unit, reconnect it to the main unit.

10

Follow the instructions on the screen.



NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Paper Sources

Check the location of the paper jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed paper.



NOTE

- The Cassette Feeding Unit-AD2 and Paper Deck Unit-B2 are optional products.
- If paper is loaded in the multi-purpose tray, remove the loaded paper.

Paper Drawer 1




NOTE

- If the Paper Deck Unit-B2 is attached, move the paper deck unit away from the main unit before proceeding with this procedure.
- If the Copy Tray-J1 is attached to the main unit, remove all output paper from the tray.




Open the lower right and upper right covers of the machine.



1. Grip the handle, and open the lower right cover of the machine.
2. Open the upper right cover of the machine.




Remove any jammed paper.



3

Remove any paper jammed in Paper Drawer 1.



1. Press and release the button on Paper Drawer 1.
2. Grip the handle, and pull out Paper Drawer 1 until it stops.
3. Remove any jammed paper.



IMPORTANT

Gently pull out the paper drawer. Jammed paper may tear, resulting in damage to the machine.

4

Gently push Paper Drawer 1 back into the machine until it clicks into place in the closed position.



CAUTION

When returning the paper drawer to its original position, be careful not to get your fingers caught, as this may result in personal injury.

5

Gently close the machine's upper right cover followed by the lower right cover until they click into place.



CAUTION

When closing the right cover of the main unit, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

- Gently close the covers until they click into place in the closed position.
- If the Paper Deck Unit-B2 was moved away from the main unit, reconnect it to the main unit.

6

Follow the instructions on the screen.



NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Paper Drawer 2




NOTE

If the Paper Deck Unit-B2 is attached, move the paper deck unit away from the main unit before proceeding with this procedure.

1


Remove any paper jammed in the paper drawer's upper right cover.



1. Open the paper drawer's upper right cover, holding it by its handle.
2. Remove any jammed paper.

2

Remove any paper jammed in Paper Drawer 2.



1. Press and release the button on Paper Drawer 2.
2. Grip the handle, and pull out paper drawer 2 until it stops.
3. Remove any jammed paper.

3

Gently push Paper Drawer 2 back into the machine until it clicks into place in the closed position.




CAUTION

When returning the paper drawer to its original position, be careful not to get your fingers caught, as this may result in personal injury.

4

Close the paper drawer's upper right cover.



CAUTION

When closing the right cover of the paper drawer, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

- Gently close the covers until they click into place in the closed position.
- If the Paper Deck Unit-B2 was moved away from the main unit, reconnect it to the main unit.

5

Follow the instructions on the screen.



NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Cassette Feeding Unit-AD2 (Optional)




NOTE

If the Paper Deck Unit-B2 is attached, move the paper deck unit away from the main unit before proceeding with this procedure.

1


Open the paper drawer's upper right cover and lower right cover.



1. Open the paper drawer's upper right cover.
2. Open the paper drawer's lower right cover.

2


Remove any paper jammed in the paper drawer's upper right cover and lower right cover.



1. Remove any paper jammed in the paper drawer's upper right cover.
2. Remove any paper jammed in the paper drawer's lower right cover.

3

Close the covers.



1. Close the paper drawer's upper right cover.
2. Close the paper drawer's lower right cover.



CAUTION

When closing the covers, be careful not to get your fingers caught, as this may result in personal injury.




NOTE

Gently close the covers until they click into place in the closed position.

4

Remove any paper jammed in the cassette feeding unit.



1. Press the open button of the paper drawer that is feeding the paper.
2. Grip the handle, and pull out the paper drawer until it stops.
3. Remove any jammed paper.

5

Gently push the paper drawer back into the machine until it clicks into place in the closed position.



CAUTION

When returning the paper drawer to its original position, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

If the Paper Deck Unit-B2 was moved away from the main unit, reconnect it to the main unit.

6

Follow the instructions on the screen.




NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Paper Deck Unit-B2 (Optional)

1


Move the paper deck unit away from the main unit.



1. Press the release button.
2. Move the paper deck unit away from the main unit.

2

Remove any paper jammed in the side of the paper deck unit.



1. Hold down the green lever on the side of the paper deck unit.
2. Remove any jammed paper, while holding down the green lever.

Paper can also be jammed in the feeding slot on the side of the main unit. Remove any jammed paper from the feeding slot.

3

Reconnect the paper deck unit to the main unit.

If the paper jam message is no longer displayed when you reconnect the paper deck unit, proceed to step 7.




CAUTION

When reconnecting the paper deck unit to main unit, be careful not to get your fingers caught, as this may result in personal injury.

4

Open the paper deck unit.



1. Press the open button.
2. Open the paper deck unit.

The inside lifter automatically descends to the paper loading position.




NOTE

If the machine is in the Sleep mode (the touch panel is not displayed, and only (Energy Saver) is lit), you may be unable to open the paper deck unit. In this case, press (Energy Saver) to reactivate the machine, and then press the open button on the paper deck unit.

5

Remove any jammed paper.



Look carefully, as jammed paper may be difficult to see.

6

Close the paper deck unit.



CAUTION

When closing the paper deck unit, be careful not to get your fingers caught, as this may result in personal injury.

7

Follow the instructions on the screen.



NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Feeder (Optional)

Check the location of the paper jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed original.




NOTE

The feeder is an optional product.

Duplex Color Image Reader Unit-E1


1

Remove originals from the original supply tray.



2


Pull the lever, and open the feeder cover.



3


Remove any jammed original.

If there is difficulty in removing jammed original, do not try to remove it forcibly, and proceed to step 4.




4

Turn the green tab in the direction of the arrow (counterclockwise), and remove the jammed original from the output tray.



5

Close the feeder cover.




CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.


6

Open the feeder, and remove any jammed paper.



7

Close the feeder.



CAUTION

- When closing the feeder, be careful not to get your fingers caught, as this may result in personal injury.
- Be aware that the light emitted from the platen glass may be very bright when closing the feeder.

8

Follow the instructions on the screen.




NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Color Image Reader Unit-F1

1


Remove originals from the original supply tray.



2

Remove any original jammed in the feeder cover.


If there is difficulty in removing jammed original, do not try to remove it forcibly, and proceed to step 3.



1. Pull the lever, and open the feeder cover.
2. Remove any jammed original.


3

Open the inner cover, holding it by its front tab.




4

Turn the feed dial inside the feeder cover in the direction of the arrow (clockwise), and remove any original jammed in the feeder cover.




5

Turn the feed dial in the direction of the arrow (counterclockwise), and remove any original jammed in the inner cover.



6


Remove any original jammed in the output tray.



1. Lift up the original supply tray.
2. Turn the feed dial in the direction of the arrow (counterclockwise), and remove the jammed original.

7

Close the feeder cover.



1. Close the inner cover.
2. Close the feeder cover.




CAUTION

When closing the covers, be careful not to get your fingers caught, as this may result in personal injury.

8

Remove any paper jammed in the feeder.



1. Open the feeder.
2. Remove any jammed original.
3. Close the feeder.



CAUTION

When closing the feeder, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

If it is difficult to remove the jammed paper, turn the feed dial counterclockwise.

9

Follow the instructions on the screen.



NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Staple Finisher-J1/Booklet Finisher-J1 (Optional)

Check the location of the paper jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed paper.




NOTE

The Staple Cartridge-D2, Booklet Finisher-J1, and Buffer Pass Unit-G1 are optional products.

1

Remove any jammed paper protruding from the output part.



1. Lift up the output slot.
2. Remove any jammed paper that is visible.

If you cannot see any paper, check whether there is any jammed paper in the output area.




NOTE

If a paper jam occurs when you are printing in the Staple mode, do not remove the output sheets that are waiting to be stapled. (Printing and stapling resume after you clear the paper jam.)

2

Open the top cover of the finisher, and remove any jammed paper.



*1 Booklet Finisher-J1
*2 Staple Finisher-J1

1. Open the top cover of the finisher.
2. Remove any jammed paper.
3. Close the top cover of the finisher.



CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

3

Follow the instructions on the screen.




NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

1

Remove any jammed paper from the buffer pass unit.



1. Open the buffer pass unit.
2. Remove any jammed paper.
3. Close the buffer pass unit.



CAUTION

When closing the buffer pass unit, be careful not to get your fingers caught, as this may result in personal injury.

2

Follow the instructions on the screen.




NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

External 2 Hole Puncher-B2/External 2/3 Hole Puncher-B2/External 2/4 Hole Puncher-B2


1

Open the front cover of the puncher waste tray.




2

Align the pointed notch on the knob within the shaded region (▲).



3

Remove any jammed paper from the top cover of the puncher.




1. Open the top cover of the puncher.
2. Remove any jammed paper.

If you cannot remove the jammed paper, remove it from below.

4

Open the top cover of the finisher, and remove any jammed paper.



*1 Booklet Finisher-J1

*2 Staple Finisher-J1

1. Open the top cover of the finisher.
2. Remove any jammed paper.
3. Close the top cover of the finisher.




CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

5

Close the top cover of the puncher and the front cover of the puncher waste tray.



1. Close the top cover.
2. Close the front cover.



CAUTION

When closing the covers, be careful not to get your fingers caught, as this may result in personal injury.

6

Follow the instructions on the screen.



NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Booklet Finisher-J1 (Optional)

Check the location of the paper jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed paper.




NOTE

The Booklet Finisher-J1 is an optional product.

Inside the Front Cover


1

Open the front cover of the finisher.



2

Remove any jammed paper from the upper delivery guide.



* Upper Delivery Guide

1. Open the upper delivery guide.
2. Remove any jammed paper.



CAUTION

When releasing the upper delivery guide, be careful not to get your fingers caught, as this may result in personal injury.




NOTE

The upper delivery guide is spring-loaded. When you release the upper delivery guide, it returns to its original position.

3

Remove any jammed paper from the lower delivery guide.



* Lower Delivery Guide

1. Turn the lever on the lower delivery guide to the right until it stops, and then tilt the lower delivery guide to the right.
2. Remove any jammed paper.
3. Return the delivery guide to its original position.



CAUTION

When returning the lower delivery guide to its original position, be careful not to get your fingers caught, as this may result in personal injury.

4

Close the front cover of the finisher.



CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

5

Follow the instructions on the screen.




NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Saddle Stitcher Unit


1

Open the front cover of the finisher.




2

Turn the knob on the right in the direction of the arrow (counterclockwise) until it stops.




3

While pushing in the knob on the left, turn it in the direction of the arrow (clockwise).




4

Remove any jammed paper protruding from the output part.



5

Remove any jammed paper from the lower delivery guide.



1. Turn the lever on the lower delivery guide to the right until it stops, and then tilt the lower delivery guide to the right.
2. Remove any jammed paper.
3. Return the delivery guide to its original position.

* Lower Delivery Guide



CAUTION

When returning the lower delivery guide to its original position, be careful not to get your fingers caught, as this may result in personal injury.

6

Close the front cover of the finisher.



CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

7

Follow the instructions on the screen.



NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Inner Finisher-E1 (Optional)

Check the location of the paper jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed paper.



NOTE


- The Inner Finisher-E1 is an optional product.
- If the Paper Deck Unit-B2 is attached, move the paper deck unit away from the main unit before proceeding with this procedure.
- If there is paper in the output tray, remove the output paper before proceeding with this procedure.
- If the Copy Tray-J1 is attached to the main unit, remove all output paper from the tray.

1

Remove any jammed paper from the output unit in accordance with steps 2 and 3 of “Main Unit.”

2


Remove any jammed paper from the inner guide.



1. Pull down the inner guide.
2. Remove any jammed paper.

3

Remove any jammed paper protruding from the finisher's output tray.



4

Push the paper output unit back into its original position.

**CAUTION**

When pushing the paper output unit back into its original position, be careful not to get your fingers caught, as this may result in personal injury.

5

Close the upper right cover and then close the lower right cover.

**CAUTION**

When closing the upper and lower right covers of the main unit, be careful not to get your fingers caught, as this may result in personal injury.

**NOTE**

- Gently close the covers until they click into place in the closed position.
- If the Paper Deck Unit-B2 was moved away from the main unit, reconnect it to the main unit.

6

Follow the instructions on the screen.

**NOTE**

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Inner 2 Way Tray-F1 (Optional)

Check the location of the paper jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed paper.




NOTE

- The Inner 2 Way Tray-F1 is an optional product.
- If the Paper Deck Unit-B2 is attached, move the paper deck away from the main unit before proceeding with this procedure.
- If the Copy Tray-J1 is attached to the main unit, remove all output paper from the tray.

1


Open the lower right and upper right covers of the machine.



1. Grip the handle, and open the lower right cover of the machine.
2. Open the upper right cover of the machine.

2

Remove any jammed paper.



3

Close the upper right cover and then close the lower right cover.



CAUTION

When closing the upper and lower right covers of the main unit, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

- Gently close the covers until they click into place in the closed position.
- If the Paper Deck Unit-B2 was moved away from the main unit, reconnect it to the main unit.

4

Follow the instructions on the screen.



NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.

Copy Tray-J1 (Optional)

Check the location of the paper jam, and follow the procedure described below, and the procedure that appears on the touch panel display, to remove the jammed paper.




NOTE

- The Copy Tray-J1 is an optional product.
- If the Paper Deck Unit-B2 is attached, move the paper deck away from the main unit before proceeding with this procedure.
- Remove all output paper from the Copy Tray-J1 before proceeding with this procedure.

1


Open the lower right and upper right covers of the machine.



1. Grip the handle, and open the lower right cover of the machine.
2. Open the upper right cover of the machine.

2

Remove any jammed paper protruding from the inside slot of the copy tray.



3

Close the upper right cover and then close the lower right cover.



CAUTION

When closing the upper and lower right covers of the main unit, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

- Gently close the covers until they click into place in the closed position.
- If the Paper Deck Unit-B2 was moved away from the main unit, reconnect it to the main unit.

4

Follow the instructions on the screen.



NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.



Reducing the Frequency of Paper Jams

If paper jams occur frequently, even though there is no apparent problem with the machine, either one of the following two reasons may be the cause. Follow the instructions described below to reduce the frequency of paper jams.

- **There are torn pieces of paper left inside the machine.**

Pulling jammed paper out of the machine by force may leave parts of the paper torn inside, leading to frequent paper jams. If paper tears while you are trying to remove jammed paper from the machine, make sure that you remove all of the torn pieces.


- **The paper is not loaded correctly in the paper drawer.**

Make sure that the paper size plate of the paper drawer matches the size of the paper loaded in the paper drawer.



Clearing Staple Jams (For Optional Products)

If a staple jam occurs, a screen indicating the location of the staple jam and how to clear the jam appears on the touch panel display. Follow the instructions on the screen to clear the staple jam. The screen is displayed repeatedly until the staple jam is cleared. If you press [Close], you can continue operations, such as setting modes or scanning originals, even if the jammed staple is not removed immediately.




IMPORTANT

Make sure to close all covers and paper drawers of the machine before clearing any staple jams.


Locations of Staple Jams

For information on the parts of the machine in which staple jams occur and instructions on clearing staple jams, see the following.


Staple Finisher-J1/Booklet
Finisher-J1 (p. 151)



Saddle Stitcher Unit of the
Booklet Finisher-J1 (p. 153)



Inner Finisher-E1 (p. 156)



Staple Finisher-J1/Booklet Finisher-J1

Check the location of the staple jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed staple.



IMPORTANT

Make sure to close all covers and paper drawers of the machine before clearing any staple jams.





NOTE

The Staple Finisher-J1 and Booklet Finisher-J1 are optional products.

1

Open the front cover of the finisher.





*1 Booklet Finisher-J1

*2 Staple Finisher-J1


2

Lift and pull out the staple case from the stapler unit, holding it by the green tab.



3


Remove any staples jammed in the staple case.



1. Push down the tab on the staple case.
2. Remove all of the staples that slide from the staple cartridge.
3. Return the tab on the staple case to its original position.

4

Gently push the staple case back into the finisher and push down firmly until it is securely in place.



5

Close the front cover of the finisher.

**CAUTION**

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

**NOTE**

After the cover is closed, the stapler unit may automatically perform a "dry" stapling operation to reposition the staples.

Saddle Stitcher Unit of the Booklet Finisher-J1

Check the location of the staple jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed staple.



IMPORTANT

- Make sure to close all covers and paper drawers of the machine before clearing any staple jams.
- Before clearing a staple jam in the saddle stitcher unit, remove all paper that has been output to the booklet tray.





NOTE

The Booklet Finisher-J1 is an optional product.



1

Open the front cover of the finisher.



2

Pull out the saddle stitcher unit.




*1 Stapler Unit of the Saddle Stitcher Unit

*2 Saddle Stitcher Unit

1. Grip the handle of the saddle stitcher unit, and pull out until it stops.
2. Pull the stapler unit of the saddle stitcher unit towards you, and then push it up.


3

Pull out the staple case containing the jammed staples, holding it by its left and right sides.



4


Push up the tab on the staple case.



1. Push down Part A to unlock.
2. Push up Part B.

5


Remove any jammed staples.



1. Remove any jammed staples.
2. Return Part B to its original position.

6


Return the staple case to its original position.



Push the staple case in until it clicks into place.

7

Gently push the saddle stitcher unit back into its original position.



1. Pull the stapler unit towards you, and then push it down into its original position.
2. Grip the handle of the saddle stitcher unit, and return it to its original position.



CAUTION

When returning the saddle stitcher unit to its original position, be careful not to get your fingers caught, as this may result in personal injury.

8

Close the front cover of the finisher.



CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

When you have cleared the staple jam, be sure to manually reposition the staples in the saddle stitcher unit. (See e-Manual > Settings/Registration.)

Inner Finisher-E1

Check the location of the staple jam, and follow the procedure described below, while referring to the directions that appear on the touch panel display, to remove the jammed staples.



IMPORTANT

Make sure to close all covers and paper drawers of the machine before clearing any staple jams.




NOTE

The Inner Finisher-E1 is an optional product.


1

Remove any jammed paper protruding from the output tray.



2


Pull out the staple case.



1. Open the front cover of the finisher.
2. Pull out the staple case, holding it by the green tab.

3


Remove any staples jammed in the staple case.



1. Push down the tab on the staple case.
2. Remove all of the staples that slide from the staple cartridge.
3. Return the tab on the staple case to its original position.

4

Attach the staple case.



1. Gently push the staple case back into the finisher and push down firmly until it is securely in place.
2. Close the front cover of the finisher.



CAUTION

When closing the cover, be careful not to get your fingers caught, as this may result in personal injury.



NOTE

After the cover is closed, the stapler unit may automatically perform a "dry" stapling operation to reposition the staples.



If Memory Becomes Full During Scanning

The machine's memory can store up to approximately 6,200 pages of scanned images. Approximately 6,000 pages of that total is shared by the various functions, including the Copy; Fax; Scan and Send; Scan and Store (Store in Mail Box); Fax/I-Fax Inbox; and, printing from computer functions. In addition, each function is guaranteed to be able to store the following number of pages:

Copy: 100 pages

Print From Computer: 100 pages (excluding Secure Print jobs)

For example, the Copy function can store up to approximately 6,100 pages of scanned images.

$6,000 + 100 = 6,100$ pages (approximate figures)

However, the number of pages that the machine's memory can store may differ, depending on the amount of memory required for files stored in the Mail Box and Fax/I-Fax Inbox, and jobs that are in the print queue.

If memory becomes full during the scanning of originals, a message will appear on the touch panel display.



NOTE

- When using Fax/Scan and Send, you can send up to 999 pages at one time.
- Delete any unnecessary files in the Mail Box and Fax/I-Fax Inbox to free up memory.

For the Copy Function

Follow the directions below based on the message that appears on the touch panel display.

- If the message <Scanning will be canceled because the memory is full. Do you want to print the scanned pages?> appears:
Select [Yes] or [No].

[Yes]: The pages scanned into memory are printed. When printing is complete, scan the remaining originals.
[No]: The pages scanned into memory are not printed.
- If the message <Scanning will be canceled because the memory is full. Wait a moment, then try again.> appears:
Select [OK].

[OK]: Returns to the Basic Features screen of the function you are using. Scan the job again when the current job is complete.

For the Fax/Scan and Send Function

Follow the directions below based on the message that appears on the touch panel display.

- If the message <Scanning will be canceled because the memory is full. Do you want to send the scanned pages?> appears:
Select [Yes] or [No].

[Yes]: The pages scanned into memory are sent. When storing is complete, scan the remaining originals.
[No]: The pages scanned into memory are not sent.

For the Scan and Store Function

Follow the directions below based on the message that appears on the touch panel display.

- If the message <Scanning will be canceled because the memory is full. Do you want to store the scanned pages?> appears:
Select [Yes] or [No].

[Yes]: The pages scanned into memory are stored. When storing is complete, scan the remaining originals.
[No]: The pages scanned into memory are not stored.
- If the message <Scanning will be canceled because the memory is full. Wait a moment, then try again.> appears:
Select [OK].


[OK]: Returns to the Basic Features screen of the function you are using.




When an Error Message Is Displayed

Error messages may appear on the touch panel display of the machine or the Web browser. Self-diagnostic error messages appear in the following cases:

- When scanning or printing cannot be performed because of an operational error
- When you need to make a decision or take some action during scanning or printing
- When you need to make a decision or take some action while browsing the network



Example of an Error Message on the Touch Panel Display



Example of an Error Message on the Web Browser

For information on error messages and instructions on resolving errors, see e-Manual > Problem Solving.


When an Error Code Is Displayed

If a job or operation does not complete successfully, the error code is displayed on the Details screen for Log on the Status Monitor/Cancel screen.

You can check the error code in the following locations:

● Details screen for Log on the Status Monitor/Cancel screen:

When a job or operation is not completed normally:



● Results row of the Communication Management Report:

If an error occurs during a send, receive, or fax job, the error code is printed.

04/12/2012		iRADVXXXX				001	
***** *** DEVICE INFORMATION COMMUNICATION LOG REPORT *** *****							
START TIME	END TIME	TYPE	TO/FROM	DATA DETAILS		RESULT	
04/06 16:06	04/06 16:07	DELIVER	111.111.111.1	DEPT.ID ADDRESS BOOK		NG	#754
04/06 16:10	04/06 16:10	DELIVER	111.111.111.1	DEPT.ID ADDRESS BOOK		NG	#754
04/06 16:10	04/06 16:10	DELIVER	222.222.222.222	DEPT.ID ADDRESS BOOK		NG	#754
04/06 16:10	04/06 16:10	DELIVER	333.333.333.333	DEPT.ID ADDRESS BOOK		NG	#754

For information on error codes and instructions on resolving errors, see e-Manual > Problem Solving.





Printer/Fax Driver Troubleshooting

See “Troubleshooting” in the driver help to resolve problems when using the printer driver or fax driver for Windows. The following screens indicate the directions on how to display “Troubleshooting” from the screen for the printer driver.



NOTE


The screens may differ, depending on the operating system, and the type and version of the printer driver you are using.






Service Call Message

If a malfunction occurs and the machine cannot operate normally, a screen prompting you to contact your local authorized Canon dealer is displayed.



If a screen such as the one above is displayed, contact your local authorized Canon dealer. (See “Contacting Your Local Authorized Canon Dealer,” on p. 164.)

● When [Limited Functions Mode] Is Displayed:




If [Limited Functions Mode] is displayed, you can temporarily set the Limited Functions Mode to continue to use the machine until the cause of the malfunction is cleared. For more information, see “Setting the Limited Functions Mode from the Service Call Message Screen,” on p. 166.

If a screen such as the one below is displayed and the print or scan function does not operate normally, some functions may still be available.

● When the print or scan function does not operate normally:

The selected function cannot be used. Press [Main Menu] to return to the Main Menu.



● When a Service Call Message Is Displayed on the Bottom of the Screen:




Even if a message prompting you to call your service representative appears on the bottom of the screen, some functions may still be available.
For more information, see "Functions Available When the Printer/Scanner Cannot Be Used Due to an Error," on p. 168.

Contacting Your Local Authorized Canon Dealer

If a screen prompting you to contact your local authorized Canon dealer is displayed, follow the procedure described below.

1

Turn OFF the main power of the main unit.



1. Open the main power switch cover.
2. Press the main power switch to the "⏻" side.
3. Close the main power switch cover.




IMPORTANT

If you turn OFF the main power switch when there is a job waiting to print, that job is erased.

2

Wait at least 10 seconds after the Main Power Indicator is turned off, and then turn the main power switch back to ON.



1. Open the main power switch cover.
2. Press the main power switch to the "I" side.
3. Close the main power switch cover.

3

If the machine still does not operate normally, follow the procedure below, and then contact your local authorized Canon dealer.

1. Turn the main power switch OFF.
2. Remove the power plug from the power outlet.



WARNING

Do not connect or disconnect the power cord with wet hands, as this may result in electrical shock.



CAUTION

Always grasp the power plug when disconnecting the power cord. Pulling on the power cord may expose or snap the core wire, or otherwise damage the power cord. If the power cord is damaged, this could cause current to leak, resulting in a fire or electrical shock.



NOTE

When you contact your local authorized Canon dealer, have the following information available:

- Product name
- Details of the malfunction
- The error code displayed on the touch panel display

Setting the Limited Functions Mode from the Service Call Message Screen

When [Limited Functions Mode] is displayed, follow the procedures below.



IMPORTANT

If you turn OFF the main power switch when there is a job waiting to print, that job is erased.



NOTE

If you set Limited Functions Mode to 'On' from the Service Call Message screen, [Limited Functions Mode] in [Management Settings] (Settings/Registration) is also set to 'On'. (See e-Manual > Security.)


1

Press [Limited Functions Mode] → [Yes].

A message prompting you to restart the machine (turning the main power switch OFF, and then ON) appears.

2


Turn OFF the main power of the main unit.



1. Open the main power switch cover.
2. Press the main power switch to the "⏻" side.
3. Close the main power switch cover.

3

Wait at least 10 seconds after the Main Power Indicator is turned off, and then turn the main power switch back to ON.



1. Open the main power switch cover.
2. Press the main power switch to the "I" side.
3. Close the main power switch cover.

The machine starts up in the Limited Functions mode.

Functions Available When the Printer/Scanner Cannot Be Used Due to an Error

You can use the following functions even when the Print and Scan functions are restricted:

Main Menu Screen

✓: Available -: Unavailable

Available Functions	When the Print function is restricted	When the Scan function is restricted
Copy	-	-
Fax	✓ ^{*1}	-
Scan and Send	✓	-
Scan and Store	✓ ^{*2}	-
Access Stored Files	-	✓ ^{*3}
Fax/I-Fax Inbox	-	✓
Secure Print	-	✓
Remote Scan	✓	-
Web Access	✓	✓
Shortcut to Settings/Registration	-	-
Tutorial	✓	✓
iW Function Flow	-	-
Document Scan Code Analyzer for MEAP ^{*4}	✓	-
Other MEAP Applications ^{*5}	✓	✓

Control Panel

✓: Available -: Unavailable

Available Functions	When the Print function is restricted	When the Scan function is restricted
Quick Menu ^{*6}	✓	✓
The Status Monitor/Cancel Screen	✓ ^{*7}	✓
Settings/Registration	-	-

● Operation From a Computer

✓: Available -: Unavailable

Available Functions	When the Print function is restricted	When the Scan function is restricted
Remote UI	✓	✓
MEAP Application ^{*5}	✓	✓

*1 Sending a fax from a computer is not available.

*2 [Print List] on the Mail Box Selection screen is not available.

*3 [Add Files (Scan and Store)] on the Edit File screen is not available.

*4 Document Scan Code Analyzer is included in the Document Scan Lock Kit. For more information, see e-Manual > Optional Products/Software.

*5 Available by installing each MEAP application. May not be available, depending on the restricted functions.

*6 The registered button may not be available, depending on the restricted functions.

*7 [Print List] on the Job Log screen and [Register] on the Consumable screen are not available.



IMPORTANT

- A print job is automatically canceled when the Print function is restricted. A scan job is automatically canceled when the Scan function is restricted.
- The machine may not enter the Sleep mode completely when a function is restricted due to an error.



NOTE

- If the target function is restricted due to an error, the function is not available when you use the shortcut key on the top of the Main Menu screen or when you use the Quick Menu.
- [Remove Toner Cartridges] is not available when the Print function is restricted.

Frequently Asked Questions

This section includes frequently asked questions and answers regarding the machine. Use this section if you have trouble using the machine.

Question		Applicable Page
Q1	I want to make a rush copy, but I cannot because of the long copy job.	p. 172
Q2	When copying, the Scan screen for the next document is displayed. Is there a way to not display this screen?	p. 172
Q3	How do I change the default settings for the Copy from the Color mode to the Black mode?	p. 173
Q4	Can a mark be applied to the document that has been scanned?	p. 173
Q5	Do I need to enter the address of the recipient every time?	p. 174
Q6	Can I send a fax to multiple destinations?	p. 174
Q7	Can you give me information on how to send to the SMB server and specify its settings?	p. 175
Q8	Can I move the Address Book registered on another Canon machine onto this machine?	p. 177
Q9	Can I forward the data received via fax/I-fax?	p. 177
Q10	When sending a fax, can the machine be set so that the sender's fax number and name be displayed?	p. 178
Q11	How do I change the default settings (scan settings and file format) of the Scan and Send Basic Features screen?	p. 178
Q12	Is there a way to prevent a transmission error when sending a facsimile to a new destination?	p. 179
Q13	The quality of the image sent by fax is not good.	p. 180
Q14	How can I make use of multiple telephone lines?	p. 180
Q15	How do I register/edit destinations in a one-touch button?	p. 181
Q16	Can I add an arbitrary subject when sending e-mail?	p. 181
Q17	How do I change the storage period for the scanned file stored in the Mail Box?	p. 182
Q18	How do I access the Advanced Box from a computer?	p. 182
Q19	How do I forward received data to the Advanced Box?	p. 183
Q20	How do I set to create a booklet with a file in a mail box?	p. 183
Q21	I cannot print PDF files stored in the Advanced Box. Are optional products required?	p. 184
Q22	When printing from the computer, booklet was not made even though saddle stitch booklet mode was set.	p. 184
Q23	The content of the reverse side appears on the copies.	p. 185
Q24	The printed paper appears dirty. Also, the color appears to be different from the original.	p. 185
Q25	The printed paper is warped.	p. 186
Q26	I had printed from the computer, but I did not find the output. I am afraid that someone may have taken it by mistake.	p. 186
Q27	Can I specify the scan settings from the computer and then store for the original loaded in the machine?	p. 187
Q28	Can I make copies or send a facsimile of different size originals at the same time?	p. 187

Question		Applicable Page
Q29	Can I print on the reverse side of the preprinted paper?	p. 188
Q30	Can I output paper to a different tray according to the function?	p. 188
Q31	Can I print on envelopes?	p. 189
Q32	What are the types of paper that I can use?	p. 189
Q33	How do I print data received via fax/I-fax on paper specified in advance?	p. 190
Q34	How can I manage documents that failed to be forwarded?	p. 190
Q35	When a fax fails to be sent, both the TX Report and the Fax TX Report are output. Is there a way to not output the Fax TX Report?	p. 191
Q36	How do I print the data received from specific destinations only?	p. 191
Q37	What is the model number of the staple cartridge for the finisher or the stamp cartridge for the feeder?	p. 192
Q38	A paper jam has occurred. How do I solve this problem?	p. 192
Q39	I cannot remove the toner cartridge after the toner replacement cover is opened.	p. 193
Q40	Numbers, such as #751 and #801 are displayed on the touch panel display. What do they mean?	p. 193
Q41	I cannot print from the computer. Did the machine malfunction?	p. 194
Q42	It seems as though turning OFF the machine is different from the previous imageRUNNER. I am afraid that this may be a wrong operation.	p. 194
Q43	The touch panel display is completely black.	p. 195
Q44	I have just sent an important document via facsimile. Can I check to make sure that it was sent correctly?	p. 195
Q45	Can I restrict the number of copies/prints?	p. 196
Q46	Can I change the language displayed on the touch panel display?	p. 196
Q47	Can I change the screen or the order that the functions are displayed on the touch panel display when the power is turned ON?	p. 197
Q48	I want to check the IP address for this machine to run the Remote UI, but I do not know how to check it.	p. 198
Q49	Can I change the default settings of the printer driver?	p. 198
Q50	Is there a way to adjust the sound heard when fax sending/receiving is complete?	p. 200
Q51	What is MEAP?	p. 200

Q

1


I want to make a rush copy, but I cannot because of the long copy job.

A


You can temporarily stop the current copy job and give priority to a rush copy by using the Interrupt mode. You can also give priority to a rush copy/print from the Status Monitor/Cancel screen.


■ Interrupt Function:

1. Press [Copy] → [Interrupt].
2. Set the desired copy mode.



■ Interrupt/Priority Print Function:

1. Press  (Status Monitor/Cancel).
2. Press [Copy/Print] → [Job Status] from the [Print] drop-down list.
3. Select the job → press [Interrupt/Priority Print].
4. Press [Interrupt and Print].



Additional Information

You can scan the original even if the machine is waiting or printing (Reserved Copying). For more information, see e-Manual > Copy.


Q

2

When copying, the Scan screen for the next document is displayed. Is there a way to not display this screen?



A

When [Job Build] is set, the Scan screen for the next document is displayed. By canceling the [Job Build] setting, the screen is not displayed.



■ Canceling the Job Build mode

1. Press [Copy] → [Options] → [Job Build].
2. Press [Close].



Additional Information


The Job Build mode is useful if you cannot load the originals all at once. This mode enables you to divide the originals into several parts, scan them, and then print them all together.


Q

3


How do I change the default settings for the Copy from the Color mode to the Black mode?

A

You can store the current settings as the default settings from [Change Default Settings] in  on the Copy Basic Features screen. If the Black mode is set as the default settings, you can reduce the printing cost.



Color Selection: Full Color




Color Selection: Black

■ Changing the Color Mode to the Black Mode:

1. Press [Copy] → [Select Color] → [Black].

■ Setting the Color Mode as the Default:

1. Press  → [Change Default Settings] → [Register] → [Yes].

Additional Information

You can also save paper by using the Image Combination mode or Two-sided Copy mode. For more information, see e-Manual > Copy.

Q

4

Can a mark be applied to the document that has been scanned?

A

The machine can print a stamp on the scanned document by using the Stamp mode.



Position at which stamp is applied

Vertical Placement




Position at which stamp is applied

Horizontal Placement

■ Setting procedure:

1. Press [Scan and Send] or [Fax] → [Options].
2. Press [Finished Stamp] → [Close].



Additional Information

After the original is sent, you can also send a job done notice to the specified e-mail address (Job Done Notice). For more information, see e-Manual > Scan and Send, or Fax.

Q

5


Do I need to enter the address of the recipient every time?

A

You can store frequently used destination in the Address Book. If the destination is stored beforehand, you do not need to enter the destination every time.



■ Storing from the Remote UI:

1. Click [Address Book] → select the destination to register.
2. Click [Register New Destination] → select the type of destination → enter necessary items.
3. Click [OK].



■ Storing from the Touch Panel Display:

1. Press [Scan and Send] or [Fax] → [Address Book] → [Register/Edit].
2. Press [Register New Dest.] → enter information following the instructions on the touch panel display → press [OK].



Additional Information

You can also store frequently used destination as a one-touch button on the Scan and Send Basic Features screen or the Fax Basic Features screen. For more information, see e-Manual > Scan and Send, or Fax.

Q

6


Can I send a fax to multiple destinations?

A

You can send a fax to multiple destinations at the same time using the following methods.

■ Specifying Multiple Destinations from the Fax Screen

1. Enter a fax number using 0 - 9 (numeric keys), *, or # → press [OK].
2. Continue entering the other fax numbers → press [OK].
3. Press (Start).



■ Specifying Multiple Destinations from the Address Book

1. Press [Fax] → [Address Book] → select multiple destinations → press [OK].
2. Press (Start).

■ Registering Multiple Destinations from the Address Book as a Group Destination and Selecting a Group Destination

Registering a group destination in the Address Book

1. Press [Address Book] → [Register/Edit] → [Register New Dest.].
2. Press [Group] → enter the name and register the group in the Address Book.
3. Press [Add from Address Book] → select the addresses to register.
4. Press [OK] → [OK].

Selecting the group destination as a destination

1. Press [Address Book] → select the registered group destination → press [OK].
2. Press (Start).

Additional Information

- You cannot specify destinations registered in the address book and destinations registered in a one-touch button at the same time.
- You can also register a group destination in a one-touch button to send to multiple destinations at the same time. For information on registering one-touch buttons, see e-Manual > Scan and Send, or Fax.

Q

7

Can you give me information on how to send to the SMB server and specify its settings?

A

You can specify the settings using the following method.

■ Setting the Shared Folder on the Computer-Side:

Using Windows 7

1. Right-click the new folder → click [Property] → [Sharing].
2. Click [Sharing] → select the users you want to authorize access.
3. Click [Add] → select [Read/Write] for <Permission Level> for the added users.
4. Click [Sharing] → [End].
5. Click [Advanced Sharing] → select [Share this folder] → click [Permission].
6. Select the users you want to authorize access → select [Allow] for [Full Control].
7. Click [OK] → [OK] → [Close].

Using Windows Vista

1. Right-click the new folder → click [Property] → [Sharing].
2. Click [Share] → select the users you want to authorize access → click [Add].
3. Select [Co-owner] for <Permission Level> for the added users → click [Share] → [End].
4. Click [Advanced Sharing] → select [Share this folder] → click [Permission].
5. Add the users you want to authorize access → select [Allow] for [Full Control].
6. Click [OK] → [OK] → [Close].


Using Windows XP

1. Right-click the new folder → click [Sharing and Security] → select [Share this folder].
2. Click [Permissions] → select Everyone → click [Delete].
3. Click [Add] → add the users you want to authorize access → select [Allow] for [Full Control].
4. Click [OK] → [OK] → [Close].

Using Windows 2000

1. Right-click the new folder → click [Sharing] → select [Share this folder].
2. Click [Permissions] → select Everyone → click [Delete].
3. Click [Add] → add the users you want to authorize access → select [Allow] for [Full Control].
4. Click [OK] → [OK].


The item names may differ, depending on the type of operating system you are using. For more information, check the manual documentation for the personal computer operating system you are using.



Specifying the File Server on the Touch Panel Display:


Specifying the File Server by Host Search:

1. Press [Scan and Send] → [New Destination] → [File].
2. From the protocol drop-down list, press [Windows (SMB)] → press [Search Host].
3. On the search criteria screen, enter the IP address for the computer you are using → press [Start Searching].
4. Specify the file server → confirm the settings → press [OK].



Specifying the File Server by Browsing:

1. Press [Scan and Send] → [New Destination] → [File].
2. From the protocol drop-down list, press [Windows (SMB)] → [Browse].
3. Select the work group name and file server → specify each settings → press [OK].



Additional Information

You can use the following procedure to check the IP address of your computer.

* The procedures may differ, depending on the type of operating system you are using.

1. On the [Start] menu, click [Run] → enter <cmd>.
2. Click [OK] → enter <ipconfig> → press [ENTER] on the keyboard.

Q

8

Can I move the Address Book registered on another Canon machine onto this machine?

A

You can use the import and export mode of the Remote UI to move the Address Book.


■ Exporting the Address Book from Another Canon Machine:

1. Click [Settings/Registration] → select [Data Management] for <Management Settings>.
2. Click [Address Lists] for <Import/Export Individually> → [Export...].
3. Select the Address List and the format of the file → click [Start Exporting].
4. Specify the location to store the file → [Store].

* The key names may differ, depending on the type of the model you are using.

■ Importing the Address Book to the Machine:

1. Click [Settings/Registration] → select [Data Management] for <Management Settings>.
2. Click [Address Lists] for <Import/Export Individually> → [Import...].
3. Select the file you want to import and specify the desired settings → click [Start Importing].



Additional Information

- To perform this procedure, you must have administrator privileges. For more information, see e-Manual > Security.
- You can also export and import forwarding settings. For more information, see e-Manual > Remote UI.


Q

9

Can I forward the data received via fax/I-fax?



A

If you specify the forwarding settings, you can forward received documents that matches the previously set conditions to the Confidential Fax Inbox of this machine, other machines, or the file server.



■ Setting procedure:

1. Press (Settings/Registration) → [Function Settings] → [Receive/Forward] → [Common Settings].
2. Press [Forwarding Settings] → [Register] → specify the forwarding conditions.
3. Press [Close].



Additional Information

- To perform this procedure, you must have administrator privileges. For more information, see e-Manual > Security.
- If frequently used e-mail addresses are stored in the Address Book, you can specify the address quickly. For more information, see e-Manual> Settings/Registration.


Q

10

When sending a fax, can the machine be set so that the sender's fax number and name be displayed?

A

After registering the sender's name, you can specify to print the TX Terminal ID when sending a fax.




■ Registering the sender's name:

1. Press (Settings/Registration).
2. Press [Function Settings] → [Send] → [Fax Settings].
3. Press [Register Sender Name (TTI)] → [Register/Edit] → enter the sender's name.
4. Press [OK].

■ Displaying/Printing the TX Terminal ID:

1. Press [Fax] → [Options] → [Sender Name (TTI)].
2. Select the sender's name → press [OK].



Additional Information

For more information, see e-Manual > Settings/Registration.


Q

11


How do I change the default settings (scan settings and file format) of the Scan and Send Basic Features screen?

A

You can store the current settings as the default settings from on the Scan and Send Basic Features screen.






Before Change



After Change

■ To register the settings as the default settings:

1. Press [Scan and Send] → specify the scan settings and the file format.
2. Press  → [Change Default Settings] → [Yes].



Additional Information


For more information on each file format, see e-Manual > Scan and Send.


Q

12


Is there a way to prevent a transmission error when sending a facsimile to a new destination?


A

If [Confirm Entered Fax Number] in  (Settings/Registration) is set, a screen to enter the number for confirmation is displayed. By entering the number again, you can reduce the risk of transmission error.



Setting procedure:

1. Press  (Settings/Registration).
2. Press [Function Settings] → [Send] → [Fax Settings].
3. Press [Confirm Entered Fax Number] → [On] → [OK].



Additional Information

- To perform this procedure, you must have administrator privileges. For more information, see e-Manual > Security.
- You can also restrict sending to a destination that is not stored in the Address Book. For more information, see e-Manual > Security.

Q

13


The quality of the image sent by fax is not good.

A

Change the scan type or settings according to the type of original. Press [Preview] to check the document before sending.



■ Setting the Original Type and Density settings:

Press [Fax] → [Options] → specify the settings for [Original Type] or [Density].



■ Viewing the preview:

1. Press [Fax] → specify the destination.
2. Press [Options] → [Preview] → [Close].
3. Press (Start).



Preview Screen

Additional Information

If [Register Options Shortcuts] is selected from , you can register the [Options] shortcut button on the Fax Basic Features screen.

Q

14


How can I make use of multiple telephone lines?

A

You can specify the settings using the following method.


■ Selecting a telephone line when sending:

1. Press [Fax] → [Options] → [Select Line].
2. Select the telephone line → press [OK] → [Close].



■ Setting the sending and receiving lines from [Select TX Line]:

1. Press (Settings/Registration).
2. Press [Function Settings] → [Send] → [Fax Settings].
3. Press [Set Line] → [Select TX Line] → set the line to use for sending in [Priority TX] → set the line to use for receiving in [Prohibit TX].
4. Press [OK].



■ Setting forwarding conditions for the receiving line:

1. Press (Settings/Registration).
2. Press [Function Settings] → [Receive/Forward] → [Common Settings].
3. Press [Forwarding Settings] → select the line from the <Receive> drop-down list → select [Register] → set the forwarding conditions.
4. Press [Close].


Additional Information

For more information on the forwarding conditions, see e-Manual > Settings/Registration.


Q 15


How do I register/edit destinations in a one-touch button?

A

Press  on the Fax screen or [One-Touch] on the Scan and Send screen.


■ Registering/Editing from the Fax Screen

1. Press  → select the button to register/edit → press [Register/Edit].
2. Register/edit the address → press [Close].



■ Registering/Editing from the Scan and Send Screen

1. Press [One-Touch] → [Register] → select the button to register/edit.
2. Press [Register/Edit] → register/edit the address → press [Close].



Additional Information

- For information on how to register/edit a destination in a one-touch button, see e-Manual > Scan and Send, or Fax.
- When registering from the Fax screen, you can only register fax destinations or groups that include fax destinations.

Q 16


Can I add an arbitrary subject when sending e-mail?

A


You can enter an e-mail subject in [Subject/Message] in [Options].

■ Setting procedure:

1. Press [Scan and Send] → specify the destination → press [Options].
2. Press [Subject/Message] → enter the subject.
3. Press [OK] → [Close].




Additional Information

- You can also enter the message for the e-mail in [Message].
- If you do not specify the subject, the string registered in [Default Subject] in  (Settings/Registration) is inserted as the subject. The default setting is 'Attached Image'.

Q 17

How do I change the storage period for the scanned file stored in the Mail Box?


A



You can change the time until files are automatically erased from [Set/Register Mail Boxes] in  (Settings/Registration).

Change the setting, as necessary.

* You can set the time until the files are automatically erased to 0 (none), 1, 2, 3, 6, 12 hours, 1, 2, 3, 7, 30 days. The default setting is '3' days.

■ Setting procedure:

1. Press  (Settings/Registration).
2. Press [Function Settings] → [Store/Access Files] → [Mail Box Settings].
3. Press [Set/Register Mail Boxes] → select the inbox number → set the time until files are automatically erased → press [OK].



Additional Information

In the Mail Box settings, you can also register a name for the Mail Box and change the password. For more information, see e-Manual > Settings/Registration.


Q 18


How do I access the Advanced Box from a computer?

A


If the Advanced Box is opened with SMB, check the following.


■ Checking the settings for [Open to Public]:

1. Press  (Settings/Registration).
2. Press [Function Settings] → [Store/Access Files] → [Advanced Box Settings].
3. Press [Open to Public] → check whether [By SMB] is selected.



■ Checking the settings for [Prohibit Writing from External]:

1. Press  (Settings/Registration).
2. Press [Function Settings] → [Store/Access Files] → [Advanced Box Settings].
3. Check whether [Prohibit Writing from External] is set to 'Off'.



Additional Information

For more information, see e-Manual > Security.

Q

19


How do I forward received data to the Advanced Box?

A

Specify an Advanced Box destination registered in the Address Book as the forwarding destination.

■ **Registering an Advanced Box Destination in the Advanced Box:**

1. Press \odot (Settings/Registration).
2. Press [Set Destination] → [Register Destinations] → [Register New Dest.].
3. Press [File] → register the Advanced Box destination.



■ **Registering an Advanced Box Destination as a Forwarding Destination:**

1. Press \odot (Settings/Registration).
2. Press [Function Settings] → [Receive/Forward] → [Common Settings].
3. Press [Forwarding Settings] → [Register] → specify the forwarding conditions.
4. Press [Forwarding Destination] → [Address Book] → specify the Advanced Box destination.



Additional Information

- For information on registering an Advanced Box destination in the Address Book, see e-Manual > Scan and Send.
- For more information on forwarding settings, see e-Manual > Settings/Registration.

Q

20



How do I set to create a booklet with a file in a mail box?

A

You can create a booklet using the Booklet mode. Specify the following settings.

■ **Setting procedure:**

1. Press [Access Stored Files] → [Mail Box] → select a stored document.
2. Press [Print] → [Change Print Settings] → [Options].
3. Press [Booklet] → [Booklet Scan] → [Fold + Saddle Stitch].
4. Specify the cover settings, orientation, and detailed settings → press [OK].



Additional Information

- For details on the Booklet mode settings, see e-Manual > Access Stored Files.
- Use a document that was stored with the [Booklet Scan] mode set.
- For details on the Booklet Scan mode settings, see e-Manual > Scan and Store.

Q

21

I cannot print PDF files stored in the Advanced Box. Are optional products required?

A

The following optional products are required to print PDF files:

PS Printer Kit
Direct Print Kit (for PDF/XPS)
Direct Print Kit (for PDF)
Additional Memory Type D (512MB)

Additional Information

If you are using the PS Printer Kit, the Direct Print Kit (for PDF/XPS) or Direct Print Kit (for PDF) is unnecessary.

Q

22

When printing from the computer, booklet was not made even though saddle stitch booklet mode was set.

A

The Saddle Stitch mode cannot be used if you exceed the maximum number of sheets that can be saddle stitched. In that case, you can use the Divided Booklet mode.



- The maximum number of sheets that can be saddle stitched is:

16 sheets (52 to 81 g/m²)
10 sheets (82 to 105 g/m²)

If the number of sheets is more than the number stated above, the output is printed without being saddle stitched.

- Setting a Divided Booklet (Windows):

Click [Booklet] → [Divide into Sets].



Additional Information

- You cannot set the Divided Booklet mode from the Macintosh printer driver.
- For information on the number of sheets that can be saddle stitched at one time, see e-Manual > Optional Products/Software.


Q

23

The content of the reverse side appears on the copies.


A

You can erase the background color of the original and prevent the original image on the reverse side of thin originals from appearing on the copies by using [Background Density].




■ Setting procedure:

1. Press [Copy] → [Options] → [Density].
 2. Press [Background Density] → [Auto] or [Adjust].
- If [Auto] is pressed, the exposure of the original image on the reverse side is automatically adjusted.
 - If [Adjust] is pressed, the exposure of the original image on the reverse side can be manually adjusted.



Adjust Overall



Adjust by Color

Additional Information

For more information, see e-Manual > Copy.

Q

24


The printed paper appears dirty.
Also, the color appears to be different from the original.

A

If streaks are printed on the paper or the image is not printed evenly, the inside of the feeder may be dirty. Follow the procedure below to clean the feeder. You can also automatically correct the gradation of the image from [Auto Adjust Gradation].


■ Cleaning the feeder:

1. Press (Settings/Registration).
2. Press [Adjustment/Maintenance] → [Maintenance] → [Clean Feeder].
3. Load 10 sheets of blank paper in the feeder → press [Start].



■ Automatic gradation adjustment:

1. Press (Settings/Registration).
2. Press [Adjustment/Maintenance] → [Adjust Image Quality] → [Auto Adjust Gradation].
3. Select the desired paper → press [Quick Adjust] → [Start].



Additional Information

For more information on Automatic Gradation Adjustment, see e-Manual > Settings/Registration.


Q

25

The printed paper is warped.

A

If you print an original filled with an image or an original with a high image density, the paper may become warped. To reduce the warping, try the following.



■ Use heavy paper:

If you are using thin paper, replace it with heavy paper with a weight of approximately 80 g/m².

■ Use paper with a low moisture content:

When you remove paper from its packaging, load it into the paper source immediately. When there is paper remaining in the packaging after you have loaded the paper, store it with the packaging closed properly to prevent the paper from absorbing moisture.

Additional Information

For information on loading paper, see e-Manual > Maintenance.

Q

26


I had printed from the computer, but I did not find the output. I am afraid that someone may have taken it by mistake.

A

You can check the Print Logs from the touch panel display of this machine. If the job is listed as 'OK' on the Log and you did not find the output, the print job may have intermixed with another user's output.

■ To check:

1. Press (Status Monitor/Cancel).
2. Press [Copy/Print] → [Log] → press the drop-down list.
3. Select the job type to display and check the log.



Additional Information

When printing from the computer, you can set a password for printing (Secured Printing). You can prevent another user from taking the output by mistake or prevent outputs from being left behind because the print job cannot be started until the password is entered on the touch panel display of the machine. For more information, see e-Manual > Practical Workflows.

Q

27


Can I specify the scan settings from the computer and then store for the original loaded in the machine?

A

It is possible if you are using Windows. Install the Network ScanGear Driver in your computer, and then switch the network scan function to online.



■ To Install the Driver:

Install using the UFR II User Software CD-ROM that comes with the machine.



■ To Switch the Network Scan Function to Online:

Press [Scanner] → [Online].



Additional Information

For instructions on installing the Network ScanGear Driver, see the Network ScanGear User's Guide on the UFR II User Software CD-ROM.

Q

28

Can I make copies or send a facsimile of different size originals at the same time?



A

You can make copies or send a facsimile of different size originals at the same time by using the Different Size Originals mode.

* The Different Size Originals mode enables you to copy/scan different size originals such as A3 and A4, together as one group.

■ Setting procedure:

1. Press [Copy] or [Fax] → [Options] → [Different Size Originals].
2. Select the type of different size originals → press [OK].



Additional Information

For more information, see e-Manual > Copy, or Fax.


Q

29

Can I print on the reverse side of the preprinted paper?


A

You can use [2nd Side of 2-Sided Page] for the multi-purpose tray to print on paper already printed on.



Setting procedure:

1. Load the paper in the multi-purpose tray with the side to print on face down.
2. Select the paper size → press [Next].
3. Select the paper type → press [2nd Side of 2-Sided Page] → [OK].
4. Press [OK].
5. Press (Start).



Additional Information

A paper jam is more likely to occur with paper already printed on compared to new paper.


Q

30

Can I output paper to a different tray according to the function?

A



You can set the output tray for each function and set priorities for outputting paper.



* The output trays indicated by Tray A, B, and C differ according to the optional product attached to the machine.

Setting procedure:

1. Press (Settings/Registration).
2. Press [Function Settings] → [Common] → [Paper Output Settings].
3. Press [Output Tray Settings].
4. Set the function and tray priority for Tray A, B, and C → press [OK].



Additional Information

For more information on setting the output tray for each function, see e-Manual > Settings/Registration.


Q

31

Can I print on envelopes?

A


Load the envelopes to print on in the multi-purpose tray.



■ Setting procedure:

Take about five envelopes, fan them, and then stack them together. Place the envelopes on a level surface, and press all the way around the envelopes by hand to remove any air inside. Open the multi-purpose tray, adjust the slide guides, and then load the envelopes, as shown below.

1. Load the envelopes.
2. Press [Envelope] → select the desired envelope type → press [OK].
3. Press [Next] → [OK] → [OK].
4. Press (Start).



Nagagata 3
Kakugata 2



ISO-C5

← Feeding Direction

Additional Information

For more information, see e-Manual > Basic Operations.

If the optional Envelope Feeder Attachment-D1 is attached to the machine, you can load envelopes in the paper drawer with the Envelope Feeder Attachment-D1 attached.

Q

32

What are the types of paper that I can use?

A

You can load and print on the following paper:

Paper Drawer

Weight	52 to 220 g/m ²
Size	Paper Drawer 1: A4, A4R, A5R, B4, B5, B5R, Custom Size (139.7 mm x 182 mm to 304.8 mm x 390 mm) Paper Drawer 2: 305 mm x 457mm, A3, A4, A5R, B4, B5, B5R, Custom Size (139.7 mm x 182 mm to 304.8 mm x 457.2 mm)
Type	Thin, Plain 1, Plain 2, Recycled, Color, Pre-Punched, Bond, Heavy 1, Heavy 2, Transparency, Tab*, Letterhead, Envelopes*

* Tab paper is available only when the Tab Feeding Attachment Kit-B1 is attached to the Paper Drawer 2. Envelope is available only when the Envelope Feeder Attachment-D1 is attached to the Paper Drawer 2..

Multi-Purpose Tray

Weight	52 to 256 g/m ²
Size	305 mm x 457mm, SRA3, A3, A4, A4R, A5, A5R, B4, B5, B5R (99 mm x 139.7 mm to 320 mm x 457.2 mm)
Type	Thin, Plain 1, Plain 2, Recycled, Color, Pre-Punched, Bond, Heavy 1, Heavy 2, Heavy 3, Tracing, Coated, Labels, Transparency, Tab, Letterhead, Envelopes

Additional Information


For more information on the available paper types, see e-Manual > Basic Operations.

Q


33


How do I print data received via fax/I-fax on paper specified in advance?

A

You can change the paper source from [Paper Drawer Auto Selection On/Off] in  (Settings/Registration).

■ Setting procedure:

1. Press  (Settings/Registration).
2. Press [Function Settings] → [Common] → [Paper Feed Settings].
3. Press [Paper Drawer Auto Selection On/Off] → [Receive/Fax] → set the paper source you want to use for printing received data to 'On' → set the paper sources you do not want to use to 'Off'.
4. Press [OK] → [OK].



Additional Information


For more information, see e-Manual > Settings/Registration.

Q


34


How can I manage documents that failed to be forwarded?

A

You can specify how to manage jobs that failed to be forwarded in [Handle Files with Forwarding Errors] in  (Settings/Registration).

■ Setting procedure:

1. Press  (Settings/Registration).
2. Press [Function Settings] → [Receive/Forward] → [Common Settings].
3. Press [Handle Files with Forwarding Errors] → select how to manage the forwarding errors → press [OK].
 - If you select [Always Print], jobs with forwarding errors are always printed.
 - If you select [Store/Print], jobs with forwarding errors are stored in Memory RX Inbox.
 - If Fax Memory Lock or I-Fax Memory Lock is set to 'Off', jobs with forwarding errors are printed.
 - If you select [Off], no jobs with forwarding errors are printed.



Additional Information

For more information, see e-Manual > Settings/Registration.

Q

35


When a fax fails to be sent, both the TX Report and the Fax TX Report are output. Is there a way to not output the Fax TX Report?

A

Disable the output function for the Fax TX Report. Specify the following settings.

Disabling output of the Fax TX Report:

1. Press (Settings/Registration).
2. Press [Function Settings] → [Send] → [Fax Settings].
3. Press [Fax TX Report] → [Off] → [OK].



Additional Information

For more information, see e-Manual > Settings/Registration.

Q

36


How do I print the data received from specific destinations only?

A

You can set the Store/Print Received File mode in Forwarding Settings to print the data received from specific destinations only.


Printing for Specific Destinations Only

1. Press (Settings/Registration).
2. Press [Function Settings] → [Receive/Forward] → [Common Settings].
3. Press [Forwarding Settings] → [Register] → specify the destinations in [Conditions].
4. Set <Store/Print Received File> to 'On' → press [OK] → [Close].



Forwarding to the Confidential Fax Inbox for Other Destinations

1. Press (Settings/Registration).
2. Press [Function Settings] → [Receive/Forward] → [Common Settings].
3. Press [Forwarding Settings] → [Forward w/o Conditions] → specify the Confidential Fax Inbox as the forwarding destination.
4. Press [OK] → [Close].



Additional Information

- If the Fax Memory Lock is being used, received data is stored in the Memory RX Inbox without being printed.
- For more information, see e-Manual > Settings/Registration.

Q

37

What is the model number of the staple cartridge for the finisher or the stamp cartridge for the feeder?

A

The model numbers of the consumables for the feeder and finisher are as follows:

■ Stamp Ink Cartridge-C1

For the feeder

■ Staple-J1

For the Staple Finisher-J1, Booklet Finisher-J1, and Inner Finisher-E1

■ Staple Cartridge-D2/Staple Cartridge-D3

For the Booklet Finisher-J1

Additional Information

For information on replacing the staple cartridges and stamp cartridges, see Chapter 3, "Routine Maintenance."

Q

38

A paper jam has occurred. How do I solve this problem?


A

The procedure for clearing a paper jam is displayed on the touch panel display. Follow the instructions to clear the paper jam.

■ Fixing Unit (Inside the Main Unit)



■ Feeder



Additional Information

If the problem is still not resolved, see Chapter 4, "Troubleshooting."


Q

39

I cannot remove the toner cartridge after the toner replacement cover is opened.

A

Check the touch panel display. The following screen is displayed.



■ To remove the toner cartridge:

Press [Remove Toner Cartridges] → the inner cover for the toner to replace opens → follow the instructions on the touch panel display to remove the toner cartridge.



Black Toner Cartridge

Additional Information

For more information on replacing the toner cartridge, see Chapter 3, "Routine Maintenance."


Q

40

Numbers, such as #751 and #801 are displayed on the touch panel display. What do they mean?


A

These are error codes indicating that a job or operation did not complete successfully. They are displayed on the Details screen from [Log] on the Status Monitor/Cancel screen.



Perform the necessary procedures after referring to the causes and remedies for the error codes described in e-Manual > Problem Solving.

Additional Information

For instructions on using  (Status Monitor/Cancel), see e-Manual > Status Monitor/Cancel.

Q


41

I cannot print from the computer.
Did the machine malfunction?

A


Check the following possible causes:

- Is the network cable disconnected?



- Is it possible that there is a network problem?

- Is the machine turned ON?



- Is there a paper jam or a toner shortage?
- Did you exceed the maximum number of prints set by the Department ID Management?

Additional Information

When network trouble occurs or for information on Department ID Management settings, contact your System Manager.


Q

42

It seems as though turning OFF the machine is different from the previous imageRUNNER. I am afraid that this may be a wrong operation.

A

For the previous imageRUNNER, you needed to press and hold the control panel power switch for more than three seconds before the machine entered the Shutdown mode. However, for the imageRUNNER ADVANCE, you just need to open the main power switch cover located on the right side of the machine, and push the main power switch toward the "⏻" side.



Additional Information

For more information, see Before Using This Machine.

Q

43


The touch panel display is completely black.

A

The main power has not been turned ON, or the machine may have entered the Auto Sleep mode to save energy. Follow the procedure below.

■ Turning the main power ON


1. Check whether the power plug is firmly inserted into the outlet.
2. Open the main power switch cover located on the right side of the machine and switch the main power switch to the "I" side to turn the power ON.



■ Recovering from the Auto Sleep mode

Press the  (Energy Saver).

Additional Information

- For more information on the Auto Sleep mode and Energy Saver mode, see e-Manual > Basic Operations.
- Follow the procedure below to change the Auto Sleep Time.
 1. Press  (Settings/Registration).
 2. Press [Preferences] → [Timer/Energy Settings] → [Auto Sleep Time].
 3. Specify the time → press [OK].

Q

44


I have just sent an important document via facsimile. Can I check to make sure that it was sent correctly?

A

You can check the send job status from the Status Monitor/Cancel screen or receive notification of the sending result via e-mail.


■ To check from the Status Monitor/Cancel screen:

1. Press  (Status Monitor/Cancel).
2. Press [Send] → [Log].



■ To receive send result via e-mail:

1. Press [Fax] → [Options] → [Job Done Notice].
2. Specify the e-mail address where you want to receive the result notification.



Additional Information

If the Fax TX Report is set, you can output and check the Fax TX Report every time. Also, if the Fax Activity Report is set, you can output and check Fax Report from the past. For more information, see e-Manual > Basic Operations.

Q


45


Can I restrict the number of copies/prints?

A


If Department ID Management is used, you can restrict the color copy or print output within groups.


■ Setting the Department ID Management and Registering the Password:

1. Press  (Settings/Registration).
2. Press [Management Settings] → [User Management] → [Department ID Management].
3. Press [On] → [Register PIN] → [Register].
4. Enter the Department ID and PIN → press [OK].



■ Setting the Page Limits:

1. Press  (Settings/Registration).
2. Press [Management Settings] → [User Management] → [Department ID Management].
3. Press [On] → [Register PIN] → [Register].
4. Press [Turn Limits On/Off and Set Page Limits] → specify the page limit settings → press [OK].



Additional Information


To perform this procedure, you must have administrator privileges. For more information, see e-Manual > Security. You can also change the default settings for the Copy screen from the Color mode to the Black mode. For more information, see e-Manual > Settings/Registration.


Q

46

Can I change the language displayed on the touch panel display?

A

You can change the language displayed from [Language/Keyboard Switch] in  (Settings/Registration).





Displayed Language: English




Displayed Language: Other

■ Setting procedure:

1. Press  (Settings/Registration).
2. Press [Preferences] → [Display Settings] → [Language/Keyboard Switch On/Off].
3. Press [On] → [OK] → [Language/Keyboard Switch].
4. Select the language to display → press [OK].





Additional Information

- You can follow the procedure below to display a shortcut to the language switch on the Main Menu screen.
- 1. Press  → [Other Main Menu Settings] → 'On' for <Display [Language/Keyboard Switch]>.
- 2. Press [OK].
- For more information, see e-Manual > Basic Operations.


Q 47

Can I change the screen or the order that the functions are displayed on the touch panel display when the power is turned ON?


A



You can change the default display that appears after the machine is turned ON from [Default Screen after Startup/Restoration] in  (Settings/Registration). You can also change the order that the functions are displayed or the layout from [Main Menu Button Display Settings] in .

■ Setting the Default Display That Appears after the Machine Is Turned ON:


1. Press  (Settings/Registration).
2. Press [Preferences] → [Display Settings] → [Default Screen after Startup/Restoration].
3. Select the settings → press [OK].

■ Changing the Displayed Function:

1. Press .
2. Press [Main Menu Button Display Settings].
3. Select the layout or the order to display the function key → press [OK].



Additional Information

To perform this procedure, you must have administrator privileges. For more information, see e-Manual > Security. You can also recall the settings that are previously stored as settings for frequently used functions from . For more information, see e-Manual > Quick Menu.

Q 48

I want to check the IP address for this machine to run the Remote UI, but I do not know how to check it.

A You can check the IP address from the touch panel display of this machine.


■ Checking the IP Address of This Machine:

IPv4 Address

1. Press **Ⓢ** (Settings/Registration).
2. Press [Preferences] → [Network] → [TCP/IP Settings].
3. Select [IPv4 Settings] → [Use IPv4] → [On].
4. Press [IP Address Settings].


IPv6 Address

1. Press **Ⓢ** (Settings/Registration).
2. Press [Preferences] → [Network] → [TCP/IP Settings].
3. Select [IPv6 Settings] → [Use IPv6] → [On].
4. Press [Manual Address Settings].



■ Starting the Remote UI:

Run the Web browser for the computer → enter 'http://<IP address of the machine>' in the address bar.



Additional Information

- To perform this procedure, you must have administrator privileges. For more information, see e-Manual > Security.
- If you cannot start the Remote UI, specify the following settings.
 1. Press **Ⓢ** (Settings/Registration).
 2. Press [Management Settings] → [License/Other] → [Remote UI].
 3. Press [On] → [OK].




Q 49

Can I change the default settings of the printer driver?

A You can change the print settings of the printer driver from the computer you are using.

■ Using Windows:



1. On the [Start] menu, click [Control Panel] → [Printer].
2. Right-click the printer icon → click [Printing Preferences] → specify the printer settings.
3. Click [OK].



■ Using a Macintosh:

Page Settings:





1. Click [Page Setup] from the [File] menu in the application software.
2. Select each item as indicated below.
Setting: [Page Attributes]
Printer: The name of your printer
3. Click the <Settings> drop-down list → [Save As Default] → [OK].



Print Settings:

1. Click [Print] from the [File] menu in the application software.
2. Click the <Printer> drop-down list → select the name of your printer.
3. Click the <Presets> drop-down list → [Save As].
4. Specify [Save Preset As] → click [OK].

5. Click the <Presets> drop-down list → select the saved preset name → click [Print].




Q




50



Is there a way to adjust the sound heard when fax sending/receiving is complete?

A

You can use  (Volume Settings) on the control panel to adjust the volume.

■ Setting procedure:

1. Press  (Volume Settings) on the control panel.
2. Press  or  to adjust the Alarm Volume and Monitor Volume → press [OK].



Q

51


What is MEAP?

A

MEAP stands for Multifunctional Embedded Application Platform and is a software platform for the Canon multitasking machines. You can expand the functions or customize them by installing the MEAP application from the computer to the multitasking machine.

■ iW Function Flow

The iW Function Flow is an application that increases the efficiency of operations that use multiple functions of the machine. By creating and registering combinations of functions that are frequently used on the machine, you can repeatedly reuse the same combination of functions.



Additional Information

For more information, see e-Manual > MEAP.



CANON INC.

30-2, Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, Japan

CANON U.S.A., INC.

One Canon Park, Melville, NY 11747, U.S.A.

CANON CANADA INC.

6390 Dixie Road Mississauga, Ontario L5T 1P7, Canada

CANON EUROPA N.V.

Bovenkerkerweg 59, 1185 XB Amstelveen, The Netherlands

(See <http://www.canon-europe.com/> for details on your regional dealer)

CANON LATIN AMERICA, INC.

703 Waterford Way Suite 400 Miami, Florida 33126 U.S.A.

CANON AUSTRALIA PTY. LTD

1 Thomas Holt Drive, North Ryde, Sydney, N.S.W. 2113, Australia

CANON CHINA CO., LTD

15F Jinbao Building No.89 Jinbao Street, Dongcheng District, Beijing 100005, China

CANON SINGAPORE PTE. LTD.

1 HarbourFront Avenue #04-01 Keppel Bay Tower, Singapore 098632

CANON HONGKONG CO., LTD

19/F., The Metropolis Tower, 10 Metropolis Drive, Hunghom, Kowloon, Hong Kong

