


Large Format Printer



iPF685

User's Guide



Basic Printing Workflow	15
Enhanced Printing Options	29
Printing CAD Drawings Printing enlargements or reductions Printing at full size Borderless Printing Printing banners or at other non-standard sizes Tiling and multiple pages per sheet Centering originals and so on	
Windows Software	141
Printer Driver Preview Free Layout Color imageRUNNER Enlargement Copy Print Plug-In for Office and so on	172 182 203
Mac OS Software	249
Printer Driver Preview Free Layout Color imageRUNNER Enlargement Copy and so on	268
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

Manuals for this printer

Setup Guide

Quick Guide

Basic Guide Electronic manual

User's Guide | Electronic manual

Paper Reference Guide Electronic manual

	Basic Printing Workflow	15
	Printing procedure Printing Options Using Rolls and Sheets Turning the Printer On and Off Loading and Printing on Rolls Loading and Printing on Sheets Printing in Windows Printing from Mac OS	17 18 21
	Canceling print jobs Canceling Print Jobs from the Control Panel	25 25
1	Enhanced Printing Options	29
	Choosing Paper for Printing Choosing a Paper for Printing Specifying Paper in the Printer Driver	
)	Printing Photos and Office Documents	31
	Printing Photos and Images Printing Photos and Images (Windows) Printing Photos and Images (Mac OS) Printing Office Documents Printing Office Documents (Windows) Printing Office Documents (Mac OS) Using PosterArtist to Compose Originals	31 33 35 35
	Printing CAD Drawings Printing CAD Drawings Printing Line Drawings and Text Printing Line Drawings and Text (Windows) Printing Line Drawings and Text (Mac OS) Printing from AutoCAD Specifying Colors and Printing CAD Drawings Specifying Colors and Printing CAD Drawings (Windows) HP-GL/2 Printing	. 40 . 41 . 42 . 44 . 45 . 46
	Adjusting Images Adjusting the Color in the Printer Driver Fine-Tuning Colors of Photos and Images (Windows) Fine-Tuning Colors of Photos and Images (Mac OS) Giving Priority to Particular Graphic Elements and Colors for Printing Choosing the Document Type and Printing Conditions (Windows) Choosing the Document Type and Printing Conditions (Mac OS)	49 52 54
	Printing enlargements or reductions Resizing Originals to Match the Paper Size	60 . 60 60 62 . 62
	Resizing Originals by Entering a Scaling Value Resizing Originals by Entering a Scaling Value (Windows)	65

Resizing Originals by Entering a Scaling Value (Mac OS)	6/
Printing at full size	70
Printing on Oversize Paper	70
Printing at Full Size (Windows)	
Printing at Full Size (Mac OS)	
Borderless Printing at Actual Size	
Borderless Printing at Actual Size (Williams)	
- · · · ·	
Borderless Printing	79
Borderless Printing on Paper of Equivalent Size	
Borderless Printing by Resizing Originals to Water the Paper Size (Windows)	
Borderless Printing by Resizing Originals to Fit the Roll Width (Windows)	
Borderless Printing by Resizing Originals to Fit the Roll Width (Mac OS)	. 85
Printing banners or at other non-standard sizes	88
Printing Vertical or Horizontal Banners (Large-Format Printing)	. 88
Printing Vertical or Horizontal Banners (Large-Format Printing; Windows)	
Printing Vertical or Horizontal Banners (Large-Format Printing; Mac OS)	
Printing on Non-Standard Paper Sizes Printing on Non-Standard Paper Sizes (Windows)	
Printing on Non-Standard Paper Sizes (Windows)	
Tiling and multiple pages per sheet	101
Printing Multiple Originals Next to Each Other	
Printing Multiple Originals Next to Each Other (Mac OS)	
Printing Multiple Pages Continuously	
Printing Multiple Pages Continuously (Windows)	
Printing Multiple Pages Continuously (Mac OS)	
Printing Multiple Pages Per Sheet	
Printing Multiple Pages Per Sheet (Mac OS)	
Printing Posters in Sections	
Printing Large Posters (Windows)	113
Centering originals	115
Printing Originals Centered on Rolls	115
Printing Originals Centered on Rolls (Windows)	115
Printing Originals Centered on Rolls (Mac OS)	
Printing Originals Centered on Sheets	
Printing Originals Centered on Sheets (Windows)	
, , ,	
Conserving roll paper	123
Conserving Roll Paper by Rotating Originals 90 Degrees	
Conserving Roll Paper by Rotating Originals 90 Degrees (Mac OS)	
Conserving Roll Paper by Printing Originals Without Top and Bottom Margins	
Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Windows)	
Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Mac OS)	128
Checking Images Before Printing	130
Checking the Layout in a Preview Before Printing	130
Other useful settings	131
Printing With Watermarks	
Printing with Watermarks—COPY, FILE COPY, and so on (Windows)	
Making the Original Orientation Match the Paper Orientation	
Making the Original Orientation Match the Paper Orientation (Windows)	
Using Favorites	

Cutting Roll Paper After Printing	137
Cutting Roll Paper After Printing (Windows)	137
Cutting Roll Paper After Printing (Mac OS)	138

Windows Software	141
Printer Driver	142
Printer Driver Settings	. 142
Specifying Paper in the Printer Driver	. 144
Confirming Print Settings	. 145
Checking the Layout in a Preview Before Printing	. 145
Using Favorites	
Accessing the Printer Driver Dialog Box from Applications	
Accessing the Printer Driver Dialog Box from the Operating System Menu	
Main Sheet	
Paper Information on Printer Dialog Box	
Paper Detailed Settings Dialog Box	
View Settings Dialog Box for the Printing Application	
Color Adjustment Sheet: Color	
Object Adjustment Dialog box: Color	
Matching Sheet	
Object Adjustment Dialog box: Monochrome	
Page Setup Sheet	
Output Method Dialog box	
Paper Size Options Dialog Box	
Layout Sheet	
Page Options Dialog Box	
Special Settings Dialog Box	
Favorites Sheet	
Utility Sheet	
Support Sheet	. 170
Settings Summaries Dialog Box	. 170
Device Settings Sheet	. 171
Preview	172
The Features of Preview	
Starting Preview	. 172
Preview Main Window	. 173
Dialog Area	
Enlarge/Reduce the screen display	
Moving a Page	
Using the ruler	
Priority setting for rotating 90 degrees	
Printing with Selecting the Layout	
Print on the Center	
Not Print Spaces at the Top/Bottom	. 181
Free Layout	182
The Features of Free Layout	
Starting Free Layout	
Free Layout Main Window	
Detailed Settings	
Preferences Dialog Box	
Page Options Dialog Box	
Zoom Dialog Box	. 10/

Format Dialog Box	
Laying out a Multiple-File Document on One Page	
Laying out a Document Created with Multiple Application Programs on One Page	191
Selecting an Object	
Changing the Object Size	194
Moving an Object	194
Rotating an Object	195
Laying out Objects Automatically	. 195
Aligning Objects	195
Changing the Object Overlapping Order	197
Pasting a Copied or Cut Object	. 198
Folded Duplex Window	199
Finished Size Settings Dialog Box	200
Binding Settings Dialog Box	201
Prints using Folded Duplex	201
Color in a ne DUNNED Follows and Const	202
Color imageRUNNER Enlargement Copy	203
The Features of Color imageRUNNER Enlargement Copy	
Starting Color imageRUNNER Enlargement Copy	
Color imageRUNNER Enlargement Copy Dialog Box	
Hot Folder	205
Creating a New Hot Folder	205
Specifying an Existing Shared Folder as a Hot Folder	208
Setting the Print Parameters	. 210
Printing Enlargements of Scanned Originals from a Color imageRUNNER	211
Print Plug-In for Office	212
Print Plug-In for Officefeatures	212
Steps to install	
Steps to uninstall	
When Print Plug-In for Office is not displayed	
To start from Microsoft Word	
Print Matching Roll Width(Word)	
Borderless Printing(Word)	
Multi-Page Printing(Word)	
Register the settings (Word)	
Print Using Registered Settings(Word)	
Portrait Orientation/Landscape Orientation(Word)	
To start from Microsoft PowerPoint	
Print Matching Roll Width(PowerPoint)	
Borderless Printing(PowerPoint)	
Multi-Page Printing(PowerPoint)	
Register the settings (PowerPoint)	
Print Using Registered Settings(PowerPoint)	
Print Using Registered Settings(PowerPoint)	
To start from Microsoft Excel	
Print Entire Sheet(Excel)	
Print Selected Area(Excel)	
Configuring Binding (Excel)	
Ournigating Opedial Octilings	24 I
Mac OS Software	249
Printer Driver	250

Printer Driver Settings	. 250
Specifying Paper in the Printer Driver	. 251
Confirming Print Settings	
Checking the Layout in a Preview Before Printing	
Using Favorites	
Accessing the Printer Driver Dialog Box from Applications	
Main Pane	
Paper Detailed Settings Dialog Box	

Color imageRUNNER Enlargement Copy

The Features of Color imageRUNNER Enlargement Copy	
Starting Color imageRUNNER Enlargement Copy	
Color imageRUNNER Enlargement Copy Dialog Box	
Hot Folder	
Creating a New Hot Folder	
Editing a Hot Folder (Setting Print Conditions)	
Deleting a Hot Folder	
Paper Settings Panel Parameters	
Easy Settings	
Advanced Settings	
Output Settings Panel	
Color Settings Panel	
Driver Matching Mode	
ICC Matching Mode	324
Printing Enlargements of Scanned Originals from a Color imageRUNNER	325
Handling and Use of Paper	327
Paper	328
Types of Paper	328
Paper Sizes	
Using Paper Other Than Genuine Paper and feed confirmed Paper	
Printing on Paper Other Than Genuine Paper and feed confirmed Paper Using Existing Settings	
Displaying the Paper Reference Guide	
Updating paper information	. 334
Handling rolls	338
Attaching the Roll Holder to Rolls	. 338
Loading Rolls in the Printer	
Changing the Type of Paper	
Specifying the Paper Length	
Removing the Roll from the Printer	
Removing the Roll Holder from Rolls	
Feeding Roll Paper Manually Keeping Track of the Amount of Roll Paper Left	
Specifying the Ink Drying Time for Rolls	
Specifying the Cutting Method for Rolls	
Cutting the Leading Edge of Roll Paper Automatically	
Reducing Dust from Cutting Rolls	
Handling sheets	359
Loading Sheets in the Printer	
Removing Sheets	
Output Stacker	365
Using the Output Stacker	. 303
Media Configuration Tool (Windows)	370
The Features of Media Configuration Tool	
Installation Procedures	
Starting Method	
Media Configuration Tool Main Window Editing Media Type Information for Genuine Paper and Feed Confirmed Paper	
Adding Media Types	
Changing Media Names	
Deleting Media Types You Have Added	
Switching Media Types Display Show/Hide	
Changing the Display Order of Media Types	
Checking the update	

	Media Configuration Tool (Mac OS)	383
Handling	The Features of Media Configuration Tool	
ig and	Procedures for Installing	
<u>ام</u>	Starting Method	
Use of Paper	Editing Media Type Information for Genuine Paper and Feed Confirmed Paper	
of Pa	Adding Media Types	
aper	Changing Media Names	
	Deleting Media Types You Have Added	
	Changing the Display Order of Media Types	
	Checking the update	
Cor	Control Panel	899
Control Panel	Operations and Display Screen	400
Jane	Control Panel	
<u> </u>	Control Panel Display	
	How to View Instructions with Navigate	
	Checking Instructions During Printer Operations	407
	Printer Menu	408
	Printer Menu Operations	
	Menu Operations	
	Menu Settings	
	Status Print	
	Printing Interface Setting Reports	431
	Drinter Dorte	125
Printer Parts	Printer Parts 4	135
Parl	Printer parts	436
୍ଷ	Front	
	Side	
	Roll Cover (Inside)	
	Carriage	439
	Ink Tank Cover (Inside)	440
	Hard Disk	441
	Printer Hard Disk Operations	
	Checking the Free Hard Disk Space Erasing Data on the Printer's Hard Disk	
	·	
	Optional accessories	445
	Roll Holder Set	
		110
Network Setting	Network Setting 4	147
ork s	Network Environment	448
) ettir	Network Environment	448
	Using RemoteUI	450
	Using RemoteUI	450
	Initial Settings	452
	Configuring the IP Address on the Printer	
	Configuring the IP Address Using the Printer Control Panel	
	Configuring the IP Address Using ARP and PING Commands	433

	(9

Configuring TCP/IPv6 Network Settings	
Configuring the Printer Driver Destination (Windows) Configuring the Printer Driver Destination (Mac OS)	
Configuring the Printer's TCP/IP Network Settings With RemoteUI	
Mac OS Settings	459
Configuring the Destination in TCP/IP Networks	
Configuring the Destination for Bonjour Network	459
Other Settings	460
Specifying Printer-Related Information	
Configuring the Communication Mode Manually	
Email Notification When Printing is Finished or Errors Occur Initializing the Network Settings	
Device Setup Utility (Windows)	463
imagePROGRAF Device Setup Utility	
Installing imagePROGRAF Device Setup Utility	
Configuring the IP Address Using imagePROGRAF Device Setup Utility	463
Driet Jak Managaran	1.67
Print Job Management	467
Status Monitor (Windows)	468
The Features of imagePROGRAF Status Monitor	
Job Management Using imagePROGRAF Status Monitor	469
Printmonitor (Mac OS)	470
The Features of imagePROGRAF Printmonitor	
Job Management Using imagePROGRAF Printmonitor	
Accounting (Windows)	472
Accounting Manager	
Accounting Manager Main Window	
Job List Area	
Accounting Manager Basic Procedures	
Configuring Unit Costs in Accounting Manager	
Setting the Unit Cost for Paper	
Setting the Unit Cost for Items Other Than Ink and Paper	
Configuring Units and Display Settings in Accounting Manager	
Automatically Acquiring Print Job Logs at Regular Intervals	
Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs	
Exporting Print Job Data as a CSV File	
Displaying Job Properties or Period Properties	
Showing, Saving and Loading Selected Unit Cost Data	
Basic Print Job Operations	484
Using the Printer Hard Disk	
Saving Print Jobs on the Printer Hard Disk	
Managing the Job Queue (Deleting or Preempting Other Jobs)	
Managing Pending Jobs (Printing or Deleting Jobs on Hold)	
Deleting Saved Jobs	
Moving Saved Jobs	
Advanced Print Job Operations	503
Saving Print Jobs Sent from Sources Other than the Printer Driver	
Printing Without Saving Jobs in the Common Box	
Setting Passwords for Personal Boxes Naming Personal Boxes	
Nathing 500 100	500

t Job M	Displaying Details of Saved Jobs	
t Job Management		
Adju	Adjustments for Better Print Quality	521
Adjustments for Better Print Quality	Adjusting the Printhead	522
nts f	Adjusting the Printhead	
의 교	Automatic Adjustment to Straighten Lines and Colors	
etter	Adjusting Line Misalignment	
Print	Troubleshooting Paper Abrasion and Blurry Images	527
<u>Q</u>	Adjusting the feed amount	529
ality	Adjusting the Feed Amount	
	Selecting a Feed Amount Adjustment Method	
	Manual Banding Adjustment	
	Fine-Tuning the Paper Feed Amount	
	Adjusting Line Length	
Maintenance and Consumables	Maintenance and Consumables	537
itenar	Ink Tanks	538
nce a	Ink Tanks	
and o	Replacing Ink Tanks	
Con	When to Replace Ink Tanks	
Suma	Attach the lnk Tank Cover to the printer	544
ables	Printheads	546
	Printhead	
	Checking for Nozzle Clogging	
	Replacing the Printhead	
	Maintenance Cartridge	554
	Maintenance Cartridge	554
	Replacing the Maintenance Cartridge	
	Checking the Remaining Maintenance Cartridge Capacity	
	Cleaning the Printer	560
	Cleaning the Printer Exterior	
	Cleaning Inside the Top Cover	
	Other Maintenance	564
	Preparing to Transfer the Printer	
	Preparing to Transfer the Printer Reinstalling the Printer Updating the Firmware	567

Iroubleshooting	5/1
Frequently Asked Questions	572
Frequently Asked Questions	572
Problems Regarding Paper	573
Clearing Jammed Roll Paper Clearing a Jammed Sheet Clearing Jammed Paper (Paper Feed Slot)	576
Roll paper cannot be inserted into the Paper Feed Slot Cannot load sheets Paper is not cut neatly	580
Paper is not cut	
The size of clear film cannot be detected	
Printing does not start	582
The Data lamp on the Control Panel does not light up	
The printer does not respond even if print jobs are sent	
The display screen indicates Agitating	
The printer stops during a print job	583
An error message is shown on the Display Screen	
The printer ejects blank, unprinted paper	
Problems with the printing quality	584
Printing is faint	
The edges of the paper are dirty	
The surface of the paper is dirty	
The back side of the paper is dirty	
Printed colors are inaccurate	
Banding in different colors occurs	
Image edges are blurred or white banding occurs	
The contrast becomes uneven during printing	588
The length of printed images is inaccurate in the feeding direction	
Documents are printed in monochrome	
Line thickness is not uniform	
Cannot print over a network	590
Cannot connect the printer to the network	
Cannot print over a Bonjour network	
Installation problems	591
The computer does not recognize the printer	
HP-GL/2 problems	593
With HP-GL/2, printing is misaligned	
Lines or images are missing in printed HP-GL/2 jobs.	
Lines are printed too thick or thin in HP-GL/2 print jobs	
HP-GL/2 jobs are printed in monochrome (or color)	
HP-GL/2 jobs are printed 6 mm larger than specified	
HP-GL/2 jobs are printed at maximum size, even if a standard size is specified	594
HP-GL/2 printing takes a long time	
The printer stops when printing a HP-GL/2 job (the carriage stops moving)	594

Other problems	595
The Ink Tank Cover has become detached from the printer	. 595
The printer does not go on	
The printer takes time to start up	
If the Printer Makes a Strange Sound	
The printer consumes a lot of ink	
Ink Level Detection	
Error Message	599
Error Messages	600
Messages regarding paper	602
Paper mismatch	. 602
MediaType Mismatch	
The paper is too small.	
The paper is too small.	
PaprWidth Mismatch	
Insufficient paper for job	
This paper cannot be used.	
Roll printing is selected.	
Roll printing is selected, but sheets are loaded.	
The roll is empty.	. 606
Sheet printing is selected.	
Regular printing is selected, but a roll is loaded.	
Paper jam	
Paper is crooked.	
Paper not aligned with right guide. Cannot detect papr	
Leading edge detection error.	
Paper cutting failed.	
End of paper feed.	
Rel lever is in wrong position.	
Borderless printng not possible.	
Paper position not suitable for borderless printing.	
Roll paper is not securely in contact with roll holder.	. 609
Messages regarding ink	610
Ink insufficient. No ink left.	
Remaining level of the ink cannot be correctly detected. Check ink tank.	
Cannot detect ink level correctly. Close tank cover.	
Close Ink Tank Cover	
Ink tank is empty.	. 611
Not much ink is left.	. 611
Check if ink tank is set, and its color and direction.	
The following ink tanks cannot be recognized.	
Wrong ink tank	
Messages regarding printing or adjustment Cannot adjust paper feed.	612
Check printed document.	
Messages regarding printheads	613
Cannot adjust printhead.	. 613
Wrong printhead.	
Printhead error	. 613
Cannot recognize print head.	
Execute printhead cleaning.	. 614

	Messages regarding the maintenance cartridge	615
Or >	Insert the maintenance cartridge.	615
Error Message	Wrong maintenance cartridge	615
sag	Maint. cart. The level is low	615
Ф	No Maintenance Cartridge capacity.	615
	Maintenance cartridge full.	
	Maintenance cartridge problem.	615
	Messages regarding the hard disk	616
	Hard disk error	616
	File read error.	
	The mail box is full.	
	Mail box full. Now printing without saving data.	
	Mail box nearly full.	
	Maximum jobs stored.	
	Mail box full. Delete unwanted data	616
	Messages regarding HP-GL/2	618
	This type of paper is not compatible with HP-GL/2.	
	GL2: Wxxxx The memory is full. (xxxx is 0501, 0903, or 0904)	
	GL2: W0502 The parameter is out of range.	
	GL2: W0504 This command is not supported.	618
	Other Messages	619
	GARO Wxxxx (x represents a number)	
	ERROR Exxx-xxxx (x represents a letter or number)	
	Hardware error. xxxxxxxx (x represents a letter or number)	
	Top cover is open.	
	Prepare for parts replacement.	
	Parts replacement time has passed. Unknown file.	
	Multi-sensor error	
	Error in cutter position.	
Sp	Specifications	521
Specifications	Printer Specifications	622
atio	·	
S	Specifications Print Area	
	FILIT AREA	023
Þ	Appendix	525
Appendix		
<u>X</u>	Safety Precautions	626
	Safety Precautions	
	Legal Notices	628
	Manuals for this printer	630
	Manuals for this printer	
	About This User Manual	630
	Disposal of the product	632
	WEEE Directive	632

Memo

User's Guide

Basic Printing Workflow

Printing procedure	16
Canceling print jobs	24
Pausing Printing	27

Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

Printing procedure

Printing Options Using Rolls and Sheets	16
Turning the Printer On and Off	17
Loading and Printing on Rolls Loading and Printing on Sheets	21
 → Specifying Paper in the Printer Driver (Windows) → Specifying Paper in the Printer Driver (Mac OS) 	251
Printing in Windows Printing from Mac OS	

Printing Options Using Rolls and Sheets

The printer supports both rolls and sheets.

This section introduces the main features of each, as well as the main printing methods available. Select rolls or sheets to suit your particular printing application.



- For information on the types of paper the printer supports, see "Types of Paper." →P.328
- A variety of other ways to print are available besides those introduced here. For details, see "Enhanced Printing Options." >P.29

Roll printing

Media in spooled rolls is generally called Roll Media. Rolls are loaded on the Roll Holder, which are in turn loaded in the printer.

Rolls can be used to print large photos or create posters or banners that cannot be printed on regular sheets.

Large-format printing

Easily print vertical or horizontal banners from familiar applications such as Microsoft Office applications. (See "Printing Vertical or Horizontal Banners (Large-Format Printing).") →P.88

Borderless printing

Print without a margin (border) around posters or photos.

(See "Borderless Printing on Paper of Equivalent Size.") →P.79

(See "Borderless Printing by Resizing Originals to Fit the Roll Width.") →P.82

(See "Borderless Printing at Actual Size.") →P.74

Banner printing

You can print multiple pages as a single continuous image, without margins between pages. (See "Printing Multiple Pages Continuously.") →P.104

90-degree rotation before printing

Originals in portrait orientation are rotated 90 degrees when possible to use paper more efficiently. (See "Conserving Roll Paper by Rotating Originals 90 Degrees.") >P.123

Enlarged/reduced printing

You can freely adjust the size of originals by enlarging or reducing originals before printing.

(See "Resizing Originals to Match the Paper Size.") →P.60

(See "Resizing Originals to Fit the Roll Width.") → P.62

(See "Resizing Originals by Entering a Scaling Value.") →P.65

Free Layout (Windows) and imagePROGRAF Free Layout (Mac OS)

Print multiple documents from multiple applications (such as word-processing programs, spreadsheet programs, and so on) next to each other.

(See "Printing Multiple Originals Next to Each Other.") →P.101

Sheet printing

Sheets refer to individual sheets of paper.

Insert the sheet between the Platen and the Paper Retainer.

Enlarged/reduced printing

You can freely adjust the size of originals by enlarging or reducing originals before printing. (See "Resizing Originals to Match the Paper Size.") >P.60 (See "Resizing Originals by Entering a Scaling Value.") >P.65

Free Layout (Windows) and imagePROGRAF Free Layout (Mac OS)
 Print multiple documents from multiple applications (such as word-processing programs, spreadsheet programs, and so on) next to each other.
 (See "Printing Multiple Originals Next to Each Other.") →P.101

Turning the Printer On and Off

Turning the printer on


Press the **Power** button to turn on the printer.
The printer will now start up.
After the Display Screen shows the Canon logo, "**Starting up... Please wait.**" is displayed.



The **Power Lamp** is lit when the printer finishes starting up, and the printer is now in **Standby**.

The printer will not go into **Standby** in the following situations. Take the appropriate action.





- The Top Cover is open Close the Top Cover.
- The Ink Tank Cover is open Close the Ink Tank Cover.
- The Printhead is not installed see "Replacing the Printhead." →P.548
- An Ink Tank is not installed see "Replacing Ink Tanks." →P.538
- If "ERROR" is shown on the Display Screen see "Error Messages." (→P.600)
- The Power Lamp and Message Lamp are not lit (even once), and nothing appears on the Display Screen

Make sure the printer is plugged in correctly. Check the connection at the plug and electrical outlet.

No paper is loaded

Load paper. (See "Loading and Printing on Rolls.") →P.18 (See "Loading and Printing on Sheets.") →P.21

Turning the printer off



• Never disconnect the printer's power supply or unplug it during a print job. This may damage the printer.

Make sure no print jobs are in progress.

If the **Message Lamp** is flashing, check the message on the Display Screen and take action as necessary. (See "Error Messages.")
PROOF



If the **Data Lamp** is flashing, the printer is receiving a print job. Turn off the printer only after printing is finished.



Hold down the **Power** button for more than a second.

After "Shut Down.. Please Wait.." is shown on the Display Screen, the printer shuts off.



Loading and Printing on Rolls

These are the basic steps for loading and printing on rolls. Follow these steps to load and print on rolls.




- For details on supported sizes and types of rolls, see **Paper Sizes** or the **Paper Reference Guide**. (See "Paper Sizes.") →P.328 (See "Types of Paper.") →P.328
- If you prefer to wait for the ink to dry after printing and simply eject the document, you can deactivate automatic cutting and cut the paper manually. (See "Specifying the Cutting Method for Rolls.") →P.352


1 Turn the printer on. (See "Turning the Printer On and Off.") →P.17




2 Load the roll on the Roll Holder. (See "Attaching the Roll Holder to Rolls.") →P.338



Load the roll in the printer. (See "Loading Rolls in the Printer.") →P.341






Select the type of paper. (See "Changing the Type of Paper.") →P.343





- If no barcode has been printed on the roll and you have set ManageRemainRoll to On, specify the roll length after the type of paper. (See "Specifying the Paper Length.") →P.345
- 5 Complete settings in the printer driver for the type of paper and other details.
 - Specifying Paper in the Printer Driver (Windows) →P.144
 - Specifying Paper in the Printer Driver (Mac OS) →P.251



- 6 Send the print job.
 - Printing in Windows → P.22
 - Printing from Mac OS →P.23

The printer now starts printing the print job.

Loading and Printing on Sheets

These are the basic steps for loading sheets and then printing. Follow the steps below to load and print on sheets.




• For details on supported types and sizes of paper, see Paper Sizes or the Paper Reference Guide. (See "Paper Sizes.") →P.328 (See "Types of Paper.") →P.328



Turn the printer on. (See "Turning the Printer On and Off.") →P.17



- 2 Complete settings in the printer driver for the type of paper and other details.
 - Specifying Paper in the Printer Driver (Windows) →P.144
 - Specifying Paper in the Printer Driver (Mac OS) →P.251




- 3 Send the print job.
 - Printing in Windows →P.22
 - Printing from Mac OS →P.23

Printing in Windows iPF685



Load the sheet. (See "Loading Sheets in the Printer.") →P.359

The printer now starts printing the print job.



Printing in Windows

Print from the application menu.




- We recommend exiting unnecessary applications before printing. Running several applications while printing may interrupt the transfer of print data and affect printing quality.
- 1 In the source application, select **Print** from the **File** menu to display the dialog box for printing conditions.
- After confirming that the printer is selected in the dialog box, click **Print** or **OK** to start printing.



tion

 The appearance of the dialog box varies depending on the software application. In most cases, the dialog box includes basic printing options and enables you to choose the printer, specify the range of pages, number of copies, and so on.
 Example: Print dialog box displayed by the applica-



• If another printer is selected, select the printer you want to use under **Select Printer** or in the dialog box displayed after clicking **Printer**.

Settings for many printing methods (including enlarged or reduced printing, borderless printing, and so on) are displayed in the printer driver dialog box. There are two ways to access the printer driver dialog box, as follows.

From the application
 (See "Accessing the Printer Driver Dialog Box from Applications .") →P.148

iPF685 Printing from Mac OS

• From the operating system menu (See "Accessing the Printer Driver Dialog Box from the Operating System Menu .") →P.149

Printing from Mac OS

Print from the application menu after registering the printer.



We recommend exiting unnecessary applications before printing. Running several applications while printing may
interrupt the transfer of print data and affect printing quality.

Registering the printer

The printer needs to be registered in **Print & Scan** (identified as **Printers & Scanners** or **Print & Fax** in other versions of Mac OS X) in **System Preferences** before printing.

For instructions on registering the printer, see "Configuring the Printer Driver Destination ." (>P.455)



• During this setup process, the printer will not be listed among available printers if it is off or disconnected.

Printing from the application software

1 In the application software, select **Print** from the **File** menu to display the dialog box for printing conditions.




 This dialog box includes basic printing options and enables you to choose the printer, specify the range of pages, number of copies, and so on.

2 Select the printer in the **Printer** list.



Click **Print** to start printing.

As shown in the following illustration, you can switch to other panes in this dialog box to complete settings for various methods of printing, including enlarged and reduced printing, borderless printing, and so on.



Canceling print jobs

Canceling Print Jobs from the Control Panel	24
Canceling Print Jobs from Windows	. 25
Canceling Print Jobs from Mac OS	. 25


Canceling Print Jobs from the Control Panel

To cancel printing or reception of print jobs, press the **Stop** button on the Control Panel.




When you press the **Stop** button during printing, printer operation varies depending on the current status.

If you press the **Stop** button before printing starts
 Pressing the **Stop** button before printing starts will display a confirmation message. To cancel the print job, select **Yes**.



• If you press the **Stop** button during printing

Pressing the **Stop** button during printing will display a confirmation message. To cancel the print job immediately, select **Yes**.



The printer stops immediately.

Canceling Print Jobs from Windows


In the printer window, you can cancel jobs that are being sent to the printer.

Using **imagePROGRAF Status Monitor**, you can cancel print jobs that have already been received by the printer or that are currently being printed.


1 Click the printer icon in the taskbar to display the printer window.



- You can proceed from the folder for configuring the printer settings in the OS you are using.
 For example, in Windows 7, open the **Devices and Printers** window from the **start** menu and double-click the printer icon.
- Right-click the job to cancel and select Cancel.



- If the job to cancel is not shown in the printer window (that is, if the print data has already been received by the printer), double-click the taskbar icon to display **imagePROGRAF Status Monitor**.
- 4 On the **Printer Status** sheet, click **Cancel Job**.





The screen may differ slightly depending on the model you are using.

Canceling Print Jobs from Mac OS

In the printer window, you can cancel jobs that are being sent to the printer.

Otherwise, you can cancel jobs from imagePROGRAF Printmonitor if they have been received by the printer or are currently being printed.



- Print jobs are shown in the printer window while they are being sent from the computer. After transmission, jobs are not displayed even during printing.
- Print jobs are displayed in the imagePROGRAF Printmonitor window from the moment the printer starts receiving
 the print data until the moment printing is finished. They are not displayed before print data is sent to the printer,
 even if the computer has started preparing the print data.
- 1 Click the printer icon in the **Dock** to display the printer window.


2 Either click × for the job to cancel printing or select the job to cancel printing and then click **Delete** to delete the job.



If there are no jobs to stop in the printer window (if sending the print data to the printer has finished), either click **Settings**, **Utility**, and then **Open Printer Utility**, or click **Utility** to open the imagePROGRAF Printmonitor.



Select the print job to cancel and click to delete the print job.





The screen may differ slightly depending on the model you are using.

The job sent to the printer is canceled.

5 Exit imagePROGRAF Printmonitor. In the printer window, click **Resume** or **Resume Printer**.



 Always follow these steps if you cancel print jobs from imagePROGRAF Printmonitor. If you do not restart job processing, the next job cannot be printed. Pausing Printing

Pausing Printing

Pausing Printing

During printing, if you set Pause Print in the Control Panel menu to On, printing is stopped at that point and the printer enters a state in which printing is paused. (See "Control Panel Display.") →P.402 Printing from the job queue is not possible in this state.

To restore normal operation after this state, set Pause Print to Off.



- In the following cases, the status is cleared even if you do not set Pause Print to Off, and printing from the job queue resumes.
 - When paper is advanced
 - When you execute Chg. Paper Type in the Paper Menu
- During printing, on the Tab Selection screen of the Control Panel, press ◀ or ▶ to select the Job tab (🔡).





- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button. The **Job Menu** is displayed.
- Press ▲ or ▼ to select **Pause Print**, and then press the **OK** button.
- Press ▲ or ▼ to select **On** or **Off**, and then press the **OK** button.

Memo

15

Enhanced Printing Options

Choosing Paper for Printing	30
Printing Photos and Office Documents	31
Printing CAD Drawings	40
Adjusting Images	48
Printing enlargements or reductions	60
Printing at full size	70
Borderless Printing	79
Printing banners or at other non-standard sizes	88
Tiling and multiple pages per sheet	101
Centering originals	115
Conserving roll paper	123
Checking Images Before Printing	130
Other useful settings	131

Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

30179 S-135

Choosing Paper for Printing

Choosing a Paper for Printing	30
→ Changing the Type of Paper	
Specifying Paper in the Printer Driver	30
→ Specifying Paper in the Printer Driver (Windows)	. 144
→ Specifying Paper in the Printer Driver (Mac OS)	. 251

Choosing a Paper for Printing

Select the appropriate media type from the printer control panel or printer driver to match the paper loaded in the printer. The appropriate media type differs between the case of genuine Canon paper or Canon feed confirmed paper and the case of paper other than Canon feed confirmed paper. Select the media type by following the description below.

For information on how to select the media type in the printer control panel, see Changing the Type of Paper →P.343 , and for information on how to select the media type in the printer driver, see Specifying Paper in the Printer Driver (Windows) →P.144 or Specifying Paper in the Printer Driver (Mac OS) →P.251 .



 If you use paper other than Canon feed confirmed paper, Canon provides absolutely no guarantees regarding print quality or paper feed properties.



- Genuine Canon paper and Canon feed confirmed paper are detailed in Paper Reference Guide.
- An error message is displayed on the printer Control Panel if the media type specified in the printer driver does not
 match the media type specified in the printer. Although you can print under these conditions, the printing results
 may not be suitable.
- Genuine Canon paper or Canon feed confirmed paper

For genuine Canon paper or Canon feed confirmed paper, select the settings that are optimized for that type of paper. For more information on the settings for genuine Canon paper or Canon feed confirmed paper, see "Displaying the Paper Reference Guide." P.331

Paper other than Canon feed confirmed paper

For paper other than Canon feed confirmed paper, printing can be performed easily by selecting the existing settings provided by the printer control panel or printer driver. For details, see "Using Paper Other Than Genuine Paper and feed confirmed Paper."

P.330

Specifying Paper in the Printer Driver

If you replace the paper, complete the printer driver settings for the paper type and size. For instructions on configuring paper settings in the printer driver, refer to the following topics, as appropriate for your computer and operating system.

- Specifying Paper in the Printer Driver (Windows) →P.144
- Specifying Paper in the Printer Driver (Mac OS) →P.251

Printing Photos and Office Documents

Printing Photos and Images	31
Printing Photos and Images (Windows)	
Printing Photos and Images (Mac OS)	
Printing Office Documents	35
Printing Office Documents (Windows)	
Printing Office Documents (Mac OS)	
Using PosterArtist to Compose Originals	38

Printing Photos and Images

By selecting the following Print Target from Easy Settings of the printer driver, you can easily configure the printing of illustrations and photos.

	Print Target	Description
SRGB_	Photo (Color)	Print photographic images from digital cameras with an optimal setting.
PECDS 122 au	Poster	An optimal setting for posters. Print in vivid colors with impact and high saturation.
	Faithful Color Reproduction	Print with minimum color difference. Suitable for printing scanner images and when print results are too vivid.



Depending on the **Media Type** setting, some **Print Target** options may not be available.



You can check the settings values for each print target by clicking View Settings.

Note • You can also fine-tune these values as needed. (Advanced Settings) For details on Advanced Settings, see "Giving Priority to Particular Graphic Elements and Colors for Printing." → P.54

For instructions on printing photos and images, refer to the following topics, as appropriate for your computer and operating system.


- Printing Photos and Images (Windows) →P.31
- Printing Photos and Images (Mac OS) →P.33

Printing Photos and Images (Windows)

This topic describes how to print photos based on the following example.

- · Document: Photo image from a digital camera
- Page size: 10×12 inches (254.0×304.8 mm)
- Paper: Roll
- Paper type: Canon Premium Glossy Paper 2 280
- Roll paper width: 10 inches (254.0 mm)
- Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") →P.148

3 Make sure the **Main** sheet is displayed.




In the A Media Type list, select the type of paper that is loaded. In this case, click Canon Premium Glossy Paper 2 280.


In the A Media Type, choose the type of paper used for printing, such as Glossy Paper, Canon Coated Paper, and so on. Make sure the paper you select is loaded in the printer.



- The paper type setting in the printer driver and related software (as well as on the Control Panel) is updated when you install the Media Configuration Tool from the User Software CD-ROM or if you change paper information by using the Media Configuration Tool. For details, see "Media Configuration Tool (Windows)." >P.370
- 5 After confirming that DEasy Settings is selected, click Photo (Color) in the EPrint Target list.



6 Click the Page Setup tab to display the Page Setup sheet.



- 7 In the A Page Size list, click the size of the original as specified in the application. In this case, click 10"x12".
- 8 Select and click a roll paper in the LPaper Source list.
- 9 Select the width of the loaded roll in the MRoll Paper Width list—in this case, 10-in. Roll (254.0mm).
- Specify additional printing conditions.

 For details on available printing conditions, see "Printer Driver Settings." →P.142

11 Confirm the print settings and print as desired.



• For instructions on confirming print settings, see "Confirming Print Settings ." →P.145


Printing Photos and Images (Mac OS)

This topic describes how to print photos based on the following example.

- · Document: Photo image from a digital camera
- Page size: 10×12 inches (254.0×304.8 mm)
- Paper: Roll paper
- Paper type: Canon Premium Glossy Paper 2 280
- Roll paper width: 10 inches (254.0 mm)
- 1 Choose Page Setup from the application menu to display the Page Attributes dialog box.



 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.



- 2 Select the printer in the B Format for list.
- In the C Paper Size list, click the size of the original. In this case, click 10"x12".
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.

6 Access the Main pane.



In the A Media Type list, select the type of paper that is loaded. In this case, click Canon Premium Glossy Paper 2 280.

Make sure the paper you select is loaded in the printer.




The types of paper indicated in the printer driver and related software (as well as on the Control Panel) are updated when you install the Media Configuration Tool from the User Software CD-ROM or if you change paper information by using the Media Configuration Tool. For details, see "Media Configuration Tool (Mac OS)." >P.383

8 After confirming that DEasy Settings is selected, click Photo (Color) in the EPrint Target list.



- For information on settings optimized for printing photos and images, see "Printing Photos and Images." →P.31
- You can check the settings values selected in the **EPrint Target** list by clicking **GView set**..
- Make your selection in the F Print Quality list.
- 10 Access the Page Setup pane.



11 Select and click a roll paper in the A Paper Source list.

- 12 Select the paper width of the roll loaded in the printer for BRoll Width. In this case, 10 in. (254.0mm) is selected.
- Specify additional printing conditions.

 For details on available printing conditions, see "Printer Driver Settings ." >P.250
- 14 Confirm the print settings, and then click M Print to start printing.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Printing Office Documents

By selecting **Office Document** from **Easy Settings** of the printer driver, you can easily configure settings for printing office documents.

Print Target	Description
Office Document	Setting optimized for printing general office documents such as materials for distribution so that they can be viewed easily.



You can check the settings values for each print target by clicking View Settings.


Vote

You can also fine-tune these values as needed. (Advanced Settings)
 For details on Advanced Settings, see "Giving Priority to Particular Graphic Elements and Colors for Printing." (>P.54)


Printing Office Documents (Windows)

This topic describes how to print office documents based on the following example.

- Document: Office document created using word-processing or spreadsheet programs
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- · Paper: Sheets
- Paper type: Plain Paper
- Paper size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.




In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.





• You can check the settings values selected in the **EPrint Target** list by clicking **GView Settings**.

6 Click the Page Setup tab to display the Page Setup sheet.



- In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4.
- 8 Click Manual in the L Paper Source list.
- 9 Specify additional printing conditions.
 For details on available printing conditions, see "Printer Driver Settings." →P.142
- 10 Confirm the print settings and print as desired.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Printing Office Documents (Mac OS)

This topic describes how to print office documents based on the following example.


- Document: Office document created using word-processing or spreadsheet programs
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- Paper: Sheets
- · Paper type: Plain Paper
- Paper size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])

37

1 Choose Page Setup from the application menu to display the Page Attributes dialog box.




 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the BFormat for list.
- In the C Paper Size list, click the size of the original. In this case, click ISO A4 for Paper Tray (Large Margins).
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the **Main** pane.




- 7 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 8 After confirming that DEasy Settings is selected, click Office Document in the EPrint Target list.



You can check the settings values selected in the EPrint Target list by clicking GView set.

- Make your selection in the F Print Quality list.
- 10 Access the Page Setup pane.



- 11 Click Manual in the A Paper Source list.
- Specify additional printing conditions.

 For details on available printing conditions, see "Printer Driver Settings ." →P.250
- 13 Confirm the print settings, and then click MPrint to start printing.




For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Using PosterArtist to Compose Originals


You can print a variety of source documents from word-processing or spreadsheet programs or screen shots from web browsers after composing an original with them using PosterArtist.

This topic describes how to use PosterArtist to compose originals from multiple applications, creating a poster layout for printing.

- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows).") →P.148
- 3 Make sure the **Main** sheet is displayed.




4 Click the Layout tab to display the Layout sheet.



- 5 Select the A Page Layout check box.
- 6 Click in the Edit Using PosterArtist in the A Page Layout list.



- This function cannot be used with a 64-bit version OS.
- When you attempt to print, PosterArtist starts up and the PageCapture window is displayed. (At this point, the document will not be printed yet.)



- 8 Choose the page to load in PosterArtist.
- 9 Edit and rearrange the image in the PosterArtist window as desired. Without closing the PosterArtist window, repeat steps 1-8 to arrange originals from multiple applications on the same page.



- For details on how to edit and sort images, refer to the PosterArtist Manual.
- 10 Print from the PosterArtist menu.

Printing CAD Drawings iPF685

Printing CAD Drawings

Printing CAD Drawings	40
Printing Line Drawings and Text	
Printing Line Drawings and Text (Windows)	
Printing Line Drawings and Text (Mac OS)	42
Printing from AutoCAD	44
Specifying Colors and Printing CAD Drawings	
HP-GL/2 Printing	47

Printing CAD Drawings

Using this printer, you can print fine lines and text clearly and sharply. It's easy to produce highly precise drawings from CAD applications.

For instructions on CAD printing, refer to the following topics, as appropriate for your computer and operating system.

- Printing Line Drawings and Text (Windows) →P.41
- Printing Line Drawings and Text (Mac OS) →P.42

Printing Line Drawings and Text

Printing is easy when you simply choose the type of original to print.

Easy Settings

Simply choose the printing application in the list for optimal printing results.

Print Target

Choose presets that match the type of document to be printed.

Print targets for line drawings and text

	Print Target	Description
	CAD (Color Line Drawing)	Settings optimized to print intricate lines in CAD drawings clearly.
	CAD (Monochrome Line Drawing)	Settings optimized to print black lines in CAD drawings clearly.
8	Perspective, GIS	Settings optimized for printing 3D CAD drawings, perspective drawings, and maps, including GIS maps.



You can check the settings values for each print target by clicking View Settings.

Note • You can also fine-tune these values as needed. (Advanced Settings) For details on Advanced Settings, see "Giving Priority to Particular Graphic Elements and Colors for Printing." → P.54

Print Quality

Choose the print quality.

The printing mode is determined by a combination of the print quality and resolution.

Print Quality	Description
Highest	A setting for printing at the highest resolution when quality is most important. Printing takes longer and consumes more ink than in other modes, but this mode offers superior printing quality.
High	Choose this setting to print at high resolution when quality is most important. Printing takes longer and consumes more ink than in Standard or Fast modes, but this mode offers exceptional printing quality.
Standard	Choose this setting to print at standard resolution when quality and speed are both important. Printing takes less time than in Highest or High mode.
Fast	Choose this setting to print faster. Printing in draft mode can help you work more efficiently when checking layouts.


For instructions on printing line drawings and text, refer to the following topics, as appropriate for your computer and operating system.

- Printing Line Drawings and Text (Windows) →P.41
- Printing Line Drawings and Text (Mac OS) →P.42

Printing Line Drawings and Text (Windows)

This topic describes how to print line drawings based on the following example.

- Document: CAD drawing
- Page size: A3 (297.0 × 420.0 mm [11.7 × 16.5 in])
- · Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- After confirming that D Easy Settings is selected, click CAD (Color Line Drawing) or CAD (Monochrome Line Drawing) in the E Print Target list.




You can check the settings values selected in the E Print Target list by clicking G View Settings.

User's Guide

41

6 Click the Page Setup tab to display the Page Setup sheet.



- 7 In A Page Size, click the size of the original as specified in the application. In this case, click ISO A3.
- 8 Select and click a roll paper in the LPaper Source list.
- Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 10 Specify additional printing conditions.

 For details on available printing conditions, see "Printer Driver Settings." →P.142
- 11 Confirm the print settings and print as desired.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.145


Printing Line Drawings and Text (Mac OS)

This topic describes how to print line drawings based on the following example.


- · Document: CAD drawing
- Page size: A3 (297.0 × 420.0 mm [11.7 × 16.5 in])
- · Paper: Roll
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])

43


1 Choose Page Setup from the application menu to display the Page Attributes dialog box.



- 2 Select the printer in the B Format for list.
- In the C Paper Size list, click the size of the original. In this case, click ISO A3.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the Main pane.




- 7 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- After confirming that DEasy Settings is selected, click CAD (Color Line Drawing) or CAD (Monochrome Line Drawing) in the EPrint Target list.



9 Make your selection in the F Print Quality list.

10 Access the Page Setup pane.



- 11 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, ISO A2/A3 (420.0mm) is selected.
- Specify additional printing conditions.

 For details on available printing conditions, see "Printer Driver Settings ." →P.250
- 14 Confirm the print settings, and then click MPrint to start printing.



- For tips on confirming print settings, see "Confirming Print Settings ." →P.252
- You can conserve roll paper by configuring settings suitable for the document.
 For details on how to conserve paper and print, see "Conserving Roll Paper by Rotating Originals 90 Degrees." P.124

Printing from AutoCAD

Printer Driver Optimization Module for AutoCAD is software for printing optimally from AutoCAD with the printer driver

By optimally controlling the processing resolution of raster data and the memory to be used in image processing of AutoCAD, printing superior in reliability and productivity is realized.

If you install Printer Driver Optimization Module for AutoCAD on a computer on which supported AutoCAD is installed, it will be installed automatically.



- Printer Driver Optimization Module for AutoCAD is applied automatically when you print from AutoCAD, and optimal printing is performed.
- Printer Driver Optimization Module for AutoCAD can be used on Windows.


Confirming the Installation of Printer Driver Optimization Module for AutoCAD

You can confirm whether Printer Driver Optimization Module for AutoCAD is installed by the following method.

1 From the File menu of AutoCAD, select Print.

The **Printing** dialog box is displayed.

Printer Driver Optimization Module for AutoCAD is installed if in **Plotter** of **Printer/plotter** this is displayed: **iPFxxxx - Optimized driver - by Canon Inc.**.



Installation of Printer Driver Optimization Module for AutoCAD

If Printer Driver Optimization Module for AutoCAD is not installed, install it by the following method.

- 1 Insert User Software CD-ROM in the CD-ROM drive and start the installer.
- 2 In the Setup Menu window, click Install Individual Software.
- 3 Click **Install** of Printer Driver Optimization Module for AutoCAD.
- 4 Follow the instructions on the screen.

Specifying Colors and Printing CAD Drawings

You can complete color settings when **Color (CAD)** is selected in **Color Mode**. Colors can be adjusted before printing as follows when **Color Compatibility** is selected.



 Color (CAD) is displayed when you select Advanced Settings on the Main sheet and set Print Priority to Line Drawing/Text.

Color Compatibility

Color Setting Item

Color Setting	Description
Color (CAD) 1	Print in standard colors.
Color (CAD) 2	Print with approximate colors emulating Canon iPF750, iPF755, iPF650, iPF655, iPF760, iPF765.
Color (CAD) 3	Print with approximate colors emulating Canon iPF500, iPF600, iPF700, iPF510, iPF610, iPF710, iPF605, iPF720, iPF810, iPF820, iPF815, iPF825.
Color (CAD) 4	Print emulating the HP Designjet 500/800, in colors resembling colors produced by these printers.
Color (CAD) 5	Print emulating the HP Designjet T1100, in colors resembling colors produced by this printer.

45



If you have selected Color (CAD) 2, Color (CAD) 3, Color (CAD) 4, or Color (CAD) 5, it is not possible to match
the colors and image quality produced by the specified printer exactly.

For instructions on configuring **Color Compatibility**, refer to the following topics.


Specifying Colors and Printing CAD Drawings (Windows) →P.46

Specifying Colors and Printing CAD Drawings (Windows)


You can complete color settings when Color (CAD) is selected in Color Mode.




- Color (CAD) is displayed when you select Advanced Settings on the Main sheet and set Print Priority to Line Drawing/Text.
- 1 Click start > Printers and Faxes (or Printers).
- 2 Select the printer, and then display the printer properties dialog box.



Click the **Device Settings** tab to display the **Device Settings** sheet.



4 Click A Color Compatibility to display the Color Compatibility dialog box.



5 Select the desired color settings in the A Color Compatibility list.



• For details on color settings, see "Specifying Colors and Printing CAD Drawings." >P.45

46

For printing instructions, refer to the following topic.

Choosing the Document Type and Printing Conditions →P.56

HP-GL/2 Printing

This printer supports printing using the original Canon GARO printer control language and printing using HP-GL/2 and HP RTL emulation to print in colors resembling the colors produced by printers from other companies. The printer automatically switches to the corresponding processing depending on whether a GARO or HP-GL/2 and HP RTL emulation job is received.



- GARO is an abbreviation of Graphic Arts Language with Raster Operations.
- Note
- HP-GL/2 is an abbreviation of Hewlett-Packard Graphics Language/2, and HP RTL is an abbreviation of Hewlett-Packard Raster Transfer Language.
- Emulation is good for obtaining results similar to printing on other printers.

When printing from applications that support HP-GL/2 output, specify HP-GL/2 in the application's plotter output settings.

HP-GL/2 and HP RTL emulation related settings such as the printer to emulate are configured from the printer Control Panel. (Refer to "Menu Structure →P.412) " and "Menu Settings →P.418")



- For instructions on configuring these settings, refer to the software documentation. It may not be possible to print jobs with excessively large amounts of data correctly.
- For information on CAD colors other than HP-GL/2 and HP RTL emulation, see "Menu Settings." →P.418

Adjusting Images

Adjusting the Color in the Printer Driver	48
Fine-Tuning Colors of Photos and Images (Windows)	
Fine-Tuning Colors of Photos and Images (Mac OS)	
Giving Priority to Particular Graphic Elements and Colors for Printing	54
Giving Priority to Particular Graphic Elements and Colors for Printing	56

Adjusting the Color in the Printer Driver

Color settings specified in the application for your documents are essentially given priority over other settings for each print job, but further color adjustment is possible in the printer driver.

Color Mode

Choose how the printer driver processes color, as desired.

The available options vary depending on the color mode.

Color Mode	Description	Color Adjustment
Color	Print in color.	You can select the color balance and color matching functions.
Monochrome	Print in grayscale.	You can adjust the color balance.
Color (CAD)	A color mode optimized for line drawings (2D-CAD). Lines in red, yellow, and other colors are printed especially clearly.	You can adjust the color balance.
Monochrome (BK ink)	A color mode for printing line drawings. Only Black ink is used.	You can adjust the color balance.
Monochrome Bitmap	Print in a color mode for CAD, using Color Ink, with all non-white portions printed in black.	No color adjustment is supported.
No color correction (*1)	Prints without performing color-matching in the printer driver.	You can adjust the color balance.

^{*1:} If No color correction is selected, the Matching sheet / Matching pane is not displayed.

Color Adjustment

You can adjust colors separately for images, graphics, and text documents.

Adjustment Item	Description	
Cyan	Fine-tune color tones by adjusting the levels of Cyan, Magenta, and Yellow.	
Magenta		
Yellow		
Gray Tone	Adjust the grayscale, in a range from cool, blue tones to warm, red tones.	
Brightness	Adjust the brightness of printed images while keeping the darkest and lightest portions intact.	
Contrast	Adjust the contrast of the darkest and lightest portions relative to each other. For soft gradation, decrease the contrast. For hard gradation, increase the contrast.	
Saturation	Adjust the level of color saturation, in a range from subdued to vivid.	



 Click Object Adjustment to open the Object Adjustment dialog box, which allows you to select the color adjustment target from Image, Graphics, and Text.

Matching

You can choose the color-matching mode and method.

By adjusting the color-matching mode and method, you can make printed colors match the colors of on-screen images more closely.

49



• If No color correction is selected under Color Mode, the Matching cannot be changed.

Matching Mode	Description	Remarks
Driver Matching Mode	Enables printing of optimal color tones using a driver specific color profile.	You should normally select this mode.
ICC Matching Mode	Enables color matching using ICC profiles. Select this if you want to print by specifying the input profile, printer profile, and matching method in detail.	This allows you to use ICC profiles for digital cameras and scanners, ICC profiles created using the profile creation tool, etc.
Host ICM Mode	Enables color matching by the host computer using the ICM function of Windows. Select this if you want to print from an application that supports the ICM function.	Available when using Windows.
ColorSync	Enables color matching by using the ColorSync function of Mac OS. Select this if you want to perform soft proofing using ColorSync before printing.	Available when using Mac OS. To select ColorSync , choose ColorSync on the Color Matching panel.

Matching Method	Description	Remarks
Auto	Color-matching optimized for images, graphics, or text.	The available options and their display or der vary depending on your selected color-matching mode, as well as the operating system.
Perceptual	Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software.	
Colorimetric	Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric.	
Colorimetric (No Wht-pnt Corr)	The processing method of color-matching is identical to Colorimetric. Use this when you want to further reproduce the target paper material color of the image data. Generally, this also is called absolute colorimetric	
Saturation	Color-matching optimized for printing posters, etc., vividly.	

For instructions on color adjustment, refer to the following topics, as appropriate for your computer and operating system.

- Fine-Tuning Colors of Photos and Images (Windows) →P.49
- Fine-Tuning Colors of Photos and Images (Mac OS) →P.52


Fine-Tuning Colors of Photos and Images (Windows)

You can specify your own print settings instead of using the **Print Target** presets. This topic describes how to fine-tune the color tone of photos before printing.




Choose **Print** in the application menu.


- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
 - 3 Make sure the **Main** sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded.
- 5 Click DAdvanced Settings to switch the print mode.



- 6 Click Color in the G Color Mode list.
- 7 Click H Color Settings to display the Color Settings dialog box.




8 On the Color Adjustment sheet, adjust the color tones, brightness, and so on as desired.

Adjustment Item	Description
D Cyan	Fine-tune color tones by adjusting the levels of Cyan, Magenta, and Yellow.
E Magenta	

Adjustment Item	Description
FYellow	Fine-tune color tones by adjusting the levels of Cyan, Magenta, and Yellow.
G Gray Tone	Adjust the gray tone. Choose cool black (tinged with blue), pure black (neutral), warm black (tinged with red), and so on.
H Brightness	Adjust the brightness of printed images while keeping the darkest and lightest portions intact.
Contrast	Adjust the contrast of the darkest and lightest portions relative to each other. For soft gradation, decrease the contrast. For hard gradation, increase the contrast.
J Saturation	Adjust the level of color saturation, in a range from subdued to vivid.



- Click Object Adjustment to open the Object Adjustment dialog box, which allows you to select the color adjustment target from Image, Graphics, and Text.
- 9 Close the Color Settings dialog box.
- Click the Page Setup tab to display the Page Setup sheet.



- 11 Confirm the settings of A Page Size, L Paper Source, and so on.
- 12 Confirm the print settings and print as desired.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.145


Fine-Tuning Colors of Photos and Images (Mac OS)

You can specify your own print settings instead of using the **Print Target** presets. This topic describes how to fine-tune the color tone of photos before printing.

1 Choose Page Setup from the application menu to display the Page Attributes dialog box.




 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



G Orientation:


If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the B Format for list.
- 3 Choose the original size in the C Paper Size list.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the Main pane.




7 In the A Media Type list, select the type of paper that is loaded.

8 Click D Advanced Settings to switch the print mode.



- 9 Click Color in the H Color Mode list.
- 10 Click Set to display the Color Settings dialog box.




11 On the Color Adjustment pane, adjust the color tones, brightness, and so on as desired.

Adjustment Item	Description	
D Cyan	Fine-tune color tones by adjusting the levels of Cyan, Magenta, and Yellow.	
E Magenta		
F Yellow		
G Gray Tone	Adjust the gray tone. Choose cool black (tinged with blue), pure black (neutral), warm black (tinged with red), and so on.	
H Brightness	Adjust the brightness of printed images while keeping the darkest and lightest portions intact.	
Contrast	Adjust the contrast of the darkest and lightest portions relative to each other. For soft gradation, decrease the contrast. For hard gradation, increase the contrast.	
J Saturation	Adjust the level of color saturation, in a range from subdued to vivid.	

Note

 Click Object Adjustment to open the Object Adjustment dialog box, which allows you to select the color adjustment target from Images, Graphics, and Text. 53

- 12 Click **OK** to close the **Color Settings** dialog box.
- 13 Access the Page Setup pane.



14 Confirm the print settings, and then click M Print to start printing.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Giving Priority to Particular Graphic Elements and Colors for Printing

You can specify detailed print settings as desired for the quality level, colors, and other criteria.

Advanced Settings

For printing results that appear just as expected for your original, you can specify which graphic elements and colors to prioritize for printing.



Easy Settings are also available, providing convenient presets. To use the presets, simply choose the printing application.

For details on Easy Settings, refer to the following topics.

- Printing Photos and Images →P.31
- Printing Line Drawings and Text → P.40
- Printing Office Documents →P.35

Print Priority

Choose the graphic elements that you want to emphasize for printing.

Print Priority (*1)	Description
Image	A setting for posters or other documents made up mainly of photos or images, or for emphasizing photos or images in printed documents.
Line Drawing/Text	Choose this setting for CAD drawings made up mainly of intricate lines, or wall newspapers and other notices with a large amount of text. Suitable for emphasizing detailed text in printed documents. However, the quality may not be sufficient when printing photos or images that require a lot of color coverage. In this case, choose Image instead.
Office Document	Choose this setting for better legibility of documents combining text and graphics, such as documents and presentation material created with typical office applications.

^{*1:} Options suitable for the selected type of paper are listed under Print Priority.

Print Quality

Choose the print quality.

55

The printing mode is determined by a combination of the print quality and resolution.

Print Quality (*1)	Description	Print Priority
Highest	A setting for printing at the highest resolution when quality is most important. Printing takes longer and consumes more ink than in other modes, but this mode offers superior printing quality.	Image
High	Choose this setting to print at high resolution when quality is most important. Printing takes longer and consumes more ink than in Standard or Fast modes, but this mode offers exceptional printing quality.	Image Line Drawing/Text
Standard	Choose this setting to print at standard resolution when quality and speed are both important. Printing takes less time than in Highest or High mode.	Image Line Drawing/Text Office Document
Fast	Choose this setting to print faster. Printing in draft mode can help you work more efficiently when checking layouts.	Image Line Drawing/Text

^{*1:} Options suitable for the selected Print Priority are listed under Print Quality.

Color Settings

Setting Item	Options	Description
Color Mode (*1)	Color Monochrome Color (CAD) Monochrome (BK ink) Monochrome Bitmap No color correction	Choose whether to print in color or monochrome. (See "Adjusting the Color in the Printer Driver.") → R48
Color Adjustment	Cyan Magenta Yellow Gray Tone Brightness Contrast Saturation	You can adjust the levels of cyan, magenta, and yellow as well as the brightness, contrast, saturation, and gray tones. If you choose Monochrome or Monochrome (BK ink) in Color Mode only Brightness and Contrast can be adjusted. Image, Graphics, and Text are available as Object Adjustment options.
Color-Matching Modes	Driver Matching Mode ICC Matching Mode Host ICM Mode (Windows) ColorSync (Mac OS)	Choose the color-matching mode.
Color-Matching Method (*2)	Auto Perceptual Colorimetric Saturation	Choose the color-matching method. The available options vary depending on your selection in Color-Matching Mode .
Gamma	2.2 1.8	You can adjust the gradation of intermediate tones in an image. You can select only after Driver Matching Mode has been selected in Matching Mode .

^{*1:} Options suitable for the selected Print Priority are listed under Color Mode.

Enhancing printing quality

Ermanoning printing quanty	
Setting Item	Description
Highest quality	This prints at the highest resolution. Printing takes longer and consumes more ink than in other modes, but this mode offers superior printing quality.
Thicken Fine Lines	Prints making fine lines appear thicker.
Sharpen Text	Choose this option to print intricate text more distinctly.

^{*2:} The order of options displayed varies depending on the operating system.

Setting Item	Description
Reduce Print Unevenness (*1)	Choose this option to counteract uneven printing.
Unidirectional Printing	Prints by suppressing color variations and misaligned ruled lines. However, this takes more time than regular printing.
Economy Printing	When this mode is selected, less ink is consumed than in regular printing, but the quality is diminished. Select this mode if you want to conserve ink when checking drawings, for example. Depending on the Media Type and Print Quality settings, this mode may not be available.

^{*1:}Displayed in Mac OS.



 To print at a higher level of quality, in the printer driver, choose High or Highest in Print Quality, and select the Unidirectional Printing check box.


For instructions on specifying the print quality and color settings before printing, refer to the following topics, as appropriate for your computer and operating system.

- Choosing the Document Type and Printing Conditions (Windows) → P.56
- Choosing the Document Type and Printing Conditions (Mac OS) →P.58

Choosing the Document Type and Printing Conditions (Windows)

You can specify your own print settings instead of using the **Print Target** presets. As an example, this topic describes how to print CAD drawings as clearly as possible, with sharp lines and text.


- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.



4 In the A Media Type list, select the type of paper that is loaded.

57


5 Click DAdvanced Settings to switch the print mode.



- 6 Click Line Drawing/Text in the E Print Priority list.
- 7 Click High (1200dpi) in the F Print Quality list.




- 8 Click Color (CAD) in the G Color Mode list.
- 9 To adjust the color, click H Color Settings.



O Select the KSharpen Text check box.

Note

Click the Page Setup tab to display the Page Setup sheet.



- 12 Confirm the settings of A Page Size, L Paper Source, and so on.
- 13 Confirm the print settings and print as desired.



For tips on confirming print settings, see "Confirming Print Settings ." →P.145


Choosing the Document Type and Printing Conditions (Mac OS)

You can specify your own print settings instead of using the **Print Target** presets. This topic describes how print photographic images in monochrome.

1 Choose Page Setup from the application menu to display the Page Attributes dialog box.




 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



G Orientation:

If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.


- 2 Select the printer in the B Format for list.
- Choose the original size in the C Paper Size list.
- 4 Click **FOK** to close the dialog box.
- 5 In the application menu, choose **Print**.
- 6 Access the Main pane.



7 In the A Media Type list, select the type of paper that is loaded.

59






- 9 Click Image in the EPrint Priority list.
- 10 Click High (600dpi) in the F Print Quality list.



- Options displayed in the FPrint Quality list vary depending on the paper type.
- - Click Monochrome in the H Color Mode list.
- 12 To adjust the brightness and contrast, click | Set.



- For instructions on adjusting brightness and contrast, see "Adjusting the Color in the Printer Driver." →P.48
- 13 Access the Page Setup pane.



14 Confirm the print settings, and then click M Print to start printing.



For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Printing enlargements or reductions

Resizing Originals to Match the Paper Size	60
Resizing Originals to Match the Paper Size (Windows)	
Resizing Originals to Fit the Roll Width	62
Resizing Originals to Fit the Roll Width (Windows)	
Resizing Originals to Fit the Roll Width (Mac OS)	
Resizing Originals by Entering a Scaling Value	65
Resizing Originals by Entering a Scaling Value (Windows)	
Resizing Originals by Entering a Scaling Value (Mac OS)	

Resizing Originals to Match the Paper Size


You can freely adjust the size of originals by enlarging or reducing them as desired.

Enlarged/Reduced Printing

Enlarge or reduce the original in the printer driver, as desired.

Fit Paper Size

Enlarge or reduce the original to match the size of the paper you are using.




For instructions on printing with resizing to fit the paper size, refer to the following topics.

• Resizing Originals to Match the Paper Size (Windows) → P.60



To print with resizing to fit the paper size on Mac OS, use Scale to fit paper size in the Paper Handling
panel provided by the OS.

For more information, see the Mac OS User Manual.



For better printing results when enlarging photos from a digital camera in TIFF or JPEG format, use an image-editing application software such as Adobe Photoshop to specify an image resolution of 150 dpi or more at actual size.

Resizing Originals to Match the Paper Size (Windows)


This topic describes how to enlarge originals before printing to match the paper size, based on the following example.

- Document: Any Type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- Paper: Roll


60

Paper type: Plain Paper

- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5 Select the printing application in the E Print Target list.
- Click the Page Setup tab to display the Page Setup sheet.



- 7 Select and click a roll paper in the LPaper Source list.
- Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4.
- 10 Select the CEnlarged/Reduced Printing check box.
- 11 Select the DFit Paper Size check box.
- 12 Click ISO A3 in the G Paper Size list.

13 Confirm the print settings and print as desired.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Resizing Originals to Fit the Roll Width


You can freely adjust the size of originals by enlarging or reducing them as desired.

Enlarged/Reduced Printing

Enlarge or reduce the original in the printer driver, as desired.

• Fit Roll Paper Width


Enlarge or reduce the original as a whole to match the roll paper width, as desired.




Resizing Originals to Fit the Roll Width (Windows)

This topic describes how to enlarge originals before printing to match the roll width, based on the following example.

- Document: Any type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- Paper: Roll
- Paper type: Plain Paper
- Roll paper width: 16 inches (406.4 mm)
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.




- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5 Select the printing application in the **EPrint Target** list.
- 6 Click the Page Setup tab to display the Page Setup sheet.



- 7 Select and click a roll paper in the LPaper Source list.
- In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").
- 9 Select the CEnlarged/Reduced Printing check box.



 If the C Enlarged/Reduced Printing check box is not displayed on the Page Setup sheet, clear the B Borderless Printing check box.



10 Click E Fit Roll Paper Width.



- After you click E Fit Roll Paper Width, the Information dialog box is displayed. Select the width of the loaded roll in the Roll Paper Width list and click OK.
- Make sure the roll paper width you specify matches the width of the loaded roll.
- 11 Confirm the print settings and print as desired.



For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Resizing Originals to Fit the Roll Width (Mac OS)


This topic describes how to enlarge originals before printing to match the roll width, based on the following example.

- Document: Any Type
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- Paper: Roll paper

- · Paper type: Plain Paper
- Roll paper width: 16 inches (406.4 mm)
- 1 Choose Page Setup from the application menu to display the Page Attributes dialog box.



 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.




If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the B Format for list.
- In C Paper Size, click the size of the original. In this case, click ISO A4.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the Main pane.



- 7 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 8 Make your selection in the EPrint Target list.
- Make your selection in the F Print Quality list.

10 Access the Page Setup pane.



- 11 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, 16 in. (406.4mm) is selected.
- 13 Select the DEnlarged/Reduced Printing check box.
- 14 Click F Fit Roll Paper Width.
- 15 Confirm the print settings, and then click MPrint to start printing.




• For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Resizing Originals by Entering a Scaling Value

You can freely adjust the size of originals by enlarging or reducing them as desired.

- Enlarged/Reduced Printing
 Enlarge or reduce the original in the printer driver, as desired.
- Scaling
 Enlarge or reduce originals by a particular amount, as desired.



For instructions on entering a scaling value to resize originals, refer to the following topics, as appropriate for your computer and operating system.

- Resizing Originals by Entering a Scaling Value (Windows) →P.66
- Resizing Originals by Entering a Scaling Value (Mac OS) →P.67



For better printing results when enlarging photos from a digital camera in TIFF or JPEG format, use an image-editing application software such as Adobe Photoshop to specify an image resolution of 150 dpi or more at actual size.

65


Resizing Originals by Entering a Scaling Value (Windows)

This topic describes how to enlarge originals before printing by entering a scaling value, based on the following example.


- Document: Any Type
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- · Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])



- In borderless printing, you cannot resize originals by entering a scaling value.
- Important
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.



- 4 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- Select the printing application in the **EPrint Target** list.
- 6 Click the Page Setup tab to display the Page Setup sheet.




- 7 Select and click a roll paper in the **LPaper Source** list.
- Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).

- 9
- In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4.
- 10 Select the CEnlarged/Reduced Printing check box.
- 11 Click ISO A4 in the G Paper Size list.
- 12 Click F Scaling and enter 120.



- You can specify enlargement that exceeds the paper size, but in this case, the portions off the bottom and right edges of the paper will not be printed.
- If the original size after enlargement or reduction is smaller than the paper size, the original is printed in the upper-left corner. In this case, you can center originals by selecting E Print Centered on the Layout sheet.



13 Confirm the print settings and print as desired.




• For tips on confirming print settings, see "Confirming Print Settings ." →P.145


Resizing Originals by Entering a Scaling Value (Mac OS)

This topic describes how to enlarge originals before printing by entering a scaling value, based on the following example.

- Document: Any Type
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- Paper: Roll paper
- · Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])

1 Choose Page Setup from the application menu to display the Page Attributes dialog box.






If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the **B** Format for list.
- 3 In C Paper Size, click the size of the original. In this case, click ISO A4.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the Main pane.



- 7 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
 - 8 Make your selection in the EPrint Target list.
 - 9 Make your selection in the F Print Quality list.

10 Access the Page Setup pane.



- 11 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, ISO A2/A3 (420.0mm) is selected.
- 13 Select the DEnlarged/Reduced Printing check box.
- 14 Click G Scaling and enter 120.



- You can specify enlargement that exceeds the paper size, but in this case, the portion off the edge of the paper will not be printed.
- If the original size after enlargement or reduction is smaller than the paper size, the original is printed in the upper-left corner. In this case, you can center originals by selecting the J Print Centered check box.
- 15 Confirm the print settings, and then click M Print to start printing.



For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Printing at full size

Printing on Oversize Paper	70
Printing at Full Size (Windows)	71
Printing at Full Size (Mac OS)	
Borderless Printing at Actual Size	74 75

Printing on Oversize Paper

You can print all areas of the original at full scale by selecting the paper size from **Oversize** (sizes where the margins needed for printer operation have been added to the page size).

We recommend when printing with a focus on image.




• If you prepare an original for printing without a margin and print it on paper of regular size, the image near the edge will not be printed.

Oversize

When printing on standard paper sizes, printing is performed by taking the margins necessary for printer operations inside the region of the original. (See "Print Area.") > P.623 For example, printing the A4 size (210 x 297 mm) original shown in Figure (b) gives the result as shown in Figure (a).

However, if **Oversize** paper is selected, printing is performed by taking the margins necessary for printer operations outside of the region of the original to give the result as shown in Figure (c).

The A4 size print as shown in Figure (b) can then be obtained by trimming the margins from the periphery after printing.





- When printing on Oversize paper, load paper larger than the page size—a size that includes the margin required by the printer.
- Sheets: Load paper that is at least 10 mm (0.39 in) wider and 28 mm (1.10 in) higher than the page size
- Rolls:Load paper that is at least 10 mm (0.39 in) wider and 10 mm (0.39 in) higher than the page size



- Paper larger than the maximum size supported by the printer cannot be used as paper for oversized printing. (See "Paper Sizes.") →P.328
- Oversized printing (selecting **Oversize** in **Page Size**) is only available in Windows.
- If you are performing oversized printing in Mac OS, you need to configure printing on non-standard paper sizes.
- To specify a non-standard paper size in oversized printing, register the paper size as a Custom Paper Size.
 Oversized printing is not available with Custom Size. (See "Printing on Non-Standard Paper Sizes.") >P.95

For instructions on oversized printing, refer to the following topics, as appropriate for your computer and operating system.

Printing at full size


71

- Printing at Full Size (Windows) →P.71
- Printing at Full Size (Mac OS) →P.72


Printing at Full Size (Windows)

This topic describes how to print at full size based on the following example. (Oversized Printing)

- · Document: Any Type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- · Paper: Roll
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- Click the Page Setup tab to display the Page Setup sheet.



- 6 Click OSize Options to display the Paper Size Options dialog box.
- 7 In the Paper Size Options dialog box, select the Oversize check box in Display Series.
- 8 Click **OK** to close the **Paper Size Options** dialog box.
- 9 Click Oversize ISO A4 in the A Page Size list.
- 10 Select and click a roll paper in the LPaper Source list.

- Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 12 Confirm the print settings and print as desired.



For tips on confirming print settings, see "Confirming Print Settings ." →P.145


Printing at Full Size (Mac OS)

This topic describes how to print at full size based on the following example. (Oversized Printing)

- Document: Any Type
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1 Choose Page Setup from the application menu to display the Page Attributes dialog box.




 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.




G Orientation:

- If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.
- 2 Select the printer in the B Format for list.
- In C Paper Size, click the size of the original. In this case, click ISO A4 Oversize.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.

6 Access the Main pane.



- 7 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 8 Make your selection in the EPrint Target list.
- Make your selection in the F Print Quality list.
- 10 Access the Page Setup pane.



- 11 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, ISO A2/A3 (420.0mm) is selected.
- 13 Confirm the print settings, and then click MPrint to start printing.



For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Borderless Printing at Actual Size

Take advantage of borderless printing to print documents such as posters (made up mainly of photos or images) without a surrounding margin, or border.

In regular printing, a margin required by the printer is added around the original. With borderless printing, you can print documents without the margin, so that the printed image covers the entire surface of the paper.

- Borderless printing is only available with rolls.
- Paper you can use for borderless printing is restricted to particular types of paper and rolls of particular widths. (See "Displaying the Paper Reference Guide.") →P.331
- Although it normally prints borderless on the top, bottom, left, and right (4-edge borderless), in the following
 cases, it becomes borderless only on the left and right (2-edge borderless) because the top and bottom of the
 printed image are not automatically cut.
 - When paper where the borderless printing is described as two edges only in the **Paper Reference Guide** (paper where printed image areas cannot be cut cleanly) is selected
 - When the following settings are made in the printer control panel
 - Cutting Mode is Manual
 - CutDustReduct. is On
 - · When auto cut is configured as not performed in the printer driver




- Borderless printing is not possible if details such as crop marks and margins are included as data on the periphery of the original.
- If the length of the image to print is short, then since the roll paper is fed out to a prescribed length before cutting
 in order to prevent cutting problems and ejection problems, the trailing edge of the roll paper might not be printed
 borderless.
- These features cannot be used in combination with borderless printing: special page layouts, centering originals, and printing cut lines on rolls.
- If Fit Paper Size or Print Image with Actual Size (Windows only) is selected while performing borderless printing, Rotate Page 90 degrees (Conserve Paper) cannot be selected. Note that if borderless printing is possible, then even if the original is rotated 90 degrees, it will be printed by automatically rotating the page by 90 degrees.

Choose the method of borderless printing that suits the original, as desired.

Print Image with Actual Size

Prints originals at actual size, without enlarging or reducing them. We recommend when focusing on image quality. You should create the original at a size larger by 3 mm on each side than the paper size.





Not all page sizes are available.

• When performing borderless printing without using **Print Image with Actual Size**, the image deteriorates slightly because the image is automatically enlarged.

For instructions on borderless printing of photos and images at actual size, refer to the following topics, as appropriate for your computer and operating system.

Borderless Printing at Actual Size (Windows) →P.75

Borderless Printing at Actual Size (Mac OS) →P.76

Borderless Printing at Actual Size (Windows)


This topic describes how to print borderlessly at actual size based on the following example.



- When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be uneven at
 the edges. If you require higher image quality, select No from the Automatic Cutting list in the Roll Paper Options dialog box. In this case, the paper can be printed without borders on the left and right sides only. Once
 printed and cut, please cut the upper and lower bands with scissors.
- Document: Any type
- Page size: 10×12 inches (254.0×304.8 mm)
- Paper: Roll
- Paper type: Canon Heavyweight Coated Paper
- Roll paper width: 10 inches (254.0 mm)
- Create the original in the source application 3 mm (0.12 in) larger on each side than 254.0×304.8 mm (10 × 12 in) —that is, 260.0×310.8 mm (10.2 × 12.2 in)



- If you can specify the margin, as in Microsoft Word, set the margin at 0 mm. For instructions on specifying the margin, refer to the software documentation.
- The extra 3 mm (0.12 in) on each side will not be printed. Create the original so that it fits inside the paper area to be printed on.
- 2 Choose **Print** in the application menu.
- 3 Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 4 Make sure the **Main** sheet is displayed.




- In the A Media Type list, select the type of paper that is loaded. In this case, click Canon Heavyweight Coated Paper.
- 6 Select the print target in the EPrint Target list.




- When you are using paper that takes longer for ink to adhere for borderless printing and the Cutter Unit touches printing surfaces that are not dry yet, it may damage the paper or the edge of the document that is cut, depending on frequency of use. In this kind of situation, change the ink drying time using the following procedure.
- Click Advanced Settings in Media Type.
- Select an ink drying time in the list for the Between Pages setting of Drying Time.

Click the Page Setup tab to display the Page Setup sheet.



- In the A Page Size list, click the size of the original as specified in the source application. In this case, click 10"x12".
- 9 Select and click a roll paper in the LPaper Source list.
- Select the **B Borderless Printing** check box to display the **Information** dialog box.



- Select the width of the loaded roll in the Roll Paper Width list—in this case, click 10-in. Roll (254.0mm).
- 12 Click **OK** to close the **Information** dialog box.
- 13 In CBorderless Printing Method, click F Print Image with Actual Size.
- 14 Confirm the print settings and print as desired.



Por tips on confirming print settings, see "Confirming Print Settings ." →P.145

Borderless Printing at Actual Size (Mac OS)

This topic describes how to print borderlessly at actual size based on the following example.




- When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be uneven at
 the edges. If you require higher image quality, select No from the Automatic Cutting list in the Paper Detailed
 Settings dialog box. In this case, the paper can be printed without borders on the left and right sides only. Once
 printed and cut, please cut the upper and lower bands with scissors.
- Document: Any type
- Page size: 10 × 12 inches (254.0×304.8 mm)–Borderless

Printing at full size

- Paper: Roll
- Paper type: Canon Heavyweight Coated Paper
- Roll paper width: 10 inches (254.0 mm)
- 1 Choose Page Setup from the application menu to display the Page Attributes dialog box.



 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the B Format for list.
- In the C Paper Size list, choose a paper size supported for borderless printing. Here, click 10"x12" Borderless.




- Paper sizes supported for borderless printing are indicated by **-Borderless**.
- 4 Click **FOK** to close the dialog box.
- 5 In the application, create an original that takes up the entire space of the paper size.
- 6 Choose **Print** in the application menu.
- 7 Access the Main pane.



- 8 In the A Media Type list, select the type of paper that is loaded. In this case, click Canon Heavyweight Coated Paper.
- 9 Select the print target in the EPrint Target list.



- When you are using paper that takes longer for ink to adhere for borderless printing and the Cutter Unit
 touches printing surfaces that are not dry yet, it may damage the paper or the edge of the document that
 is cut, depending on frequency of use. In this kind of situation, change the ink drying time in Between
 Pages in the Paper Detailed Settings dialog box.
- 10 Access the Page Setup pane.



- Select and click a roll paper in the A Paper Source list.

 Select the paper width of the roll loaded in the printer for B Roll Width. In this case, 10 in. (254.0mm) is selected.
- 12 Confirm the print settings, and then click M Print to start printing.



For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Borderless Printing

Borderless Printing on Paper of Equivalent Size	.79
Borderless Printing by Resizing Originals to Match the Paper Size (Windows)	
Borderless Printing by Resizing Originals to Fit the Roll Width	82
Borderless Printing by Resizing Originals to Fit the Roll Width (Windows)	83
Borderless Printing by Resizing Originals to Fit the Roll Width (Mac OS)	85
Borderless Printing at Actual Size	74
Borderless Printing at Actual Size (Windows)	
Borderless Printing at Actual Size (Mac OS)	

Borderless Printing on Paper of Equivalent Size

Take advantage of borderless printing to print documents such as posters (made up mainly of photos or images) without a surrounding margin, or border.

In regular printing, a margin required by the printer is added around the original. With borderless printing, you can print documents without the margin, so that the printed image covers the entire surface of the paper.

- Borderless printing is only available with rolls.
- Paper you can use for borderless printing is restricted to particular types of paper and rolls of particular widths.
 (See "Displaying the Paper Reference Guide.") →P.331
- Although it normally prints borderless on the top, bottom, left, and right (4-edge borderless), in the following
 cases, it becomes borderless only on the left and right (2-edge borderless) because the top and bottom of the
 printed image are not automatically cut.
 - When paper where the borderless printing is described as two edges only in the **Paper Reference Guide** (paper where printed image areas cannot be cut cleanly) is selected
 - When the following settings are made in the printer control panel
 - Cutting Mode is Manual
 - CutDustReduct. is On
 - When auto cut is configured as not performed in the printer driver




- Borderless printing is not possible if details such as crop marks and margins are included as data on the periphery of the original.
- If the length of the image to print is short, then since the roll paper is fed out to a prescribed length before cutting
 in order to prevent cutting problems and ejection problems, the trailing edge of the roll paper might not be printed
 borderless.
- These features cannot be used in combination with borderless printing: special page layouts, centering originals, and printing cut lines on rolls.
- If **Fit Paper Size** or **Print Image with Actual Size** (Windows only) is selected while performing borderless printing, **Rotate Page 90 degrees (Conserve Paper)** cannot be selected. Note that if borderless printing is possible, then even if the original is rotated 90 degrees, it will be printed by automatically rotating the page by 90 degrees.

Choose the method of borderless printing that suits the original, as desired.

• Fit Paper Size

Enlarge or reduce the original to match the size of the paper you are using.






 The printer driver automatically enlarges originals 3 mm (0.12 in) past the dimensions of the paper on each side. The 3 mm portion beyond the edge on each side is not printed.

For instructions on borderless printing of photos, images, and other documents to match the paper size, refer to the following topics, as appropriate for your computer and operating system.

Borderless Printing by Resizing Originals to Match the Paper Size (Windows) →P.80



 To perform borderless printing with resizing to fit the paper size on Mac OS, select borderless in Paper Size and use Scale to fit paper size in the Paper Handling panel provided by the OS.
 For more information, see the Mac OS User Manual.



Borderless Printing by Resizing Originals to Match the Paper Size (Windows)

This topic describes how to enlarge originals before borderless printing to match the paper size, based on the following example.



- When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be uneven at
 the edges. If you require higher image quality, select No from the Automatic Cutting list in the Roll Paper Options dialog box. In this case, the paper can be printed without borders on the left and right sides only. Once
 printed and cut, please cut the upper and lower bands with scissors.
- Document: Any type
- Page size: 10×12 inches (254.0×304.8 mm)
- Paper: Roll


80

- Paper type: Canon Heavyweight Coated Paper
- Roll paper width: 10 inches (254.0 mm)
- 1 In the application, create an original that takes up the entire space of the paper size.



- If you can specify the margin, as in Microsoft Word, set the margin at 0 mm. For instructions on specifying the margin, refer to the software documentation.
- 2 Choose **Print** in the application menu.


- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 4 Make sure the **Main** sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Canon Heavyweight Coated Paper.
- 6 Select the print target in the EPrint Target list.




- When you are using paper that takes longer for ink to adhere for borderless printing and the Cutter Unit
 touches printing surfaces that are not dry yet, it may damage the paper or the edge of the document that
 is cut, depending on frequency of use. In this kind of situation, change the ink drying time using the
 following procedure.
 - Click Advanced Settings in Media Type.
 - Select an ink drying time in the list for the Between Pages setting of Drying Time.
- Click the Page Setup tab to display the Page Setup sheet.



- 8 In the A Page Size list, click the size of the original as specified in the application. In this case, click 10"x12".
- Select and click a roll paper in the LPaper Source list.

Select the **B Borderless Printing** check box to display the **Information** dialog box.



- 11 Select the width of the loaded roll in the Roll Paper Width list—in this case, click 10-in. Roll (254.0mm).
- 12 Click **OK** to close the **Information** dialog box.
- 13 In CBorderless Printing Method, click DFit Paper Size.
- 14 Click Match Page Size in the G Paper Size list.
- 15 Confirm the print settings and print as desired.



For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Borderless Printing by Resizing Originals to Fit the Roll Width

Take advantage of borderless printing to print documents such as posters (made up mainly of photos or images) without a surrounding margin, or border.

In regular printing, a margin required by the printer is added around the original. With borderless printing, you can print documents without the margin, so that the printed image covers the entire surface of the paper.

- · Borderless printing is only available with rolls.
- Paper you can use for borderless printing is restricted to particular types of paper and rolls of particular widths. (See "Displaying the Paper Reference Guide.") >P.331
- Although it normally prints borderless on the top, bottom, left, and right (4-edge borderless), in the following
 cases, it becomes borderless only on the left and right (2-edge borderless) because the top and bottom of the
 printed image are not automatically cut.
 - When paper where the borderless printing is described as two edges only in the Paper Reference Guide (paper where printed image areas cannot be cut cleanly) is selected
 - · When the following settings are made in the printer control panel
 - Cutting Mode is Manual
 - CutDustReduct. is On
 - · When auto cut is configured as not performed in the printer driver

83




- Borderless printing is not possible if details such as crop marks and margins are included as data on the periphery of the original.
- If the length of the image to print is short, then since the roll paper is fed out to a prescribed length before cutting in order to prevent cutting problems and ejection problems, the trailing edge of the roll paper might not be printed borderless.
- These features cannot be used in combination with borderless printing: special page layouts, centering originals, and printing cut lines on rolls.
- If Fit Paper Size or Print Image with Actual Size (Windows only) is selected while performing borderless printing, Rotate Page 90 degrees (Conserve Paper) cannot be selected. Note that if borderless printing is possible, then even if the original is rotated 90 degrees, it will be printed by automatically rotating the page by 90 degrees.

Choose the method of borderless printing that suits the original, as desired.

Scale to fit Roll Paper Width

Enlarge or reduce the original as a whole to match the roll paper width.





You can combine this function with rotating pages 90 degrees before printing so that the original width (relative to portrait orientation) matches the roll paper width in borderless printing.

For instructions on borderless printing of photos, images, and other documents to match the roll paper width, refer to the following topics, as appropriate for your computer and operating system.

- Borderless Printing by Resizing Originals to Fit the Roll Width (Windows) →P.83
- Borderless Printing by Resizing Originals to Fit the Roll Width (Mac OS) →P.85

Borderless Printing by Resizing Originals to Fit the Roll Width (Windows)

This topic describes how to enlarge originals before borderless printing to match the roll width, based on the following example.




- When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be uneven at
 the edges. If you require higher image quality, select No from the Automatic Cutting list in the Roll Paper Options dialog box. In this case, the paper can be printed without borders on the left and right sides only. Once
 printed and cut, please cut the upper and lower bands with scissors.
- · Document: Any type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- Paper: Roll
- Paper type: Canon Heavyweight Coated Paper
- Roll paper width: 10 inches (254.0 mm)
- 1 In the application, create an original that takes up the entire space of the paper size.



 If you can specify the margin, as in Microsoft Word, set the margin at 0 mm. For instructions on specifying the margin, refer to the software documentation.


- 2 Choose **Print** in the application menu.
- 3 Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P:148
- 4 Make sure the **Main** sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Canon Heavyweight Coated Paper.
- 6 Select the print target in the **EPrint Target** list.




- When you are using paper that takes longer for ink to adhere for borderless printing and the Cutter Unit
 touches printing surfaces that are not dry yet, it may damage the paper or the edge of the document that
 is cut, depending on frequency of use. In this kind of situation, change the ink drying time using the
 following procedure.
 - Click Advanced Settings in Media Type.
 - Select an ink drying time in the list for the Between Pages setting of Drying Time.
- Click the Page Setup tab to display the Page Setup sheet.



- In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4.
- 9 Select and click a roll paper in the LPaper Source list.

Select the **B** Borderless Printing check box to display the Information dialog box.



- 11 Select the width of the loaded roll in the Roll Paper Width list—in this case, click 10-in. Roll (254.0mm).
- 12 Click **OK** to close the **Information** dialog box.
- 13 In C Borderless Printing Method, make sure E Scale to fit Roll Paper Width is selected.
- 14 Confirm the print settings and print as desired.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Borderless Printing by Resizing Originals to Fit the Roll Width (Mac OS)

This topic describes how to enlarge originals before borderless printing to match the roll width, based on the following example.




- When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be uneven at
 the edges. If you require higher image quality, select No from the Automatic Cutting list in the Paper Detailed
 Settings dialog box. In this case, the paper can be printed without borders on the left and right sides only. Once
 printed and cut, please cut the upper and lower bands with scissors.
- · Document: Any type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- · Paper: Roll
- Paper type: Canon Heavyweight Coated Paper
- Roll paper width: 10 inches (254.0 mm)

1 Choose Page Setup from the application menu to display the Page Attributes dialog box.



 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the B Format for list.
- In C Paper Size, click the size of the original. In this case, click ISO A4.



- All sizes are available in borderless printing if you resize originals to fit the roll width.
- 4 Click **FOK** to close the dialog box.
- 5 In the application, create an original that takes up the entire space of the paper size.
- 6 Choose **Print** in the application menu.
- 7 Access the Main pane.




In the A Media Type list, select the type of paper that is loaded. In this case, click Canon Heavyweight Coated Paper.





- When you are using paper that takes longer for ink to adhere for borderless printing and the Cutter Unit
 touches printing surfaces that are not dry yet, it may damage the paper or the edge of the document that
 is cut, depending on frequency of use. In this kind of situation, change the ink drying time in Between
 Pages in the Paper Detailed Settings dialog box.
- 10 Access the Page Setup pane.



- 11 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, 10 in. (254.0mm) is selected.
- 13 Select the DEnlarged/Reduced Printing check box.
- Select the H Borderless Printing check box.

 This ensures that F Fit Roll Paper Width is automatically selected in D Enlarged/Reduced Printing.
- 15 Confirm the print settings, and then click M Print to start printing.



For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Printing banners or at other non-standard sizes

Printing Vertical or Horizontal Banners (Large-Format Printing)	89
Printing on Non-Standard Paper Sizes	95

Printing Vertical or Horizontal Banners (Large-Format Printing)

On this printer, large-format printing of up to 18.0 m is available using rolls.


If you use Print Plug-In for Office or PosterArtist, you can easily print maximum 18.0 m vertical or horizontal banners. (Refer to "Print Plug-In for Officefeatures (Windows)" >P.212 and "Using PosterArtist to Compose Originals" >P.38 .)

However, you may not be able to print 18.0 m due to restrictions in the settable document size according to the application software.

Fit Roll Paper Width

To match the width of vertical and horizontal banners with the width of rolls, use the printer driver function for automatically enlarging/reducing and printing.

For example, if you automatically enlarge a document created with application software such as Microsoft Word, you can print the full width of the roll easily.



For instructions on printing vertical or horizontal banners, refer to the following topics, as appropriate for your computer and operating system.

- Printing Vertical or Horizontal Banners (Large-Format Printing; Windows) →P.89
- Printing Vertical or Horizontal Banners (Large-Format Printing; Mac OS) →P.92



- Before printing, check how much of the roll paper is left. If you have activated automatic detection of the remaining roll paper, a warning message is displayed when there is not enough roll paper left.
- If not much ink is left, prepare replacement ink tanks.
- To print at a higher level of quality, in the printer driver, choose **High** or **Highest** in Print Quality, and choose **Unidirectional Printing** as the direction of printing.

89

Printing Vertical or Horizontal Banners (Large-Format Printing; Windows)

By automatic enlargement of a document created with an application software by the printer driver, you can print maximum 18.0 m vertical or horizontal banners.

However, you may not be able to print 18.0 m due to restrictions in the settable document size according to the application software.

This topic describes how to print a banner about five times as long as the roll width based on the following example.

- · Document: A horizontal banner created in Microsoft Word
- Page size: Non-standard (100×500 mm [3.9×19.7 in])
- · Paper: Roll
- Paper type: Plain Paper
- Roll paper width: 16 in (406.4 mm)


The print procedure is as follows.

- Register a Custom Paper Size in the printer driver.
 Call a non-standard paper size registered in the printer driver with Custom Paper Size.
 Once you register Custom Paper Size, you then can select it repeatedly from the paper size list.
 Custom Paper Size can be set up to 18.0 m.
- 2. In the application, create an original in the size you registered.
- Print the banner, using the settings that correspond to banners.

Registering a Custom Paper Size

This example describes how to register a paper size that is horizontally elongated and suitable for banners in either horizontal or vertical format.

- Display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from the Operating System Menu .") →P.149
- Click the Page Setup tab to display the Page Setup sheet.



- 3 Select and click a roll paper in the LPaper Source list.
- 4 Click Osize Options to display the Paper Size Options dialog box.
- 5 Enter a desired paper name in Custom Paper Size Name. My Horizontal Banner is used in this example.
- 6 In Units, click mm.
- 7 Under Paper Size, enter 100 in Width and 500 in Height.
- 8 Click **Add** to add the paper size of **My Horizontal Banner**.
- 9 Click **OK** to close the **Paper Size Options** dialog box.

10 Close the printer driver dialog box.



 Although you can even set Custom Size for the paper size, the maximum settable size is 3.2 m. The setting of Custom Size is disabled when you exit the application software.

For more information, see "Printing on Non-Standard Paper Sizes ." >P.95

Creating the banner in the application


Follow the steps below to create the banner in Microsoft Word using the Custom Paper Size you registered.

- 1 Start Microsoft Word.
- Choose Page Setup from the File menu to display the Page Setup dialog box.
- 3 Under Paper Size, click the Custom Paper Size you registered—My Horizontal Banner in this example.
- If My Horizontal Banner is not listed, make sure this printer is selected as the printer to use.
- In applications such as Microsoft PowerPoint that do not enable you to choose registered paper sizes, use the custom paper size setting in **Custom** and specify 100×500 mm (3.9×19.7 in)
- 4 Set the printing orientation to horizontal.
- 5 Create the banner.

Printing the banner


Follow these steps to print the banner using the corresponding banner settings.

- 1 Choose **Print** in the Microsoft Word menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- After confirming that DEasy Settings is selected, click Poster in the EPrint Target list.


Click the Page Setup tab to display the Page Setup sheet.



- 7 In the A Page Size list, click the size you registered, My Horizontal Banner.
- 8 Select the CEnlarged/Reduced Printing check box.



 If the C Enlarged/Reduced Printing check box is not displayed on the Page Setup sheet, clear the B Borderless Printing check box.




- 9 Select and click a roll paper in the LPaper Source list.
- 10 After you click **E** Fit Roll Paper Width, the Information dialog box is displayed.
- Select the width of the loaded roll in the Roll Paper Width list. In this case, click 16-in. Roll (406.4mm), and then click OK.
- 12 Confirm the print settings and print as desired.




• For tips on confirming print settings, see "Confirming Print Settings ." →P.145

If printing is unsuccessful, you may be able to print after completing the following setting.

On the **Layout** sheet, click **J Special Settings** to display the **Special Settings** dialog box.



2 In the FineZoom Settings list, click Yes.



Printing Vertical or Horizontal Banners (Large-Format Printing; Mac OS)

By automatic enlargement of a document created with an application software by the printer driver, you can print maximum 18.0 m vertical or horizontal banners.

This topic describes how to print a banner about five times as long as the roll width based on the following example.

- Document: An original designed for a horizontal banner
- Page Size: Non-standard (100×500 mm [3.9×19.7 in])
- Paper: Roll
- Paper type: Plain Paper
- Roll paper width: 16 inches (406.4 mm)

The print procedure is as follows.

- $oldsymbol{1}_{oldsymbol{\cdot}}$ In the application, create an original in the format of a horizontal or vertical banner.
- In Page Setup, register Custom Paper Sizes.
 Once you register Custom Paper Sizes, you then can select it repeatedly from the paper size list.
 Custom Paper Sizes can be set up to 18.0 m.
- Print the banner, using the settings that correspond to banners.



92

 The following instructions are for OS X v10.7. The method of setting up non-standard paper sizes varies depending on the version and settings of Mac OS X.

Register a Custom Paper Sizes


This example describes how to register and print using a page size that is horizontally elongated and suitable for banners in either horizontal or vertical format.

1 Create the document in the application.

2 Choose **Print** in the application menu.



- 3 Select the printer in the A Printer list.
- 4 Click Manage Custom Sizes in the F Paper Size list to display the Custom Paper Sizes dialog box.



- 5 Double-click **Untitled** in the list at left, and then enter a name for the page size you want to register. Here, enter **100*500**.
 - If the **Untitled** size is not listed at left, click + below the list.
- Under Paper Size, enter 100 in Width and 500 in Height. Here, measurements are entered in millimeters.
- Specify the margins by entering 3 in Non-Printable Area. Here, too, measurements are entered in millimeters.
- 8 Click **OK** to close the **Custom Paper Sizes** dialog box.
- In the F Paper Size list, click the size of the original. In this case, click 100*500, the size you registered.
- 10 In G Orientation, click the icon of the document in landscape orientation.
- 11 If you configured the settings using the Page Attributes dialog box, click OK to close the dialog box.

Print the banner


Follow the steps below to print the banner using the corresponding banner settings.

1 Choose **Print** in the application menu.

Access the Main pane.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 4 Make your selection in the E Print Target list.
- 5 Make your selection in the F Print Quality list.
- 6 Access the Page Setup pane.



- 7 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, 16 in. (406.4mm) is selected.
- 94 Select the DEnlarged/Reduced Printing check box.
 - 10 Click F Fit Roll Paper Width.

Confirm the print settings, and click **M Print** to start printing.



For tips on confirming print settings, see "Confirming Print Settings." →P.252

Printing on Non-Standard Paper Sizes

For printing on non-standard size paper, first register the paper size in the printer driver.

Once you register a paper size, you then can select it repeatedly from the paper size list. The paper size can be set up to 18.0 m.



 In Windows, although you can even set Custom Size for the paper size, the maximum settable size is 3.2 m. The setting of **Custom Size** is disabled when you exit the application software.

For instructions on specifying non-standard paper sizes for printing, refer to the following topics, as appropriate for your computer and operating system.

- Printing on Non-Standard Paper Sizes (Windows) →P.95
- Printing on Non-Standard Paper Sizes (Mac OS) →P.98

Printing on Non-Standard Paper Sizes (Windows)

For printing on non-standard size paper, first register the paper size in the printer driver.

Call a non-standard paper size registered in the printer driver with Custom Paper Size.

Once you register Custom Paper Size, you then can select it repeatedly from the paper size list. Custom Paper Size can be set up to 18.0 m.




Although you also can set **Custom Size** for the paper size temporarily, the maximum settable size is 3.2 m. Also, the setting of **Custom Size** is disabled when you exit the application software.

Registering and Printing With a Custom Paper Size


This topic describes how to register a non-standard paper size by the name of 430 mm Square and print based on the following example.

- Document: Any Type
- Page Size: A square sheet (430 × 430 mm [16.9 × 16.9 in])
- Paper: Sheets
- Media Type: Any type
- Paper Size: A square sheet (430 × 430 mm [16.9 × 16.9 in])
- Load the square paper (430 × 430 mm [16.9 × 16.9 in]) in the printer.
- Choose Print in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") →P.148

4 Make sure the **Main** sheet is displayed.



- 5 In the A Media Type list, select the type of paper that is loaded.
- 6 After confirming that D Easy Settings is selected, select from the E Print Target list.
- 7 Click the Page Setup tab to display the Page Setup sheet.



- 8 Click OSize Options to display the Paper Size Options dialog box.
- 9 Enter a desired paper name in Custom Paper Size Name. 430 mm Square is used in this example.
- 10 Select mm in Units.
- 11 Enter 430 (16.9 in) in both Width and Height.



- If you select the Fix the Ratio of the Width to Height check box, after you enter a value in either Width
 or Height, the other value will be automatically applied based on the original aspect ratio.
- 12 Click Add to register 430 mm Square.
- 13 Click **OK** to close the **Paper Size Options** dialog box.
- 96 14 Click Manual in the L Paper Source list.
 - 15 In the A Page Size list, click the size you added,430 mm Square.

16 Confirm the print settings and print as desired.




• For tips on confirming print settings, see "Confirming Print Settings ." →P.145


Printing by using Custom Size

This section describes how to print using **Custom Size** based on the following example.

- · Document: Any Type
- Page size: Square of non-standard dimensions (430×430 mm [16.9×16.9 in])
- · Paper: Sheets
- Paper type: Any type
- Paper Size: A square sheet (430 × 430 mm [16.9 × 16.9 in])
- Load the square paper (430 × 430 mm [16.9 × 16.9 in]) in the printer.
- 2 Choose **Print** in the application menu.
- 3 Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 4 Make sure the **Main** sheet is displayed.



- 5 In the A Media Type list, select the type of paper that is loaded.
- 6 After confirming that DEasy Settings is selected, select from the EPrint Target list.
- Click the Page Setup tab to display the Page Setup sheet.



8 Click Manual in the L Paper Source list.

- Click Custom Size in the A Page Size list to display the Custom Size Settings dialog box.
- 10 Confirm that mm is selected in Units.
- 11 Enter 430 (16.9 in) in both Width and Height.
- 12 Click **OK** to close the **Custom Size Settings** dialog box.
- 13 Confirm the print settings and print as desired.



For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Printing on Non-Standard Paper Sizes (Mac OS)

For printing on non-standard size paper, first register the paper size in the printer driver.

Call a non-standard paper size registered in the printer driver with Custom Paper Sizes .

Once you register Custom Paper Sizes, you then can select it repeatedly from the paper size list.

Custom Paper Sizes can be set up to 18.0 m.

This topic describes how to register a non-standard paper size by the name of **430*430** and print based on the following example.


- · Document: Any Type
- Page Size: A square sheet (430 × 430 mm [16.9 × 16.9 in])
- · Paper: Sheets
- Media Type: Any type
- Paper Size: A square sheet (430 × 430 mm [16.9 × 16.9 in])




- The following instructions are for OS X v10.7. The method of setting up non-standard paper sizes varies depending on the version and settings of Mac OS X.
- 1 Create the document in the application.
- Load the square paper (430 × 430 mm [16.9 × 16.9 in]) in the printer.
- 3 Choose **Print** in the application menu.



- 4 Select the printer in the A Printer list.
- 5 Click Manage Custom Sizes in the F Paper Size list to display the Custom Paper Sizes dialog box.




- In Paper Size, enter the height and width of the original. Here, enter 430 mm in Height and Width.
- 7 In **Non-Printable Area**, enter **5** for the top and side margins and **23** for the bottom margin. Here, measurements are entered in millimeters.
- 8 Double-click **Untitled** in the list at left in the **Custom Paper Sizes** dialog box and enter the paper name—in this case, **430*430**.
- 9 Click **OK** to close the **Custom Paper Sizes** dialog box.
- 10 In the F Paper Size list, click the size of the original. In this case, click 430*430, the size you registered.
- If you configured the settings using the **Page Attributes** dialog box, click **OK** to close the dialog box, and then select **Print** from the application software menu.
- 12 Access the Main pane.




- 13 In the A Media Type list, select the type of paper that is loaded.
- 14 After confirming that DEasy Settings is selected, select from the EPrint Target list.
- 15 Make your selection in the F Print Quality list.

16 Access the Page Setup pane.



- 17 Click Manual in the A Paper Source list.
- 18 Confirm the print settings, and then click M Print to start printing.



Tiling and multiple pages per sheet

Printing Multiple Originals Next to Each Other	101 102
Printing Multiple Originals Next to Each Other (Mac OS)	
Printing Multiple Pages Continuously	
Printing Multiple Pages Continuously (Windows)	105
Printing Multiple Pages Continuously (Mac OS)	106
Printing Multiple Pages Per Sheet	108
Printing Multiple Pages Per Sheet (Windows)	
Printing Multiple Pages Per Sheet (Mac OS)	
Printing Posters in Sections	113
Printing Large Posters (Windows)	

Printing Multiple Originals Next to Each Other

By arranging originals from word-processing or spreadsheet programs or web browser screen shots next to each other on single sheets, you can create highly expressive presentation materials, easy-to-understand meeting materials, and a variety of other printed documents.

• Free Layout (Windows)

Besides combining multiple pages in a single-page layout, you can combine originals from multiple files—even multiple source applications—in a single-page layout.



• Free Layout (Mac OS)

Besides combining multiple pages in a single-page layout, you can combine originals from multiple files—even multiple source applications—in a single-page layout.




For instructions on arranging originals from multiple applications, refer to the following topics.

- Printing Multiple Originals Next to Each Other (Windows) →P.102
- Printing Multiple Originals Next to Each Other (Mac OS) →P.103

Printing Multiple Originals Next to Each Other (Windows)


This topic describes how to arrange multiple originals using the Free Layout function.

- 1 Choose **Print** in the application menu.
- 2 Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") →P.148
- 3 Make sure the **Main** sheet is displayed.



103

4 Click the Layout tab to display the Layout sheet.



- 5 Select the A Page Layout check box.
- 6 Click Free Layout in the A Page Layout list.
- When you attempt to print, the **imagePROGRAF Free Layout** window is displayed. (At this point, the document will not be printed yet.)



8 Edit and rearrange the image in the imagePROGRAF Free Layout window as desired.



- Without closing the imagePROGRAF Free Layout window, repeat steps 1–7 to arrange originals from multiple applications on the same page.
- For instructions on editing and rearranging images, refer to the imagePROGRAF Free Layout help topic.
- Print from the imagePROGRAF Free Layout menu.




• For details on imagePROGRAF Free Layout functions, see "Free Layout." →P.182

Printing Multiple Originals Next to Each Other (Mac OS)


This topic describes how to use the **Free Layout** function to arrange multiple originals next to each other before printing.

1 Choose **Print** in the application menu.

Access the Page Setup pane.



- 3 Select the N Free Layout check box.
- 4 Click M Print.
- The Canon imagePROGRAF Free Layout window is displayed.



6 Edit and rearrange the image in the Canon imagePROGRAF Free Layout window as desired.



- Without closing the Canon imagePROGRAF Free Layout window, repeat steps 1 to 4 to arrange originals from multiple applications on the same page.
- For instructions on editing and rearranging images, refer to the **Canon imagePROGRAF Free Layout** help topic.
- 7 Print from the Canon imagePROGRAF Free Layout menu.




• For details on Canon imagePROGRAF Free Layout functions, see "Free Layout." →P.289

104 Printing Multiple Pages Continuously

You can print multiple pages as a single continuous image, without margins between pages.

Banner Printing





- This feature is only available with rolls. It cannot be used when printing on sheets.
- When using Banner Printing, some of the settings are disabled, including Borderless Printing, Enlarge/ Reduce Printing, and Layout.

For instructions on printing multiple pages continuously, refer to the following topics, as appropriate for your operating system.


- Printing Multiple Pages Continuously (Windows) →P.105
- Printing Multiple Pages Continuously (Mac OS) →P.106

Printing Multiple Pages Continuously (Windows)

This topic describes how to print multiple pages as a single continuous image, without margins between pages.



- This feature is only available with rolls. It cannot be used when printing on sheets.
- When using Banner Printing, some of the settings are disabled, including Borderless Printing, Enlarge/Reduce Printing, and Layout.
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications.") >P.148
- Make sure the **Main** sheet is displayed.




In the A Media Type list, click the type of paper that is loaded.

Click the Page Setup tab to display the Page Setup sheet.



- 6 Select and click a roll paper in the LPaper Source list.
- 7 Click N Roll Paper Options to display the Roll Paper Options dialog box.



- 8 Select the Banner Printing check box.
- 9 Click OK.
- 10 Confirm the print settings and print as desired.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Printing Multiple Pages Continuously (Mac OS)


This topic describes how to print multiple pages as a single continuous image, without margins between pages.




- This feature is only available with rolls. It cannot be used when printing on sheets.
- When using Banner Printing, some of the settings are disabled, including Borderless Printing, Enlarge/Reduce Printing, and Layout.

107

1 Choose Page Setup from the application menu to display the Page Attributes dialog box.






If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the **B** Format for list.
- Choose the original size in the C Paper Size list.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the Main pane.



- 7 In the A Media Type list, click the type of paper that is loaded.
- 8 Make your selection in the E Print Target list.
- Make your selection in the F Print Quality list.

10 Access the Page Setup pane.




- 11 Click Roll Paper (Banner) in the A Paper Source list.
- 12 Confirm the print settings, and then click M Print to start printing.



For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Printing Multiple Pages Per Sheet

To conserve paper, you can print several pages of the original on a single sheet by reducing the original and dividing the sheet into areas for each page.



Page Layout

Specify a number of pages of the original to print on a single sheet, in a layout of multiple pages per sheet.



- This function cannot be combined with the following options.
 - Borderless Printing
 - Scaling Originals (Windows)
 - Banner Printing (Windows)
- When printing using this function, the **Print Centered** setting is disabled.



- You can print up to 16 pages of the original on a single sheet.
- Note You can also change the page layout order and print page boundary lines, as desired.


For instructions on printing multiple pages per sheet, refer to the following topics, as appropriate for your computer and operating system.

- Printing Multiple Pages Per Sheet (Windows) →P.109
- Printing Multiple Pages Per Sheet (Mac OS) →P.110


Printing Multiple Pages Per Sheet (Windows)

This topic describes how to print four pages of originals together on a single sheet based on the following example.

- · Document: Any Type
- Page size: A3 (297.0×420.0 mm [11.7×16.5 in])
- Paper: Roll
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.




- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5 Make your selection in the EPrint Target list.
- Make your selection in the F Print Quality list.
- Click the Page Setup tab to display the Page Setup sheet.



In A Page Size, click the size of the original as specified in the application software. In this case, click ISO A3.

- Select and click a roll paper in the LPaper Source list.
- Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 11 Click the Layout tab to display the Layout sheet.



- 12 Select the A Page Layout check box.
- 13 Click 4 Pages/Sheet in the A Page Layout list.



- You can select the layout order for placing four pages on a sheet and a frame border in the Page Layout
 Printing dialog box by clicking B Set. If you select a pattern to print borders, the size of the images are
 reduced about 5% to create space for the printed border. If None is selected, then the images are not
 reduced for printing.
- 14 Confirm the print settings and print as desired.




For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Printing Multiple Pages Per Sheet (Mac OS)


This topic describes how to print four pages of an original on a single sheet, based on the following example.

- Document: Any Type
- Page size: A3 (297.0 × 420.0 mm [11.7 × 16.5 in])
- Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])






 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



G Orientation:

If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the B Format for list.
- In the C Paper Size list, click the size of the original. In this case, click ISO A3.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the Layout pane.




7 Click 4 in the A Pages per Sheet list.




 You can choose the layout order and specify a boundary line for the four pages in B Layout Direction and C Border. 8 Access the **Main** pane.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 10 Make your selection in the EPrint Target list.
- 11 Make your selection in the F Print Quality list.
- 12 Access the Page Setup pane.




- 13 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, ISO A2/A3 (420.0mm) is selected.
- 12 15 Confirm the print settings, and then click M Print to start printing.



Printing Posters in Sections

You can enlarge an original to print it in sections on several sheets. By assembling the printed sheets, you can create a poster larger than the maximum supported paper size of the printer.



Page Layout

Choose poster printing.



When printing using this function, the Print Centered, Watermark, No Spaces at Top or Bottom (Conserve Paper), and Page Options settings are disabled.

For instructions on printing large posters, refer to the following topics, as appropriate for your computer and operating system.

Printing Large Posters (Windows) →P.113




This method of poster printing is supported in Windows.

Printing Large Posters (Windows)

You can enlarge an original to print it in sections on several sheets. By assembling the printed sheets, you can create a poster larger than the maximum supported paper size of the printer. This topic describes how to enlarge an A2 original for printing it in sections on four sheets, based on the following example.

- Document: Poster
- Page size: A2 (420.0×594.0 mm [16.5 × 23.4 in])
- · Paper: Sheets
- Paper Size: A2 (420.0 × 594.0 mm [16.5 × 23.4 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.




In the A Media Type list, select the type of paper that is loaded.

113


5 Click **Poster** in the **EPrint Target** list.

Printing Large Posters (Windows)

Click the Page Setup tab to display the Page Setup sheet.



- 7 In A Page Size, click the size of the original as specified in the application. In this case, click ISO A2.
- 8 Click Manual in the L Paper Source list.
- 9 Click the Layout tab to display the Layout sheet.



- 10 Select the A Page Layout check box.
- 11 Click Poster (2 x 2) in the A Page Layout list.
- Follow the steps below to print only a portion of the poster as divided for printing.

Note

- Click B Set under A Page Layout to display the Pages to Print dialog box.
- On the Pages to Print dialog box, clear the check boxes of the portion you do not want to print.
- Click **OK** to close the **Pages to Print** dialog box.
- 12 Confirm the print settings and print as desired.



For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Centering originals


Printing Originals Centered on Rolls	115
Printing Originals Centered on Rolls (Windows)	115
Printing Originals Centered on Rolls (Mac OS)	117
Printing Originals Centered on Sheets	119
Printing Originals Centered on Sheets	

Printing Originals Centered on Rolls

You can print originals centered on a page—for example, if the paper is larger than the original, or if you are reducing the original.

Print Centered

If you use originals smaller than the roll paper width, you can center them relative to the width when printing.



For instructions on centering originals when printing on rolls, refer to the following topics, as appropriate for your computer and operating system.


- Printing Originals Centered on Rolls (Windows) →P.115
- Printing Originals Centered on Rolls (Mac OS) →P.117

Printing Originals Centered on Rolls (Windows)


This topic describes how to center originals before printing on rolls based on the following example.

- Document: Any type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- · Paper: Roll
- Paper type: Plain Paper
- Roll width: A3/A4 roll (297.0 mm [11.7 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148


3 Make sure the Main sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5 Select the print target in the EPrint Target list.
- 6 Click the Page Setup tab to display the Page Setup sheet.



- In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").
- 8 Select and click a roll paper in the LPaper Source list.
- Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A3/A4 Roll (297.0mm).
- 10 Click the Layout tab to display the Layout sheet.



- 11 Select the EPrint Centered check box.
- 12 Confirm the print settings and print as desired.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.145


Printing Originals Centered on Rolls (Mac OS)

This topic describes how to center originals before printing on rolls based on the following example.

- · Document: Any Type
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A3/A4 roll (297.0 mm [11.7 in])
- 1 Choose Page Setup from the application menu to display the Page Attributes dialog box.




 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.




- If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.
- 2 Select the printer in the B Format for list.
- 3 In C Paper Size, click the size of the original. In this case, click ISO A4.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.


6 Access the Main pane.



- 7 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 8 Make your selection in the EPrint Target list.
- Make your selection in the F Print Quality list.
- 10 Access the Page Setup pane.



- 11 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, ISO A3/A4 (297.0mm) is selected.
- 118 13 Select the J Print Centered check box.
 - $oxed{14}$ Confirm the print settings, and then click $oxed{\mathsf{M}}$ **Print** to start printing.




Printing Originals Centered on Sheets

You can print originals centered on a page—for example, if the paper is larger than the original, or if you are reducing the original.

Print Centered

If you use paper larger than the original size or print originals after reduction, the printed images may be aligned in the upper-left corner of the paper. In this case, you can center originals on sheets when printing.




For instructions on centering originals when printing on sheets, refer to the following topics, as appropriate for your computer and operating system.

- Printing Originals Centered on Sheets (Windows) →P.119
- Printing Originals Centered on Sheets (Mac OS) →P.120

Printing Originals Centered on Sheets (Windows)


This topic describes how to reduce an original 50% for printing centered on a sheet.

- · Document: Any Type
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- · Paper: Sheets
- · Paper type: Plain Paper
- Paper size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.




- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5 Make your selection in the EPrint Target list.

Click the Page Setup tab to display the Page Setup sheet.



- 7 In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4.
- 8 Select the CEnlarged/Reduced Printing check box.
- 9 Click Match Page Size in the G Paper Size list.
- 10 Click F Scaling and enter 50.
- 11 Click Manual in the L Paper Source list.
- 12 Click the Layout tab to display the Layout sheet.



- 13 Select the EPrint Centered check box.
- 14 Confirm the print settings and print as desired.
 - If you have selected **Manual** as the paper source, follow the instructions on the printer control panel to enter the paper size.
 - For tips on confirming print settings, see "Confirming Print Settings ." →P.145

 Note

Printing Originals Centered on Sheets (Mac OS)


This topic describes how to center originals for printing on sheets, based on the following example.


- · Document: Any Type
- Page size: A4


· Paper: Sheets

Paper type: Plain PaperPaper size: Non-standard

1 Choose Page Setup from the application menu to display the Page Attributes dialog box.








- 2 Select the printer in the B Format for list.
- In the C Paper Size list, click the size of the original. In this case, click ISO A4 for Paper Tray (Large Margins).
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the Main pane.



- 7 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 8 Make your selection in the EPrint Target list.

- Make your selection in the F Print Quality list.
- 10 Access the Page Setup pane.



- 11 Click Manual in the A Paper Source list.
- 12 Select the J Print Centered check box.
- 13 Confirm the print settings, and then click MPrint to start printing.



For tips on confirming print settings, see "Confirming Print Settings ." →P.252



If you have selected Manual as the paper source, follow the instructions on the printer control panel to enter the
paper size.

Conserving roll paper


Conserving Roll Paper by Rotating Originals 90 Degrees	123
Conserving Roll Paper by Rotating Originals 90 Degrees (Windows)	
Conserving Roll Paper by Rotating Originals 90 Degrees (Mac OS)	
Conserving Roll Paper by Printing Originals Without Top and Bottom Margins	126
Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Windows)	127
Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Mac OS)	

Conserving Roll Paper by Rotating Originals 90 Degrees

You can conserve roll paper by specifying particular settings as suitable for your original.

Rotate Page 90 degrees (Conserve Paper)

When originals are printed in portrait orientation, the original is rotated 90 degrees before printing if it fits within the roll width. This enables you to conserve paper.





If the page would exceed the roll paper width after rotation, use this function with Scale to fit Roll Paper Width to print rotated pages.

For tips on conserving roll paper, refer to the following topics, as appropriate for your computer and operating system.

- Conserving Roll Paper by Rotating Originals 90 Degrees (Windows) →P.123
- Conserving Roll Paper by Rotating Originals 90 Degrees (Mac OS) →P.124

Conserving Roll Paper by Rotating Originals 90 Degrees (Windows)


This topic describes how to conserve paper by rotating originals 90 degrees before printing, based on the following example.

- Document: Any type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3×11.7 in)
- Paper: Roll
- Paper type: Plain Paper
- Roll paper width: A3/A4 roll (297.0 mm [11.7 in])


This example illustrates how to rotate an A4 (210.0×297.0 mm)/Letter (8.3×11.7 in) original in portrait orientation 90 degrees to fit within the width of A3/A4 roll paper (297.0 mm [11.7 in]), which enables you to conserve paper.

- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148)


3 Make sure the **Main** sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5 Click the Page Setup tab to display the Page Setup sheet.



- In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").
- 7 Select and click a roll paper in the LPaper Source list.
- Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A3/A4 Roll (297.0mm).
- 9 Select the KRotate Page 90 degrees (Conserve Paper) check box.
- 10 Confirm the print settings and print as desired.




Conserving Roll Paper by Rotating Originals 90 Degrees (Mac OS)


- This topic describes how to conserve roll paper by rotating originals 90 degrees before printing, based on the following example.
 - Document: Any Type
 - Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
 - · Paper: Roll paper
 - Paper type: Plain Paper
 - Roll paper width: A3/A4 roll (297.0 mm [11.7 in])

This example illustrates how to rotate an A4 ($210.0 \times 297.0 \text{ mm}$)/Letter ($8.3 \times 11.7 \text{ in}$) original in portrait orientation 90 degrees to fit within the width of A3/A4 roll (297.0 mm [11.7 in]), which enables you to conserve paper.

1 Choose Page Setup from the application menu to display the Page Attributes dialog box.




- 2 Select the printer in the B Format for list.
- In C Paper Size, click the size of the original. In this case, click ISO A4.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the Main pane.



7 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.

8 Access the Page Setup pane.



- 9 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, ISO A3/A4 (297.0mm) is selected.
- 11 Select the LRotate Page 90 degrees check box.
- 12 Confirm the print settings, and then click M Print to start printing.




• For tips on confirming print settings, see "Confirming Print Settings ." →P.252

Conserving Roll Paper by Printing Originals Without Top and Bottom Margins

You can conserve roll paper by specifying particular settings as suitable for your original.

No Spaces at Top or Bottom (Conserve Paper)

You can print without feeding the paper for blank portions of originals if there are top and bottom margins in originals. This enables you to conserve as much paper as the size of the margins.





• Printing without the top and bottom margins is not supported in the following cases.

Important • If you have chosen poster as the type of page layout

- in you have chosen poster as the type of page layo
 - Even during borderless printing, you can print without the top and bottom margins.

 Printing without the top and bottom margins may cause inconsistency in the size of printed documents, depending on the layout of images or text in your originals.

For tips on conserving roll paper, refer to the following topics, as appropriate for your computer and operating system.


Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Windows) →P.127

Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Mac OS) →P.128


Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Windows)

This topic describes how to conserve roll paper when printing originals that have a top and bottom margin, based on the following example.

- · Document: Any type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- · Paper: Roll
- Paper type: Plain Paper
- Roll paper width: A3/A4 roll (297.0 mm [11.7 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.




- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- Click the Page Setup tab to display the Page Setup sheet.



- In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").
- 7 Select and click a roll paper in the **L** Paper Source list.
- Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A3/A4 Roll (297.0mm).

Olick the **Layout** tab to display the **Layout** sheet.



- 10 Select the GNo Spaces at Top or Bottom (Conserve Paper) check box.
- 11 Confirm the print settings and print as desired.



For tips on confirming print settings, see "Confirming Print Settings ." →P.145


Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Mac OS)

This topic describes how to conserve roll paper when printing originals that have a top and bottom margin, based on the following example.

- Document: Any Type
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- Paper: Roll paperPaper type: Plain Paper
- Roll paper width: A3/A4 roll (297.0 mm [11.7 in])
- 1 Choose Page Setup from the application menu to display the Page Attributes dialog box.




 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.




If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the B Format for list.
- In C Paper Size, click the size of the original. In this case, click ISO A4.
- 4 Click **FOK** to close the dialog box.

- 5 Choose **Print** in the application menu.
- 6 Access the Main pane.



- 7 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 8 Access the Page Setup pane.



- Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, ISO A3/A4 (297.0mm) is selected.
- 11 Select the KNo Spaces at Top or Bottom check box.
- 12 Confirm the print settings, and then click M Print to start printing.



For tips on confirming print settings, see "Confirming Print Settings ." →P.252


Checking Images Before Printing

Checking the Layout in a Preview Before Printing

You can check the print layout on the preview screen.

Open Preview When Print Job Starts (Windows)

While viewing the preview screen, you can also adjust orientation or other settings, and your changes will be instantly applied on the preview screen.






Under some settings and in some environments, PageComposer may be started.

• Preview (Mac OS)

While viewing the preview screen, you can also adjust layout or size settings, and your changes will be instantly applied on the preview screen.



For instructions on how to check the layout before printing, refer to the following topics:

- Checking the Layout in a Preview Before Printing (Windows) →P.145
- Checking the Layout in a Preview Before Printing (Mac OS) →P.253

Printing With Watermarks

Other useful settings

Printing With Watermarks — COPY, FILE COPY, and so on (Windows)	131
Making the Original Orientation Match the Paper Orientation	
Making the Original Orientation Match the Paper Orientation (Windows)	134
Making the Original Orientation Match the Paper Orientation (Mac OS)	135
Using Favorites	
→ Using Favorites (Windows)	
→ Using Favorites (Mac OS)	253
Cutting Roll Paper After Printing	137
Cutting Roll Paper After Printing (Windows)	
Cutting Roll Paper After Printing (Mac OS)	138

Printing With Watermarks

You can add watermarks (background images) to documents that require special handling.





Watermark

Watermarks are applied to all pages of your document.



Watermarks are not printed if you select poster as the type of page layout.

The following watermarks are provided:

- CONFIDENTIAL
- COPY
- DRAFT
- FILE COPY
- FINAL
- PRELIMINARY
- PROOF
- TOP SECRET

You can also create your own watermarks. Specify the following options to customize your watermark.

- Watermark string: Specify the font, size, color, and so on. Surround the watermark with a frame, if desired.
- Watermark position: Specify the position on the page, the angle, and so on.
- Watermark printing method: Specify whether to print the watermark superimposed or under the document image. You can also print the watermark only on the first page, if desired.



Watermarks are supported in Windows.

Note • In addition to the provided watermarks, you can create up to 50 original watermarks.

For detailed instructions on printing with watermarks, refer to the following topics:


131

Printing with Watermarks—COPY, FILE COPY, and so on (Windows) →P.132

Printing with Watermarks—COPY, FILE COPY, and so on (Windows)


This topic describes how to print with watermarks, based on the following example of printing with a **FILE COPY** watermark.

- Document: Any type
- Page size: A2 (420.0×594.0 mm [16.5 × 23.4 in])
- Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.




- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5 Make your selection in the EPrint Target list.
 - You can check the settings values selected in the EPrint Target list by clicking GView Settings.

 Note
- 6 Click the Page Setup tab to display the Page Setup sheet.



In A Page Size, click the size of the original as specified in the application software. In this case, click ISO A2.

- 8 Select and click a roll paper in the LPaper Source list.
- 9 Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 10 Click the Layout tab to display the Layout sheet.



- 11 Select the C Watermark check box.
- 12 Click FILE COPY in the Watermarks list.



- Click D Edit Watermark to open the Edit Watermark dialog box. In the Edit Watermark dialog box, you
 can create custom watermarks and change the position and angle of watermarks.
- 13 Confirm the print settings and print as desired.




For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Making the Original Orientation Match the Paper Orientation

You can specify the original orientation to match the orientation of the paper for printing.

Orientation

Paper is usually loaded in the printer in portrait orientation. When you have an original in landscape orientation, you can specify the printing orientation so that the original is printed in landscape orientation.



Rotate 180 degrees

The original is rotated 180 degrees to print it upside down.

Mirror

A mirror image of the original is printed.


For instructions on specifying the original orientation before printing, refer to the following topics, as appropriate for your computer and operating system.

- Making the Original Orientation Match the Paper Orientation (Windows) →P.134
- Making the Original Orientation Match the Paper Orientation (Mac OS) →P.135


Making the Original Orientation Match the Paper Orientation (Windows)

This topic describes how to print an original in landscape orientation after matching the paper orientation, based on the following example.

- Document: An original in landscape orientation
- Page size: A4 (210.0 × 297.0 mm)/Letter (8.3 × 11.7 in)
- Paper: Roll
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.



- In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5 Make your selection in the EPrint Target list.
- 6 Make your selection in the F Print Quality list.
- 7 Click the Page Setup tab to display the Page Setup sheet.



- 134
- In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").
- 9 In HOrientation, click J Landscape.
- 10 Select and click a roll paper in the LPaper Source list.

- Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 12 Confirm the print settings and print as desired.



• For tips on confirming print settings, see "Confirming Print Settings ." →P.145


Making the Original Orientation Match the Paper Orientation (Mac OS)

This topic describes how to print an original in landscape orientation after matching the paper orientation, based on the following example.

- Document: An original in landscape orientation
- Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1 Choose Page Setup from the application menu to display the Page Attributes dialog box.




 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



Paper Size: ISO A4


G Orientation:

If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.




- 3 In C Paper Size, click the size of the original. In this case, click ISO A4.
- In **D** Orientation, click the icon of the document in landscape orientation.
- 5 Click **FOK** to close the dialog box.
- 6 Choose **Print** in the application menu.


7 Access the Main pane.



- 8 In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 9 Make your selection in the EPrint Target list.
- 10 Make your selection in the F Print Quality list.
- 11 Access the Page Setup pane.



- 12 Select and click a roll paper in the A Paper Source list.
- Select the paper width of the roll loaded in the printer for BRoll Width. In this case, ISO A2/A3 (420.0mm) is selected.
- Confirm the print settings, and then click M Print to start printing.



Using Favorites

Using Favorites

You can register print settings as **Favorites** to reuse settings from a particular job that met your expectations, or settings for a particular page size that you will use repeatedly.

Registering a favorite for later use. You can choose the settings you have registered from a list before printing, and you can check the settings details.



· You can also save the favorite settings as files. Using these files is a convenient way to print under the same conditions on another computer. (In Windows.)

For instructions on using favorites to print, refer to the following topics, as appropriate for your computer and operating system.

- Using Favorites (Windows) →P.146
- Using Favorites (Mac OS) →P.253

Cutting Roll Paper After Printing

Roll paper can be automatically cut after printing.



 It may not be possible to cut certain types of paper, such as adhesive paper. For details on types of paper that cannot be used with the auto cut feature, see the Paper Reference Guide. (See "Types of Paper.") >P.328

Automatic Cutting

Roll paper is cut automatically after printing. If you prefer, you can print continuously without cutting the roll, or you can print a cut line.

For instructions on cutting roll paper after printing, refer to the following topics, as appropriate for your computer and operating system.

- Cutting Roll Paper After Printing (Windows) →P.137
- Cutting Roll Paper After Printing (Mac OS) →P.138

Cutting Roll Paper After Printing (Windows)

This topic describes how to cut roll paper automatically after printing (using the auto cut function), as well as how to print a cut line for manual cutting.




- The auto cut function is activated on the printer by default and when the printer driver is installed. Follow the steps below to reactivate the function if it is disabled, or to select the setting for printing a cut line instead.
- Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") →P.148

Click the Page Setup tab to display the Page Setup sheet.



- 4 Select and click a roll paper in the LPaper Source list.
- Click N Roll Paper Options to display the Roll Paper Options dialog box.



- To enable automatic cutting, click **Yes** in the **A Automatic Cutting** list. If you prefer to cut the paper later yourself, click **Print Cut Guideline**.
- 7 Click **OK** to close the **Roll Paper Options** dialog box.
- 8 Confirm the print settings and print as desired.



For tips on confirming print settings, see "Confirming Print Settings ." →P.145

Roll paper will be automatically cut after printing.


Cutting Roll Paper After Printing (Mac OS)

This topic describes how to cut roll paper automatically after printing (using the auto cut function), as well as how to print a cut line for manual cutting.




• The auto cut function is activated on the printer by default and when the printer driver is installed. Follow the steps below to reactivate the function if it is disabled, or to select the setting for printing a cut line instead.

1 Choose Page Setup from the application menu to display the Page Attributes dialog box.




- 2 Select the printer in the B Format for list.
- Choose the original size in the C Paper Size list.
- 4 Click **FOK** to close the dialog box.
- 5 Choose **Print** in the application menu.
- 6 Access the Page Setup pane.




7 Select and click a roll paper in the A Paper Source list.

8 Access the Main pane.



- In the A Media Type list, select the type of paper that is loaded.
- Click C Set to display the Paper Detailed Settings dialog box.



- To enable automatic cutting, click **Printer Default** in the **H Automatic Cutting** list. If you prefer to cut the paper later yourself, click **Print Cut Guideline**.
 - Important
- If the automatic cut function has been deactivated on the printer, change the auto cut setting on the printer Control Panel.
- 12 Click **OK** to close the **Paper Detailed Settings** dialog box.
- 13 Confirm the print settings, and then click M Print to start printing.
 - Note
- For tips on confirming print settings, see "Confirming Print Settings." →P.252

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29

Windows Software

Printer Driver	142
Preview	172
Free Layout	182
Color imageRUNNER Enlargement Copy	203
Print Plug-In for Office	212
→ Status Monitor	468
→ Accounting	472
Device Setup Utility	463
→ Media Configuration Tool	370

Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

Printer Driver Settings iPF685

Printer Driver


Printer Driver Settings	142
Specifying Paper in the Printer Driver	144
Confirming Print Settings	
Checking the Layout in a Preview Before Printing	145
Using Favorites	
Accessing the Printer Driver Dialog Box from Applications	148
Accessing the Printer Driver Dialog Box from the Operating System Menu	
Main Sheet	150
Paper Information on Printer Dialog Box	153
Paper Detailed Settings Dialog Box	154
View Settings Dialog Box for the Printing Application	
Color Adjustment Sheet: Color	156
Object Adjustment Dialog box: Color	
Matching Sheet	157
Color Adjustment Sheet: Monochrome	159
Object Adjustment Dialog box: Monochrome	160
Page Setup Sheet	161
Output Method Dialog box	163
Paper Size Options Dialog Box	164
Layout Sheet	165
Page Options Dialog Box	166
Special Settings Dialog Box	167
Favorites Sheet	168
Utility Sheet	169
Support Sheet	170
Settings Summaries Dialog Box	170
Device Settings Sheet	171

Printer Driver Settings

For instructions on accessing the Windows printer driver, refer to the following topics.

- Accessing the Printer Driver Dialog Box from Applications →P.148
- Accessing the Printer Driver Dialog Box from the Operating System Menu →P.149

For information on the Windows printer driver settings, refer to the following topics.



Main Sheet →P.150

You can specify the type of paper, color processing, print quality, print preview, and other settings. Choose **Easy Settings** to specify basic print settings based on the printing application or **Advanced Settings** to complete more detailed settings as desired.

- Paper Detailed Settings Dialog Box →P.154
 - View Settings Dialog Box for the Printing Application →P.155
 - Color Adjustment Sheet: Color →P.156
 - Object Adjustment Dialog box: Color →P.157
 - Matching Sheet →P.157
 - Color Adjustment Sheet: Monochrome →P.159
 - Object Adjustment Dialog box: Monochrome →P.160
- Page Setup Sheet →P.161

You can specify the page size of the original, borderless printing, enlargement or reduction, the orientation, the paper size and feed source, and automatic cutting.

- Output Method Dialog box →P.163
- Paper Size Options Dialog Box →P.164
- Layout Sheet →P.165

You can specify the page layout, watermarks, the orientation, the number of copies, and print processing options.

- Page Options Dialog Box →P.166
- Special Settings Dialog Box →P.167
- Favorites Sheet →P.168


Groups of print settings you select on each sheet can be saved as a favorite. Favorites you have added can be edited or used at the time of printing as desired.

• Utility Sheet →P.169

You can specify settings related to maintenance for the Printhead and feed amount, as well as settings for **Color imageRUNNER Enlargement Copy**.

Support Sheet →P.170

You can view support information and the user manual.



Device Settings Sheet →P.171
 You can display settings for optional equipment installed on the printer and see the version information for the printer driver.

imagePROGRAF Free Layout is a feature for freely arranging originals from various source applications on a single page as desired before printing. For details, see "Free Layout." →P.182

Color imageRUNNER Enlargement Copy is a feature for automatic enlargement and printing of scanned originals from a Color imageRUNNER. For details, see "Color imageRUNNER Enlargement Copy." →P.203



• Color imageRUNNER Enlargement Copy is not displayed in 64-bit editions of Windows.


143

Specifying Paper in the Printer Driver

If you have replaced the paper, you must complete the following settings in the printer driver.



- Always specify the same type and size of paper in the printer menu and printer driver.
- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- 3 Make sure the **Main** sheet is displayed.




4 In the A Media Type list, select the type of paper that is loaded.



Click the B Get Information button to display the Paper Information on Printer dialog box. On the Paper Information on Printer dialog box, you can obtain information on the paper in the printer and configure printer driver settings for the feed source and type of paper.
 This function requires that the Status Monitor be installed.

Click the Page Setup tab to display the Page Setup sheet.



- 6 In the A Page Size list, select the size of the original as specified in the application.
- 7 In the L Paper Source list, select how paper is supplied.
- If you have selected roll paper in LPaper Source, select the width of the loaded roll in MRoll Paper Width.




• A variety of settings are available in the printer driver to suit different printing applications. For details on available printing conditions, see "Printer Driver Settings ." →P.142

Confirming Print Settings

There are two ways to confirm the print settings, as follows.

· Checking a preview of the settings

A preview of the settings is displayed on the left side of the **Main**, **Page Setup**, and **Layout** sheets. By checking illustrations and numerical values in the preview, you can confirm current settings for the page size, orientation, paper source, layout, and so on.



Display Area	Information Displayed
P Top illustrations	Illustrations indicate the orientation, page layout, borderless printing selection, color mode, and other settings information.
Q Middle, bordered area	The page size, paper size, and method and percentage of enlargement or reduction are indicated.
R Bottom illustrations	Illustrations indicate the feed source, orientation, borderless printing selection, and other settings information.



To confirm the Print Target specified in Easy Settings, click G View Settings on the Main sheet to display
the View Settings dialog box.

· Checking a print preview

You can check an image of the original just as it will be printed.

When you activate this feature, **imagePROGRAF Preview** or PageComposer is started before printing. Confirming how documents will be printed this way helps prevent printing errors.


For details on print previews, see "Checking the Layout in a Preview Before Printing." >P.130

Checking the Layout in a Preview Before Printing


This topic describes how to preview images of print jobs before actually printing them.

- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148

3 Make sure the **Main** sheet is displayed.



- 4 Select the LOpen Preview When Print Job Starts check box.
- After you click **OK**, when you print a job, the **image-PROGRAF Preview** window will be displayed.





- If PageComposer is running, access the Special Settings dialog box from the Layout sheet and clear Preview Switching.
- 6 On the main window, you can check the layout and change settings as needed.
- 7 To print, click **Print** in the **File** menu.



146

• For details on imagePROGRAF Preview functions, see "Preview." →P.172

Using Favorites

This topic describes how to register favorites and print using favorite settings.


Registering a favorite

This section describes the procedure for registering printing settings that have been changed in the driver as **Favorites**.


- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148
- Perform normal printing settings.
 The favorite is registered from here.

Using Favorites

Click the **Favorites** tab to display the **Favorites** sheet.



5 Click H Add to display the Add dialog box.



- 6 Enter a desired name in Name, such as Photos for Presentations or Monthly Report.
- 7 Choose a fitting icon for these print settings in the Icon list.
- 8 In **Comment**, enter a description of the favorite to be added, as desired.
- Click **OK** to close the **Add** dialog box.
 The favorite you have added is now displayed in **A Favorites**.




To save a favorite as a file, click JExport and specify the file to save.

Printing using the favorite

Follow the steps below to print using the favorite you have registered.

- 1 Choose **Print** in the application menu.
- Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications .") >P.148

Click the **Favorites** tab to display the **Favorites** sheet.



- 4 In the A Favorites, choose the favorite you registered.
 - To import a favorite, click Import and specify the favorite file.
- 5 Click DApply Favorite to replace the favorite settings with the current print settings.
- 6 Confirm the print settings and print as desired.




• For instructions on confirming print settings, see "Confirming Print Settings ." →P.145

Accessing the Printer Driver Dialog Box from Applications


- 1 Choose **Print** from the **File** menu to display the dialog box for printing conditions.
- 2 Select the printer, and then display the printer driver dialog box.



- The dialog box for specifying printing conditions varies depending on the source application. In some cases, when you select the printer, a sheet for configuring the printer driver is added to the dialog box.
 In the following case, click **Preferences**.
- Example: Print dialog box displayed by the application software



Six sheets of print settings are displayed by the printer driver: Main, Page Setup, Layout, Favorites, Utility, and Support.





 The titles of dialog boxes may vary depending on the application, and sheets other than these six sheets may be displayed.




- If you access the printer driver dialog box from the source application, changes you make to the settings will only
 apply temporarily to that application. Because these are sizes you specify temporarily in the printer driver, the
 sizes will not be available after you exit the application.
- You can also access the printer driver dialog box from the Windows system menu.
 To use the settings continuously in all applications, open the printer driver from the system menu to make the settings.

(See "Accessing the Printer Driver Dialog Box from the Operating System Menu .") →P.149

Accessing the Printer Driver Dialog Box from the Operating System Menu


- 1 Click start > Printers and Faxes (or Printers).
- 2 Select the printer, and then display the printer properties dialog box.



3

Main Sheet

Click **Printing Preferences** to display the **Main**(or **Printing Preferences**) dialog box, titled with the name of this printer.




iPF685



 The Device Settings sheet is also an extension of the printer driver. (See "Device Settings Sheet .") →P.171

Six sheets of print settings are displayed by the printer driver: Main, Page Setup, Layout, Favorites, Utility, and Support.





- If you access the printer driver dialog box from the operating system menu, changes you make to the settings will
 apply to all applications you use for printing.
- You can also access the printer driver dialog box from applications.
 (See "Accessing the Printer Driver Dialog Box from Applications .") →P.148


Main Sheet

The following settings are available on the **Main** sheet. For details on settings items, refer to the printer driver help file.



 On the Main sheet, choose Easy Settings to specify basic print settings based on the particular printing application, or switch to Advanced Settings to complete more detailed settings as desired. iPF685 Main Sheet

Common Items



A Media Type

Select the type of paper.

For information on the types of paper the printer supports, refer to the **Paper Reference Guide**. (See "Displaying the Paper Reference Guide.") >P.331

• B Get Information

Displays **Paper Information on Printer**. You can update the printer driver settings for the feed source, media type, and roll width by selecting the feed source.

Paper Information on Printer Dialog Box →P.153

C Advanced Settings

Displays **Paper Detailed Settings**. You can configure the printing settings to match the type of media, such as the ink drying time.

Paper Detailed Settings Dialog Box →P.154

• LOpen Preview When Print Job Starts

When the check box is selected, **imagePROGRAF Preview** is launched before printing.

This allows you to check on-screen previews of documents before printing.

Checking the Layout in a Preview Before Printing →P.130

• M Status Monitor

Starts imagePROGRAF Status Monitor.

You can check the printer status, job status, and other conditions.

You can also set up email notification if printer errors occur by completing the **Email Notice** settings.

For details, refer to the **Status Monitor** help file.


• N About

Displays version information for the printer driver.

S Defaults

Restores all settings on the sheet to the default values.

Configuration using Easy Settings



• E Print Target

Choose presets that match the type of document to be printed.

- Printing Photos and Images →P.31
- Printing Line Drawings and Text →P.40
- Printing Office Documents →P.35

Depending on the A Media Type setting, some E Print Target options may not be available.

• F Print Quality

Choose the level of print quality.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.54


G View Settings

Displays the **EPrint Target** setting values.

You can view and change the order of **EPrint Target** setting values.

View Settings Dialog Box for the Printing Application →P.155

Configuration using Advanced Settings



152

• E Print Priority

Choose the graphic elements that you want to emphasize for printing.

• Giving Priority to Particular Graphic Elements and Colors for Printing →P.54

• F Print Quality

Choose the level of print quality.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.54

THighest quality

When the check box is selected, printing is performing focusing on quality. Printing takes longer and consumes more ink than in other modes, but this mode offers superior printing quality.



If you set F Print Quality to High, you can select T Highest quality. However, depending on A Media Type and E Print Priority, you may not be able to select T Highest quality.

• U Economy Printing

If you select this option, you can print with less ink consumed. However, print quality is lower than in regular printing.

Select this option to save ink, such as when printing to check drawings. Depending on the settings of A Media Type and F Print Quality, you may not be able to select this option.



• If you set **F Print Quality** to **Fast**, you can select **U Economy Printing**. However, depending on **A Media Type** and **E Print Priority**, you may not be able to select **U Economy Printing**.

• G Color Mode

Choose the color mode.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.54



• Depending on the A Media Type setting, some G Color Mode options may not be available.

H Color Settings

Click to display the Color Settings dialog box for more advanced color settings.

Adjusting the Color in the Printer Driver →P.48

• Thicken Fine Lines

Select this option to print fine lines more distinctly.

J Unidirectional Printing


Select this checkbox to prevent problems such as misaligned lines and improve the print quality. However, the printing speed becomes slower.

K Sharpen Text

Select this option to print text more sharply.

Paper Information on Printer Dialog Box

On the **Paper Information on Printer** dialog box, you can obtain information on the paper in the printer and configure printer driver settings for the paper source and media type.





• To display the Paper Information on Printer dialog box, on the Main sheet, click Get Information by Media Type. (See "Main Sheet .") →P.150

A Paper Source


Shows the paper source supported by the printer, as well as information about the loaded paper. To update the paper source and media type settings in the printer driver, select the desired **Paper Source** option and click **OK**.

Paper Detailed Settings Dialog Box

In the **Paper Detailed Settings** dialog box, you can set **Drying Time** for the paper selected with **Media Type** of the **Main** sheet, etc.

You can display this dialog box by clicking **Advanced Settings** of **Media Type** on the **Main** sheet. (See "Main Sheet .") P150

As for the items for which you can select **Printer Default** in this dialog box, you also can set them from the control panel of the printer. (See "Menu Settings.") >P.418



A Drying Time

Specify the time that the printer waits for ink to dry, as needed. The Between Pages setting is only valid for rolls.

Between Pages

You can set the time to wait after printing 1 document page until ejecting the paper. Since waiting time is required for ink to dry before a roll is cut, you can deliver paper in the Output Stacker with the ink dried even if **Cutting Mode** is set to **Automatic**.

Setting Item	Details
Printer Default	The setting of the control panel of the printer is applied.
Off	Paper is ejected immediately after printing completes.
30 sec. / 1 min. / 3 min. / 5 min. / 10 min. / 30 min. / 60 min.	Paper is ejected when the set time elapses after printing completes.

C Between Scans

You can set the time to wait after printing 1 line on a page until printing the next line. Set this to avoid bleeding or color unevenness such as when bleeding occurs on a page or when color unevenness occurs during borderless printing.

Setting Item	Details
Printer Default	The setting of the control panel of the printer is applied.
Off	The next line is printed immediately after a line is printed.
1 sec. / 3 sec. / 5 sec. / 7 sec. / 9 sec.	The next line is printed when the set time elapses after a line is printed. * Increase the time according to the occurrence condition of bleeding or unevenness.

155

D Roll Paper Margin for Safety

You can specify the length of a margin on the leading edge of paper to ensure that paper susceptible to curling is held firmly against the Platen.

• ENear End Margin

Specify the length of the Near End Margin (the leading edge margin) of the roll, as needed.

Setting Item	Details
Printer Default	The setting of the control panel of the printer is applied.
3 mm (0.12 in)	The document is printed in the standard size.
	* Select this when you do not have any problems in printing.
20 mm (0.8 in)	Select this when rubbing against the printhead occurs such as when using paper that tends to curl.

F Cut Speed

Select the speed of automatic cutting, as needed. You can adjust this setting if paper is not cut well when automatic cutting is used.


Setting Item	Details
Printer Default	The setting of the control panel of the printer is applied.
High Speed	When the Standard setting does not result in cutting the surface cleanly, select this.
Standard	Select this when you do not have any problems in automatic cutting.
Low Speed	This helps prevent adhesive from sticking to the cutter and keeps the cutter sharp if you select it when using adhesive paper.

G Mirror

Specify whether to print a mirror image, as needed. Select this option to print a version of the document or image with the left and right sides inverted.

View Settings Dialog Box for the Printing Application

In the View Settings dialog box, you can check details of the selected printing application.





• To display the View Settings dialog box, on the Main sheet, click View Settings by Print Target. (See "Main Sheet .") >P.150

A Print Target

Shows all Print Target options (settings items for the printing application).

• B Name


Identifies the item selected in **Print Target** by its name and an icon.

• C Details

Here, you can confirm detailed settings values for each listed item for the selected Print Target.

Color Adjustment Sheet: Color

If the color tone as printed is not as you expected, you can adjust it on the Color Adjustment sheet.





• To display the Color Adjustment sheet, on the Main sheet, click Color Settings by Color Mode in Advanced Settings. (See "Main Sheet .") →P.150

A Sample Type

Choose a sample image from **Standard**, **Portrait**, **Landscape**, or **Graphics**.

B View Color Pattern

Select this checkbox to display the color pattern.

C Apply to Sample

Select this checkbox to apply the changed settings to the sample image.

D Cyan/ E Magenta/ F Yellow

Fine-tune color tones by adjusting the levels of each color.

G Gray Tone

Adjust the color tone of grays as desired. Choose **Cool Black** (tinged with blue) or **Warm Black** (tinged with red).

• H Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

Contrast

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the **Contrast** makes images sharper, and reducing the **Contrast** softens images.

J Saturation

Adjust the color intensity as desired. Increasing the **Saturation** setting makes colors more vivid, and reducing the **Saturation** makes colors more subdued.

KObject Adjustment

Select this option to display the **Object Adjustment** dialog box, in which you can specify objects subject to color adjustment.

Object Adjustment Dialog box: Color →P.157

• S Defaults

Click to restore all settings on the sheet to the default values.



For details on settings items, see "Adjusting the Color in the Printer Driver." →P.48

Object Adjustment Dialog box: Color

In the **Object Adjustment** dialog box, you can specify what type of print jobs to apply color adjustment to. If an original comprises images, graphics, and text, you can specify which portion to apply color adjustment to.





• To display the Object Adjustment dialog box, click Object Adjustment on the Color Adjustment sheet.

• A Image

Select this option to apply color adjustment to image areas, such as photos.

• B Graphics

Select this option to apply color adjustment to graphics, such as lines and circles.

C Text

Select this option to apply color adjustment to text.

Matching Sheet

On the **Matching** sheet, you can specify color matching to compensate for differences in the appearance of colors on various devices.



If No color correction is selected under Color Mode, the Matching sheet is not displayed.




• To display the Matching sheet, on the Main sheet, click Color Settings in Color Mode in Advanced Settings, and then click the Matching sheet. (See "Main Sheet .") →P.150

Matching Sheet iPF685

Driver Matching Mode

The following options are available when you select **Driver Matching Mode** in the A Matching Mode list.



A Matching Mode

Select the color matching mode to use, as desired.

Normally, select **Driver Matching Mode**. For color matching based on ICC profiles, select **ICC Matching Mode** or **Host ICM Mode**, depending on your color matching system.

• B Matching Method

Select the color matching method that suits the document to be printed. Various **Matching Method** options are available depending on your selection in **Matching Mode**.


• E Gamma

You can adjust the gradation of intermediate tones in an image.

2.2 is normally selected. If you want a softer impression than 2.2, select 1.8.

ICC Matching Mode and Host ICM Mode

The following options are available when you select **ICC Matching Mode** or **Host ICM Mode** in the **A Matching Mode** list.



A Matching Mode

Select the color matching mode to use, as desired.

• BInput Profile Settings

You can select Image, Graphics, or Text. You can choose Matching Method and Input Profile.

Various options are available depending on your selected Matching Mode.

To apply the same input profile automatically for **Graphics** and **Text**, select **Use the Same Profile for All Objects**. To apply separate input profiles to **Graphics** and **Text**, clear **Use the Same Profile for All Objects** and specify the individual settings.

C Printer Profile Settings

Specify the printer profile as desired. Normally, select Auto Settings.

We recommend that you select an ICC profile created using commercially available profile creation software in order to perform color management accurately on paper other than genuine Canon paper and feed confirmed paper.

The created ICC profile needs to be saved in the following folder on the computer you are using. C:\Windows\system32\spool\drivers\color folder



• C: may vary according to the user environment.






For details on settings items, see "Adjusting the Color in the Printer Driver." →P.48

Color Adjustment Sheet: Monochrome

On the Color Adjustment sheet for monochrome printing, you can adjust the brightness and contrast.





• To display the Color Adjustment sheet, on the Main sheet, click Color Settings by Color Mode in Advanced Settings. (See "Main Sheet .") →P.150

A Sample Type

Choose a sample image from Standard, Portrait, Landscape, or Graphics.

B View Color Pattern

Select this checkbox to display the color pattern.

C Apply to Sample

Select this checkbox to apply the changed settings to the sample image.

• D Cyan/ E Magenta/ F Yellow

Not available.

G Gray Tone

Not available.

H Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

• | Contrast

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the Contrast makes images sharper, and reducing the Contrast softens images.

J Saturation

Not available.

K Object Adjustment

Select this option to display the **Object Adjustment** dialog box, in which you can specify objects subject to color adjustment.

Object Adjustment Dialog box: Monochrome →P.160

S Defaults

Click to restore all settings on the sheet to the default values.




For details on settings items, see "Adjusting the Color in the Printer Driver." →P.48

Note

Object Adjustment Dialog box: Monochrome

In the Object Adjustment dialog box, you can specify what type of print jobs to apply color adjustment to. If an original comprises images, graphics, and text, you can specify which portion to apply color adjustment to.





To display the Object Adjustment dialog box, click Object Adjustment on the Color Adjustment sheet.

A Image

Select this option to apply color adjustment to image areas, such as photos.

• B Graphics

Select this option to apply color adjustment to graphics, such as lines and circles.


C Text

Select this option to apply color adjustment to text.

Page Setup Sheet

Page Setup Sheet

The following settings are available on the **Page Setup** sheet. For details on settings items, refer to the printer driver help file.




• A Page Size

Select the page size as specified in the source application.

For details on available page sizes, see "Paper Sizes." →P.328

• B Borderless Printing



Borderless printing is available if roll paper is selected in the **L Paper Source** list. Choose from the following options when this setting is activated.

- Borderless Printing on Paper of Equivalent Size →P.79
- Borderless Printing by Resizing Originals to Fit the Roll Width →P.82
- Borderless Printing at Actual Size →P.74

D Fit Paper Size

Scales the document image to match the paper size.

• EScale to fit Roll Paper Width

Scales the document image to match the roll width.

• F Print Image with Actual Size

Prints documents at their actual size. This function is available when you have selected the size same as the width of **Roll Paper** for either the length or width of the document from the **A Page Size** list.

• G Paper Size

Available when **D** Fit Paper Size is selected.

Choose the size of the paper you will print on.

For details on available paper sizes, see "Paper Sizes." →P.328

Paper sizes compatible with borderless printing are shown in the list.

• C Enlarged/Reduced Printing



Choose from the following options when this setting is activated.

- Resizing Originals to Match the Paper Size →P.60
- Resizing Originals to Fit the Roll Width → P.62
- Resizing Originals by Entering a Scaling Value →P.65

D Fit Paper Size

Scales the document image to match the paper size.

• E Fit Roll Paper Width

Scales the document image to match the roll width.

F Scaling

Resizes the document image based on a specified scaling value. Enter a value in a range of 5-600.

G Paper Size

Choose the size of the paper you will print on.

For details on available paper sizes, see "Paper Sizes." →P.328

H Orientation

Choose the printing orientation.

Making the Original Orientation Match the Paper Orientation →P.133

K Rotate Page 90 degrees (Conserve Paper)

Activate this setting to rotate the document image by 90 degrees before printing.

Conserving Roll Paper by Rotating Originals 90 Degrees →P.123

L Paper Source

Choose the feed source, as desired.

Options displayed in the list vary depending on the selection in **Media Type** on the **Main** sheet.


• M Roll Paper Width

Choose the roll width.

For details on available roll widths, see "Paper Sizes." →P.328

• N Roll Paper Options

Complete optional roll paper settings. Click to display the Roll Paper Options dialog box.



162

Under A Automatic Cutting, you can specify Yes or No and Print Cut Guideline.

Cutting Roll Paper After Printing →P.137

Select **B** Banner Printing when printing multiple pages continuously.

Printing Multiple Pages Continuously →P.104

iPF685

Printer Driver

P Output Method

Click to display the **Output Method** dialog box, which enables you to complete the **Output Method** and **Name** of data to be saved settings.

Output Method Dialog box →P.163

O Size Options

Click to display the **Paper Size Options** dialog box, which enables you to register additional paper sizes or select the size system for use.


Paper Size Options Dialog Box →P.164

• S Defaults

Restores all settings on the sheet to the default values.

Output Method Dialog box

The **Output Method** dialog box allows you to select the **Output Method** and set the save settings when saving to the box.





• To display the **Output Method** dialog box, on the **Page Setup** sheet, click **Output Method**. (See "Page Setup Sheet .") →P.161

A Output Method

If **Print** is selected, the print job is saved to the printer hard disk after printing has finished.

If **Save in mail box** is selected, the print job is saved to the printer hard disk. If you choose **Save in mail box**, also specify the destination personal box in the **Mail box** list.

If **Print after reception is complete** is checked, you can prevent degradation of print quality that occurs when receiving a print job is interrupted and printing is aborted in the middle.

These can be selected as **Print** options.

B Name of data to be saved

To use the file name, choose **Use file name**.

Otherwise choose Enter name and enter a name in Name.

• C Mail box


Displays a list of mail boxes. If you choose **Save in mail box**, also specify the destination personal box from the list.

• D Acquire Mail Box Name

When this is clicked, the box name acquired from the printer main unit is displayed in **Mail box**.

Paper Size Options Dialog Box

In the **Paper Size Options** dialog box, you can create and register your own Custom Paper Size. The sizes you define are listed with standard paper sizes for selection later as needed.





You cannot create any arbitrary roll paper width as a Custom Paper Size.

Important • If you select a Paper Size from Paper Size Options, load paper of a size equal to or larger than the Paper Size Options into the printer. If the size of the loaded paper is smaller than the Paper Size Options, an incomplete output image may be printed.



To display the Paper Size Options dialog box, on the Page Setup sheet, click Paper Size Options. (See "Page Setup Sheet .") →P.161

A Paper Size List

Shows the names and sizes of paper that can be used with the printer driver.

B Delete

Custom paper sizes created by users can be deleted from the A Paper Size List, as needed. However, they cannot be deleted in the following situations.

- If a standard paper size of the printer driver is selected.
- If an oversized paper size is selected.
- If a paper size marked with a red circle is selected.

C Custom Paper Size Name

You can name Custom Paper Size as desired.

D Units

Specify the desired unit of measure for the Custom Paper Size height and width.

E Paper Size

Specify the desired Width and Height. You can make your selection from sizes that are compatible with Borderless Printing by selecting Borderless Printing Size. To maintain the aspect ratio of the Width and Height as you resize the paper, select Fix the Ratio of the Width to Height.

Enables you to register the custom paper size you have specified or overwrite an existing custom paper size.


G Display Series

You can limit the number of options shown in Page Size, Paper Size, and Paper Size List.

Layout Sheet

Layout Sheet

The following settings are available on the **Layout** sheet. For details on settings items, refer to the printer driver help.



A Page Layout

Activate this setting to select a particular page layout.

- Printing Multiple Pages Per Sheet →P.108
- Printing Posters in Sections →P.113
- Printing Multiple Originals Next to Each Other →P.101
- Using PosterArtist to Compose Originals →P.38

• B Set

Click to display one of the following dialog boxes depending on the selection in A Page Layout. In these dialog boxes, you can specify layout details and which pages to print, as well as other settings.

- Page Layout Printing
- Pages to Print
- Free Layout Settings

C Watermark

Activating this option makes two settings available, **Watermarks** and **D Edit Watermark**.

- Printing With Watermarks →P.131
- Watermarks

Lists the provided watermarks. Choose the watermark to print.

• D Edit Watermark

Click to display the **Edit Watermark** dialog box for creating your own, original watermark.

• E Print Centered

Activate this setting to print document images in the center of the paper.

- Printing Originals Centered on Rolls →P.115
- Printing Originals Centered on Sheets →P.119

F Rotate 180 degrees

Activate this option to rotate document images by 180 degrees before printing.

• G No Spaces at Top or Bottom (Conserve Paper)

Activate this setting to print the next image skipping blank areas above and below printable data in documents, which enables you to conserve the paper.

Conserving Roll Paper by Printing Originals Without Top and Bottom Margins →P.126

• H Copies

Enter the number of copies to print, in a range of 1-999.

Reverse Order

Page Options Dialog Box iPF685

Activate this option to print pages in reverse order.

Page Options

Click to display the **Page Options** dialog box, which enables you to complete settings for printing the user name, date, or page number in the header or footer.

Page Options Dialog Box →P.166

J Special Settings

If the printing results are not as you expected, click this option to display the **Special Settings** dialog box and change how printing is processed.


Special Settings Dialog Box →P.167

S Defaults

Click to restore all settings on the sheet to the default values.

Page Options Dialog Box

The Page Options dialog box offers the following settings.



Note

• To display the Page Options dialog box, on the Layout sheet, click Page Options. (See "Layout Sheet .") →P.165

A Print Date

Select where the date is printed, as desired. To print the time as well, select **B Print Time Also**.

• C Print User Name


Select where the user name is printed, as desired.

D Print Page Number

Select where the page number is printed, as desired.

• E Format Settings

Click to display the Format Settings dialog box, which enables you to complete format-related settings.



Printer Driver

Windows Software

Special Settings Dialog Box




• If you specify the same position for multiple items, the items are printed from left to right in this order: date, user name, and page number.

 When you print multiple pages per sheet using Page Layout Printing or similar functions, these items will be printed for each page.

Special Settings Dialog Box

If the printing results are not as you expected, you can change how printing is processed in the **Special Settings** dialog box.





- To display the **Special Settings** dialog box, on the **Layout** sheet, click **Special Settings**. (See "Layout Sheet .") →P.165
- Click the processing method for Parameter within the Settings Summaries frame to display a list of the setting
 details under the frame.

A Spooling at Printer Driver

Sets whether or not print jobs are spooled in the printer driver and processed by PageComposer. Printing results may be improved in some cases by setting this to **No** or **No** (**EMF Spooling**).



When set to No or No (EMF Spooling), functions such as Page Layout, Watermark, Reverse Order, Page
Options, FineZoom Settings, and Preview Switchingcan no longer be used.

B FineZoom Settings

This function is used in large-format printing.

If it is set to **Yes**, problems in the printing may be improved.

If it is set to **No**, image distortions such as fine lines disappearing may be improved.

C Preview Switching

When this setting is turned on, PageComposer starts when printing is performed with the **Open Preview When Print Job Starts** check box selected in the **Main** sheet.

D Application Color Matching Priority

When this is on, you can give applications priority in color management.

• E Fast Graphic Process

Turning this setting on may help produce the expected results if image colors are inconsistent in printed documents or if lines are printed in varying thicknesses.



This function cannot be used on 64-bit version of Windows.

• F Reduce Print Unevenness

If you want to reduce unevenness of the printed image, turn this on to improve the print result. However, printing may take longer for some images.


Favorites Sheet iPF685

G Adjust faint lines

Turn this off to obtain expected results when fine lines have been printed in a color different from other diagrams and illustrations. However, lines in some colors may appear broken.

Favorites Sheet

The following settings are available on the **Favorites** sheet. For details on settings items, refer to the printer driver help.



A Favorites

Printing favorites you have created are listed with **Default Settings** favorites.

Using Favorites →P.137

B Settings Details

Displays details of the favorite selected in the A Favorites.

• C Comment

Displays notes registered in the favorite.

D Apply Favorite

Click to change the current print settings to those of the favorite selected in the A Favorites.

E Application Settings Priority

Activate this setting to use settings values specified in the source application in preference to favorite settings selected in the **A Favorites**, when clicking **D Apply Favorite**. For details on the settings items used in preference, refer to the printer driver help.

• F Delete


Click to delete the selected favorite from the A Favorites list.

G Edit

Click to display the **Edit** dialog box, which enables you to change the name and icon for the favorite selected in the **A Favorites** list.

• HAdd

Click to display the Add dialog box, which enables you to add the current print settings as a favorite.



• Import

Click to display the Open dialog box, which enables you to import favorite settings saved as a file.

J Export

Click to display the Save As dialog box, which enables you to save the favorite settings as a file.

• KUp


Click to move the selected favorite up in the A Favorites list.

• L Down

Click to move the selected favorite down in the A Favorites list.

Utility Sheet

The following items can be executed on the **Utility** sheet. For details on the utilities, refer to the relevant utility help.



A Maintenance

Click to start the imagePROGRAF Status Monitor, which offers the following maintenance for the printer.

- Nozzle (ink ejecting outlet) check
- Nozzle (ink ejecting outlet) cleaning
- Head alignment adjustment
- · Feed amount adjustment

B Color imageRUNNER Enlargement Copy

Click to launch **Color imageRUNNER Enlargement Copy** (iR enlargement copy), which enables you to create hot folders used for **Color imageRUNNER Enlargement Copy** and assign print settings to hot folders.

Printing Enlargements of Scanned Originals from a Color imageRUNNER →P.211

For details, see "Color imageRUNNER Enlargement Copy." →P.203


Support Sheet iPF685



Color imageRUNNER Enlargement Copy is not displayed in 64-bit editions of Windows.

Support Sheet

On the **Support** sheet, you can view support information and the user's manual.



A Support Information

Click to access the Canon support webpage, where you can find the latest information on the printer and consumables, check for printer driver updates, and browse other information.

B User Manual


Click to connect to the Internet and display the printer user's manual.

C Settings Summaries

Click to display the **View Settings** dialog box, which enables you to confirm the settings for the **Main**, **Page Setup**, **Layout**, and **Favorites** sheets.

Settings Summaries Dialog Box

The **Settings Summaries** dialog box enables you to confirm the settings for the **Main**, **Page Setup**, **Layout**, and **Favorites** sheets.



• A Copy

170


Click to copy the settings information to the clipboard. You can paste the settings information into a file created with a text editor or similar application.

Device Settings Sheet

Device Settings Sheet


Many settings items on the printer properties sheets are controlled by Windows applications. However, the **Device Settings** sheet is for configuring the printer, and it is an extension of the printer driver.

The following settings are available on the **Device Settings** sheet.



• A Color Compatibility

Click to display the **Color Compatibility** dialog box, which enables you to adjust colors if you have selected **Color Mode** > **Color (CAD)**.



- For details on color settings, see "Specifying Colors and Printing CAD Drawings." →P.45
- B About

You can display version information for the printer driver.

The Features of Preview iPF685

Preview

The Features of Preview	
Starting Preview	172
Preview Main Window	173
Dialog Area	175
Enlarge/Reduce the screen display	176
Moving a Page	176
Using the ruler	176
Priority setting for rotating 90 degrees	177
Printing with Selecting the Layout	178
Print on the Center	180
Not Print Spaces at the Top/Bottom	181

The Features of Preview

The main features of Preview are as follows.

- While viewing this screen, you can adjust layout settings of a document created with application software.
- You can not only adjust layout settings but also your changes will be instantly applied on the preview screen, and you can print the preview screen as it is seen.



 The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Preview settings.

Starting Preview


Follow the procedure below to start the Preview.

- Start the apllication software which you use.
- From the application software's File menu, select the printer setup menu to open the Print dialog box.



• Normally, select **Print** from the **File** menu.

On the Main sheet, click on the Open Preview When Print Job Starts check box. Click the **OK** button to save the settings.







Note

Your printer is depicted in the lower-left area of this screen.


On the **Print** dialog box in the apllication software, click the **Print** button.





Preview Main Window

The Preview main window consists of the menu and tool bars, preview and dialog area and status bar.





• You can use the **View** menu to show or hide the tool bar.

Menu Bar

This allows you to select menus required for operations.




Tool Bar

This allows you to select tool buttons required for major operations.



Preview Area


You can check the settings you made in this area.



Dialog Area

This allows you to set the print conditions and perform a print job.

For more information about Dialog Area, see "Dialog Area." →P.175



Status Bar

This shows the message, Pages and Output Size.


Rotating images 90 degrees can conserve paper. Pages : 1/1 Output Size : 11.7in × 16.5in

Dialog Area

175

Dialog Area

You can select the layout and print on the center.



Media Type/Paper Source/Paper Size

You can confirm the information that is set.

Layout Selection

You can print which conserves paper by selecting the layout.

For more information about Layout Selection, see "Printing with Selecting the Layout." →P.178

Center Originals Across Roll

You can print on the center of the media loaded in the printer.

For more information about Center Originals Across Roll, see "Print on the Center." →P.180



Available only if rolls are selected in Paper Source.

No Spaces at Top or Bottom

You can save paper on not to feed roll paper for the empty spaces when the print data contains spaces at the top or bottom.

For more information about No Spaces at Top or Bottom, see "Not Print Spaces at the Top/Bottom." >P.181



Available only if rolls are selected in Paper Source.

• Print Button

Click the button to start printing.

Cancel Button

Click the button to stop printing.

Printer Information

You can confirm the information acquired from the printer.

176

• Update Printer Information Button

Click the button to update the printer information with connecting to the printer.

• Status Monitor Button

Click the button to start Status Monitor.

Enlarge/Reduce the screen display

You can enlarge or reduce the screen display when you select **Zoom** from the **View** menu.

Setting	Details
Fit Screen	Display all.
Fit to Width	Display to the width of the paper.
Reduce	Display at half of the standard size.
Standard	Display at the standard size.
Enlarge	Display with the double of the standard size.
Enlarge More	Display with the triple of the standard size.



This item can be selected even if you have clicked the ▼ button in the toolbar Zoom.

Moving a Page

You can move a page to display when you select **Go to Page** from the **View** menu.

Setting	Details
First Page	Go to the first page.
Previous Page	Go to the previous page.
Next Page	Go to the next page.
Last Page	Go to the last page.
Go To Page	Go to the specified page.



You can also move a page by clicking



on the tool har

Using the ruler


You can confirm the layout with using the ruler.

- Switching the ruler Show/Hide
 In the View menu, select Ruler to switch the ruler Show/Hide.
- Changing the ruler unit
 You can set the ruler unit when you select Units from the View menu.

Setting	Details
mm	Use mm as the ruler unit.
inch	Use inches as the ruler unit.


Priority setting for rotating 90 degrees

You can select Rotate 90 Degrees If Possible or Use Driver Settings from the Options menu.




Setting	Details
Rotate 90 Degrees If Possible	Rotates pages in portrait orientation 90 degrees before printing. Pages are only rotated if they can fit lengthwise across the roll.
Use Driver Settings	Follows printer driver settings when determining whether to rotate pages.

Selecting Rotate 90 Degrees If Possible or Placing a checkmark for Rotate Page 90 degrees (Conserve Paper) on the printer driver



Selecting Use Driver Settings



You can print which conserves paper by selecting the layout.


1 In Layout Selection, click the layout button to use.



Button	Details
Upper Button	Turn at the position of
Right Button	Turn at the position of
Left Button	Turn at the position of
Lower Button	Turn at the position of



- Right Button or Left Button can be selected only when the rotated pages can fit lengthwise across the roll.
- By clicking **Right Button** or **Left Button**, you can save paper by printing in landscape orientation on roll paper.
- You can select only Upper Button or Lower Button if Cut Sheet is selected.



Button	Details
R	The button is selected currently.
R	The button can be selected.
R	The button can not be selected.

2 Click the **Print** button.

Printing on the selected layout begins.

Print on the Center

You can print on the center of the media loaded in the printer.

1 Click the Center Originals Across Roll check box on.



2 Click the **Print** button.

Printing on the center begins.




• Available only if rolls are selected in Paper Source.

Not Print Spaces at the Top/Bottom

You can save paper on not to feed roll paper for the empty spaces when the print data contains spaces at the top or bottom.

1 Click the No Spaces at Top or Bottom check box on.



2 Click the **Print** button.

Printing on the settings with no spaces at top or bottom begins.


Free Layout

The Features of Free Layout	182
Starting Free Layout	182
Free Layout Main Window	184
Detailed Settings	
Preferences Dialog Box	
Page Options Dialog Box	
Zoom Dialog Box	
Format Dialog Box	188
Laying out a Multiple-File Document on One Page	
Laying out a Document Created with Multiple Application Programs on One Page	
Selecting an Object	
Changing the Object Size	
Moving an Object	
Rotating an Object	
Laying out Objects Automatically	
Aligning Objects	
Changing the Object Overlapping Order	
Pasting a Copied or Cut Object	198
Folded Dupley Window	100
Folded Duplex Window	
Finished Size Settings Dialog Box	
Binding Settings Dialog Box	
Prints using Folded Duplex	201

The Features of Free Layout

The main features of Free Layout are as follows.

- Allows you to lay out at will and print a document created with application software.
- You can not only lay out multiple pages on one page but also lay out and print a multiple-file document on one page, or lay out and print a document created with multiple application programs on one page.
- Any two pages can be arranged and printed in a layout that becomes duplex on folding.
 This can be used such as for advertising posters that are suspended from the ceiling.





182

 The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Free Layout settings.

Starting Free Layout

Follow the procedure below to start the Free Layout.

1 Start the apllication software which you use.

From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



• Normally, select **Print** from the **File** menu.

From the list, select the printer and select the **Layout** sheet.





- Your printer is depicted in the lower-left area of this screen.
- In the **Layout** sheet, click on the **Page Layout** check box and select Free Layout from the list. Click the **OK** button to save the settings.




- When you select Free Layout, all other setting items will be disabled.
- On the **Print** dialog box in the apllication software, click the **Print** button.

 Free Layout main window is displayed.



Free Layout Main Window

The Free Layout main window consists of the menu and tool bars, layout area and status bar.






• You can use the View menu to show or hide the tool and status bar.

Menu Bar

This allows you to select menus required for operations.




Tool Bar

This allows you to select tool buttons required for major operations.



Layout Area


This allows you to lay out objects and edit the object size and orientation.



iPF685 Detailed Settings


Status Bar

This shows the paper size, unit of length, and number of objects.



Detailed Settings

The printer driver opens when you select **Detailed Settings** from the **File** menu. The printer driver is used to configure basic settings to match the type of media loaded in the printer.




Refer to "Printer Driver" >P.142) for details on the printer driver.



When you select the **Detailed Settings**, the only three sheets displayed are the **Main** sheet, the **Page Setup** sheet, and the**Layout** sheet. Some of the printer driver settings may be disabled.

Preferences Dialog Box

This dialog box appears when you select **Preferences** from the **File** menu. This allows you to configure the preferences of Free Layout.



Units

Set the unit for paper length, margins, and so on.

Gridlines

You can input a grid line width value in numerical characters so that they serve as a guide to laying out objects.

185



You can input between 10.0 and 200.0(mm) (between 0.39 and 7.88(inch)).

You can change the numbers by clicking either ▲ button or ▼ button.

Divisions

You can change the number of divisions of grid lines so that they serve as a guide to laying out objects.



- You can input between 1 and 10.
- You can change the numbers by clicking either ▲ button or ▼ button.

Grid Color

Select the grid line color.

Auto Arrange Spacing

Change the object-to-object spacing to be applied in the operation of laying out objects automatically.



- You can input between 0.0 and 100.0(mm) (between 0.00 and 3.94(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Object Frame Style

You can select the object frame style for printing.

The following settings are available for the object frame style.

Setting	Details
None	You can print with no frame style.
Solid Line	You can print the solid line as the frame style.
Dotted Line	You can print the dotted line as the frame style.
Dashed Line	You can print the dashed line as the frame style.
Crop Marks	You can print with the crop marks.

Page Options Dialog Box

This dialog box appears when you select **Page Options** from the **File** menu. This allows you to configure the roll paper length, object layout order, and margins of Free Layout.



186

Roll Paper Length

Set the length of one page to print on roll paper.

The following settings are available for roll paper length.

•	
Setting	Details
Auto Settings	The one-page length to be printed on roll paper is automatically set so that the laid-out objects are printed on one page.
Manual Settings	You can input the length of one page to print on roll paper in numerical characters.



- Available only if rolls are selected in **Paper Source**.
- You can input between 203.2 and 18000.0(mm) (between 8.00 and 708.66(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Order

Set the object layout order.

The following settings are available for order.

Setting	Details
Upper Left to Right	The objects are laid out from upper left to right.
Upper Left to Bottom	The objects are laid out from upper left to bottom.
Upper Right to Left	The objects are laid out from upper right to left.
Lower Left to Top	The objects are laid out from lower left to top.



- When you have selected Roll Paper Length > Auto Settings and Paper Orientation > Vertical, you can choose Upper Left to Right or Upper Right to Left.
- When you have selected **Roll Paper Length > Auto Settings** and **Paper Orientation > Horizontal**, you can choose **Upper Left to Bottom** or **Lower Left to Top**.

Margins


You can input the paper margins in numerical characters.



- You can input between 0.0 and 50.0(mm) (between 0.00 and 1.97(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Zoom Dialog Box

This dialog box appears when you select **Zoom** from the **View** menu. You can enlarge or reduce the screen display.



Scaling

Set the magnification for enlargement or reduction of the screen display.




- You can input between 25 and 400.
- You can change the numbers by clicking ▼ button.

Format Dialog Box

This dialog box appears when you select Format from the Object menu after you select an object.

Size Sheet

You can rotate, enlarge, or reduce an object.





When the objects are not selected, you can not select Format.

Rotate

When you place a checkmark here, you can select Rotate Right or Rotate Left.

Setting	Details
Rotate Right	Rotates the object 90 degrees clockwise.
Rotate Left	Rotates the object 90 degrees counterclockwise.



• When several objects are selected, you cannot select **Rotate**.

• Enl./Red.

When you place a checkmark here, you can select Scaling, Fit Paper Size, or Fit Photo Size.


Setting	Details
Scaling	Allows you to input the value of the enlargement or reduction ratio of an object.
Fit Paper Size	Prints by enlarging or reducing each object to match the paper size. If you are using roll paper, objects are enlarged or reduced so that the width of each object matches the width of the roll paper.
Fit Photo Size	Prints all of the objects at the specified photo size.



- You can input between 25 and 600.
- You can change the numbers by clicking either ▲ button or ▼ button.

Position Sheet

You can rotate, enlarge, or reduce an object.





• When the objects are not selected, you can not select Format.

Object Position

You can move the object position by changing the values.

Setting	Details
Vertical Pos	You can input the number of the vertical position in numerical characters.
Horizontal Pos	You can input the number of the horizontal position in numerical characters.
Page Pos	You can input the number of the page position in numerical characters.

Object Size

You can confirm the object size.



• When several objects are selected, you cannot display **Object Size**.

Laying out a Multiple-File Document on One Page


You can lay out and print a multiple-file document on one page.

From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



• Normally, select **Print** from the **File** menu.

Click Properties to open the Properties dialog box.




In the Page Setup sheet, select Paper Source.






- Your printer is depicted in the lower-left area of this screen.
- In the Layout sheet, click on the Page Layout check box and select Free Layout from the list.




190

- Your printer is depicted in the lower-left area of this screen.
- When you select Free Layout, all other setting items will be disabled.
- 5 Click the **OK** button to save the settings.

In the **Print** dialog box, select the pages to print and the number of copies, and click the **OK** button.



Free Layout starts, laying out the document created with application software in the layout area as an object.



7 Leaving Free Layout running, open other files with the application software and repeat the above steps.

Laying out a Document Created with Multiple Application Programs on One Page


You can lay out and print a document created with multiple application programs on one page.

1 From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



• Normally, select **Print** from the **File** menu.

Click Properties to open the Properties dialog box.




3 In the Page Setup sheet, select Paper Source.





- Your printer is depicted in the lower-left area of this screen.
- In the Layout sheet, click on the Page Layout check box and select Free Layout from the list.






192

- Your printer is depicted in the lower-left area of this screen.
- When you select Free Layout, all other setting items will be disabled.
- 5 Click the **OK** button to save the settings.

In the **Print** dialog box, select the pages to print and the number of copies, and click the **OK** button.



Free Layout starts, laying out the document created with application software in the layout area as an object.



T Leaving Free Layout running, open other files with other application software and repeat the above steps.

Selecting an Object

When an object is selected, a select box (blue border) appears around the object.






· To select an object, click that object.

To select multiple successive objects, click them while holding down the Shift key.

- To select multiple arbitrary objects, click them while holding down the Ctrl key.
- To select all objects, select **Select All** from the **Edit** menu.
- When you specify the area with dragging the mouse, the object in the area is selected.



Changing the Object Size


You can change the object size by means of mouse operation or by specifying a scaling value.



• The vertical-to-horizontal ratio remains unchanged when the object is enlarged or reduced.

Resizing by means of mouse operation

- 1 Select an object.
- Place the pointer at a corner of the selection box around the object to show the arrow handle, and drag this handle to change the object size.



Resizing by specifying a scaling value

- Select an object.
 Click on the Enl./Red. checkbox in the Format Dialog Box →P.188 and select Scaling.
- 2 You either enter numbers directly.



- You can input between 25 and 600.
- You can change the numbers by clicking either ▲ button or ▼ button.

194

3 Click the **OK** button.

Moving an Object

You can move the object position.


1 Select an object.

195

Rotating an Object

Place the pointer inside the selection box of the object to show the crosshair handle, and drag it to move

Alternatively, you can move the **Object Position** by changing the values in Vertical Pos, Horizontal Pos and Page Pos in the Format Dialog Box →P.188 .




Rotating an Object

You can rotate the object.


- Select an object.
- **Degrees** from the toolbar. Alternatively, you may click on the **Rotate** check box in the Format Dialog Box →P.188 then select Rotate Right or Rotate Left, and click the OK button.

Select Rotate Left 90 Degrees orRotate Right 90



Laying out Objects Automatically

Click Auto Arrange Object in the tool bar. This automatically lays out objects. Alternatively, you may select Auto Arrange Object from the Object menu.





• The object layout order varies depending on the **Order** setting in the **Page Options Dialog Box** >P.186 dialog box.

Aligning Objects

You can align objects systematically.

Select multiple objects.


2

Click the align button from the toolbar.

Alternatively, you may select the align menu from the **Object** menu.


Align Top

Lays out the objects, justifying them to the top.




Center Vertically

Lays out the objects, justifying them to the vertical center.




Align Bottom

Lays out the objects, justifying them to the bottom.




Align Left

Lays out the objects, justifying them to the left.




Center Horizontally

Lays out the objects, justifying them to the horizontal center



Align Right

Lays out the objects, justifying them to the right.



Changing the Object Overlapping Order

You can change the object overlapping order.


- 1 Select an object.
- 2 Select the Overlapping Order menu from the **Object** menu.



- The order of overlapping affects the order of objects automatically laid out.
- You can also select by clicking the right button of the mouse on an object.


Bring to Front

Moves the object to the frontmost position.




Send to Back

Moves the object to the backmost position.




Bring Forward

Moves the object one position to the front.



Send Backward

Moves the object one position to the back.



Pasting a Copied or Cut Object

- Click Copy or Cut from the toolbar.

 Alternatively, you may select Copy or Cut from the Edit menu.
- Click **Paste** from the toolbar.

 Alternatively, you may select **Paste** from the **Edit** menu.



- The copied or cut object is laid out at the end of the page.
- You can also select by clicking the right button of the mouse on an object.
- In order to paste an object on any position that you like, you can paste the object with **Pointed Paste** by clicking the right button of the mouse on any position that you want.

iPF685 Folded Duplex Window

Folded Duplex Window

This window is displayed if you select Folded Duplex from the Edit menu after selecting an object. Using the Fol**ded Duplex** function allows you to print with fold lines added.

The Folded Duplex window consists of the menu and tool bars, layout area and status bar.





• The toolbar and status bar can be toggled between hidden and displayed from the View menu.

Menu Bar

This allows you to select menus required for operations.



Tool Bar

This allows you to select tool buttons required for major operations.




Layout Area

This allows you to check the arrangement and orientation of objects.




Status Bar

This shows the paper source, roll paper width, and output size.



Finished Size Settings Dialog Box

This dialog box is displayed when you select **Finished Size Settings** from the **Edit** menu. This allows you to configure finished size settings.



Finished Size

Selects the method for setting the finished size.

The following settings are available for the finished size.


Setting	Details
Fit Roll Paper Width	Prints by automatically enlarging or reducing the entire document so that the width of the document matches the roll paper width.
Specify Folded Size	Prints by automatically enlarging or reducing the entire document to match the size of the paper. Select the actual size of the paper you want to print on in Fit Paper Size .
Rotate Page 90 degrees (Conserve Paper)	Prints by rotating pages by 90 degrees. Pages are automatically rotated if they will fit within the roll paper width when rotated, and are not rotated if they will not fit within the roll paper width.

Binding Settings Dialog Box

201

Binding Settings Dialog Box

This is displayed when you select **Binding Settings** from the **Edit** menu. This allows you to configure the binding edge settings.



Binding Edge

Configures the binding edge when folding paper.

The following settings are available for the binding edge.

Setting	Details
Bottom	Prints by placing the binding margin (gutter) at the bottom of the document.
Тор	Prints by placing the binding margin (gutter) at the top of the document.

Binding

Configures the binding margin (gutter).

Prints by creating a binding margin (gutter) of the specified size. Enter the margin size as a number.



The values that can be entered are 0 to 50 (mm).

Print Fold Lines

Configures the color and type of fold lines.



To not print fold lines, clear the Print Fold Lines checkbox.

Fold Line Color

You can select the fold lines.

Fold Line Type

You can select the fold lines.

The following settings are available for the fold line type.

Setting	Details
Solid Line	You can print the solid line as the frame style.
Dotted Line	You can print the dotted line as the frame style.
Dashed Line	You can print the dashed line as the frame style.

Only Print Center and Edges

To print fold lines at the center and both edges, select the Only Print Center and Edges checkbox.

Prints using Folded Duplex

This prints 2 pages consecutively. Folding back the paper at the fold lines of the center substitutes for duplex printing.

1

Select two objects from the layout area of Free Layout.

- Select Folded Duplex from the Edit menu of Free Layout.

 Open the Folded Duplex window and arrange the selected objects in the layout area.
- 3 Open the Finished Size Settings dialog box from the Edit menu.
- 4 Select Fit Roll Paper Width or Specify Folded Size in Finished Size.



- Rotate Page 90 degrees (Conserve Paper) is also available when Specify Folded Size is selected.
- 5 Click **OK** to save the settings.
- 6 Open the **Binding Settings** dialog box from the **Edit** menu.
- 7 Select Bottom or Top in Binding Edge.
- 8 Specify the **Binding** width in **Binding**.
- Oonfigure the Fold Line Color and Fold Line Type from Print Fold Lines.



- When the **Only Print Center and Edges** checkbox is selected, fold lines are only printed at the three locations of the center and both edges.
- 10 Click **OK** to save the settings.
- 11 Confirm the print setting and begin printing.

Color imageRUNNER Enlargement Copy

The Features of Color imageRUNNER Enlargement Copy	
Color imageRUNNER Enlargement Copy Dialog Box	204
Hot Folder	205
Setting the Print Parameters	

The Features of Color imageRUNNER Enlargement Copy

The main features of Color imageRUNNER Enlargement Copy are as follows.

- Allows the document scanned with the Color imageRUNNER to be automatically enlarged and printed.
- You can perform basic printer settings such as printer selection, media type and output profile selection, and matching methods, in addition to borderless printing and enlargement/reduction process without growing through the printer driver.



 The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Color imageRUNNER Enlargement Copy settings.

Starting Color imageRUNNER Enlargement Copy


Follow the procedure below to start the Color imageRUNNER Enlargement Copy.

To start by selecting Printers and Faxes from the start button


- Open the folder of the OS you are using for configuring printers.

 For example, on Windows XP click the **start** button on the desktop, and then select **Printers and Faxes**.
- Right-click the Printers icon and select Printing Preferences to open the Printing Preferences dialog box.

In the **Utility** sheet, click the **Color imageRUNNER Enlargement Copy** button.



The Color imageRUNNER Enlargement Copy dialog box displays.






 If you click on the Add to Startup folder check box in the Color imageRUNNER Enlargement Copy dialog box, the icon of Color imageRUNNER Enlargement Copy utility will appear on the task bar when starting Windows thereafter.

To start by selecting Color imageRUNNER Enlargement Copy from the start button

From the Windows start button, select Color image-RUNNER Enlargement Copy.




The Color imageRUNNER Enlargement Copy dialog box displays.



Color imageRUNNER Enlargement Copy Dialog Box

The explanation below is on the Color imageRUNNER Enlargement Copy dialog box.





204

iPF685 Hot Folder

Hot Folder

The hot folder list appears.

Add Button

Click the button to open the Easy Setup Wizard dialog box so that you can add a hot folder.

Edit Button

From the **Hot Folder** list, select a hot folder and click the button to open the **Add/Edit Hot Folder** dialog box that allows you to edit the hot folder.

• Delete Button

From the Hot Folder list, select a hot folder and click the button to delete the hot folder.

Start Button

Clicking the button changes the status of the selected inactive Hot Folder to active.

• Stop Button

Clicking the button changes the status of the selected active Hot Folder to inactive.

Add to Startup folder

Register the application in the Windows startup menu.

Save Printed Data

Automatically saves printed data.

About Button

Click the button to display the name and the version number of the utility.

• Operation Guide Button

Click the button to display the Color imageRUNNER Enlargement Copy Setup Manual.

Hot Folder

Hot folder refers to a folder used for Color imageRUNNER Enlargement Copy.


- When transferred to the PC's hot folder, the document data scanned with the Color imageRUNNER is printed in enlarged size from the printer according to the print conditions set in the hot folder.
- You can create a new hot folder, edit or delete an existing one, and set print conditions at will.



You can create up to 20 hot folders.

Creating a New Hot Folder

Open the Color imageRUNNER Enlargement Copy dialog box, and then click the Add button.




205



For the step to open the Color imageRUNNER Enlargement Copy dialog box, see "Starting Color imageRUNNER Enlargement Copy." →P.203

The Easy Setup Wizard dialog box displays. Click the Next button.



3 Select the type of printer to use. Click the **Next** button.




4 Select the media type to print.




• If the **Borderless Printing** checkbox is checked, only media types that can be used for borderless printing are displayed in the list.


Click the Next button.



Select roll paper or cut sheet to print. Also, select the media size to print.
Click the **Next** button.




Select the color matching method.
Click the **Next** button.



7 To receive a document scanned with the Color imageRUNNER, you need to share a folder. Enter the folder shared name in Shared Name. Click the Next button.




- This shared name is used as the name of the hot folder.
- You cannot use the Back button, after clicking the Next button here.




207

8

Click **Finish** button to close the **Easy Setup Wizard** dialog box.




The hot folder you have created appears in the **Hot Folder** list in the **Color imageRUNNER Enlargement Copy** dialog box.



Specifying an Existing Shared Folder as a Hot Folder


- 1 Share the folder you want to specify as a hot folder.
- Open the Color imageRUNNER Enlargement Copy dialog box, and then click the Add button.






• For the step to open the Color imageRUNNER Enlargement Copy dialog box, see "Starting Color imageRUNNER Enlargement Copy."
• P.203

The Easy Setup Wizard dialog box displays. Click the Manual Settings button.



The Add/Edit Hot Folder dialog box displays.
Enter the hot folder name in Name.
Click the Browse botton, with selecting Specify a folder, to set the existing shared folder.




The location of the folders will appear.
Select the folder to specify a hot folder, and click the **OK** button.






As necessary, set the print conditions in the hot folder. (See "Setting the Print Parameters.") P.210 Click the **OK** button to close the **Add/Edit Hot Folder** dialog box.




The hot folder you have created appears in the **Hot Folder** list in the **Color imageRUNNER Enlargement Copy** dialog box.



Setting the Print Parameters

The printer driver opens when you click the **Properties** button in the **Add/Edit Hot Folder** dialog box. The printer driver is used to configure basic settings to match the type of media loaded in the printer.



Refer to "Printer Driver" >P.142 for details on the printer driver.



• The only three sheets displayed are the **Main** sheet, the **Page Setup** sheet, and the **Layout** sheet. Some of the printer driver settings may be disabled.

Apply Sharpness

Place a checkmark here to set the sharpness.

Drag the slider bar to the left or right to adjust. You can also adjust by directly entering a number in the numeric input field.



- You can input between 0 and 500.
- You can change the numbers by clicking either ▲ button or ▼ button.
 - You cannot be applied to PDF files.

Printing Enlargements of Scanned Originals from a Color imageRUNNER

Scanned originals from a Color imageRUNNER can be enlarged and printed automatically.

Originals you create by scanning with a Color imageRUNNER are transferred to a "hot folder" and printed automatically after enlargement according to printing conditions you specify for that folder.

This processing sequence is called the **Color imageRUNNER Enlargement Copy** function.

To use Color imageRUNNER Enlargement Copy, first complete these settings in the following order.

- 1. Register a hot folder on your computer.

 Register a hot folder on your computer for storing scanned originals from the Color imageRUNNER and complete the settings for enlargement copy. For details, see "Creating a New Hot Folder." >P.205
- Complete the scanning settings on the Color imageRUNNER. Configure the Color imageRUNNER to send scanned originals to the hot folder.

After these settings are complete, you can print enlarged copies of scanned originals from the Color imageRUNNER.

Completing the scanning settings on the Color imageRUNNER.

Configure the Color imageRUNNER to send scanned originals to the hot folder. It is easy to send scanned originals to the hot folder if you assign the scanning settings and destination to a **Favorites** button on the Color imageRUNNER.

For instructions on assigning scanning settings and destinations to a **Favorites** button, refer to the setting manual, displayed by clicking **Color imageRUNNER Enlargement Copy Setup Manual** button of **Color imageRUNNER Enlargement Copy** utility, or refer to the Color imageRUNNER manual.

Scanning the original and print an enlargement

Follow the steps below to scan an original on the Color imageRUNNER for enlarged printing on the printer. For detailed instructions, refer to the Color imageRUNNER manual.

- 1 Load the original on the platen glass or document feeder of the Color imageRUNNER.
- 2 Press **Send** to display the screen for transmission.
- Press Favorites, and then press the Favorites button assigned to the hot folder.
- Press **Start** on the control panel. If you scan originals on the platen glass, after scanning all originals, press **Done** on the touch-panel display.

Scanned originals are sent to the hot folder and automatically enlarged and printed following the conditions you specified for the folder.

Print Plug-In for Office

Print Plug-In for Officefeatures Steps to install Steps to uninstall When Print Plug-In for Office is not displayed	215
To start from Microsoft Word Print Matching Roll Width(Word) Borderless Printing(Word) Multi-Page Printing(Word) Register the settings (Word) Print Using Registered Settings(Word) Portrait Orientation/Landscape Orientation(Word)	
To start from Microsoft PowerPoint	231 232 234 236 237
To start from Microsoft Excel Print Entire Sheet(Excel) Print Selected Area(Excel) Configuring Binding (Excel)	241 243 246
Configuring Special Settings	247

Print Plug-In for Officefeatures

Print Plug-In for Office is a Plug-In that enables easy printing from Microsoft Office.

- It is displayed on the toolbar/ribbon, so it is easily accessible.
- It can be set by just selecting from the Wizard.
- Large-Format Printing custom size can also be set in the Wizard from Microsoft Word or Microsoft Power-Point.
- Custom size can be set automatically from Microsoft Excel.
 - The layout can be checked before printing by starting the preview screen.



64 bit edition Windows OS operates only on WOW64 (32 bit emulator).



- The Print Plug-In for Office toolbar/ribbon might not be displayed in Microsoft Office after installing image-PROGRAF Print Plug-In for Office. For details, refer to "When Print Plug-In for Office is not displayed" >P.215 .
- If you opened the Office document from Internet Explorer, the software will not run correctly.
- If you are editing an embedded object or link object, the software will not run correctly.
- If you added the imagePROGRAF Print Plug-In ribbon to the Microsoft Office Quick Access toolbar, the software will not run correctly.

Steps to install

Below are the steps to install Print Plug-In for Office.



212

• You must log into Windows as an Administrator before the installation.

Note

1 Insert "User Software CD-ROM" into the CD-ROM drive and start the installer.




• If the installer screen does not appear automatically, open the CD-ROM drive icon of your computer and double-click the **iPFInst.exe** icon.

2 Click the imagePROGRAF Print Plug-In button.



Click the **Next**button.



Read the License Agreement, and click the Yes but-



5

Click the Start button.




6 Click the Yes button.






 The following message may be displayed in Windows 8 or a later OS. If this happens, install the .NET Framework by following the procedure.



7 Click the **Exit** button.

The installation for **Print Plug-In for Office** is complete.



214



- When you install this software, the virtual printer Canon imagePROGRAF PrintPlugIn may be installed. If you
 want to use this software, do not uninstall the virtual printer Canon imagePROGRAF PrintPlugIn.
- The Print Plug-In for Office toolbar/ribbon might not be displayed in Microsoft Office after installing image-PROGRAF Print Plug-In for Office.


Refer to the following topic for details on how to display the **imagePROGRAF Print Plug-In for Office** toolbar/ribbon.

When Print Plug-In for Office is not displayed →P.215

Steps to uninstall

Below are the steps to uninstall Print Plug-In for Office.

- 1 If Microsoft Office is open, close it.
- Select Control Panel from the start menu.
- Open Add or Remove Programs.
- 4 Select imagePROGRAF Print Plug-In, and click the Remove button.





You cannot uninstall Print Plug-In for Office if an Office application is running. When a message appears, select
 Cancel and close all Office applications that are running.

When Print Plug-In for Office is not displayed

Buttons such as **Start imagePROGRAF Print Plug-In** sometimes do not appear in the **Word**, **PowerPoint** and **Excel** Office applications, and the **Print Plug-In for Office** functions are not available.

In this event, re-install **Print Plug-In for Office**.

If you are using **Microsoft Office 2003** or later, you can also enable add-ins to display **Print Plug-In for Office**. See below for the procedure for re-installing the plug-in or enabling add-ins.

Re-installing Print Plug-In for Office

If a problem occurs, such as the system or an application terminating abnormally, the **Microsoft Office** application disables add-ins as a safety precaution.

In this event, you will need to re-install **Print Plug-In for Office** to display the **imagePROGRAF Print Plug-In** toolbar/ribbon.



 You cannot re-install Print Plug-In for Office once an Office application is running. When the message appears, select Cancel and close the active Office application.

Re-install Print Plug-In for Office as follows:

- 1 Close Microsoft Office if it is open.
- Install Print Plug-In for Office.

 For information about instsalling, see "Steps to install." →P.212

Enabling **Print Plug-In for Office** for items disabled in Office applications


If a problem occurs, such as the system or an application terminating abnormally, the **Microsoft Office** application disables add-ins as a safety precaution.

In this event, you will need to restore the disabled add-ins in order to display the **imagePROGRAF Print Plug-In** toolbar/ribbon.


Use the procedure below to restore the add-ins disabled by Microsoft Office.

215


- For Microsoft Office 2010 or later
- Select **Options** from the **File** menu.



- From the list on the left side of the <application name> options dialog box, select Add-ins.
- 3 Select **Disabled Items** in the **Manage** combo box and click the **Go** button.




If Addin imageprograf print plug-in (ipfaddinif.dll) is displayed in the **Disabled Items** dialog box, select it and click the **Enable** button.




- 5 Close all the dialog boxes and restart the Office application.
- For Microsoft Office 2007


Click the Office button and then click the <application name> options button.



- From the list on the left side of the <application name> options dialog box, select Add-ins.
- 3 Select **Disabled Items** in the **Manage** combo box and click the **Go** button.



If Addin imageprograf print plug-in (ipfaddinif.dll) is displayed in the **Disabled Items** dialog box, select it and click the **Enable** button.



- 5 Close all the dialog boxes and restart the Office application.
- For Microsoft Office 2003


tware Print Plug-In for Office

218

1 Click About <application name> in the Help menu of application.



Click the **Disabled Items** button in the **About <application name>** dialog box.



If Addin imageprograf print plug-in (ipfaddinif.dll) is displayed in the **Disabled Items** dialog box, select it and click the **Enable** button.



4 Close all the dialog boxes and restart the Office application.

To start from Microsoft Word

Below are the steps to start Print Plug-In for Office from Microsoft Word.

- 1 Start Microsoft Word.
- If Start imagePROGRAF Print Plug-In is displayed on the toolbar/ ribbon, click it.





- If the imagePROGRAF Print Plug-In toolbar/ribbon is not displayed, refer to the following.
 - "When Print Plug-In for Office is not displayed" →P.215






4 Click the buttons on the toolbar/ribbon according to the items you want to set.

Icon	Contents
imagePROGRAF * Menu	Displays the About , Help , and Special Settings dialog boxes. You can change the settings using the Special Settings dialog box. Refer to "Configuring Special Settings" → P.247 for details.
Canon iPFxxxx ▼ Printer list	Select Printer. If you select Show All Printers , the imagePROGRAF printers will be displayed again. Select this when you want to display all printer drivers or update the display.
Print PrintButton	The print Wizard is displayed. The settings Print Matching Roll Width , Borderless Printing , Multi-Page Printing , and Print Using Registered Settings can be set.
Paper Settings Paper Settings Button	Large-Format Wizard is displayed. Settings for Portrait or Landscape Orientation can be set.


Printing Wizard dialog box





• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

Large-Format Printing Wizard dialog box





- If you want to change the display to another file or application while the Large-Format Printing Wizard
 is open, close the Large-Format Printing Wizard dialog box. Otherwise, you may not be able to
 change displays or operate the toolbar/ribbon.
- The layout may collapse if you create a form using existing data. If that is the case, modify the data again.

Print Matching Roll Width(Word)


Prints to the edge of the roll width. You can print large exhibits and posters, and also print Portrait and Landscape orientations made in **Large-Format Printing Wizard**.

- 1 Start Microsoft Word.
- 2 If Start imagePROGRAF Print Plug-In is displayed, click it.



Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon.

The **Printing Wizard** dialog box is displayed.







If you want to change the display to another file or application while the **Printing Wizard** is open, close
the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

221

4 Click Print Matching Roll Width.



- 5 Select Roll Paper Width that is set in the printer.
- 6 Select image size.
- 7 Select layout.
- 8 Select Next.



- 9 Select Media Type.
- Select **Print Range** from **All Pages**, **Current Page**, and **Pages**. If **Pages** is selected, enter the number of pages.
- 11 Enter Copies.



• When **Print in Draft mode** is selected, printing is fast but the print quality is poor.

Note

- When **Saturation** is selected, you can print posters, etc., vividly.
- The settings are registered when the **One-Touch Registration** is pressed. This is convenient if you to need print multiple times using the same setting.
- Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- When you print to the edge of the roll width, the maximum length will be the lesser of 5.587 times the roll paper width, or 18.0m.
- 12 Press Print to start printing.

Borderless Printing(Word) iPF685

Borderless Printing(Word)


Prints up to the border of the media. Photos and posters can be printed without worrying about margins.

- 1 Start Microsoft Word.
- If Start imagePROGRAF Print Plug-In is displayed, click it.




Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon.

The **Printing Wizard** dialog box is displayed.





- If you want to change the display to another file or application while the **Printing Wizard** is open, close
 the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- 4 Click Borderless Printing.



A confirmation dialog box is displayed. If the data fills up the page, confirm that **Continue using the plugin** is selected in **Choose how to proceed** and press **OK**.




• To adjust the data, select **Return to application** and press **OK**. Exit **Print Plug-In for Office** and return to the application.

- Select Roll Paper Width that is set in the printer.
- Select layout.

iPF685

Select Next.



- Select Media Type.
- Select Print Range from All Pages, Current Page, and Pages. If **Pages** is selected, enter the number of pages.
- Enter Copies.



- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- Note When **Saturation** is selected, you can print posters, etc., vividly.
 - Press the One-Touch Registration button to register the settings. This is useful for multiple printing using the same settings.
 - · Press the Print Preview button to display the preview screen. You can confirm and make changes to the layout in the preview screen.
 - The maximum length for Borderless Printing is the lesser of 5.587 times the roll paper width, or 18.0m.
- 12 Press Print to start printing.

223

Multi-Page Printing(Word) iPF685

Multi-Page Printing(Word)


Prints multiple pages as one page. You can print handouts into a single page, or print matter with many pages.

- 1 Start Microsoft Word.
- 2 If Start imagePROGRAF Print Plug-In is displayed, click it.




Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon.

The **Printing Wizard** dialog box is displayed.






- If you want to change the display to another file or application while the **Printing Wizard** is open, close
 the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- 4 Click Multi-Page Printing.



- 5 Select Roll Paper Width that is set in the printer.
- 224 6 Select layout from Layout Selection.

7 Select Next.



- 8 Select Media Type.
- 9 Select **Print Range** from **All Pages**, **Current Page**, and **Pages**. If **Pages** is selected, enter the number of pages.
- 10 Enter Copies.



- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When Saturation is selected, you can print posters, etc., vividly.
 - The settings are registered when the One-Touch Registration is pressed. This is convenient if you to need print multiple times using the same setting.
 - Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- The maximum length for Multi-Page Printing is the lesser of 5.587 times the roll paper width, or 18.0m.
- 11 Press Print to start printing.

Register the settings (Word)


If you are going to print multiple times using the same setting, you can select **One-Touch Registration**. Registered settings can be recalled from **Print Using Registered Settings**.

1 Set up to the Print screen from Print Matching Roll Width, Borderless Printing or Multi-Page Printing of Printing Menu.



- Up to 20 items can be registered.
- The available settings are as follows.
 - Print Matching Roll Width(Word) →P.220
 - Borderless Printing(Word) →P.222
 - Multi-Page Printing(Word) →P.224

Click the One-Touch Registration button.



- Enter name in **Name**.
 Up to 31 characters can be entered.
- Click . The name you entered is displayed in Registered Settings.
- 5 Click **OK**, and return to the **Print** screen.
- 6 Click **Print** to print, and click **Cancel** to cancel the print.



Clicking Cancel in the Print screen will not delete the registered settings.

Print Using Registered Settings(Word)


Prints using the registered settings.

- 1 Start Microsoft Word.
- If Start imagePROGRAF Print Plug-In is displayed, click it.



Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon.

The **Printing Wizard** dialog box is displayed.







Important

If you want to change the display to another file or application while the Printing Wizard is open, close
the Printing Wizard dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

4 Click Print Using Registered Settings.



5 Click the **Next**button.



- 6 Select Media Type.
- 7 Select **Print Range** from **All Pages**, **Current Page**, or **Pages**. If **Pages** is selected, enter the number of pages.
- 8 Enter Copies.



- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- Press the Print Preview button to display the preview screen. You can check and make changes to the layout in the preview screen.
- The maximum print length when printing with the registered settings is the lesser of 5.587 times the roll paper width, or 18.0m.
- **9** Press **Print** to start printing.

Portrait Orientation/Landscape Orientation(Word)

Print to the edge of the roll width. You can print large exhibits and posters, or print the Landscape or Portrait Orientation Page Sizes made in the **Large-Format Printing Wizard**.

Create Page Size in Portrait or Landscape Orientation.

Use the **Large-Format Printing Wizard** to create portrait page sizes for Potrait Orientation, and landscape page sizes for Landscape Orientation.


- 1 Start Microsoft Word.
- If Start imagePROGRAF Print Plug-In is displayed, click it.



Click Paper Settings from the imagePROGRAF Print Plug-In toolbar/ribbon. The Large-Format Printing Wizard dialog box is displayed.




If you want to change the display to another file or application while the Large-Format Printing Wizard is
open, close the Large-Format Printing Wizard dialog box. Otherwise, you may not be able to change
displays or operate the toolbar/ribbon.




4 Click Portrait Orientation or Landscape Orientation.



• The steps taken to create a Portrait Page Size will be used as an example to explain the procedure.



- 5 Adjust **Length** from the list-box or slide-bar.
- 6 Click the Create Page button.
- 7 Click**OK** if the message is displayed.



8 Edit and create the document.



Printing is done in Print Matching Roll Width of the Printing Wizard. For details on Print Matching Roll Width, see "Print Matching Roll Width(Word)." >P.220



• The layout may collapse if you create a form using existing data. If that is the case, modify the data again.

To start from Microsoft PowerPoint


Below are the steps to start Print Plug-In for Office from Microsoft PowerPoint.

- 1 Start Microsoft PowerPoint.
- If Start imagePROGRAF Print Plug-In is displayed on the toolbar/ribbon, click it.

Start imagePROGRAF Print Plug-In



- If the imagePROGRAF Print Plug-In toolbar/ribbon is not displayed, refer to the following.
- When Print Plug-In for Office is not displayed →P.215
- Check that the **imagePROGRAF Print Plug-In** toolbar/ribbon is displayed.



4 Click the buttons on the toolbar/ribbon according to the items you want to set.

Icon	Contents
imagePROGRAF *	Displays the About, Help, and Special Settings dialog boxes. (See "Configuring Spe-
Menu	cial Settings.") → P.247
Canon iPFxxxx ▼	Select Printer. If you select Show All Printers , the imagePROGRAF printers will be displayed again.
Printer list	Select this when you want to display all printer drivers or update the display.
Print	The print Wizard is displayed. The settings Print Matching Roll Width , Borderless Printing , Multi-Page Printing , and Print Using Registered Settings can be set.
Print Button	

229

Icon	Contents
Paper Settings	Large-Format Wizard is displayed. Settings for Portrait or Landscape Orientation can be set.
Paper Settings Button	

Printing Wizard dialog box






If you want to change the display to another file or application while the **Printing Wizard** is open, close
the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.



• If you open a password protected document as read-only, the **Printing Wizard** cannot be run.

Large-Format Printing Wizard dialog box





- If you want to change the display to another file or application while the **Large-Format Printing Wizard** is open, close the **Large-Format Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- The layout may collapse if you create a form using existing data. If that is the case, modify the data again.



 If you open a password protected document as read-only, the Large-Format Printing Wizard cannot be run. Remove the password protection.

230

Print Matching Roll Width(PowerPoint)


Prints to the edge of the roll width. You can print large exhibits and posters, and also print Portrait and Landscape orientations made in **Large-Format Printing Wizard**.

- 1 Start Microsoft PowerPoint.
- 2 If Start imagePROGRAF Print Plug-In is displayed, click it.




Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon.

The **Printing Wizard** dialog box is displayed.






- If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- 4 Click Print Matching Roll Width.



- 5 Select Roll Paper Width that is set in the printer.
- 6 Select image size.
- 7 Select layout.

8 Select Next.



- 9 Select Media Type.
- Select **Print Range** from **All Slides**, **Current Slide**, and **Slides**. If **Slides** is selected, enter the slide number.
- 11 Enter Copies.



- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- Note When **Saturation** is selected, you can print posters, etc., vividly.
 - The settings are registered when the One-Touch Registration is pressed. This is convenient if you to need print multiple times using the same setting.
 - Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
 - When you print to the edge of the roll width, the maximum length will be the lesser of 14.22 times the roll paper width, or 18.0m.
- 12 Press **Print** to start printing.

Borderless Printing(PowerPoint)


Prints up to the border of the media. Photos and posters can be printed without worrying about margins.

- 1 Start Microsoft PowerPoint.
- If Start imagePROGRAF Print Plug-In is displayed, click it.




Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon.

The Printing Wizard dialog box is displayed.






- If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- 4 Click Borderless Printing.




A confirmation dialog box is displayed. If the data fills up the page, confirm that Continue using the plugin is selected in Choose how to proceed and press OK.



 To adjust the data, select Return to application and press OK. Exit Print Plug-In for Office and return to the application.



- 6 Select Roll Paper Width that is set in the printer.
- 7 Select layout.
- 8 Select Next.



- 9 Select Media Type.
- Select Print Range from All Slides, Current Slide, and Slides. If Slides is selected, enter the slide number.
- 11 Enter Copies.



- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When Saturation is selected, you can print posters, etc., vividly.
 - Press the One-Touch Registration button to register the settings. This is useful for multiple printing using the same settings.
 - Press the **Print Preview** button to display the preview screen. You can confirm and make changes to the layout in the preview screen.
 - The maximum length for Borderless Printing is the lesser of 14.22 times the roll paper width, or 18.0m.
- 12 Press Print to start printing.

Multi-Page Printing(PowerPoint)


Prints multiple pages as one page. You can print handouts into a single page, or print matter with many pages.

- 1 Start Microsoft PowerPoint.
- If Start imagePROGRAF Print Plug-In is displayed, click it.




Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon.

The **Printing Wizard** dialog box is displayed.






- If you want to change the display to another file or application while the **Printing Wizard** is open, close
 the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- 4 Click Multi-Page Printing.



- 5 Select Roll Paper Width that is set in the printer.
- 6 Select layout from Layout Selection.
- 7 Select Next.



- 8 Select Media Type.
- Select Print Range from All Slides, Current Slide, and Slides. If Slides is selected, enter the slide number.
- 10 Enter Copies.



- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- Note When **Saturation** is selected, you can print posters, etc., vividly.
 - The settings are registered when the One-Touch Registration is pressed. This is convenient if you to need print multiple times using the same setting.
 - Press the Print Preview button to display the preview screen. You can check and make changes to the layout in the preview screen.
 - The maximum length for Multi-Page Printing is the lesser of 14.22 times the roll paper width, or 18.0m.
- Press **Print** to start printing.


Register the settings (PowerPoint)

If you are going to print multiple times using the same setting, you can select One-Touch Registration. Registered settings can be recalled from Print Using Registered Settings.

Set up to the Print screen from Print Matching Roll Width, Borderless Printing or Multi-Page Printing of Printing Menu.



- Up to 20 items can be registered.
- The available settings are as follows.
 - Print Matching Roll Width(PowerPoint) →P.231
 - Borderless Printing(PowerPoint) → P.232
 - Multi-Page Printing(PowerPoint) → P.234
- Click the One-Touch Registration button.



- Enter name in Name. Up to 31 characters can be entered.
- . The name you entered is displayed in Registered Settings.
- 236 Click **OK**, and return to the **Print** screen.
 - Click Print to print, and click Cancel to cancel the print.



Clicking **Cancel** in the **Print** screen will not delete the registered settings.

Print Using Registered Settings(PowerPoint)


Prints using the registered settings.

- 1 Start Microsoft PowerPoint.
- 2 If Start imagePROGRAF Print Plug-In is displayed, click it.




Click Print from the imagePROGRAF Print Plug-In toolbar/ribbon.

The **Printing Wizard** dialog box is displayed.






- If you want to change the display to another file or application while the **Printing Wizard** is open, close
 the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- 4 Click Print Using Registered Settings.



5 Click the **Next**button.



- 6 Select Media Type.
- 7 Select **Print Range** from **All Slides**, **Current Slide**, and **Slides**. If **Slides** is selected, enter the slide number.
- 8 Enter Copies.



- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- Note When **Saturation** is selected, you can print posters, etc., vividly.
 - Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
 - The maximum print length when printing with the registered settings is the lesser of 14.22 times the roll paper width, or 18.0m.
- Press Print to start printing.

Portrait Orientation/Landscape Orientation(PowerPoint)

Print to the edge of the roll width. You can print large exhibits and posters, or print the Landscape or Portrait Orientation Page Sizes made in the **Large-Format Printing Wizard**.

Create Page Size in Portrait or Landscape Orientation.


Use the **Large-Format Printing Wizard** to create portrait page sizes for Potrait Orientation, and landscape page sizes for Landscape Orientation.

- 1 Start Microsoft PowerPoint.
- If Start imagePROGRAF Print Plug-In is displayed, click it.



Click Paper Settings from the imagePROGRAF Print Plug-In toolbar/ribbon.

The Large-Format Printing Wizard dialog box is displayed.







- If you want to change the display to another file or application while the **Large-Format Printing Wizard** is open, close the **Large-Format Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- 4 Click Portrait Orientation or Landscape Orientation.



• The steps taken to create a Portrait Page Size will be used as an example to explain the procedure.



- 5 Adjust **Length** from the list-box or slide-bar.
- 6 Click the Create Page button.
- 7 Click**OK** if the message is displayed.



To start from Microsoft Excel iPF685

8

Edit and create the document.



 The layout may collapse if you create a form using existing data. If that is the case, modify the data again.



Printing is done in Print Matching Roll Width of the Printing Wizard. For details on Print Matching Roll Width, see "Print Matching Roll Width(PowerPoint)." →P231

To start from Microsoft Excel

Below are the steps to start Print Plug-In for Office from Microsoft Excel.

- 1 Start Microsoft Excel.
- 2 If Start imagePROGRAF Print Plug-In is displayed on the toolbar/ribbon, click it.





- If the imagePROGRAF Print Plug-In toolbar/ribbon is not displayed, refer to the following.
- When Print Plug-In for Office is not displayed →P.215
- Check that the imagePROGRAF Print Plug-In toolbar/ribbon is displayed.



4 Click the buttons on the toolbar/ribbon according to the items you want to set.

Icon	Contents
imagePROGRAF *	Displays the About , Help , and Special Settings dialog boxes. (See "Configuring Special Settings")
Menu	cial Settings.") →P.247
Canon iPFxxxx ▼	Select Printer. If you select Show All Printers , the imagePROGRAF printers will be displayed again.
Printer list	Select this when you want to display all printer drivers or update the display.
Print	The print Wizard is displayed. The settings Print Entire Sheet and Print Selected Area can be set.
Print Button	

Printing Wizard dialog box



iPF685 Print Entire Sheet(Excel)



If you want to change the display to another file or application while the **Printing Wizard** is open, close
the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

- The Printing Wizard will not start if you click the Print button on the toolbar/ribbon while editing a cell.
- When more than one worksheet is selected, the Printing Wizard cannot be run. Select only one worksheet and click Print again.
- When an object is selected, the Printing Wizard is not started if you click the Print button on the toolbar/ribbon.
- If the paper size in Excel is blank, the **Printing Wizard** cannot be run. From the **File** menu in Excel, select **Page Setup** and check **Paper size**.



- If you click the Print button with a graph selected, a message dialog box will appear asking if you want to
 continue printing. If you click No, you will return to the application.
- If you click the Print button with a page break set, a message dialog box will appear asking if you want to
 continue printing. If you click No, you will return to the application. If you do not use the set page break,
 check the page break preview and change the setting.
- If you click the **Print** button with a page range set, a message dialog box will appear asking if you want to
 continue printing. If you click **No**, you will return to the application. If you do not use the set page range,
 check the page break preview and change the setting.
- If you click the Print button with a worksheet or cell protected, a message dialog box will appear asking if
 you want to continue printing. If you click No, you will return to the application. If you want to change the
 setting, remove the protection from the worksheet or cell.

Print Entire Sheet(Excel)

For resizing the entire sheet to fit the roll width. Choose this option to enlarge the currently displayed sheet before printing.

- 1 Start Microsoft Excel.
- If Start imagePROGRAF Print Plug-In is displayed, click it.



Click Print from the imagePROGRAF Print Plug-In toolbar/ribbon.




When more than one worksheet is selected, the Printing Wizard cannot be run. Select only one worksheet and click Print again.

If a print area is set, a confirmation message dialog box will appear.

To print the entire sheet, cancel the setting of the print area.




The **Printing Wizard** dialog box is displayed.




4 Click Print Entire Sheet.

A message will appear informing you that analysis is in progress.



The Layout menu will appear automatically.




Note

- If data analysis requires time, a message dialog will appear. If you select No, you will return to the application.
- 5 Select Roll Paper Width that is set in the printer.
- 6 Select image size.
- 7 Select layout.

243

- To configure **Binding**, click the **Binding Settings** button.

 Refer to "Configuring Binding (Excel)" >P.246 for details on the procedure for configuring **Binding**.
- 9 Select Next.



- 10 Select Media Type.
- 11 Enter Copies.
- 12 If the upper and lower margins are too wide, check No Spaces at Top or Bottom (Conserve Paper). The upper and lower margins can be checked in Print Preview.



- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- Note When **Saturation** is selected, you can print posters, etc., vividly.
 - Press the Print Preview button to display the preview screen. You can check and make changes to the layout in the preview screen.
 - When you print to the edge of the roll width, the maximum print length is 18.0m.
- 13 Press Print to start printing.



- If divided into plural pages, try reducing the data size or the range you select.
- Important You cannot run Print or Print Preview if you select it for a worksheet with no data displayed.

Print Selected Area(Excel)

For resizing the selected range of cells to fit the roll width. Choose this option to enlarge a particular part of the sheet before printing.

- 1 Start Microsoft Excel.
- If Start imagePROGRAF Print Plug-In is displayed, click it.



Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon.




When more than one worksheet is selected, the Printing Wizard cannot be run. Select only one worksheet and click Print again.

If a print area is set, a confirmation message dialog box will appear.

To print the selected area, cancel the setting of the print area.



The **Printing Wizard** dialog box is displayed.




4 Click Print Selected Area.




If only one cell is selected, Print Selected Area cannot be selected.

A message will appear informing you that analysis is in progress.



The Layout menu will appear automatically.






• If the range selected in **Excel 2007 or later** is too large, it will not be possible to analyze the data. Select a smaller range and then run the analysis.



- If data analysis requires time, a message dialog will appear. If you select **No**, you will return to the application.
- 5 Select Roll Paper Width that is set in the printer.
- 6 Select image size.
- 7 Select layout.
- To configure **Binding**, click the **Binding Settings** button.

 Refer to "Configuring Binding (Excel)" →P.246 for details on the procedure for configuring Binding.
- 9 Select Next.



- 10 Select Media Type.
- 11 Enter Copies.

Print Plug-In for Office

12 If the upper and lower margins are too wide, check No Spaces at Top or Bottom (Conserve Paper). The upper and lower margins can be checked in **Print Preview**.



- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- · Press the Print Preview button to display the preview screen. You can check and make changes to the layout in the preview screen.
- When you print to the edge of the roll width, the maximum print length is 18.0m.
- 13 Press Print to start printing.



• If divided into plural pages, try reducing the data size or the range you select.



Important • You cannot run Print or Print Preview if you select it for a worksheet with no data displayed.

Configuring Binding (Excel)

You can configure **Binding** margins for binding printouts.

Configure the settings up to Layout Selection in the Layout screen in Print Entire Sheet or Print Selec-

Refer to "Print Entire Sheet(Excel)" →P.241 and "Print Selected Area(Excel)" →P.243 for the configuration methods.

Click the Binding Settings button.




You cannot click the Binding Settings button in the following situations.

Important

- When the Image Size is set to a value smaller than 100%
- · When a graph is selected
- When page breaks have been set
- · When a sheet or cell is protected


Open the **Binding Settings** dialog box.



- If the **Binding** checkbox is not checked, select it to turn binding on.
- Select Binding Edge.
- Select Binding Margin.

6 Click the **OK** button. Return to the **Layout** screen.

Check that the **Binding** settings are applied in the preview screen.




7 Configure the settings in the **Printing Wizard** dialog box.

Configuring Special Settings

You can configure **Special Settings** from the **imagePROGRAF Print Plug-In** toolbar.

Click imagePROGRAF in the toolbar, and select Special Settings.



2 Turn the checkbox for the item you want to change on or off.

-	
Item	Details
Show progress indicator during plug-in start- up	When this setting is off, hides the progress indicator that appears while the plug-in is starting up.
Center sheets and print areas	When this setting is off, printing is performed without changing the position. When this setting is on, printing is performed with the top, bottom, left, and right margins layed out equally. When this setting is off, printing is performed without changing the position. This function is only valid in Microsoft Excel .
Ensure image quality when creating page sizes	When this setting is on, documents are created at the maximum size. This reduces the enlargement ratio during actual printing, which minimizes degradation of the quality of photos, etc. This function is only valid in Microsoft PowerPoint .
Correct the print area when analyzing	For data that cannot be processed with usual data analysis, the print area is corrected and then the data is processed. When data analysis fails, you may be able to print by turning on this checkbox. This function is only valid in Microsoft Excel .

3 Click **OK** to close the **Special Settings** dialog box.

Memo

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141

Mac OS Software

Printer Driver	250
Preview	268
Free Layout	289
Color imageRUNNER Enlargement Copy	312
→ Printmonitor	470
→ Media Configuration Tool	383

Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

250


Printer Driver

Printer Driver Settings	250
Specifying Paper in the Printer Driver Confirming Print Settings Checking the Layout in a Preview Before Printing	253
Using Favorites	
Accessing the Printer Driver Dialog Box from Applications	254
Main Pane	254
Paper Detailed Settings Dialog Box	258
View set. Dialog Box for the Printing Application	260
Matching pane	260
Color Settings Pane: Color	
Object Adjustment dialog box: Color	263
Color Settings Pane: Monochrome	264
Object Adjustment dialog box: Monochrome	265
Page Setup Pane	265
Additional Settings Pane	266

Printer Driver Settings

For instructions on accessing the Mac OS printer driver, refer to the following topics.

Accessing the Printer Driver Dialog Box from Applications →P254



For information on the Mac OS printer driver settings, refer to the following topics.

- Main Pane → P.254
 - You can specify the media type, color processing, print quality, print preview, and other settings. Choose **Easy Settings** to specify basic print settings based on the printing application or **Advanced Settings** to complete more detailed settings as desired.
 - Paper Detailed Settings Dialog Box → P.258
 - View set. Dialog Box for the Printing Application →P.260
 - Color Settings Pane: Color →P.262
 - Object Adjustment dialog box: Color →P.263
 - Matching pane →P.260
 - Color Settings Pane: Monochrome → P.264

- Object Adjustment dialog box: Monochrome →P.265
- Page Setup Pane →P.265

You can specify the page size of the original, borderless printing, enlargement or reduction, the orientation, the paper size and source, and automatic cutting.

Additional Settings Pane →P.266
 You can configure the method of outputting print jobs to the printer.

With the **imagePROGRAF Free Layout** feature, you can arrange originals from various source applications on a single page before printing. For details, see "Free Layout." >P.289

With the **imagePROGRAF Preview** feature, you can check the layout before printing and adjust layout or size settings while viewing a preview screen. For details, see "Preview." >P.268

With the Color imageRUNNER Enlargement Copy feature, you can automatically enlarge and print scanned originals from a Color imageRUNNER. For details, see "Color imageRUNNER Enlargement Copy."

P.312


Specifying Paper in the Printer Driver

If you have replaced the paper, you must complete the following settings in the printer driver.

1 This sets the B Format for and C Paper Size.



 The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



G Orientation:

If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.

- 2 Select the printer in the A Printer list.
- Choose the original size in the F Paper Size list.
- If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.


Printer Driver

5

Access the Main pane.



- 6 In the A Media Type list, select the type of paper that is loaded.
- 7 Access the Page Setup pane.



- 8 In the A Paper Source list, select how paper is supplied.
- If Roll Paper is selected in A Paper Source, select the width of the roll paper that is loaded in B Roll Width.



• A variety of settings are available in the printer driver to suit different printing applications. For details on available printing conditions, see "Printer Driver Settings." >P.250

252 Confirming Print Settings

The ways to confirm what printing conditions have been specified are as follows.

Checking a print preview

You can check an image of the original just as it will be printed.


Confirming the image of print jobs beforehand helps prevent printing errors.

For details on print previews, see "Checking the Layout in a Preview Before Printing." >P.130


Checking the Layout in a Preview Before Printing

This topic describes how to check the layout before printing using the Canon imagePROGRAF Preview function.

- 1 Choose **Print** in the application menu.
- 2 Access the Main pane.



- 3 Select the OPrint Preview check box.
- 4 Click M Print.
- The Canon imagePROGRAF Preview window is displayed.



- 6 Check the layout and adjust settings in the Canon imagePROGRAF Preview window as desired.
- 7 Print from the Canon imagePROGRAF Preview menu.



For details on imagePROGRAF Preview functions, see "Preview." →P.268

Using Favorites

You can use the **Presets** function in Mac OS for favorite-based printing.



• In the printing dialog box, click **Save As** in the **Presets** list to save the current print settings. This is a standard feature of the operating system. For details, refer to the Mac OS documentation.


Accessing the Printer Driver Dialog Box from Applications

 $oxed{1}$ In the application software, select **Print** from the **File** menu to display the dialog box for printing conditions.




 This dialog box includes basic printing options and enables you to choose the printer, specify the range of pages, number of copies, and so on.

2 Select the printer in the **Printer** list.



3 Click **Print** to start printing.

As shown in the following illustration, you can switch to other panes in this dialog box to complete settings for various methods of printing, including enlarged and reduced printing, borderless printing, and so on.




Main Pane

The following settings are available on the **Main** pane. For details on settings items, refer to the printer driver help.



• On the **Main** pane, choose **Easy Settings** to specify basic print settings based on the print target, or switch to **Advanced Settings** to complete more detailed settings as desired.

Common Items



A Media Type

Select the paper type.

For information on the types of paper the printer supports, refer to the **Paper Reference Guide**. (See "Displaying the Paper Reference Guide.") >P.331

• C Set

Displays **Paper Detailed Settings**. You can configure the printing settings to match the type of media, such as the ink drying time.

Paper Detailed Settings Dialog Box →P.258


O Print Preview

When the check box is selected, **imagePROGRAF Preview** is launched before printing. This allows you to check on-screen previews of documents before printing.



- When Free Layout is selected on the Page Setup panel, Free Layout is disabled.
- Checking the Layout in a Preview Before Printing →P.130

Configuration using Easy Settings



• E Print Target

Choose presets that match the type of document to be printed.

- Printing Photos and Images →P.31
- Printing Office Documents →P.35

• F Print Quality


Choose the level of print quality.

G View set.

Click to display the **View set.** dialog box, which enables you to confirm the settings for the selected item from the **E Print Target** list or change the order of items listed in **E Print Target**.

View set. Dialog Box for the Printing Application →P.260

Configuration using Advanced Settings



iPF685

• E Print Priority

Choose the graphic elements that you want to emphasize for printing.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.54

F Print Quality

Choose the level of print quality.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.54

N Highest quality

When the check box is selected, printing is performing focusing on quality. Printing takes longer and consumes more ink than in other modes, but this mode offers superior printing quality.



If you set F Print Quality to High, you can select N Highest quality. However, depending on A Media
 Type, you may not be able to select N Highest quality.

K Economy Printing

When this mode is selected, you can print with less ink consumed. However, print quality is lower than in regular printing. Select this option to save ink, such as when printing to check drawings. Depending on the A Media Type and F Print Quality settings, this mode may not be available.



If you set F Print Quality to Fast, you can select K Economy Printing. However, depending on A Media
Type, you may not be able to select K Economy Printing.

• R Fast Graphic Process

Select this option to print faster than usual, when possible.

• H Color Mode

Choose the color mode.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.54

• | Set

Click to display the **Color Settings** dialog box for more advanced color settings.

Adjusting the Color in the Printer Driver →P.48

J Unidirectional Printing

Select this checkbox to prevent problems such as misaligned lines and improve the print quality. However, the printing speed becomes slower.

• Q Thicken Fine Lines

Select this check box to print fine lines more distinctly.

P Sharpen Text

Select this check box to print text more sharply.


S Reduce Print Unevenness

Select this checkbox for two-pass printing to reduce color shading.

This option is displayed if you have selected Plain Paper in **Media Type** and **Office Document** in **Print Priority**.

Paper Detailed Settings Dialog Box

The **Paper Detailed Settings** dialog box offers the following settings. For details on settings items, refer to the printer driver help.





• To display the **Paper Detailed Settings** dialog box, on the **Main** pane, click **Set** by **Media Type**. (See "Main Pane.") →P.254

A Media Type

The paper selected with **Media Type** of the **Main** panel is displayed.

For information on the types of paper the printer supports, refer to the **Paper Reference Guide**. (See "**Displaying** the **Paper Reference Guide**.") →P.331

B Drying Time

Specify the time that the printer waits for ink to dry, as needed. The Between Pages setting is only valid for rolls.

C Between Pages

You can set the time to wait after printing 1 document page until ejecting the paper. Since waiting time is required for ink to dry before a roll is cut, you can deliver paper in the Output Stacker with the ink dried even if **Cutting Mode** is set to **Automatic**.

Setting Item	Details
Printer Default	The setting of the control panel of the printer is applied.
None	Paper is ejected immediately after printing completes.
30 sec. / 1 min. / 3 min. / 5 min. / 10 min. / 30 min. / 60 min.	Paper is ejected when the set time elapses after printing completes.

D Between Scans

You can set the time to wait after printing 1 line on a page until printing the next line. Set this to avoid bleeding or color unevenness such as when bleeding occurs on a page or when color unevenness occurs during borderless printing.

Setting Item	Details
Printer Default	The setting of the control panel of the printer is applied.
None	The next line is printed immediately after a line is printed.
1 sec. / 3 sec. / 5 sec. / 7 sec. / 9	The next line is printed when the set time elapses after a line is printed.
Sec.	* Increase the time according to the occurrence condition of bleeding or unevenness.

E Roll Paper Margin for Safety

You can specify the length of a margin on the leading edge of paper to ensure that paper susceptible to curling is held firmly against the Platen.

• F Near End Margin

Specify the length of the Near End Margin (the leading edge margin) of the roll, as needed.

Setting Item	Details
Printer Default	The setting of the control panel of the printer is applied.
3 mm (0.12 in)	The document is printed in the standard size.
	* Select this when you do not have any problems in printing.
20 mm (0.8 in)	Select this when rubbing against the printhead occurs such as when using paper that tends to curl.

G Cut Speed

Select the speed of automatic cutting, as needed. You can adjust this setting if paper is not cut well when automatic cutting is used.

Setting Item	Details
Printer Default	The setting of the control panel of the printer is applied.
High Speed	When the Standard setting does not result in a clean cut surface, select this.
Standard	Select this when you do not have any problems in automatic cutting.
Low Speed	This helps prevent adhesive from sticking to the cutter and keeps the cutter sharp if you select it when using adhesive paper.

H Automatic Cutting

Set whether to perform roll cutting automatically or print a cut line.

The following settings are available for automatic cutting.


Setting Item	Details
Printer Default	The setting of the control panel of the printer is applied.
None	After printing completes, the roll is not cut per page, and the next page of data is printed successively.
Print Cut Guideline	After printing completes, a line is printed per page, and the next page of data is printed successively.

J Mirror

Specify whether to print a mirror image, as needed. Select this option to print a version of the document or image with the left and right sides inverted.

View set. Dialog Box for the Printing Application

In the View set. dialog box, you can check details of the selected printing application.





- To display the **View set.** dialog box, on the **Main** pane, click **View set.** by **Print Target**. (See "Main Pane.") → P.254
- A Print Target

Shows all **Print Target** options (settings items for the printing application).

• B Name

Identifies the item selected in **Print Target** by its name and an icon.

C Details

Here, you can confirm detailed settings values for each item selected in the Print Target list.

Matching pane

On the **Matching** pane, you can specify color matching to compensate for differences in the appearance of colors on various devices.



The Matching pane is not displayed when No color correction or Monochrome is selected in Color Mode.




 To display the Matching pane, on the Main pane click Color Settings by Color Mode in Advanced Settings, and then click the Matching tab. (See "Main Pane .") →P254

261

Matching pane

Driver Matching Mode

The following options are available when you select **Driver Matching Mode** in the A **Matching Mode** list.



A Matching Mode

Select the color matching mode to use, as desired.

Normally, select Driver Matching Mode. For color matching based on ICC profiles, select ICC Matching Mode depending on your color matching system.

• B Matching Method

Select the color matching method that suits the document to be printed. Various B Matching Method options are available depending on your selection in A Matching Mode.


• E Gamma

You can adjust the gradation of intermediate tones in an image.

2.2 is normally selected. If you want a softer impression than 2.2, select 1.8.

ICC Matching Mode

The following options are available when you select ICC Matching Mode, in the A Matching Mode list.





 To display the Matching pane, on the Main pane, click Color Settings by Color Mode in Advanced Settings, and then click the Matching tab. (See "Main Pane .") →P.254

A Matching Mode

Select the color matching mode to use, as desired.

• BInput Profile Settings

You can choose Input Profile.

Various options are available depending on your selected A Matching Mode.

C Matching Method

You can choose C Matching Method.

Various options are available depending on your selected A Matching Mode.

• D Printer Profile Settings

Specify the printer profile as desired.

We recommend that you select an ICC profile created using commercially available profile creation software in order to perform color management accurately on paper other than genuine Canon paper and feed confirmed paper.


The created ICC profile needs to be saved in the following folder on the computer you are using. /user/(user name)/library/ColorSync/Profiles folder



For details on settings items, see "Adjusting the Color in the Printer Driver." →P.48

Color Settings Pane: Color

In general, make any needed adjustments to the color of documents in the application used to create them. However, if the color tone as printed is not as you expected, you can also adjust the color in the printer driver. If the color tone as printed is not as you expected, you can adjust it on the **Color Adjustment** pane.





- To display the Color Adjustment pane, on the Main pane click Color Settings by Color Mode in Advanced Settings. (See "Main Pane .") →P.254
- For details on settings items, see "Adjusting the Color in the Printer Driver." →P.48

A Sample Type

Choose a sample image from Standard, Portrait, Landscape, or Graphics.

B View Color Pattern

Select this checkbox to display the color pattern.

C Apply to Sample

Select this checkbox to apply the changed settings to the sample image.

• D Cyan/ E Magenta/ F Yellow

Correct color tones by adjusting the levels of each color.

• G Gray Tone

Adjust the color tone of grays as desired. Choose Cool (tinged with blue) or Warm (tinged with red).

• H Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

• | Contrast

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the **Contrast** makes images sharper, and reducing the **Contrast** softens images.

J Saturation

Adjust the color intensity as desired. Increasing the **Saturation** setting makes colors more vivid, and reducing the **Saturation** makes colors more subdued.

K Object Adjustment

Select this option to display the **Object Adjustment** dialog box, in which you can specify objects subject to color adjustment.

Object Adjustment dialog box: Color →P.263

Object Adjustment dialog box: Color

In the **Object Adjustment** dialog box, you can specify what type of print jobs to apply color adjustment to. If an original comprises images, graphics, and text, you can specify which portion to apply color adjustment to.





To display the Object Adjustment dialog box, click Object Adjustment on the Color Adjustment panel.

• Almages

Select this option to apply color adjustment to image areas, such as photos.

• B Graphics


Select this option to apply color adjustment to graphics, such as lines and circles.

• C Text

Select this option to apply color adjustment to text.

Color Settings Pane: Monochrome

On the Color Adjustment pane for monochrome printing, you can adjust the brightness and contrast.





- To display the Color Adjustment pane, on the Main pane, click Color Settings in Advanced Settings. (See "Main Pane .") →P.254
- For details on settings items, see "Adjusting the Color in the Printer Driver." >P.48

A Sample Type

Choose a sample image from Standard, Portrait, Landscape, or Graphics.

• B View Color Pattern

Select this checkbox to display the color pattern.

C Apply to Sample

Select this checkbox to apply the changed settings to the sample image.

D Cyan/ E Magenta/ F Yellow

Not available.

• G Gray Tone

Not available.

H Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

• | Contrast

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the **Contrast** makes images sharper, and reducing the **Contrast** softens images.

J Saturation

264

Not available.


K Object Adjustment

Select this option to display the **Object Adjustment** dialog box, in which you can specify objects subject to color adjustment.

Object Adjustment dialog box: Monochrome →P.265

Object Adjustment dialog box: Monochrome

In the **Object Adjustment** dialog box, you can specify what type of print jobs to apply color adjustment to. If an original comprises images, graphics, and text, you can specify which portion to apply color adjustment to.





To display the Object Adjustment dialog box, click Object Adjustment on the Color Adjustment panel.

• Almages

Select this option to apply color adjustment to image areas, such as photos.

• B Graphics


Select this option to apply color adjustment to graphics, such as lines and circles.

C Text

Select this option to apply color adjustment to text.

Page Setup Pane

The following settings are available on the **Page Setup** pane. For details on settings items, refer to the printer driver help.



A Paper Source

Choose how paper is supplied.

Options displayed in the list vary depending on the selection in A Media Type in the Main pane.

• B Roll Width

Select the paper width of the roll loaded in the printer.

Additional Settings Pane iPF685

D Enlarged/Reduced Printing

Select this checkbox to choose the following options.

- Resizing Originals to Fit the Roll Width →P.62
- Resizing Originals by Entering a Scaling Value →P.65

• Fit Roll Paper Width

Resizes the document image to match the roll width.

G Scaling

Resizes the document image based on a specified scaling value. Enter a value in a range of 5-600.

H Borderless Printing

Borderless printing is available if roll paper is selected in the A Paper Source list.

Activate this setting for borderless printing to match the size and width of the paper.

- Borderless Printing by Resizing Originals to Fit the Roll Width →P.82
- Borderless Printing at Actual Size →P.74

J Print Centered

Select this checkbox to print document images in the center of the paper.

- Printing Originals Centered on Rolls →P.115
- Printing Originals Centered on Sheets →P.119

K No Spaces at Top or Bottom

Select this checkbox to print the next image skipping blank areas above and below printable data in documents, which enables you to conserve the paper.

Conserving Roll Paper by Printing Originals Without Top and Bottom Margins →P.126

L Rotate Page 90 degrees

Select this checkbox to rotate the document image by 90 degrees before printing.

Conserving Roll Paper by Rotating Originals 90 Degrees →P.123

N Free Layout

Select this checkbox to start imagePROGRAF Free Layout before printing.

This allows you to print multiple documents next to each other.




When Print Preview is selected on the Main panel, Print Preview is disabled.

Printing Multiple Originals Next to Each Other →P.101

Additional Settings Pane

The following settings are available on the Additional Settings pane.



A Send job to

You can configure the method for saving print jobs to the printer hard disk.

Printer Driver

267

• B Print after reception is complete

You can prevent degradation of print quality that occurs when receiving a print job is interrupted and printing is aborted in the middle.

Preview

The Features of Preview	268
Starting Preview	268
Preview Main Window	
Paper Settings Panel	
Easy Settings	
Advanced Settings	
Output Settings Panel	
Color Settings Panel	
Color Adjustment	
Matching	
Driver Matching Mode	
ICC Matching Mode	
ColorSync	283
Profesonana Dialog Roy	202
Preferences Dialog Box	
Zoom Dialog Box	
GO to Page Dialog Box	204
Print with No Borders	284
Print on the Center	
Not Print Spaces at the Top/Bottom	
Print Page Rotated 90 Degrees	
Display with Fitting to the Width of the Paper	
Display with All	
Display with Actual Size	
Moving a Page	

The Features of Preview

The main features of Preview are as follows.

- While viewing this screen, you can adjust layout settings of a document created with application software.
- You can not only adjust layout settings but also your changes will be instantly applied on the preview screen, and you can print the preview screen as it is seen.



 The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Preview settings.

Starting Preview

Follow the procedure below to start the Preview.

- 1 Start the apllication software which you use.
- From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



• Normally, select **Print** from the **File** menu.


268

3 Click **Print Preview** in the **Main** panel to attach a checkmark.

Preview

iPF685 Starting Preview

4 Click the **Print** button in the **Print** dialog box.






Your printer is depicted in the lower-left area of this screen.

Preview main window is displayed.



Preview Main Window

The Preview main window consists of the menu and tool bars, and preview, dialog, drawer and status area.





• You can use the View menu to show or hide the tool bar.

Menu Bar

This allows you to select menus required for operations.

imagePROGRAF Advanced Preview File Edit View Object Window Help

Tool Bar

This allows you to select tool buttons required for major operations.



Preview Area


You can check the settings you made in this area.



Preview

· Dialog Area

This allows you to set the print conditions and perform a print job.




Drawer Area

This allows you to display the thumbnails of a document.

This area appears when you click **Drawer** from the tool bar.

Alternatively, you may select Drawer from the View menu.



• Status Area


This shows Input Size and Output Size.

Input Size 16.54 x 23.39 in. Output Size 24.00 x 23.39 in.

iPF685

Paper Settings Panel

This panel appears when you select Paper Settings in the dialog area.



Media Type

This allows you to select the media type.



 Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.

Easy Settings / Advanced Settings

Two modes are available to provide the optimum print settings for jobs.

The settings available on each mode are as follows.

- Easy Settings → P.273
- Advanced Settings →P.274

Paper Source

You can select the paper source.

The following settings are available for paper source.

Setting	Details
Manual	Select for manual paper feed printing.
Roll Paper	Select to print on roll paper.

Roll Paper Width

This selects the width of the roll media set to the printer.



Available only if rolls are selected in Paper Source.

Copies

272

You can input the number of print copies in numerical characters.



- The maximum value is 999.
- You can change the numbers by clicking either ▲ button or ▼ button.

iPF685 Easy Settings

• Restore Defaults Button

Click the button to reset to the setting when starting Preview.

• Print Button


Click the button to begin printing.

• Update Printer Info. Button

Click the button to acquire printer information.

Easy Settings

You can easily select the best settings for the print job by just selecting an item from the print target list that matches the content of the document.



Print Target

You can easily select the best settings for the print job simply.

If you select each Print Target item the corresponding comment for that item is displayed below the list.

,	1 3
Setting	Details
Default Settings	Suitable for printing normal documents that contain a mixture of text, photographs, and graphics.
Poster	The best setting for posters. Prints using vivid and high impact colors.
CAD (Color Line Drawing)	Prints the fine lines of CAD drawings and other such documents sharp and clear.
CAD (B/W Line Drawing)	Suitable for printing CAD drawings with sharp, dark lines.
Perspective, GIS	Suitable for attractive printing of 3D-CAD drawings, perspective drawings, and GIS drawings including maps.
Photo (Color)	Suitable for printing photographic images captured with a digital camera.
Office Document	Suitable for printing handouts as well as general office documents for which print clarity is key.
Faithful Color Reproduction	Prints by faithfully reproducing the colors of the original image.
Custom Settings	Suitable for printing documents for which Advanced Settings have been specified.



The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.


Setting	Details
Print Quality	Highest quality / Highest / High / Standard / Fast
Resolution	1200dpi / 600dpi / 300dpi



- The availability of settings is determined by the media type and print priority selections.
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
- Printing time is shorter and less ink is consumed with Fast than with High, however, print quality is lower.
- For Highest quality, the resolution is not displayed.

Advanced Settings

Presents detailed settings for the print quality, the color mode, and other items so you can select the values for these settings yourself.



Print Priority

Select a print quality mode that is appropriate for the print job.

Image

This mode achieves the best results for printing photographic images and illustrations.

Line Drawing

This mode is best for printing CAD drawings with fine lines or wall newssheet or other documents that contain large amounts of text. However, you may not achieve the quality you expect with printing photographs or other images with many filled areas. For these types of jobs, select Image.

Office Document

Prints common office documents, such as proposals, memos for distribution, etc., so they are easy to read.



• The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.


Setting	Details
Print Quality	Highest quality / Highest / High / Standard / Fast
Resolution	1200dpi / 600dpi / 300dpi



- The availability of settings is determined by the media type and print priority selections.
- Note Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
 - Printing time is shorter and less ink is consumed with Fast than with High, however, print quality is lower.
 - For **Highest quality**, the resolution is not displayed.

Output Settings Panel

This panel appears when you select **Output Settings** in the dialog area.



• Enlarged/Reduced Printing

Select the method for enlarged/reduced printing.

The following settings are available for enlarged/reduced printing.

Setting	Details
Fit Paper Size	Enlarges/reduces the whole page automatically to fit the media size selected for output. Select the media size to print from Paper Size .
Fit Roll Paper Width	Enlarges/reduces the whole page automatically to fit the width of the roll paper with the page width.
	*Make sure that the width of the roll paper in the printer is set correctly for Roll Paper Width in the Paper Settings panel. *Displayed only if rolls are selected in Paper Source .

Setting	Details
Scaling	Enlarges/reduces the whole page by the scaling rate as specified. Input the scaling value in numerical characters. You can specify a range between 5 and 600%.
	*You can change the numbers by clicking either ▲ button or ▼ button. *Although Scaling can be set to make the image larger than the media size, the part that does not fit in the media cannot be printed. *This is not displayed when a checkmark is placed in Borderless Printing .

Borderless Printing

You can print the media without margins on all sides when the roll paper with the specific width and the specific media type is used.

For more information about Borderless Printing, see "Print with No Borders." >P.284



- Available only if rolls are selected in **Paper Source**.
- Note This is not displayed when a checkmark is placed in **Print Centered**.

Paper Size

You can select the size of the print media.



This is not displayed when Fit Roll Paper Width is set in Enlarged/Reduced Printing.

Print Centered

You can print on the center of the media loaded in the printer.

For more information about **Print Centered**, see "Print on the Center." →P.285



This is not displayed when a checkmark is placed in Borderless Printing.

No Spaces at Top or Bottom

You can save paper on not to feed roll paper for the empty spaces when the print data contains spaces at the top or bottom.

For more information about No Spaces at Top or Bottom, see "Not Print Spaces at the Top/Bottom." >P.285



Available only if rolls are selected in Paper Source.

Rotate Page

Select the method for rotating page.

The following settings are available for rotating page.

Setting	Details
Rotate Right 90 Degrees	Rotates the portrait page right 90 degrees and print in landscape orientation. When the rotated page can fit in the width of roll paper, the page is rotated automatically, and when it can not fit in the width of roll paper, the page is not rotated.
Rotate Left 90 Degrees	Rotates the portrait page left 90 degrees and print in landscape orientation. When the rotated page can fit in the width of roll paper, the page is rotated automatically, and when it can not fit in the width of roll paper, the page is not rotated.
Rotate 180 degrees	Allows you to rotate the image 180 degrees from the vertical to the right.

• Restore Defaults Button

Click the button to reset to the setting when starting Preview.

• Print Button

Click the button to begin printing.

• Update Printer Info. Button

Click the button to acquire printer information.


276

iPF685

Color Settings Panel

Color Settings Panel

This panel appears when you select Color Settings in the dialog area.



Color Mode

You can select a color mode to suit the print job.

Setting	Details
Color	Enables color printing.
Monochrome	Disables color printing and converts image from continuous color to grayscaled mono- chrome.
Color (CAD)	Prints lines in the best color possible so they are easy to see.
Monochrome Bitmap	Prints all colors other than white in black.
Monochrome (BK ink)	Select to print all lines with black ink.
No color correction	Prints without performing color matching in the printer driver. Select this when color matching is performed by the application such as Adobe Photoshop or when you want to print color charts using the profile creation tool.



• The availability of settings depends on the print priority and media type selections.

Color Adjustment / Gray Adjustment / Matching

You can set the color adjustment and matching.

- Color Adjustment →P.278
- Matching → P.279



• Matching is not displayed if No color correction has been selected in Color Mode.

• Restore Defaults Button

Click the button to reset to the setting when starting Preview.

• Print Button

Click the button to begin printing.

• Update Printer Info. Button

Click the button to acquire printer information.


Color Adjustment

You can set the color adjustment.

Adjusting Color

Normally colors should be adjusted in the software application, but if you see colors in the printout that do not match colors on the screen, you can perform color adjustments.

- 1 Select Color on Color Mode in the Color Settings panel.
- 2 Select Color Adjustment.



3 Drag each slider to the left or right to adjust.

Setting	Details
Cyan	Adjusts the strength of colors to compensate the hues.
Magenta	Adjusts the strength of colors to compensate the hues.
Yellow	Adjusts the strength of colors to compensate the hues.
Brightness	Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature.
Contrast	Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast.
Saturation	Adjusts the hues for vivid color or dark color.
Gray Tone	Adjusts gray from cool black (bluish tones) to warm black (reddish tones).

Matching




• You can also click the up or down arrow, or enter the number directly to increase or decrease the value.

Adjusting Monochrome

Use the monochrome setting to print monochrome images of color photographs captured with a scanner or digital camera or other color images.

- Select Monochrome on Color Mode in the Color Settings panel.
- Select Color Adjustment.



Drag each slider to the left or right to adjust.

Setting	Details
Brightness	Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature.
Contrast	Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast.



You can also click the up or down arrow, or enter the number directly to increase or decrease the value.

Matching


You can set the matching.



If No color correction is selected under Color Mode, the Matching is not displayed.

User's Guide

Matching iPF685



Matching Mode

You can select a matching mode to suit the print job.

Setting	Details
Driver Matching Mode →P.281	Enables printing of optimal color tones using a driver specific color profile. You should normally select this mode.
ICC Matching Mode → P.282	Enables color matching using ICC profiles. Select this if you want to print by specifying the input profile, printer profile, and matching method in detail. This allows you to use ICC profiles for digital cameras and scanners, ICC profiles created using the profile creation tool, etc.
ColorSync →P.283	Enables color matching by using the ColorSync function of OS X. Select this if you want to perform soft proofing using ColorSync before printing.



- You need to set each correction on the printer driver.
- Note ColorSync needs to be selected in the Color Matching panel of the driver in order to select ColorSync.

Matching Method

You can select a matching method to suit the print job.

Gamma

You can adjust the gradation of intermediate tones in an image. **2.2** is normally selected. If you want a softer impression than **2.2**, select **1.8**.



• You can select only after **Driver Matching Mode** has been selected in **Matching Mode**.

• Input Profile

Select the input profile.



You can select only after ICC Matching Mode has been selected in Matching Mode.

Printer Profile

Select the printer profile.



• You can select only after ICC Matching Mode has been selected in Matching Mode.

Soft Proof

When you place a checkmark here, ColorSync applies to the preview area.



• You can select only after **ColorSync** has been selected in **Matching Mode**.

Driver Matching Mode

Under Matching Mode, select Driver Matching Mode.




Click the Matching Method list, and then select a setting.

Setting	Details
Auto	Automatically selects the best color matching method for each Image, Graphics, Text.
Perceptual	Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software.
Saturation	Color-matching optimized for printing posters, etc., vividly.
Colorimetric	Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric.

ICC Matching Mode

1 Under Matching Mode, select ICC Matching Mode.



Click the **Matching Method** list, and then select a setting.

Setting	Details
Perceptual	Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software.
Saturation	Color-matching optimized for printing posters, etc., vividly.
Colorimetric	Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric.
Colorimetric (No White-Point Correction)	The processing method of color-matching is identical to Colorimetric . Use this when you want to further reproduce the target paper material color of the image data. Generally, this also is called absolute colorimetric.


- 3 Click the **Input Profile** list and select an input profile.
- 4 Click the **Printer Profile** list and select a printer profile.

ColorSync

283

ColorSync

1 Check that ColorSync is selected in Matching Mode.



To apply ColorSync to previews, check the Soft Proof check box.

Preferences Dialog Box

This dialog box appears when you select **Preferences** from the **imagePROGRAF Advanced Preview** menu. You can set the preferences for Preview.




Units

Set the unit for paper length, margins, and so on.

Zoom Dialog Box

This dialog box appears when you select **Zoom** from the **View** menu. You can enlarge or reduce the screen display.



Scaling


Set the magnification for enlargement or reduction of the screen display.



- You can input between 10 and 400.
- You can change the numbers by clicking ▼ button.

Go to Page Dialog Box

This dialog box appears when you select Go to Page from the View menu.





You can not select Go to Page if the document is only one page.

Page

Input the page number in numerical characters to display in the preview area.




• You can change the numbers in the range of the page of the documents.

Print with No Borders

You can use the borderless printing function to print without margins surrounding the image.

- With some media borderless printing can be performed only between two edges.
- Note To use the borderless printing function, the specified media must be set to the printer.
- 1 On the Paper Settings Panel →P.272 , select Roll Paper in Paper Source.
- On the Output Settings Panel >P.275 , click the Enlarged/Reduced Printing check box on.
- 3 Select Fit Roll Paper Width.
- 4 Click the **Borderless Printing** check box on.



284

5 Click the **Print** button.

Borderless printing begins.


Print on the Center

You can print on the center of the media loaded in the printer.



• This is not displayed when a checkmark is placed in Borderless Printing.

On the Output Settings Panel →P.275 , click the Print Centered check box on.



Click the **Print** button.


Printing on the center begins.

Not Print Spaces at the Top/Bottom

You can save paper on not to feed roll paper for the empty spaces when the print data contains spaces at the top or bottom.



- This is not displayed when a checkmark is placed in Borderless Printing.
- 1 On the Paper Settings Panel →P.272 , select Roll Paper in Paper Source.
- On the Output Settings Panel →P.275 , click the No Spaces at Top or Bottom check box on.




3 Click the **Print** button.

Printing on the settings with no spaces at top or bottom begins.

Print Page Rotated 90 Degrees

You can save paper by printing in landscape orientation on roll paper.

- On the Paper Settings Panel Paper in Paper Source.
- On the Output Settings Panel >P.275 , click the Rotate Page check box on.
- Select Rotate Right 90 Degrees or Rotate Left 90 Degrees.




Click the **Print** button. Printing on rotating 90 degrees begins.

Display with Fitting to the Width of the Paper

In the preview area, you can display to the width of the paper.

- Select Fit to Width from the tool bar.
- Fitting to the width of the paper, it is displayed.




Display with All

286

In the preview area, you can display all.

Select Fit Screen from the tool bar.


All is displayed.



Display with Actual Size

In the preview area, you can display the actual size.

- 1 Select Actual Size from the tool bar.
- 2 Actual size is displayed.



Moving a Page


You can move a page to display in the preview area.

1 Select each button in **Go to Page** on the tool bar.

Setting	Details
	Go to the first page.
4	Go to the previous page.
D	Go to the next page.
	Go to the last page.

2

The target page appears.





• You can also move a page by clicking the page on the thumbnails.

Free Layout

The Features of Free Layout	289
Starting Free Layout	289
	200
Free Layout Main Window	
Paper Settings Panel	
Easy Settings	
Advanced Settings	
Color Settings Panel	
Color Adjustment	
Matching	
Driver Matching Mode	
ICC Matching Mode	
ColorSync	302
Preferences Dialog Box	302
Page Setup Dialog Box	
Zoom Dialog Box	
Format Dialog Box	
· · · · · · · · · · · · · · · · · · ·	
Laying out a Multiple-File Document on One Page	
Laying out a Document Created with Multiple Application Programs on One Page	
Selecting an Object	
Changing the Object Size	
Moving an Object	
Rotating an Object	
Laying out Objects Automatically	
Aligning Objects	
Changing the Object Overlapping Order	
Pasting a Copied or Cut Object	311

The Features of Free Layout

The main features of Free Layout are as follows.

- Allows you to lay out at will and print a document created with application software.
- You can not only lay out multiple pages on one page but also lay out and print a multiple-file document on one page, or lay out and print a document created with multiple application programs on one page.



 The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Free Layout settings.

Starting Free Layout

Follow the procedure below to start the Free Layout.


- 1 Start the apllication software which you use.
- From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



Normally, select Print from the File menu.

Click on Free Layout in the Page Setup panel to attach a checkmark.


4 Click the **Print** button in the **Print** dialog box.






· Your printer is depicted in the lower-left area of this screen.

5 Free Layout main window is displayed.



Free Layout Main Window

The Free Layout main window consists of the menu and tool bars, layout area and dialog areas.



290



iPF685

• You can use the View menu to show or hide the tool.

• Menu Bar

This allows you to select menus required for operations.

imagePROGRAF Advanced Preview File Edit View Object Window Help

Tool Bar

This allows you to select tool buttons required for major operations.



Layout Area


This allows you to lay out objects and edit the object size and orientation.



Paper Settings Panel iPF685


· Dialog Area

This allows you to set the print conditions and perform a print job.



Paper Settings Panel

This panel appears when you select Paper Settings in the dialog area.



292

Media Type

This allows you to select the media type.

Paper Settings Panel



Always select media type that is actually set in the printer. When the media you chose is different from the
media set in the printer, you may not receive the desired print results.

Easy Settings / Advanced Settings

Two modes are available to provide the optimum print settings for jobs.

The settings available on each mode are as follows.

- Easy Settings → P.294
- Advanced Settings → P.295

Paper Source

You can select the paper source.

The following settings are available for paper source.

Setting	Details
Manual	Select for manual paper feed printing.
Roll Paper	Select to print on roll paper.

Roll Paper Width

This selects the width of the roll media set to the printer.



• Available only if rolls are selected in **Paper Source**.

Copies

You can input the number of print copies in numerical characters.



- The maximum value is 999.
- You can change the numbers by clicking either ▲ button or ▼ button.

• Restore Defaults Button

Click the button to reset to the setting when starting Free Layout.

• Print Button

Click the button to begin printing.


• Update Printer Info. Button

Click the button to acquire printer information.

Easy Settings iPF685

Easy Settings

You can easily select the best settings for the print job by just selecting an item from the print target list that matches the content of the document.



Print Target

You can easily select the best settings for the print job simply.

If you select each Print Target item the corresponding comment for that item is displayed below the list.

Setting	Details
Default Settings	Suitable for printing normal documents that contain a mixture of text, photographs, and graphics.
Poster	The best setting for posters. Prints using vivid and high impact colors.
CAD (Color Line Drawing)	Suitable for printing fine lines such as drawings clearly.
CAD (B/W Line Drawing)	Suitable for printing CAD drawings with sharp, dark lines.
Perspective, GIS	Suitable for attractive printing of 3D-CAD drawings, perspective drawings, and GIS drawings including maps.
Photo (Color)	Suitable for printing photographic images captured with a digital camera.
Office Document	Suitable for printing handouts as well as general office documents for which print clarity is key.
Faithful Color Reproduction	Prints by minimizing color differences. Suitable for when the printing results are too vivid or when printing scanned images.
Custom Settings	Suitable for printing documents for which Advanced Settings have been specified.



The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.

Setting	Details
Print Quality	Highest quality / Highest / High / Standard / Fast

Advanced Settings


Details Setting Resolution 1200dpi / 600dpi / 300dpi



- The availability of settings is determined by the media type and print priority selections.
- Note Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
 - Printing time is shorter and less ink is consumed with Fast than with High, however, print quality is lower.
 - For Highest quality, the resolution is not displayed.

Advanced Settings

Presents detailed settings for the print priority, the print quality, and other items so you can select the values for these settings yourself.



Print Priority

Select a print quality mode that is appropriate for the print job.

Setting	Details
Image	This mode achieves the best results for printing photographic images and illustrations.
Line Drawing	This mode is best for printing CAD drawings with fine lines or wall newssheet or other documents that contain large amounts of text. However, you may not achieve the quality you expect with printing photographs or other images with many filled areas. For these types of jobs, select Image .
Office Document	Prints common office documents, such as proposals, memos for distribution, etc., so they are easy to read.



The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.


Setting	Details
Print Quality	Highest quality / Highest / High / Standard / Fast
Resolution	1200dpi / 600dpi / 300dpi



- The availability of settings is determined by the media type and print priority selections.
- Vote
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
 - Printing time is shorter and less ink is consumed with **Fast** than with **High**, however, print quality is lower.
 - · For Highest quality, the resolution is not displayed.

Color Settings Panel

This panel appears when you select **Color Settings** in the dialog area.



Color Mode

You can select a color mode to suit the print job.

Setting	Details
Color	Enables color printing.
Monochrome	Disables color printing and converts image from continuous color to grayscaled monochrome.
Color (CAD)	Prints lines in the best color possible so they are easy to see.
Monochrome Bitmap	Prints all colors other than white in black.
Monochrome (BK ink)	Select to print all lines with black ink.
No color correction	Prints without performing color matching in the printer driver. Select this when color matching is performed by the application such as Adobe Photoshop or when you want to print color charts using the profile creation tool.



The availability of settings depends on the print priority and media type selections.

297

Color Adjustment / Matching

You can set the color adjustment and matching.

- Color Adjustment → P.297
- Matching → P.299



• Matching is not displayed if No color correction has been selected in Color Mode.

• Restore Defaults Button

Click the button to reset to the setting when starting Free Layout.

• Print Button

Click the button to begin printing.

• Update Printer Info. Button

Click the button to acquire printer information.


Color Adjustment

You can set the color adjustment.

Adjusting Color

Normally colors should be adjusted in the software application, but if you see colors in the printout that do not match colors on the screen, you can perform color adjustments.

- 1 Select Color on Color Mode in the Color Settings panel.
- 2 Select Color Adjustment.



3 Drag each slider to the left or right to adjust.

Setting	Details
Cyan	Adjusts the strength of colors to compensate the hues.
Magenta	Adjusts the strength of colors to compensate the hues.
Yellow	Adjusts the strength of colors to compensate the hues.

Setting	Details
Brightness	Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature.
Contrast	Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast.
	<u> </u>
Saturation	Adjusts the hues for vivid color or dark color.
Gray Tone	Adjusts gray from cool black (bluish tones) to warm black (reddish tones).




• You can also click the up or down arrow, or enter the number directly to increase or decrease the value.

Adjusting Monochrome

Use the monochrome setting to print monochrome images of color photographs captured with a scanner or digital camera or other color images.

- 1 Select Monochrome on Color Mode in the Color Settings panel.
- 2 Select Color Adjustment.



3 Drag each slider to the left or right to adjust.

Setting	Details
Brightness	Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature.
Contrast	Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast.

299

Matching




• You can also click the up or down arrow, or enter the number directly to increase or decrease the value.

Matching

You can set the matching.



If No color correction is selected under Color Mode, the Matching is not displayed.



Matching Mode

You can select a matching mode to suit the print job.

Setting	Details
Driver Matching Mode →P.300	Enables printing of optimal color tones using a driver specific color profile. You should normally select this mode.
ICC Matching Mode →P.301	Enables color matching using ICC profiles. Select this if you want to print by specifying the input profile, printer profile, and matching method in detail. This allows you to use ICC profiles for digital cameras and scanners, ICC profiles created using the profile creation tool, etc.
ColorSync →P.302	Enables color matching by using the ColorSync function of OS X. Select this if you want to perform soft proofing using ColorSync before printing.



- You need to set each correction on the printer driver.
- Note ColorSync needs to be selected in the Color Matching panel of the driver in order to select ColorSync.

Matching Method

You can select a matching method to suit the print job.

Gamma

You can adjust the gradation of intermediate tones in an image. 2.2 is normally selected. If you want a softer impression than 2.2, select 1.8.



• You can select only after **Driver Matching Mode** has been selected in **Matching Mode**.

Input Profile

Select the input profile.



• You can select only after ICC Matching Mode has been selected in Matching Mode.

Printer Profile

Select the printer profile.



• You can select only after ICC Matching Mode has been selected in Matching Mode.

Soft Proof


When you place a checkmark here, ColorSync applies to the layout area.



• You can select only after **ColorSync** has been selected in **Matching Mode**.

Driver Matching Mode

Under Matching Mode, select Driver Matching Mode.




2 Click the **Matching Method** list, and then select a setting.

Setting	Details
Auto	Automatically selects the best color matching method for each Image, Graphics, Text.
Perceptual	Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software.
Saturation	Color-matching optimized for printing posters, etc., vividly.

Setting	Details
Colorimetric	Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric.

ICC Matching Mode

1 Under Matching Mode, select ICC Matching Mode.



2 Click the Matching Method list, and then select a setting.


Setting	Details
Perceptual	Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software.
Saturation	Color-matching optimized for printing posters, etc., vividly.
Colorimetric	Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric.
Colorimetric (No White-Point Correction)	The processing method of color-matching is identical to Colorimetric . Use this when you want to further reproduce the target paper material color of the image data. Generally, this also is called absolute colorimetric.

- 3 Click the **Input Profile** list and select an input profile.
- 4 Click the **Printer Profile** list and select a printer profile.

301

ColorSync


1 Check that ColorSync is selected in Matching Mode.



Place a checkmark on **Soft Proof** to simulate the output product in Layout Area.

Preferences Dialog Box

This dialog box appears when you select **Preferences** from the imagePROGRAF Advanced Preview menu. You can set the preferences for Free Layout.



Units

302

Set the unit for paper length, margins, and so on.

Gridlines

You can input a grid line width value in numerical characters so that they serve as a guide to laying out objects.



- You can input between 10.0 and 200.0(mm) (between 0.39 and 7.87(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

303

Divisions

You can change the number of divisions of grid lines so that they serve as a guide to laying out objects.



- You can input between 1 and 10.
- You can change the numbers by clicking either ▲ button or ▼ button.

Grid Color

Select the grid line color.

Print Object Frames

You can print the object border.



If you do not want to print the object border, deselect the Print Object Frames check box.

Object Frame Style

You can select the object frame style for printing.

The following settings are available for the object frame style.

Setting	Details
Solid Line	You can print the solid line as the frame style.
Dotted Line	You can print the dotted line as the frame style.
Dashed Line	You can print the dashed line as the frame style.

Auto Arrange Spacing


Change the object-to-object spacing to be applied in the operation of laying out objects automatically.



- You can input between 0.0 and 100.0(mm) (between 0.00 and 3.94(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Page Setup Dialog Box

This dialog box appears when you select **Page Setup** from the **File** menu. This dialog box provides selections for setting the media size, orientation and other important features.



Paper Orientation

This selects the paper orientation.

The following settings are available for orientation.

Setting	Details
Vertical	Prints the image and text created with the application software in the orientation as it is.
Horizontal	Prints the image and text by rotating sideways 90 degrees from the orientation as specified in the application.

Roll Paper Length

Set the length of one page to print on roll paper.

Zoom Dialog Box iPF685

When you place a checkmark on **Auto Settings**, the one-page length to be printed on roll paper is automatically set so that the laid-out objects are printed on one page.



- Available only if rolls are selected in **Paper Source**.
- You can input between 203.2 and 18000.0(mm) (between 8.00 and 708.66(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Order

Set the object layout order.

The following settings are available for order.

Setting	Details
Upper Left to Right	The objects are laid out from upper left to right.
Upper Left to Bottom	The objects are laid out from upper left to bottom.



- When you have selected Roll Paper Length > Auto Settings and Paper Orientation > Vertical, you can choose only Upper Left to Right.
- When you have selected Roll Paper Length > Auto Settings and Paper Orientation > Horizontal, you can choose only Upper Left to Bottom.

Paper Size


You can select the size of the print media.



You cannot display this if Roll Paper is selected in Paper Source.

Zoom Dialog Box

This dialog box appears when you select **Zoom** from the **View** menu. You can enlarge or reduce the screen display.



Scaling

Set the magnification for enlargement or reduction of the screen display.




- You can input between 10 and 400.
- You can change the numbers by clicking ▼ button.

Format Dialog Box

Format Dialog Box

This dialog box appears when you select **Format** from the **Object** menu after you select an object. You can rotate, enlarge, or reduce an object.





When the objects are not selected, you can not select Format.

Rotate

When you place a checkmark here, you can select Rotate Right or Rotate Left.

Setting	Details
Rotate Right	Rotates the object 90 degrees clockwise.
Rotate Left	Rotates the object 90 degrees counterclockwise.



When several objects are selected, you cannot select Rotate.

Scaling

You can input the value for enlargement or reduction of the obeject in numerical characters.



- You can input between 25 and 400.
- You can change the numbers by clicking either ▲ button or ▼ button.

Object Size

You can confirm the object size.



When several objects are selected, you cannot display Object Size.

Laying out a Multiple-File Document on One Page

You can lay out and print a multiple-file document on one page.

1 From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



Normally, select Print from the File menu.

- 2 Click on Free Layout in the Page Setup panel to attach a checkmark.
- In the **Print** dialog box, select the pages to print and the number of copies, and click the **Print** button. Free Layout starts, laying out the document created with application software in the layout area as an object.

4 Leaving Free Layout running, open other files with the application software and repeat the above steps.

Laying out a Document Created with Multiple Application Programs on One Page

You can lay out and print a document created with multiple application programs on one page.

From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



- Normally, select **Print** from the **File** menu.
- Click on Free Layout in the Page Setup panel to attach a checkmark.
- In the **Print** dialog box, select the pages to print and the number of copies, and click the **Print** button. Free Layout starts, laying out the document created with application software in the layout area as an object.
- 4 Leaving Free Layout running, open the files with other application software and repeat the above steps.

Selecting an Object

When an object is selected, a select box (blue border) appears around the object.





- To select an object, click that object.
- To select multiple successive objects, click them while holding down the shift key.
- To select multiple arbitrary objects, click them while holding down the command key.
- To select all objects, select Select All from the Edit menu.

Changing the Object Size

You can change the object size by means of mouse operation or by specifying a scaling value.




306

• The vertical-to-horizontal ratio remains unchanged when the object is enlarged or reduced.

Moving an Object

Resizing by means of mouse operation

- 1 Select an object.
- Place the pointer at a corner of the selection box around the object to show the arrow handle, and drag this handle to change the object size.



Resizing by specifying a scaling value

- 1 Select an object.
- 2 Open the Format Dialog Box →P.305.
- 3 Use **Scaling** to set the magnification for enlargement or reduction. You either enter numbers directly.




- You can input between 25 and 400.
- You can change the numbers by clicking either ▲ button or ▼ button.
- 4 Click the **OK** button.

Moving an Object

You can move the object position.

- 1 Select an object.
- Place the pointer inside the selection box of the object to show the crosshair handle, and drag it to move the object.




Rotating an Object

You can rotate the object.

1 Select an object.

307

Select Rotate Left or Rotate Right from the toolbar.
Alternatively, you may click on the Rotate check box in the Format Dialog Box P.305 then select Rotate Right or Rotate Left, and click the OK button.






When several objects are selected, you cannot select Rotate.

Laying out Objects Automatically

Click **Auto Arrange** in the tool bar. This automatically lays out objects. Alternatively, you may select **Auto Arrange Object** from the **Object** menu.






• The object layout order varies depending on the **Order** setting on the **Page Setup Dialog Box PR303**.

Aligning Objects

You can align objects systematically.


- 1 Select multiple objects.
- 2 Select the align menu from the **Object** menu.
 - Align Top
 Lays out the objects, justifying them to the top.



Aligning Objects


Center Vertically

Lays out the objects, justifying them to the vertical center




Align Bottom

Lays out the objects, justifying them to the bottom.




Align Left

Lays out the objects, justifying them to the left.




Center Horizontally

Lays out the objects, justifying them to the horizontal center.



Align Right

Lays out the objects, justifying them to the right.




Changing the Object Overlapping Order

You can change the object overlapping order.

- 1 Select an object.
- 2 Select the overlapping order menu from the **Object** menu.


Bring to Front

Moves the object to the frontmost position.




Send to Back

Moves the object to the backmost position.




Bring Forward

Moves the object one position to the front.



Send Backward

Moves the object one position to the back.



Pasting a Copied or Cut Object

- Click **Copy** or **Cut** from the toolbar.

 Alternatively, you may select **Copy** or **Cut** from the **Edit** menu.
- Click **Paste** from the toolbar.
 Alternatively, you may select **Paste** from the **Edit** menu.



• The copied or cut object is laid out at the end of the page.

Color imageRUNNER Enlargement Copy

The Features of Color imageRUNNER Enlargement Copy	
Color imageRUNNER Enlargement Copy Dialog Box	. 313
Hot Folder	. 313
Hot Folder Creating a New Hot Folder	. 314
Editing a Hot Folder (Setting Print Conditions)	. 315
Deleting a Hot Folder	. 317
Setting the Print Parameters	. 318
Paper Settings Panel	. 318
Easy Settings	. 319
Advanced Settings	. 320
Output Settings Panel	. 321
Color Settings Panel	
Driver Matching Mode	
ICC Matching Mode	. 324
Printing Enlargements of Scanned Originals from a Color imageRUNNER	325

The Features of Color imageRUNNER Enlargement Copy

The main features of Color imageRUNNER Enlargement Copy are as follows.

- Allows the document scanned with the Color imageRUNNER to be automatically enlarged and printed.
- You can perform basic printer settings such as printer selection, media type and output profile selection, and matching methods, in addition to borderless printing and enlargement/reduction process without growing through the printer driver.



 The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Color imageRUNNER Enlargement Copy settings.

Starting Color imageRUNNER Enlargement Copy


You can start the utility by clicking on the Color imageRUNNER Enlargement Copy.app icon in Applications > Canon Utilities > iR Enlargement Copy.



• If you are using OS X v10.7 and later, start it from Launchpad.

Color imageRUNNER Enlargement Copy Dialog Box

The explanation below is on the Color imageRUNNER Enlargement Copy dialog box.





 For the step to open the Color imageRUNNER Enlargement Copy dialog box, see "Starting Color imageRUN-NER Enlargement Copy." →P.312

· Delete files in the folder

From the Hot Folder list, select a hot folder and click the **Delete** button to delete only files in the hot folder.

• Delete the entire folder, as well as items in the list above

From the Hot Folder list, select a hot folder and click the **Delete** button to delete the hot folder.

• Delete Button

Select **Delete files in the folder** or **Delete the entire folder**, **as well as items in the list above** and click this button to delete the hot folder or only files in the hot folder.

• Add Button

Click the button to open the **Destination Selection** dialog box so that you can add a hot folder.

• Edit Button

From the Hot Folder list, select a hot folder and click this button to open the **Add/Edit Hot Folder** dialog box that allows you to edit the hot folder.

Monitor Hot Folder Constantly

If the check box is selected, the Hot Folder is monitored from after the next login.

Hot Folder

Hot folder refers to a folder used for Color imageRUNNER Enlargement Copy.

- When transferred to the PC's hot folder, the document data scanned with the Color imageRUNNER is printed in enlarged size from the printer according to the print conditions set in the hot folder.
- You can create a new hot folder, edit or delete an existing one, and set print conditions at will.




You can create up to 10 hot folders.

Creating a New Hot Folder iPF685

Creating a New Hot Folder


1 Open the Color imageRUNNER Enlargement Copy dialog box.






- For the step to open the Color imageRUNNER Enlargement Copy dialog box, see "Starting Color imageRUNNER Enlargement Copy."

 P.312
- Click the Add button in Enlarged Copy Settings to open the Destination Selection dialog box.




- From the printer list in **Destination**, select the printer of destination.
- Click the **OK** button to open the **Add/Edit Hot Folder** dialog box.



- 5 In **Name**, enter the name to display in the Hot Folder list.
- 6 In **Hot Folder**, enter the Hot Folder name.

7 Click the OK button. The created Hot Folder is listed in the Color imageRUNNER Enlargement Copy dialog box.



- 8 Click the Close button to close the Color imageRUNNER Enlargement Copy dialog box.
- 9 From the Apple Menu, open the Sharing dialog box for System Preferences.
- 10 For OS X v10.6:

Check the **File Sharing** checkbox and click the **Options** button.

Check the **Share files and folders using FTP** and **Share files and folders using SMB** checkboxes to configure the sharing.

For OS X v10.7 and later:

Check the File Sharing checkbox and click the Options button.


Check the **Share files and folders using SMB** checkbox to configure the sharing.



• You can create up to 10 hot folders.


Editing a Hot Folder (Setting Print Conditions)

1 Open the Color imageRUNNER Enlargement Copy dialog box.




- 2 Select the Hot Folder from the Hot Folder list.
- 3 From Enlarged Copy Settings, click Edit button to open the Add/Edit Hot Folder dialog box.

Make the necessary settings in the Paper Settings Panel →P.318).



Make the necessary settings in the Output Settings Panel →P.321 .



6

Make the necessary settings in the Color Settings Panel →P.323 .



- 7 Click the **OK** button to close the **Add/Edit Hot Folder** dialog box.
- From the Apple Menu, open the Sharing dialog box for System Preferences.
- **9** For OS X v10.6:

Check the File Sharing checkbox and click the Options button.

Check the **Share files and folders using FTP** and **Share files and folders using SMB** checkboxes to configure the sharing.

For OS X v10.7 and later:

Check the **File Sharing** checkbox and click the **Options** button.


Check the **Share files and folders using SMB** checkbox to configure the sharing.



 If you've made shared settings when you created a new Hot Folder, you do not need to execute steps 8 to 9.

Deleting a Hot Folder

1 Open the Color imageRUNNER Enlargement Copy dialog box.



2 Select the Hot Folder you want to delete from the Hot Folder list.

3 Select Delete the entire folder, as well as items in the list above, and then click the Delete button.



4 Read the messag,e and then click the **OK** button.




• Select **Delete files in the folder** to delete only files in the hot folder.

Setting the Print Parameters

You can set the print conditions in the setting panels within the **Add/Edit Hot Folder** dialog box. The settings available on each panel are as follows.

- Paper Settings Panel →P.318
- Output Settings Panel →P.321
- Color Settings Panel →P.323

Paper Settings Panel



Easy Settings / Advanced Settings

Two modes are available to provide the optimum print settings for jobs.

- The settings available on each mode are as follows.
 - Advanced Settings → P.320

Easy Settings →P.319

Media Type

318

This allows you to select the media type.



Always select media type that is actually set in the printer. When the media you chose is different from the
media set in the printer, you may not receive the desired print results.

Paper Source

You can select the paper source.

iPF685 Easy Settings

The following settings are available for paper source.

Setting	Details
Manual	Select for manual paper feed printing.
Roll Paper	Select to print on roll paper.

Roll Paper Width

This selects the width of the roll media set to the printer.



Available only if rolls are selected in Paper Source.

Automatic Cutting

You can set the printer to cut roll paper automatically or print a guideline for cutting.

The following settings are available for automatic cutting.

Setting	Details
Printer Default	The value set on the printer operation panel takes priority.
None	Each page is not cut after it is printed and printing continues without interruption.
Print Cut Guideline	A print cut guideline is printed after each page and printing continues without interruption.



· Available only if rolls are selected in Paper Source.

Copies


You can input the number of print copies in numerical characters.



- The maximum value is 999.
- You can change the numbers by clicking either ▲ button or ▼ button.

Easy Settings

You can easily select the best settings for the print job by just selecting an item from the print target list that matches the content of the document.



Print Target

You can easily select the best settings for the print job simply.

If you select each Print Target item the corresponding comment for that item is displayed below the list.

,	, ,
Setting	Details
Default Settings	Suitable for printing normal documents that contain a mixture of text, photographs, and graphics.
Office Document	Suitable for printing handouts as well as general office documents for which print clarity is key.
Poster	The best setting for posters. Prints using vivid and high impact colors.
CAD (Color Line Drawing)	Prints the fine lines of CAD drawings and other such documents sharp and clear.
CAD (B/W Line Drawing)	Suitable for printing CAD drawings with sharp, dark lines.
Perspective, GIS	Suitable for attractive printing of 3D-CAD drawings, perspective drawings, and GIS drawings including maps.
Photo (Color)	Suitable for printing photographic images captured with a digital camera.
Faithful Color Reproduction	Prints by faithfully reproducing the colors of the original image.
Custom Settings	Suitable for printing documents for which Advanced Settings have been specified.



• The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.


Setting	Details
Print Quality	Highest / High / Standard / Fast
Resolution	1200dpi / 600dpi / 300dpi



- The availability of settings is determined by the media type and print priority selections.
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
- Printing time is shorter and less ink is consumed with **Fast** than with **High**, however, print quality is lower.

Advanced Settings

Presents detailed settings for the print priority, the print quality, and other items so you can select the values for these settings yourself.



Print Priority

Select a print quality mode that is appropriate for the print job.

Setting	Details
Image	This mode achieves the best results for printing photographic images and illustrations.
Line Drawing	This mode is best for printing CAD drawings with fine lines or wall newssheet or other documents that contain large amounts of text. However, you may not achieve the quality you expect with printing photographs or other images with many filled areas. For these types of jobs, select Image .
Office Document	Prints common office documents, such as proposals, memos for distribution, etc., so they are easy to read.



• The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.


The level of the print quality and resolution settings are displayed in the following combinations.

Setting	Details
Print Quality	Highest / High / Standard / Fast
Resolution	1200dpi / 600dpi / 300dpi



- The availability of settings is determined by the media type and print priority selections.
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
- Printing time is shorter and less ink is consumed with Fast than with High, however, print quality is lower.

Output Settings Panel



Enlarged/Reduced Printing

Select the method for enlarged/reduced printing.

The following settings are available for enlarged/reduced printing.

Setting	Details
Fit Paper Size	Enlarges/reduces the whole page automatically to fit the media size selected for output. Select the media size to print from Paper Size .
Fit Roll Paper Width	Enlarges/reduces the whole page automatically to fit the width of the roll paper with the page width.

321

Setting	Details
Fit Roll Paper Width	*Make sure that the width of the roll paper in the printer is set correctly for Roll Paper Width in the Paper Settings panel. *Displayed only if rolls are selected in Paper Source .
Scaling	Enlarges/reduces the whole page by the scaling rate as specified. Input the scaling value in numerical characters. You can specify a range between 5 and 600%.
	*You can change the numbers by clicking either ▲ button or ▼ button. *Although Scaling can be set to make the image larger than the media size, the part that does not fit in the media cannot be printed. *This is not displayed when a checkmark is placed in Borderless Printing.

Borderless Printing

You can print the media without margins on all sides when the roll paper with the specific width and the specific media type is used.



Available only if rolls are selected in Paper Source.

Paper Size

You can select the size of the print media.



This is not displayed when Fit Roll Paper Width is set in Enlarged/Reduced Printing.

Print Centered

Select this feature to print the image in the center of a cut sheet or to print left and right margins evenly from the edges of roll paper.



This feature is useful when you print the document enlarged or reduced with Scaling as well. When an image
is scaled, it is always enlarged or reduced in reference to a starting point in the upper left corner of the page.
If the image is reduced, the bottom and right margins are enlarged and the top and left margins remain unchanged. At that point, you can set all margins evenly with this feature.

No Spaces at Top or Bottom

You can set the printer to print without any empty area when the print data contains empty area at the top or bottom. Since the printer does not feed paper over the empty area, you can save paper.



Available only if rolls are selected in Paper Source.

Rotate Page

Select the method for rotating page.

The following settings are available for rotating page.

Setting	Details
Rotate Right 90 Degrees	Rotates the portrait page right 90 degrees and print in landscape orientation. When the rotated page can fit in the width of roll paper, the page is rotated automatically, and when it can not fit in the width of roll paper, the page is not rotated.
	*When Fit Roll Paper Width is selected under Enlarged/Reduced Printing , then the image is enlarged or reduced after rotating to fit the width of the roll paper.
Rotate Left 90 Degrees	Rotates the portrait page left 90 degrees and print in landscape orientation. When the rotated page can fit in the width of roll paper, the page is rotated automatically, and when it can not fit in the width of roll paper, the page is not rotated.
	*When Fit Roll Paper Width is selected under Enlarged/Reduced Printing , then the image is enlarged or reduced after rotating to fit the width of the roll paper.
Rotate 180 degrees	Allows you to rotate the image 180 degrees from the vertical to the right.




Available only if rolls are selected in Paper Source.

• Output Method Button

Click the button to open the **Output Method** dialog box. In this dialog box, you can specify the object output method.

Color Settings Panel



Color Mode

You can select a color mode to suit the print job.

, ,	
Setting	Details
Color	Enables color printing.
Monochrome	Disables color printing and converts image from continuous color to grayscaled monochrome.
Color (CAD)	Prints lines in the best color possible so they are easy to see.
Monochrome Bitmap	Prints all colors other than white in black.
Monochrome (BK ink)	Select to print all lines with black ink.



• The availability of settings depends on the print priority and media type selections.

Matching Mode

Under Matching Mode, select the matching mode.

Setting	Details
Driver Matching Mode →P.324	Enables printing of optimal color tones using a driver specific color profile. You should normally select this mode.
ICC Matching Mode →P.324	Enables color matching using ICC profiles. Select this if you want to print by specifying the input profile, printer profile, and matching method in detail. This allows you to use ICC profiles for digital cameras and scanners, ICC profiles created using the profile creation tool, etc.
No Correction	No color matching is performed. Select this option when you want to perform color matching in the software application.

Driver Matching Mode

1 Under Matching Mode, select Driver Matching Mode.



2 Click Matching Method list, and then select a setting.

Setting	Details
Auto	Automatically selects the best color matching method for each Image, Graphics, Text.
Perceptual	Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software.
Saturation	Color-matching optimized for printing posters, etc., vividly.
Colorimetric	Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric.

ICC Matching Mode

1 Under Matching Mode, select ICC Matching Mode.



Click Matching Method list, and then select a setting.

Setting	Details
Perceptual	Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software.
Saturation	Color-matching optimized for printing posters, etc., vividly.
Colorimetric	Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric.
Colorimetric (No White-Point Correction)	The processing method of color-matching is identical to Colorimetric . Use this when you want to further reproduce the target paper material color of the image data. Generally, this also is called absolute colorimetric.

3 Click the **Input Profile** list, and then select an input profile.



- To match the color on the printing, select the input profile for Color imageRUNNER Enlargement Copy of the Color imageRUNNER type in use.
- 4 Click the **Printer Profile** list, and then select a printer profile.

Printing Enlargements of Scanned Originals from a Color imageRUNNER

Scanned originals from a Color imageRUNNER can be enlarged and printed automatically.

Originals you create by scanning with a Color imageRUNNER are transferred to a "hot folder" and printed automatically after enlargement according to printing conditions you specify for that folder.

This processing sequence is called the **Color imageRUNNER Enlargement Copy** function.

To use Color imageRUNNER Enlargement Copy, first complete these settings in the following order.

- 1. Register a hot folder on your computer.

 Register a hot folder on your computer for storing scanned originals from the Color imageRUNNER and complete the settings for enlargement copy. For details, see "Creating a New Hot Folder." >P.314
- Complete the scanning settings on the Color imageRUNNER.Configure the Color imageRUNNER to send scanned originals to the hot folder.

After these settings are complete, you can print enlarged copies of scanned originals from the Color imageRUNNER.

Completing the scanning settings on the Color imageRUNNER.

Configure the Color imageRUNNER to send scanned originals to the hot folder. It is easy to send scanned originals to the hot folder if you assign the scanning settings and destination to a **Favorites** button on the Color imageRUNNER.

For instructions on assigning scanning and sending settings to the **Favorites** button, refer to the Color imageRUNNER manual.

Scanning the original and print an enlargement

Follow the steps below to scan an original on the Color imageRUNNER for enlarged printing on the printer. For detailed instructions, refer to the Color imageRUNNER manual.

- 1 Load the original on the platen glass or document feeder of the Color imageRUNNER.
- Press **Send** to display the screen for transmission.
- Press **Favorites**, and then press the **Favorites** button assigned to the hot folder.



Press **Start** on the control panel. If you scan originals on the platen glass, after scanning all originals, press **Done** on the touch-panel display.

Scanned originals are sent to the hot folder and automatically enlarged and printed following the conditions you specified for the folder.

Poins Enige

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249

Handling and Use of Paper

Paper	328
Handling rolls	338
Handling sheets	359
Output Stacker	365
Media Configuration Tool (Windows)	370
Media Configuration Tool (Mac OS)	383

Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

Types of Paper iPF685

Paper

Types of Paper	. 328
Using Paper Other Than Genuine Paper and feed confirmed Paper Printing on Paper Other Than Genuine Paper and feed confirmed Paper Using Existing Settings	
Displaying the Paper Reference Guide	

Types of Paper

The following types of paper are supported by the printer. For details on the paper supported by the printer, refer to the **Paper Reference Guide**. (See "**Displaying the Paper Reference Guide**.") >P.331

- · Plain Paper
- Coated Paper
- Photo Paper
- Glossy Paper
- · Proofing Paper
- · CAD-dedicated Paper Etc.

The following content is described in the Paper Reference Guide.

- · Types of paper
- Paper handling
- · Paper product specifications
- Use precautions
- · Setting of printer driver, control panel etc.

• Paper Reference Guide display method

You can display the **Paper Reference Guide** from [imagePROGRAF Support Information]. (See "**Displaying** the **Paper Reference Guide**.") →P.331

1. Method of Updating Supported Paper

Photo Paper

To use newly released paper, register the latest paper information on the printer with the Media Configuration Tool. (See "Updating paper information.") >P.334



 To install the Paper Reference Guide and register paper types applicable to your region on your printer even when not using the printer driver, install the Media Configuration Tool.

(See "Media Configuration Tool (Windows).") →P.370

(See "Media Configuration Tool (Mac OS).") →P.383

Paper Sizes

Rolls

Rolls that meet the following conditions are supported.

- Outer diameter: Up to 150 mm (6 in)
- Inner diameter of paper core: 2 or 3 inches
- · Printing side out

Roll Width	Roll Paper Width Setting in Printer Driver (*1)	Borderless Printing (*1)
609.6 mm (24.00 in)	24-in. Roll (609.6mm)	Yes
594.0 mm (23.39 in)	ISO A1/A2 Roll (594.0mm)	Yes
515.0 mm (20.28 in)	JIS B2/B3 Roll (515.0mm)	Yes

iPF685 Paper Sizes

Roll Width	Roll Paper Width Setting in Printer Driver (*1)	Borderless Printing (*1)
431.8 mm (17.00 in)	17-in. Roll (431.8mm)	Yes
420.0 mm (16.54 in)	ISO A2/A3 Roll (420.0mm)	Yes
406.4 mm (16.00 in)	16-in. Roll (406.4mm)	No
355.6 mm (14.00 in)	14-in. Roll (355.6mm)	Yes
300.0 mm (11.81 in)	300mm Roll (300.0mm)	Yes
297.0 mm (11.69 in)	ISO A3/A4 Roll (297.0mm)	Yes
257.0 mm (10.12 in)	JIS B4 Roll (257.0mm)	Yes
254.0 mm (10.00 in)	10-in. Roll (254.0mm)	Yes

^{*1:} For information on types of paper compatible with borderless printing, refer to the **Paper Reference Guide**. (See "Types of Paper.") →P328

Sheets

Sheets of the following sizes are supported.

Paper Sizes	Dimensions
ISO A1	594.0 × 841.0 mm (23.39 × 33.11 in)
ISO A2+	431.8 × 609.6 mm (17.00 × 24.00 in)
ISO A2	420.0 × 594.0 mm (16.54 × 23.39 in)
ISO A3+	329.0 × 483.0 mm (12.95 × 19.02 in)
ISO A3	297.0 × 420.0 mm (11.69 × 16.54 in)
ISO A4	210.0 × 297.0 mm (8.27 × 11.69 in)
ISO B2	500.0 × 707.0 mm (19.69 × 27.83 in)
ISO B3	353.0 × 500.0 mm (13.90 × 19.69 in)
ISO B4	250.0 × 353.0 mm (9.84 × 13.90 in)
JIS B2	515.0 × 728.0 mm (20.28 × 28.66 in)
JIS B3	364.0 × 515.0 mm (14.33 × 20.28 in)
JIS B4	257.0 × 364.0 mm (10.12 × 14.33 in)
22"x34"(ANSI D)	558.8 × 863.6 mm (22.00 × 34.00 in)
17"x22"(ANSI C)	431.8 × 558.8 mm (17.00 × 22.00 in)
11"x17"(Ledger)	279.4 × 431.8 mm (11.00 × 17.00 in)
13"x19"(Super B)	330.2 × 482.6 mm (13.00 × 19.00 in)
Letter(8.5"x11")	215.9 × 279.4 mm (8.50 × 11.00 in)
Legal(8.5"x14")	215.9 × 355.6 mm (8.50 × 14.00 in)
24"x36"(ARCH D)	609.6 × 914.4 mm (24.00 × 36.00 in)
18"x24"(ARCH C)	457.2 × 609.6 mm (18.00 × 24.00 in)
12"x18"(ARCH B)	304.8 × 457.2 mm (12.00 × 18.00 in)
9"x12"(ARCH A)	228.6 × 304.8 mm (9.00 × 12.00 in)
DIN C2	458.0 × 648.0 mm (18.03 × 25.51 in)
DIN C3	324.0 × 458.0 mm (12.76 × 18.03 in)
DIN C4	229.0 × 324.0 mm (9.02 × 12.76 in)
20"x24"	508.0 × 609.6 mm (20.00 × 24.00 in)
18"x22"	457.2 × 558.8 mm (18.00 × 22.00 in)
14"x17"	355.6 × 431.8 mm (14.00 × 17.00 in)
12"x16"	304.8 × 406.4 mm (12.00 × 16.00 in)
10"x12"	254.0 × 304.8 mm (10.00 × 12.00 in)
10"x15"	254.0 × 381.0 mm (10.00 × 15.00 in)
US Photo 16"x20"	406.4 × 508.0 mm (16.00 × 20.00 in)

Paper Sizes	Dimensions	
Poster 20"x30"	508.0 × 762.0 mm (20.00 × 30.00 in)	
13"x22"	329.0 × 558.0 mm (12.95 × 21.97 in)	
Poster 300x900mm	300.0 × 900.0 mm (11.81 × 35.43 in)	
Custom Paper Size	203.2 x 279.0 mm (8.00 x 10.98 in) to 610.0 x 1600.0 mm (24.02 x 62.99 in)	



- For details on non-standard Custom Paper Size, see "Printing on Non-Standard Paper Sizes." >P.95
- Borderless printing is not supported on sheets.

Using Paper Other Than Genuine Paper and feed confirmed Paper

When using this printer to print on paper other than genuine Canon paper and feed confirmed paper, use paper that meets the following conditions.



- Refer to Paper Reference Guide for details on genuine Canon paper and feed confirmed paper. (See "Displaying the Paper Reference Guide.") >P.331
- Paper where the size is described in "Paper Sizes" (See "Paper Sizes.") →P.328
- Paper where the thickness is described in "Paper Thickness" in "Specifications" (See "Specifications.") → P.622
- · Paper where bleeding and ink overflow does not occur when printing
- · Paper that does not warp severely when loading the paper or printing



• If you use paper other than genuine Canon paper and feed confirmed paper, Canon provides absolutely no guarantees regarding print quality or paper feed properties. Refer to **Paper Reference Guide** for details on genuine Canon paper and feed confirmed paper. (See "**Displaying the Paper Reference Guide**.") >P.331

Load paper in the printer and then select the paper type in the control panel and printer driver and print.

You can print easily by selecting from existing settings provided in the printer control panel and printer driver. (See "Printing on Paper Other Than Genuine Paper and feed confirmed Paper Using Existing Settings.")
P.330

Printing on Paper Other Than Genuine Paper and feed confirmed Paper Using Existing Settings

You can easily print on paper other than genuine Canon paper and feed confirmed paper without making complicated settings by selecting existing settings provided in the printer control panel and printer driver depending on the media type you are using. The existing settings consist of general-purpose paper settings provided for each media type and special settings that allow you to select the amount of ink to use.



The genuine Canon paper settings provided in the printer control panel and printer driver are optimized for genuine Canon paper. If these settings are selected for printing on paper other than genuine Canon paper, the ink may bleed or the printhead may rub against the paper. In order to easily print on paper other than genuine Canon paper and feed confirmed paper, we recommend that you select one of the following general-purpose paper settings or special settings.



- For an overview of the media types, see "Types of Paper." → P.328
- For details on how to select the media type in the control panel and printer driver, see "Types of Paper." >P.328

Choosing General-Purpose Paper Settings

Since these settings anticipate a wide variety of paper other than genuine Canon paper and feed confirmed paper, these settings will make it difficult for bleeding ink and the printhead rubbing to occur. Refer to the following table for the relationships between the conditions of the paper other than genuine Canon paper and feed confirmed paper and the media type to select.

Type	Approximate weight	Approximate thickness	Printer control panel	Printer driver
Plain Paper	70 g/m²	0.09 mm (0.0035 in.)	Plain Paper	Plain Paper
Coated Paper	90 g/m²	0.13 mm (0.0051 in.)	LW. Coated Paper	Lightweight Coated Paper

330

Туре	Approximate weight	Approximate thickness	Printer control panel	Printer driver
Coated Paper	170 g/m²	0.22 mm (0.0087 in.)	HW. Coated Paper	Heavyweight Coated Paper
Photo Paper	180 g/m²	0.18 mm (0.0071 in.)	LW. Photo Paper	Lightweight Photo Paper
			LWPhotoPaper(LI)(*1)	Lightweight Photo Paper (LowInk)(*1)
	260 g/m²	0.26 mm (0.010 in.)	HW. Photo Paper	Heavyweight Photo Paper
			HWPhotoPaper(LI)(*1)	Heavyweight Photo Paper (LowInk)(*1)
Proof	80 g/m²	0.10 mm (0.0039 in.)	News Proof	(*2)
Sign/CAD Paper	150 g/m²	0.11 mm (0.0043 in.)	CAD Clear Film	CAD Clear Film
	90 g/m²	0.08mm (0.0031 in.)	CAD Trce(LowInk)	CAD Tracing Paper (Low Ink)
	100 g/m²	0.13 mm (0.0051 in.)	Syn.Papr(LowInk)	Synthetic Paper (LowInk)

^{*1:} Print using slightly less ink. Try this if you are concerned about rubbing of ink after printing.

Selecting Special Settings

Special settings are provided that allow you to select the amount of ink used in steps. You can fix lackluster colors or bleeding ink by selecting special settings where the amount of ink used is suitable for the paper you are using. "Special 1" uses the least amount of ink, with the amount of ink used increasing through 5 steps as the number increases up to "Special 5" which uses the greatest amount of ink. Although colors become more vivid as the amount of ink used increases, bleeding also occurs more easily. We recommend that you try in order starting from "Special 1" while checking the state of the printing.


Displaying the Paper Reference Guide

The **Paper Reference Guide** are not included. To view, display the **Paper Reference Guide** on the website from the links in the installed software. An Internet connection is required in order to view them.

Windows


The basic instructions for displaying the Paper Reference Guide from the printer driver are as follows.

- Open the printer driver.
 (See "Accessing the Printer Driver Dialog Box from Applications (Windows).") →P.148
 (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows).") →P.149
- Select the Support sheet and click the User Manual button.



^{*2:} Software RIP is required separately.

3. Click Paper Reference Guide.




Mac OS

The basic instructions for displaying the **Paper Reference Guide** from the imagePROGRAF Printmonitor are as follows.


1. Click the System Preferences icon in the Dock.




 Click Print & Scan. (This is identified as Printers & Scanners or Print & Fax in other versions of Mac OS X.)




Select the printer from the list of printers and click Options & Supplies.




4. Click Utility.



5. Click Open Printer Utility.



6. Click Support.



333

7. Click the User Manual button.



8. Click Paper Reference Guide.



Updating paper information

As for paper information of the printer Control Panel and printer driver, you can update it to the latest information by downloading and installing the latest version of **Media Information File** from the imagePROGRAF website. The latest **Media Information File** can be downloaded by accessing the imagePROGRAF website from the links in the software installed on your computer. Contact your Canon dealer if you are unable to download it. For details on **Media Information File** (Media Information File), refer as follows.

- Media Configuration Tool (Windows) →P.370
- Media Configuration Tool (Mac OS) → P.383



When your version of Media Configuration Tool is older than the version released on the imagePROGRAF
website, download and install the latest version of Media Configuration Tool before installing Media Information File. If you do not install the latest version of Media Configuration Tool before installing Media Information File, the latest paper information cannot be updated.


Windows

The basic instructions for accessing the dedicated website from the printer driver are as follows.

Open the printer driver.
 (See "Accessing the Printer Driver Dialog Box from Applications (Windows).") →P.148
 (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows).") →P.149

2. Select the **Support** sheet and click the **Support Information** button.

The default browser on your computer is started and the imagePROGRAF webpage is displayed.



Mac OS

The basic instructions for accessing the dedicated website from the imagePROGRAF Printmonitor are as follows.


1. Click the **System Preferences** icon in the **Dock**.



2. Click Print & Scan. (This is identified as Printers & Scanners or Print & Fax in other versions of Mac OS X.)




Select the printer from the list of printers and click Options & Supplies.





4. Click Utility.

5. Click Open Printer Utility.










7. Click the **Support Information** button.

The default browser on your computer is started and the imagePROGRAF webpage is displayed.



Handling rolls

Attaching the Roll Holder to Rolls	338
Changing the Type of Paper	343
Removing the Roll from the Printer	345
→ Clearing Jammed Roll Paper→ Clearing Jammed Paper (Paper Feed Slot)	
Feeding Roll Paper Manually	. 350
Specifying the Cutting Method for Rolls Cutting the Leading Edge of Roll Paper Automatically Reducing Dust from Cutting Rolls	356
Roll Holder Set	. 445

Attaching the Roll Holder to Rolls

When printing on rolls, attach the Roll Holder to the roll.

Rolls have a two- or three-inch paper core. Use the correct attachment for the paper core. The printer comes equipped with the 2-Inch Paper Core Attachment installed.

Using Rolls with a 2-Inc	oh Danor Coro	Lleing Bollo with a	2 Inch Daner Core	
Using Rolls With a 2-life	Cil Paper Core	Using Rolls with a 3-Inch Paper Core		
Holder Stopper (Left Side)	Roll Holder (Right Side)	Holder Stopper (Left Side)	Roll Holder (Right Side)	
2-Inch Paper Core Attachment	No Attachment Needed	3-Inch Paper Core Attachment L	3-Inch Paper Core Attachment R	



Set the roll on a table or other flat surface so that it does not roll or fall. Rolls are heavy, and dropping a roll may
cause injury.




- When handling the roll, be careful not to soil the printing surface. This may affect the printing quality. We recommend wearing clean cloth gloves when handling rolls to protect the printing surface.
- Use scissors or a cutting tool to cut the edge of the roll paper if it is uneven, dirty, or has tape residue. Otherwise,
 it may cause feeding problems and affect the printing quality. Be careful not to cut through any barcodes printed
 on the roll.
- Align the edges of the paper on both ends of the roll. Misalignment may cause feeding problems.








- For details on supported sizes and types of rolls, see Paper Sizes or the Paper Reference Guide. (See "Paper Sizes.") →P.328 (See "Displaying the Paper Reference Guide.") →P.331
- To view instructions as you attach the Roll Holder, press the **Navigate** button. (See "How to View Instructions with Navigate.") >P.406
- Lift the Holder Stopper lever (a) from the shaft side to unlock it. Holding the Holder Stopper at the position indicated (b), remove it from the Roll Holder.




- 2 Insert the respective attachments for the roll paper core on the Roll Holder and Holder Stopper.
 - Using rolls with a 2-inch paper core

Holder Stopper (Left Side)	Roll Holder (Right Side)
Align the tips (a) of the 2-Inch Paper Core Attachment with the holes (b) of the Holder Stopper and insert it firmly.	No attachment is needed.


• Using rolls with a 3-inch paper core



With the edge of the roll paper facing forward as shown, insert the Roll Holder from the right of the roll. Insert it firmly until the roll touches the flange (a) of the Roll Holder, leaving no gap.



Insert the Holder Stopper from the left in the Roll Holder as shown. Holding it at the position shown (b), push it firmly in until the flange (a) of the Holder Stopper touches the roll. Lock the Holder Stopper lever (c) by pushing it down toward the shaft side.



iPF685 Loading Rolls in the Printer

Loading Rolls in the Printer

Follow these steps to load rolls in the printer.




- Before loading rolls, make sure the printer is clean inside the Top Cover and around the Ejection Guide. If these areas are dirty, we recommend cleaning them in advance. (See "Cleaning Inside the Top Cover.") >P.560
- Press the Load button.




Press ▲ or ▼ to select "Load Roll Paper", and then press the OK button.




- If any paper has been advanced that will not be used, a message is shown requesting you to remove it. Press ▲ or ▼ to select **Yes**, and then press the **OK** button. Remove the paper and go to the next step.
- Positioning your hands as shown, open the Roll Cov-






At this time, position the holder so that the $\bf R$ label (c) on the [W label (c) on the Roll Holder flange is aligned with the $\bf R$ label (d) on the printer .




Holding the Roll Holder flange (a), guide the holder along the Roll Loading Slots (b) on both ends, keeping the holder level as you load it in the Roll Holder Slot.






- Do not force the Roll Holder into the printer with the right and left ends reversed. This may damage the printer and Roll Holder.
- Do not release the flanges until the holder is loaded in the Roll Holder Slot.
- Be careful not to pinch your fingers between the Roll Loading Slots (b) and the Roll Holder shaft (c) when loading rolls.
- Insert the edge of the roll in the Paper Feed Slot (a) and advance the roll until you hear the feed tone.





Be careful not to soil the printing surface of roll paper as you insert it in the slot. This may affect the
printing quality. We recommend wearing clean cloth gloves when handling rolls to protect the printing
surface.

- If the paper is wrinkled or warped, straighten it out before loading it.
- Load paper straight so it is not fed askew.





Once paper feeding starts, you will need to do the following, based on the ManageRemainRoll setting and the barcode printed on rolls. (See "Keeping Track of the Amount of Roll Paper Left.") P.350

ManageR- emainRoll	Barcodes	Printer Operation After the Paper is Fed
Off	Printed	A menu for selection of the type of paper is automatically shown on the Display Screen. Press ▲ or ▼ to select the type of paper, and then press the OK button.
	Not prin- ted	
On	Printed	The type and amount of paper left is automatically detected based on the barcode printed on the roll. There is no need to specify the type and length of the paper.
	Not prin- ted	A menu for selection of the paper type and length is automatically shown on the Display Screen. Press ▲ or ▼ to select the type and length of paper loaded, and then press the OK button.



• For details on types of paper to select, see the **Paper Reference Guide**. (See "**Displaying the Paper Reference Guide**.") → P.331







 Cut the edge of the roll after the paper is advanced if it is soiled or if there are cuts from scissors or the blade after removing creased edges. (See "Specifying the Cutting Method for Rolls.") >P.352

Changing the Type of Paper

Follow these steps to change the type of paper specified on the printer after you have loaded paper. If you will continue using this type of paper later, selecting **Keep Paper Type > On** will save the time and effort of configuring the media type setting when you load the paper again. The current media type settings before you select **On** will be automatically selected at that time. (See "Using the Same Type of Paper Regularly.") >P.344



- For best printing results, the printer fine-tunes the print head height and the feed amount for each type of paper. Be sure to select the type of paper to use correctly before printing.
- Because the printer fine-tunes the feed amount for each type of paper, the margins and the size of printed images may vary depending on the type of paper used. If margins and the size of images are not as you expected, adjust the paper feed amount.
 - (See "Adjusting the Feed Amount.") → P.529
- Rolls and sheets have different printing areas, and sheets having a larger bottom margin than rolls.
 (See "Print Area.") >P.623

Changing the Type of Paper



 When you load a roll, a menu for selection of the type of paper is shown on the Display Screen. Select the type of paper, and then press the OK button.

If no barcode has been printed on the roll and you have set **ManageRemainRoll** to **On**, specify the roll length after the type of paper. (See "Specifying the Paper Length.") > P.345

1 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Paper Menu** is displayed.
- Press ▲ or ▼ to select Chg. Paper Type, and then press the OK button.
- Press ▲ or ▼ to select the type of paper loaded (Roll Paper or Cut Sheet), and then press the OK button.
- 5 Press ▲ or ▼ to select the type of paper loaded in the printer, and then press the **OK** button.



 Be sure to select the correct paper type. If this setting does not match the loaded paper, it may cause feed errors and affect printing quality.



- For details on types of paper, see the **Paper Reference Guide**. (See "Types of Paper.") P.328 By default, Plain Paper is selected.
- If you move the Release Lever, the setting automatically reverts to the previously selected paper.

Using the Same Type of Paper Regularly

Configure this setting so that current media type settings will be automatically selected when you load the same type of paper later.

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Paper Menu** is displayed.
- Press ▲ or ▼ to select **Keep Paper Type**, and then press the **OK** button.
- 4 Press ▲ or ▼ to select **On**, and then press the **OK** button.



- The specified media type setting is updated in the following situations.
 - When using sheets, if you send a print job before loading a sheet, the media type setting is updated to match the type of paper specified by the print job.
 - When you have selected ManageRemainRoll > On on the Control Panel and a barcode is printed on the roll, the media type setting is updated to match the type of paper specified by the barcode.
- To change the media type setting, see "Changing the Type of Paper." →P.344

Specifying the Paper Length

When changing the length of paper after the paper has been advanced, specify the length as follows.



- Specify the paper length when you have set ManageRemainRoll to On. (See "Keeping Track of the Amount of Roll Paper Left.") →P350
- On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Paper Menu** is displayed.
- Press ▲ or ▼ to select **Chg. Paper Size**, and then press the **OK** button.
- 4 Press ▲ or ▼ to select Roll Length, and then press the OK button.
- Press ▲ or ▼ to select the length of paper loaded in the printer, and then press the **OK** button. Specify the roll length as follows.
 - Press the ◀ or ▶ button to move to the next field for input.
 - 2. Press the ▲ or ▼ button to enter the value.
 - 3. Repeat steps 1 and 2 to finish entering the value, and then press the **OK** button.

Removing the Roll from the Printer


Remove rolls from the printer as follows.



If you need to cut the roll, see "Specifying the Cutting Method for Rolls." →P.352

345

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (.).






- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button. The Paper Menu is displayed.
- Press ▲ or ▼ to select **Eject Paper**, and then press the **OK** button.
- 4 Press ▲ or ▼ to select **Yes**, and then press the **OK** button. The roll is now rewound and ejected.





er.

• If you have selected ManageRemainRoll > On in the Control Panel menu, a barcode is printed on the leading edge of the roll.


Do not remove the roll before the barcode is printed. You will be unable to keep track of the amount








6 Using both hands, rotate the Roll Holder toward the back to rewind the roll.




Holding the Roll Holder flange (a), remove the holder from the Roll Holder Slot.





- For instructions on removing the Roll Holder from rolls, see "Removing the Roll Holder from Rolls." →P.348
- 8 Holding it at the positions indicated, close the Roll Cover.







• To load new roll paper in the printer at this point, see "Loading Rolls in the Printer." →P.341

Removing the Roll Holder from Rolls


Lift the Holder Stopper lever (a) from the shaft side to unlock it. Holding the Holder Stopper at the position indicated (b), remove it from the Roll Holder.




2 Remove the Roll Holder from the roll.




- 3 When removing attachments, push the tips (a) in as you remove the attachment.
 - 3-Inch Paper Core Attachment R (Roll Holder side)



• 3-Inch Paper Core Attachment L (Holder Stopper side)



2-Inch Paper Core Attachment





 Store the roll in the original bag or box, away from high temperature, humidity, and direct sunlight. If paper is not stored properly, the printing surface may become scratched, which may affect the printing quality when you use it again.

Feeding Roll Paper Manually

After a roll has been advanced, you can press the **Feed** button to feed or retract the roll with the ▲ and ▼ buttons.



- 1 Press the Feed button.
- Press the ▲ or ▼ button to advance or retract the roll.


 Press ▲ to retract the roll manually.
 - Press ▼ to advance the roll manually.



If you hold down ▲ or ▼ for less than a second, the roll will move about 1 mm (0.04 in).
 If you hold down ▲ or ▼ for more than a second, the roll will move until you release the button. Release the button when the Display Screen indicates "End of paper feed. Cannot feed paper more.".

Keeping Track of the Amount of Roll Paper Left

Setting ManageRemainRoll to On in the Paper Menu of the Control Panel will print a barcode with text on the roll when the roll is removed that identifies the type of paper and amount left. When ManageRemainRoll is On and you load rolls with printed barcodes, the type of paper and amount left are automatically detected after rolls are loaded. The barcode will be cut off after it has been read.






If the barcode on the roll is not detected, enter the type and length of paper on the Control Panel.

Follow these steps to set ManageRemainRoll to On as follows.

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab ().





- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button. The **Paper Menu** is displayed.
- Press ▲ or ▼ to select ManageRemainRoll, and then press the OK button.
- Press ▲ or ▼ to select **On**, and then press the **OK** button.

Specifying the Ink Drying Time for Rolls

When you are using paper that takes longer for ink to adhere, ink may be transferred onto the paper surface during ejection, soiling it. In that case, you may be able to improve the condition by setting the time to wait for the ink to dry after printing.




- If the Cutter touches the print surface on which the ink is not dry, the paper surface may become scratched or soiled, or the paper surface may rub when the paper falls and the surface may become soiled. To wait for the ink to dry without allowing printed documents to fall after printing, set Cutting Mode on the menu of the printer to **Eject**. (See "Specifying the Cutting Method for Rolls.") →P.352
- The settings can also be made from the Control Panel on the printer. Select the type of paper from Paper Details in Paper Menu. (See "Menu Settings.") →P.418

Windows

350

Display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows).") →P.149 2 Select the Main sheet and click C Advanced Settings in A Media Type.




In the Paper Detailed Settings dialog box displayed next, select the desired settings values in B Between Pages and C Between Scans in A Drying Time, and then click OK.

(See "Paper Detailed Settings Dialog Box (Windows).") PP.154



Mac OS

- 1 Choose **Print** in the application menu.
- Select the Main pane and click C Settings in A Media Type.



351

OS).") → P.258

3

In the Paper Detailed Settings dialog box displayed next, select the desired settings values in C Between Pages and D Between Scans in B Drying Time, and then click OK.

(See "Paper Detailed Settings Dialog Box (Mac

Paper Detailed Settings Media Type: Plain Paper B Drying Time C Between Pages : Printer Default * D Between Scans : Printer Default + Roll Paper Margin for Safety F Near End Margin : Printer Default + G Cut Speed: Printer Default + H Automatic Cutting : Printer Default \$ J ⊳ী́ ☐ Mirror Revert Cancel

Specifying the Cutting Method for Rolls

How rolls are cut after ejection varies depending on printer settings.


Cutting Method		Printer	Printer Setting		er Setting
Automatic	The roll is automatically cut by the Cutter Unit following printer driver settings.	Media Menu >	Automatic	Automatic Cutting	Yes
Eject (wait- ing for ink to dry after printing)	Choose this setting if you prefer not to have documents dropped immediately after printing, as when waiting for ink to dry. To cut the roll with the Cutter Unit, press the Cut button.	Paper Details > (Various Types of Paper) > Cutting			Yes
Manual (when using media that cannot be cut with the Cutter Unit)	Choose this setting when using media that cannot be cut using the Cutter Unit. Cut each page from the roll using scissors. For continuous printing (if you will cut each page later), select Automatic Cutting > Yes or select Print Cut Guideline. (See "Cutting Roll Paper After Printing.") →P.137	Mode	Manual		No, Yes, Print Cut Guideline
Paper cut- ting (to have the roll cut at your speci- fied posi- tion)	Choose this option if you want to cut pages by pressing Cutter Unit buttons for manual cutting after printing when Automatic Cutting > No is selected or Print Cut Guideline is selected in the printer driver. Otherwise choose this option if you want to cut the roll edge after loading a roll.	Cut button pressed	Yes		No, Print Cut Guideline



- Automatic and Eject are valid only when you have selected **Automatic Cutting > Yes** in the printer driver.
- Note With Eject, printing does not resume after a series of jobs have been printed continuously until the roll is cut.
 - **Eject** is the preset selection in **Cutting Mode** for some types of paper. For this paper, we recommend keeping the preset cutting mode.


Cut rolls manually in the following cases:

Eject (waiting for ink to dry after printing)





- When cutting wide printed documents after ejection, have two people support the documents. If the paper drops, printed documents may be damaged.
- Do not lift the paper when holding printed documents before cutting. If the paper rises, it may affect the printing quality or cause rough cut edges.
- 1 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).






- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button. The **Paper Menu** is displayed.
- Press ▲ or ▼ to select Paper Details, and then press the OK button.
- 4 Press ▲ or ▼ to select the type of paper, and then press the **OK** button.
- 5 Press ▲ or ▼ to select **Cutting Mode**, and then press the **OK** button.
- 6 Press ▲ or ▼ to select **Eject**, and then press the **OK** button.
- 7 Starts printing.
 When printing is finished, the printer will stop without cutting.
- 8 Holding the printed document to prevent it from dropping, press the **Cut** button to cut the roll.



Manual (when using media that cannot be cut with the Cutter Unit)



On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).






- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button. The **Paper Menu** is displayed.
- 3 Press ▲ or ▼ to select Paper Details, and then press the OK button.
- Press ▲ or ▼ to select the type of paper, and then press the **OK** button.
- 5 Press ▲ or ▼ to select Cutting Mode, and then press the OK button.
- 6 Press ▲ or ▼ to select Manual, and then press the OK button.
- Starts printing.The printer stops advancing the paper after printing.
- 8 Press the Feed button.

Roll paper is fed to the specified cut position and then automatically stopped.



355

9 Cut the roll paper manually with scissors or the like.




10 Press the **OK** button.

After the roll is rewound, it stops automatically.



Paper cutting (to have the roll cut at your specified position)



- 1 Press the Feed button.
- Press the ▼ button to advance the roll to the position for cutting.



3 Press the **Cut** button.





Press ▲ or ▼ to select **Yes**, and then press the **OK** button. After the roll paper is cut, it is rewound automatically.



 If paper would be short when cut at a particular position, the roll may automatically be advanced in some cases before cutting.


Cutting the Leading Edge of Roll Paper Automatically

If the leading edge of the paper is cut crooked or is not cut straight when roll paper is loaded, it will not print correctly. If this happens, you can cut the leading edge of the paper straight when loading a paper roll by using **Trim Edge First** in the Control Panel menu.

Trim Edge First offers the following options.

Automatic

If the leading edge of the paper is cut crooked and is not cut straight when loading roll paper, cut the leading edge straight and eject the fragment of paper to prevent printing on the platen and soiling the printer.



• On (Preset Len)

The amount to cut from the leading edge of the paper varies depending on the media type, and is cut to a prescribed length. For more information on the prescribed length, see the leading edge precut length in the **Paper Reference Guide**. (See "Displaying the Paper Reference Guide.") >P.331

On(Input Length)

The amount to cut from the leading edge of paper is specified in the control panel. The amount to cut from the leading edge can be specified in the range of lengths displayed in the control panel. The range of lengths differs between each media type.



The amount to cut from the leading edge of paper cannot be set shorter than the length displayed in the control panel.

Manual

The amount to cut from the leading edge of the paper can be adjusted by pressing the ▲ and ▼ buttons. After making the adjustment, you can cut the paper by pressing the **Paper Cutting** button and selecting "**Cut paper**".

After the paper has been cut, press "Finish paper set".



If you do not press "Finish paper set" after cutting the paper, you will not be able to print again.


Off

The edge is not cut and scraps are not removed.

Follow these steps to change the **Trim Edge First** setting.

356

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).






- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Paper Menu** is displayed.
- Press ▲ or ▼ to select Paper Details, and then press the OK button.
- 4 Press ▲ or ▼ to select the type of paper, and then press the **OK** button.
- 5 Press ▲ or ▼ to select **Trim Edge First**, and then press the **OK** button.
- Press ▲ or ▼ to select the desired setting option, and then press the **OK** button. This setting takes effect the next time you load a roll.

Reducing Dust from Cutting Rolls

For media such as Backlit Film that are more likely to generate debris when cut, select **CutDustReduct**. > **On** in the **Paper Menu** of the Control Panel. This option reduces debris from cutting by printing black lines at the leading and trailing edges of documents. It may help prevent Printhead damage. You can specify for **CutDustReduct**. to be activated for particular types of paper.






- Do not set **CutDustReduct.** to **On** for paper that wrinkles easily, such as Plain Paper or lightweight paper. This may impair cutting and cause paper jams.
- Borderless printing is not available when CutDustReduct. is set to On. To use borderless printing, select Cut-DustReduct. > Off.

Set CutDustReduct. to On as follows.

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Paper Menu** is displayed.
- Press ▲ or ▼ to select Paper Details, and then press the OK button.
- 4 Press ▲ or ▼ to select the type of paper loaded in the printer, and then press the **OK** button.
- 5 Press ▲ or ▼ to select CutDustReduct., and then press the OK button.

357

6 Press ▲ or ▼ to select On, and then press the OK button.

358

Handling sheets

Loading Sheets in the Printer	359
Changing the Type of Paper Printing From a Desired Starting Point	
Removing Sheets	363
→ Clearing a Jammed Sheet→ Clearing Jammed Paper (Paper Feed Slot)	

Loading Sheets in the Printer

Follow these steps to load sheets in the printer.



- One sheet of paper can be loaded in the Paper Feed Slot at a time. Do not load more than one sheet at a time.
 This may cause paper jams.
- Before feeding paper or printing, make sure the sheet is flat against the Roll Cover. The sheet may jam if it curls before feeding or printing and the trailing edge drops toward the front.
- Paper that is wrinkled or warped may jam. If necessary, straighten the paper and reload it.
- Load the paper straight. Loading paper askew will cause an error. (See "Paper is crooked..") → P.607



- Store unused paper in the original package, away from high temperature, humidity, and direct sunlight.
- 1 Select sheets as the paper source.
 - If a print job was received
 Sheets are automatically selected, and the media type and size specified by the print job are shown on the Display Screen. Go to the next step.
 - If no print job was received
 - 1. Press the **Load** button.




2. Press ▲ or ▼ to select "Load Cut Sheet", and then press the OK button.




If any paper has been advanced that will not be used, a message is shown requesting you to remove it.
 Press ▲ or ▼ to select Yes, and then press the OK button. Remove the paper and go to the next step.


2

Slide the Width Guide (a) to align it with the mark for the size of paper you will load.




3 Load a single sheet printing-side up in the Paper Feed Slot, with the right edge aligned with the Paper Alignment Guide (a) to the right of the Roll Cover. Insert the paper until the leading edge makes contact and you hear a tone.





Set the Width Guide against the edge of the paper to prevent the paper from becoming crooked or wrinkled.



- 5 Press the **OK** button.
 - If a print job was received
 The printer now starts printing the print job.
 - If no print job was received

A menu for selection of the type of paper is automatically shown on the Display Screen.

Press ▲ or ▼ to select the type of paper, and then press the **OK** button.

The printer now starts feeding the paper.



• Refer to Paper Reference Guide for details on type of paper to select. (See "Displaying the Paper Reference Guide.") →P.331

Printing From a Desired Starting Point

When printing inside boundaries or in other situations when you want to specify a particular position to start printing from, set **Width Detection** to **Off** in the printer menu for the type of paper used.

Set Width Detection to Off

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





• If the Tab Selection screen is not displayed, press the Menu button.

- Press the **OK** button.
 The **Paper Menu** is displayed.
- 3 Press ▲ or ▼ to select Paper Details, and then press the OK button.
- 4 Press ▲ or ▼ to select the type of paper, and then press the **OK** button.
- 5 Press ▲ or ▼ to select Width Detection, and then press the OK button.
- 6 Press ▲ or ▼ to select **Off**, and then press the **OK** button.

Load paper in the desired position to start printing from

Follow these instructions to load paper at the desired starting position for printing when Width Detection is Off.


If you did not send a print job in advance, a menu for selection of the type of paper is displayed. Press ▲ or ▼ to select the type of paper, and then press the **OK** button.



• If a print job was received before paper was advanced, the media type and size specified by the job are shown on the Display Screen.


Thus, this screen is not displayed. Go to step 2.

- 2 "Width Detection OFF. OK to continue?" is now shown on the Display Screen. Press ▲ or ▼ to select "Leave OFF", and then press the OK button.
- 3 After a menu for selection of the paper size is displayed, press ▲ or ▼ to select the paper size, and then press the **OK** button.
- 4 Open the Top Cover and check the position where paper is loaded.




To start printing from the current position, close the Top Cover.


To reposition the paper, push the Release Lever back.



Keeping the right edge of the paper aligned with the extended line of the Paper Alignment Line (a) to the right of the ejection guide and the leading edge aligned with the groove (b) at the far end of the Platen, load the paper at the position from which to start printing.




6 Pull the Release Lever forward and close the Top Cover.



Removing Sheets


Remove sheets from the printer as follows.

1 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).






- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Paper Menu** is displayed.
- Press ▲ or ▼ to select **Eject Paper**, and then press the **OK** button.
- Press ▲ or ▼ to select **Yes**, and then press the **OK** button. The paper is ejected from the front of the printer.
- Holding the paper, push the Release Lever back and remove the sheet.



6 Pull the Release Lever forward.



Output Stacker

Using the Output Stacker

This section describes how to use the Output Stacker.




- The Stand that can be used with this printer is Printer Stand ST-27 and Printer Stand ST-26.
- The Stand is described in the illustration of Printer Stand ST-27. Note that the illustrations may look different from the appearance of your printer in some cases.

· When storing printed documents on the Output Stacker

Use position (1). For details on how to use the Extended position which is a useful function for retrieving printed matter, refer to the note regarding the Extended position. (See "Note regarding the Extended position.")
P.365

 When the Output Stacker is not used, when loading paper, or when moving the printer Use position (2).

When moving the printer, always lift the Support Rod to Extended position A before putting it in position (2), otherwise the Basket Cloth may touch the floor and be soiled or damaged. (See "Switching to Extended position A.") \rightarrow P.366





- When storing printed documents on the Output Stacker, always use it in position (1). If you do not, printed documents may not be dropped into the Output Stacker, and the printed surface may become soiled.
- The Output Stacker can hold one sheet. When printing multiple pages, remove each sheet after it is printed.
- The Output Stacker can hold printed documents from paper up to 36 inches (915 mm) long.


Note regarding the Extended position

The Output Stacker has a regular position and a position for easy removal of printed documents. Use the best position for the paper size and orientation that you are using.

For information on the types and sizes of paper that the Extended position supports, refer to the following.


- Printer Stand ST-27: Output stacker operation guide (Included with the Printer Stand ST-27)
- Printer Stand ST-26: Paper Reference Guide (See "Types of Paper.") →P.328
 Regular position

Using the Output Stacker iPF685




Extended position A

Extended position B (ST-27 only)




- Switching to Extended position A
 Switch the stacker to Extended position A as follows.
- Lift the Support Rod to the position shown (a) and switch the stacker to Extended position A.







When using 24-inch or A1 (portrait) rolls, pull out the Adjustable Stopper (a). This completes the procedure for switching to Extended position A.




Once the printing has finished, use the following procedure to return to the regular position.






2 Return to the regular position.




Switching to Extended position B (ST-27 only)
 Switch the stacker to Extended position B as follows.

Using the Output Stacker iPF685

Grasp the Output stacker handle (a) and pull out the Output Stacker so that it tilts towards you.





Open the Output Stacker Ejection Guides (a). This completes the procedure of switching to Extended position B.




Once the printing has finished, use the following procedure to return to the regular position.


Push the Output Stacker Ejection Guides (a) closed until it clicks into place.








While continuing to hold the Output stacker handle (a), slowly lower the Output Stacker.



4 Return to the regular position.



Media Configuration Tool (Windows)

The Features of Media Configuration Tool Installation Procedures Starting Method	. 370
Media Configuration Tool Main Window	372
Editing Media Type Information for Genuine Paper and Feed Confirmed Paper Adding Media Types Changing Media Names Deleting Media Types You Have Added Switching Media Types Display Show/Hide Changing the Display Order of Media Types	374 376 378 379
Checking the update	382

The Features of Media Configuration Tool

In imagePROGRAF, the best printer settings for each paper are collected together in media information files in order to give the highest quality printing results. Settings for Canon genuine paper and Canon feed confirmed paper are provided by Canon in these media information files.



Canon genuine paper and Canon feed confirmed paper are detailed in the Paper Reference Guide.

The Media Configuration Tool allows you to perform the following tasks.

- When supported paper has been newly added to the printer, you can add that media type to the printer control panel and printer driver by using the media information file provided by Canon.
- You can rearrange lists of the types of paper on the printer control panel and in printer driver dialog boxes and rename them, in addition to other functions.



- Normally, the Media Configuration Tool is installed and the media information is configured when you install the
 printer driver from the User Software CD-ROM. Use this software if you want to add new media information or
 edit existing media information.
- Administration of paper information using the Media Configuration Tool should be performed by the printer administrator.

Drivers Applicable with Media Configuration Tool

imagePROGRAF Printer Driver

Installation Procedures


The Media Configuration Tool installation screen appears when you start the installation of a new version of the Media Configuration Tool. The installation procedure started from this screen is described below.



- When you install the printer driver from the User Software CD-ROM, the Media Configuration Tool is also installed and the media information is also configured. The following procedure is therefore not normally needed. Perform the following procedure if you are installing the Media Configuration Tool without using the User Software CD-ROM, such as by downloading the latest version of the Media Configuration Tool from the Canon website.
- You must be logged in as Administrator when installing software in Windows.


iPF685 Installation Procedures

Start the Media Configuration Tool installer. Click the **Next** button.



The next screen presents selections for the country or area where the printer is used.


Select a country or territory then click the **Next** button.



The License Agreement is displayed. If you accept the agreement, click Yes.




The **Change Installation Location** screen appears.
Select the destination folder then click the **Next** button.





The **Installation Complete** screen appears. Click the **Finish** button.

This completes the installation of Media Configuration Tool.




Starting Method

Follow the procedure below to start Media Configuration Tool.

From the start menu go to All Programs > iPFxxxx Media Configuration Tool > iPFxxxx Media Configuration Tool.

Media Configuration Tool main window is displayed.






If you only start the Media Configuration Tool, the media information on the printer control panel and in the printer driver is not updated. If this screen is displayed, select **Add Genuine Paper** in the main window, and click the **Update** button in the **Edit Media Types** screen to update the media information.



Media Configuration Tool Main Window

The explanation below is on the Media Configuration Tool main window.





For the step to open the Media Configuration Tool main window, see "Starting Method." →P.372

Add Genuine Paper button

When this button is clicked, the **Edit Media Types** dialog box is displayed, which allows you to add media information files released by Canon to the printer control panel and printer driver. You can also change names, toggle between displaying and hiding, and delete added media types.

You can also change the display order of the paper types.

Refer to "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper" →P.373 for details on Add Genuine Paper.

• Link to Support Information button


You can check information such as the latest information for the product and software version upgrade information.

• Link to User Manual Button

Displays the printer user's manual

Editing Media Type Information for Genuine Paper and Feed Confirmed Paper

To add genuine paper and feed confirmed paper to the printer control panel and printer driver and edit the media type information, click the **Add Genuine Paper** button in the Media Configuration Tool main window. Confirm the printer, where media type information is to be updated, to be displayed in **Printer** in the **Select Printer** dialog box, and then click the **Next** button.



Communication with the printer begins.




• Do not attempt to print or turn the printer off while the program is communicating with the printer.

The **Edit Media Types** dialog box is displayed.



• In the following screens, you cannot change the printer where media type information is to be updated.





Paper that is displayed grayed out does not appear in the printer driver or printer panel.

Adding Media Types iPF685

Add Button

To add genuine paper or feed confirmed paper to the printer control panel and printer driver, click this button. For details on the procedure for adding media types, see "Adding Media Types." >P.374



• To add media types, download the media information file (.amf file) in advance from the Canon website.

Rename Button

To change the name on the printer control panel and the name in the printer driver for genuine paper and feed confirmed paper, select the paper to change and click this button.

For details on the procedure for changing paper display names, see "Changing Media Names." >P.376

• Delete Button

To delete added genuine paper and feed confirmed paper from the printer control panel and printer driver, select the paper to delete and click this button.

For details on the procedure for deleting added media types, see "Deleting Media Types You Have Added." >P.378

• Show/Hide Button

To change whether or not genuine paper or feed confirmed paper is displayed in the printer control panel and printer driver, select the paper to change and click this button.

For details on the procedure for changing whether or not to display media types, see "Switching Media Types Display Show/Hide." →P.379

Change Display Order button (5) or 1)

To change the display order of a media type in the printer control panel and printer driver, select the paper to change and click this button.

For details on the procedure for changing the display order of media types, see "Changing the Display Order of Media Types." >P.381



 When you update the media type information, perform the same update on all of the PCs that are using that printer.




• It may not be possible to deleting, showing/hiding, and changing the display order under some conditions.

Adding Media Types

Media information files (.amf files) released by Canon are registered in the printer control panel and printer driver.



- Do not perform printing on the target printer while adding the media types.
- Reinstalling Media Configuration Tool after registering a media information file may delete the registered media information file. In this case, first download and install latest Media Configuration Tool, then download and register the required media information file.
- 1 Open the **Edit Media Types** dialog box, and then click the **Add** button.




iPF685 Adding Media Types




• For details on the procedure for opening the **Edit Media Types** dialog box, see "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper." >P.373


The Add Media Type dialog box displays. Click the Browse button.



Open the folder that contains the media information files (.amf files).




The names of the media information files contained in the selected folder are displayed in **Media Information File** in the **Add Media Type** dialog box. Select the check box for the paper you want to add and click the **OK** button.






- If Master Media Information File is displayed as the Type of the Media Information File, the media type display order and media type display/non-display settings are initialized. Reconfigure these after added the master media information file.
- Click **OK** when the confirmation message is displayed.

In the Edit Media Types dialog box, click the Update button.



7 The Confirm Update dialog box is displayed. Configure Update Target and click the Execute button.

Communication with the printer begins.






You should normally select Update the printer control panel and printer driver.




- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the Cancel button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.
- 8 Click the **OK** button.



Changing Media Names

1 Open the Edit Media Types dialog box.




iPF685 Changing Media Names




For details on the procedure for opening the Edit Media Types dialog box, see "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper." →P.373

In the Media Type list, select the name to change. Click the Rename button.



The Rename Media dialog box is displayed. Edit the names in Name in Printer Driver and Name on Control Panel and click the OK button.






To restore the original names, click the **Restore** button.

Note • The characters that can be entered for Name in Printer Driver and Name on Control Panel are stated


alphanumeric, space, "-", ".", " ", "(", ")", "+", "%", ",", "/"

- For Name in Printer Driver up to 32 one Byte characters can be entered, and for Name on Control Panel up to 16 one Byte characters can be entered.
- 4 In the Edit Media Types dialog box, click the Update button.



The **Confirm Update** dialog box is displayed. Configure Update Target and click the Execute but-

Communication with the printer begins.






• You should normally select Update the printer control panel and printer driver.




- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the Cancel button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.
- 6 Click the **OK** button.



Deleting Media Types You Have Added


1 Open the **Edit Media Types** dialog box.





- For details on the procedure for opening the Edit Media Types dialog box, see "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper." →P.373
- In the **Media Type** list, select the name of the media to delete.


 Click the **Delete** button.






Only paper for which Status in the Media Type is Add can be deleted.

In the Edit Media Types dialog box, click the Update button.




The **Confirm Update** dialog box is displayed. Click the **Execute** button. Communication with the printer begins.






- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the **Cancel** button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.
- 5 Click the **OK** button.



Switching Media Types Display Show/Hide

1 Open the Edit Media Types dialog box.




Note

For details on the procedure for opening the **Edit Media Types** dialog box, see "**Editing Media Type Information for Genuine Paper and Feed Confirmed Paper**." →P.373

In the **Media Type** list, select the name of the media to switch off or on for display.


Click the Show/Hide button.

The selected paper is alternately shown or hidden.






- You can select multiple paper.
- The names of media switched for non-display appear grayed out in the Media Type list.
- Each time you click the Show/Hide button, the display mode cycles from showing both the printer driver and printer panel, to hiding both the printer driver and printer panel, and then to showing only the printer panel.
- In the Edit Media Types dialog box, click the Update button.



The **Confirm Update** dialog box is displayed.
Configure Update Target and click the **Execute** button

Communication with the printer begins.







You should normally select **Update the printer control panel and printer driver**.




- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the Cancel button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.





Changing the Display Order of Media Types

1 Open the Edit Media Types dialog box.







- For details on the procedure for opening the **Edit Media Types** dialog box, see "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper."
 P.373
- Select the paper in the **Media Type** list for which to change the display order, and then click the buttons to move the item () or).

 The selected item moves one line up or down for every

The selected item moves one line up or down for every button click.




In the **Edit Media Types** dialog box, click the **Update** button.



Checking the update iPF685

The Confirm Update dialog box is displayed.
Configure Update Target and click the Execute button

Communication with the printer begins.







You should normally select Update the printer control panel and printer driver.



- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the Cancel button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.





Checking the update

After updating the media information using the Media Configuration Tool, you can check whether the update has been applied to the printer in the control panel of the printer.

- Click the **About** button in the Media Configuration Tool main window to open the **About** dialog box.
- 2 Check the value xx.xx (xxxx) of MIT DB Version.
- 3 Check the value xx.xx (xxxx) of MIT in Set./Adj. Menu > Printer Info > System Info in the printer control panel.

If the values in Steps 2 and 3 are the same, the update has been applied to the printer.

Media Configuration Tool (Mac OS)

The Features of Media Configuration Tool Procedures for Installing Starting Method	383
Media Configuration Tool Main Window	386
Editing Media Type Information for Genuine Paper and Feed Confirmed Paper Adding Media Types Changing Media Names Deleting Media Types You Have Added Switching Media Types Display Show/Hide Changing the Display Order of Media Types	
Checking the update	397

The Features of Media Configuration Tool

In imagePROGRAF, the best printer settings for each paper are collected together in media information files in order to give the highest quality printing results. Settings for Canon genuine paper and Canon feed confirmed paper are provided by Canon in these media information files.



Canon genuine paper and Canon feed confirmed paper are detailed in the Paper Reference Guide.

The Media Configuration Tool allows you to perform the following tasks.

- When supported paper has been newly added to the printer, you can add that media type to the printer control panel and printer driver by using the media information file provided by Canon.
- You can rearrange lists of the types of paper on the printer control panel and in printer driver dialog boxes and rename them, in addition to other functions.



- Normally, the Media Configuration Tool is installed and the media information is configured when you install the
 printer driver from the User Software CD-ROM. Use this software if you want to add new media information or
 edit existing media information.
- Administration of paper information using the Media Configuration Tool should be performed by the printer administrator.

Drivers Applicable with Media Configuration Tool

imagePROGRAF Printer Driver

Procedures for Installing

Start the installer in the new version of Media Configuration Tool, and follow procedures below to install the Media Configuration Tool.




When you install the printer driver from the User Software CD-ROM, the Media Configuration Tool is also installed and the media information is also configured. The following procedure is therefore not normally needed. Perform the following procedure if you are installing the Media Configuration Tool without using the User Software CD-ROM, such as by downloading the latest version of the Media Configuration Tool from the Canon website.

Procedures for Installing iPF685

Double-click Canon iPFxxxx Series Media Configuration Tool.pkg to start the Media Configuration Tool installer.



The **Software License Agreement** is displayed.
After you have read Canon Software License Agreement, click the **Continue** button.



The next screen presents selections for the country or area where the printer is used.

Select a country or territory then click the **Continue** button.



4 Click the Install button.





Enter an administrator name/password and click the **Install Software** button.



6

Click the Close button.

The installation of Media Configuration Tool is complete.





 When the installation is completed properly, the Media Configuration Tool folder is saved in the following folder.

Applications > Canon Utilities > iPFxxxx Media Configuration Tool


• The iPFxxxx in the folder above will be the printer name in use.

Starting Method

Follow the procedure below to start the Media Configuration Tool.

From the **Applications** menu > **Canon Utilities** >**iPFxxxx Media Configuration Tool** > **MCTxxxx.app**.

Media Configuration Tool main window is displayed.



386



 If a compatible printer driver is not installed, the Media Configuration Tool will not start. If you attempt to start the Media Configuration Tool when a printer driver is not installed, the warning message below is displayed.




• If you only start the Media Configuration Tool, the media information on the printer control panel and in the printer driver is not updated. If this screen is displayed, select **Add Genuine Paper** in the main window, and click the **Update** button in the **Edit Media Types** screen to update the media information.



Media Configuration Tool Main Window

The explanation below is on the Media Configuration Tool main window.





For the step to open the Media Configuration Tool main window, see "Starting Method." →P.385

Add Genuine Paper button

When this button is clicked, the **Edit Media Types** dialog box is displayed, which allows you to add media information files released by Canon to the printer control panel and printer driver. You can also change names, toggle between displaying and hiding, and delete added media types.

You can also change the display order of the paper types.

Refer to "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper" >P.387 for details on Add Genuine Paper.

Link to Support Information button

You can check information such as the latest information for the product and software version upgrade information.

• Link to User Manual Button

Displays the printer user's manual

Editing Media Type Information for Genuine Paper and Feed Confirmed Paper

To add genuine paper and feed confirmed paper to the printer control panel and printer driver and edit the media type information, click the **Add Genuine Paper** button in the Media Configuration Tool main window. Confirm the printer, where media type information is to be updated, to be displayed in **Printer** in the **Select Printer** dialog box, and then click the **Next** button.



Communication with the printer begins.




• Do not attempt to print or turn the printer off while the program is communicating with the printer.

The Edit Media Types dialog box is displayed.



In the following screens, you cannot change the printer where media type information is to be updated.





Paper that is displayed grayed out does not appear in the printer driver or printer panel.

Add Button

To add genuine paper or feed confirmed paper to the printer control panel and printer driver, click this button. For details on the procedure for adding media types, see "Adding Media Types." >P.388



• To add media types, download the media information file (.amf file) in advance from the Canon website.

Rename Button

To change the name on the printer control panel and the name in the printer driver for genuine paper and feed confirmed paper, select the paper to change and click this button.

For details on the procedure for changing paper display names, see "Changing Media Names." →P.391

Adding Media Types iPF685

Delete Button

To delete added genuine paper and feed confirmed paper from the printer control panel and printer driver, select the paper to delete and click this button.

For details on the procedure for deleting added media types, see "Deleting Media Types You Have Added." >P.393

· Show/Hide Button

To change whether or not genuine paper or feed confirmed paper is displayed in the printer control panel and printer driver, select the paper to change and click this button.

For details on the procedure for changing whether or not to display media types, see "Switching Media Types Display Show/Hide." >P.394

Change Display Order button (or i)

To change the display order of a media type in the printer control panel and printer driver, select the paper to change and click this button.

For details on the procedure for changing the display order of media types, see "Changing the Display Order of Media Types." >P.396)



When you update the media type information, perform the same update on all of the PCs that are using that printer.




• It may not be possible to deleting, showing/hiding, and changing the display order under some conditions.

Adding Media Types

Media information files (.amf files) released by Canon are registered in the printer control panel and printer driver.



- Do not perform printing on the target printer while adding the media types.
- Reinstalling Media Configuration Tool after registering a media information file may delete the registered media information file. In this case, first download and install latest Media Configuration Tool, then download and register the required media information file.
- 1 Open the **Edit Media Types** dialog box, and then click the **Add** button.






For details on the procedure for opening the Edit Media Types dialog box, see "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper." →P.387


The Add Media Type dialog box displays. Click the Browse button.



Open the folder that contains the media information files (.amf files).



The names of the media information files contained in the selected folder are displayed in **Media Information File** in the **Add Media Type** dialog box. Select the check box for the paper you want to add and click the **OK** button.






- If **Master Media Information File** is displayed as the **Type** of the **Media Information File**, the media type display order and media type display/non-display settings are initialized. Reconfigure these after added the master media information file.
- 5 Click **OK** when the confirmation message is displayed.

Adding Media Types iPF685

6

In the **Edit Media Types** dialog box, click the **Update** button.



7 The **Confirm Update** dialog box is displayed.
Configure Update Target and click the **Execute** button

Communication with the printer begins.





You should normally select **Update the printer control panel and printer driver**.




- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the Cancel button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.
- 8 Click the **OK** button.



iPF685 Changing Media Names


Changing Media Names

1 Open the Edit Media Types dialog box.





- For details on the procedure for opening the Edit Media Types dialog box, see "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper." →P.387
- In the **Media Type** list, select the name to change. Click the **Rename** button.



The Rename Media dialog box is displayed.
Edit the names in Name in Printer Driver and Name
on Control Panel and click the OK button.






- To restore the original names, click the Restore button.
- The characters that can be entered for Name in Printer Driver and Name on Control Panel are stated below.

alphanumeric, space, "-", ".", "_", "(", ")", "+", "%", ",", "/"

• For Name in Printer Driver up to 32 one Byte characters can be entered, and for Name on Control Panel up to 16 one Byte characters can be entered.



In the **Edit Media Types** dialog box, click the **Update** button.



The **Confirm Update** dialog box is displayed.
Configure Update Target and click the **Execute** button.

Communication with the printer begins.






You should normally select Update the printer control panel and printer driver.




- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the Cancel button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.






Deleting Media Types You Have Added

1 Open the **Edit Media Types** dialog box.






- For details on the procedure for opening the Edit Media Types dialog box, see "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper." →P.387
- In the **Media Type** list, select the name of the media to delete.
 Click the **Delete** button.






- Only paper for which Status in the Media Type is Add can be deleted.
- In the Edit Media Types dialog box, click the Update button.



The **Confirm Update** dialog box is displayed. Click the **Execute** button. Communication with the printer begins.






- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the Cancel button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.
- 5 Click the **OK** button.



Switching Media Types Display Show/Hide

1 Open the Edit Media Types dialog box.






For details on the procedure for opening the **Edit Media Types** dialog box, see "Editing Media Type Information for Genuine Paper and Feed Confirmed Paper." >P.387

In the **Media Type** list, select the name of the media to switch off or on for display.

Click the Show/Hide button.

The selected paper is alternately shown or hidden.





- · You can select multiple paper.
- Note The names of media switched for non-display appear grayed out in the **Media Type** list.
 - Each time you click the **Show/Hide** button, the display mode cycles from showing both the printer driver and printer panel, to hiding both the printer driver and printer panel, and then to showing only the printer panel.
- In the **Edit Media Types** dialog box, click the **Update** button.



The **Confirm Update** dialog box is displayed.
Configure Update Target and click the **Execute** button.

Communication with the printer begins.






You should normally select **Update the printer control panel and printer driver**.




- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the Cancel button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.





Changing the Display Order of Media Types


1 Open the Edit Media Types dialog box.






- Select the paper in the **Media Type** list for which to change the display order, and then click the buttons to move the item (or).

The selected item moves one line up or down for every button click.




In the Edit Media Types dialog box, click the Update button.





The Confirm Update dialog box is displayed. Configure Update Target and click the Execute but-

Communication with the printer begins.






You should normally select Update the printer control panel and printer driver.



- · When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the Cancel button.
- Do not attempt to print or turn the printer off while the program is communicating with the printer.





Checking the update

After updating the media information using the Media Configuration Tool, you can check whether the update has been applied to the printer in the control panel of the printer.

- Click the **About** button in the Media Configuration Tool main window to open the **About** dialog box.
- Check the value xx.xx (xxxx) of MIT DB Version.
- Check the value xx.xx (xxxx) of MIT in Set./Adj. Menu > Printer Info > System Info in the printer control

If the values in Steps 2 and 3 are the same, the update has been applied to the printer.

Memo

Solls Enide

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327

Control Panel


Operations and Display Screen	400
Printer Menu	408

Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

Operations and Display Screen

Control Panel	400
Control Panel Display	402
How to View Instructions with Navigate	406
Checking Instructions During Printer Operations	407

Control Panel



a Display Screen

Shows printer menus, as well as the printer status and messages.

b Data Lamp (green)

Flashing

During printing, the Data lamp flashes when the printer is receiving or processing print jobs. Otherwise, this lamp flashes when the print job is paused or the printer is updating the firmware.

Off

There are no active print jobs when the Data lamp is off.

c Message Lamp (orange)

On

A warning message is displayed.

Flashing

An error message is displayed.

Off

The printer is off or is operating normally.

d Power button (green)

Turns the printer on and off. (See "Turning the Printer On and Off.") \rightarrow P.17

The **Power** button is lit when the printer is on or in Sleep mode.

e Stop button

400

Cancels print jobs in progress and ends the ink drying period.

f Navigate button

Enables you to check instructions for loading and removing paper or replacing ink tanks or printheads, as well as other operations. (See "How to View Instructions with Navigate.") >P.406

Control Panel

g Arrow buttons

■ button

Press this button on the **Tab Selection screen** to move to another tab.

In menu items requiring numerical input, press this button to move to another digit.

▲ button

Press this button in the menu to move to another item.

In menu items requiring numerical input, press this button to increment the number.

• button

Press this button on the Tab Selection screen to move to another tab.

In menu items requiring numerical input, press this button to move to another digit.

• ▼ button

Press this button in the menu to move to another item.

In menu items requiring numerical input, press this button to decrement the number.

h OK button

Press this button on the **Tab Selection screen** to display the menu of the tab shown.

Pressing this button in menu items of each tab for which 🛨 is displayed at left will move to the lower level of the menu item, enabling you to execute menu commands or set menu values.

Also press this button if the Display Screen indicates to press the **OK** button.

i Back button

Displays the screen before the current screen.

j Menu button

Displays the **Tab Selection screen**. (See "Menu Settings.") →P.418

k Load button

Press this button when loading or replacing paper.

(See "Loading Rolls in the Printer.") →P.341

(See "Loading Sheets in the Printer.") →P.359

I Feed button

Pressing this button when rolls are loaded enables you to reposition the paper. (See "Feeding Roll Paper Manually.") → P.349

m Cut button

Pressing this button when rolls are loaded cuts the paper, if you have specified Automatic or Eject in Cutting Mode in the Control Panel menu. (See "Specifying the Cutting Method for Rolls.") →P.352

n Cut Sheet lamp (green)

Lit when sheets are selected as the paper source.

Roll Media lamp (green)

Lit when rolls are selected as the paper source.



To recover from Sleep mode, any button can be pressed except the Power button.

Note

Control Panel Display


After the printer starts up, the **Tab Selection screen** is displayed.

Each of the four tabs presents status, menus, and error information related to the particular tab.

Types of tabs

The **Tab Selection screen** presents four tabs. Each tab is represented by an icon in the top row. Press the ◀ or ▶ button to access other tabs.

Paper tab



A tab indicating status and showing menus related to paper. Pressing the **OK** button when this tab is highlighted will display the **Paper Menu**.

Top line displayed

The paper icon is highlighted.

Middle line displayed

Indicates the printer status and shows menu names.

· Bottom line displayed

The first and second lines display the paper type and size.



A tab indicating status and showing menus related to ink. Pressing the **OK** button when this tab is highlighted will display the **Ink Menu**.

Top line displayed

The ink icon is highlighted.

Middle line displayed

Indicates the printer status and shows menu names.

Bottom line displayed

Here, the remaining ink level is indicated. (See "Checking Ink Tank Levels.") >P.543

Ready OK: Job Menu

A tab indicating status and showing menus related to print jobs. Pressing the **OK** button when this tab is highlighted will display the **Job Menu** menu.

Top line displayed

The job icon is highlighted.

• Middle line displayed

Indicates the printer status and shows menu names.

Settings/Adj. tab



A tab indicating status and showing menus related to settings and adjustment. Pressing the **OK** button when this tab is highlighted will display the **Set./Adj. Menu**.

• Top line displayed

The settings/adjustment icon is highlighted.

Middle line displayed

Indicates the printer status and shows menu names.

Bottom line displayed

The remaining Maintenance Cartridge capacity is shown on the first line and **Tot.Print Area** on the second. The display unit for **Tot.Print Area** can be specified in the **Length Unit** menu. (See "Menu Settings.") →P.418

Printer status and modes

The printer has the following status.

Standby




The printer is ready to receive jobs sent from the computer. Jobs sent from the computer are printed immediately.

Printing Paused



Printing is paused on the printer. Any jobs sent from the computer are held without being printed.

Printing



Printing is in progress on the printer. Jobs sent from the computer are printed after the current job. The time left until printing is finished is indicated in the upper-right corner of the screen. (Values exceeding 10 hours are not shown.)

Sleep

Blank display

The printer is in power-saving mode. The printer automatically enters Sleep mode to conserve power when idle for a specific period (by default, five minutes), that is, if no print jobs are received or buttons are pressed while all covers are closed.

You can specify the period before the printer enters **Sleep** mode in the **Sleep Timer** menu. (See "Menu Settings.") →P.418

After entering **Sleep** mode from **Standby** mode, the printer automatically recovers if print jobs are received, and the jobs are printed.

Off

The printer is not on.

If no operations are performed on the printer for the duration of the time set in **Shut Down Timer** after entering Sleep mode, the printer automatically turns off. (See "**Menu Settings**.") →P.418

Blank display




The printer requires your attention. Any jobs sent from the computer cannot be processed. The tab related to the error is displayed.

For information about the display in the case of multiple errors, see "Display Transitions in Error Status."

Display Transitions in Normal Status

The display transitions while the printer is in the normal status (the status where no errors have occurred) are shown below.




- *1: The printer automatically enters **Sleep** mode when idle for a specific period (by default, five minutes), that is, if no print jobs are received or buttons are pressed while all covers are closed. However, it does not enter **Sleep** mode while error messages are displayed or when a roll can be manually advanced by pressing the **Feed** button.
- *2: When the printer is in **Sleep** mode, you can press any button except the **Power** button to recover from **Sleep** mode. **Sleep** mode is also terminated if a print job is received or a command is issued from RemoteUI.

Display Transitions in Error Status

The display transitions while an error has occurred on the printer are shown below.

If multiple errors have occurred, the tabs for errors that have occurred other than the currently displayed error are displayed flashing. You can move between the tabs to check the errors by pressing the ◀ and ▶ keys. If multiple errors have occurred in the Job tab and Settings/Adj. tab, the error message switches every four seconds within each tab.




How to View Instructions with Navigate

You can refer to instructions for loading paper, replacing ink tanks, and performing other operations on the printer control panel.

- 1 Press the Navigate button.
- Press ▲ or ▼ to select the desired navigation menu.
- Press ▲ or ▼ to select View Op. Guide, and then press the OK button. Instructions are now displayed.





Checking Instructions During Printer Operations

You can refer to instructions on the printer control panel when loading paper, replacing ink tanks, or performing other operations.


How to view instructions

Once you complete an action described in the instructions, the printer detects the action and switches to the next instruction screen.

In the case of actions the printer cannot detect, instruction screens are switched every four seconds, and the sequence of operations is shown repeatedly.

When all actions in the sequence are finished, the instruction screen for the next step is displayed.

Example: Ink tank replacement





Press the ◀ or ▶ button to display the previous or next screens. If you do not press the ◀ or ▶ button within 30 seconds, continuous display is resumed.

Press the \mathbf{OK} button to display the instruction screen for the next step.

Printer Menu Operations iPF685

Printer Menu

rinter Menu Operations40	80
Menu Operations40	
1enu Structure	12
Menu Settings41	18
tatus Print	28
rinting Interface Setting Reports	31

Printer Menu Operations

The printer menu is classified into regular menu items available when no print job is in progress and menu during printing items only available while printing is in progress.

- Regular menu operations →P.408
- Menu operations during printing →P.408

Regular menu operations

To view available menus organized on tabs, select a tab on the **Tab Selection screen** and press the **OK** button.



• If the **Tab Selection screen** is not displayed, pressing **OK** will not display menus. Menus can be selected after you resolve the problem.

The following operations are available from the menu.

- Paper Menu
 - Paper menu settings
- Ink Menu
 - Ink menu operations
- Job Menu
 - Menu operations to manage print jobs
- · Set./Adj. Menu

Menu operations for printer adjustment and maintenance

For a description of specific menu items available, see "Menu Settings." >P.418
For instructions on selecting menu items, see "Menu Operations." >P.409



 By default, menu settings apply to all print jobs. However, for settings that are also available in the printer driver, the values specified in the printer driver take priority.

Menu operations during printing

During printing, only a limited set of menu items are displayed. Menu items that are not displayed during printing should be operated after printing has finished.

To display menus during printing, select a tab on the **Tab Selection screen** on the Control Panel, and then press the **OK** button.



If the Tab Selection screen is not displayed, pressing OK will not display menus.
 Menus can be selected after you resolve the problem.

The following operations are available from the menu during printing.

- Ink Menu Ink menu operations
- Job Menu
 Menu operations to manage print jobs
- · Set./Adj. Menu

Menu Operations


Fine-tuning paper feeding
Display of printer-related information

For a description of specific menu items available, see "Menu Settings." →P.418
For instructions on selecting menu items during printing, see "Menu Operations." →P.409

Menu Operations

To view available menus organized on tabs, select a tab on the **Tab Selection screen** and press the **OK** button. For details, see "Menu Settings." \rightarrow P.418)

When the Ink tab is selected and the OK button is pressed





• If the **Tab Selection screen** is not displayed, pressing **OK** will not display menus. Menus can be selected after you resolve the problem.

Simply press buttons on the Control Panel to access menus on various tabs from the **Tab Selection screen** and set or execute **Menu** items.


The following section describes menu operations and how they are presented in this User Manual.

- Accessing menus →P.409
- Specifying menu items →P.410
- Specifying numerical values →P.410
- Executing menu commands →P.411

Accessing menus

Printer menus are grouped by function.

Menus are displayed with the upper line selected. You can use the buttons on the Control Panel to access each menu.



• Press Back button to access a higher menu in the menu list, and press OK button to access a lower one.

Press ▲ to access a higher menu in the menu list, and press ▼ to access a lower one. If items of the menu list are more than the lines of the screen, press ▲ and ▼ to scroll the menu. Items you select are highlighted. The scroll bar at right indicates the current position in the overall menu.



• Lower menus are available if 🛨 is displayed at left next to the second and subsequent rows. To access the lower menus, select the menu and press the **OK** button.




Specifying menu items

Menu items can be set as follows.




Press ▲ or ▼ to select the desired setting, and then press the **OK** button.

After two seconds, the display reverts to the upper level menu.










- If a confirmation message is displayed regarding the setting you entered, follow the on-screen instructions.
- If you have changed the Interface Setup menu settings, a message confirming whether to register the settings is displayed if you press Back button or Menu button. Follow the instructions shown on the screen.

Specifying numerical values

Follow these steps to enter numbers. In this example, network settings items are entered.



Press the ◀ or ▶ button to move to the next field for input.



Press the ▲ or ▼ button to enter the value.



Hold down ▲ or ▼ to increase or decrease the value continuously.



Repeat steps 1 and 2 to complete the settings, and then press the **OK** button.



- If a confirmation message is displayed regarding the setting you entered, follow the on-screen instructions.
- If you have changed the Interface Setup menu settings, a message confirming whether to register the settings is displayed if you press Back button or Menu button. Follow the instructions shown on the screen.

Executing menu commands

Menu commands can be executed as follows.



Press ▲ or ▼ to select the action to execute, and then press the **OK** button. The menu command is now executed.

Menu Structure

The menu structure is shown categorized by tab. The * on the right side of an item indicates the default value. The printer menu is classified into regular menu items available when no print job is in progress and menu during printing items only available while printing is in progress. see "Printer Menu Operations."

P.408

Regular menu	Menu during printing
☐ Paper Menu	Not displayed
△ Ink Menu	The same
Job Menu	The same Job Menu as normal is displayed.
Set./Adj. Menu	A limited 🕒 Set./Adj. Menu containing the following items is displayed.
	Adj. Fine Feed(*1)Printer Info

^{*1:} Only displayed in the menu during printing. Not displayed in the regular menu.

For instructions on menu operations, see "Menu Operations." →P.409 For details on menu items, see "Menu Settings." →P.418

□ Paper Menu


The **Paper Menu** is not displayed during printing.

First Level	Second Level	Third Level	Fourth Level	Fifth Level
:(Load Paper	Roll Paper Cut Sheet			
-Eject Paper				
··Chg. Paper Type(*1)	Roll Paper	····(The paper type is dis	splayed here.) (*1)	
	: Cut Sheet	·····(The paper type is dis	splayed here.) (*1)	
··Chg. Paper Size	Sheet Size	(The size of paper is o	displayed here.) (*2)	
		: CustomPaperSize	(Set the length and width)
	Roll Length(*3)	·····(Set the length)		
	: Roll Width(*4)	····(Set the width)		
·· ManageRemainRoll	····Off* On		_	
··Paper Details	···· (The paper type is dis-	·····(Head Height	Automatic* Highest High	gh Standard Low
	played here.) (*1)	Okaw Ohaak I w	Lowest Super Low	1*
		Skew Check Lv.	High Accuracy Standard	<u> </u>
		Cutting Mode(*6) Cut Speed	Automatic Eject Manua	
		Trim Edge First	Automatic Off On (Pres	cot Lon) LOn/Innut
		Tilli Euge Filst	Length) Manual	set Leff) Off(input
		· CutDustReduct.	Off On	
		··VacuumStrngth	Automatic* Strongest S	Strong Standard Weak
		Scan Wait Time	···· Dry time	·· Off* 1 sec. 3 sec.
				5 sec. 7 sec. 9 sec.
			Area(*5)	Entire area* Leading edge
		··Roll DryingTime	Off 30 sec. 1 min. 3 m min. 60 min.	nin. 5 min. 10 min. 30
		NearEnd RollMrgn	(3mm 20mm	
		·· NearEnd Sht Mrgn	3mm 20mm	
		BordlessOversize	···· Standard* Little	
		·· Width Detection	····Off On*	
		Return Defaults		
Paper Details				
Keep Paper Type	····Off* On			


*1: For information on the types of paper the printer supports, refer to the **Paper Reference Guide**. (See "**Displaying the Paper Reference Guide**.") P331 Types of paper in the printer driver and related software (as well as on the Control Panel) are updated when you install the printer driver from the User Software CD-ROM or if you update paper information with the Media Configuration Tool. (See "**Updating paper information**.") P334

- *2: For information on the sizes of paper the printer supports, see "Paper Sizes." →P.328
- *3: Available only if ManageRemainRoll is On.
- *4: Available only if Width Detection is Off.
- *5: Leading edge is not available as a setting option in the Paper Detailed Settings dialog box of the printer driver.
- *6: see "Specifying the Cutting Method for Rolls." →P.352

O Ink Menu




Job Menu





- *1: If a pending job is selected, **Print Anyway** is displayed.
- *2: Restrictions apply if a password is configured using **Change Password** in the **Admin. Menu**. Viewing is possible for administrators only.


Set./Adj. Menu


Limited items are displayed during printing. The displayed items are indicated by annotations.











- *1: Available after you have used Auto(Advanced) in Head Posi. Adj. once.
- *2: Available if Adj. Priority is Automatic or Print Quality.
- *3: Available if Adj. Priority is Automatic or Print Length.
- *4: Available only if **Use Nesting** is **On**.
- *5: Not displayed if **IPv4 Mode** is **Manual**.
- *6: Not displayed if Auto Detect is On.
- *7: Follows the setting in **Date Format**.
- *8: Restrictions apply if a password is configured using **Change Password** in the **Admin. Menu**. Viewing and configuration is possible for administrators, and only viewing for other users.
- *9: Restrictions apply if a password is configured using **Change Password** in the **Admin. Menu**. Viewing and configuration is possible for administrators only.
- *10: Not displayed if IPv6 Support is Off.
- *11: Default setting for the time to enter the power save mode/Sleep mode is recommended.
- *12: Displayed as the menu during printing while printing is in progress.
- *13: Not displayed in the regular menu.

Menu Settings iPF685

Menu Settings

Menu items are as follows.

The printer menu is classified into regular menu items available when no print job is in progress and menu during printing items only available while printing is in progress. see "Printer Menu Operations." →P.408

Regular menu	Menu during printing
Paper Menu	Not displayed
Ink Menu	The same Ink Menu as normal is displayed.
Job Menu	The same Job Menu as normal is displayed.
Set./Adj. Menu	A limited Set./Adj. Menu containing the following items is displayed.
	Adj. Fine Feed (*1)
	Printer Info

^{*1:} Only displayed in the menu during printing. Not displayed in the regular menu.

For instructions on selecting menu items, see "Menu Operations." →P.409
For details on the displayed menu hierarchy, see "Menu Structure." →P.412

Paper Menu

The **Paper Menu** is not displayed during printing.

Setting Item			Description, Instructions
Load Paper			Select either sheets or rolls and load the paper.
Eject Paper			Choose this item before removing loaded paper.
Chg. Paper Type	(*1)		Change the type of paper loaded. (See "Changing the Type of Paper.") →P.343
Chg. Paper Size			Change the size of paper loaded. (See "Specifying the Paper Length.") →P.345 (See "Paper Sizes.") →P.328
ManageRemainRoll			Choose On to print a barcode at the end of a roll before you remove it. The printed barcode can be used in managing the amount of roll paper left. Choose Off if you prefer not to print the barcode. (See "Keeping Track of the Amount of Roll Paper Left.") →P.350
Paper Details	(The type of paper is displayed	Head Height	Adjust the Printhead height. (See "Troubleshooting Paper Abrasion and Blurry Images.") →P.527
	here.)(*1)	Skew Check Lv.	If you print on Japanese paper (washi) or other handmade paper that has an irregular width, choose Loose for a higher skew detection threshold, or choose Off to disable skew detection. However, if paper is loaded askew when detection is Off , note that paper jams or Platen soiling may occur.
		Cutting Mode	Specify whether or not to cut with the standard round-bladed cutter. If you choose Automatic , the roll will be cut automatically using the Cutter Unit, depending on the printer driver settings. Select Eject to prevent printed documents from falling immediately after printing such as when you wait for the ink to dry, etc. Manual prints lines at the cut position instead of cutting after printing. (See "Specifying the Cutting Method for Rolls.") PR352
		Cut Speed	Choose the cutting speed. The preset selection represents the optimal cutting speed for the type of paper. We recommend keeping the preset cutting speed. If you use adhesive paper, choosing Slow helps prevent adhesive from sticking to the cutter and keeps the cutter sharp.
		Trim Edge First	Selects whether or not to automatically cut the leading edge of the roll paper when roll paper is loaded. (See "Cutting the Leading Edge of Roll Paper Automatically.") P.356

iPF685 Menu Settings

	Setting Item		Description, Instructions
Paper Details	(The type of paper is displayed here.)(*1)	CutDustReduct.	If you choose On , a line will be printed at the cut position when paper cutting is selected. This option reduces the amount of debris given off after cutting. It also helps prevent adhesive from sticking to the cutter and keeps the cutter sharp if you use adhesive paper. (See "Reducing Dust from Cutting Rolls.") \Rightarrow P357
		VacuumStrngth	Specify the level of suction that holds paper against the Platen. (See "Adjusting the Vacuum Strength.") →P.535
		Scan Wait Time	Specify the time to wait for the ink to dry between each scan (afte the printhead finishes moving in one direction), in consideration of how quickly the ink dries. Also specify the applicable area for the ink drying time. Select Entire area to apply the ink drying time after each scan until the document is fully printed. Select Leading edge to apply the ink drying time after each scan only in the area 110–140 mm from the leading edge. (The applicable length varies depending on the Print Quality setting.) Note that printing will take longer if you specify the Scan Wait Time setting. In particular, when Leading edge is selected, colors may be uneven in the boundary between the areas with and without a drying time.
		Roll DryingTime	Specify the time to wait for the ink to dry for each sheet.
		NearEnd RollMrgn	Specify the minimum margin at the leading edge of roll paper to ensure better printing quality at the leading edge. Note that if you choose 3mm , it may lower the printing quality at the leading edge and affect feeding accuracy. The printed surface may be scratched, and ink may adhere to the leading edge. It may also cause the Platen to become soiled.
		NearEnd Sht Mrgn	Specify a margin at the leading edge of sheets to ensure better printing quality at the leading edge. Note that if you choose 3mm , it may lower the printing quality at the leading edge and affect feeding accuracy. The printed surface may be scratched, and ink may adhere to the leading edge.
		BordlessOver- size	Select the amount of oversize extension of the original during bor derless printing. Normally, we recommend that you set this to Standard . If it is set to Little , although it will reduce soiling on the back surface, white patches may remain on the printed surface.
		Width Detection	Specify this option to print inside boundaries or in other cases when specifying a particular starting position for printing. Paper width and skew are not detected if you select Off . If paper is loaded askew, paper jams or Platen soiling may occur.
		Return Defaults	Choose OK to restore Paper Details to the default values.
Paper Details			Print the paper settings as specified in Paper Details .
Keep Paper Type			Select On when printing on a particular type of paper regularly. (See "Changing the Type of Paper.") >P.343

^{*1:} For information on the types of paper the printer supports, refer to the **Paper Reference Guide**. (See "**Displaying the Paper Reference Guide**.") P331 Types of paper in the printer driver and related software (as well as on the Control Panel) are updated when you install the printer driver from the User Software CD-ROM or if you update paper information with the Media Configuration Tool. (See "**Updating paper information**.") P334

Ink Menu

Setting Item	Description, Instructions
Rep. Ink Tank	Replace the Ink Tank at this point. Follow the instructions displayed to complete the required procedure. (See "Replacing Ink Tanks.") →P.538
Head Cleaning A	Printhead cleaning options. (See "Cleaning the Printhead.") P.547 Execute Head Cleaning A if printing is faint, oddly colored, or contains foreign substances.

Job Menu

Setting Item					Description, Instructions
Print Job Job List		(Choose a print job)	Delete		Delete the current job or queued jobs. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") →P.488
			Preempt Jobs		Print the job first after the current print job is finished. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") →P.488
Stored	Mailbox	(Enter a password	'	Print	Print the saved job.
Job	List			Delete	Delete the saved job.
		been set.)	Print Job L	ist	Print a list of saved print jobs.
Job Log	(Choose	Document	Name		Indicates the document name of the selected print job.
	from infor- mation	User Name			Indicates the name of the user who sent the print job.
	about the	Page Coun	Page Count		Indicates the number of pages in the job.
	last three	Job Status			Indicates the printing results.
	print jobs.)	Print Start	Time		Indicates when the print job was started.
	,	Print End Time			Indicates when the print job was finished.
		Print Time			Indicates the time required to print the job.
		Print Size			Indicates the paper size in the print job.
		Media Type			Indicates the type of paper in the print job.
		Interface			Indicates the interface used for the print job.
		Ink Consumed			Indicates a rough estimate of how much ink was consumed per job.(*1)
		Print settings			A counter for maintenance purposes. Indicates job print settings.
		Head Height			A counter for maintenance purposes. Indicates the head height when jobs wereprinted.
		Temp./Humidity			A counter for maintenance purposes. Indicates the temperature and humiditywhen jobs were printed.
Adjustment req.			A counter for maintenance purposes. Indicates adjustment conditions applied to jobs.		
Print Job Log			Print a record of print jobs, including the paper type and size, amount of ink consumed, and so on. Ink consumption indicates a rough estimate of the amount of ink consumed per print job. (*1)		
Pause Print			Choose On to stop printing.		
HDD Information			Indicates the total hard disk capacity and the mail box free space.		

^{*1:} A rough estimate of the amount of ink consumed per print job is displayed. Actual ink consumption may be different. The average margin of error for estimates calculated according to Canon measurement conditions for ink costs is ±15%. Canon does not guarantee the accuracy of these estimates. Estimates may vary depending on conditions of use. Calculation of these estimates does not include ink consumed when cleaning printheads by forceful ejection of ink.

Set./Adj. Menu

Limited items are displayed during printing. The displayed items are indicated by annotations.

	Setting Item	Description, Instructions	
Test	Nozzle Check	Print a test pattern to check the nozzles.	
Print	Status Print	Print information about the setting values and condition of the printer.	
	Interface Print	Print interface settings information.	
	GL2 Set Print	Print the settings as specified in GL2 Settings .	
	Paper Details	Print the paper settings as specified in Paper Details .	

Menu Settinas

Setting Item Description, Instructions Test **Print Job Log** Print a record of print jobs, including the paper type and **Print** size, amount of ink consumed, and so on. Ink consumption indicates a rough estimate of the amount of ink consumed per print job.(*1) Menu Map Print the menu structure. **Color Palette** Print the GL2 color palette. Adjust Head Auto(Standard) The printer prints and reads a test pattern for automatic Printer Posi. adjustment of Printhead alignment relative to the printing Adj. direction. (See "Automatic Adjustment to Straighten Lines and Colors.") →P.522 The printer prints and reads a test pattern for automatic Auto(Advanced) adjustment of Printhead alignment relative to the printing direction and spacing between nozzles and colors. (See "Automatic Adjustment to Straighten Lines and Colors.") → P.522 Print a test pattern for adjustment of Printhead alignment Manual relative to the printing direction. Enter the adjustment value manually based on the resulting pattern. (See "Manual Adjustment to Straighten Lines and Colors.") → P.523 Head Inc. Adj. Print a test pattern for adjustment of the Printhead orientation. (See "Adjusting Line Misalignment.") → P.525 Feed Adj. Pri-**Automatic** Specify exact paper feeding, if desired. Normally, select **Priority** ority Automatic. Choose Print Quality for attractive printing. **Print Quality** Choosing Print Quality also makes banding less noticea-**Print Length** ble. Choose **Print Length** if you prefer to feed the paper an exact amount. Adj. Auto(GenuinePpr) Specify this mode with paper identified in the Paper Ref-Quality erence Guide. (See "Displaying the Paper Reference Guide.") → P.331 The printer prints and reads a test pattern for automatic adjustment of the feed amount. (See "Automatic Banding Adjustment.") →P.530 Auto(OtherPaper) Specify this mode with paper not in the **Paper Reference** Guide. (See "Displaying the Paper Reference Guide.") → P.331 The printer prints and reads a test pattern for automatic adjustment of the feed amount. Note that this function takes more time and consumes more ink than Auto(GenuinePpr). (See "Automatic Banding Adjustment.") → P.530 Manual Use this mode with highly transparent media or other paper for which Auto(GenuinePpr) or Auto(OtherPaper) cannot be used. Print a test pattern for adjustment of the feed amount based on the type of paper. (See "Manual Banding Adjustment.") → P.531 Adjust Adjust-Print a test pattern for particular types of paper to com-A:High Length mentpensate for paper stretching or shrinkage, after which you **B:Standard/Draft** Print enter the amount of adjustment. (See "Adjusting Line Length.") →P.533 Change A:Hiah Displayed when you have selected Feed Priority > Adi. Priority > Print Length. **Settings** B:Standard/Draft Adjustment relative to the amount of stretching or shrinkage of the current paper. Enter either the adjustment results from AdjustmentPrint

421

or the discrepancy that you measured (as a percentage).

Menu Settings

422

		Settii	ng Item		Description, Instructions			
Adjust Printer	Feed Priority	Adjust Length	Change Settings	B:Standard/Draft	For paper that tends to stretch, increase the feed amount by choosing a higher adjustment value. For paper that tends to shrink, decrease the feed amount by choosing a lower adjustment value. (See "Adjusting Line Length.") P.533			
Mainte- nance	Head Cle	aning			Clean the Printhead. (See "Cleaning the Printhead.") →P.547 Choose Head Cleaning A if printing is faint, oddly colored, or contains foreign substances. Choose Head Cleaning B if no ink is printed at all, or if printing is not improved by Head Cleaning A.			
	Nozzle C	heck			Print a test pattern to check the nozzles.			
	Replace I	P.head			Execute when replacing the Printhead. Follow the instructions displayed to complete the required procedure. (See "Replacing the Printhead.") →P.548 Not displayed during a warning message that the remaining Maintenance Cartridge capacity is low.			
	Repl. ma	int cart			Execute when replacing the Maintenance Cartridge. Follow the instructions displayed to complete the required procedure. (See "Replacing the Maintenance Cartridge.") →P.554			
	Head Info)			Indicates information about the printhead.			
GL2	Quality	Color Monochrome		ome	Print in monochrome.			
Settings	_	Manag- Mode er	Color (CA	ND) 1	Print in standard colors.			
	er		Color (CA	AD) 2	Print with approximate colors emulating Canon iPF750, iPF755, iPF650, iPF655, iPF760, iPF765.(*2)			
			Color (CA	AD) 3	Print with approximate colors emulating Canon iPF500, iPF600, iPF700, iPF510, iPF610, iPF710, iPF605, iPF72 iPF810, iPF820, iPF815, iPF825.(*2)			
			Color (CA	AD) 4	Print emulating the HP Designjet 500/800, in colors resembling colors produced by these printers.(*2)			
				Color (CA	AD) 5	Print emulating the HP Designjet T1100, in colors resembling colors produced by this printer.(*2)		
		Print Qua	ality		Choose the print quality.			
		Input Res	solution		Choose the printer input resolution, 600dpi or 300dpi.			
					Print (Economy)			When On is selected, print using less ink. However, the quality is lower than regular printing. Select On to conserve ink such as the layout confirmation. Note that although Print (Economy) is only available when Fast is selected in Print Quality , it might not be available depending on the paper type.
	Paper	Paper Sc	urce		Choose the source of paper for HP-GL/2 printing.			
	Manag- er	Margin			Specify the margin around paper. The margin for the trai ing edge of sheets is 23 mm (0.9 in). However, if you have specified the leading margin in Paper Details, the larger of the setting values has priority.			
		Oversize			Set the position of the margin relative to the image range. Choose Off to set the margin inside the image range. The image may be missing depending on the layout. Choose On to set the margin outside the image range. Although the image will not be missing, you should print on paper larger than the size of the image range plus the margins.			
	Conserve Paper				Conserves paper when printing.			

iPF685 Menu Settings

		Settin	g Item	Description, Instructions		
GL2 Settings	Paper Manag- er	7.0.10 1.010.10		If the long side of an original is shorter than the roll width, the original is automatically rotated 90 degrees to conserve paper. Similarly, if the long side of an original in landscape orientation is longer than the roll width and the short side is shorter than the roll width, the original is repositioned to fit on the paper. HP RTL print jobs are not rotated. Because HP RTL images are not rotated even if the paper is rotated 90 degrees, images may be cut off or the blank paper may be ejected. In this case, set Auto Rotate to Off .		
		Enlarge/Reduce		Enlarge or reduce the image. Choose Specify scaling to print based on the specified scaling value. The specified range is 25 to 400 %. Choose Fit to paper to print by resizing to fit the paper loaded in the printer. If Standard cut is On , the printing is resized to fit the standard paper size.		
		Print cent	tered	Print in the center of the paper.		
		Standard	cut	Automatically selects the best standard paper size from the width of the loaded roll paper and the image size and cuts the roll paper.		
		Nesting	Use Nesting	Selecting On will store print jobs until multiple documents can be arranged to fill up the roll width, instead of printing each print job as it is received.		
			Nesting WaitTime	Specify a time to wait until printing, as desired.		
			Cut Lines	Select On to print cut lines between each document on the roll.		
	Line & Pen Manag-er	Enable merge		Specify whether to merge or print over colors where lines overlap. Choose Off to print the second line over the first. Choose On to merge all overlapping colors.		
		Pen Set- up	Select Palette	As pen values, choose Software , Palette A , Palette B , or Factory . Choose Software to print according to software settings. Choose Palette A or Palette B to print using the value specified in Define Palette .		
			Define Palette	Specify the Width, Color, and Line Attributes in the palette Pen no Choose Factory to confirm the values when Factory is selected in Select Palette. In Line Attributes, choose No Setting or Circle Setting as the processing for the ends and junctions of lines. • If you choose No Setting		
				If you choose Circle Setting		
			Reset Palette	Restore Define Palette to the default palette settings.		
		Smoothing		Choose whether to print arcs as smooth curved lines or as multiple connected line segments.		

Menu Settings

		Setti	ng Item		Description, Instructions
GL2 Settings	Line & Pen Manag-er	Smoothi	ng		 If you choose Software Operation is determined by the application. If nothing is specified by the application, the result is as shown in the figure. Note: By default, this is a 72-sided figure If you choose Smooth
		Thicken	FineLines		Select On to print fine lines more distinctly.
		AdjustFaintLines			If fine lines are printed in colors that do not match the colors of other shapes, selecting Off may help produce the expected results. However, lines in some colors may appear broken.
		Ln wdth	correct		Corrects by using a correction value that specifies the pen width. You can configure Black/gray and Color for each group. The specified range is -20 to +20.
	ProcessingOption	Warning			Select On to have any GL2-related warnings displayed.
		On-the-F	ly		Selecting On will start printing jobs sooner if you are printing only HP RTL print jobs and printing would not start until later. However, images may be incomplete in some cases, so be sure to check the printing results.
		Detect img size			Sets the method of deciding the region to output in order to print efficiently while avoiding missing images. If Off is selected and the data contains image range information, the image range information is followed. If Off is selected and the data does not contain image range information, a size with the maximum roll paper width of the printer for the width and 1.5 times the maximum roll paper width for the length is used. If Command priority is selected and the data contains image range information, the image range information is followed. If Command priority is selected and the data does not contain image range information, the detected minimum image area is used. If Detected size is selected, the detected minimum image area is used.
	GL2 Set F	Print			Print GL2 settings information.
Inter- face	EOP Time				Specify the timeout period before cancellation of print jobs that cannot be received by the printer.
Setup	TCP/IP	IPv4	IPv4 Mod	le	Choose whether the printer IP address is configured automatically or a static IP address is entered manually.
	Proto- col DHCP		DHCP	Specify the protocol used to configure the IP address automatically.	

iPF685 Menu Settings

_			g Item			Description, Instructions
Inter- face	TCP/IP	IPv4	Proto- col	ВООТР		Specify the protocol used to configure the IP address automatically.
Setup			COI	RARP		tornationity.
•			IPv4	IP Addres	ss	Specify the printer network information when using a stat-
			Settings	Subnet Mask Default G/W		ic IP address. Enter the IP address assigned to the printer, as well as the network subnet mask and default gateway. The value that was automatically configured is displayed if you have set IPv4 Mode to Automatic.
			DNS Settings	DNS Dyn	c update	Specify whether DNS server registration is updated automatically.
				Pri. DNS	SrvAddr	Specify the DNS server address.
				Sec. DNS	SrvAddr	
				DNS Hos	t Name	Specify the DNS host name.
				DNS Dom	nain Name	Specify the DNS domain name.
		IPv6	IPv6 Supp	oort		Specify whether to connect via IPv6.
			IPv6 Stles	sAddrs		Specify whether a IPv6 stateless address is used.
			DHCPv6			Specify whether DHCPv6 settings are used.
			DNS Settings	DNS Dync	Statefull Addr	Specify whether DNS server registration is updated auto matically.
				update	State- less Addr	
				Dri DNS	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Specify the DNS server address.
				Pri. DNS SrvAddr		opecity the DNO server address.
				Sec. DNS SrvAddr DNS Host Name		Specify the DNS host name.
					nain Name	Specify the DNS domain name.
	Ether- net Driver	Auto Dete	ect			Specify the communication method. To apply your changes, choose Register Setting . Choose On for automatic configuration of the LAN communication protocol. Choose Off to use settings values of Comm.Mode and Ethernet Type .
		Comm.Mode				Choose the LAN communication method.
		Ethernet '	Ethernet Type			Choose the LAN transfer rate.
		Spanning Tree		ee		Choose whether spanning-tree packets are supported over the LAN.
		MAC Add	ress			Indicates the MAC address.
	Interface	Print				Print interface settings information.
	Return Do	efaults				Choose OK to restore Interface Setup settings to the default values.
System	Sleep Tin	ner				Specify the period before the printer enters sleep mode.
Setup	Shut Down Timer					Sets the time until the printer turns off automatically. If no operations are performed on the printer for the duration of the time set in Shut Down Timer after entering Sleep mode, the printer automatically turns off.
	Buzzer					Choose On for the buzzer to sound once for warnings are three times for errors.
	Contrast	Adj.				Adjust the Display Screen contrast level.
	Date &	Date				Set the current date.
	Time	Time				Set the current time. Available only if the Date setting is specified.
	Date Form	mat				Specify the date format.

Menu Settings

System Setup

	Setting Item	Description, Instructions
Language)	Specify the language used on the Display Screen.
Time Zon	e	Specify the time zone. Time zone options indicate a main city in this time zone and the difference from Greenwich Mean Time.
Length U	nit	Choose the display unit for length. Change the unit displayed for the remaining amount of roll paper, Tot.Print Area , and so on.
Detect Mi	smatch	Specify printing behavior if the type and size of paper specified in the printer menu does not match the type and size in the printer driver. Choose Pause to have printing paused under these circumstances. Choose Warning to continue printing after notification. Choose None to continue printing without notification. Choose Hold Job to store jobs with mismatched types and sizes of paper on the printer hard disk, in a print queue awaiting processing. (See "Using the Printer Hard Disk.") →P.484
Paper Size Ba- sis	Roll Selection 1	If roll size detection is activated, choose whether ISO A3 (297mm) or 300mm Roll is applied when a roll of an intermediate width is detected.
	Roll Selection 2	If roll size detection is activated, choose whether 10in . (254mm) or JIS B4 (257mm) is applied when a roll of an intermediate width is detected.
Кеер Рар	er Size	Choose On to use the paper size setting as the basis for printing instead of other settings. The margin setting of the printer menu will be used instead of the margin setting of the printer driver if the latter is smaller, which may prevent text or images in the margin from being printed. SAMPLE Choose Off to give priority to margin settings. The larger value is used if the margin specified in the printer driver does not match the margin in the printer menu. SAMPLE SAMPLE SAMPLE SAMPLE
TrimEdge Reload		Specify whether to trim the leading edge of the currently retracted roll when the roll is advanced. Cut the edge if you are concerned about any marks left on the roll when the roll is left in the retracted position. Specify On to have rolls cut when printing begins after Sleep mode or when the power is restored. Selecting Automatic will trim the edge when the roll has been in the retracted position for two days or more.
Rep.P.hea	ad Print	Choose On to have the printer automatically execute the Advanced Adj. operations after you replace the Printhead. (See "Automatic Adjustment to Straighten Lines and Colors.") →P.522

iPF685 Menu Settings

	Setting Item Description, Instructions					
System Setup	Nozzle C	heck	In Frequency , specify the timing for automatic checks of nozzle clogging. Choose Standard to have the printer adjust the timing for checks based on the frequency of nozzle use. Choose 1 page to check once per page. Choose 10 pages to check once per 10 pages. Choose Off to not execute check. If On is selected in Warning , a warning may be displayed on the Control Panel depending on the result of the nozzle check.			
	Use USB		When Off is selected, the device can no longer be accessed via USB.			
	Use Ethe	rnet	When Off is selected, the device can no longer be accessed via Ethernet.			
	Use Rem	oteUI	Choosing Off prohibits access from RemoteUI. Settings can only be configured from the control panel.			
	Reset Pa	prSetngs	Restores settings that you have changed with Media Configuration Tool to the default values.			
	Erase HDD Data	High Speed	Erases file management data for print job data stored on the printer's hard disk. (See "Erasing Data on the Printer's Hard Disk.") →P.443			
		Secure High Spd.	Overwrites the entire hard disk with random data. (See "Erasing Data on the Printer's Hard Disk.") →P.443			
		Secure	Overwrites the entire hard disk with 00, FF, and random data (one time each). Verification is performed to check if the data was correctly written. (See "Erasing Data on the Printer's Hard Disk.") →P.443			
	Output Method	Print	Select the printing method for jobs received from software other than the printer driver. When using the printer driver,			
		Print (Auto Del) Save: Box XX	configure settings on the printer. To print as usual, select Print . Selecting Print (Auto Del) will print the job and then delete the data from the printer's hard disk. Selecting Save: Box 01 will only save the print job in the box, without printing it.			
	Print Afte	Pr Recv	A setting for jobs received from software other than the printer driver. When using the printer driver, configure settings on the printer. Select On to print the job after it has been saved.			
		mmon Box	Select Off to print without saving jobs in the common box.			
	Show Jol	b Log	Selecting Off prevents display of the log in Job Menu > Job Log . Additionally, the log is not printed if you choose Job Menu > Print Job Log . Note that because job logs are not collected, the Status Monitor accounting functions will not work correctly.			
Prep.MovePrinter			When transferring the printer to another location, choose the level of transfer and follow the instructions on the screen. (See "Preparing to Transfer the Printer.") >P.564 Not displayed during a warning message that the remaining Maintenance Cartridge capacity is low.			
Admin. Menu	Change Password		The password that can be entered is a number from 0 to 9999999. The restriction states and main items are shown below. For more specific information on restricted items, see "Menu Structure." →P.412			
			 Viewing and configuration by administrators only Change Password Init.Admin.Pswd Etc. 			

	Setting Item	Description, Instructions
Admin. Menu	Change Password	 Viewing and configuration by administrators, and only viewing by other users Date & Time Time Zone Use RemoteUI Etc.
	Init.Admin.Pswd	Choose OK to restore the Admin. Menu password to the default values.
Adj. Fine Feed (*2) (*3)		Displayed when you have selected Feed Priority > Adj. Priority > Automatic or Print Quality . Fine-tune the feed amount manually.
Printer Info (*2)	Paper Info	Indicates the current paper size, type, and related printer settings.
	Ink Info	Indicates ink levels and maintenance cartridge capacity.
	Head Info	Indicates information about the printhead.
	System Info	Indicates the firmware version, serial number, and interface information.
	Error Log	Indicates the most recent error messages (up to five).
	Use Situation	A counter for maintenance purposes. Displays printer usage related information.

^{*1:} A rough estimate of how much ink was consumed per job is displayed. Actual ink consumption may be different. The average margin of error for estimates calculated according to Canon measurement conditions for ink costs is ±15%. Canon does not guarantee the accuracy of these estimates. Estimates may vary depending on conditions of use. Calculation of these estimates does not include ink consumed when cleaning printheads by forceful ejection of ink.

- *2: Displayed as the menu during printing while printing is in progress.
- *3: Not displayed in the regular menu.

Status Print


You can print a **Status Print** report indicating the current status of the printer.

With **Status Print**, information is printed regarding the printer firmware version, various settings, and the status of consumables.

Printing Status Print reports

- Load paper.

 If using cut sheets, load paper A4/Letter-sized, you will need three sheets.
- On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select Settings/Adj. tab (ⓑ).





If the Tab Selection screen is not displayed, press the Menu button.

- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select **Test Print**, and then press the **OK** button.
- 5 Press ▲ or ▼ to select Status Print, and then press the OK button.

iPF685 Status Print

Checking the information in **Status Print** reports

The following information is included in **Status Print** reports.

Canon imagePROGRAF iPFxxxx Status Print	Printer model
Firm	Firmware version
Boot	Boot ROM version
MIT(DBF)	MIT database format version
MIT(DB)	MIT database version
S/N	Printer serial number
Date	Indicates when the status print report was printed.

Paper Menu		Information on the loaded paper.
	Roll Media Type	
	Cut Sheet Type	
	ManageRemainRoll	
	Keep Paper Type	

Job Menu			Job-related information.	
	Job Log HDD Information		A counter for maintenance purposes. Various information about previous jobs.	
			Indicates the total hard disk capacity and the mail box free	
		Total capacity	space.	
		Box free space		

Set./Adj. Menu				Settings and adjustment information.
	System Setup		Printer system settings, as well	
		Sleep Timer		as settings regarding warnings and errors.
		Shut Down Timer		and errors.
		Buzzer		
		Contrast Adj.		
		Date Format		
		Language		
		Time Zone		
		Length Unit		
		Detect Mismatch		
		Paper Size Basis		Paper-related settings.
			Roll Selection 1	
			Roll Selection 2	
		Keep Paper Size		
		TrimEdge Reload		
		Rep.P.head Print		Settings after a test pattern was printed following head replacement.
		Nozzle Check		Nozzle-check settings.
			Frequency	
			Warning	

Status Print

	Lies LICD		Has HOD settings values	
	Use USB		Use USB settings values.	
	Use Ethernet Use RemoteUI		Use Ethernet settings values.	
			Settings used by RemoteUI.	
	Show Job Log		Print job settings.	
	Output Method		Print job settings.	
	Print After Recv			
	Save: Common Box		Save: Common Box settings values.	
Adjust Printer			Adjustment settings.	
	Head Posi. Adj.		A counter for maintenance pur-	
		Adjust Log	poses. Head position adjustment values for previous jobs.	
Printer Info			Ink information, RAM usage, and a record of errors.	
	Ink Info		Ink-related information.	
		MC	Maintenance Cartridge capacity (%)	
		(The ink color is displayed here.)	Ink levels. The remaining ink is displayed in a five-level scale.	
	System Info		Indicates the total amount of	
		RAM	RAM.	
	Error Log		The past five error codes.	

HEAD LOT	NUMBER/ D	ATE OF INSTALLATION	The printhead lot number and date and time when the Print-	
	HEAD INFxx		head was installed.	
PARTS ST	PARTS STATUS		Utilization status of replacement parts that require servicing.	
	COUNTER			
COUNTER			Utilization status of the cutter, media, and other items (indicat-	
	CUTTER		ing how much they have been used).	
	MEDIA			
		LIFE TTL		
		LIFE ROLL		
		LIFE CUTSHEET		
	MEDIA 1-7	OTHER		
		NAME		
		TTL		
		ROLL		
		CUTSHEET		
	AFTER INS	STALLATION		

DUTY		Counters for maintenance purposes. Needed when service is
	UNIT:m2	requested.
	UNIT:sq.f	
	UNIT:A4 Sheet	
	UNIT:Letter Sheet	


Printing Interface Setting Reports

You can print an Interface Print report indicating the current interface settings values of the printer.

Printing Interface Print reports

- Load the paper.

 If using sheets, load paper A4/Letter-sized, you will need at least three sheets.





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select **Test Print**, and then press the **OK** button.
- 5 Press ▲ or ▼ to select Interface Print, and then press the OK button.

Confirming Interface Print information

The following information is included in the **Interface Print** report.

Canon imagePROGRAF iPFxxxx Interface Print	Printer model	
Firm	Firmware Version	
Boot	Boot ROM Version	
MIT(DBF)	MIT Database Format Version	
MIT(DB)	MIT Database Version	
S/N	Printer serial number	
Date	The date when the interface setup print report was printed.	

EOP Timer		Specify the timeout period before cancellation of print jobs that cannot be received by the printer.
TCP/IPv4	Frame Type	IPv4 settings values.
	Use DHCP	
	Use BOOTP	
	Use RARP	
	Enable DNS Dynamic Update	
	Use Zeroconf Function	
	IP Address	
	Subnet Mask	
	Gateway Address	
	LPD Printing	
	IPP Printing	

432	

TCP/IPv4	IPP Printer URI	IPv4 settings values.
	RAW Printing	
	Raw Mode Bi-direction	
	FTP Printing	
	WSD Printing	
	Use Discovery	
	Scope	
	Primary DNS Server Address	
	Secondary DNS Server Address	
	DNS Host Name	
	DNS Domain Name	
	MulticastDNS ServiceName	
	SNMPv1	
	SNMPv3	

TCP/IPv6	Use IPv6	Use IPv6	
	Use DHCPv6	Stateful Address	
		Prefix Length	
		Primary DNS Server Address	
		Secondary DNS Server Address	
	Use a stateless address	Stateless Address 1	
		Prefix Length 1	
		Stateless Address 2	
		Prefix Length 2	
		Stateless Address 3	
		Prefix Length 3	
		Stateless Address 4	
		Prefix Length 4	
		Stateless Address 5	
		Prefix Length 5	
		Stateless Address 6	
		Prefix Length 6	
	Use a link-local Address	Link-Local Address	
l		Prefix Length	
	Use a manual address	IP Address	
		Prefix Length	
		Default Router Address	
		Prefix Length	
		Primary DNS Server Address	
		Secondary DNS Server Address	
	Use the same host name and do-	DNS Host Name	
	main name as IPv4	DNS Domain Name	
	Perform dynamic updating of statefu	Perform dynamic updating of stateful addresses	
	Dynamically update the stateless ad	dress	
	Dynamically update the manual add	Dynamically update the manual address	

\equiv
\supset
=
Œ
\neg
_
<
=
(I)
-
=
⊆

433

Network Interface	Network Interface	Physical Interface	Network interface settings values.
		Transmission Rate	
		MAC Address	
		Auto Detect	
		Communication	
		Ethernet Type	
		Spanning Tree	
		Use the Jumbo Frame Function	

Memo

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399

Printer Parts


Printer parts	436
Hard Disk	441
Optional accessories	445

Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

Printer parts

Front	
Top Cover (Inside) Roll Cover (Inside) Carriage Ink Tank Cover (Inside)	439
Control Panel	400

Front



- a Roll Cover
 - Open this cover to load rolls. (See "Roll Cover (Inside).") →P.439
- b Paper Feed Slot

When loading paper, insert it here.

c Roll Ledge

When loading rolls, rest the Roll Holder here before loading it in the Roll Holder Slot.

d Release Lever

When releasing the Paper Retainer, push this lever back.

e Control Panel

Use this panel to operate the printer and check the printer status. (See "Control Panel.") →P.400

f Ink Tank Cover

Open this cover to replace an Ink Tank. (See "Ink Tank Cover (Inside).") >P.440

g Paper Alignment Line

An orange line for alignment of paper.

h Maintenance Cartridge Cover

Open this cover to replace the Maintenance Cartridge.

i Maintenance Cartridge

Absorbs ink used for maintenance purposes such as head cleaning. (Replace the cartridge when it is full.)

i Cutter Unit

A round-bladed cutter for automatic roll cutting.

k Cutter Rail

The Cutter Unit passes over this rail to cut paper.

Output Tray

All printed documents are ejected from this slot.

m Ejection Guide

Supports output paper.

n Top Cover

Open this cover to install the Printhead and remove any jammed paper from inside the printer, as needed. (See "Top Cover (Inside).") >P.438

Width Guide

When loading the sheets, move the guide to match the paper size.


p Stand (Optional)

A stand that holds the printer. Equipped with casters to facilitate moving it. (See "Stand.") →P.446



 The Stand is normally offered as an optional accessory, but it may be provided as a standard accessory in some sales regions.

Side



437

Top Cover (Inside) iPF685

a Manual Pocket

Store printer manuals in this pocket.

b Ethernet Port

Connect an Ethernet cable to this port.

c USB Port

Connect a USB cable to this port. The printer is compatible with Hi-Speed USB connections.


d Carrying Handles

When carrying the printer, have three people hold it by these handles on the back at both ends. Grasp these parts on the left and right sides also when moving the printer with the stand attached.

e Power Supply Connector

Connect the power cord to this connector.

Top Cover (Inside)



a Carriage

Moves the Printhead. The carriage serves a key role in printing. (See "Carriage.") →P.439

b Carriage Shaft

The Carriage slides along this shaft.

c Paper Retainer

Important in supplying the paper. This retainer holds paper as it is fed.

d Platen

438

The Printhead moves across the platen to print. Vacuum holes on the platen hold paper in place.

e Borderless Printing Ink Grooves

For catching ink outside the edges of paper during borderless printing.


f Linear Scale

The linear scale serves a key role in detecting the Carriage position. Be careful not to touch this part when cleaning inside the Top Cover or clearing paper jams.

g Cleaning Brush

When cleaning inside the printer under the Top Cover, use this brush to sweep away paper dust on the Platen.

Roll Cover (Inside)



a Roll Holder

Load the roll on this holder.

b Holder Stopper

Secure rolls on the Roll Holder with this part.


c Roll Loading Slots

Slide the Roll Holder along these slots.

d Roll Holder Slot

Load the Roll Holder into this holder slot.

Carriage



439

Ink Tank Cover (Inside) iPF685

a Angle Adjustment Lever

Use this lever to fine-tune the printer to correct misalignment of printed lines.

b Printhead

The printhead is equipped with ink nozzles. The carriage serves a key role in printing.


c Printhead Fixer Lever

Locks the Printhead Fixer Cover.

d Printhead Fixer Cover

Holds the Printhead in place.

Ink Tank Cover (Inside)



a Ink Tank Lock Lever

A lever that locks the Ink Tank in place and protects it. Lift and press down the lever when replacing an Ink Tank.

b Ink Color Label

Load an Ink Tank that matches the color and name on this label.

c Ink Lamp (Red)

Indicates the state of the Ink Tank as follows when the Ink Tank Cover is opened.

• On

The Ink Tank is installed correctly.

Off

No Ink Tank is installed, or the ink level detection function has been released.

Flashing Slowly

Not much ink is left.

Flashing Rapidly

There is no ink left.

d Ink Tank

Cartridges of ink in various colors.

Hard Disk

Printer Hard Disk Operations	441
Checking the Free Hard Disk Space	442
Erasing Data on the Printer's Hard Disk	

Printer Hard Disk Operations

Printer hard disk operations are available from the following programs and interfaces.

- · Printer driver
- Free Layout
- Color imageRUNNER Enlargement Copy
- Preview
- imagePROGRAF Status Monitor
- imagePROGRAF Printmonitor
- RemoteUI
- Control Panel

The hard disk operations available through each interface are as follows.

Оре	eration	 Printer driver Free Layout Color imageRUNNER Enlargement Copy Preview 	 imagePROGRAF Status Monitor imagePROGRAF Printmonitor 	RemoteUI	Control Pan- el
Saving print jobs	Save in mail box	Yes	No	No	No
	Do Not Save Print Jobs in the Common Box	No	No	No	Yes
	Save print jobs sent from sources other than the printer driver	No	No	No	Yes
Operations with saved	Print saved jobs	No	Yes	Yes	Yes
jobs	Delete saved jobs	No	Yes	Yes	Yes
Job queue manage-	Display job queue	No	Yes	Yes	Yes
ment	Delete	No	Yes	Yes	Yes
	Preempt Jobs	No	Yes	Yes	Yes
	Operations with held jobs	No	Yes	Yes	Yes
Mail box management	Move saved jobs	No	Yes	Yes	No
	Modify saved jobs	No	Yes	Yes	No
	Modify mail boxes	No	Yes	Yes	No
	Print a list of saved jobs	No	No	No	Yes
	Display a list of saved jobs	No	Yes	Yes	Yes
Other operations	Display free hard disk space	No	Yes	Yes	Yes
	Initialize hard disk	No	No	No	Yes
	Display the time of printing	No	Yes	Yes	Yes
Display error messages		No	Yes	Yes	Yes

Checking the Free Hard Disk Space

Check the space available on the printer's hard disk as follows.

This operation is available from the Control Panel, in RemoteUI, imagePROGRAF Status Monitor, and image-PROGRAF Printmonitor.

Using the Control Panel

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (...).





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Job Menu** is displayed.
- 3 Press ▲ or ▼ to select HDD Information, and then press the OK button.

Using RemoteUI

To view the box list, select **Stored Job** in Job Management. On the **Stored Job** page, the free hard disk space is shown in the upper-right corner when boxes are listed.




For details, refer to the RemoteUI help file.

443

Using imagePROGRAF Status Monitor


The Hard Disk sheet shows the free hard disk space.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor

The Hard Disk pane shows the free hard disk space.



For details, refer to the imagePROGRAF Printmonitor help file.


Erasing Data on the Printer's Hard Disk

When erasing all data on the hard disk, choose from the following three options. This operation is only available from the Control Panel.

Erasure Method	Details
High Speed	Erases file management data for print job data stored on the printer's hard disk. Choose this method for relatively fast erasure. Because only the file management data is erased, the print job data itself is not erased. Note that it may be possible to read this data using commercial data recovery software.
Secure High Spd.	Overwrites the entire hard disk with random data. No verification is performed to check if the data was correctly written. Choose this method to erase highly confidential data. Note that it may be possible to read the overwritten data using specialized data recovery tools.
Secure	Overwrites the entire hard disk with 00, FF, and random data (one time each). Verification is performed to check if the data was correctly written. Choose this method to erase especially confidential data. It is virtually impossible to recover the overwritten data. Conforms to the DoD5220.22-M standard of the U.S. Department of Defense.



- For a more secure method of preventing data recovery, we recommend physically or magnetically destroying the hard disk. In this case, the hard disk can no longer be used.
- Erase HDD Data is not available if there is a job queue.
 Additionally, print jobs are not processed during execution of Erase HDD Data.
- 1 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (♣).





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select System Setup, and then press the OK button.
- 4 Press ▲ or ▼ to select Erase HDD Data, and then press the OK button.
- Press ▲ or ▼ to select **High Speed**, **Secure High Spd.**, or **Secure**, and then press the **OK** button to display the confirmation screen.



- If a password has been set on the printer, the Admin.Pswd screen is displayed. In this case, enter the
 password and press the OK button to go to the next step.
- As for the time required for deletion, confirm it on the Control Panel. However, when High Speed is selected, this finishes in several seconds.
- 6 Press ▲ or ▼ to select **Yes**, and then press the **OK** button to start erasure. After the printer hard disk is erased, the printer automatically restarts.


Optional accessories

Roll Holder Set	. 445
Stand	. 446


Roll Holder Set

Load a roll on the roll holder and then load the holder in the printer. The Roll Holder in the Roll Holder Set RH2-33 is for use with both 2-inch and 3-inch paper cores. Use the correct attachment for the particular paper core. (See "Attaching the Roll Holder to Rolls.") >P.338

- Roll Holder Set RH2-33
 - Roll Holder (for 2- and 3-inch paper cores)



Attachments




Stand

Stand iPF685

When using an optional Stand, you can store and stack documents printed on rolls.

Printer Stand ST-27



a Accessory Pocket

Stores printer accessories.

b Output Stacker

Printed documents are ejected into the output tray.

c Locking Caster

Lock to immobilize the caster.

Before moving the printer, always unlock all four casters. Moving the printer while casters are locked may scratch the casters or the floor.

d Adjustable Stopper

Pull out depending on the paper size when using the output stacker in the Extended position A. For details on the extended position, see "Using the Output Stacker." >P.365

e Paper Guide

Guides printed documents into the output stacker.

f Output stacker handle

This handle is grasped and supports the sliding output stacker when putting the output stacker into Extended position B and returning it to the regular position.

For details on the extended position, see "Using the Output Stacker." →P.365

g Output stacker release lever

Pull this lever towards you to release Extended position B.

For details on the extended position, see "Using the Output Stacker." >P.365

h Output Stacker Ejection Guides

This guide supports the paper that is output when using the output stacker in Extended position B.



The Stand that can be used with this printer is Printer Stand ST-27 and Printer Stand ST-26.

Note

- The Stand is normally offered as an optional accessory, but either one or the other of the Stand may be included as a standard accessory in some sales regions and periods.
- The output stacker of the Printer Stand ST-26 has a regular position and an Extended position A. For details on the extended position, see "Using the Output Stacker." >P.365
- The Stand is described in the illustration of Printer Stand ST-27. Note that the illustrations may look different from the appearance of your printer in some cases.

iPF685

User's Guide

Basic Printing Workflow	15
Basic I fifting Workhow	13
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435

Network Setting

Network Environment	448
Using RemoteUI	450
Initial Settings	452
Mac OS Settings	459
Other Settings	460
Device Setup Utility (Windows)	463

Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

Network Environment

Network Environment

System requirements

The system requirements, which vary depending on your network, are as follows.

- Printing over a TCP/IP network (when using IPv4)
 - · Compatible operating systems
 - Windows XP
 - Windows Server 2003
 - Windows Vista
 - Windows Server 2008
 - Windows 7
 - Windows 8
 - Windows Server 2003 x64
 - Windows Vista x64
 - Windows Server 2008 x64
 - Windows Server 2012 x64
 - Windows 7 x64
 - Windows 8 x64
 - OS X v10.6.8 or later
 - Unix (Solaris 9)
 - Unix (Red Hat 9)
- Printing over a TCP/IP network (when using IPv6)
 - · Compatible operating systems
 - Windows Vista
 - Windows Server 2008
 - Windows 7
 - Windows 8
 - Windows Vista x64
 - Windows Server 2008 x64
 - Windows Server 2012 x64
 - Windows 7 x64
 - Windows 8 x64
 - OS X v10.6.8 or later




- When using IPv6, you must specify IPv6 on the Control Panel or in RemoteUI. For instructions, "Configuring TCP/IPv6 Network Settings" →P.454 or see "Configuring the Printer's TCP/IP Network Settings With RemoteUI." →P.456
- The imagePROGRAF printer driver is not compatible with Unix.

Network Environment

After confirming what type of network environment you will connect the printer to, set up the printer and computers as needed. For the specifications of the network interface, see "Specifications." >P.622

• Example of a Windows network

In Windows networks, print over TCP/IP.






• NetBIOS is not supported.

Example of a Mac OS network

In Mac OS networks, print over TCP/IP using the Bonjour function.



Using RemoteUI iPF685

Using RemoteUI

Using RemoteUI

RemoteUI is software with which you can access the printer via the network from your Web browser to confirm the printer status, operate jobs, and configure the settings. Since the software (Web server) for using RemoteUI is built in the printer, preparing software other than a Web browser is unnecessary. You can use RemoteUI if an image-PROGRAF printer on a network is connected to your computer. If you start your Web browser and specify the IP address of the printer, the RemoteUI screen is displayed, and you can use RemoteUI.



• To use RemoteUI, an IP address must be set on the printer in advance. For the method of setting an IP address, see "Configuring the IP Address on the Printer." P.452


What You Can Do With RemoteUI

With RemoteUI, you can access the printer via a network, configure network settings, and display the current status of the printer, various types of information, the processing status of jobs, etc.

Starting RemoteUI

Start RemoteUI by the following operations.

- 1 Start your Web browser.
 - 2 Enter the following URL in **Address** or **Location**. http://printer IP address or name/
 Example: http://xxx.xxx.xxx.xxx/
- The RemoteUI screen is displayed.





• The screen slightly differs depending on the model of printer.

Configuring the Network With RemoteUI

For details on configuring printer settings for networks, refer to the following topics.

- Configuring the Printer's TCP/IP Network Settings With RemoteUI →P.456
- Specifying Printer-Related Information →P.460

iPF685 Using RemoteUI



• For the Web browser, use Netscape Navigator 6.0 or later, Internet Explorer 5.01 or later, or Firefox 1.5 or later. For Mac OS X, Safari 1.32 or later or 2.03 or later also is supported.

- This cannot be used connected via a proxy server. In environments where a proxy server is used, add the printer's IP address to Exceptions (addresses accessed without a proxy server) in the web browser proxy server settings. (Settings may vary depending on the network environment.)
- Enable JavaScript and cookies in the web browser.
- If you access RemoteUI with the printer name instead of its IP address, make sure the DNS settings are correctly configured.
- Depending on the network environment, you may not be able to start RemoteUI.
- Confirm whether **System Setup > Use RemoteUI** is set to **On** on the Control Panel of the printer.



- RemoteUI also offers many other features. You can display the ink levels, check error messages and other status
 information, and cancel print jobs.
- By factory default, the English screen is displayed. To change the display language, select the desired language under Language before logging on in administrator mode.
- If you login in Administrator Mode, you can configure to use the Jumbo Frame function in the **Network** page. However, this function might not be able to be used depending on the network environment.

Initial Settings

Configuring the IP Address on the Printer Configuring the IP Address Using imagePROGRAF Device Setup Utility Configuring the IP Address Using the Printer Control Panel Configuring the IP Address Using ARP and PING Commands	. 463 . 452
Configuring TCP/IPv6 Network Settings	. 454
Configuring the Printer Driver Destination (Windows)	
Configuring the Printer's TCP/IP Network Settings With RemoteUI	. 456

Configuring the IP Address on the Printer

You must configure the printer's IP address before using the printer in a TCP/IP network.

The printer's IP address is configured automatically when you install the printer driver following the instructions in the Setup Guide.

Configure the IP address by using **imagePROGRAF Device Setup Utility**, the printer Control Panel, or ARP or PING commands, if the IP address is changed, or if you change the printer connection mode to a network connection. For details on configuring the IP address, refer to the following topics.

- Configuring the IP Address Using imagePROGRAF Device Setup Utility →P.463 (Windows)
- Configuring the IP Address Using the Printer Control Panel →P.452
- Configuring the IP Address Using ARP and PING Commands →P.453



- If you use a DHCP server for automatic assignment of the printer's IP address, printing may no longer be possible after the printer is turned off and on. This is because an IP address different from before has been assigned.
 Thus, when using DHCP server functions, consult your network administrator and configure the settings in one of the following ways.
- Configure the setting for dynamic DNS updating
 In the printer menu, either set DNS Dync update to On, or activate the setting Enable DNS Dynamic Update in RemoteUI.

(See "Menu Settings.") →P.418

(See "Configuring the Printer's TCP/IP Network Settings With RemoteUI.") →P.456

• Configure the setting for assignment of the same IP address each time the printer starts up



 We recommend configuring the printer's IP address even if you will use the printer in networks other than TCP/IP networks. Configuring the printer's IP address enables you to use RemoteUI to configure the network settings and manage the printer with a web browser.

For details on RemoteUI, see "Using RemoteUI." >P.450


Configuring the IP Address Using the Printer Control Panel

This topic describes how to configure the printer's IP address on the Control Panel.



452

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (♣).





• If the Tab Selection screen is not displayed, press the Menu button.

453

- 2 Press the **OK** button.
 - The Set./Adj. Menu is displayed.
- Press ▲ or ▼ to select Interface Setup, and then press the OK button.
- Press ▲ or ▼ to select TCP/IP, and then press the OK button.
- 5 Press ▲ or ▼ to select IPv4, and then press the OK button.
- 6 Press ▲ or ▼ to select IPv4 Settings, and then press the OK button.
- 7 Press ▲ or ▼ to select IP Address, and then press the OK button.
- 8 After you press ◀ or ▶ to select the input field, numerical input is possible.
- Press the ▲ or ▼ button to enter the value.



- Pressing the ▲ button increases the number by 1. The maximum value is 9, after which 0 is displayed.
- Note Pressing the ▼ button decreases the number by 1. The minimum value is 0, after which 9 is displayed.
 - Hold down ▲ or ▼ to increase or decrease the value continuously.
 - Make sure the IP address you enter for the printer is not the same as any computer IP address in your network.
- 10 Repeat steps 8 and 9 to complete the settings, and then press the **OK** button.
- Press the **Menu** button.

 If you have changed the settings, a confirmation message is displayed. Press ▲ or ▼ to select **Yes**, and then press the **OK** button.





- Be sure to complete step 11. This will activate the values you have entered.
- Important If an error message is displayed, check the settings and correct any invalid values.



• You can also specify the subnet mask and default gateway on the Control Panel.


Configuring the IP Address Using ARP and PING Commands

This topic describes how to configure the IP address using ARP and PING commands.

To use the ARP and PING commands, you will need to know the printer's MAC address. You can confirm the MAC address on the Control Panel.

1 Check the printer's MAC address.
You can confirm the MAC address on the Control Panel as follows:

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (().



2. Press the **OK** button.

The Set./Adj. Menu is displayed.

- 3. Press ▲ or ▼ to select Interface Setup, and then press the OK button.
- **4.** Press **△** or **▼** to select **Ethernet Driver**, and then press the **OK** button.
- Press ▲ or ▼ to select MAC Address, and then press the OK button.



• If the **Tab Selection screen** is not displayed, press the **Menu** button.

Note • You can investigate the MAC address by printing an interface setting report. (See "Printing Interface Setting Reports.") →P.431

- In Windows, open a command prompt, or in Mac OS, start Terminal.
- 3 Execute the following command to add entries to the ARP table for managing IP addresses and corresponding MAC addresses.

arp -s [IP address] [the printer's MAC address you have verified] Example: arp -s xxx.xxx.xxx.xxx 00-1E-8F-xx-xx-xx



In Mac OS when using Terminal, enter the arp command in the format arp -s xxx.xxx.xxx.xxx 00:1E: 8F:xx:xx:xx. For details, refer to the help file for the command line.

Execute the following command to send the IP address to the printer and configure it. ping [IP address as specified in the ARP command] -I 479 Example: ping xxx.xxx.xxx.xxx -I 479



In -I, the I is the letter I.

Note

In Mac OS when using Terminal, enter the ping command in the format ping -s 479 xxx.xxx.xxx.xxx. For details, refer to the help file for the command line.




The subnet mask and default gateway are set to 0.0.0.0. Use RemoteUI to change the subnet mask and default gateway to match your network settings.

For details on RemoteUI, see "Using RemoteUI." →P.450

Configuring TCP/IPv6 Network Settings

When printing in a TCP/IPv6 network, you must configure the TCP/IPv6 settings on the Control Panel. Follow the steps below to configure the TCP/IPv6 network settings.

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (--).





If the Tab Selection screen is not displayed, press the Menu button.

- 454
- Press the **OK** button. The Set./Adj. Menu is displayed.
- Press ▲ or ▼ to select Interface Setup, and then press the OK button.
- Press ▲ or ▼ to select TCP/IP, and then press the OK button.
- Press ▲ or ▼ to select IPv6, and then press the OK button.

455

- 6 Press ▲ or ▼ to select IPv6 Support, and then press the OK button.
- 7 Press ▲ or ▼ to select On, and then press the OK button.



Once you set IPv6 Support to On, the IPv6 StlessAddrs setting takes effect.



You can also configure IPv6 StlessAddrs and DHCPv6 from the printer Control Panel.

Configuring the Printer Driver Destination (Windows)

This topic describes how to specify the printer driver destination if the printer's IP address is changed, or if you will use the printer over a network connection instead of via USB connection.

The procedure described below is the configuration based on the LPR or Raw protocol using the standard TCP/IP port in Windows (**Standard TCP/IP Port**).



- If you will use the printer in a TCP/IP network, make sure the printer's IP address is configured correctly.
- Important
 Configuring the IP Address on the Printer →P.452



This section describes the procedure in Windows 7.

- 1 Open the **Devices and Printers** window.
- 2 Right-click the icon of this printer and choose **Printer Properties** to open the printer properties window.
- 3 Click the **Port** tab to display the **Port** sheet.
- 4 Click **Add Port** to display the **Printer Ports** dialog box.
- 5 In the Available Port list, select Standard TCP/IP Port.
- Click New Port.

 After the wizard starts, a window is displayed for the Welcome to the Add Standard TCP/IP Printer Port Wizard.
- 7 Click Next.
- In **Printer Name or IP Address**, enter the printer's IP address. If the DNS is configured, you can also enter the DNS Domain Name.
- 9 Follow the instructions on the screen to add a printer port.
- 10 Click Close to close the Printer Ports dialog box.
- 11 Make sure the printer port you added is displayed under **Ports**, and that the port is selected.
- 12 Click Close to close the printer properties window.

Configuring the Printer Driver Destination (Mac OS)

Specify the printer driver destination as follows if the printer's IP address is changed, or if you will use the printer over a network connection instead of via USB connection.

 If you switch to printing in a TCP/IP network, or if the printer's IP address is changed, see "Configuring the Destination in TCP/IP Networks ." →P.459 • If you switch to printing in a Bonjour network, see "Configuring the Destination for Bonjour Network ." →P.459

Configuring the Printer's TCP/IP Network Settings With RemoteUI

Follow the steps below to configure the TCP/IP network settings.

When using an IPv4 IP address

1 Start the web browser and enter the following URL in the **Location** (or **Address**) box to display the RemoteUI page.

http://printer IP address or name/ Example: http://xxx.xxx.xxx.xxx/

2 Select Administrator Mode and click Logon.



- If a password has been set on the printer, enter the password.
- 3 Click **Network** in the **Device Manager** menu at left to display the **Network** page.
- 4 Click **Edit** in the upper-right corner of the **TCP/IPv4** group to display the **Edit TCP/IP Protocol Settings** page.
 - 5 Refer to the TCP/IP Settings Items table to complete the settings.

TCP/IP Settings Items

Item	Details	Default Setting
Use DHCP	Activate this setting to use DHCP for configuring the IP address.	Off
Use BOOTP	Activate this setting to use BOOTP for configuring the IP address.	Off
Use RARP	Activate this setting to use RARP for configuring the IP address.	Off
Enable DNS Dynamic Update	Activate this setting to perform DNS server registration automatically.	Off
Use Zeroconf Func- tion	Activate this setting to use Bonjour.	On
IP Address	Specify the printer's IP address.	0.0.0.0
Subnet Mask	Specify the printer's subnet mask.	0.0.0.0
Gateway Address	Specify the printer's default gateway.	0.0.0.0
LPD Printing	Activate this setting to use LDP Printing.	On
IPP Printing	Activate this setting to use IPP Printing.	On
IPP Printer URI	Specify the URI of the printer used for IPP printing using up to 252 characters.	printer
RAW Printing	Activate this setting to use Raw Printing.	On
RAW Mode Bi-direction	Activate this setting to use Raw mode bidirectional communication.	Off
FTP Printing	Activate this setting to use FTP Printing.	On
Use Discovery	Activate this setting to use SLP Discovery function.	On
Scope	Enter the SLP search range.	default
SMTP Server Address	Specify the SMTP server's IP address. You can also specify the SMTP server domain name, if desired.	0.0.0.0
Primary DNS Server Address	Specify the IP address of the primary DNS server.	0.0.0.0
Secondary DNS Server Address	Specify the IP address of the secondary DNS server.	0.0.0.0

Item	Details	Default Setting
DNS Host Name	Specify the printer host name, up to 63 characters (1–63 characters). Use single-byte letters, numbers, and - (hyphens). Do not use numbers or - for the first character or - for the last character.	NB-18GBipxxxxxx
DNS Domain Name	Specify the printer domain name, up to 63 characters. Use single-byte letters, numbers, - (hyphens), and . (periods). Do not use numbers, -, or . for the first character, or - or . for the last character.	blank
Multicast DNS Service Name	Specify the printer's Multicast DNS service name. (1–63 characters) This name will be displayed when Bonjour functions are used.	Canon iPFxxxx (xxxxxx)

6 Click **OK** to display the **Network** page.



- If you specify to configure the IP address using DHCP, BOOTP, or RARP, there must be a server that supports such protocol running in the network.
- If you specify to configure the IP address using DHCP, BOOTP, or RARP, the IP address obtained by this method is used first. If you cannot obtain the IP address, the address specified in **IP Address** is used.
- It takes up to two minutes to determine whether DHCP, BOOTP, or RARP are available. We recommend clearing check boxes of options you will not use.
- If you are using a DNS server, select Enable DNS Dynamic Update and enter the IP Address for DNS servers and DNS domain name in Primary DNS Server Address, Secondary DNS Server Address and DNS Domain Name, respectively.

When using an IPv6 IP address

1 Start the web browser and enter the following URL in the **Location** (or **Address**) box to display the RemoteUI page.

http://printer IP address or name/ Example: http://xxx.xxx.xxx.xxx/

2 Select Administrator Mode and click Logon.



- If a password has been set on the printer, enter the password.
- 3 Click **Network** in the **Device Manager** menu at left to display the **Network** page.
- Click Edit in the upper-right corner of the TCP/IPv6 group to display the Edit TCP/IPv6 Protocol Settings page.
- Refer to the TCP/IPv6 Settings Items table to complete the settings.

TCP/IPv6 Settings Items

	Item	Details	Default Setting
Use IPv6		Activate to enable IPv6.	Off
Use DHCPv	6	Activate when using a DHCPv6 server to acquire the IP address.	Off
Use a statel	ess address	Activate when using an IPv6-compatible router to acquire the IP address.	On
Use a manual address		Activate when configuring the IP address manually.	Off
	IP Address	Enter the printer's IP address.	::
	Prefix Length	Enter the IP address prefix length.	
	Default Router Address	Enter the default router address.	::
	Prefix Length	Enter the prefix length of the default router address.	
Primary DNS Server Address		Specify the IP address of the primary DNS server.	::

457

	Item	Details	Default Setting
Secondary D	ONS Server Address	Specify the IP address of the secondary DNS server.	::
Use the same host name and do- main name as IPv4		Activate when using the same DNS host and domain names as for IPv4.	Off
	DNS Host Name	Specify the printer host name, up to 63 characters (1–63 characters). Use single-byte letters, numbers, and - (hyphens). Do not use numbers or - for the first character or - for the last character.	NB-18GBip6xxxxxx
	DNS Domain Name	Specify the printer domain name, up to 63 characters. Use single-byte letters, numbers, - (hyphens), and . (periods). Do not use numbers, -, or . for the first character, or - or . for the last character.	blank
Perform dynamic updating of state- ful addresses		Activate this setting to automatically register the stateful address with the DNS server.	Off
Dynamically update the stateless address		Activate this setting to automatically register the stateless address with the DNS server.	Off
Dynamically dress	update the manual ad-	Activate this setting to automatically register the manual address with the DNS server.	Off

6

Click **OK** to display the **Network** page.



• If you are using a DNS server, select **Enable DNS Dynamic Update** and enter the IP Address for DNS servers and DNS domain name in **Primary DNS Server Address**, **Secondary DNS Server Address** and **DNS Domain Name**, respectively.

Mac OS Settings

Configuring the Destination in TCP/IP Networks

If you use the printer in a TCP/IP network, register the printer in **Print & Scan** (This is identified as **Printers & Scanners** or **Print & Fax** in other versions of Mac OS.) in the Mac OS **System Preferences**.



• For details on how to register a printer using a TCP/IP network, see the OS User Manual.



 If you use the printer in a TCP/IP network, make sure the printer's IP address is configured correctly. (See "Configuring the IP Address Using the Printer Control Panel.") →P.452

Configuring the Destination for Bonjour Network

If you use the printer in a network that uses the Bonjour function, register the printer in **Print & Scan** (This is identified as **Printers & Scanners** or **Print & Fax** in other versions of Mac OS.) in the Mac OS **System Preferences**.



• For details on how to register a printer using Bonjour, see the OS User Manual.



- Bonjour and IP Print (Auto) do not support printing to a printer on other network groups that require a router for connection. Make sure the computer and printer are on the same network. For information about network settings, ask your network administrator.
- By default, Bonjour is activated on the printer. You can activate or deactivate the Bonjour function or change the printer name by using RemoteUI. For instructions on changing it, see "Using RemoteUI." (>P.450)

Other Settings

Specifying Printer-Related Information	460
Configuring the Communication Mode Manually	461
Email Notification When Printing is Finished or Errors Occur	462
nitializing the Network Settings	462

Specifying Printer-Related Information

Follow the steps below to specify device information and security settings.

1 Start the web browser and enter the following URL in the **Location** (or **Address**) box to display the RemoteUI page.

http://printer IP address or name/ Example: http://xxx.xxx.xxx.xxx/

2 Select Administrator Mode and click Logon.



- If a password has been set on the printer, enter the password.
- 3 Click Information in the Device Manager menu at left to display the Information page.
- To display the relevant settings page, click **Edit** in the upper-right corner of **Device Information** or **Security**, depending on what information you want to specify.

 To change the administrator password, click the **Change Password** button in the **Security** group.
- Refer to the table of settings for device information and security as you complete these settings. Security setting items are displayed when you click the **Change Password** button in the **Security** group. Device Information Settings

Item	Details	Default Setting
Device Name	Enter a device name. (0–32 characters)	blank
Location	Enter the location where the device is installed. (0–32 characters)	blank
Administrator	Enter the administrator's name. (0–32 characters)	blank
Phone	Enter the administrator's contact information. (0–32 characters)	blank
Comments(E-mail)	Enter any comments regarding the administrator. (0–32 characters)	blank

Security Settings


Item	Details	Default Setting
New Password	Enter the new password. (0-9999999)	blank
Confirm	Enter the new password again to confirm it. (0-9999999)	blank

- *1:On the **Security** settings screen, besides entering a password, you can specify other security-related information, such as IP address-based SNMP or TCP usage restrictions, MAC address-based access restrictions, or IPP and FTP authentication settings.
- 6 Click **OK** to activate the settings.

Configuring the Communication Mode Manually

This topic gives instructions for configuring the communication mode manually.

1 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (♣).





- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- 3 Press ▲ or ▼ to select Interface Setup, and then press the OK button.
- Press ▲ or ▼ to select **Ethernet Driver**, and then press the **OK** button.
- 5 Press ▲ or ▼ to select Auto Detect, and then press the OK button.
- 6 Press ▲ or ▼ to select **Off**, and then press the **OK** button. The display reverts to the **Ethernet Driver** menu.
- 7 Press ▲ or ▼ to select Comm.Mode, and then press the OK button.
- Press ▲ or ▼ to select the communication mode, and then press the **OK** button. The display reverts to the **Ethernet Driver** menu.
- Press ▲ or ▼ to select **Ethernet Type**, and then press the **OK** button.
- Press ▲ or ▼ to select the Ethernet type, and then press the **OK** button. The display reverts to the **Ethernet Driver** menu.
- 11 Press ▲ or ▼ to select **Spanning Tree**, and then press the **OK** button.
- Press ▲ or ▼ to enable or disable spanning tree support, and then press the **OK** button. The display reverts to the **Ethernet Driver** menu.
- Press the **Menu** button.


 After the confirmation message is displayed, press the **OK** button.

 The new settings will take effect after the printer restarts.



Email Notification When Printing is Finished or Errors Occur

The printer can notify you of the printer status by email. Even when you are away from the printer, you can know when printing is finished or if errors occur. Receive notification via email on your mobile phone or at your computer.



Use the **imagePROGRAF Status Monitor** (Windows) function to set up email recipients and message timing. Besides being informed of finished print jobs or errors, you can also complete settings for email notification when service is needed or it's time to replace consumables. For detailed instructions,see "Specifying Printer-Related Information." >P.460



- For details on email notification using **imagePROGRAF Status Monitor** (in Windows), refer to the **imagePROGRAF Status Monitor** help.
- Mail server authentication is only supported with imagePROGRAF Status Monitor.

Initializing the Network Settings

Use RemoteUI to restore the network settings to the default values as follows.



- Initializing the network settings will also restore the default value of the printer's IP address. As a result, the RemoteUI page cannot be displayed in the web browser after this procedure.
- For instructions on reconfiguring the IP address, see "Configuring the IP Address on the Printer." →P.452
- For details on RemoteUI, see "Using RemoteUI." →P.450
- Start the web browser and enter the following URL in the **Location** (or **Address**) box to display the RemoteUI page.

http://printer IP address or name/ Example: http://xxx.xxx.xxx/

2 Select Administrator Mode and click Logon.



- If a password has been set on the printer, enter the password.
- 3 Click **Network** in the **Device Manager** menu at left to display the **Network** page.
- 4 Click Reset to Default settings in the lower-right corner of the Network Interface group.
- After confirming the message, click **OK** to restore the network settings to the default values.



 You can also use imagePROGRAF Device Setup Utility or the Control Panel to restore the default network settings.

Device Setup Utility (Windows)

magePROGRAF Device Setup Utility	463
nstalling imagePROGRAF Device Setup Utility	463
Configuring the IP Address Using imagePROGRAF Device Setup Utility	463

imagePROGRAF Device Setup Utility

imagePROGRAF Device Setup Utility is a utility to establish communication between the printer and your computer by completing relevant settings. After the printer is installed, for example, you can use **imagePROGRAF Device Setup Utility** to complete the network settings initially.



- Starting **imagePROGRAF Device Setup Utility** will show a list of printers found on the network. In this list, select the printer (specifically, the printer's MAC address) that you want to set up, and then configure the basic settings from your computer, such as the printer's IP address and the network frame type.
- You can see which printers are online in the network by checking the printer list. Communication between your computer and these printers is possible.



- We recommend that your network or printer administrator complete the setup work using imagePROGRAF Device Setup Utility.
- For details, refer to the imagePROGRAF Device Setup Utility help.

Installing imagePROGRAF Device Setup Utility

Install **imagePROGRAF Device Setup Utility** from the User Software CD-ROM provided with the printer as follows:

- 1 Insert the User Software CD-ROM in the CD-ROM drive.
- On the Setup Menu window, click Install Individual Software.
- Click Install in imagePROGRAF Device Setup Utility.
- Follow the instructions on the screen to proceed with the installation.

Configuring the IP Address Using imagePROGRAF Device Setup Utility

On a computer running Windows, you can use **imagePROGRAF Device Setup Utility** provided with the printer to configure the printer's IP address. This topic describes how to configure the IP address using **imagePROGRAF Device Setup Utility**.



To configure network settings, you must be logged in with administrative rights such as Administrator account.
 We recommend that your network administrator configure the network settings.




• For instructions on installing imagePROGRAF Device Setup Utility, see "Installing imagePROGRAF Device Setup Utility." →P.463

When specifying an IPv4 IP address

1 Start imagePROGRAF Device Setup Utility from the start menu.



- 2 In the **Device Name** list displayed, select the printer to configure.
- 3 Choose **Protocol Settings** from the **Printer** menu.
- 4 Select the IPv4 tab.



- 5 In the Setting IP Address list, choose Manual.
- 6 Enter the IP address assigned to the printer and click the **Set** button.
- 7 Click **OK** after the **Confirmation** message is displayed.
- 8 Exit imagePROGRAF Device Setup Utility.




- To configure the IP address automatically, choose Auto in the Setting IP Address list and select DHCP, BOOTP, or RARP.
- · You can also specify the subnet mask and default gateway.

When specifying an IPv6 IP address

1 Start imagePROGRAF Device Setup Utility from the start menu.



- 2 In the **Device Name** list displayed, select the printer to configure.
- 3 Choose **Protocol Settings** from the **Printer** menu.
- 4 Select the IPv6 tab.



- 5 In IPv6, select On.
- When there is an IPv6-compatible router in the network environment, select **On** in **Stateless Address**. Additionally, when there is an DHCPv6-compatible server in the network environment, select **On** in **DHCPv6**.



- When there is no IPv6-compatible router or DHCPv6-compatible server, select On in Manual and enter the IPv6 Address and Prefix Length.
- 7 Click Set.
- 8 Click **OK** after the **Confirmation** message is displayed.
- 9 Exit imagePROGRAF Device Setup Utility.

Memo

DING SIES

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447

Print Job Management


Status Monitor (Windows)	468
Printmonitor (Mac OS)	470
Accounting (Windows)	472
Basic Print Job Operations	484
Advanced Print Job Operations	503


Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

Status Monitor (Windows)

The Features of imagePROGRAF Status Monitor

imagePROGRAF Status Monitor is a utility for checking the printer status and managing print jobs. Two screens are available in imagePROGRAF Status Monitor: **Printer List** shows a list of printers, and **Status Monitor** shows details for each printer.





- You can view a list of the printers for which printer drivers have been installed on your computer, printers connected to your computer, and printers found on the network.
- If a printer error occurs, you can investigate the corrective action immediately.
- Printer status can be checked in real time on a computer monitor.
- Displays the ink level of every color in the printer. An icon and warning message will notify you when ink levels
 are low.
- The type of paper loaded in each media source is identified. You can also check to see if paper has run out.
- This way, the utility enables you to check printer information and take care of printer maintenance for optimal printing results.
- You can also set up automatic email notification of any printer problems or errors to email addresses you designate in advance.
- You can check the status of the hard disk and the documents saved on the hard disk.
- You can use the Accounting Manager to collect the print job logs for the printers and check information such as the printing costs.
 - For details of the Accounting Manager, see "Accounting Manager." →P.472


468



For details, refer to the imagePROGRAF Status Monitor help.

Job Management Using imagePROGRAF Status Monitor

You can use the **Job** sheet in imagePROGRAF Status Monitor for operations such as pausing and canceling print jobs.



Preempting Other Jobs

If you select a print job and click the **Preempt Other Jobs** button, the selected job is printed ahead of the job that currently precedes it in the print queue.

Pausing/Resuming Print Jobs

Selecting a print job and clicking the **Pause** button pauses printing of the selected job.

To resume printing of a paused print job, select the print job and click the **Resume** button.



Once all the print data for a print job has been sent to the printer, the job can no longer be paused/resumed.

· Canceling Print Jobs

Selecting a print job and clicking the Cancel Job button cancels printing of the selected job.



You cannot cancel other users' print jobs.

Printing Held Jobs

Printing of the job with a **Status** of **Holding** is paused because the paper specified by the driver does not match the paper currently loaded in the printer.

Use the procedure below to print the held job.

- 1 Select the held job and click the Replace Paper button.
- 2 Replace the paper in the printer with the correct paper.




- To continue printing without changing the paper in the printer, select the held job and click Continue to print button.
- The printing behavior when the paper specified by the driver does not match the paper currently loaded in the printer can be changed by using **Detect Mismatch** in the operation panel menu. Refer to "Menu Settings" →P.418 for details.

Printmonitor (Mac OS)

The Features of imagePROGRAF Printmonitor	470)
Job Management Using imagePROGRAF Printmonitor	.471	L

The Features of imagePROGRAF Printmonitor

imagePROGRAF Printmonitor is a utility for checking the printer status and managing print jobs.




- Printer status can be checked in real time on a computer monitor.
- You can check the status of print jobs, cancel jobs, and manage them as needed.
- If a printer error occurs, you can investigate the corrective action immediately.
- You can also set up automatic email notification of any printer problems or errors to email addresses you designate in advance.
- You can check the status of the hard disk and the documents saved on the hard disk.



- If the status of the desired printer is not shown in imagePROGRAF Printmonitor, select the printer again as follows.
- 1. Make sure the printer is on and connected to the network or to a local port.
- 2. In the **Printer** menu, select the name of the desired printer. After the printer is detected, the printer status is shown.
- **3.** If information about the printer is not shown in step 2, choose **Search Printer** in the **Printer** menu. Printer names listed in the **Printer** menu are updated with the printers that are now detected.
- **4.** In the **Printer** menu, select the name of the desired printer. After the printer is detected, the printer status is shown.

Job Management Using imagePROGRAF Printmonitor

You can use the **Driver** Panel in imagePROGRAF Printmonitor for operations such as pausing and canceling print jobs.



• Pausing/Resuming Print Jobs

Selecting a print job and clicking the button pauses printing of the selected job.

To resume printing of a paused print job, select the print job and click the button



• Once all the print data for a print job has been sent to the printer, the job can no longer be paused/resumed.

· Canceling Print Jobs

Selecting a print job and clicking the button cancels printing of the selected job.



You cannot cancel other users' print jobs.

Preempting Other Jobs

If you select a print job and click the button, the selected job is printed ahead of the job that currently precedes it in the print queue.

Printing Held Jobs

Printing of the job with a **Status** of **Holding** is paused because the paper specified by the driver does not match the paper currently loaded in the printer.

Use the procedure below to print the held job.

- 1 Select the held job and click the **Replace Paper** button.
- 2 Replace the paper in the printer with the correct paper.



 To continue printing without changing the paper in the printer, select the held job and click Continue to print button.

Accounting Manager iPF685

Accounting (Windows)

Accounting ManagerLaunching the Accounting Manager	. 472 . 472
Accounting Manager Main Window	. 473 475
Accounting Manager Basic Procedures	
Configuring Unit Costs in Accounting Manager	476 . 477
Setting the Unit Cost for Paper	478
Configuring Units and Display Settings in Accounting Manager	
Automatically Acquiring Print Job Logs at Regular Intervals	
Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs	
Exporting Print Job Data as a CSV File	. 481
Displaying Job Properties or Period Properties	483
Showing the Total Amount of Ink and Paper Consumed	. 483

Accounting Manager

The Accounting Manager stores the printer's print job logs so that you can use the information for checking printing costs, etc.

The benefits of using the Accounting Manager are outlined below.

- Print Job Log Collection
 This allows you to check which documents were printed from each printer, who printed them and when.
- Calculation of the Total Pages Used and the Total Cost
 This allows you to use the collected print job logs to calculate totals for items such as the number of pages printed, the amount of paper used and the printing costs incurred.
- Regular Data Acquisition for Print Jobs
 Job logs can be automatically collected periodically.
- Exporting Print Job Data
 This allows you to export collected print job data as a CSV file.



- The Accounting Manager in Status Monitor displays approximate estimates of the amount of paper consumed and the ink consumed per job. Canon cannot guarantee the accuracy of these estimates. These estimates will also vary depending on the conditions of printer use.
- Print job log collection is not performed when Set./Adj. Menu -> System Setup -> Show Job Log of the control
 panel is Off. However,
 - even if Show Job Log is set to Off, regularly acquired jobs that already have been retrieved at that time are displayed.
 - When **Show Job Log** has been set to **On** again, all jobs within the printer at that time are displayed.


Launching the Accounting Manager

The procedure for launching the Accounting Manager is shown below.

1 Open the imagePROGRAF Status Monitor window.



Select **Accounting** in the **Accounting** menu. Or, open the **Accounting** sheet and click the **Accounting** button.






- If Show Job Log is set to off and an administrator password is configured in the printer, the administrator password needs to be entered on startup.
 - If the password is correct, you are logged on as administrator and Accounting starts. Furthermore, when you exit from Accounting, you can choose to log off as administrator.
- If you log off as administrator, you need to enter the password again the next time it starts.
- The administrator password can be set or cleared using Chg.Admin.Pswd/Init.Admin.Pswd in the Admin. Menu in the Set./Adj. Menu in the printer.

The administrator menu can only be displayed and configured by the administrator.

Accounting Manager Main Window

The Accounting Manager main window consists of a title bar, menu bar, toolbars, listed job selection area, job list area, totals area and status bar.



• Title Bar

This displays the printer model, its serial number and the port number it is using.



Menu Bar

Allows you to select the menu options required for operation.



Toolbars

Provide tool buttons and pull-down menus for the main operations.






• You can opt to either show or hide the toolbars in the View menu.

Listed Job Selection Area

You can use this area to select which job log is displayed.

If you are using regular data acquisition, this area allows you to view the collective job logs for each specified period.




For more information on how to select the job logs displayed, see "Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs." >P.481

Job List Area

This area lists the details of acquired jobs.

Displays a list of the jobs in the printers or periodically acquired jobs. (See "Job List Area.") →P.475






You can change the items that are displayed and the display order using the Advanced Display Settings
dialog box. The Advanced Display Settings dialog box can be displayed by selecting Advanced Display
Settings from the Show menu.

Totals Area

Displays the total costs for the selected job and the amounts of paper and ink consumed.






• If you are viewing regularly acquired print jobs, selecting a period on the left side of the window displays the total costs for that period and the amounts of paper and ink consumed.

iPF685 Job List Area

Status Bar

Displays messages and other information.



Job List Area

The job items and details that can be displayed in the job list area are as follows.

No.

The job serial number.

Job Cost

The cost of printing.



• If the ink and paper unit costs are not set, **** is displayed.

Document Name

This is the name of the printed document.

Printing Results

OK is displayed when the print process was executed, and **Cancel** is displayed if the print process was not executed.

Media Type

This is the type of paper used in printing.

Output Image Size

The size of the image used for printing.



• If the job has multiple pages, the size of the last page is displayed.

Paper Consumed

The area of paper used for printing.



• The Paper Consumed may differ from the product of Paper Width and Paper Length.

Paper Width

The width of paper used for printing.



• If the job has multiple pages, the width of the last page is displayed.

Paper Length

The length of paper used for printing.

Ink Consumed

The amount of ink used for printing.

Owner

The sender of the job.

Print Job Start Time/Print Time

The time when printing started and the time taken to print.

Number of Pages

The number of pages printed.

Roll Paper Width

The width of roll paper used for printing.

Paper Cost

The cost of paper used for printing.



• If the paper unit cost is not set, **** is displayed.

Total Ink Cost

The total value of the cost of ink used for printing.



If the ink unit cost is not set, **** is displayed.

Note

Total of Other Costs

The total value of costs other than paper and ink.

Ink Cost Details

The cost of each ink color.

Ink Consumption Details

The amount of each color of ink used.

Accounting Manager Basic Procedures

The first time you use the Accounting Manager, use the following procedures to configure the settings.

- 1 Configure unit costs, including the costs of ink and paper.

 For details of the unit cost settings, see "Configuring Unit Costs in Accounting Manager." →P.476
- Set options such as the units displayed.

 For details of the unit settings, see "Configuring Units and Display Settings in Accounting Manager."

 P480
- If you are using Regular Data Acquisition, configure the Regular Data Acquisition settings. For details of the Regular Data Acquisition settings, see "Automatically Acquiring Print Job Logs at Regular Intervals." >P.480
- Specify the jobs to be listed.
 For details of how to select the job logs displayed, see "Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs."

 P.481

This displays the required print job logs and lists the details.

476

Configuring Unit Costs in Accounting Manager

Select **Unit Costs** in the **Settings** menu to open the **Unit Costs** dialog box. Configure the unit cost settings in this dialog box.




• When you select a job and then open the **Unit Costs** dialog box, items with unit costs that have not yet been configured for that job are shown highlighted.

• Setting the Unit Cost for Ink →P.477

- Setting the Unit Cost for Paper →P.478
- Setting the Unit Cost for Items Other Than Ink and Paper →P.479

Setting the Unit Cost for Ink

Open the Ink sheet. Set the unit cost for ink in this sheet.



To set the same unit cost for all the inks

- 1 Select the Use same price for all ink checkbox.
- 2 Enter the Tank Capacity and corresponding Price.
- 3 Click the **OK** button.
 - Important
- Your settings are not applied until you click the OK button.

To set different unit costs for each ink color

- 1 Select the ink color to be costed.
- 2 Enter the Tank Capacity and corresponding Price.
- 3 Click the **Overwrite** button.
- 4 Repeat steps 1 to 3 for all the inks.
- 5 Click the **OK** button.




Your settings are not applied until you click the OK button.

Setting the Unit Cost for Paper iPF685

Setting the Unit Cost for Paper

Opens the **Paper** sheet. This sheet is used to configure the unit cost of paper.




Setting Standard Prices

- 1 Select the media type in Media Type.
- 2 Enter the **Width** and **Length** of the paper, as well as the **Price** for the area of the configured width x height.
- Click the **Add** button. To change the unit cost of a media type that has already been configured, click the **Overwrite** button.
- 4 Click the **OK** button.
 - Important

• The settings are not applied until you click the OK button.

Specifying Price by Roll Paper

- 1 Select the media type in Media Type.
- Click the Roll Paper Width Settings button to display the Roll Paper Width Settings dialog box.



Print Job Management

Accounting (Windows)


- 3 Enter the Roll Paper Width and Length of the paper, as well as the Price for the configured length.
- 4 Click the **Add** button to return to the **Paper** sheet.
- 5 To change the unit cost of a media type that has already been configured, click the **Overwrite** button.
- 6 Click the **OK** button.



- If you do not set the standard prices, you cannot set the price for each roll paper.
- If the Roll Paper Width is set to the same value as the Width of the paper configured in the standard prices, the cost is calculated using the price configured in the Roll Paper Width Settings dialog box.
 - The settings are not applied until you click the OK button.

Setting the Unit Cost for Items Other Than Ink and Paper

Open the **Other** sheet. Use this sheet to set any price for items other than inks and paper.



- 1 Enter any name in the Name field.
- 2 Enter a value in **Unit Cost**.
- 3 Use Allocated to specify whether the costs are allocated as being incurred by the print job.
- 4 Click the **Add** button. To change the unit cost for a media type you have already set, click the **Overwrite** button.
- 5 Click the **OK** button.



• Your settings are not applied until you click the **OK** button.


User's Guide



You can set unit costs for up to 5 items.

Configuring Units and Display Settings in Accounting Manager

Select **Units and Display** in the **Settings** menu to open the **Units and Display** dialog box. Use this dialog box to configure the display settings.



Date Display Format

Use this option to select the display format for dates. "YYYY" indicates the year, "MM" the month and "DD" the day.

Currency Unit

Enter the currency unit. Enter a text string up to 3 characters long.

• 1000 Separator

Use this option to select the symbol used as a separator in numbers. The symbol is inserted every 3 digits.

Decimal Symbol

Use this option to select the symbol used as a decimal point.

Ink Consumed

Use this option to select the unit used for ink consumption.

Paper Width

Use this to select the unit used for paper width.

Paper Length

Use this to select the unit used for paper length.

Area Display Format

Use this to select the unit used for paper area.

Automatically Acquiring Print Job Logs at Regular Intervals

This feature collects print job logs from the printer at regular intervals and saves the logs on your computer.

- 1 Select Regular Data Acquisition in the Settings menu.
- 2 Select Acquire print job logs regularly.
- 3 Click the **OK** button to close the dialog box.



Print job log collection is not performed when Set./Adj. Menu -> System Setup -> Show Job Log of the control
panel is Off. However, even if Show Job Log is set to Off, regularly acquired jobs that already have been retrieved at that time are displayed.



- Immediately after you configure Regular Data Acquisition, no print jobs are displayed. Wait a few moments and then select **Refresh** in the **View** menu to display the print jobs.
- A maximum of 10,000 records are saved in a print job log. If this number is exceeded, jobs are deleted from the log starting from the oldest record. To save old data, it is recommended that you export the data as a CSV file.
 For details of how to export print job logs as CSV files, see "Exporting Print Job Data as a CSV File." → P.4481

Canceling Regular Print Job Log Acquisition

You can use this procedure to cancel the regular acquisition of print job logs from printers.

- Select Regular Data Acquisition in the Settings menu.
- 2 Uncheck the Acquire print job logs regularly option.
- Click the **OK** button to close the dialog box.

Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs

The print job logs displayed by the Status Monitor Accounting Manager contain two types of job: Jobs on Printer and Regularly Acquired Jobs.

You can select whether to display Jobs on Printer or Regularly Acquired Jobs in the Listed Job Selection Area on the left side of the window.

Jobs on Printer

This shows a list of the print jobs currently held on printers.

You can change the number of jobs displayed per page using the **Print Jobs Shown Per Page** setting in the **View** menu or the toolbar.

You can skip to a particular page using the **Go to** option in the **View** menu or the toolbar.



- For printers with built-in hard disks, you can view up to 500 print jobs per printer.
- For printers without built-in hard disks, you can view up to 32 print jobs per printer. However, only 10 jobs can be displayed if the printer is switched off.

Regularly Acquired Jobs

This shows a list of regularly acquired print jobs.

To view all the jobs in a set period, specify the period using **Calculate Total for Period** and then **Starting Date** (or **Starting Day of Week** or **Starting Month**) in the **View** menu or the toolbar.

For example, to view monthly job logs starting on the 1st of each month, set **Calculate Total for Period** to **Monthly** and set **Starting Date** to **1**.



• Up to 10,000 regularly acquired jobs are displayed for each printer.

Exporting Print Job Data as a CSV File

You can export the collected print job data in the form of a CSV file by selecting **Export Job Cost Data** in the **File** menu.



• You can also select **Export Job Cost Data** using the icon in the toolbar.

Selected Jobs

Exports the data for the selected print jobs in the job list as a CSV file.



You can select multiple jobs by holding down the Shift key or Ctrl key as you click the job names.

Listed Jobs

Exports the data for the print jobs currently displayed in the list as a CSV file.

Displaying Job Properties or Period Properties

You can display the **Job properties** dialog box or **Period Properties** dialog box to check detailed cost information and other items.

The **Job properties** dialog box displays detailed information about the selected job.

The Period Properties dialog box displays detailed information within the Regularly Acquired Jobs period.

Displaying the Job properties Dialog Box

Select a job from the job list, and then select **Show Job Properties** from **Job properties** in the **File** menu. You can also select multiple jobs at once.



You can also display the dialog box by selecting a job, right-clicking it, and then selecting Show Job Properties, or by using the icon in the toolbar.


Displaying the Period Properties Dialog Box

Select a period from the **Regularly Acquired Jobs** list, and then select **Show Period Properties** from **Job properties** in the **File** menu. You can also select multiple periods at once.



 You can also display the dialog box by selecting and right-clicking a period and then selecting Show Period Properties, or by using the icon in the toolbar.

• Components of the Job properties Dialog Box/Period Properties Dialog Box



Job ta

Displays detailed information about the selected job. You can display detailed information about each job by selecting the corresponding **Document Name**.

Owner tab

You can display detailed information about each owner by selecting the corresponding **Owner**.

Copy button
 Click this button to copy the displayed text information to the clipboard.

Accounting (Windows)

Showing, Saving and Loading Selected Unit Cost Data

Show Unit Cost Data

Select **Show Unit Cost Data** in the **File** menu to open the **Unit Cost Data** dialog box. This lists the unit costs for items such as the selected ink and paper.

You can copy text-based information in this dialog box to the clipboard by clicking the Copy button.

Save Unit Cost Data

Select a destination folder using **Save Unit Cost Data** in the **File** menu. The unit cost data for items such as the selected ink and paper is saved as a file.

Load Unit Cost Data

Selecting Load Unit Cost Data in the File menu loads saved unit cost data.

Showing the Total Amount of Ink and Paper Consumed

Select Show Ink and Paper Consumed in the File menu to open the Show Ink and Paper Consumed dialog box.

This lists the total amounts of ink and paper consumed by the printer so far.

You can copy text-based information in this dialog box to the clipboard by clicking the **Copy** button.



• Up to 7 types of media are listed in order of the amount consumed. The total consumption for other media types is shown as **Other**.

Using the Printer Hard Disk iPF685


Basic Print Job Operations

Using the Printer Hard Disk	484
Saving Print Jobs on the Printer Hard Disk	. 488
Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs	.496

Using the Printer Hard Disk

The printer can save print jobs on the built-in hard disk.

Using print jobs stored on the printer enables you to print the jobs again as needed without using a computer.



Saving print jobs offers the following benefits.

Save the time spent using a computer

When you send a print job to the printer, you can save it on the printer after printing or simply save it on the printer without printing it yet. Saved print jobs can be printed in the required quantity later without the need to use a computer again.

• Simplify reprinting, if any errors occur

If errors occur in the middle of printing (as when paper runs out), you can resume printing after clearing the error without resending the print job from a computer.

Streamline printing work

Without using a computer, you can select print jobs and print in the desired quantity. You can also select multiple print jobs to print during the same period. This enables unattended operation at night, for example.

Output Method

To save print jobs on the printer's hard disk, configure the printer driver.

In Windows, this is set using the **Output Method** dialog box.

In Mac OS, this is set using the **Additional Settings** pane.

Print

Save print jobs on the printer's hard disk after printing.

Save in mail box


Save print jobs on the printer's hard disk.

Print after reception is complete

This option is available in combination with **Print**. You can prevent degradation of print quality that occurs when receiving a print job is interrupted and printing is aborted in the middle.

Storage destination

The storage area on the printer's hard disk is divided into a temporary storage area and a permanent storage area. The temporary storage area stores print jobs in the job queue or shared mailbox. The permanent storage area stores jobs in personal boxes.



Job queue

The job queue refers to print jobs that are being processed by the printer (saved, received, prepared for processing, printed, deleted, or held). Up to 64 jobs can be stored in the temporary storage area.

When the job queue is full, additional jobs sent from a computer are treated as "standby" jobs, to be processed when possible.

However, if all queued jobs are simply being held, the oldest job is deleted and the print job sent from the computer is processed.

Shared mailbox

Jobs for which you have specified **Print** in **Output Method** (in Windows) or **Send job to** (in Mac OS) are saved in the shared mailbox and classified as saved jobs.

There is one shared mailbox, numbered **00**. A password cannot be set for the shared mailbox.

Up to 100 print jobs can be saved here, but they will be deleted one after another starting with the oldest job in the following situations.

- If there are more than 100 jobs queued and saved in the shared mailbox combined
- If no more temporary storage space is available when jobs for which you have selected Print in Output Method (in Windows) or Send job to (in Mac OS) are received
- If there is not enough space in the temporary or permanent storage area when jobs for which you have selected **Save in mail box** in **Output Method** (in Windows) or **Send job to** (in Mac OS) are received

Personal boxes

Jobs are classified as saved jobs and saved in personal boxes in the following situations.


- When a saved job stored in the shared mailbox is moved to a personal box
- When you have selected **Save in mail box** as the option in **Output Method** (in Windows) or **Send job to** (in Mac OS)

There are 29 personal boxes, numbered **01** to **29**. You can specify a name and password for each personal box

Up to 100 print jobs can be saved in all personal boxes combined.

Saving Print Jobs on the Printer Hard Disk

To save print jobs on the printer's hard disk, configure the printer driver.






- Printing from the following software also enables you to save print jobs on the printer's hard disk.
 Windows
 - Free Layout →P.182
 - Color imageRUNNER Enlargement Copy →P.203
 - Preview →P.172

Mac OS


- Free Layout →P.289
- Color imageRUNNER Enlargement Copy →P.312
- Preview →P.172

Configuring the Printer Driver in Windows

1 Access the Page Setup sheet.



Click Output Method to display the Output Method dialog box.



- 486
- 3 Make your selection in Output Method.
 - Print

Save print jobs on the printer's hard disk after printing.

Save in mail box

Save print jobs on the printer's hard disk.

If you choose Save in mail box, also specify the destination personal box in the Mail box list.

Print after reception is complete

This option is available in combination with **Print**. You can prevent degradation of print quality that occurs when receiving a print job is interrupted and printing is aborted in the middle.




Click Acquire Mail Box Name to display personal box names in the Mail box list, as acquired from the
printer.

- 4 In Name of data to be saved, specify how to name saved print jobs.
 - To use the file name, choose Use file name.
 - Otherwise choose **Enter name** and enter a name in **Name**.
- 5 Click **OK** to close the **Output Method** dialog box.

Configuring the printer driver in Mac OS

1 Access the Additional Settings pane.




- 2 Make your selection in Send job to.
 - Print

Save print jobs on the printer's hard disk after printing.

Save in mail box

Save print jobs on the printer's hard disk.

The **Destination** dialog box is displayed if you select **Save in mail box**. Here, specify the name and personal box number for saved print jobs.



1. In **Document title**, enter a name to identify saved print jobs.



If printed from Free Layout or Preview, the **Document title** is saved under the name image-PROGRAF.

- 2. Select the personal box number in the Mail box list.
- 3. Click **OK** to close the **Destination** dialog box.
- · Print after reception is complete


This option is available in combination with **Print**. You can prevent degradation of print quality that occurs when receiving a print job is interrupted and printing is aborted in the middle.

Managing the Job Queue (Deleting or Preempting Other Jobs)


Print jobs being processed by the printer are collectively called the job queue. You can delete or preempt jobs in the job queue as needed.

These operations are available from the Control Panel, in RemoteUI, imagePROGRAF Status Monitor, and image-PROGRAF Printmonitor.

Delete
 Note that only jobs that are not currently being deleted can be deleted from the job queue.



Preempting other jobs
 You can preempt other jobs by printing jobs that are currently being received or prepared for processing first.





• For information on managing jobs being held, see "Managing Pending Jobs (Printing or Deleting Jobs on Hold)." →P.490

Using the Control Panel

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (.).



Basic Print Job Operations






Note

- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Job Menu** is displayed.
- 3 Manage the job queue as needed.
 - Deleting jobs
 - Press ▲ or ▼ to select Print Job, and then press the OK button.
 - Press ▲ or ▼ to select the print job to delete, and then press the OK button.
 - 3. Press ▲ or ▼ to select **Delete**, and then press the **OK** button.
 - Preempting other jobs
 - 1. Press ▲ or ▼ to select **Print Job**, and then press the **OK** button.
 - 2. Press ▲ or ▼ to select the job to print first, and then press the **OK** button.
 - 3. Press ▲ or ▼ to select **Preempt Jobs**, and then press the **OK** button.


Using RemoteUI

Manage jobs as needed on the **Print Job** page. For details, refer to the RemoteUI help file.




Using imagePROGRAF Status Monitor (Windows)

Manage jobs as needed on the **Job** sheet. For details, refer to the imagePROGRAF Status Monitor help file.



Using imagePROGRAF Printmonitor (Mac OS)

Manage jobs as needed on the **Driver** sheet. For details, refer to the imagePROGRAF Printmonitor help file.



Managing Pending Jobs (Printing or Deleting Jobs on Hold)

If the type or size of paper loaded does not match the settings in the print job received when you have set **Detect Mismatch** to **Hold Job** in the Control Panel menu, the print job is held on the printer as a pending job in the job queue.

Manage held jobs such as these as follows.

These operations are available from the Control Panel or in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.




- As long as you do not manage held jobs from the Control Panel, imagePROGRAF Status Monitor, or imagePROGRAF Printmonitor, they will remain in the job queue. In this case, the printer processes the next job in the queue without pausing.
- To print held jobs, replace the loaded paper with the paper specified in the print job. (See "Loading Rolls in the Printer.") →P341 (See "Loading Sheets in the Printer.") →P359

Using the Control Panel

1 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (♣:::).

"There are held jobs." is displayed if jobs are being held.





- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Job Menu** menu is displayed.
- Press ▲ or ▼ to select **Print Job**, and then press the **OK** button.



Press \blacktriangle or \blacktriangledown to select the print job to manage, and then press the **OK** button.

Held jobs are labeled with an icon.






Press ▲ or ▼ to select **Print Anyway** or **Delete**, and then press the **OK** button.

- If you choose Print Anyway
 Press ▲ or ▼ to select Yes or No, and then press the OK button.
- If you choose Delete
 Press ▲ or ▼ to select Yes or No, and then press the OK button.


Using RemoteUI

Manage jobs as needed on the Print Job page. For details, refer to the RemoteUI help file.




Using imagePROGRAF Status Monitor

Manage jobs as needed on the **Job** sheet. For details, see "**Job Management Using imagePROGRAF Status Monitor**." →P.469



Using imagePROGRAF Printmonitor


Manage jobs as needed on the **Driver** sheet. For details, see "Job Management Using imagePROGRAF Printmonitor." >P.471



Printing Saved Jobs

Print saved print jobs stored on the printer's hard disk as follows.

These operations are available from the Control Panel or in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.



Using the Control Panel

1 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (.................................).





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Job Menu** menu is displayed.
- Press ▲ or ▼ to select **Stored Job**, and then press the **OK** button.
- Press ▲ or ▼ to select the box number (in the range 00–29), and then press the **OK** button.




• Enter a password if one has been set, and then press the **OK** button.

- 5 Press ▲ or ▼ to select Job List, and then press the OK button.
- 6 Press ▲ or ▼ to select the saved job, and then press the **OK** button.
- 7 Press ▲ or ▼ to select **Print**, and then press the **OK** button.
- Specify the number of copies and press the **OK** button.

Using RemoteUI

1 On the **Stored Job** page, choose the box.




Enter a password if one has been set.

Note



2 Select the print job and click **Resume**.




On the **Print Saved Document** page, enter the quantity to print in **Copies** and click **OK**.



For details, refer to the RemoteUI help.

Using imagePROGRAF Status Monitor

On the **Hard Disk** sheet, select a box and click **Open**.




Note •


• Enter a password if one has been set.



In the **Documents** dialog box, select the print job and click **Print**.



In the **Print** dialog box, enter the quantity to print in **Copies** and click **OK**.



Printing Saved Jobs

iPF685




• The printing time initially indicates how long it took to finish printing one copy during the previous print job. If you change the value in **Copies**, the printing time indicates the time it took to print one copy during the previous print job multiplied by the number of copies.

For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor

1 On the Hard Disk pane, click ▶ by Inbox No./Name.








Enter a password if one has been set.
 The password is a four-digit number.



2 Select the saved job and click Resume Printing.







For details, refer to the imagePROGRAF Printmonitor help file.

Deleting Saved Jobs

Delete saved print jobs stored on the printer's hard disk as follows.

This operation is available from the Control Panel, in RemoteUI, imagePROGRAF Status Monitor, and image-PROGRAF Printmonitor.

Using the Control Panel

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (....).





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Job Menu** is displayed.
- Press ▲ or ▼ to select **Stored Job**, and then press the **OK** button.
- Press ▲ or ▼ to select the box number (in the range 00–29), and then press the **OK** button.



- Enter a password if one has been set, and then press the **OK** button.
- 5 Press ▲ or ▼ to select Job List, and then press the OK button.
- 6 Press ▲ or ▼ to select the saved job, and then press the **OK** button.
- 7 Press ▲ or ▼ to select **Delete**, and then press the **OK** button.
- 8 Press ▲ or ▼ to select **Yes**, and then press the **OK** button.

Using RemoteUI

1 On the **Stored Job** page, choose the mail box.




Note •

• Enter a password if one has been set.




2 Select the print job and click **Delete**.



For details, refer to the RemoteUI help file.

Using imagePROGRAF Status Monitor

On the **Hard Disk** sheet, select a box and click **Open**.






• Enter a password if one has been set.




In the **Documents** dialog box, select the print job and click **Delete**.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor

In the Hard Disk pane, click ▶ next to Inbox No./ Name.






Enter a password if one has been set.
 The password is a four-digit number.





Select the print job and click the **Delete** button.




For details, refer to the imagePROGRAF Printmonitor help file.

Moving Saved Jobs

Print jobs stored on the printer's hard disk (saved jobs) can be moved from the current box to another box as follows.

However, jobs saved in personal boxes cannot be moved to the shared mailbox.

This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.





 Jobs stored in the shared mailbox may be automatically deleted under some conditions. To prevent jobs from being deleted, move them from the shared mailbox to personal boxes. (See "Using the Printer Hard Disk.") → P.484

Using RemoteUI

1 On the **Stored Job** page, choose the box.






Enter a password if one has been set.





Select the print job and click Move Document.




On the **Move Document** page, select the name or number of the destination personal box in the **Destination mail box** list and click **OK**.



For details, refer to the RemoteUI help file.

Using imagePROGRAF Status Monitor (Windows)

On the **Hard Disk** sheet, select a box and click **Open**.




Note


Enter a password if one has been set.



In the **Documents** dialog box, select the print job and click **Move**.




In the **Move** dialog box, select the destination personal box and click **OK**.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Mac OS)

In the Hard Disk pane, click ▶ next to Inbox No./ Name.







Enter a password if one has been set.
 The password is a four-digit number.



2 Select the print job and click **Move**.



In the **Move Document** dialog box, select the destination personal box and click **OK**.




For details, refer to the imagePROGRAF Printmonitor help file.

Advanced Print Job Operations

Saving Print Jobs Sent from Sources Other than the Printer Driver	503 504
Setting Passwords for Personal Boxes Naming Personal Boxes	
Displaying a List of Saved Jobs Printing a List of Saved Jobs Displaying Details of Saved Jobs Renaming Saved Jobs	513 514
→ Printer Hard Disk Operations→ Checking the Free Hard Disk Space	

Saving Print Jobs Sent from Sources Other than the Printer Driver

To save print jobs sent from software or systems other than the printer driver or applications provided with the printer, complete the **Output Method** and **Print After Recv** settings in the Control Panel menu.






Contact the software or system developer for information about support for this printer function.

Specifying Output Method

In **Output Method**, specify how to manage jobs, regarding printing and saving them.

- Print
 Save print jobs automatically at the same time they are printed. (This is the default format.)
- Print (Auto Del)
 Save print jobs temporarily at the same time they are printed and delete them after printing.
- Save: Box 01 (Here, the number represents a box number)
 Save print jobs on the printer.
- On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (♣).





If the Tab Selection screen is not displayed, press the Menu button.

- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- 3 Press ▲ or ▼ to select **System Setup**, and then press the **OK** button.





Press ▲ or ▼ to select **Output Method**, and then press the **OK** button.


- If a password has been set on the printer, the Logon screen is displayed.
 To change the settings, select Administrator and press the OK button. When the Admin.Pswd screen is displayed, enter the password and press the OK button to proceed to the next step.
 - If you select User and press the OK button, you can check settings values but cannot change them.
- Press ▲ or ▼ to select Print, Print (Auto Del), or Save: Box 01. Follow these steps only when you select Save: Box 01.
- 6 Press ▲ or ▼ to select the box, and then press the **OK** button.

Specify Print After Recv

To save print jobs on the hard disk before printing, specify **Print After Recv**.

Printing will start when **Print After Recv** is set to **On**, even if you have selected **Save: Box 01** in **Output Method**.

1 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (♣).






- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select **System Setup**, and then press the **OK** button.
- 4 Press ▲ or ▼ to select **Print After Recv**, and then press the **OK** button.
- 5 Press ▲ or ▼ to select On or Off, and then press the OK button.

Printing Without Saving Jobs in the Common Box

Jobs sent from a computer for which you have selected **Print** in **Output Method** (in Windows) or **Send job to** (in Mac OS) in the printer driver are saved in the shared mailbox. (See "Using the Printer Hard Disk.") >P.484
When **Save: Common Box** is **Off** in the Control Panel menu, print jobs for which you have selected **Print** in the **Output Method** dialog box of the printer driver are deleted from the shared mailbox after printing.
Use this function when printing highly confidential documents.





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.

- Press ▲ or ▼ to select **System Setup**, and then press the **OK** button.
- 4 Press ▲ or ▼ to select Save: Common Box, and then press the OK button.



• If a password has been set on the printer, the **Logon** screen is displayed.

To change the settings, select **Administrator** and press the **OK** button.

When the **Admin.Pswd** screen is displayed, enter the password and press the **OK** button to proceed to the next step.


If you select **User** and press the **OK** button, you can check settings values but cannot change them.

5 Press ▲ or ▼ to select **Off**, and then press the **OK** button.

Setting Passwords for Personal Boxes

For greater security, you can specify a password for personal boxes. After you set a password, it will be required to modify the personal box settings, as well as to display, print, delete, move, and modify jobs saved in the personal box.

This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.






- By default, no passwords are set for personal boxes.
- A password cannot be set for the shared mailbox.
- Enter a four-digit number as the password, in the range 0001–9999.
- Even if you have set passwords, they are not required to access personal boxes in Administrator Mode in RemoteUI.

Using RemoteUI

- 1 On the **Stored Job** page, choose the personal box.
- 2 Click Edit.




- In the Set/Register User's Inbox dialog box, specify the password and click OK.
 - Set Password Select the check box.
 - Password
 Enter the password. (This field is limited to four digits in the range 0001–9999.)
 - Confirmation Number
 Re-enter the password to confirm it.




For details, refer to the RemoteUI help.

Using imagePROGRAF Status Monitor (Windows)

On the **Hard Disk** sheet, select the personal box and click **Open**.



2 In the **Documents** dialog box, click **Settings**.




- In the **Settings** dialog box, specify the password and click **OK**.
 - Set password Select the check box.
 - Password

Enter the password. (This field is limited to four digits in the range 0001–9999.)

• Re-enter to confirm


Re-enter the password to confirm it.




For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Mac OS)

1 On the **Hard Disk** pane, click ▶ by **Inbox No./Name**. Select a saved job in the list and click **Set**.



- In the **Settings** dialog box, specify the password and click **OK**.
 - Set password Select the check box.
 - Password
 Enter the password. (This field is limited to four digits in the range 0001–9999.)
 - Verify
 Re-enter the password to confirm it.



507

For details, refer to the imagePROGRAF Printmonitor help file.

Naming Personal Boxes iPF685


Naming Personal Boxes

For easier identification, you can assign names to personal boxes.

This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.

Using RemoteUI

1 On the **Stored Job** page, choose the personal box.




Note

 Enter a password if one has been set for the personal box.



2 Click Edit.



In the **Set/Register User's Inbox** dialog box, enter the name in **Inbox Name** and click **OK**.


For details, refer to the RemoteUI help file.



Naming Personal Boxes

Using imagePROGRAF Status Monitor (Windows)

On the **Hard Disk** sheet, select the personal box and click **Open**.







 Enter a password if one has been set for the personal box.



2 In the **Documents** dialog box, click **Settings**.



In the **Settings** dialog box, enter the name and click **OK**.




For details, refer to the imagePROGRAF Status Monitor help file.

510

Using imagePROGRAF Printmonitor (Mac OS)

In the Hard Disk pane, click ▶ next to Inbox No./ Name. Select a saved job in the list and click Set.



Note

Enter a password if one has been set.
 The password is a four-digit number.



In the **Settings** dialog box, enter the name and click **OK**.



For details, refer to the imagePROGRAF Printmonitor help file.

Displaying a List of Saved Jobs

Print jobs stored on the printer's hard disk (saved jobs) can be listed by box as follows. These operations are available from the Control Panel or in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.

Using the Control Panel

On the **Tab Selection screen** of the Control Panel, press **◄** or **▶** to select the Job tab (...).





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Job Menu** is displayed.
- Press ▲ or ▼ to select **Stored Job**, and then press the **OK** button.
- Press ▲ or ▼ to select the box number (in the range 00–29), and then press the **OK** button.
 - Enter a password if one has been set, and then press the **OK** button. Note
- 5 Press ▲ or ▼ to select **Job List**, and then press the **OK** button.

Using RemoteUI

On the **Stored Job** page, choose the box.






Enter a password if one has been set.




Jobs saved in the box are listed.



For details, refer to the RemoteUI help.


Using imagePROGRAF Status Monitor (Windows)

On the Hard Disk sheet, select a box and click Open.






Jobs saved in that box are displayed in the Documents dialog box.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Mac OS)

On the **Hard Disk** pane, click by **Inbox No./Name**.





Enter a password if one has been set.
 The password is a four-digit number.



For details, refer to the imagePROGRAF Printmonitor help file.

Printing a List of Saved Jobs

The list of print jobs stored on the printer's hard disk (saved jobs) can be printed by box as follows.





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button. The **Job Menu** is displayed.
- Press ▲ or ▼ to select **Stored Job**, and then press the **OK** button.



Press ▲ or ▼ to select the box number (in the range 00–29), and then press the **OK** button.



• Enter a password if one has been set, and then press the **OK** button.



Press ▲ or ▼ to select **Print Job List**, and then press the **OK** button.

Displaying Details of Saved Jobs

Details of print jobs stored on the printer's hard disk (saved jobs) can be displayed as follows.

This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.

Using RemoteUI

1 On the **Stored Job** page, choose the box.




Note

• Enter a password if one has been set.



2 Select the print job and click **Details**.




The **Details of the saved document** page is displayed.



For details, refer to the RemoteUI help file.

Using imagePROGRAF Status Monitor (Windows)

On the Hard Disk sheet, select a box and click Open.




• Enter a password if one has been set.


Note



In the **Documents** dialog box, select the print job and click **Properties**.




The **Properties** dialog box is displayed.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Mac OS)

In the Hard Disk pane, click ▶ next to Inbox No./ Name.





Enter a password if one has been set.
 The password is a four-digit number.



For details, refer to the imagePROGRAF Printmonitor help file.


Renaming Saved Jobs

Print jobs stored on the printer's hard disk (saved jobs) can be renamed as follows. This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.

Using RemoteUI

Note

1 On the **Stored Job** page, choose the box.




516


Enter a password if one has been set.




2 Select the print job and click **Details**.



On the **Details of the saved document** page, click **Change Document**.




In the **Rename Saved Document** dialog box, enter the name and click **OK**.



For details, refer to the RemoteUI help file.

Using imagePROGRAF Status Monitor (Windows)

On the **Hard Disk** sheet, select a box and click **Open**.







• Enter a password if one has been set.



In the **Documents** dialog box, select the print job and click **Properties**.




In the **Properties** dialog box, enter the new name and click **OK**.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Mac OS)

In the Hard Disk pane, click ▶ next to Inbox No./
Name.






Enter a password if one has been set.
 The password is a four-digit number.



2 Select the print job and click **Set**.



In the **Settings** dialog box, enter the new name and click **OK**.



For details, refer to the imagePROGRAF Printmonitor help file.

Memo

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467

Adjustments for Better Print Quality

Adjusting the Printhead	522
Adjusting the feed amount	529

Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

Adjusting the Printhead

Adjusting the Printhead	522
Automatic Adjustment to Straighten Lines and Colors	
Manual Adjustment to Straighten Lines and Colors	
Adjusting Line Misalignment	525
Troubleshooting Paper Abrasion and Blurry Images	527

Adjusting the Printhead

If printed documents are affected by the following problems, try adjusting the printhead.

- Printing is faint or affected by banding in different colors
 Execute Nozzle Check to check for printhead nozzle clogging.

 For instructions, see "Checking for Nozzle Clogging." >P.546
- - (See "Automatic Adjustment to Straighten Lines and Colors.") →P.523 (See "Manual Adjustment to Straighten Lines and Colors.") →P.523
- Printed lines are misaligned
 Execute Head Inc. Adj. to adjust the angle of inclination of the printhead.
 Even slight misalignment can be corrected.
 (See "Adjusting Line Misalignment.") >P.525
- Paper rubs against the printhead, or image edges are blurred
 Executing Head Height to adjust the printhead height may improve printing results.

 (See "Troubleshooting Paper Abrasion and Blurry Images.") →P.527

Automatic Adjustment to Straighten Lines and Colors

If printed vertical lines are warped or colors are out of alignment, execute **Head Posi. Adj.** to adjust the Printhead alignment.

There are two modes for automatic Printhead adjustment: Auto(Standard) and Auto(Advanced).

Auto(Standard) will fix most slight image distortion or color misalignment, but if not, try **Auto(Advanced)**. Use **Auto(Standard)** or **Auto(Advanced)** to have the printer print and read a test pattern for automatic adjustment of the Printhead.







- This function is not available with Tracing Paper, Translucent Matte Film, or Clear Film.
- If adjustment is not possible as expected using special media, try another type of paper, or try Manual adjustment

(See "Manual Adjustment to Straighten Lines and Colors.") →P.523



- Because the results of adjustment vary depending on the type of paper used for adjustment, use the same type of paper as you will use for printing.
- Use Auto(Standard) if you have switched to another type of paper or if you want the boundaries between colors to appear as clear as possible.
- Use Auto(Advanced) to fine-tune the space between nozzles or colors if you have switched the printhead or if clearer printing is required. We recommend Auto(Advanced) for printing at the highest level of quality.

iPF685

Adjusting the Printheac

Paper to Prepare


When Using Rolls	An unused roll at least 10 inches wide
When Using Sheets	Auto(Standard): One sheet of unused paper of at least A4/Letter size Auto(Advanced): Six sheets of unused paper of at least A4/Letter size (or one sheet when using A2 or larger)

Perform adjustment as follows.

- 1 Load the paper.
 - Attaching the Roll Holder to Rolls →P.338
 - Loading Rolls in the Printer →P.341
 - Loading Sheets in the Printer →P.359



- Always make sure the loaded paper matches the type of paper specified on the printer. Adjustment cannot be completed correctly unless the loaded paper matches the settings.
- 2 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (().





- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select Adjust Printer, and then press the OK button.
- 5 Press ▲ or ▼ to select **Head Posi. Adj.**, and then press the **OK** button.
- Press ▲ or ▼ to select Auto(Standard) or Auto(Advanced), and then press the OK button. A test pattern is printed for adjustment.

 Adjustment is now finished if you have printed on a roll or a sheet of A2 size or larger.
- If you are printing on sheets smaller than A2 size for **Auto(Advanced)**, a confirmation message is displayed requesting you to continue printing. Press the **OK** button and follow the instructions displayed.

Manual Adjustment to Straighten Lines and Colors


If printed vertical lines are warped or colors are out of alignment, execute **Head Posi. Adj.** to adjust the Printhead alignment.

Normally, execute Standard.

(See "Automatic Adjustment to Straighten Lines and Colors.") →P.522

However, when printing on special paper, or if printing is not improved after **Standard**, try **Manual**.

Manual adjustment requires you to examine the printed test pattern and enter an adjustment value.







We recommend using the type of paper you use most often for adjustment.

Items to Prepare


When Using Rolls	An unused roll at least 254.0 mm (10.00 in) wide	1
When Using Sheets	Two sheets of unused paper, A4/Letter size (or one sheet when using A2)	1

Perform adjustment as follows.

- 1 Load paper.
 - Attaching the Roll Holder to Rolls →P.338
 - Loading Rolls in the Printer →P.341
 - Loading Sheets in the Printer →P.359



- Always make sure the loaded paper matches the type of paper specified on the printer. Adjustment cannot be completed correctly unless the loaded paper matches the settings.
- 2 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (📆).






- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select Adjust Printer, and then press the OK button.
- 5 Press ▲ or ▼ to select **Head Posi. Adj.**, and then press the **OK** button.
- Press ▲ or ▼ to select **Manual**, and then press the **OK** button. A test pattern is printed for adjustment.



- Manual may be unavailable in some cases, even if it is displayed in the menu.
 If so, execute Standard once.
 (See "Automatic Adjustment to Straighten Lines and Colors.") →P.522
- If you printed on cut sheets, follow the instructions on the Display Screen and use another sheet of the same type of paper.
- 7 Press ▲ or ▼ to select **D**, and then press the **OK** button.
- 8 Press ▲ or ▼ to select **D-1**, and then press the **OK** button.



Examine adjustment test pattern **D-1** and determine the number with straight lines.





 If two patterns seem equally good and you cannot decide which one is better, choose an intermediate value.

For example, choose 11 if you cannot decide whether pattern 10 or 12 is better.

- 10 Press ▲ or ▼ to select the pattern number you have decided, and then press the **OK** button.
- Repeat steps 8–10 to specify the adjustment value for **D-2** to **D-17**. Note that **D-6** and **D-12** cannot be configured.
- 12 Press the Back button.
- 13 Press ▲ or ▼ to select Register Setting, and then press the OK button.
- Press ▲ or ▼ to select Yes, and then press the OK button.

 The adjustment value is now registered, and adjustment is complete.

Adjusting Line Misalignment

If printed lines are misaligned, execute **Head Inc. Adj.** to adjust the angle of inclination of the Printhead. Executing **Head Inc. Adj.** requires you to examine a printed test pattern and enter an adjustment value.

Paper to Prepare


Rolls	An unused roll at least 10 inches wide
Sheets	One sheet of unused paper of at least A4/Letter size

Perform adjustment as follows.

- 1 Load the paper.
 - Attaching the Roll Holder to Rolls → P.338
 - Loading Rolls in the Printer →P.341
 - Loading Sheets in the Printer →P.359



- When loading paper, specify the type of paper correctly. Using paper that you have not specified on the printer may cause feeding problems and affect the printing quality.
- We recommend loading a type of paper that you use often.
- 2 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (♣).






If the **Tab Selection screen** is not displayed, press the **Menu** button.

User's Guide


- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
 - Press ▲ or ▼ to select **Adjust Printer**, and then press the **OK** button.
- Press ▲ or ▼ to select **Head Inc. Adj.**, and then press the **OK** button.

 After the Carriage is moved, a message is displayed requesting you to open the Top Cover.
- 6 Open the Top Cover.




- Important
- If you accidentally move the Carriage, you will hear a warning tone. In this case, close the Top Cover.
- 7 Align the Angle Adjustment Lever with the red square and close the Top Cover.

A test pattern is printed for adjustment.



Important

Do not touch the Linear Scale (a) or Carriage Shaft (b).
 Touching these parts may damage them.



526


8 Examine the test pattern for adjustment. Determine the straightest set of lines.





Open the Top Cover and move the Angle Adjustment Lever to match the number (or the square) of the straightest set of lines.


If no single set of lines is perfectly straight, move the Angle Adjustment Lever to a position between the numbers (or between the number and the square) of the two sets of lines that are least misaligned.





Close the Top Cover.

The Printhead is now straight, and adjustment is complete.



Troubleshooting Paper Abrasion and Blurry Images

The Printhead height setting affects printing quality.

Specifying a low Printhead height makes images clearer and enhances printing quality but may cause paper to rub against the Printhead.

On the other hand, specifying a high Printhead height will prevent paper from rubbing against the Printhead but may reduce the printing quality.



 Paper rubbing against or becoming caught on the Printhead may jam or result in printed documents that are soiled.



- Raise or lower the printhead, depending on the nature of the problem.
 - (See "Paper rubs against the Printhead.") →P.584
 - (See "The edges of the paper are dirty.") → P.585
 - (See "Image edges are blurred or white banding occurs.") →P.588
- On the Tab Selection screen of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





If the Tab Selection screen is not displayed, press the Menu button.

- Press the **OK** button.
 The **Paper Menu** is displayed.
- Press ▲ or ▼ to select Paper Details, and then press the OK button.




Press ▲ or ▼ to select the type of paper, and then press the **OK** button.



When Head Height is set to Automatic, the setting value selected for the previous print job is displayed (to the right of Automatic) once you select the type of paper currently supplied. However, the value is cleared when the printer is turned off or the paper is replaced.

Press ▲ or ▼ to select the desired setting value, and then press the **OK** button.







- Using **Automatic** will ensure that the printer adjusts the Printhead height to the optimal level before printing, accounting for the ambient temperature and humidity. When a setting other than **Automatic** is used, that value will always be applied.
- Depending on the type of paper, some setting values may not be available.

Adjusting the feed amount

Adjusting the Feed Amount	529
Selecting a Feed Amount Adjustment Method	
Automatic Banding Adjustment	
Manual Banding Adjustment	
Fine-Tuning the Paper Feed Amount	
Adjusting Line Length	
Adjusting the Vacuum Strength	535

Adjusting the Feed Amount

If printed documents are affected by the following problems, try adjusting the feed amount.

- · Banding in different colors
- · Line length is not accurate in the direction paper is fed

To adjust the feed amount, do the following, in this order.

- Depending on the issue, adjust **Adj. Priority** to suit the particular type of paper. (See "Selecting a Feed Amount Adjustment Method.") →P.529
- Execute Adj. Quality or Adjust Length, depending on the selection in Adj. Priority.

 (See "Automatic Banding Adjustment.") →P.530

 (See "Manual Banding Adjustment.") →P.531

 (See "Adjusting Line Length.") →P.533
- After executing Adj. Quality, execute Adj. Fine Feed for further adjustment as needed. (See "Fine-Tuning the Paper Feed Amount.") >P.533

Selecting a Feed Amount Adjustment Method

Methods of adjusting the amount paper is fed are set in **Adj. Priority**. Adjust **Adj. Priority** to suit your particular printing application.

- Print Quality: Adjusts the feed amount to reduce banding across the sheet in printed documents.
 Adj. Quality settings are applied. When Adj. Fine Feed is executed, the Adj. Fine Feed settings are applied in addition to the Adj. Quality settings.
- **Print Length**: Adjusts the feed amount for better accuracy of lines in printed documents. The settings of **A:High** or **B:Standard/Draft** in **Adjust Length** are applied.
- Automatic: Print Quality or Print Length is selected, depending on Print Priority as selected in the printer driver at the time of printing.

Image or Office Document: Print Quality is selected.

Line Drawing/Text: Print Length is selected.





- Either **A:High** or **B:Standard/Draft** in the **Adjust Length** menu is applied, depending on printer driver settings at the time of printing.
- If you have selected Easy Settings in the printer driver, follow these steps to confirm the Print Priority setting.
 - Windows: Click View Settings on the Main tab to display the View Settings dialog box.
 - Mac OS: Click View set. on the Main pane to display the View set. dialog box.

Follow these steps to configure the settings.

- $oxed{1}$ Load the paper.
 - Attaching the Roll Holder to Rolls →P.338
 - Loading Rolls in the Printer →P.341
 - Loading Sheets in the Printer →P.359

Adjusting the feed amount







- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select Adjust Printer, and then press the OK button.
- 5 Press ▲ or ▼ to select **Feed Priority**, and then press the **OK** button.
- 6 Press ▲ or ▼ to select Adj. Priority, and then press the OK button.
- 7 Press ▲ or ▼ to select Automatic, Print Quality, or Print Length, and then press the OK button.

Automatic Banding Adjustment

If printed images are affected by banding in different colors across the sheet, execute **Adj. Quality** for automatic adjustment of the paper feed amount.

There are two modes of automatic adjustment to correct banding: **Auto(GenuinePpr)** and **Auto(OtherPaper)**. In either mode, the printer prints and reads a test pattern for automatic adjustment of the feed amount.

Auto(GenuinePpr)

Use this mode with paper identified in the **Paper Reference Guide**. (See "Types of Paper.") →P.328

Auto(OtherPaper)

Use this mode with paper not in the **Paper Reference Guide**, or if **Auto(GenuinePpr)** does not eliminate banding.

(See "Types of Paper.") →P.328



- Always check the Adj. Priority values before using Auto(GenuinePpr) or Auto(OtherPaper).
 (See "Selecting a Feed Amount Adjustment Method.") >P.529
- Adjustment is not possible with Auto(GenuinePpr) and Auto(OtherPaper) when using highly transparent media.
 In this case, use Manual adjustment.
 (See "Manual Banding Adjustment.") →P.531
- If additional fine-tuning is necessary after Auto(GenuinePpr) and Auto(OtherPaper), execute Adj. Fine Feed. (See "Fine-Tuning the Paper Feed Amount.") (>P.533)
- Use **Adjust Length** to ensure that lines in CAD drawings are printed at exactly the right length. (See "Adjusting Line Length.") →P.533
- This may take some time, depending on the type of paper.
- Use paper of the same type and size for adjustment as you will use for printing.

Items to Prepare

When Using Rolls	An unused roll at least 10 inches wide
When Using Sheets	Auto(GenuinePpr): One sheet of unused paper, A4/Letter size
	Auto(OtherPaper) : Two sheets of unused paper, A4/Letter size (or one sheet when using A2)


Perform adjustment as follows.

- 1 Load the paper.
 - Attaching the Roll Holder to Rolls →P.338
 - Loading Rolls in the Printer →P.341
 - Loading Sheets in the Printer → P.359



Always make sure the loaded paper matches the type of paper specified. Adjustment cannot be completed correctly unless the loaded paper matches the settings.

2 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (♣).





• If the **Tab Selection screen** is not displayed, press the **Menu** button.

- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select Adjust Printer, and then press the OK button.
- 5 Press ▲ or ▼ to select Feed Priority, and then press the OK button.
- 6 Press ▲ or ▼ to select Adj. Quality, and then press the OK button.
- Press ▲ or ▼ to select Auto(GenuinePpr) or Auto(OtherPaper), and then press the OK button. A test pattern is printed for adjustment.

Adjustment is now finished if you have printed on a roll or a sheet of A2 size or larger.

If you are printing on sheets smaller than A2 size for **Auto(OtherPaper)**, a confirmation message is shown on the Display Screen requesting you to continue printing.

Press the **OK** button and follow the instructions on the Display Screen.

Manual Banding Adjustment

If printed images are affected by banding in different colors, execute **Adj. Quality** for adjustment of the paper feed amount.

Use **Manual** adjustment with highly transparent media or other paper for which **Auto(GenuinePpr)** or **Auto(Other-Paper)** cannot be used.

(See "Automatic Banding Adjustment.") →P.530

Manual adjustment requires you to enter an adjustment value after a test pattern is printed.



- Use paper of the same type and size for adjustment as you will use for printing.
- Always check the Adj. Priority values before using Manual adjustment.
 (See "Selecting a Feed Amount Adjustment Method.") →P.529
- If additional fine-tuning is necessary after **Manual** adjustment, use **Adj. Fine Feed** (See "Fine-Tuning the Paper Feed Amount.") →P.533
- Use Adjust Length to ensure that lines in CAD drawings are printed at exactly the right length.
 (See "Adjusting Line Length.") →P.533

Paper to Prepare


When Using Rolls	An unused roll at least 10 inches wide
When Using Sheets	Two sheets of unused paper of at least A4/Letter size

Perform adjustment as follows.

- 1 Load the paper.
 - Attaching the Roll Holder to Rolls → P.338
 - Loading Rolls in the Printer →P.341
 - Loading Sheets in the Printer →P.359



- Always make sure the loaded paper matches the type of paper specified. Adjustment cannot be completed correctly unless the loaded paper matches the settings.
- 2 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (♣).






- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select Adjust Printer, and then press the OK button.
- 5 Press ▲ or ▼ to select **Feed Priority**, and then press the **OK** button.
- 6 Press ▲ or ▼ to select Adj. Quality, and then press the OK button.
- 7 Press ▲ or ▼ to select **Manual**, and then press the **OK** button. Test pattern A is printed for manual adjustment.



- When printing on sheets, follow the instructions on the Display Screen and remove the sheet.
- 8 Examine test pattern A for adjustment. Determine the pattern in which banding is least noticeable.



532



 If banding seems least noticeable in two patterns but you cannot decide which one is better, choose an intermediate value.

For example, choose 11 if you cannot decide whether pattern 10 or 12 is better.



Press ▲ or ▼ to select the pattern number you have decided, and then press the **OK** button. Test pattern B is printed for adjustment.



• If you printed test pattern A on a sheet, follow the instructions on the Display Screen and use another sheet of the same type of paper.

Additionally, after test pattern B is printed, follow the instructions on the Display Screen and remove the sheet.

- 10 Examine test pattern B for adjustment. Determine the pattern in which banding is least noticeable.
- Press ▲ or ▼ to select the pattern number you have decided, and then press the **OK** button. The adjustment value is now registered, and adjustment is complete.

Fine-Tuning the Paper Feed Amount


If the contrast is uneven or banding in different colors appears at 50 mm (2.0 in) intervals in printed documents, try executing **Adj. Fine Feed** during printing to fine-tune the feed amount.



- The Adj. Fine Feed menu is only displayed during printing.
 Additionally, it is displayed when you have selected Automatic or Print Quality in Adj. Priority in Feed Priority.
 (See "Menu Settings.") >P.418
- Always execute Adj. Quality before Adj. Fine Feed.
 Once you execute Adj. Quality, the Adj. Fine Feed value will revert to 0.
 (See "Automatic Banding Adjustment.") →P.530
 (See "Manual Banding Adjustment.") →P.531

Perform adjustment as follows.

1 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (🛈).





- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- 3 Press ▲ or ▼ to select Adj. Fine Feed, and then press the OK button.
- Press ▲ or ▼ to select a setting value in the range -5 to 5, and then press the **OK** button. At this time, if banding in dark colors appears, select a setting value in the range 1 to 5, and if banding in light colors appears, select a setting value in the range -1 to -5.

Adjusting Line Length

To ensure that lines in CAD drawings are printed at exactly the right length, use **Adjust Length** to adjust the amount that paper is advanced.

There are two options in **Adjust Length**: **AdjustmentPrint** and **Change Settings**.

- AdjustmentPrint
 - After a test pattern is printed, you will measure the discrepancy based on the results of printing.
- Change Settings

No test pattern is printed. Instead, you will measure a document already printed to determine the discrepancy.

Additionally, two modes are available in both **AdjustmentPrint** and **Change Settings**: **A:High** or **B:Standard/Draft**. Choose the mode that suits your particular printing application.

A:High

This setting is applied when **Highest** or **High** is selected in **Print Quality** in the printer driver.

B:Standard/Draft

This setting is applied when Standard or Fast is selected in Print Quality in the printer driver.



- Always check the Adj. Priority values before using Adjust Length. (See "Selecting a Feed Amount Adjustment Method.") >P.529
- Use paper of the same type and size for adjustment as you will use for printing.

Paper to Prepare


When Using Rolls	An unused roll at least 10 inches wideHigh-precision ruler
When Using Sheets	One sheet of unused paper of at least A4/Letter sizeHigh-precision ruler

Perform adjustment as follows.

- 1 Load the paper.
 - Attaching the Roll Holder to Rolls →P.338
 - Loading Rolls in the Printer →P.341
 - Loading Sheets in the Printer →P.359



- Always make sure the loaded paper matches the type of paper specified. Adjustment cannot be completed correctly unless the loaded paper matches the settings.
- 2 On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (♣).






- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- 4 Press ▲ or ▼ to select Adjust Printer, and then press the OK button.
- 5 Press ▲ or ▼ to select **Feed Priority**, and then press the **OK** button.
- 6 Press ▲ or ▼ to select Adjust Length, and then press the OK button.
 - then press the **OK** button.

 When you select **AdjustmentPrint**, a test pattern is printed for you to measure the scale and calculate the discrepancy. The scale bar prints **Millimeter** in 50 mm increments and **Inch** in 1-inch increments.

Press ▲ or ▼ to select AdjustmentPrint or Change Settings, and





• A test pattern is printed in black when you choose A:High or in magenta if you choose B:Standard/Draft.

Note

To cancel printing the test pattern for adjustment, hold down the Stop button. When "Stop printing?" is displayed, press ▲ or ▼ to select Yes, and then press the OK button.


Press ▲ or ▼ to enter the amount of discrepancy, and then press the **OK** button. If the scale is shorter than the actual size, use a positive setting value. If it is longer, use a negative value. The feed amount can be adjusted in 0.02% increments.

Adjusting the Vacuum Strength

When printing on heavyweight paper or paper that curls or wrinkles easily, if the Printhead rubs against paper, adjusting the level of suction against paper on the Platen may improve results.



- Paper rubbing against or becoming caught on the Printhead may jam or result in printed documents that are soiled.
- On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).






- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Paper Menu** is displayed.
- Press ▲ or ▼ to select Paper Details, and then press the OK button.
- Press ▲ or ▼ to select the type of paper, and then press the **OK** button.



When VacuumStrngth is set to Automatic, the setting value selected for the previous print job is displayed (to the right of Automatic) once you select the type of paper currently supplied. However, the value is cleared when the printer is turned off or the paper is replaced.



- 5 Press ▲ or ▼ to select **VacuumStrngth**, and then press the **OK** button.
- 6 Press ▲ or ▼ to select the desired setting value, and then press the **OK** button.

Memo

301719 S-1351

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521

Maintenance and Consumables

Ink Tanks	538
Printheads	546
Maintenance Cartridge	. 554
Cleaning the Printer	560
Other Maintenance	. 564

Troubleshooting	571
Error Message	599
Specifications	621
Appendix	625

538


Ink Tanks

Ink Tanks	
Checking Ink Tank Levels	543
When to Replace Ink Tanks	

Ink Tanks

When purchasing, check the Model number.







• For instructions on Ink Tank replacement, see "Replacing Ink Tanks." →P.538

Replacing Ink Tanks

Compatible ink tanks

For information on the compatible ink tanks for this printer, see "Ink Tanks." →P.538 Replacement ink tanks in 130 ml (4.4 fl oz) and 300 ml (10.2 fl oz) capacities are supported.



Depending on the color, you can also use ink tanks of different capacities.

Precautions when handling ink tanks

Take the following precautions when handling ink tanks.



- For safety, keep ink tanks out of the reach of children.
- If ink is accidentally ingested, contact a physician immediately.




- There may be ink around the ink supply section of ink tanks you removed. Handle ink tanks carefully during replacement. The ink may stain clothing.
- Do not install used ink tanks in another model of printer.
 This will prevent correct ink level detection, which may damage the printer or cause other problems.
- We recommend using up an Ink Tank in the course of printing within six months after breaking the seal. Printing quality may be affected if you use older ink tanks.
- Do not leave the printer without ink tanks installed for extended periods (a month or more). Residual ink may become clogged inside the printer and affect printing quality.

Confirm the message

When the ink level becomes low, a message is displayed on the Display Screen.

According to the message, replace the ink tank or prepare a new ink tank. (See "When to Replace Ink Tanks.") (>P.543)



If a message requests you to replace an Ink Tank, press the **OK** button. In this case, you can skip the step **Access the menu for ink tank replacement.** Follow the instructions in **Remove the ink tanks**.






 Do not remove an Ink Tank during initialization immediately after turning on the printer, or during printhead cleaning. Ink may leak out.



 Ink Tank replacement is possible even during printing, when print jobs are being canceled, or when paper is being advanced.


Access the menu for Ink Tank replacement







- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Ink Menu** is displayed.
- Press ▲ or ▼ to select **Rep. Ink Tank**, and then press the **OK** button. A message on the Display Screen requests you to open the Ink Tank Cover.

Remove the Ink Tank






Press the tip of the Ink Tank Lock Lever of the color for replacement horizontally and pull the Ink Tank Lock Lever up to open it.




3 Hold the lnk Tank by the grips and remove it. Press the **OK** button.





- Do not turn off the printer while the Ink Tank is removed.
 It may cause the interior of the Ink Tank Cover to become soiled.
- If there is still ink in the Ink Tank you removed, store it with the ink holes (a) facing up. Otherwise, ink may leak and cause stains. Put the Ink Tank in a plastic bag and seal it.






• Dispose of used ink tanks according to local regulations.


Installing Ink Tanks

Before opening the pouch, gently agitate the lnk Tank once or twice. Agitate the ink in the lnk Tank by slowly rotating the lnk Tank upside-down and right side up repeatedly.






- After installing an ink tank, do not remove and shake it. Doing so may cause the ink to leak out.
- Important If you do not agitate the lnk Tank, the ink may settle, which may affect printing quality.
- 2 Open the pouch and remove the lnk Tank.





- Never touch the ink holes or electrical contacts. This may cause stains, damage the lnk Tank, and affect printing quality.
- Press the **OK** button and install the lnk Tank into the holder as shown, with the ink holes facing down.






 Ink tanks cannot be installed in the holder if the color or orientation is incorrect.


If the lnk Tank does not fit in the holder, do not force it in. Check the lnk Tank serial number, the lnk Color Label, the color of the lnk Tank, and the orientation of the lnk Tank before reinstalling it.

Forcing the Ink Tank into the holder may damage the printer



4

Push the Ink Tank Lock Lever closed until it clicks into place.





Do not push the lnk Tank in by hand.
 Forcing the lnk Tank into the holder may damage the printer.




 If a 130 ml (4.4 fl oz) ink tank is installed facing the wrong direction, the rotating part of the lnk Tank Lock Lever come out of place.

If this happens, open the Ink Tank Lock Lever to return it to the proper position.





5 Make sure the lnk Lamp is lit in red.





• If the Ink Lamp is not lit, reinstall the tank.






Checking Ink Tank Levels

On the Display Screen, you can check how much ink is left in the ink tanks.

To check remaining lnk Tank levels, access the **Tab Selection screen** on the Control Panel and press \triangleleft or \triangleright to select the lnk tab (\bigcirc).





- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Note If an error has occurred and the **Tab Selection screen** cannot be displayed, display **Ink Info** as follows.
 - 1. Press the **OK** button to display **Printer Info**.
 - 2. Press the ▲ or ▼ button to select Ink Info.
 - Press the OK button.

The remaining ink levels shown on the Display Screen correspond to the inks identified by the Color Label on the bottom of the Display Screen.

These symbols may be displayed above the ink level: ! if ink is low, * if no ink is left, and ? if you have deactivated ink level detection.

The remaining ink level is indicated as shown below.




If the Display Screen indicates to replace the Ink Tank, replace the Ink Tank. If a message is displayed indicating to check the remaining ink levels, or after tasks that consume a lot of ink such as large-format printing or head cleaning, check the remaining levels and replace Ink Tank as needed. (See "Replacing Ink Tanks.") >P.538

When to Replace Ink Tanks

Replace or prepare to replace ink tanks in the following situations.


If a message for checking the ink is shown on the Display Screen

When there is little ink left, the **Message Lamp** is lit and "**Not much ink is left.**" is shown on the Display Screen. You can continue to print, but prepare to replace the lnk Tank. (See "Checking lnk Tank Levels.") > P.543




Before print jobs and maintenance that consume a lot of ink

If little ink is left, there may not be enough for large-format printing, head cleaning, and maintenance, which require a lot of ink. In this case, replace or prepare to replace the lnk Tank before maintenance.



If a message for ink replacement is shown on the Display Screen

When ink runs out, the **Message Lamp** flashes, a message regarding lnk Tank replacement is shown on the Display Screen, and printing is disabled. Replace the lnk Tank at this point.



Attach the Ink Tank Cover to the printer

If too much force is applied to the Ink Tank Cover while it is open, Ink Tank Cover may become detached from the printer.


If the Ink Tank Cover has become detached from the printer, attach it using the following procedure.




 Although the attachment procedure describes the Ink Tank Cover on the right side of the printer, the Ink Tank Cover on the left side can also be attached using the same procedure.




Rotate the Ink Tank Cover attachment part and store it in the printer.



Move the Ink Tank Cover horizontally to align the position with the printer.




Rotate the lnk Tank Cover and place it on the printer.



Push down on the near side of the Ink Tank Cover from the top until it clicks.



Open the Ink Tank Cover and check that it is attached to the printer.




Printheads

Printhead	546
Checking for Nozzle Clogging	546
Cleaning the Printhead	
Replacing the Printhead	. 548

Printhead

When purchasing, check the Model number.





• For instructions on replacing the Printhead, see "Replacing the Printhead." →P.548

Checking for Nozzle Clogging

If printing is faint or affected by banding in different colors, make sure the Printhead nozzles are clear by printing a test pattern to check the nozzles.




Nozzles are periodically checked to ensure they are clear. Configure the settings on the Control Panel menu in Nozzle Check. (See "Menu Settings.") →P.418

Paper to Prepare

When Using Rolls	An unused roll at least 254.0 mm (10.00 in) wide
When Using Sheets	One sheet of unused paper of at least A4/Letter size

- Load paper.
 - Attaching the Roll Holder to Rolls →P.338
 - Loading Rolls in the Printer →P.341
 - Loading Sheets in the Printer →P.359
- On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (---).



546



• If the Tab Selection screen is not displayed, press the Menu button.

Press the **OK** button. The Set./Adj. Menu is displayed.




Press ▲ or ▼ to select **Test Print**, and then press the **OK** button.



Press ▲ or ▼ to select **Nozzle Check**, and then press the **OK** button. The printer now prints a test pattern for checking the nozzles.


6 Check the printing results.

If the horizontal lines are not faint or incomplete, the nozzles are clear.



If some sections of the horizontal lines are faint or incomplete, the nozzles for those colors are clogged.

If horizontal lines are faint or incomplete, follow the steps below and check again for nozzle clogging.



- 1. Clean the Printhead. (See "Cleaning the Printhead.") →P.547
- 2. Print a test pattern to check the nozzles.



• If you repeat these steps several times but the horizontal lines are still faint or incomplete, the Printhead may have reached the end of its useful life. Contact your Canon dealer for assistance.

Cleaning the Printhead

If printing is faint, cleaning the Printhead may improve results.

Choose one of two Printhead cleaning modes (**Head Cleaning A** or **Head Cleaning B**), depending on the problem to resolve.

Head Cleaning A

Use this mode if printing is faint or contains foreign substances. This method of cleaning consumes the least amount of ink.

It takes about three minutes to complete.

Head Cleaning B

Use this mode if no ink is ejected at all, or if **Head Cleaning A** does not solve the problem. It takes about three and a half minutes to complete.



- Do not remove the Maintenance Cartridge or ink tanks during either Head Cleaning A or Head Cleaning B.
 Ink may leak or an error may occur.
- If printing does not improve even if you execute **Head Cleaning B**, try repeating **Head Cleaning B** once or twice. If this still does not improve printing, the Printhead may have reached the end of its useful life. Contact your Canon dealer for assistance.



By default, nozzles are checked at fixed intervals.
 Configure the settings on the Control Panel menu in Nozzle Check.
 (See "Menu Settings.") →P418

Perform cleaning as follows.

1





If the Tab Selection screen is not displayed, press the Menu button.

Press the **OK** button.
The **Set./Adj. Menu** is displayed.

- 3 Press ▲ or ▼ to select Maintenance, and then press the OK button.
- Press ▲ or ▼ to select **Head Cleaning**, and then press the **OK** button.
- Press ▲ or ▼ to select **Head Cleaning A** or **Head Cleaning B**, and then press the **OK** button. Head cleaning is now executed.
- 6 Print a test pattern to check the nozzles, and determine whether cleaning has cleared the nozzles. (See "Checking for Nozzle Clogging.") →P.546

Replacing the Printhead

When to replace the Printhead

Replace the Printhead in the following situations.

- If the printing quality does not improve even after one or two cycles of Head Cleaning B from the printer menu
- If the Display Screen indicates "Open top cover and replace the printhead."
- · If your Canon dealer has advised you to replace the Printhead

Compatible printheads

For information on compatible printheads, see "Printhead." →P.546

Precautions when handling the Printhead

Take the following precautions when handling the Printhead.



- For safety, keep the Printhead out of the reach of children.
- If ink is accidentally ingested, contact a physician immediately.
 - Do not touch the Printhead immediately after printing. The Printhead becomes extremely hot, and there is a risk of burns.



- There may be ink around the nozzles of the Printhead you remove. Handle the Printhead carefully during replacement. The ink may stain clothing.
- Do not open the Printhead pouch until immediately before installation. After removing the Printhead from the
 pouch, install it right away. If the Printhead is left after the pouch is opened, the nozzles may dry out, which may
 affect printing quality.

Access the menu for Printhead replacement




 When replacing the Printhead immediately after printing, wait a few minutes before replacing it. The metal parts of the Printhead become hot during printing, and there is a risk of burns from touching these parts.




 Your hands may become dirty during Printhead replacement. Use the gloves provided with the new Printhead for replacement.



- Prepare a new Ink Tank when ink levels are low.
- When the remaining capacity of Maintenance cartridge is low, prepare a new Maintenance cartridge.








- If the Tab Selection screen is not displayed, press the Menu button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- Press ▲ or ▼ to select Maintenance, and then press the OK button.
- Press ▲ or ▼ to select **Replace P.head**, and then press the **OK** button.

 Ink begins being drawn in. When it finishes, instructions are displayed on the Display Screen. It takes about two minutes to complete.

Replace the Printhead

1 Open the Top Cover.
Instructions are now shown on the Display Screen regarding Printhead replacement.






During Printhead replacement, do not move the Carriage from the position indicated. If you accidentally
move the Carriage, you will hear a warning tone, and Printhead replacement is no longer possible.
 If you move the Carriage by mistake, close the Top Cover. The Carriage will be moved to the position as
indicated.


2

If the Printhead Fixer Cover or Printhead Fixer Lever is dirty, use a damp cloth that you have wrung out completely to wipe it clean.






• Do not touch the Linear Scale (a) or Carriage Shaft (b). Touching these parts may damage them.




Pull the Printhead Fixer Lever forward all the way to open it completely.






Pull up the Printhead Fixer Cover to open it completely.



5 Remove the Printhead and press the **OK** button.






Never touch the metal contacts of the Carriage. Furthermore, do not allow any dirt or debris to become
adhered to the metal contacts of the Carriage. These may damage the printer.



• Dispose of the used Printhead in accordance with local regulations.




Holding the new Printhead by the grips (a), remove it from the pouch.






- When handling the Printhead, always hold it by the grips (a). Never touch the nozzles (b) or metal contacts (c). This may damage the Printhead and affect printing quality.
- Never touch the ink supply section (d). This may cause printing problems.




While firmly holding the Printhead you have removed, use your other hand to remove the orange Protective Part (a). Squeeze the grips (c) of Protective Part (b) and pull it down to remove it.






- The inside surface of the Protective Part (a) and Protective Part (b) is coated with ink to protect the nozzles. Be careful not to touch these surfaces when removing the caps.
- The Printhead contains ink to protect the nozzles. We recommend removing Protective Part (b) as you
 hold it over the Printhead package or safely out of the way to avoid spilling ink and staining your clothes
 or the surrounding area. If ink accidentally spills, wipe off the ink with a dry cloth.
- If you need to put a Printhead somewhere temporarily before installation, do not keep the nozzles and metal contacts facing down. If the nozzles or metal contacts are damaged, it may affect the printing quality.
- Do not reattach the removed Protective Part. Dispose of these materials in accordance with local regulations.
- With the nozzles facing down and the metal contacts toward the back, insert the Printhead into the Carriage. Carefully push the printhead firmly into the Carriage, ensuring that the nozzles and metal contacts do not touch the carriage.




Pull the Printhead Fixer Cover down toward the front to lock the Printhead in place.






10 Push the Printhead Fixer Lever toward the back of the printer until it clicks.



Close the Top Cover.

Ink now fills the system. It takes about seven minutes to complete.





· While ink is being filled, definitely do not remove the Ink Tank or Maintenance Cartridge. Ink may leak out.



After Printhead has been replaced and filled with ink, Head Posi. Adj. (Auto(Advanced)) is performed if you have selected Rep.P.head Print > On in the Control Panel menu. (See "Menu Settings.") →P.418 In this case, follow the instructions on the Display Screen for Printhead adjustment. If Rep.P.head Print is Off, perform Head Posi. Adj. (Auto(Advanced)) yourself. (See "Automatic Adjustment to Straighten Lines and Colors.") →P.522

Maintenance Cartridge

Maintenance Cartridge	
Checking the Remaining Maintenance Cartridge Capacity	
When to Replace the Maintenance Cartridge	. 558

Maintenance Cartridge

When purchasing, check the Model number.





• For instructions on replacing the Maintenance Cartridge, see "Replacing the Maintenance Cartridge." >P.554

iPF685

Replacing the Maintenance Cartridge

Compatible maintenance cartridges

For information on compatible maintenance cartridges, see "Maintenance Cartridge." (→P.554)

Precautions when handling the Maintenance Cartridge

Take the following precautions when handling the Maintenance Cartridge.



- For safety, keep the Maintenance Cartridge out of the reach of children.
- If ink is accidentally ingested, contact a physician immediately.




- Do not remove the Maintenance Cartridge except to replace it. Ink may leak out.
- Important Do not remove an Maintenance Cartridge during initialization immediately after turning on the printer, during Printhead cleaning, while ink is being drawn out, or during initialization immediately after replacing the Maintenance Cartridge.

The Maintenance Cartridge may become damaged or ink may leak out.

- To prevent ink from leaking from a used Maintenance Cartridge, avoid dropping the cartridge or storing it at an angle. Otherwise, ink may leak and cause stains.
- Ink adheres to the top of the Maintenance Cartridge after it has been used. Handle the Maintenance Cartridge carefully during replacement. The ink may stain clothing.


Confirm the message

When the Maintenance Cartridge is almost empty, a message is shown on the Display Screen. According to the message, replace the Maintenance Cartridge or prepare a new Maintenance Cartridge. (See "When to Replace the Maintenance Cartridge.") → P.558




Maintenance Cartridge

If a message is displayed requesting Maintenance Cartridge replacement, you can skip the step **Access the menu for Maintenance Cartridge replacement.** Follow the instructions in **Replace the Maintenance Cartridge**.



Access the menu for Maintenance Cartridge replacement

On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (🕌).






- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button. The **Set./Adj. Menu** is displayed.
- 3 Press ▲ or ▼ to select Maintenance, and then press the OK button.
- Press ▲ or ▼ to select **Repl. maint cart**, and then press the **OK** button.

 A message on the Display Screen advises you to open the Maintenance Cartridge Cover.


Replace the Maintenance Cartridge

Open the box, remove the plastic bag and packaging material, and take out the Maintenance Cartridge.







 Never touch the metal contacts (a). This may damage the Maintenance Cartridge.



At this point, open the Maintenance Cartridge Cover.




Hold the used Maintenance Cartridge by the grip (a) with one hand and put your other hand under the Maintenance Cartridge to hold it firmly on the bottom, keeping it level as you pull it out.






- Used Maintenance Cartridges are heavy. Always grasp the cartridge firmly and keep the cartridge level during removal and storage. If you drop a used Maintenance Cartridge or store it at an angle, ink may leak and cause stains.
- The remaining Maintenance Cartridge capacity is recorded on each printer. Do not install a used Maintenance Cartridge in another printer.
- Keep the used Maintenance Cartridge level as you put it in the plastic bag. Expel excess air from the plastic bag and seal the zipper.





Confirm the Maintenance Cartridge is right-side up, put it in the box with the packaging material attached, and store it so that it stays level.






 Always put the used Maintenance Cartridge back in the box and store the box on a flat surface. Also, seal the zipper thoroughly. Otherwise, ink may leak and cause stains.




- Put the used Maintenance Cartridge in the plastic bag of the new cartridge, and dispose of it in accordance with local regulations.
- Keeping the new Maintenance Cartridge level, insert it all the way in.

The printer now initializes the Maintenance Cartridge.





- Do not remove the Maintenance Cartridge during initialization immediately after replacing the Maintenance Cartridge. The Maintenance Cartridge may become damaged.
- 7 Close the Maintenance Cartridge Cover.





If you did not perform the operation in **Access the menu for Maintenance Cartridge replacement**, this is the end of the procedure and you do not need to press the **OK** key in the next step.

558




Press the **OK** button.



Checking the Remaining Maintenance Cartridge Capacity

The Maintenance Cartridge absorbs excess ink from borderless printing, printhead cleaning, and other processes. You can confirm the remaining capacity of the Maintenance Cartridge by checking the Maintenance Cartridge capacity shown on the Display Screen.

To check remaining Maintenance Cartridge capacity, access the **Tab Selection screen** on the Control Panel and press ◀ or ▶ to select the Settings/Adj. tab ([----]).





• If the **Tab Selection screen** is not displayed, press the **Menu** button.

If the Display Screen indicates to replace the Maintenance Cartridge, replace the Maintenance Cartridge. If a message is displayed indicating to check the remaining capacity of the Maintenance Cartridge, or before tasks that deplete much of the capacity such as head cleaning or preparations to move the printer, check the remaining Maintenance Cartridge capacity and prepare a new Maintenance Cartridge as needed. (See "Replacing the Maintenance Cartridge.")


P.554

When to Replace the Maintenance Cartridge

Replace or prepare to replace the Maintenance Cartridge in the following situations.

If a message for checking the Maintenance Cartridge is shown on the Display Screen

When the Maintenance Cartridge is almost full, the **Message Lamp** is lit and "**The level is low**" is shown on the Display Screen. You can continue to print, but check the remaining Maintenance Cartridge capacity and prepare to replace the Maintenance Cartridge with a new one. (See "Checking the Remaining Maintenance Cartridge Capacity.") > P.558




When much of the Maintenance Cartridge capacity is depleted

Printhead cleaning, Printhead replacement, and preparations to transfer the printer deplete much of the Maintenance Cartridge capacity. (In particular, preparing to move the printer depletes a lot of the capacity.)


Maintenance Cartridge

Check the remaining Maintenance Cartridge capacity before this maintenance and replace the Maintenance Cartridge if necessary.



If a message for the Maintenance Cartridge replacement is shown on the Display Screen

When the Maintenance Cartridge is full, the **Message Lamp** flashes and a message to replace the Maintenance Cartridge is shown on the Display Screen. Printing is disabled, and you cannot replace the Printhead or transfer the printer. Replace the Maintenance Cartridge with a new one.



Cleaning the Printer

Cleaning the Printer Exterior	560
Cleaning Inside the Top Cover	560
Cleaning the Printhead	547


Cleaning the Printer Exterior

Clean the printer regularly to maintain better printing quality and help prevent problems. To ensure a comfortable working environment, clean the printer exterior about once a month.

- 1 Turn the printer off. (See "Turning the Printer On and Off.") →P.17
- 2 Unplug the power cord from the outlet.



- Always turn off the printer and unplug the power cord before cleaning or maintenance. Accidentally leaving the printer on poses a risk of injury if you touch moving parts inside the printer.
- 3 Using a damp cloth that you have wrung out completely, wipe the exterior surfaces of the printer. Dry the surfaces with a dry cloth.





Never use flammable solvents such as alcohol, benzene, or thinner. If these substances come into contact with electrical components inside the printer, there is a risk of fire or electrical shock.



 If the Ejection Guide is dirty, it may soil the edge of the paper when the paper is cut. We recommend cleaning the Ejection Guide even if it does not appear dirty, because it may actually be covered with paper dust.

(See "Cleaning Inside the Top Cover.") →P.560

4 Plug the power cord into the outlet.


Cleaning Inside the Top Cover

Clean inside the Top Cover about once a month to maintain better printing quality and help prevent problems. Also clean inside the Top Cover in the following situations to ensure optimal operation.


- If the printed surface or the underside of paper is dirty after printing
- After you have used up a roll
- After borderless printing
- After printing on small paper
- After printing on paper that generates a lot of cutting debris
- If you have replaced the roll
- After printing on paper that generates a lot of paper dust
- After printing on adhesive paper



- If the Platen inside the Top Cover becomes dirty, it may soil the underside of paper. We recommend cleaning the Platen after borderless printing or printing on small paper.
- If the Ejection Guide is dirty, it may soil the edge of the paper when the paper is cut. We recommend cleaning the Ejection Guide even if it does not appear dirty, because it may actually be covered with paper dust.
- Printing on adhesive paper may leave adhesive on the Platen, Paper Retainer, or other parts. To prevent paper
 jams, we recommend cleaning inside the Top Cover after printing.
- 1 Open the Top Cover.



If paper dust has accumulated in the Vacuum holes (a) on the Platen or in the Borderless Printing Ink Grooves (b), use the Cleaning Brush (c), provided with the printer, to wipe it away.






• If the Cleaning Brush is dirty, rinse it in water.



Using a damp cloth that you have wrung out completely, wipe inside the Top Cover to clean it. Wipe away any ink residue on the Platen as a whole (a), the Paper Retainer (b), Borderless Printing Ink Grooves (c), and Ejection Guide (d).






Never use flammable solvents such as alcohol, benzene, or thinner. If these substances come into contact with electrical components inside the printer, there is a risk of fire or electrical shock.




- Do not use a dry cloth to wipe inside the Top Cover. This may create a static charge, which may attract dust and affect the printing quality.
- Do not touch the Linear Scale (a) or Carriage Shaft (b). This may stain your hands and damage the printer.




Cleaning the Printer



 When cleaning between the Platen and Ejection Guide, use a damp cloth that you have wrung out completely to wipe over the Output Tray and along grooves.



4 Close the Top Cover.



Other Maintenance

Preparing to Transfer the Printer	564
Reinstalling the Printer	567
	570
Updating the Firmware	5/0

Preparing to Transfer the Printer

To protect the internal parts in transit, always follow these steps before transferring the printer to a new location. Refer to the Setup Guide for details on packing the printer and installing it after transfer.



Avoid tilting the printer excessively in transit. This may cause ink in the printer to leak and cause stains.



- When you execute prepare to transfer, ink is drawn into the Maintenance Cartridge. Depending on the amount of free space in the mounted Maintenance Cartridge, you may need to replace it with a new one at this time.
 Note that replacement is not required if there is 80% or more free space. (See "Checking the Remaining Maintenance Cartridge Capacity.")

 P.558
- Depending on the state of the printer, part replacement may be necessary when preparing to transfer the printer (that is, when you execute the printer menu item to prepare for transfer).

Remove paper


- 1 Remove the paper.
 - Rolls (See "Removing the Roll from the Printer.") →P.345
 - Sheets (See "Removing Sheets.") →P.363

Access the Prep.MovePrinter menu

If a message instructing you to replace the Maintenance Cartridge is displayed on the Display Screen, replace the Maintenance Cartridge.

(See "Replacing the Maintenance Cartridge.") →P.554

2 On the **Tab Selection screen** of the Control Panel, press **◄** or **▶** to select the Settings/Adj. tab (→).





- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- 564 Press ▲ or ▼ to select **Prep.MovePrinter**, and then press the **OK** button.
 - Press ▲ or ▼ to select **Standard** or **Limited**, and then press the **OK** button. Displays the confirmation screen.



If Limited is selected, do not transport in low temperature environments. The ink remaining in the printer
may freeze and damage the printer.




Press ▲ or ▼ to select **Yes** (or **Execute** if **Limited** is selected), and then press the **OK** button. Ink is now drawn into the Maintenance Cartridge.


Once preparations are finished, a message on the Display Screen requests you to open the Ink Tank Cover.




- Do not remove the Maintenance Cartridge except when the message for replacing it is displayed.
 If you remove the Maintenance Cartridge while ink is being drawn out, the ink may leak out.
- If consumables must be replaced, the message "Consumables must be replaced. Call for service." is shown on the Display Screen and preparation is not possible. If this message is displayed, press the OK button and contact your Canon dealer for assistance.

Remove the Ink Tank






Pressing the tip of the Ink Tank Lock Lever horizontally, lift the Ink Tank Lock Lever to release the lock.




Holding the ink tanks by the grips, remove them.







Store the ink tanks you removed with the ink holes (a) facing up.
 Otherwise, ink may leak and cause stains.




4 Repeat steps 2 and 3 to remove all ink tanks.



5 Push all ink tank lock levers closed until they click into place.



Close the Ink Tank Cover.
Ink is now drawn into the Maintenance Cartridge.





- Do not remove the Maintenance Cartridge except when the message for replacing it is displayed.
 If you remove the Maintenance Cartridge while ink is being drawn out, the ink may leak out.
- 7 When the processing is complete, "Completed! Turn Power Off!!" is displayed. Press the Power button to turn the power off.



Pack the printer


1 Disconnect the power cord and interface cable.



• Turn off the printer before you unplug it. It may damage the printer if you unplug it before it is off and transfer it in that state. If you accidentally unplug the printer, plug it in again, reinstall the ink tanks, and follow this procedure again.



Tape down printer covers to secure them, in the reverse order of tape removal during installation.




- 3 Remove the Stand by reversing the installation procedure, when it was attached to the printer.
- 4 Disassemble and repackage the Stand by following the installation procedure in reverse.
- 5 Repack the Roll Holder, Holder Stopper, and printer in shipping materials, and then package them in a shipping box.

Reinstalling the Printer

The basic workflow for reinstalling the printer is as follows. For detailed instructions, see the Setup Guide.


Assemble the stand (optional)

If you are using the optional Stand, assemble the Stand by referring to the Printer Stand Setup Guide included with the Stand.






- The Stand must be assembled by at least two people on a flat surface. Attempting assembly by yourself
 poses a risk of injury or bending the Stand.
- When assembling the Stand, lock all four of the casters. Attempting to move the stand when the casters are not locked poses a risk of injury or damage to the location site.
- Before moving the assembled stand, lift the support rod to the position shown (a) and unlock all four casters. Moving the stand with the support rod lowered or the casters locked may cause injury or damage the area of installation or basket cloth.




Install the printer

Install the printer on a table or other flat surface. If you will use the printer on an optional Stand, assemble the Stand before mounting the printer on it, and then secure it with the Main Unit Securing Bolts.





• Moving the printer requires at least three people. Be careful to avoid back strain and other injuries.


Caution • When moving the printer, firmly grasp the Carrying Handles. The printer may be unsteady if you hold it at other positions, which poses a risk of injury from dropping the printer.



- When placing the printer on the Stand, lock all four of the casters of the Stand. Attempting to place the printer on the Stand while the casters are not locked poses a risk of injury.
- Remove tape and packaging material attached to the printer.









- 4 Plug the power cord into the outlet.
- Press the power button to turn the printer on.
 Instructions are displayed on the Display Screen.



6 Open the Ink Tank Cover and install the ink tanks.




7 Load the Roll Media on the Roll Holder. (See "Attaching the Roll Holder to Rolls.") →P.338



8 Load the Roll Media in the printer.

(See "Loading Rolls in the Printer.") >P.341





Install the software.

Note that the driver installation procedure varies depending on the type of connection.



• When the printer is connected to a network (via TCP/IP), the printer's IP address may be changed if you reinstall the printer.


In this case, be sure to reconfigure the printer's IP address.

Updating the Firmware

Update the printer firmware to take advantage of new and improved printer functions.

Confirming the firmware version







- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- 3 Press ▲ or ▼ to select **Printer Info**, and then press the **OK** button.
- Press ▲ or ▼ to select **System Info**, and then press the **OK** button. The firmware version is displayed.

Updating the Firmware

To obtain the latest firmware, visit the Canon website. If the firmware available online is newer than the installed firmware, update the printer firmware. For details on downloading and updating the firmware, visit the Canon website.

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537

Troubleshooting

requently Asked Questions5	572
roblems Regarding Paper 5	573
rinting does not start5	582
ne printer stops during a print job5	583
roblems with the printing quality5	584
annot print over a network5	590
stallation problems5	591
P-GL/2 problems 5	593
ther problems5	
·	

LITOI Message	399
Specifications	621
Appendix	625

Frequently Asked Questions

Frequently Asked Questions

This section presents frequently asked questions and answers. To view more detailed explanations, click the hyperlinks in the answer column.

Question	Answer
I want to easily create vertical or horizontal banners.	You can print originals that are in landscape (or portrait) orientation automatically enlarged to fit the roll width. This is an easy way to create vertical or horizontal banners. (See "Printing Vertical or Horizontal Banners (Large-Format Printing).") →P88
Does this printer support sub-ink tank system?	This printer supports sub-ink tank system. Even if an ink tank becomes empty during printing, since a certain amount of ink always is stored in a sub-ink tank, you can replace the ink tank while printing. (See "Replacing Ink Tanks.") P.538
I want to know how to configure roll cutting.	You can select the cutting method by the setting of the printer driver and the setting of the printer. To cut rolls automatically after printing, set Cutting Mode of the printer to Automatic and Automatic Cutting of the printer driver to Yes . When using paper for which ink adhesion takes time or the print surface is easily scratched, we recommend that you set the Cutting Mode setting of the printer to Eject . (See "Specifying the Cutting Method for Rolls.") →P.352 (See "Cutting Roll Paper After Printing.") →P.137
I want to configure so that the roll is cut automatically after waiting for the ink to dry.	In the printer driver, you can set the time for waiting until the ink dries. Also, you can set likewise on the printer. (See "Specifying the Ink Drying Time for Rolls.") →P.350 (See "Menu Structure.") →P.412
How do I print without borders?	When printing on rolls, you can perform borderless printing by configuring the printer driver. (when printing on cut sheets, you cannot perform borderless printing) (See "Borderless Printing on Paper of Equivalent Size.") →P.79 (See "Borderless Printing by Resizing Originals to Fit the Roll Width.") →P.82 (See "Borderless Printing at Actual Size.") →P.74
I want to know the paper types that can be used in this printer.	Concerning the paper that can be used in this printer, refer to the imagePROGRAF home page or the Paper Reference Guide . (See "Displaying the Paper Reference Guide.") P.331
The paper type that I want to print is not displayed on the Display Screen.	When using newly released paper, paper information must be registered on the printer and the printer driver. Download the new version of Media Information File from the imagePROGRAF website and install it. (See "Updating paper information.") →P334
Can I perform duplex printing?	This printer cannot perform duplex printing. If you use the Folded Duplex function in the Free Layout of Windows software, you can print two pages one-sided, fold them at the center and suspend them to substitute for duplex printing. (See "Prints using Folded Duplex (Windows).") →P.201
I want to perform enlargement printing.	With the printer driver, you can specify the ratio matching the document with the paper size and width and perform enlargement printing or reduction printing. (See "Resizing Originals to Match the Paper Size.") → P.60 (See "Resizing Originals to Fit the Roll Width.") → P.62 (See "Resizing Originals by Entering a Scaling Value.") → P.65


Problems Regarding Paper

Clearing Jammed Roll Paper	576
Roll paper cannot be inserted into the Paper Feed Slot	
Paper is not cut neatly	580 580
Depression on the leading edge is left	. 581
The size of clear film cannot be detected	


Clearing Jammed Roll Paper

If paper from a roll becomes jammed, "Paper jam." is shown on the Display Screen of the Control Panel. Remove the jammed paper as follows.

Positioning your hands as shown, open the Roll Cover.



2 Cut the loaded roll paper with regular scissors or the like.




Caution


When cutting paper, be careful to avoid injury or damage to the printer.



Push the Release Lever back.




- 4 Remove the jammed paper.
 - If paper is jammed inside the Top Cover
 - 1. Open the Top Cover and move the Carriage to the left or right side manually, away from the jam.






- Do not move the Carriage over jammed paper. This may damage the Printhead.
- 2. Clear any jammed paper from inside the Top Cover.

 After removing the paper, make sure there are no other scraps of paper in the printer.
- **3.** Close the Top Cover.






• Do not touch the Linear Scale (a) or Carriage Shaft (b). This may stain your hands and damage the printer.




 If paper from a roll is jammed by the Paper Feed Slot Remove the jammed paper from the Paper Feed Slot.

After removing the paper, make sure there are no other scraps of paper in the printer.




 If the paper is jammed by the Ejection Guide Remove the jammed paper from the Output Tray.
 After removing the paper, make sure there are no other scraps of paper in the printer.






Pull the Release Lever forward.




Clearing a Jammed Sheet

If a sheet becomes jammed, "Paper jam." is shown on the Display Screen of the Control Panel. Remove the jammed paper as follows.

1 Push the Release Lever back.




- 2 Remove the jammed paper.
 - If paper is jammed inside the Top Cover
 - Open the Top Cover and move the Carriage to the left or right side manually, away from the jam.








- Do not move the Carriage over jammed paper. This may damage the Printhead.
- Clear any jammed paper from inside the Top Cover.After removing the paper, make sure there are no other scraps of paper in the printer.
- **3.** Close the Top Cover.






Do not touch the Linear Scale (a) or Carriage Shaft (b).
 This may stain your hands and damage the printer.




 If the paper is jammed by the Paper Feed Slot Remove the jammed paper from the Paper Feed Slot.

After removing the paper, make sure there are no other scraps of paper in the printer.




• If the paper is jammed by the Ejection Guide Remove the jammed paper from the Output Tray.

After removing the paper, make sure there are no other scraps of paper in the printer.




3 Pull the Release Lever forward.



Clearing Jammed Paper (Paper Feed Slot)


Follow these steps to remove any scraps left in the Paper Feed Slot after you clear jammed sheets or roll paper.

- Turn the printer off. (See "Turning the Printer On and Off.") →P.17
- 2 Push the Release Lever back.







Positioning your hands as shown, open the Roll Cover.



Fold an A4 sheet lengthwise four times and insert it through the gap of the Paper Feed Slot. Push the scrap out toward the Platen.




- 5 Remove the scrap when it is pushed out onto the Platen.
- 6 If any scraps remain inside the paper feed slot, repeat steps 4 and 5.
- 7 Holding it at the positions indicated, close the Roll Cover.





Pull the Release Lever forward.



Roll paper cannot be inserted into the Paper Feed Slot

Cause	Corrective Action
The roll paper is warped.	Straighten out curls and reload the roll.
Paper is jammed by the paper feed slot.	Remove the jammed paper. (See "Clearing Jammed Roll Paper.") →P.573 (See "Clearing a Jammed Sheet.") →P.576
The paper source selection is incorrect.	Press the Load button and select the paper source.

Cannot load sheets

Cause	Corrective Action
The paper source selection is incorrect.	Press the Load button and select the paper source.

Paper is not cut neatly

Cause	Corrective Action
The paper is bent or curled at the cut position.	Straighten out any curling by the edges of the paper.
Paper rises by the ends of the cut position before it is cut.	Reload the paper correctly.
You are using paper that cannot be cut with the Cutter Unit.	Specify Manual in Cutting Mode in the Control Panel menu and use scissors or a cutting tool to cut the roll after printing. (See "Specifying the Cutting Method for Rolls.") P352
Cut Speed is not configured correctly in the Control Panel menu.	Change the Cut Speed setting in the Control Panel menu. (See "Menu Structure.") →P.412
During cutting, printed documents fall out at an angle.	In the Control Panel menu, set Cutting Mode to Eject . Hold documents after printing, as they are cut. (See "Specifying the Cutting Method for Rolls.") →P.352

Paper is not cut

Cause	Corrective Action
In the printer driver, No or Print Cut Guideline is specified in Automatic Cutting .	Specify Yes in Automatic Cutting in the printer driver. (See "Page Setup Sheet (Windows).") → P.161 (See "Paper Detailed Settings Dialog Box (Mac OS).") → P.258
In the Control Panel menu, Cutting Mode is set to Eject or Manual .	If the Cutting Mode is Eject, press the Cut button to cut the paper. If the Cutting Mode is Manual, cut rolls with scissors or the like. (See "Specifying the Cutting Method for Rolls.") P.352

Problems Regarding Paper

Depression on the leading edge is left

Cause	Corrective Action
Keeping a roll in the printer for a long time without printing on it may leave a depression on the leading edge.	When printing quality is most important, we recommend setting TrimEdge Reload to On or Automatic so that the paper edge is automatically cut before printing. (See "Menu Structure.") →P.412

The size of clear film cannot be detected

Cause	Corrective Action
The Platen is soiled with ink or other substances.	Open the Top Cover and clean the entire Platen.
	(See "Cleaning Inside the Top Cover.") →P.560

Roll Paper is Continuously Ejected

Cause	Corrective Action	
Although sheets are selected as the paper source, a roll was advanced.	After roll ejection stops, follow these steps to reload the roll. 1. Push the Release Lever back. 2. Open the Roll Cover.	
 Using both hands, rotate the Roll Holder toward the back to rewind the roll. At this time, ensure the both ends of the roll are rewound evenly. Pull the Release Lever forward. Load the roll. At this time, be sure to press the Load button and select "Load Roll Paper". (See "Loading Rolls in the Printer.") →P.341 		

Printing does not start

The Data lamp on the Control Panel does not light up	. 582
The printer does not respond even if print jobs are sent	
Ink Filling is displayed	. 582
The display screen indicates Agitating	

The Data lamp on the Control Panel does not light up

Cause	Corrective Action
The printer is not on.	Make sure the power cord is securely plugged in, all the way. Press the Power button to turn on the printer.
The target printer was not selected when printing.	 In Windows, select the printer by clicking Select Printer or Printer in the printing dialog box and try printing again. In Mac OS, open the dialog box of the printer driver, select the printer from the list of Printer, and try print-
	ing again.
The print job is paused.	 In Windows, restart the print job as follows. 1. Select the printer icon in the Printers and Faxes (or Printers) window.
	2. Clear Pause Printing in the File menu to restart the print job.
	In Mac OS, restart the print job as follows.
	 Click Print & Scan. (This is identified as Printers & Scanners or Print & Fax in other versions of Mac OS.)
	2. Select the printer, and then Resume Printer (or Resume) in the Printers menu to restart the print job.

The printer does not respond even if print jobs are sent

Cause	Corrective Action
In the Control Panel menu, Pause Print is On .	Set Pause Print to Off. (See "Pausing Printing.") →P.27
In the Control Panel menu, Use USB or Use Ethernet is set to Off .	Set Use USB or Use Ethernet to On. (See "Menu Settings.") →P.418
You have selected Save in mail box in Output Method on the printer.	Print the job saved on the printer's hard disk. (See "Printing Saved Jobs.") →P.492
Print jobs are pending.	Manage the jobs on hold and print as needed. (See "Managing Pending Jobs (Printing or Deleting Jobs on Hold).") →P.490

Ink Filling.. is displayed

	Cause	Corrective Action
The printe	r was forced off during operation.	Wait until the system has been filled with ink.

The display screen indicates Agitating...

Cause	Corrective Action
Ink agitation is in progress.	Please wait until ink agitation is finished.

The printer stops during a print job

The printer stops during a print job

An error message is shown on the Display Screen	583
The printer ejects blank, unprinted paper	583
The printer stops when printing a HP-GL/2 job (the carriage stops moving)	594

An error message is shown on the Display Screen

Cause	Corrective Action
The last portion of roll paper was used during a print job, and paper could not be advanced because the trailing edge is taped to the roll.	Remove the used roll and insert a new roll. (See "Removing the Roll from the Printer.") >P345
	(See "Removing the Roll Holder from Rolls.") →P.348 (See "Loading and Printing on Rolls.") →P.18

The printer ejects blank, unprinted paper

Cause	Corrective Action
The leading edge of the roll paper was cut to straighten it.	The leading edge of rolls may be cut to straighten it if Trim Edge First is set to a value other than Off in the Control Panel menu. (See "Cutting the Leading Edge of Roll Paper Automatically.") →P.356
The Printhead nozzles are clogged.	Print a test pattern to check the nozzles and make sure the Printhead is in good condition for printing. (See "Checking for Nozzle Clogging.") →P.546
A print job was received from an incompatible printer driver.	Use the correct imagePROGRAF printer driver for the printer and try printing again.
The printer has received print data that includes HP RTL commands when Auto Rotate is On in the Control Panel menu.	In the Control Panel, set Auto Rotate to Off and print again. (See "Menu Settings.") →P.418
The printer is damaged.	Contact your Canon dealer for assistance.

584

Problems with the printing quality

Printing is faint	584
Printing is faint	584
The edges of the paper are dirty	585
The surface of the paper is dirty	586
The back side of the paper is dirty	586
Printed colors are inaccurate	586
Banding in different colors occurs	587
Image edges are blurred or white banding occurs	
The contrast becomes uneven during printing	588
	500
The length of printed images is inaccurate in the feeding direction	588
Images are printed crooked	589
Documents are printed in monochrome	589
Line thickness is not uniform	589
Lines are misaligned	
Lilioo dio iliiodiigiloo	

Printing is faint

Cause	Corrective Action
You may be printing on the wrong side of the paper.	Print on the printing surface.
The Printhead nozzles are clogged.	Print a test pattern to check the nozzles and see if they are clogged. (See "Checking for Nozzle Clogging.") →P.546
Because the printer was left without ink tanks installed for some time, ink has become clogged in the ink supply system.	After the ink tanks have been installed for 24 hours, run Head Cleaning B from the Control Panel. (See "Cleaning the Printhead.") →P.547
Paper is jammed inside the Top Cov-	Follow the steps below to remove the jammed piece of paper inside the Top Cover.
er.	1. Open the Top Cover and make sure the Carriage is not over the Platen.
	2. Remove any scraps of paper inside the Top Cover. (See "Clearing Jammed Roll Paper.") →P.573 (See "Clearing a Jammed Sheet.") →P.576
	3. Close the Top Cover.
The ink was not dry when paper was cut.	Specify a longer drying period in the Control Panel menu, in Paper Details > Roll Drying- Time . (See "Menu Settings.") →P.418
Printing may be faint if Print Quality in Advanced Settings in the printer driver is set to Standard or Fast .	In Advanced Settings of the printer driver, choose Highest or High in Print Quality. Printing in Fast or Standard mode is faster and consumes less ink than in Highest or High modes, but the printing quality is lower. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") →P.54
You are printing on paper that tends to generate dust when cut.	In the Control Panel menu, set CutDustReduct. in Paper Details to On . (See "Reducing Dust from Cutting Rolls.") →P357

Paper rubs against the Printhead

Cause	Corrective Action
The type of paper specified in the printer driver does not match the type loaded in the printer.	Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359
	Make sure the same type of paper is specified in the printer driver as you have loaded in the printer.

5	8	5

Cause	Corrective Action	
The type of paper specified in the printer driver does not match the type loaded in the printer.	 Press the Stop button and stop printing. Change the type of paper in the printer driver and try printing again. 	
Paper has been loaded incorrectly, causing it to wrinkle.	Reload the paper. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359	
The Printhead is set too low in the Control Panel menu.	In the Control Panel menu, set Head Height to Automatic . (See "Troubleshooting Paper Abrasion and Blurry Images.") →P.527	
You are printing on heavyweight paper or paper that curls or wrinkles easily after absorbing ink.	For paper-based media such as Heavyweight Coated Paper, set the VacuumStrngth to Strong or Strongest in the Control Panel menu. If the paper still rubs against the printhead set the Head Height in the Control Panel menu to a higher value than the current setting. (See "Adjusting the Vacuum Strength.") →P.535 (See "Troubleshooting Paper Abrasion and Blurry Images.") →P.527	
	For film-based media such as Tracing Paper, set the VacuumStrngth to Standard, Strong or Strongest in the Control Panel menu. If the paper still rubs against the printhead, set the Head Height in the Control Panel menu to a higher value than the current setting. (See "Adjusting the Vacuum Strength.") →P.535 (See "Troubleshooting Paper Abrasion and Blurry Images.") →P.527	
	When printing on paper 0.1 mm (0.004 in) thick or less, choose a VacuumStrngth setting of Weakest in the Control Panel menu. If rubbing still occurs, in the Control Panel menu, use a higher Head Height setting. (See "Adjusting the Vacuum Strength.") →P.535 (See "Troubleshooting Paper Abrasion and Blurry Images.") →P.527	
When you have loaded paper, the paper you have loaded does not match the type selected on the Control Panel.	Be sure to select the correct type of paper in the Control Panel menu when loading paper. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359	

The edges of the paper are dirty

and dagger of the paper a	
Cause	Corrective Action
The Platen has become dirty after borderless printing or printing on small paper.	Open the Top Cover and clean the Platen. (See "Cleaning Inside the Top Cover.") →P.560
The type of paper as specified on the printer does not match the type speci-	Make sure the same type of paper is specified on the printer as in the printer driver. (See "Changing the Type of Paper.") →P.343
fied in the printer driver.	 Make sure the same paper type is specified in the printer driver as on the printer. Press the Stop button and stop printing. Change the type of paper in the printer driver and try printing again.
The paper is wrinkled or warped.	Straighten out the wrinkles or curls and reload the paper. Do not use paper that has been printed on previously. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359
A cut line is printed because CutDus- tReduct. is On in the Control Panel menu to reduce cutting dust.	If this function is not needed, set CutDustReduct . to Off in the Control Panel menu. (See "Menu Settings.") →P.418
The Printhead is set too low in the Control Panel menu.	In the Control Panel menu, set Head Height to Automatic . (See "Troubleshooting Paper Abrasion and Blurry Images.") →P.527
You are printing on heavyweight paper or paper that curls or wrinkles easily after absorbing ink.	For paper-based media such as Heavyweight Coated Paper, set the VacuumStrngth to Strong or Strongest in the Control Panel menu. If the paper still rubs against the printhead, set the Head Height in the Control Panel menu to a higher value than the current setting. (See "Adjusting the Vacuum Strength.") >P.535 (See "Troubleshooting Paper Abrasion and Blurry Images.") >P.527

Cause	Corrective Action
You are printing on heavyweight paper or paper that curls or wrinkles easily after absorbing ink.	For film-based media such as Tracing Paper, set the VacuumStrngth to Standard, Strong or Strongest in the Control Panel menu. If the paper still rubs against the printhead, set the Head Height in the Control Panel menu to a higher value than the current setting. (See "Adjusting the Vacuum Strength.") →P.535 (See "Troubleshooting Paper Abrasion and Blurry Images.") →P.527
The Ejection Guide is soiled.	Clean the Ejection Guide. (See "Cleaning the Printer Exterior.") →P.560

The surface of the paper is dirty

Cause	Corrective Action
The Paper Retainer is soiled.	Clean the Paper Retainer. (See "Cleaning Inside the Top Cover.") →P.560
You are using a paper that does not dry easily.	In the Control Panel menu, set Roll DryingTime to at least 1 min . (See "Menu Settings.") →P.418
	When paper that does not dry easily is used for printing, it may curl during printing and touch the Output Tray. In this case, in the Control Panel menu, complete the settings for Dry time and Area in Scan Wait Time . However, note that printing will now take longer. (See "Menu Settings.") →P.418

The back side of the paper is dirty

Cause	Corrective Action
The Platen has become dirty after borderless printing or printing on small paper.	Open the Top Cover and clean the Platen. (See "Cleaning Inside the Top Cover.") →P.560
The Platen has become soiled because you have set Width Detection to Off in the Control Panel menu.	Set Width Detection to On in the Control Panel menu, and then open the Top Cover and clean the Platen. (See "Cleaning Inside the Top Cover.") →P.560
	Open the Top Cover and clean the Platen. After this, manually advance the roll onto the Platen before printing. (See "Cleaning Inside the Top Cover.") →P.560 (See "Feeding Roll Paper Manually.") →P.349
The Paper Retainer is soiled.	Clean the Paper Retainer. (See "Cleaning Inside the Top Cover.") →P.560

Printed colors are inaccurate

Cause	Corrective Action
Color adjustment has not been activated in the Advanced Settings of the printer driver.	In the Advanced Settings of the printer driver, access Color Settings in Color Mode to adjust colors. (See "Main Sheet (Windows).") →P.150 (See "Main Pane (Mac OS).") →P.254
Colors have not been adjusted on the computer or	Refer to the computer and monitor documentation to adjust the colors.
monitor.	Adjust the settings of the color management software, referring to the software documentation as needed.
The Printhead nozzles are clogged.	Print a test pattern to check the nozzles and see if they are clogged. (See "Checking for Nozzle Clogging.") →P.546
Application Color Matching Priority is set to Off in the Windows printer driver.	Click Special Settings in the Layout sheet of the printer driver, and set Application Color Matching Priority to On in the dialog box that is displayed. (See "Layout Sheet (Windows).") →P.165

Cause	Corrective Action
Color may change slightly even on the same model of printer if you use a different version of the firmware or printer driver, or when you print under different settings or in a different printing environment.	 Follow these steps to prepare the printing environment. Use the same version of firmware or printer driver. Specify the same value for all settings items.

Banding in different colors occurs

Cause	Corrective Action
The paper feed amount is out of adjustment.	Adjust the feed amount. (See "Adjusting the Feed Amount.") →P.529
Printing does not proceed smoothly be- cause print jobs are interrupted during transmission.	Exit other applications and cancel other print jobs.
In the Control Panel menu, Adj. Priority is set to Print Length .	Setting Adj. Priority to Print Quality in the Control Panel menu and adjusting the feed amount may improve results. (See "Adjusting the Feed Amount.") →P.529
The Printhead is out of alignment.	Adjust the Printhead alignment. (See "Automatic Adjustment to Straighten Lines and Colors.") →P.522
The Printhead nozzles are clogged.	Print a test pattern to check the nozzles and see if they are clogged. (See "Checking for Nozzle Clogging.") P.546
Streaks may occur if you set the Print Quality too low.	Choose a higher level of Print Quality in the Advanced Settings of the printer driver and try printing again. Printing in Fast or Standard mode is faster and consumes less ink than in Highest or High modes, but the printing quality is lower. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") P.54
The type of paper specified in the printer driver does not match the type loaded in the printer.	Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359
	Make sure the same type of paper is specified in the printer driver as you have loaded in the printer.
	1. Press the Stop button and stop printing.
	2. Change the type of paper in the printer driver and try printing again.

Colors in printed images are uneven

Cause	Corrective Action
Line Drawing/Text is selected when printing images in many solid colors.	In Print Priority in the Advanced Settings of the printer driver, choose Image .
You are printing on paper that curls easily.	Printed colors may appear uneven on the leading edge of paper that is susceptible to curling. Select a stronger level in VacuumStrngth in the Control Panel menu to increase suction against the paper, or specify a leading margin of 20 mm (0.79 in) or more. (See "Adjusting the Vacuum Strength.") →P.535
Printed colors may be uneven if you set the Print Quality too low.	Choose a higher level of Print Quality in the Advanced Settings of the printer driver. Printing in Fast or Standard mode is faster and consumes less ink than in Highest or High modes, but the printing quality is lower. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") P.54
Color may be uneven between dark and light image areas.	Select Unidirectional Printing in the Advanced Settings of the printer driver.
When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be slightly uneven at the leading edges.	Specify No in Automatic Cutting in the printer driver before printing. In this case, the paper can be printed without borders on the left and right sides only. Cut the printed document ejected from the printer, and then use scissors or a cutting tool to cut away the edges on the top and bottom.
	Choose a higher level of Print Quality in the Advanced Settings of the printer driver. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") →P.54
The Printhead is out of alignment.	Adjust the Printhead alignment.

Cause	Corrective Action
The Printhead is out of alignment.	(See "Automatic Adjustment to Straighten Lines and Colors.") →P.522
Allowing printed documents to dry on top of each other may cause uneven colors.	To avoid uneven colors, we recommend drying each sheet separately.
Density may be uneven if you use Glossy Paper or Coated Paper.	In Advanced Settings of the printer driver, choose Highest or High in Print Quality.
The type of paper specified in the printer driver does not match the type loaded in the printer.	Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359
	Make sure the same type of paper is specified in the printer driver as you have loaded in the printer. 1. Press the Stop button and stop printing. 2. Change the type of paper in the printer driver and try printing again.
Scan Wait Time > Area in the Control Panel menu is set to Leading edge.	When Scan Wait Time > Area is set to Leading edge , colors may be uneven 110–140 mm from the leading edge. (The position varies depending on the Print Quality setting.) In this case, select Scan Wait Time > Area > Entire area . However, note that printing will now take longer. (See "Menu Settings.") →P418

Image edges are blurred or white banding occurs

Cause	Corrective Action
The Platen suction is too strong.	In the Control Panel menu, reduce the level of VacuumStrngth . (See "Adjusting the Vacuum Strength.") →P.535
Incorrect Printhead alignment value.	In the Control Panel menu, set Head Height to a lower height. (See "Troubleshooting Paper Abrasion and Blurry Images.") →P.527
The type of paper specified in the printer driver does not match the type loaded in the printer.	Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359
	Make sure the same type of paper is specified in the printer driver as you have loaded in the printer.
	 Press the Stop button and stop printing. Change the type of paper in the printer driver and try printing again.

The contrast becomes uneven during printing

Cause	Corrective Action
The paper feed amount is out of adjustment.	Adjust the feed amount. (See "Adjusting the Feed Amount.") →P.529
The type of paper specified in the printer driver does not match the type loaded in the printer.	Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P341 (See "Loading Sheets in the Printer.") →P359
	Make sure the same type of paper is specified in the printer driver as you have loaded in the printer.
	 Press the Stop button and stop printing. Change the type of paper in the printer driver and try printing again.

The length of printed images is inaccurate in the feeding direction

Cause	Corrective Action
In the Control Panel menu, Adj. Priority is set to Print Quality.	Set Adj. Priority to Print Length in the Control Panel menu, and then execute Adjust Length. (See "Adjusting the Feed Amount.") → P.529

5	8	9

Cause	Corrective Action
The type of paper specified in the printer driver does not match the type loaded in the printer.	Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359
	Make sure the same type of paper is specified in the printer driver as you have loaded in the printer.
	 Press the Stop button and stop printing. Change the type of paper in the printer driver and try printing again.

Images are printed crooked

Cause	Corrective Action
In the Control Panel menu, Skew Check Lv. is set to Loose or Off.	In the Control Panel menu, set Skew Check Lv. to Standard .
In the Control Panel menu, Width Detection is set to Off.	Set Width Detection to On in the Control Panel menu.

Documents are printed in monochrome

Cause	Corrective Action
In the Advanced Settings of the printer driver, Monochrome, Monochrome (BK ink), or Monochrome Bitmap is specified in Color Mode.	In the Advanced Settings of the printer driver, specify Color in Color Mode and try printing again.
The Printhead nozzles are clogged.	Print a test pattern to check the color ink nozzles and see if they are clogged. (See "Checking for Nozzle Clogging.") →P.546

Line thickness is not uniform

Cause	Corrective Action
In the Special Settings dialog box of the Windows printer driver, Fast	Access the printer driver Properties dialog box from Print in the File menu of the source application, and follow these steps to print.
Graphic Process is set to On.	1. Clear the option Open Preview When Print Job Starts on the Main sheet.
	2. Clear the option Page Layout on the Layout sheet.
	3. Click the Special Settings button in the Layout sheet, open the Special Settings dialog box, and set Fast Graphic Process to Off.
The type of paper specified in the printer driver does not match the type loaded in the printer.	Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359
	Make sure the same type of paper is specified in the printer driver as you have loaded in the printer.
	1. Press the Stop button and stop printing.
	2. Change the type of paper in the printer driver and try printing again.

Lines are misaligned

Cause	Corrective Action
The Printhead alignment is not adjusted.	Adjust the Printhead alignment. (See "Automatic Adjustment to Straighten Lines and Colors.") →P.522 (See "Manual Adjustment to Straighten Lines and Colors.") →P.523 (See "Adjusting Line Misalignment.") →P.525
The type of paper specified in the printer driver does not match the type loaded in the printer.	Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359
	Make sure the same type of paper is specified in the printer driver as you have loaded in the printer.
	1. Press the Stop button and stop printing.
	2. Change the type of paper in the printer driver and try printing again.

590

Cannot print over a network

Cannot connect the printer to the network
Cannot print over a TCP/IP network

Cannot connect the printer to the network

Cause	Corrective Action	
The Ethernet cable is not connected	1. Make sure the printer is connected to the network with the correct Ethernet cable, and then turn the printer on. For instructions on connecting the cable, refer to the Setup Guide.	
correctly to the printer's Ethernet port.	2. Make sure the Link indicator is lit. The bottom indicator is green if the printer is connected via 1000Base-T, while the top indicator is orange if connected via 100Base-TX and the top indicator is green if connected via 10Base-T. If the Link indicator is not lit, check the following points.	
	Make sure the connection point is on.	
	 Make sure the end of the Ethernet cable is connected correctly. Insert the Ethernet cable until it clicks and locks in place. 	
	 Make sure there is no problem with the Ethernet cable. If there is any problem, replace the Ethernet cable. 	
	 Check the communication mode with the connection point. Although the printer normally detects the communication mode and transmission rate of the communication point automatically (in auto negotiation mode), sometimes the communication point settings cannot be detected. In this case, configure the connection method manually, specifying the communication mode in use. (See "Configuring the Communication Mode Manually.") → P.461 	

Cannot print over a TCP/IP network

Cause	Corrective Action
The printer's IP address is not configured correctly.	Make sure the printer's IP address is configured correctly. (See "Configuring the IP Address Using imagePROGRAF Device Setup Utility.") →P.463 (See "Configuring the IP Address Using the Printer Control Panel.") →P.452
The printer's TCP/IP network settings are not configured correctly.	Make sure the printer's TCP/IP network settings are configured correctly. (See "Configuring the Printer's TCP/IP Network Settings With RemoteUI.") →P.456
The computer you are trying to print from is not configured correctly.	Make sure the computer's TCP/IP network settings are configured correctly. (See "Configuring the Printer Driver Destination (Windows).") →P.455 (See "Configuring the Destination in TCP/IP Networks (Mac OS).") →P.459

Cannot print over a Bonjour network

Cause	Corrective Action	
The computer you are trying to print from is not configured correctly.	Make sure the computer is configured correctly. (See "Configuring the Destination for Bonjour Network (Mac OS).") →P.459	
The computer and printer are not on the same network.	Due to the nature of Bonjour, you cannot print if the printer is on another network behind a router. Make sure the computer and printer are on the same network. For information about network settings, ask your network administrator.	

Installation problems

The computer does not recognize the printer	591
Removing Installed Printer Drivers	591

The computer does not recognize the printer

Cause	Corrective Action
In the Control Panel menu, Use USB or Use Ethernet is set to Off .	Set Use USB or Use Ethernet to On. (See "Menu Settings.") →P.418

Removing Installed Printer Drivers

Follow these steps to remove installed printer drivers and utilities.

Removing printer drivers (Windows)

Remove the printer driver as follows.



- The following procedure is for Windows 7. The method of removing printer drivers varies depending on the version of Windows.
- 1 From the Windows start menu, select All Programs > Canon Printer Uninstaller > imagePROGRAF Printer Driver Uninstaller to display the Delete Printer window.
- 2 Select the printer in the list and click **Delete**.
- 3 Click **Yes** after the **Warning** message is displayed.
- 4 Make sure that the printer has been removed from the list, and then click Exit.

Removing imagePROGRAF Status Monitor (Windows)

Remove imagePROGRAF Status Monitor as follows.



- The following procedure is for Windows 7. The method of removing printer drivers varies depending on the version of Windows.
- 1 Select Control Panel from the start menu.
- 2 Select Uninstall a program.



- If the User Account Control dialog box is displayed, click Yes.
- 3 Select imagePROGRAF Status Monitor, and then click the Uninstall button.

Removing imagePROGRAF Device Setup Utility (Windows)

Remove imagePROGRAF Device Setup Utility as follows.



The following procedure is for Windows 7. The method of removing printer drivers varies depending on the version of Windows.

1 Select Control Panel from the start menu.





• If the User Account Control dialog box is displayed, click Yes.

Select imagePROGRAF Device Setup Utility, and then click the Uninstall button.

593

HP-GL/2 problems

With HP-GL/2, printing is misaligned	593
Lines or images are missing in printed HP-GL/2 jobs.	
Lines are printed too thick or thin in HP-GL/2 print jobs	593
HP-GL/2 jobs are printed in monochrome (or color)	
Printed colors of lines are inaccurate during HP-GL/2 printing	
HP-GL/2 jobs are printed 6 mm larger than specified	
HP-GL/2 jobs are printed at maximum size, even if a standard size is specified	
HP-GL/2 printing takes a long time	504
The printer stops when printing a HP-GL/2 job (the carriage stops moving)	

With HP-GL/2, printing is misaligned

Cause	Corrective Action
The plotter origin is incorrect.	Check the printing commands.
	Set Detect img size to Command priority or Detected size in the Control Panel menu. (See "Menu Settings.") →P418
The Margin setting in the Control Panel menu is incorrect.	Adjust the Margin setting values in the Control Panel menu. (See "Menu Settings.") →P.418

Lines or images are missing in printed HP-GL/2 jobs.

Cause	Corrective Action
The memory is full.	Check the size of the data in the print job.
An HP-GL/2 command not supported by this printer was received.	Check the print job and settings.
The printer has received print data that includes HP RTL commands when Auto Rotate is On in the Control Panel menu.	In the Control Panel, set Auto Rotate to Off and print again. (See "Menu Settings.") → P.418
The plotter origin is incorrect.	Set Detect img size to Command priority or Detected size in the Control Panel menu. (See "Menu Settings.") →P.418
Oversize in the Control Panel menu is set to Off.	Set Oversize to On in the Control Panel menu. (See "Menu Settings.") →P.418

Lines are printed too thick or thin in HP-GL/2 print jobs

Cause	Corrective Action
The Width setting in the Control Panel menu is incorrect.	Change the Width setting configured in Pen no. of the Palette A or Palette B selected in the Control Panel menu. (See "Menu Settings.") →P.418
ThickenFineLines in the Control Panel menu is set to Off.	If fine lines are printed faintly, setting ThickenFineLines to On will print the lines more distinctly. (See "Menu Settings.") →P.418
The Ln wdth correct setting in the Control Panel menu is incorrect.	Change the Ln wdth correct setting in the Control Panel menu. (See "Menu Settings.") →P.418

HP-GL/2 jobs are printed in monochrome (or color)

Cause	Corrective Action
The Color Mode setting in the Control Panel menu is incorrect.	Check the Color Mode setting in the Control Panel menu. (See "Menu Settings.") →P.418 However, for optimal Printhead performance, the printer consumes trace amounts of color ink even when Monochrome is selected as Color Mode .

Printed colors of lines are inaccurate during HP-GL/2 printing

Cause	Corrective Action	
AdjustFaintLines is On in the Control Panel menu.	Setting AdjustFaintLines to Off in the Control Panel menu may help produce the expected results. However, lines in some colors may appear broken.	

HP-GL/2 jobs are printed 6 mm larger than specified

Cause	Corrective Action
The page size of the HP-GL/2 print job, as created in the source application, is incorrect.	In the Control Panel menu, set Oversize to Off . (See "Menu Settings.") →P.418

HP-GL/2 jobs are printed at maximum size, even if a standard size is specified

Cause	Corrective Action
The page size of the HP-GL/2 print job, as created in the source application, is incorrect.	Set Detect img size to Command priority or Detected size in the Control Panel menu. (See "Menu Settings.") →P.418
	Set Conserve Paper to On in the Control Panel menu. (See "Menu Settings.") →P.418

HP-GL/2 printing takes a long time

Cause	Corrective Action
Large print jobs with a lot of data take longer to print.	Please wait a while until printing is finished.
A job was printed when Input Resolution in the Control Panel menu was set to 600dpi .	In the Control Panel menu, set Input Resolution to 300dpi and print again. (See "Menu Settings.") →P.418

The printer stops when printing a HP-GL/2 job (the carriage stops moving)

Cause	Corrective Action
The printer is analyzing the print job.	Please wait a while until printing is finished.
A job was printed when Input Resolution in the Control Panel menu was set to 600dpi .	In the Control Panel menu, set Input Resolution to 300dpi and print again. (See "Menu Settings.") →P.418

Other problems

Other problems

The Ink Tank Cover has become detached from the printer	. 595
If the Printer Makes a Strange Sound	596
Messages advising to check the maintenance cartridge are not cleared	. 596
The printer consumes a lot of ink	

The Ink Tank Cover has become detached from the printer

Cause	Corrective Action
The Ink Tank Cover became detached from the printer because too much force was applied to the Ink Tank Cover.	Attach the Ink Tank Cover to the printer. (See "Attach the Ink Tank Cover to the printer.") →P.544

The printer does not go on

Cause	Corrective Action
The printer is unplugged.	Plug the power cord into the outlet, and then turn on the printer.
The specified voltage is not supplied.	Check the voltage of the outlet and breaker. (See "Specifications.") →P.622

The printer takes time to start up

Cause	Corrective Action
The printer may have shut down incorrectly last time. This may happen after power outages or if the printer is unplugged before it is turned off. In this case, the next time power is restored, the printer's hard disk is checked, and startup may take some time.	Please wait a while, because it may take several minutes to finish checking the hard disk. If an error message is displayed after the hard disk check, follow the instructions indicated to resolve the problem.

596

If the Printer Makes a Strange Sound

Cause	Corrective Action
The printer	The following sounds do not indicate a problem with the printer.
makes a sound during operation.	 There is a sound of suction from the Platen To prevent paper from rising, paper is held against the Platen by suction from Vacuum holes under it.
	 There is a sound when a different size of paper is used and when the Carriage goes from side to side When paper of a different size is used, a valve is automatically activated to switch the area for paper suction, which may make a sound. This mechanism prevents suction from Vacuum holes where there is no paper. In addition, ink is ejected in sync with the movement of the Carriage back and forth to ensure optimal ink flow. At this time, the valve automatically switches the area for paper suction, which may make a sound.
	 Roll paper makes a fluttering sound during printing There may be a fluttering sound when large paper is advanced.
	 If you suddenly hear the tone for cleaning operations At regular intervals, for printer maintenance, cleaning operations will begin automatically, even if the printer is in Sleep mode.
	 If you suddenly hear the tone for ink agitation At regular intervals, to ensure optimal printing quality, the ink is agitated automatically, even if the printer is in Sleep mode. The ink is also agitated automatically under the following conditions. Note that other operations are not possible while "Agitating" is displayed on the control panel.
	After the printer is turned on
	In other cases, contact your Canon dealer.

Messages advising to check the maintenance cartridge are not cleared

Cause	Corrective Action
The printer has not detected the new Maintenance Cartridge that was used to replace the old one.	Remove the new Maintenance Cartridge you have just installed and insert it again firmly. (See "Replacing the Maintenance Cartridge.") →P.554

The printer consumes a lot of ink

Cause	Corrective Action
Many full-page color images are printed.	In print jobs such as photos, images are filled with color. This consumes a lot of ink. This does not indicate a problem with the printer.
Head Cleaning B in the Control Panel menu is executed frequently.	Head Cleaning B in the Control Panel menu consumes a lot of ink. This does not indicate a problem with the printer. Unless the printer has been moved or stored for a long period or you are troubleshooting Printhead problems, we recommend not performing Head Cleaning B , to the extent possible.
You have just finished initial installation, when more ink is consumed to fill the system.	After initial installation or at the first-time use after transfer, ink flows into the system between the Ink Tank and Printhead. Although the amount of remaining ink may drop as a result, it does not indicate a problem.
The Printhead nozzles are clogged.	Check for nozzle clogging. (See "Checking for Nozzle Clogging.") →P.546

Ink Level Detection

Ink level detection will be deactivated if you load ink tanks once emptied.

Ink level detection

Ink tanks specified for this printer feature an ink level detection function to prevent the ink from running out during printing, which prevents printer damage. (See "Ink Tanks.") >P.538

This function will not work correctly if you use refill ink tanks. As a result, printing stops. Thus, before using refill ink tanks, you must cancel the ink level detection.

Printing with the ink level detection canceled may lead to printer damage and printing problems. Canon Inc. is not liable for any damage that may occur as a result of refilling ink.



After ink level detection has been released, this function cannot be reactivated for currently loaded lnk Tank. To
use ink level detection again, replace the lnk Tank with new ones specified for use with the printer.


 Repeatedly removing and inserting an Ink Tank may damage the connection between the Ink Tank and the printer, which may cause ink leakage from the Ink Tank and damage the printer.

Releasing ink level detection

1 On the Display Screen, a message indicates that the ink level cannot be detected. After checking the message, press the ▶ button.

Remaining level of the ink cannot be correctly detected. Check ink tank.

Press ▲ or ▼ to select Information, and then press the OK button.



A confirmation message is shown on the Display Screen about releasing ink level detection. After checking the message, press the button.


Tank once emptied is used. Printing stopped due to ink level unknown.

4 After checking the message, press the ▶ button.

To continue, you must release ink level detection.


◀

5 Press ▲ or ▼ to select **Yes**, and then press the **OK** button.



6 Check the message and press the ▶ button.

Release ink level detection after confirming that ink is in ink tank.



No

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571

Error Message

Error Messages	600
Messages regarding paper	602
Messages regarding ink	610
Messages regarding printing or adjustment	612
Messages regarding printheads	613
Messages regarding the maintenance cartridge	615
Messages regarding the hard disk	616
Messages regarding HP-GL/2	618
Other Messages	619

Specifications	021
Appendix	625

Error Messages

Borderless printing not possible	609
Cannot adjust paper feed.	612
Cannot adjust printhead.	
Cannot detect ink level correctly. Close tank cover.	610
Cannot detect papr	
Cannot recognize print head.	
Check if ink tank is set, and its color and direction.	
Check printed document	
Close IIIk Talik Cover	010
Do not pull out ink tank	611
End of paper feed.	608
ERROR Exxx-xxxx (x represents a letter or number)	
Error in cutter position.	
Execute printhead cleaning.	614
File read error.	616
GARO Wxxxx (x represents a number)	619
GL2: W0502 The parameter is out of range.	
GL2: W0504 This command is not supported.	
GL2: Wxxxx The memory is full. (xxxx is 0501, 0903, or 0904)	
Lloud didt ower	(1)
Hard disk error. Hardware error. xxxxxxxx-xxxx (x represents a letter or number)	
Traidware error. XXXXXXX-XXXX (X represents a letter of flurriber)	019
Ink insufficient.	
Ink tank is empty.	
Insert the maintenance cartridge.	
Insufficient paper for job	605
Leading edge detection error.	608
Mail box full. Delete unwanted data	616
Mail box full. Now printing without saving data.	616
Mail box nearly full.	
Maint. cart. The level is low	
Maintenance cartridge full.	
Maintenance cartridge problem.	
Maximum jobs storedMediaType Mismatch	
Multi-sensor error	
No ink left.	
No Maintenance Cartridge capacity.	
Not much ink is left.	611
Paper cutting failed.	608
Paper is crooked	
Paper jam	
Paper mismatch	
Paper not aligned with right guide.	
Paper position not suitable for borderless printing. Paper size not detected.	
PaprWidth Mismatch	
Parts replacement time has passed.	
Prepare for parts replacement.	
Printhead error	

Error Messages

Regular printing is selected, but a roll is loaded	. 606
Regular printing is selected, but a roll is loaded. Rel lever is in wrong position.	. 608
Remaining level of the ink cannot be correctly detected. Check ink tank.	610
Roll paper is not securely in contact with roll holder.	. 609
Roll printing is selected, but sheets are loaded.	. 605
Roll printing is selected.	. 605
Sheet printing is selected.	606
The following ink tanks cannot be recognized.	611
The mail box is full.	. 616
The paper is too small.	. 603
The paper is too small	
The roll is empty.	. 606
This paper cannot be used.	
This type of paper is not compatible with HP-GL/2.	. 618
Top cover is open.	. 620
Unknown file.	620
Wrong ink tank.	. 611
Wrong maintenance cartridge.	. 615
Wrong printhead	613

Messages regarding paper

Paper mismatch MediaType Mismatch The paper is too small. The paper is too small. PaprWidth Mismatch Paper size not detected. Insufficient paper for job This paper cannot be used.	602 603 603 604 604
Roll printing is selected. Roll printing is selected, but sheets are loaded. The roll is empty.	605
Sheet printing is selected. Regular printing is selected, but a roll is loaded.	
Paper jam Paper is crooked Paper not aligned with right guide. Cannot detect papr Leading edge detection error. Paper cutting failed End of paper feed Rel lever is in wrong position	607 607 608 608 608
Borderless printing not possible. Paper position not suitable for borderless printing.	
Roll paper is not securely in contact with roll holder.	609

Paper mismatch

Cause	Corrective Action
You tried to print a test pattern for printer adjustment on several sheets, but sheets of different types or sizes of paper were used.	When printing a test pattern for adjustment, use sheets of the same size and type of paper, in the required quantity. Press ▲ or ▼ to select Change Paper , press the OK button, and replace the paper. (See "Loading and Printing on Sheets.") →P.21 The printer now starts printing the test pattern.
	Press ▲ or ▼ to select Stop Printing , and then press the OK button.

MediaType Mismatch

	Cause	Corrective Action
	When Detect Mismatch in the Control Panel menu is set to Pause , the type of paper loaded does not match the type specified in the printer driver.	Follow these steps to ensure the paper type matches on the printer and in the printer driver.
		1. Press ▲ or ▼ to select Stop Printing, and then press the OK button.
		2. Change the paper type setting in the printer driver to the type loaded in the printer and try printing again.
		Follow these steps to ensure the paper type matches on the printer and in the printer driver.
		1. Press ▲ or ▼ to select Change Paper, and then press the OK button.
		 Replace the loaded paper with paper of the type and size you have specified in the printer driver. (See "Loading and Printing on Rolls.") →P.18 (See "Loading and Printing on Sheets.") →P.21

Cause	Corrective Action
When Detect Mismatch in the Control Panel menu is set to Pause , the type of paper loaded does not match the type specified in the printer driver.	Press ▲ or ▼ to select Print , and then press the OK button to resume printing. However, note that this error may cause paper jams and affect the printing quality.
When Detect Mismatch in the Control Panel menu is set to Warning , the type of paper loaded does not match the type specified in the printer driver.	You can continue to print, but note that this error may cause paper jams or problems in the printing results.

The paper is too small.

Cause	Corrective Action
When Detect Mismatch in the Control Panel menu is set to Pause , paper smaller than the size specified in the printer driver is loaded.	Press ▲ or ▼ to select Print , and then press the OK button to resume printing. However, note that this error may cause paper jams and affect the printing quality.
	Adjust the paper size setting in the printer driver to match the size loaded in the printer as follows.
	1. Press ▲ or ▼ to select Stop Printing , and then press the OK button.
	2. Change the paper size setting in the printer driver to the size loaded in the printer and try printing again.
	Replace the loaded paper with paper of a size that matches the size setting in the printer driver as follows.
	 Press ▲ or ▼ to select Change Paper, and then press the OK button to stop printing.
	 Replace the loaded paper to match the settings in the printer driver and try printing again. (See "Loading and Printing on Rolls.") →P.18 (See "Loading and Printing on Sheets.") →P.21
When Detect Mismatch in the Control Panel menu is set to Warning , paper smaller than the size specified in the printer driver is loaded.	You can continue to print, but note that this error may cause problems in the printing results.

The paper is too small.

"Replace paper with A4/LTR (vertical) or larger"

Cause	Corrective Action
The loaded paper is too small.	Replace the paper with paper of A4/Letter (vertical) size or larger as follows.
	 Press ▲ or ▼ to select Change Paper, press the OK button, and remove the paper. (See "Removing Sheets.") → R363
	2. Switch to paper A4/Letter (vertical) or larger. (See "Loading and Printing on Sheets.") →P.21 The printer will resume printing.
	Press ▲ or ▼ to select Stop Printing , and then press the OK button.

"Replace roll with 10 in. wide or larger roll."

Cause	Corrective Action
The loaded paper is too small.	Replace the roll with a roll 10 inches in width or larger as follows.
	1. Press ▲ or ▼ to select Change Paper, and then press the OK button. (See "Removing the Roll from the Printer.") →P.345 (See "Removing the Roll Holder from Rolls.") →P.348
	2. Replace the roll with a roll 10 inches wide or larger. (See "Attaching the Roll Holder to Rolls.") →P.338 (See "Loading Rolls in the Printer.") →P.341



 Cause
 Corrective Action

 The loaded paper is too small.
 The printer will resume printing.

 Press ▲ or ▼ to select Stop Printing, and then press the OK button.

"Remove paper and check pap. size"

Cause

A sheet has come out of the printer during printing.

Corrective Action

- 1. Press the Release Lever back and remove the paper.
- 2. Reload the sheet, aligning it with the guide on the right.
- Pull the Release Lever forward.
- 4. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button. Printing will resume, starting from the page on which the error occurred.

(See "Loading Sheets in the Printer.") →P.359

PaprWidth Mismatch

Cause Corrective Action When **Detect Mismatch** in the Control Panel menu is Press ▲ or ▼ to select **Print**, and then press the **OK** button to resume set to Pause or Hold Job, the width of the loaded roll does not match the width specified in Fit Roll Paper However, note that this error may cause paper jams and affect the printing Width in the printer driver. quality. Press ▲ or ▼ to select **Stop Printing**, and then press the **OK** button. Follow these steps to replace the roll to match the width specified in the printer driver. 1. Press ▲ or ▼ to select Change Paper, and then press the OK button. (See "Removing the Roll from the Printer.") →P.345 (See "Removing the Roll Holder from Rolls.") →P.348 2. Replace with paper of the width configured in the printer driver. (See "Attaching the Roll Holder to Rolls.") → P.338 (See "Loading Rolls in the Printer.") →P.341 The printer now starts printing the print job. Make sure the roll width selected in the dialog box displayed when you select Fit Roll Paper Width in the printer driver matches the width of the roll loaded in the printer, and then try printing again.

Paper size not detected.


Cause	Corrective Action
Paper has been loaded askew, or warped paper has been loaded.	Follow these steps to reload the roll. 1. Press the OK button and reload the paper. (See "Loading Rolls in the Printer.") →P.341 2. Pull the Release Lever forward. 3. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press
	the OK button. Printing will resume, starting from the page on which the error occurred. If this error recurs after you reload the roll, remove the Roll Holder from the printer, push the roll firmly in until it touches the Roll Holder flange, and reload the Roll Holder in the printer. (See "Attaching the Roll Holder to Rolls.") P.338
	Follow these step to reload a sheet. 1. Push the Release Lever back.

Cause	Corrective Action
Paper has been loaded askew, or warped paper has been loaded.	 Load the sheet, aligning it with the guide on the right. (See "Loading Sheets in the Printer.") →P.359 Pull the Release Lever forward.
	4. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button. Printing will resume, starting from the page on which the error occurred.

Insufficient paper for job

Cause

The printer has received a print job longer than the amount of roll paper left when ManageRemainRoll in the Control Panel menu is On.



Press ▲ or ▼ to select **Print**, and then press

the **OK** button to resume printing. However, the roll paper may run out during the print job and you may not be able to print all of the document.

Corrective Action

Press ▲ or ▼ to select Change Paper, and then press the OK button to stop printing. Either change the printer driver Paper Source setting or the GL2 Settings > Paper Source setting in the printer menu or replace the roll with a roll that has enough paper for the print job, and then try printing again.

(See "Removing the Roll from the Printer.") →P.345

(See "Loading Rolls in the Printer.") →P.341

Press ▲ or ▼ and select **Stop Printing** or press the **Stop** button to stop printing.

This paper cannot be used.

Cause	Corrective Action
Paper smaller than the printer's minimum supported size has been loaded.	Push the Release Lever back and load paper of the correct size. (See "Paper Sizes.") →P328
Paper has been loaded that is too small to print the test pattern for printhead adjustment or nozzle checking.	Push the Release Lever back and load unused paper of A4 size or larger. More than one sheet may be required depending on the adjustment.

Roll printing is selected.

Cause	Corrective Action
You have attempted to print on a roll, but no roll is loaded.	Press ▲ or ▼ to select "Load Roll Paper", and then press the OK button. Load the roll, and then print. (See "Attaching the Roll Holder to Rolls.") →P.338 (See "Loading Rolls in the Printer.") →P.341
	Press ▲ or ▼ and select Stop Printing or press the Stop button to stop printing.

Roll printing is selected, but sheets are loaded.

	Cause	Corrective Action	
	A print job for rolls was received when a sheet is loaded.	Follow these steps to load and print on a roll. 1. Press ▲ or ▼ to select Eject Cut Sheet , press the OK button, and remove the sheet. (See "Removing Sheets.") →P.363	
		2. Load a new roll. (See "Loading Rolls in the Printer.") →P.341 The printer now starts printing the print job.	
		Press ▲ or ▼ to select Stop Printing , and then press the OK button.	

The roll is empty.

Cause	Corrective Action
The roll is empty.	Follow these steps to replace the used roll with a new roll of the same type and size.
	1. Press the Release Lever back and remove the roll. (See "Removing the Roll from the Printer.") →P.345 (See "Removing the Roll Holder from Rolls.") →P.348
	2. Load the new roll. (See "Attaching the Roll Holder to Rolls.") →P.338 (See "Loading Rolls in the Printer.") →P.341
	3. If no barcode was printed on the roll, specify the type of paper. (See "Changing the Type of Paper.") →P343
	 4. When you have selected ManageRemainRoll > On in the control panel menu and a barcode is not printed on the roll, also specify the paper length. (See "Specifying the Paper Length.") →P.345
	5. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button. Printing will resume, starting from the page on which the error occurred. If no message appears, printing will continue from the next page.
There is remaining roll paper, but because it could not be advanced, it could not be detected.	The unused portion of the roll is heavy, and this is placing a burden on the printer. It may be helpful to change the printing mode, which will change the paper feed timing. Choose a higher level of Print Quality in the Advanced Settings of the printer driver. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") P.54

Sheet printing is selected.

Cause	Corrective Action
You have attempted to print on a sheet, but no sheet is loaded.	Press ▲ or ▼ to select Load Paper , and then press the OK button. Load a sheet, and then print. (See "Loading and Printing on Sheets.") →P.21
	Press ▲ or ▼ and select Stop Printing or press the Stop button to stop printing.

Regular printing is selected, but a roll is loaded.

Cause	Corrective Action
A print job for printing on sheets was sent when a roll is loaded.	 Press ▲ or ▼ to select Remove Roll Paper, and then press the OK button to stop printing. After removing the roll, load and print on a sheet of the type and size of paper you have specified in the printer driver.
	(See "Removing the Roll from the Printer.") → P.345 (See "Loading and Printing on Sheets.") → P.21 Press ▲ or ▼ to select Stop Printing , and then press the OK button to stop printing.

Paper jam

•	
Cause	Corrective Action
A paper jam occurred in the printer during printing.	For roll paper, cut the paper on the upper side of the {Paper Feed Slot. 1. Push the Release Lever back and remove the jammed paper. (See "Clearing Jammed Roll Paper.") →P.573 (See "Clearing a Jammed Sheet.") →P.576
	2. Load the paper. (See "Loading Rolls in the Printer.") →P.341 (See "Loading Sheets in the Printer.") →P.359
	3. Pull the Release Lever forward.
	4. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button.
	Printing will resume, starting from the page on which the error occurred.

Paper is crooked.

Cause Corrective Action Paper loaded crooked was detected when the paper was advanced. Follow these steps to reload the roll. 1. Push the Release Lever back. 2. Adjust the right edge of the roll to make it parallel to the orange Paper Alignment Line. 3. Pull the Release Lever forward. (See "Loading Rolls in the Printer.") →P.341 If this error recurs after you reload the roll, remove the Roll Holder from the printer, push the roll firmly in until it touches the Roll Holder flange, and reload the Roll Holder in the print-(See "Attaching the Roll Holder to Rolls.") →P.338 Follow these step to reload a sheet. 1. Push the Release Lever back. Pull out the sheet. 3. Pull the Release Lever forward. **4.** Reload the sheet, aligning it with the guide on the right. (See "Loading Sheets in the Printer.") →P.359



To disable this message (if it is displayed repeatedly despite reloading paper, for example), choose **Off** or **Loose** in the **Skew Check Lv.** setting of the printer menu. However, this may cause jams and printing problems because paper may be askew when printed. Also, the Platen may become soiled, which may soil the back of the next document when it is printed.

Paper not aligned with right guide.

Cause	Corrective Action
When paper was loaded, it was not aligned with the guide on the right side.	Follow these step to reload a sheet.
Side.	1. Push the Release Lever back.
	2. Pull out the sheet.
	3. Pull the Release Lever forward.
	4. Reload the sheet, aligning it with the guide on the right.

608

Cannot detect papr

Cause	Corrective Action
The printer could not detect the paper.	Reload the paper as follows.
	1. Remove the paper and press the OK button.
	2. Reload the paper. (See "Loading Sheets in the Printer.") →P.359 (See "Loading Rolls in the Printer.") →P.341

Leading edge detection error.

Cause	Corrective Action
The leading edge of the paper cannot be detected.	Follow these step to reload a sheet.
	1. Push the Release Lever back.
	2. Reload the sheet straight, in the correct position. (See "Loading Sheets in the Printer.") →P.359

Paper cutting failed.

Cause	Corrective Action
There are sheets left on the Ejection Guide.	 Push the Release Lever back and remove the paper. Load the paper. Pull the Release Lever forward. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button. Printing will resume, starting from the page on which the error occurred. (See "Loading Rolls in the Printer.") P341
There is a foreign object by the Output Tray, obstructing the Cutter Unit.	 Lift the Top Cover and remove the foreign object. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button. Printing will resume, starting from the page on which the error occurred.
You are not using the printer under the recommended environmental conditions for the paper.	Use the printer only where the recommended environmental conditions for the paper are met. Note that various environmental conditions are recommended for various types of paper. For details on the recommended environmental conditions for paper, see Paper Reference Guide." (See "Displaying the Paper Reference Guide.") → P.331
You are using paper that is not compatible with automatic cutting.	 Specify Manual as the cutting method and use scissors or a cutting tool to cut the roll. (See "Specifying the Cutting Method for Rolls.") →P.352 For information about paper that is compatible with automatic cutting, see the Paper Reference Guide. (See "Displaying the Paper Reference Guide.") →P.331 Push the Release Lever back and remove the paper.
In other cases, the Cutter Unit may be damaged.	Contact your Canon dealer for assistance.

End of paper feed.

Cause	Corrective Action
Although an attempt was made to advance the paper manually, it reached the limit position that can be advanced.	Canceling manual advancing. (See "Feeding Roll Paper Manually.") →P.349

Rel lever is in wrong position.

Cause	Corrective Action
The Release Lever is pushed back.	
	Turn off the printer and wait a while before restoring power.

Borderless printng not possible.

2014011000 printing not populate.		
Cause	Corrective Action	
The print job received specifies a type or width of paper that is not compatible with borderless printing.	Follow these steps to change the settings of the print job to enable borderless printing.	
	1. Press ▲ or ▼ to select Stop Printing , and then press the OK button.	
	 Make sure the correct printer driver for the printer is selected and try printing again. For information on types of paper compatible with borderless printing, refer to the Paper Reference Guide. (See "Displaying the Paper Reference Guide.") →P.331 	
	Press ▲ or ▼ to select Print With Border , and then press the OK button to continue printing. The document will be printed with a border.	
The loaded paper is a size not	Press ▲ or ▼ to select Stop Printing , and then press the OK button.	
compatible with borderless printing.	Replace the paper with paper compatible for borderless printing as follows.	
S .	 Press ▲ or ▼ to select Change Paper, and then press the OK button. (See "Removing the Roll from the Printer.") →P.345 (See "Removing the Roll Holder from Rolls.") →P.348 	
	2. Replace the paper with paper compatible for borderless printing. (See "Attaching the Roll Holder to Rolls.") →P.338 (See "Loading Rolls in the Printer.") →P.341 The printer now starts printing the print job. For information on types of paper compatible with borderless printing, refer to the Paper Reference Guide. (See "Displaying the Paper Reference Guide.") →P.331	
	Press ▲ or ▼ to select Print With Border , and then press the OK button to continue printing. The document will be printed with a border.	
Because paper expands or contracts depending on the environment of use, it may become narrower or wider than the supported width for borderless printing.	Use each type of paper only where the recommended environmental conditions are met. For details on environmental conditions for various paper, see the Paper Reference Guide . (See " Displaying the Paper Reference Guide .") → P.331	

Paper position not suitable for borderless printing.

Cause	Corrective Action
Because paper expands or contracts depending on the environment of use, it may become narrower or wider than the supported width for borderless printing.	Press ▲ or ▼ to select Stop Printing , and then press the OK button. Use each type of paper only where the recommended environmental conditions are met. For details on environmental conditions for various paper, see the Paper Reference Guide . (See " Displaying the Paper Reference Guide .") →P.331
The paper is loaded askew.	Press ▲ or ▼ to select Fix Paper Position and straighten the paper so that the edges are between the ink grooves for borderless printing. Insert the roll firmly until it touches the flange of the Roll Holder. (See "Attaching the Roll Holder to Rolls.") → P.338
	Press ▲ or ▼ to select Print With Border , and then press the OK button to continue printing. The document will be printed with a border.
	Press ▲ or ▼ to select Stop Printing , and then press the OK button.

Roll paper is not securely in contact with roll holder.

Cause	Corrective Action
When the roll was loaded, the roll was not inserted firmly all the way on the Roll Holder.	Follow these steps to reload the roll. 1. Press the OK button and remove the roll holder from the printer.
	2. Insert the roll firmly on the Roll Holder until it touches the flange. (See "Attaching the Roll Holder to Rolls.") →P338
	3. Load the Roll Holder in the printer.

Messages regarding ink

Ink insufficient. No ink left. Remaining level of the ink cannot be correctly detected. Check ink tank. Cannot detect ink level correctly. Close tank cover.	610 610
Close Ink Tank Cover	611
Check if ink tank is set, and its color and direction. The following ink tanks cannot be recognized. Wrong ink tank.	611 611
Do not pull out ink tank.	

Ink insufficient.

Cause	Corrective Action
The ink level is low, so you cannot print, clean the Printhead, or do other operations that require ink. There is not enough ink of the color with × displayed above the remaining ink indicator.	Press ▲ or ▼ to select Rep. Ink Tank , and then press the OK button. Replace the Ink Tank that is low with a new Ink Tank. (See "Replacing Ink Tanks.") →P.538
	Press ▲ or ▼ to select Continue to print , and then press the OK button to resume printing. However, note that this error may affect the printing quality.
	Press the OK button, open the lnk Tank Cover, and replace the lnk Tank for the color that does not have enough ink. (See "Replacing lnk Tanks.") → P.538

No ink left.

Cause	Corrective Action
There is no ink left. There are no ink colors with x displayed above the remaining ink indicator.	Press the OK button, open the lnk Tank Cover, and replace the lnk Tank for the color that is out of ink. (See "Replacing lnk Tanks.") →P.538


Remaining level of the ink cannot be correctly detected. Check ink tank.

Cause	Corrective Action
Ink level detection cannot work correctly if you use refill ink tanks.	The refill ink tank can no longer be used. See the section Ink level detection and take the appropriate action. (See " Ink Level Detection .") \rightarrow P.596

Cannot detect ink level correctly. Close tank cover.

Cause	Corrective Action
The remaining ink level could not be correctly detected.	Close the Ink Tank Cover. The buzzer stops sounding. Next, "No ink left." → P.610

Close Ink Tank Cover



Ink tank is empty.

Cause	Corrective Action
There is no ink left in an ink tank. There are no ink colors with × displayed above the remaining ink indicator in the lnk tab top screen. (See "Checking lnk Tank Levels.") →P.543	Open the Ink Tank Cover, and replace the Ink Tank for the color that is out of ink. (See "Replacing Ink Tanks.") →P.538

Not much ink is left.

Cause	Corrective Action
Not much ink is le	ft. Prepare a new Ink Tank. We recommend replacing the Ink Tank with a new Ink Tank at this point if you plan to print large-format or high-quantity jobs.

Check if ink tank is set, and its color and direction.

Cause	Corrective Action
There is no Ink Tank of the indicated color in the printer.	Load the Ink Tank. (See "Replacing Ink Tanks.") →P.538
There is a problem with the lnk Tank.	Replace it with a new lnk Tank. (See "Replacing lnk Tanks.") →P.538

The following ink tanks cannot be recognized.

Cause	Corrective Action
An Ink Tank that is incompatible with the printer is loaded.	Load an Ink Tank that is compatible with the printer. (See "Replacing Ink Tanks.") →P.538

Wrong ink tank.

Cause	Corrective Action
The Ink Tank in the printer is incompatible.	Load an Ink Tank specified for use with the printer.
	(See "Replacing Ink Tanks.") → P.538

Do not pull out ink tank.

Cause	Corrective Action
The Ink Tank was removed using an	Install the Ink Tank that was removed.
incorrect procedure.	The buzzer stops sounding.
	Next, replace the lnk Tank using the procedure on the Display Screen in the Control Panel.

N	Jaccanae	regarding	printing	or ad	inetmant
IV	lessages	regarding	printing	oi au	justinen

Cannot adjust printhead.	613
Borderless printng not possible.	609
Cannot adjust paper feed. Check printed document.	

Cannot adjust paper feed.

• • •	
Cause	Corrective Action
The Printhead nozzles are clogged.	Execute Adj. Quality again, as follows.
	1. Press the OK button to clear the error.
	2. Print a test pattern to check the nozzles. (See "Checking for Nozzle Clogging.") →P.546
	3. Clean the Printhead if the nozzles are clogged. (See "Cleaning the Printhead.") →P.547
	4. Execute Adj. Quality again. (See "Automatic Banding Adjustment.") →P.530
Highly transparent film is loaded that cannot be used for automatic feed amount adjustment.	Press the OK button to clear the error, and then adjust the feed amount manually. (See "Manual Banding Adjustment.") >P.531

Check printed document.

Cause	Corrective Action
The Printhead nozzles are becoming clogged.	If printing is faint, clean the Printhead. (See "Cleaning the Printhead.") →P.547

Messages regarding printheads

Cannot adjust printhead.	613
Wrong printhead.	613
Printhead error	
Cannot recognize print head	613
Execute printhead cleaning	

Cannot adjust printhead.

Cause	Corrective Action
The Printhead nozzles are clogged.	Execute Head Posi. Adj. again, as follows.
clogged.	1. Press the OK button to clear the error.
	2. Print a test pattern to check the nozzles. (See "Checking for Nozzle Clogging.") →P.546
	3. Clean the Printhead if the nozzles are clogged. (See "Cleaning the Printhead.") →P.547
	4. Execute Head Posi . Adj . again. (See "Automatic Adjustment to Straighten Lines and Colors.") →P.522
The Printhead cannot be aligned; highly transparent film is loaded.	Press the OK button to clear the error. We recommend using a type of paper that you often use, other than film, for Printhead adjustment. (See "Automatic Adjustment to Straighten Lines and Colors.") →P.522
The Printhead is installed	Straighten the Printhead as follows, and then execute Head Posi. Adj. again.
crooked.	1. Press the OK button to clear the error.
	2. Use Head Inc. Adj. to adjust the angle of inclination of the Printhead. (See "Adjusting Line Misalignment.") →P.525
	3. Execute Head Posi . Adj . again. (See "Automatic Adjustment to Straighten Lines and Colors.") →P.522

Wrong printhead.

Cause	Corrective Action
An incompatible Printhead has been installed.	Open the Top Cover and replace the Printhead with a new one. (See "Replacing the Printhead.") →P.548

Printhead error

Cause	Corrective Action
There is a problem with the Printhead.	Open the Top Cover and replace the Printhead with a new one.
	(See "Replacing the Printhead.") →P.548

Cannot recognize print head.

Cause	Corrective Action
No Printhead is installed.	Follow these steps to install the Printhead.
	1. Open the Top Cover.
	2. Install the Printhead. (See "Replacing the Printhead.") →P.548
The Printhead cannot be recognized because it is not installed correctly.	Follow these steps to reinstall the Printhead.
	1. Open the Top Cover.
	2. Reinstall the Printhead. (See "Replacing the Printhead.") →P.548

Execute print	head cleaning.
_	

Cause	Corrective Action
The Printhead noz-	Follow these steps to clean the Printhead.
zles are clogged.	1. Stop printing by pressing ▲ or ▼ to select Stop Printing .
	2. Clean the Printhead. (See "Cleaning the Printhead.") →P.547
If the message is still displayed when printing, replace the Printhead. (See "Replacing the Printhead.") →P.548	
	Press ▲ or ▼ to select Print , and then press the OK button to resume printing. However, note that this error may affect the printing quality.

Messages regarding the maintenance cartridge

Insert the maintenance cartridge. Wrong maintenance cartridge.	
Maint. cart. The level is low	615
No Maintenance Cartridge capacity.	. 615
Maintenance cartridge full.	615
Maintenance cartridge problem.	. 615

Insert the maintenance cartridge.

Cause	Corrective Action
The Maintenance Cartridge is not installed.	Install the Maintenance Cartridge. (See "Replacing the Maintenance Cartridge.") →P.554

Wrong maintenance cartridge.

Cause	Corrective Action
A Maintenance Cartridge for a different model of printer is installed.	Replace it with the Maintenance Cartridge for your particular model. (See "Maintenance Cartridge.") → P.554

Maint. cart. The level is low

Cause	Corrective Action
The Maintenance Cartridge is almost full.	You can continue to print, but prepare a new Maintenance Cartridge to use when the message for replacement is displayed.

No Maintenance Cartridge capacity.

Cause	Corrective Action
The Maintenance Cartridge cannot absorb enough ink for Printhead cleaning or other operation.	After confirming that the printer has stopped operating, replace the Maintenance Cartridge. (See "Replacing the Maintenance Cartridge.") →P.554

Maintenance cartridge full.

Cause	Corrective Action
The Maintenance Cartridge is full.	After confirming that the printer has stopped operating, replace the Maintenance Cartridge.
	(See "Replacing the Maintenance Cartridge.") →P.554

Maintenance cartridge problem.

Cause	Corrective Action
An incompatible or used Maintenance Cartridge has	Install an unused Maintenance Cartridge specified for use with the printer.
been installed.	(See "Replacing the Maintenance Cartridge.") →P.554

616

Messages	regard	ling the	hard	disk

Hard disk error	
The mail box is full. Mail box full. Now printing without saving data. Mail box nearly full.	616
Maximum jobs stored. Mail box full. Delete unwanted data	616

Hard disk error.

Cause	Corrective Action	
The format of the printer's hard disk is invalid.	Press the OK button to start reformatting the hard disk. When formatting is finished, data on the printer hard disk is erased and the printer automatically restarts.	

File read error.

Cause	Corrective Action
Files on the printer's hard disk have become corrupted.	Restart the printer. Only the corrupted files will be deleted, and the printer will restart.

The mail box is full.

Cause	Corrective Action
There is no more space on the printer's hard disk.	Press the Stop button and stop printing.
	Delete print jobs from the queue. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") →P.488
	Delete unneeded jobs stored in personal boxes. (See "Deleting Saved Jobs.") → P.496

Mail box full. Now printing without saving data.

Cause	Corrective Action
No more space is available on the printer's hard disk, so jobs are now printed	After printing, this message is cleared.
without saving them. (Print jobs can no longer be saved on the hard disk.)	Delete unneeded jobs stored in personal boxes. (See "Deleting Saved Jobs.") →P.496

Mail box nearly full.

Cause	Corrective Action
The free hard disk space left for Personal Boxes in the printer's hard disk does not have more than 1 GB, combined.	Delete unneeded jobs stored in Personal Boxes. (See "Deleting Saved Jobs.") →P.496

Maximum jobs stored.

Cause	Corrective Action
100 jobs are stored in the personal box.	Delete unneeded jobs stored in personal boxes. (See "Deleting Saved Jobs.") →P.496

Mail box full. Delete unwanted data

Cause	Corrective Action
100 jobs are stored in the Personal Box.	Press the Stop button and stop printing.
	Delete print jobs from the queue. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") →P.488
	Delete unneeded jobs stored in personal boxes.

Cause	Corrective Action
100 jobs are stored in the Personal Box.	(See "Deleting Saved Jobs.") →P.496

Messages regarding HP-GL/2

This type of paper is not compatible with HP-GL/2.	
GL2: Wxxxx The memory is full. (xxxx is 0501, 0903, or 0904)	
GL2: W0502 The parameter is out of range618	
GL2: W0504 This command is not supported	

This type of paper is not compatible with HP-GL/2.

Cause	Corrective Action
The printer has received a HP-GL/2 print job that cannot be printed on the	Follow these steps to replace the type of paper in the printer. 1. Press ▲ or ▼ to select Stop Printing, and then press the OK button.
paper that has been advanced.	 Replace the paper with a type compatible with HP-GL/2. For details on paper compatible with HP-GL/2, refer to the Paper Reference Guide. (See "Displaying the Paper Reference Guide.") →P.331
	Press ▲ or ▼ to select Print , and then press the OK button to resume printing. However, note that this error may cause paper jams and affect the printing quality.

GL2: Wxxxx The memory is full. (xxxx is 0501, 0903, or 0904)

Cause	Corrective Action
The printer memory is full.	Because the entire print job could not be received, the printer may not be able to print the entire original. Check the printing results.
	In the Control Panel menu, setting On-the-Fly to On may enable printing. However, check the printing results because the image may be incomplete in some cases.

GL2: W0502 The parameter is out of range.

Cause	Corrective Action
A parameter specified in a HP-GL/2 command is out of the supported range.	Check the print job.
	If you have specified ProcessingOption > Warning > On in the Control Panel menu, set it to Off instead.

GL2: W0504 This command is not supported.

Cause	Corrective Action
The printer has received an unsupported HP-GL/2 command.	Check the print job.
	If you have specified ProcessingOption > Warning > On in the Control Panel menu, set it to Off instead.

Other Messages

Other Messages

GARO Wxxxx (x represents a number)	619
Top cover is open.	. 620
Prepare for parts replacement. Parts replacement time has passed.	
Unknown file. Multi-sensor error	
Error in cutter position.	. 620

GARO Wxxxx (x represents a number)

Cause	Corrective Action
There is a problem with the print job.	Try printing again, using the correct printer driver.
	It is also possible to continue printing in this state. However, you may not be able to obtain the desired printing results.

ERROR Exxx-xxxx (x represents a letter or number)

Cause	Corrective Action
An error requiring service may have occurred. •• ERROR Exxx-xxxx Call for service.	Write down the error code and message, turn off the printer, and contact your Canon dealer for assistance.
OK: Printer Info.	

Hardware error. xxxxxxxxxxxxx (x represents a letter or number)

Cause		Corrective Action
The last portion of roll paper was used during a print job. The paper was not advanced because the trailing edge is taped to the roll.		Turn off the printer and remove the roll from the printer before restoring power.
Fastening tape or the Belt Stopper has not been rem the Top Cover.	noved inside	Turn off the printer, open the Top Cover and remove the tape or the Belt Stopper before restoring power.
An error requiring service may have occurred. I Hardware error. xxxxxxxx-xxxx Turn off printer, wait, then turn on again. OK: Printer Info.		Turn off the printer and wait at least three seconds before restoring the power. If the message is displayed again, write down the error code and message, turn off the printer, and contact your Canon dealer for assistance.

Hardware error. 03130031-2F7x (x is 0, 1, or 2)

Cause	Corrective Action
The ink tank is not installed correctly.	Turn off the power, remove and then reinstall all of the ink tanks, and then turn on the power. If the same message is displayed again, write down the error code and message, turn off the printer, and contact your Canon dealer for assistance. (See "Replacing Ink Tanks.") → P.538



Cause	Corrective Action
The printer has detected that the Top Cover is open.	Open the Top Cover fully, remove any foreign objects, and close the Top Cover again.
	If the error occurs again, close the Top Cover, turn off the printer, and wait a while before restoring power.

Prepare for parts replacement.

Cause	Corrective Action
It is almost time to replace consumables for which service is required.	If "Parts replacement time has passed." is displayed, you can continue to use the printer for some time. Contact your Canon dealer for assistance.

Parts replacement time has passed.

Cause	Corrective Action
It is past the recommended time to replace consumables for which service is required.	Contact your Canon dealer for assistance.

Unknown file.

Cause	Corrective Action
Data sent to keep the printer up to date (such as paper information) is in the wrong format.	Check the data. Turn off the printer and wait a while before restoring power, and then resend the data.
You have uploaded firmware for a different model.	Check the firmware version. Turn off the printer and wait a while before restoring power, and then resend the firmware.
	If the message is displayed again, contact your Canon dealer for assistance.

Multi-sensor error

Cause	Corrective Action
Direct sunlight or strong lighting may be shining on the printer and causing the sensor to malfunction.	Take steps to ensure the printer is not used when exposed to direct sunlight or strong lighting.
The performance of a sensor inside the printer may be impaired.	Turn off the printer and wait at least three seconds before restoring the power. If the message is displayed again, contact your Canon dealer for assistance.

Error in cutter position.

Cause	Corrective Action
The Cutter Unit stops in the middle of cutting.	1. Push the Release Lever back and remove the paper.
	2. Pull the Release Lever forward.

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599

Specifications

Appendix 625

Printer Specifications

Specifications



• The following values may vary depending on the operating environment.

Printer

Power supply		100-240 V AC (50/60 Hz)		
Power consumption	During operation	140 W max.		
Sleep mode	Sleep mode	5 W max.		
	Off	0.5 W max. (*1)		
Operating noise (*2)	Sound pressure level	During operation	Approx. 47 dB (A)	
		Standby	35 dB (A) max.	
	Audio power level (during opera	ation)	Approx. 6.4 bels	
Operating environment	Temperature	15-30°C (59-86°F)		
	Humidity	10–80%, non-condensing		
Dimensions (W × D × H)	Printer only		997×757×507 mm (39.3×29.8×20.0 in)	
	Printer and Stand (When the Output Stacker is used)	Extended position A	997×887×1,062 mm (39.3×34.9×41.8 in)	
		Extended position B	997×1,100×1,062 mm (39.3×43.3×41.8 in)	
Weight	Printer only	Approx. 46.2 kg (101.9l	b)	
	Main unit and Stand(including Roll Holder. Does not include Printhead and Ink Tank.)	Approx. 56.9 kg (125.4l	b)	
Space for installation (W × D	Space for installation (W × D Printer only		1,397×1,367×807 mm (55.0×53.8×31.8 in)	
× H)	Printer and Stand	1,397×1,700×1,362 mm (55.0×66.9×53.6 in)		
Related standards	International Energy Star Program, Law on Promoting Green Purchasing/GPN (Japan), Eco Mark (Japan), RoHS			

^{*1:} The printer uses a trace amount of power even when turned off. To stop all power consumption, turn off the printer and unplug the power cord.

Printing performance

Print method	Bubblejet
Maximum resolution	2400 dpi horizontally (*1) × 1200 dpi vertically
Printhead	PF-04
Number of nozzles	MBK: 5120; Others: 2560 each color

^{*1:} Prints with a minimum 1/2400 inch dot pitch between ink droplets.

Memory and hard disk

Memory	32 GB (256 MB physical memory)
Hard disk capacity	320 GB

^{*2:} Calculation based on ISO 7779. Operating conditions: On the **Main** sheet of the printer driver, **Media Type** > Plain Paper, **Advanced Settings** > **Print Priority** > **Line Drawing/Text**, and **Print Quality** > **Standard**.

Hard disk capacity	Personal mail boxes (Permanent storage area)	180 GB
Print job storage capacity	Common Box	100 jobs
	Personal Boxes	100 jobs

Interface

USB	Format	Internal port
	Mode	Full-speed (12 Mbps), high-speed (480 Mbps), bulk transfer
	Connector	Series B (4-pin)
Ethernet	Format	Internal port
	Specification	IEEE 802.3 10Base-T, IEEE 802.3u 100Base-TX/Auto-Negotiation, IEEE 802.3ab 1000Base-T/Auto-Negotiation, IEEE 802.3x Full Duplex IEEE 802.3az EEE
	Protocols	SNMP (supports Canon-MIB), HTTP, TCP/IP (IPv4/IPv6)

Ink

For information on the ink the printer supports, see "Ink Tanks." →P.538

Paper

For information on the types of paper the printer supports, refer to the **Paper Reference Guide**. (See "**Displaying** the **Paper Reference Guide**.") →P.331

Paper width	For information on the	For information on the paper widths the printer supports, see "Paper Sizes." →P328	
Minimum paper length	Rolls	203.2 mm (8.0 in)	
	Sheets	279.4 mm (11.0 in)	
Maximum printable length (*1)	Rolls	18 m (19.7 yd)	
	Sheets	1,600 mm (63.0 in)	
Thickness	Rolls	0.07-0.8 mm (0.0028-0.031 in)	
	Sheets	0.07-0.8 mm (0.0028-0.031 in)	
Roll maximum outer diameter Supported paper core inner diameter		150 mm (6 in) or shorter	
		2 inches / 3 inches	
Print area	For details, see "Print	For details, see "Print Area." →P.623	

^{*1:} Varies depending on the operating system or application.

Roll Holder Set	Roll Holder Set RH2-26
Stand	Printer Stand ST-27
Stand(*1)	Printer Stand ST-27

^{*1:} The stand that is included depends on the region where you purchased the printer.

Print Area


A margin required by the printer is added with respect to the size of paper loaded in the printer. Except in border-less printing, the actual printing area corresponds to the paper size minus the space for this margin.




- Printable Area: The area that can be printed.
- There is no margin (that is, a margin of 0 mm) during borderless printing on rolls.
- Recommended Print Area: We recommend printing within this area.
- To print so that your original matches the print area exactly, use an oversized paper size that includes the required margin. (See "Printing on Oversize Paper.") >P.70

	Margins of Printable Area			Margins of Recommended Print Area		
	Top Edge	Bottom Edge	Sides	Top Edge	Bottom Edge	Sides
Sheets	3 mm (0.12 in)	23 mm (0.91 in)	3 mm (0.12 in)	20 mm (0.79 in)	23 mm (0.91 in)	5 mm (0.20 in)
Rolls	0/3 mm (0/0.12 in)	0/3 mm (0/0.12 in)	0/3 mm (0/0.12 in)	20 mm (0.79 in)	5 mm (0.20 in)	5 mm (0.20 in)

Sheets



Recommended Print Area




Printable Area

a margin of 3 mm (0.12 in) on top, 23 mm (0.91 in) on bottom, and 3 mm (0.12 in) on left and right sides is required.


• Recommended Print Area

A margin of 20 mm (0.79 in) on top, 23 mm (0.91 in) on bottom, and 5 mm (0.20 in) on left and right sides is required.

Rolls



Recommended Print Area



Printable Area

A margin of 3 mm (0.12 in) on all sides is required. During borderless printing, the margin on all sides is 0 mm. For information on paper compatible with borderless printing, see the **Paper Reference Guide**. (See "Types of Paper.") >P.328

Recommended Print Area

A margin of 20 mm (0.79 in) on top, 5 mm (0.20 in) on bottom, and 5 mm (0.20 in) on left and right sides is required.

Append

SOLLS EULGE

iPF685

User's Guide

Basic Printing Workflow	15
Enhanced Printing Options	29
Windows Software	141
Mac OS Software	249
Handling and Use of Paper	327
Control Panel	399
Printer Parts	435
Network Setting	447
Print Job Management	467
Adjustments for Better Print Quality	521
Maintenance and Consumables	537
Troubleshooting	571
Error Message	599
Specifications	621

Appendix

▲Safety Precautions	626
—	
Manuals for this printer	630
•	
Disposal of the product	632

626

Safety Precautions

Safety Precautions	626
Legal Notices	628

Safety Precautions

Follow the warnings and precautions below to use the printer safely. Do not perform any operations or procedures other than as described in this manual. Doing so may result in unexpected accidents and can cause a fire or electrical shocks.

Printer location



Do not set up the printer in any location exposed to alcohol, thinner, or other volatile liquids. If these substances
come into contact with electrical components inside the printer, there is a risk of fire or electrical shock.



- Never install the printer on an unstable or vibrating surface. If it falls over, this could cause personal injury.
- Never set up the printer in a location that is exposed to high humidity or large amounts of dust, or exposed to direct sunlight, high temperature, or open flame. This could cause a fire or electrical shock. Use the printer location in an environment where temperature and humidity are within the ranges of 15 °C to 30 °C (59 °F to 86 °F) and 10 to 80% RH (with no condensation).
- Never place the printer on a heavy wool or shag carpet. The fibers may enter the printer and cause a fire.
- Keep the area around the power outlet clear of items so that you can disconnect the power cable immediately if
 the printer starts operating abnormally. In the event of a printer malfunction, remove the power cable from the
 outlet as soon as possible to prevent fire and electrical shocks.
- Do not install the printer near sources of strong electromagnetic fields, whether equipment that generates such fields or places where such fields occur. This could damage the printer or cause malfunction.

Power Supply



- Never handle the power cable with wet hands. Doing so may cause electrical shock.
- Warning Insert the power cable securely and completely into the power source. If the power cable is not inserted completely, this could cause a fire or electrical shock.
 - Do not use any power cable other than the one provided. This could cause a fire or electrical shock. Never use the
 power cable with any other electrical device.
 - Never cut the power cable or attempt to modify it, and never stretch it or bend it forcefully. Never place a heavy
 object on the power cable. Damaged sections of the power cable could cause a short circuit and may cause a fire
 or electrical shock.
 - Never connect the power cable to a power strip or any power source shared by other electrical devices. This could
 cause a fire or electrical shock.
 - Never knot the power cable or wrap it around itself. This could cause a fire or electrical shock.
 - Periodically disconnect the power cable and use a dry cloth to wipe away dust that has collected on the plug and
 the area around the power outlet. Leaving the power cable plugged in and not cleaned for a long period, especially in an area subject to dust, oil, and humidity, could cause the insulation material to deteriorate and lead to a fire.



- Always grip the plug to remove the power cable from the power outlet. Pulling on the power cable could damage
 the cable and lead to a fire or electrical shock.
- Never use an extension cord. This could cause a fire or electrical shock.
- Never use any power source other than 100–120 / 220–240 V AC. This could cause a fire or electrical shock. The
 printer operating conditions are described below. Use the printer under the following conditions.
 Power supply voltage: 100–120 / 220–240 V AC

Power supply frequency: 50/60 Hz

Appendix

In an Emergency



If the printer emits smoke or strange odors, continuing to use the printer may cause a fire or electrical shock.
 Switch the printer off immediately and remove the power plug from the power outlet. Contact your Canon dealer or support center.

Cleaning the Printer



For cleaning, use a cloth dampened in water. Never use flammable solvents such as alcohol, benzene, or thinner.
 If these substances come into contact with electrical components inside the printer, there is a risk of fire or electrical shock.



Always disconnect the power cable from the outlet before cleaning the printer. If the printer is switched on accidentally, moving parts inside the printer may cause personal injuries.

Pacemakers



• This printer generates a low-level magnetic field. Anyone wearing a pacemaker who experiences discomfort while working around the printer should leave the area. Consult a physician before continuing to work around the printer.

Moving the Printer



- Moving the printer requires at least three people, holding it on both sides and from behind. Be careful to avoid back strain and other injuries.
- When moving the printer, firmly grasp the Carrying Handles under each side and in back. The printer may be unsteady if you hold it at other positions, which poses a risk of injury from dropping the printer.

Printhead, Ink Tanks, and Maintenance Cartridge




- Always store consumables in a safe location out of the reach of small children. If a child licks or ingests ink accidentally, seek medical assistance immediately.
- If ink accidentally gets in your eyes, immediately rinse with water.
 If ink gets on your skin, immediately clean it off with soap and water.
 If irritation persists in your eyes or on your skin, contact a physician immediately.
- Avoid dropping or shaking printheads, ink tanks, and maintenance cartridges. Spilled ink can stain clothing and the work area.
- Never touch the electrical contacts of the Printhead after printing. The contacts become extremely hot and can cause minor burns.

Legal Notices iPF685

Other



- Never disassemble the printer or attempt repairs. There are high voltage parts inside the printer that can cause a fire or electrical shock.
- Never use flammable sprays around the printer. The gas of flammable sprays can cause a fire or electrical shock, if it contacts high voltage points inside the printer.
- Never touch the cutting edge of Cutter Unit (a). This could cause personal injury.





- Never insert your hand into the printer while it is printing. Moving parts inside the printer can cause injuries.
- Never place anything on the printer such as small metal objects (paper clips, staples), liquids, any type of liquid container that contains flammable liquids (alcohol, benzene, etc.). If such objects fall into the printer, this could cause a fire or electrical shock.
- To prevent a fire hazard or dangerous electric shock, if a foreign object falls into or a liquid spills into the printer, press the Power button immediately to switch the printer off, unplug the printer power cable from the outlet, and then contact your Canon dealer or support center. If you continue to use the printer, this could cause a fire or electrical shock.



- Connect the interface cable correctly. To avoid damage, before connection make sure that the shape of the cable connector matches the connection point on the printer.
- During printing, turn on the ventilation system in the room.
- We recommend ensuring ample space for installation.

Legal Notices

FCC Regulations (U.S.A)

Canon Large Format Printer

iPF685

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Safety Precautions

629

Legal Notices iPF685 Use of shielded cable is required to comply with Class B limits in Subpart B of Part 15 of FCC Rules.

Do not make any changes or modifications to the equipment unless otherwise specified in the manual. If such changes or modifications should be made, you could be required to stop operation of the equipment. Canon U.S.A. Inc.

One Canon Park Melville, NY 11747, U.S.A.

Tel No. 1-800-652-2666

For CA, USA Only

Included battery contains Perchlorate Material - special handling may apply. See http://www.dtsc.ca.gov/hazardouswaste/perchlorate/ for detail.

Trademarks

- Canon, the Canon logo, and imagePROGRAF are trademarks or registered trademarks of CANON INC.
- Microsoft is a registered trademark of Microsoft Corporation.
- Windows is a trademark or registered trademark of Microsoft Corporation in the U.S. and/or other countries.
- Windows Vista is a trademark or registered trademark of Microsoft Corporation in the U.S. and/or other countries.
- Excel, Internet Explorer and PowerPoint are registered trademarks or trademarks of Microsoft Corporation in the U.S. and/or other countries.
- · Mac, Mac OS, Bonjour, Safari and OS X are trademarks of Apple Inc., registered in the U.S. and other coun-
- Adobe RGB, a trademark of Adobe Systems Incorporated, is color space proposed by Adobe Systems Incorporated.

Copyright

Unauthorized reproduction of this user manual in whole or part is prohibited.

Legal Notice

- It is illegal to reproduce currency, bills, negotiable securities and other documents prohibited by law. Reproduction of such items may be subject to criminal prosecution.
- It is illegal to reproduce legal certificates, licenses, travel tickets, and certain public and private documents prohibited from reproduction by law. Reproduction of such items may be subject to criminal prosecution.
- Please note that intellectual property protected by copyright may not be reproduced without the express permission of the copyright holder except for personal or household use under limited circumstances.


Manuals for this printer

Manuals for this printer	630
About This User Manual	630

Manuals for this printer

This printer has the following manuals.

Name	Contents	Medium	
Setup Guide	Instructions for unpacking and setting up the printer, and for installing the software and electronic manuals.	for in- Printed Manuals	
Quick Guide	Contains information such as a guide to exchanging paper, Ink Tank, and Printhead, and cautions for using the product safely.		
Basic Guide	Descriptions of basic printer operations.	Electronic manuals	
User's Guide	Detailed instructions for using the printer.		
Paper Reference Guide	This guide describes about the types and specifications of the available media on the printer.		



About This User Manual

Symbols

The following symbols are used in this user manual to indicate safety information and explanations on restrictions or precautions in use.

	Warning	Indicates warning items for which operating error poses a risk of death or serious injury. To ensure safe use, always follow these warnings.
	Caution	Indicates caution items for which operating error poses a risk of injury. To ensure safe use, always follow these cautions.
	Important	Indicates important information and restrictions that definitely are to be followed during operation. Be sure to read this information to prevent troubles, malfunctions, or damage to equipment or property by operating errors.
	Note	Indicates helpful reference information and supplemental information on particular topics.

Button names and user interface elements

Key and button names on the control panel and user interface elements in software (such as menus and buttons) are indicated as follows in this user manual.

Control panel buttons	Example: Press the OK button.
Control panel messages	Example: Head Cleaning is displayed.
Software interface items (menus and buttons)	Example: Click OK .
Keyboard keys	Example: Press the Tab key.

• Cross-reference

Other pages or manuals that provide related information are indicated as follows in this user manual.

Cross-reference in the same user manual	Example: see "Menu Structure." →P.412 Click the link to jump to the corresponding page.
Cross-reference in related manuals	Example: Refer to the Paper Reference Guide.
Other cross-reference	Example: See the printer driver help.

• Figures and software screens

- Figures in this user manual may be different from the actual appearance of the printer in some cases.
- Screens depicted in this user manual for the printer driver or other software may be different from the actual screens because of subsequent updates.

· May we request

- The information in this user manual is subject to change without notice.
- We strive to ensure accuracy of information in this user manual, but if you notice errors or omissions, contact support center.

WEEE Directive iPF685

Disposal of the product

WEEE Directive





Only for European Union and EEA (Norway, Iceland and Liechtenstein)

These symbols indicate that this product is not to be disposed of with your household waste, according to the WEEE Directive (2012/19/EU), the Battery Directive (2006/66/EC) and/or national legislation implementing those Directives.

If a chemical symbol is printed beneath the symbol shown above, in accordance with the Battery Directive, this indicates that a heavy metal (Hg = Mercury, Cd = Cadmium, Pb = Lead) is present in this battery or accumulator at a concentration above an applicable threshold specified in the Battery Directive.

This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (EEE) and batteries and accumulators. Improper handling of this type of waste could have a possible impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. Your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources.

For more information about the recycling of this product, please contact your local city office, waste authority, approved scheme or your household waste disposal service or visit

www.canon-europe.com/weee , or

www.canon-europe.com/battery .

Nur für Europäische Union und EWR (Norwegen, Island und Liechtenstein)

Diese Symbole weisen darauf hin, dass dieses Produkt gemäß WEEE-Richtlinie (2012/19/EU; Richtlinie über Elektro- und Elektronik-Altgeräte), Batterien-Richtlinie (2006/66/EG) und nationalen Gesetzen zur Umsetzung dieser Richtlinien nicht über den Hausmüll entsorgt werden darf.

Falls sich unter dem oben abgebildeten Symbol ein chemisches Symbol befindet, bedeutet dies gemäß der Batterien-Richtlinie, dass in dieser Batterie oder diesem Akkumulator ein Schwermetall (Hg = Quecksilber, Cd = Cadmium, Pb = Blei) in einer Konzentration vorhanden ist, die über einem in der Batterien-Richtlinie angegebenen Grenzwert liegt.

Dieses Produkt muss bei einer dafür vorgesehenen Sammelstelle abgegeben werden. Dies kann z. B. durch Rückgabe beim Kauf eines neuen ähnlichen Produkts oder durch Abgabe bei einer autorisierten Sammelstelle für die Wiederaufbereitung von Elektro- und Elektronik-Altgeräten sowie Batterien und Akkumulatoren geschehen. Der unsachgemäße Umgang mit Altgeräten kann aufgrund potenziell gefährlicher Stoffe, die generell mit Elektro- und Elektronik-Altgeräten in Verbindung stehen, negative Auswirkungen auf die Umwelt und die menschliche Gesundheit haben.

Durch Ihre Mitarbeit bei der umweltgerechten Entsorgung dieses Produkts tragen Sie zu einer effektiven Nutzung natürlicher Ressourcen bei.

Um weitere Informationen über die Wiederverwertung dieses Produkts zu erhalten, wenden Sie sich an Ihre Stadtverwaltung, den öffentlich-rechtlichen Entsorgungsträger, eine autorisierte Stelle für die Entsorgung von Elektround Elektronik-Altgeräten oder Ihr örtliches Entsorgungsunternehmen oder besuchen Sie

→ www.canon-europe.com/weee , oder → www.canon-europe.com/battery .

Union Européenne, Norvège, Islande et Liechtenstein uniquement.

Ces symboles indiquent que ce produit ne doit pas être mis au rebut avec les ordures ménagères, comme le spécifient la Directive européenne DEEE (2012/19/UE), la Directive européenne relative à l'élimination des piles et des accumulateurs usagés (2006/66/CE) et les lois en vigueur dans votre pays appliquant ces directives. Si un symbole de toxicité chimique est imprimé sous le symbole illustré ci-dessus conformément à la Directive rela-

tive aux piles et aux accumulateurs, il indique la présence d'un métal lourd (Hg = mercure, Cd = cadmium, Pb = plomb) dans la pile ou l'accumulateur à une concentration supérieure au seuil applicable spécifié par la Directive.

WEEE Directive

Disposal of the product

Ce produit doit être confié au distributeur à chaque fois que vous achetez un produit neuf similaire, ou à un point de collecte mis en place par les collectivités locales pour le recyclage des Déchets des Équipements Électriques et Électroniques (DEEE). Le traitement inapproprié de ce type de déchet risque d'avoir des répercussions sur l'environnement et la santé humaine, du fait de la présence de substances potentiellement dangereuses généralement associées aux équipements électriques et électroniques.

Votre entière coopération dans le cadre de la mise au rebut correcte de ce produit favorisera une meilleure utilisation des ressources naturelles.

Pour plus d'informations sur le recyclage de ce produit, contactez vos services municipaux, votre éco-organisme ou les autorités locales compétentes, ou consultez le site > www.canon-europe.com/weee . ou → www.canon-europe.com/battery

Uitsluitend bestemd voor de Europese Unie en EER (Noorwegen, IJsland en Liechtenstein)

Met deze symbolen wordt aangegeven dat dit product in overeenstemming met de AEEA-richtlijn (2012/19/EU), de richtlijn 2006/66/EG betreffende batterijen en accu's en/of de plaatselijk geldende wetgeving waarin deze richtlijnen zijn geïmplementeerd, niet bij het normale huisvuil mag worden weggegooid.

Indien onder het hierboven getoonde symbool een chemisch symbool gedrukt staat, geeft dit in overeenstemming met de richtlijn betreffende batterijen en accu's aan dat deze batterij of accu een zwaar metaal bevat (Hg = kwik, Cd = cadmium, Pb = lood) waarvan de concentratie de toepasselijke drempelwaarde in overeenstemming met de genoemde richtlijn overschrijdt.

Dit product dient te worden ingeleverd bij een hiervoor aangewezen inzamelpunt, bijv. door dit in te leveren bij een hiertoe erkend verkooppunt bij aankoop van een gelijksoortig product, of bij een officiële inzameldienst voor de recycling van elektrische en elektronische apparatuur (EEA) en batterijen en accu's. Door de potentieel gevaarlijke stoffen die gewoonlijk gepaard gaan met EEA, kan onjuiste verwerking van dit type afval mogelijk nadelige gevolgen hebben voor het milieu en de menselijke gezondheid. Uw medewerking bij het op juiste wijze weggooien van dit product draagt bij tot effectief gebruik van natuurlijke hulpbronnen.

Voor verdere informatie over recycling van dit product kunt u contact opnemen met uw plaatselijke gemeente, afvaldienst, officiële dienst voor klein chemisch afval of afvalstortplaats, of kunt u terecht op

→ www.canon-europe.com/weee , of → www.canon-europe.com/battery .

Sólo para la Unión Europea y el Área Económica Europea (Noruega, Islandia y Liechtenstein)

Estos iconos indican que este producto no debe desecharse con los residuos domésticos de acuerdo con la Directiva sobre RAEE (2012/19/UE) y la Directiva sobre Pilas y Acumuladores (2006/66/CE) y/o la legislación nacional. Si aparece un símbolo químico bajo este icono, de acuerdo con la Directiva sobre Pilas y Acumuladores, significa que la pila o el acumulador contiene metales pesados (Hg = Mercurio, Cd = Cadmio, Pb = Plomo) en una concentración superior al límite especificado en dicha directiva.

Este producto deberá entregarse en un punto de recogida designado, por ejemplo, entregándolo en el lugar de venta al adquirir un producto nuevo similar o en un centro autorizado para la recogida de residuos de aparatos eléctricos y electrónicos (RAEE), baterías y acumuladores. La gestión incorrecta de este tipo de residuos puede afectar al medio ambiente y a la salud humana debido a las sustancias potencialmente nocivas que suelen contener estos aparatos.

Su cooperación en la correcta eliminación de este producto contribuirá al correcto aprovechamiento de los recursos naturales.

Los usuarios tienen derecho a devolver pilas, acumuladores o baterías usados sin coste alguno. El precio de venta de pilas, acumuladores y baterías incluye el coste de la gestión medioambiental de su desecho, y no es necesario mostrar la cuantía de dicho coste en la información y la factura suministradas a los usuarios finales.

Si desea más información sobre el reciclado de este producto, póngase en contacto con su municipio, el servicio o el organismo encargado de la gestión de residuos domésticos o visite > www.canon-europe.com/weee , o → www.canon-europe.com/battery

Solo per Unione Europea e SEE (Norvegia, Islanda e Liechtenstein)

Questi simboli indicano che il prodotto non può essere smaltito con i rifiuti domestici, ai sensi della Direttiva RAEE (2012/19/UE), della Direttiva sulle Batterie (2006/66/CE) e/o delle leggi nazionali che attuano tali Direttive. Se sotto il simbolo indicato sopra è riportato un simbolo chimico, in osservanza della Direttiva sulle batterie, tale simbolo indica la presenza di un metallo pesante (Hg = Mercurio, Cd = Cadmio, Pb = Piombo) nella batteria o nell'accumulatore con un livello di concentrazione superiore a una soglia applicabile specificata nella Direttiva sulle batterie.

634

WEEE Directive iPF685

Il prodotto deve essere conferito a un punto di raccolta designato, ad esempio il rivenditore in caso di acquisto di un nuovo prodotto simile oppure un centro di raccolta autorizzato per il riciclaggio di rifiuti di apparecchiature elettriche ed elettroniche (RAEE) nonché di batterie e accumulatori. Un trattamento improprio di questo tipo di rifiuti può avere conseguenze negative sull'ambiente e sulla salute umana a causa delle sostanze potenzialmente nocive solitamente contenute in tali rifiuti.

La collaborazione dell'utente per il corretto smaltimento di questo prodotto contribuirà a un utilizzo efficace delle risorse naturali ed eviterà di incorrere in sanzioni amministrative ai sensi dell'art. 255 e successivi del Decreto Legislativo n. 152/06.

Per ulteriori informazioni sul riciclaggio di questo prodotto, contattare le autorità locali, l'ente responsabile della raccolta dei rifiuti, un rivenditore autorizzato o il servizio di raccolta dei rifiuti domestici, oppure visitare il sito

www.canon-europe.com/weee

Apenas para a União Europeia e AEE (Noruega, Islândia e Liechtenstein)

Estes símbolos indicam que este produto não deve ser eliminado juntamente com o seu lixo doméstico, segundo a Diretiva REEE de 2012/19/UE, a Diretiva de Baterias (2006/66/CE) e/ou a sua legislação nacional que transponha estas Diretivas.

Se houver um símbolo químico impresso como mostrado abaixo, de acordo com a Diretiva de Baterias, isto indica que um metal pesado (Hg = Mercúrio, Cd = Cádmio, Pb = Chumbo) está presente nesta pilha ou acumulador, numa concentração acima de um limite aplicável especificado na Diretiva.

Este produto deve ser entregue num ponto de recolha designado, por exemplo num local autorizado de troca quando compra um equipamento novo idêntico, ou num local de recolha autorizado para reciclar equipamento elétrico e eletrónico (EEE) em fim de vida, bem como pilhas e baterias. O tratamento inadequado deste tipo de resíduos pode ter um impacto negativo no ambiente e na saúde humana, devido a substâncias potencialmente perigosas que estão associadas com equipamentos do tipo EEE.

A sua cooperação no tratamento correto deste produto irá contribuir para a utilização mais eficaz dos recursos naturais.

Para obter mais informações acerca de como reciclar este produto, por favor contacte as suas autoridades locais responsáveis pela matéria, serviço de recolha aprovado para pilhas e baterias ou serviço de recolha de resíduos sólidos domésticos da sua municipalidade, ou visite

www.canon-europe.com/weee , ou

www.canon-europe.com/battery

Gælder kun i Europæiske Union og EØS (Norge, Island og Liechtenstein)

Disse symboler betyder, at produktet ikke må bortskaffes sammen med dagrenovation i henhold til WEEE-direktivet (2012/19/EU), batteridirektivet (2006/66/EF) og/eller den lokale lovgivning, som disse direktiver er gennemført i. Hvis der i overensstemmelse med batteridirektivet er trykt et kemisk symbol under det symbol, der er vist ovenfor, betyder det, at batteriet eller akkumulatoren indeholder tungmetaller (Hg = kviksølv, Cd = cadmium, Pb = bly) i en koncentration, som ligger over de grænseværdier, der er beskrevet i batteridirektivet.

Produktet skal afleveres på et godkendt indsamlingssted, f.eks. i overensstemmelse med en godkendt én-til-én-procedure, når du indkøber et nyt tilsvarende produkt, eller på et godkendt indsamlingssted for elektronikaffald samt for batterier og akkumulatorer. Forkert håndtering af denne type affald kan medføre negative konsekvenser for miljøet og menneskers helbred på grund af de potentielt sundhedsskadelige stoffer, der generelt kan forefindes i elektrisk og elektronisk udstyr.

Når du foretager korrekt bortskaffelse af produktet, bidrager du til effektiv brug af naturressourcerne. Kontakt din kommune, den lokale affaldsmyndighed, det lokale affaldsanlæg, eller besøg → www.canon-europe.com/weee , eller → www.canon-europe.com/battery for at få flere oplysninger om genbrug af dette produkt.

Μόνο για την Ευρωπαϊκή Ένωση και τον ΕΟΧ (Νορβηγία, Ισλανδία και Λιχτενστάιν)

Αυτά τα σύμβολα υποδεικνύουν ότι αυτό το προϊόν δεν πρέπει να απορρίπτεται μαζί με τα οικιακά απορρίμματα, σύμφωνα με την Οδηγία για τα Απόβλητα Ηλεκτρικού και Ηλεκτρονικού Εξοπλισμού (ΑΗΗΕ) (2012/19/ΕΕ), την Οδηγία για τις Ηλεκτρικές Στήλες (2006/66/ΕΚ) ή/και την εθνική νομοθεσία που εφαρμόζει τις Οδηγίες εκείνες. Εάν κάποιο χημικό σύμβολο είναι τυπωμένο κάτω από το σύμβολο που φαίνεται παραπάνω, σύμφωνα με την Οδηγία για τις Ηλεκτρικές Στήλες, υποδηλώνει ότι κάποιο βαρύ μέταλλο (Hg = Υδράργυρος, Cd = Κάδμιο, Pb = Μόλυβδος) υπάρχει στην μπαταρία ή τον συσσωρευτή σε συγκέντρωση μεγαλύτερη από το ισχύον επίπεδο που καθορίζεται στην Οδηγία για τις Ηλεκτρικές Στήλες.

Αυτό το προϊόν πρέπει να παραδίδεται σε καθορισμένο σημείο συλλογής, π.χ. σε μια εξουσιοδοτημένη βάση ανταλλαγής όταν αγοράζετε ένα νέο παρόμοιο προϊόν ή σε μια εξουσιοδοτημένη θέση συλλογής για την ανακύκλωση των αποβλήτων ηλεκτρικού και ηλεκτρονικού εξοπλισμού (ΗΗΕ) και των ηλεκτρικών στηλών και συσσωρευτών. Ο ακατάλληλος χειρισμός αυτού του τύπου αποβλήτων μπορεί να έχει αρνητικό αντίκτυπο στο περιβάλλον και την υγεία του ανθρώπου, λόγω δυνητικά επικίνδυνων ουσιών που γενικά συνδέονται με τον ΗΗΕ.

iPF685 WEEE Directive

Η συνεργασία σας για τη σωστή απόρριψη αυτού του προϊόντος θα συμβάλει στην αποτελεσματική χρήση των φυσικών πόρων.

Για περισσότερες πληροφορίες σχετικά με ανακύκλωση αυτού του προϊόντος, επικοινωνήστε με το τοπικό γραφείο της πόλης σας, την υπηρεσία απορριμμάτων, το εγκεκριμένο σχήμα ή την υπηρεσία απόρριψης οικιακών αποβλήτων ή επισκεφθείτε τη διεύθυνση → www.canon-europe.com/weee ή → www.canon-europe.com/battery.

Gjelder kun den europeiske union og EØS (Norge, Island og Liechtenstein)

Disse symbolene indikerer at dette produktet ikke skal kastes sammen med husholdningsavfall, i henhold til WEEE-direktivet (2012/19/EU), batteridirektivet (2006/66/EF) og/eller nasjonal lov som har implementert disse direktivene.

Hvis et kjemisk symbol vises under symbolet vist ovenfor, i samsvar med batteridirektivet, indikerer dette at et tungmetall (Hg = kvikksølv, Cd = kadmium, Pb = bly) finnes i batteriet eller akkumulatoren i en konsentrasjon over en gjeldende øvre grense som er spesifisert i batteridirektivet.

Produktet må leveres til et dertil egnet innsamlingspunkt, det vil si på en autorisert en-til-en-basis når en kjøper et nytt lignende produkt, eller til et autorisert innsamlingssted for resirkulering av avfall fra elektrisk og elektronisk utstyr (EE-utstyr) og batterier og akkumulatorer. Feil håndtering av denne typen avfall kan være miljø- og helseskadelig på grunn av potensielt skadelige stoffer som ofte brukes i EE-utstyr.

Din innsats for korrekt avhending av produktet vil bidra til effektiv bruk av naturressurser.

Du kan få mer informasjon om resirkulering av dette produktet ved å kontakte lokale myndigheter, avfallsadministrasjonen, et godkjent program eller husholdningens renovasjonsselskap, eller gå til

→ www.canon-europe.com/weee , eller → www.canon-europe.com/battery .

Vain Euroopan unionin sekä ETA:n (Norja, Islanti ja Liechtenstein) alueelle.

Nämä tunnukset osoittavat, että sähkö- ja elektroniikkalaiteromua koskeva direktiivi (SER-direktiivi, 2012/19/EU), paristoista ja akuista annettu direktiivi (2006/66/EY) sekä kansallinen lainsäädäntö kieltävät tuotteen hävittämisen talousjätteen mukana.

Jos yllä olevan symbolin alapuolelle on paristodirektiivin mukaisesti painettu kemiallisen aineen tunnus, kyseinen paristo tai akku sisältää raskasmetalleja (Hg = elohopea, Cd = kadmium, Pb = lyijy) enemmän kuin paristodirektiivin salliman määrän.

Tuote on vietävä asianmukaiseen keräyspisteeseen, esimerkiksi kodinkoneliikkeeseen uutta vastaavaa tuotetta ostettaessa tai viralliseen sähkö- ja elektroniikkalaiteromun tai paristojen ja akkujen keräyspisteeseen. Sähkö- ja elektroniikkalaiteromun virheellinen käsittely voi vahingoittaa ympäristöä ja ihmisten terveyttä, koska laitteet saattavat sisältää ympäristölle ja terveydelle haitallisia aineita. Tuotteen asianmukainen hävittäminen säästää myös luonnonvaroia.

Jos haluat lisätietoja tämän tuotteen kierrätyksestä, ota yhteys kunnan jätehuoltoviranomaisiin tai käyttämääsi jätehuoltoyhtiöön tai käy osoitteessa → www.canon-europe.com/weee , tai → www.canon-europe.com/battery .

Endast för Europeiska unionen och EES (Norge, Island och Liechtenstein)

De här symbolerna visar att produkten inte får sorteras och slängas som hushållsavfall enligt WEEE-direktivet (2012/19/EU), batteridirektivet (2006/66/EG) och/eller nationell lagstiftning som implementerar dessa direktiv. Om en kemisk symbol förekommer under ovanstående symbol innebär detta enligt Batteridirektivet att en tungmetall (Hg = Kvicksilver, Cd = Kadmium, Pb = Bly) förekommer i batteriet eller ackumulatorn med en koncentration som överstiger tillämplig gräns som anges i Batteridirektivet.

Produkten ska lämnas in på en avsedd insamlingsplats, t.ex. på en återvinningsstation auktoriserad att hantera elektrisk och elektronisk utrustning (EE-utrustning) samt batterier och ackumulatorer eller hos handlare som är auktoriserade att byta in varor då nya, motsvarande köps (en mot en). Olämplig hantering av avfall av den här typen kan ha negativ inverkan på miljön och människors hälsa på grund av de potentiellt farliga ämnen som kan återfinnas i elektrisk och elektronisk utrustning.

Din medverkan till en korrekt avfallshantering av produkten bidrar till effektiv användning av naturresurserna. Om du vill ha mer information om var du kan lämna in den här produkten, kontakta ditt lokala kommunkontor, berörd myndighet eller företag för avfallshantering eller se

www.canon-europe.com/weee , eller

www.canon-europe.com/battery .

Pouze Evropská unie a EHP (Norsko, Island a Lichtenštejnsko)

Tento symbol znamená, že podle směrnice OEEZ (2012/19/EU), směrnice o bateriích (2006/66/ES) a/nebo podle vnitrostátních právních prováděcích předpisů k těmto směrnicím nemá být tento výrobek likvidován s odpadem z domácností.

WEEE Directive iPF685

Je-li v souladu s požadavky směrnice o bateriích vytištěna pod výše uvedeným symbolem chemická značka, udává, že tato baterie nebo akumulátor obsahuje těžké kovy (Hg = rtuť, Cd = kadmium, Pb = olovo) v koncentraci vyšší, než je příslušná hodnota předepsaná směrnicí.

Tento výrobek má být vrácen do určeného sběrného místa, např. v rámci autorizovaného systému odběru jednoho výrobku za jeden nově prodaný podobný výrobek, nebo do autorizovaného sběrného místa pro recyklaci odpadních elektrických a elektronických zařízení (OEEZ), baterií a akumulátorů. Nevhodné nakládání s tímto druhem odpadu by mohlo mít negativní dopad na životní prostředí a lidské zdraví, protože elektrická a elektronická zařízení zpravidla obsahují potenciálně nebezpečné látky. Vaše spolupráce na správné likvidaci tohoto výrobku napomůže efektivnímu využívání přírodních zdrojů.

Chcete-li získat podrobné informace týkající se recyklace tohoto výrobku, obraťte se prosím na místní úřad, orgán pro nakládání s odpady, schválený systém nakládání s odpady či společnost zajišťující likvidaci domovního odpadu, nebo navštivte webové stránky www.canon-europe.com/weee nebo www.canon-europe.com/battery

Csak az Európai Unió és az EGT (Norvégia, Izland és Liechtenstein) országaiban

Ezek a szimbólumok azt jelzik, hogy a termék hulladékkezelése a háztartási hulladéktól különválasztva, az elektromos és elektronikus berendezések hulladékairól (WEEE) szóló (2012/19/EU) irányelvnek és az elemekről és akkumulátorokról, valamint a hulladék elemekről és akkumulátorokról szóló (2006/66/EK) irányelvnek megfelelően és/vagy ezen irányelveknek megfelelő helyi előírások szerint történik.

Amennyiben a fent feltüntetett szimbólum alatt egy vegyjel is szerepel, az elemekről és akkumulátorokról szóló irányelvben foglaltak értelmében ez azt jelzi, hogy az elem vagy az akkumulátor az irányelvben meghatározott határértéknél nagyobb mennyiségben tartalmaz nehézfémet (Hg = higany, Cd = kadmium, Pb = ólom).

E terméket az arra kijelölt gyűjtőhelyre kell juttatni – pl. hasonló termék vásárlásakor a régi becserélésére vonatkozó hivatalos program keretében, vagy az elektromos és elektronikus berendezések (EEE) hulladékainak gyűjtésére, valamint a hulladék elemek és hulladék akkumulátorok gyűjtésére kijelölt hivatalos gyűjtőhelyre. Az ilyen jellegű hulladékok nem előírásszerű kezelése az elektromos és elektronikus berendezésekhez (EEE) általánosan kapcsolható potenciálisan veszélyes anyagok révén hatással lehet a környezetre és az egészségre.

E termék megfelelő leselejtezésével Ön is hozzájárul a természeti források hatékony használatához.

A termék újrahasznosítását illetően informálódjon a helyi polgármesteri hivatalnál, a helyi közterület-fenntartó vállalatnál, a hivatalos hulladéklerakó telephelyen vagy a háztartási hulladék begyűjtését végző szolgáltatónál, illetve látogasson el a

www.canon-europe.com/weee , vagy

www.canon-europe.com/battery internetes oldalra.

Tylko dla krajów Unii Europejskiej oraz EOG (Norwegia, Islandia i Liechtenstein)

Te symbole oznaczają, że produktu nie należy wyrzucać razem z odpadami gospodarstwa domowego, zgodnie z dyrektywą WEEE w sprawie zużytego sprzętu elektrycznego i elektronicznego (2012/19/UE) lub dyrektywą w sprawie baterii (2006/66/WE) bądź przepisami krajowymi wdrażającymi te dyrektywy.

Jeśli pod powyższym symbolem znajduje się symbol chemiczny, zgodnie z dyrektywą w sprawie baterii oznacza to, że bateria lub akumulator zawiera metal ciężki (Hg = rtęć, Cd = kadm, Pb = ołów) w stężeniu przekraczającym odpowiedni poziom określony w dyrektywie w sprawie baterii.

Użytkownicy baterii i akumulatorów mają obowiązek korzystać z dostępnego programu zwrotu, recyklingu i utylizacji baterii oraz akumulatorów.

Niewłaściwe postępowanie z tego typu odpadami może mieć wpływ na środowisko i zdrowie ludzi ze względu na substancje potencjalnie niebezpieczne, związane ze zużytym sprzętem elektrycznym i elektronicznym.

Państwa współpraca w zakresie właściwej utylizacji tego produktu przyczyni się do efektywnego wykorzystania zasobów naturalnych.

W celu uzyskania informacji o sposobie recyklingu tego produktu prosimy o kontakt z właściwym urzędem miejskim lub zakładem gospodarki komunalnej bądź zapraszamy na stronę www.canon-europe.com/weee , lub www.canon-europe.com/battery .

Platí len pre štáty Európskej únie a EHP (Nórsko, Island a Lichtenštajnsko)

Tieto symboly označujú, že podľa Smernice o odpade z elektrických a elektronických zariadení (OEEZ) 2012/19/EÚ, Smernice o batériách (2006/66/ES) a podľa platnej legislatívy Slovenskej republiky sa tento produkt nesmie likvidovať spolu s komunálnym odpadom.

Ak je chemická značka vytlačená pod vyššie uvedeným symbolom, znamená to, že táto batéria alebo akumulátor obsahuje ťažký kov (Hg = ortuť, Cd = kadmium, Pb = olovo) v koncentrácii vyššej, ako je príslušná povolená hodnota stanovená v Smernici o batériách.

Produkt je potrebné odovzdať do určenej zberne, napr. prostredníctvom výmeny za kúpu nového podobného produktu, alebo na autorizované zberné miesto, ktoré spracúva odpad z elektrických a elektronických zariadení (EEZ), batérií a akumulátorov. Nesprávna manipulácia s takýmto typom odpadu môže mať negatívny vplyv na životné prostredie a ľudské zdravie, pretože elektrické a elektronické zariadenia obsahujú potenciálne nebezpečné látky.

637

iPF685 WEEE Directive

Spoluprácou na správnej likvidácii tohto produktu prispejete k účinnému využívaniu prírodných zdrojov. Ďalšie informácie o recyklácii tohto produktu získate od miestneho úradu, úradu životného prostredia, zo schváleného plánu OEEZ alebo od spoločnosti, ktorá zaisťuje likvidáciu komunálneho odpadu. Viac informácií nájdete aj na webovej stránke: → www.canon-europe.com/weee , alebo → www.canon-europe.com/battery .

Üksnes Euroopa Liit ja EMP (Norra, Island ja Liechtenstein)

Antud sümbolid viitavad sellele, et vastavalt elektri- ja elektroonikaseadmete jäätmeid käsitlevale direktiivile (2012/19/EL), patareisid ja akusid ning patarei- ja akujäätmeid käsitlevale direktiivile (2006/66/EÜ) ja/või nimetatud direktiive rakendavatele riiklikele õigusaktidele ei või seda toodet koos olmejäätmetega ära visata.

Kui keemiline sümbol on trükitud eespool toodud sümboli alla, siis tähendab see, et antud patareis või akus leiduva raskemetalli (Hg = elavhõbe, Cd = kaadmium, Pb = plii) kontsentratsioonitase on kõrgem kui patareisid ja akusid ning patarei- ja akujäätmeid käsitlevas direktiivis sätestatud piirmäär.

Antud tootest tekkinud jäätmed tuleb anda vastavasse kogumispunkti, nt müügipunkti, mis on volitatud üks ühe vastu vahetama, kui ostate uue sarnase toote, või vastavasse elektri- ja lektroonikaseadmete jäätmete ning patareide ja akude ümbertöötlemiseks mõeldud kogumispunkti. Antud liiki jäätmete vale käitlemine võib kahjustada keskkonda ja inimeste tervist elektri- ja elektroonikajäätmetes tavaliselt leiduvate potentsiaalselt ohtlike ainete tõttu. Antud tootest tekkinud jäätmete nõuetekohase kõrvaldamisega aitate kasutada loodusvarasid efektiivselt. Täiendava teabe saamiseks elektri- ja elektroonikaseadmetest tekkinud jäätmete ning patarei- ja akujäätmete tagastamise ja ümbertöötlemise kohta võtke ühendust kohaliku omavalitsusega, asjakohase valitsusasutusega, asjakohase tootjavastutusorganisatsiooniga või olmejäätmete käitlejaga. Lisateavet leitate ka Interneti-leheküljelt → www.canon-europe.com/weee või → www.canon-europe.com/battery .

Tikai Eiropas Savienībai un EEZ (Norvēģijai, Islandei un Lihtenšteinai)

Šie simboli norāda, ka atbilstoši ES Direktīvai (2012/19/ES) par elektrisko un elektronisko iekārtu atkritumiem (EEIA), Direktīvai (2006/66/EK) par baterijām un akumulatoriem, un akumulatoru atkritumiem, ar ko atceļ Direktīvu 91/157/EEK, un vietējiem tiesību aktiem šo izstrādājumu nedrīkst izmest kopā ar sadzīves atkritumiem. Ja zem iepriekš norādītā simbola ir uzdrukāts ķīmiskais simbols, saskaņā ar direktīvu par baterijām un akumulatoriem tas nozīmē, ka šīs baterijas vai akumulatori satur smagos metālus (Hg = dzīvsudrabs, Cd = kadmijs, Pb = svins) un to koncentrācijas līmenis pārsniedz direktīvā par baterijām un akumulatoriem minēto piemērojamo slieks-

Šis izstrādājums ir jānodod piemērotā savākšanas vietā, piemēram, apstiprinātā veikalā, kur iegādājaties līdzīgu jaunu produktu un atstājat veco, vai apstiprinātā vietā izlietotu elektrisko un elektronisko iekārtu un bateriju un akumulatoru pārstrādei. Nepareiza šāda veida atkritumu apsaimniekošana var apdraudēt vidi un cilvēka veselību tādu iespējami bīstamu vielu dēļ, kas parasti ir elektriskajās un elektroniskajās iekārtās.

Jūsu atbalsts pareizā šāda veida atkritumu apsaimniekošanā sekmēs efektīvu dabas resursu izmantošanu. Lai saņemtu pilnīgāku informāciju par šāda veida izstrādājumu nodošanu otrreizējai pārstrādei, sazinieties ar vietējo pašvaldību, atkritumu savākšanas atbildīgo dienestu, pilnvaroto organizāciju vai iestādi, kas veic sadzīves atkritumu apsaimniekošanu, vai apmeklējiet tīmekļa vietni → www.canon-europe.com/weee , vai → www.canon-europe.com/battery

Tik Europos Sajungai ir EEE (Norvegijai, Islandijai ir Lichtenšteinui)

Šie simboliai reiškia, kad šio gaminio negalima išmesti į buitines atliekas, kaip reikalaujama WEEE Direktyvoje (2012/19/ES) ir Baterijų direktyvoje (2006/66/EB) ir (ar) jūsų šalies nacionaliniuose įstatymuose, kuriais šios Direktyvos yra jgyvendinamos.

Jeigu cheminio ženklo simbolis yra nurodytas žemiau šio ženklo, tai reiškia, kad vadovaujantis Baterijų direktyvą, baterijų ar akumuliatorių sudėtyje yra sunkiųjų metalų (Hg = gyvsidabrio, Cd = kadmio, Pb = švino), kurių koncentracija viršija Baterijų direktyvoje nurodytas leistinas ribas.

Šį gaminį reikia pristatyti į specialųjį surinkimo punkta, pavyzdžiui, mainais, kai jūs perkate naują panašų gaminį, arba i specialiaja surinkimo vieta, kurioje perdirbamos elektrinės ir elektroninės įrangos atliekos bei naudotos baterijos ir akumuliatoriai. Dėl netinkamo šio tipo atliekų tvarkymo gali nukentėti aplinka ir iškilti grėsmė žmogaus sveikatai dėl galimai kenksmingų medžiagų, iš esmės susijusių su elektrine ir elektronine įranga.

Bendradarbiaudami ir teisingai utilizuodami šiuos gaminius, jūs padėsite efektyviai naudoti gamtinius išteklius. Daugiau informacijos apie gaminio perdirbimą jums gali suteikti vietinis biuras, atliekų tvarkymo bendrovė, sertifikuoti organai ar buitinių atliekų surinkimo įmonės. Taip pat siūloma apsilankyti interneto svetainėje → www.canon-europe.com/weee , arba → www.canon-europe.com/battery .

Samo za Evropsko unijo in EGP (Norveška, Islandija in Lihtenštajn)

Ti simboli pomenijo, da tega izdelka skladno z Direktivo OEEO (2012/19/EU), Direktivo 2006/66/ES in/ali nacionalno zakonodajo, ki uvaja ti direktivi, ne smete odlagati z nesortiranimi gospodinjskimi odpadki.

WEEE Directive iPF685

Če je pod zgoraj prikazanim simbolom natisnjen kemijski simbol, to v skladu z Direktivo pomeni, da je v tej bateriji ali akumulatorju prisotna težka kovina (Hg = živo srebro, Cd = kadmij, Pb = svinec), in sicer v koncentraciji, ki je nad relevantno mejno vrednostjo, določeno v Direktivi.

Ta izdelek je potrebno odnesti na izbrano zbirno mesto, t. j. pooblaščeno trgovino, kjer ob nakupu novega (podobnega) izdelka vrnete starega, ali na pooblaščeno zbirno mesto za ponovno uporabo odpadne električne in elektronske opreme (EEO) ter baterij in akumulatorjev. Neustrezno ravnanje s to vrsto odpadkov lahko negativno vpliva na okolje in človeško zdravje zaradi potencialno nevarnih snovi, ki so pogosto povezane z EEO.

Vaše sodelovanje pri pravilnem odlaganju tega izdelka predstavlja pomemben prispevek k smotrni izrabi naravnih virov.

Za več informacij o ponovni uporabi tega izdelka se obrnite na lokalen mestni urad, pristojno službo za odpadke, predstavnika pooblaščenega programa za obdelavo odpadkov ali na lokalno komunalo. Lahko pa tudi obiščete našo spletno stran > www.canon-europe.com/weee , ali > www.canon-europe.com/battery .

Само за Европейския съюз и ЕИП (Норвегия, Исландия и Лихтенщайн)

Тези символи показват, че този продукт не трябва да се изхвърля заедно с битовите отпадъци съгласно Директивата за ИУЕЕО (2012/19/EC), Директивата за батерии (2006/66/EO) и/или Вашето национално законодателство, прилагащо тези Директиви.

Ако под показания горе символ е отпечатан символ за химически елемент, съгласно разпоредбите на Директивата за батерии, този втори символ означава наличието на тежък метал (Hg = живак, Cd = кадмий, Pb = олово) в батерията или акумулатора в концентрация над указаната граница за съответния елемент в Директивата.

Този продукт трябва да бъде предаден в предназначен за целта пункт за събиране, например на база размяна, когато купувате нов подобен продукт, или в одобрен събирателен пункт за рециклиране на излязло от употреба електрическо и електронно оборудване (ИУЕЕО), батерии и акумулатори. Неправилното третиране на този тип отпадъци може да доведе до евентуални отрицателни последствия за околната среда и човешкото здраве поради потенциално опасните вещества, които обикновено са свързани с ЕЕО. В същото време Вашето съдействие за правилното изхвърляне на този продукт ще допринесе за ефективното използване на природните ресурси.

За повече информация относно това къде можете да предадете за рециклиране на този продукт, моля свържете се с Вашите местни власти, с органа, отговорен за отпадъците, с одобрената система за ИУЕЕО или с Вашата местна служба за битови отпадъци, или посетете → www.canon-europe.com/weee , или → www.canon-europe.com/battery .

Doar pentru Uniunea Europeană și EEA (Norvegia, Islanda și Liechtenstein)

Aceste simboluri indică faptul că acest produs nu trebuie aruncat împreună cu deșeurile menajere, în conformitate cu Directiva DEEE (2012/19/UE), Directiva referitoare la baterii (2006/66/CE) şi/sau legile dvs. naţionale ce implementează aceste Directive.

Dacă un simbol chimic este imprimat sub simbolul de mai sus, în conformitate cu Directiva referitoare la baterii, acest simbol indică prezenţa în baterie sau acumulator a unui metal greu (Hg = Mercur, Cd = Cadmiu, Pb = Plumb) într-o concentraţie mai mare decât pragul admis specificat în Directiva referitoare la baterii.

Acest produs trebuie înmânat punctului de colectare adecvat, ex: printr-un schimb autorizat unu la unu atunci când cumpărați un produs nou similar sau la un loc de colectare autorizat pentru reciclarea reziduurilor de echipament electric și electronic (EEE) și baterii și acumulatori. Administrarea neadecvată a acestui tip de deșeuri, ar putea avea un impact asupra mediului și asupra sănătății umane datorită substanțelor cu potențial de risc care sunt în general asociate cu EEE.

Cooperarea dvs. în direcția reciclării corecte a acestui produs va contribui la o utilizare eficientă a resurselor naturale

Pentru mai multe informaţii despre reciclarea acestui produs, vă rugăm să contactaţi biroul dvs. local, autorităţile responsabile cu deşeurile, schema aprobată sau serviciul dvs. responsabil cu deşeurile menajere sau vizitaţi-ne la

www.canon-europe.com/weee , sau

www.canon-europe.com/battery .

Samo za Europsku uniju i EEA (Norveška, Island i Lihtenštajn)

Oznaka pokazuje da se ovaj proizvod ne smije odlagati s komunalnim i ostalim vrstama otpada, u skladu s direktivom WEEE (2012/19/EC), Direktivom o baterijama (2006/66/EC) i Pravilnikom o gospodarenju otpadnim baterijama i akumulatorima te Pravilnikom o gospodarenju otpadnim električnim i elektroničkim uređajima i opremom. Ako je ispod prethodno prikazane oznake otisnut kemijski simbol, u skladu s Direktivom o baterijama, to znači da se u ovoj bateriji ili akumulatoru nalazi teški metal (Hg = živa, Cd = kadmij, Pb = olovo) i da je njegova koncentracija iznad razine propisane u Direktivi o baterijama.

WFFF Directive Ovaj bi proizvod trebalo predati ovlašenom skupljaču EE otpada ili prodavatelju koji je dužan preuzeti otpadni

proizvod po sistemu jedan za jedan, ukoliko isti odgovara vrsti te je obavljao primarne funkcije kao i isporučena EE oprema. Otpadne baterije i akumulatori predaju se ovlaštenom skupljaču otpadnih baterija ili akumulatora ili prodavatelju bez naknade i obveze kupnje za krajnjeg korisnika. Neodgovarajuće rukovanje ovom vrstom otpada može utjecati na okoliš i ljudsko zdravlje zbog potencijalno opasnih supstanci koje se najčešće nalaze na takvim mjesti-

Vaša suradnja u pravilnom zbrinjavanju ovog proizvoda pridonijet će djelotvornom iskorištavanju prirodnih resursa. Dodatne informacije o recikliranju ovog proizvoda zatražite od svog lokalnog gradskog ureda, službe za zbrinjavanje otpada, odobrenog programa ili komunalne službe za uklanjanje otpada ili pak na stranicama

→ www.canon-europe.com/weee iii → www.canon-europe.com/battery .

Només per a la Unió Europea i a l'Espai Econòmic Europeu (Noruega, Islàndia i Liechtenstein)

Aquests símbols indican que aquest producte no s'ha de llençar amb les escombraries de la llar, d'acord amb la RAEE (2012/19/UE), la Directiva relativa a piles i acumuladors (2006/66/CE) i la legislació nacional que implementi aquestes directives.

Si al costat d'aquest símbol hi apareix imprès un símbol químic, segons especifica la Directiva relativa a piles i acumuladors, significa que la bateria o l'acumulador conté un metall pesant (Hg = mercuri, Cd = cadmi, Pb = plom) en una concentració superior al límit aplicable especificat en la Directiva.

Aquest producte s'hauria de lliurar en un dels punts de recollida designats, com per exemple, intercanviant un per un en comprar un producte similar o lliurant-lo en un lloc de recollida autoritzat per al reciclatge de residus d'aparells elèctrics i electrònics (RAEE) i piles i acumuladors. La manipulació inadequada d'aquest tipus de residus podria tenir un impacte negatiu en l'entorn i en la salut humana, a causa de les substàncies potencialment perilloses que normalment estan associades a l'RAEE.

La vostra cooperació a l'hora de rebutjar correctament aquest producte contribuirà a la utilització efectiva dels recursos naturals.

Els usuaris tenen dret a retornar les bateries o els acumuladors usats sense cap càrrec. El preu de venda de les bateries i els acumuladors inclou el cost de la gestió ambiental dels residus i no es necessari mostrar l'import d'aquest cost en aquest fullet o en la factura que es lliuri a l'usuari final.

Per a més informació sobre el reciclatge d'aquest producte, contacteu amb l'oficina municipal, les autoritats encarregades dels residus, el pla de residus homologat o el servei de recollida d'escombraries domèstiques de la vostra localitat o visiteu → www.canon-europe.com/weee , 0 → www.canon-europe.com/battery .

Korisnici u Srbiji

Ovaj simbol označava da ovaj proizvod ne sme da se odlaže sa ostalim kućnim otpadom, u skladu sa WEEE Direktivom (2012/19/EU), Direktivom o baterijama (2006/66/EC) i nacionalnim zakonima.

Ukoliko je ispod gore navedenog simbola odštampan hemijski simbol, u skladu sa Direktivom o baterijama, ovaj simbol označava da su u ovoj bateriji ili akumulatoru prisutni teški metali (Hg – živa, Cd – kadmijum, Pb - olovo) u koncentracijama koje premašuju prihvatljivi prag naveden u Direktivi o baterijama.

Ovaj proizvod treba predati određenom centru za prikupljanje, npr. po principu "jedan-za-jedan" kada kupujete sličan novi proizvod, ili ovlašćenom centru za prikupljanje za reciklažu istrošene električne i elektronske opreme (EEE), baterija i akumulatora. Nepravilno rukovanje ovom vrstom otpada može imati negativne posledice po životnu sredinu i ljudsko zdravlje usled potencijalno opasnih materijala koji se uglavnom vezuju za EEE.

Vaša saradnja na ispravnom odlaganju ovog proizvoda će doprineti efikasnom korišćenju prirodnih resursa. Više informacija o tome kako možete da reciklirate ovaj proizvod potražite od lokalnih gradskih vlasti, komunalne službe, odobrenog plana reciklaže ili servisa za odlaganje kućnog otpada, ili posetite stranicu

→ www.canon-europe.com/weee , ili → www.canon-europe.com/battery .

Memo

Index

A
Accounting
Adjusting the Vacuum Strength
В
Bonjour Network
C
CAD 40, 44, 45, 46 Checking Ink Tank Levels 543 Cleaning 547, 560 Clearing a Jammed Sheet 576 Color Adjustment 156, 159, 278, 297 Color imageRUNNER Enlargement Copy 203, 204, 312, 313 Configuring the IP Address 452, 453, 463
D
Deleting Saved Jobs496Device Settings Sheet171Device Setup Utility463Drying Time350
F
Favorites Sheet
G
GARO Wxxxx (x represents a number)
H
Hardware error
laterfee:
Interface
Large-Format Printing
M
Main Pane 254 Main Sheet 150 Maintenance Cartridge 554, 558, 615 Menu Operations 408, 409 Menu Structure 412
N
Navigate 406 Nozzle 546

0
Orientation 133, 134, 135, 228, 238 Output Method 163 Oversize 70
P
Page Setup Pane 265 Page Setup Sheet 161 Paper Feed Slot 578, 580 Personal Box 505, 508 PosterArtist 38 Power 229, 231, 232, 234, 236, 237, 238 Preparing to Transfer the Printer 564 Print Job Log 480, 481 Printer Driver Settings 142, 250 Printer Hard Disk Operations 441 Printing Posters in Sections 113 Printing Saved Jobs 492 Printing Vertical or Horizontal Banners 88, 89, 92 Printing at Actual Size 74, 75, 76
Printing on Rolls
Removing the Roll 345, 348 Replacing Ink Tanks 538 Roll Holder 338, 445
Saving Print Jobs
Saving Print 300s 483, 303 Size Options 164 Special Settings 167, 247 Specifications 622 Specifying Paper in the Printer Driver 30, 144, 251 Status Print 428 Support Sheet 170
U
Using the Output Stacker
W
Watermark

ENG