

## Using WFT Utility

You can configure the wireless or wired LAN settings by using WFT Utility. This is convenient if you want to create a wireless or wired LAN settings file when the camera and WFT-E4 II are not nearby.

### Starting WFT Utility

- In Windows, click the **[Start]** button, select **[All Programs]** (or **[Programs]**) → **[Canon Utilities]** → **[WFT Utility]**. Then, start up the WFT Utility version corresponding to your model of WFT.
- For Macintosh, open folders in the following order: **[Applications]** → **[Canon Utilities]** → **[WFT Utility]**. Then, start up the WFT Utility version corresponding to your model of WFT.

### Using Wireless or Wired LAN Settings

- Click the tabs for the transmitter's **[TCP/IP settings]**, **[FTP settings]**, and **[Wireless LAN settings]** and complete the required settings for a wireless or wired LAN connection. Settings available here are the same as settings on the camera.


The screenshot shows the WFT Utility application window. At the top, there's a menu bar with 'File', 'Edit', and 'Help'. Below the menu bar is a toolbar with icons for file operations. The main area has a 'Settings name:' text box and two radio buttons for 'Wireless' (selected) and 'Wired'. Below these are three tabs: 'TCP/IP settings' (highlighted with a red circle), 'FTP settings', and 'Wireless LAN settings'. The 'TCP/IP settings' tab contains several sections:
 

- IP Addressing: Two radio buttons, 'Obtain an IP address automatically(O)' (selected) and 'Use the following IP address(S)'. Below the latter are input fields for 'IP Address(I):', 'Subnet mask(U):', and 'Gateway(W):'.
- DNS Settings: Three radio buttons, 'Do not use DNS server' (selected), 'Obtain DNS server address automatically', and 'Use the following DNS server address'. Below the latter is an input field for 'DNS server(V):'.
- IP Security: A checkbox 'Use IP Security'. If checked, there are input fields for 'Destination address:' (showing '0.0.0.0') and 'Shared Key:'.


 At the bottom left, there is a checkbox for 'Protect settings(T)'.

## Setting the Wireless LAN Channel

When setting the wireless LAN channel on the [Wireless LAN Settings] tab, first select the version of transmitter used.



## Wireless or Wired LAN Settings Files



- Settings files can be used as follows.

|                           |   |
|---------------------------|---|
| Open                      | Open a settings file saved on the computer or a CF card.  |
| Save                      | Save the settings file on the computer or a CF card. The [Settings name] is used as the file name.<br>For instructions on applying a settings file on a CF card to the camera, see "Saving and Loading Settings" in the WFT-E4 II instruction manual. |
| Load settings from camera | Load a settings file on the camera to the computer. The camera and computer must be connected with the USB cable.   |
| Apply settings to camera  | Apply the settings file to a camera. The camera and computer must be connected with the USB cable.  |