

<<<To EOS-1D X Users Updating the Camera Firmware to Version 2.0.x>>>

This manual is for the EOS-1D X installed with firmware version 2.0.0 or later.
Functions added by firmware version 2.0.x are described on the following pages.

[AF]

- Acceleration/deceleration tracking [-2] and [-1] added ([0, 1, 2] expanded to [-2, -1, 0, +1, +2]) (p.91, 85-89, 350)
- AI Servo 2nd image priority [-2] and [+2] added ([-1, 0, +1] expanded to [-2, -1, 0, +1, +2]) (p.94-95)
- Orientation linked AF point setting [Separate AF pts: Pt only] added (p.101-102)
(Changed from [Select separate AF points] to [Separate AF pts: Area+pt] and [Separate AF pts: Pt only])
- Initial AF point, for AI Servo AF with [Auto selection: 61 pt AF] New function (p.103)

[Exposure Control]

- Auto ISO minimum shutter speed [1/8000] sec. to [1/500] sec. added (p.134)
- Exposure compensation with manual exposure and Auto ISO New function (p.178)
- Same exposure for new aperture New function (p.341)

[Operability]

- Image jump with Main Dial [Display protected images only] added (p.258)
- Slide show [Protect] added (p.272)
- Custom Controls
 - AF start button / AE lock button [ONE SHOT⇌AI SERVO] added (p.350)
[AI Servo AF characteristics], [AF mode], and [14fps super high speed] added to [Metering and AF start] Detail settings (p.348-349)
 - SET button [Expo comp (hold btn, turn ) added (p.353)