


1 Unpack the Printer


NOTE: These instructions are for both the i350 Series Color Bubble Jet and the i250 Series Color Bubble Jet printers. Some of the graphics used may vary slightly from the product you have purchased.

- 1 Carefully remove all items from the box.



i350 Series Color Bubble Jet Printer

OR




i250 Series Color Bubble Jet Printer



i350/i250 Series Print Head



Power Cord



Ink Tanks

BCI-24 Black

BCI-24 Color




Documentation and Software Kit

NOTE: USB cable not included.


2 Prepare the Printer

- 1 Remove all shipping tape from the printer.




Shipping Tape

- 2 Open the front cover. Remove the packing material from the print head holder.



Serial number




Packing material

Print head holder

NOTE: The serial number is located to the right of the print head. You will need this to register the product.

3 Install the Print Head


- 1 Remove the print head from its package.



Tear at notch to open


- 2 Remove the orange protective cap.

NOTE: Do not touch the electrical contacts on the back and bottom of the print head.




Electrical contacts

- 3 Raise the gray lock lever on the printer.




- 4 Slide the print head into the holder until it is securely seated.

Do not press it down.




- 5 Lower the lever until it locks into place.



4 Install the Ink Tanks

- 1 Remove the black ink tank (BCI-24 Black) from its package and pull off the orange protective cap.

NOTE: To avoid spilling ink, do not touch the bottom of the tank once you have removed the protective cap.




Protective cap

- 2 Insert the black ink tank (BCI-24 Black) into the slot on the right. Press down until the ink tank locks into place.




Click

- 3 Repeat the procedure for the color ink tank (BCI-24 Color), inserting it into the remaining slot. Close the front cover.




- 4 Pull out the paper rest and the output tray (i350 only).





5 Connect the Printer To Your Computer

- 1 Plug the power cord into the back of the printer and connect the other end to a power outlet.



IMPORTANT: BE SURE THE PRINTER IS OFF, or the computer will attempt to install the printer driver before the printer is ready.

- 2 Connect one end of a USB cable (not included) to the computer, the other to the printer.



USB Port

USB Cable

Continue with Step 6 on side two.



6 Install the Printer Driver (Windows®)

Windows

- Turn the computer on and **LEAVE THE PRINTER OFF**.

NOTE: For Windows® XP or Windows 2000, log on to Windows as an Administrator before continuing.

IMPORTANT: If you see the Found New Hardware Wizard, click Cancel.



- Close any open software applications, then insert the "Setup Software & User's Guide" CD-ROM. The setup program should run automatically.


NOTE: If the setup does not run automatically, click **Start**, then **Run**, then type **D:\msetup.exe**, where **D** is your CD-ROM drive.

- Read the License Agreement, then click **Yes** to continue.

- When the main menu appears, click **Install**.



- When the Printer Port window appears, **TURN THE PRINTER ON**. The software will begin identifying the printer port being used.



- When Terminate Installation window appears, click **OK**.

NOTE: Remember to register your product. The serial number is located on the inside of the printer, to the right of the print head.

- When the software menu appears, click **Install**. Then follow the on-screen instructions.



- When the Terminate Installation window appears, click **OK**, then **Exit**.

- Click **Yes** if you are prompted to restart your computer.


IMPORTANT: To ensure highest quality output, continue with Step 7 Align the Print Head.

6 Install the Printer Driver (Macintosh®)


Macintosh

- Turn on your Mac and your printer and insert the "Setup Software & User's Guide" CD-ROM.

- Double-click the CD-ROM icon, then the **Mac OS X** folder, then the **Printer Driver** folder.



- Double-click the **i350 190.pkg** or **i250 190.pkg** icon.



- When the "Authenticate" screen appears, enter your administrator name and password, then click **OK**.

- When the "Welcome to the BJ printer driver Installer" screen appears, click **Continue**.

- Read the Software License Agreement and click **Continue**, then click **Agree**.

- Select a destination for the printer driver to be installed. Then click **Continue**.



- Click **Install**. When a message asking for your confirmation to proceed with the installation, click **Continue Installation**.



- When the message "The software was successfully installed" appears, click **Restart**.

- Access your CD-ROM again. From the **Application** folder, double-click on the software to be installed.



- Follow the on-screen instructions. When the "Installation has finished" screen appears, click **OK**.

NOTE: Be sure to register your product. The serial number is located on the inside of the printer, to the right of the print head.

IMPORTANT: To ensure highest quality output, continue with Step 7 Align the Print Head.

7 Align the Print Head


- Place a sheet of blank paper in the paper rest.
- Start the alignment procedure.

Windows:

- For Windows XP/2000, click **Start**, select **Control Panel, Printers and Other Hardware**, then **Printers and Faxes**.
- Right-click the **Canon i350** or **i250** icon, then click **Printing Preferences**.

NOTE: For Windows 98/Me, click **Start, Settings**, then **Printers**. Right-click the **Canon i350** or **i250** icon, then click **Properties**.


- Click the **Maintenance** tab, then click the **Print Head Alignment** icon.



- When asked to start print head alignment, click **OK**.

Macintosh OS X:


- Double-click the **Macintosh HD** icon, then the **Applications** folder. Double-click the **Utilities** folder, then the **Print Center** icon. When the Printer List screen appears, Select **i350** or **i250**.



Under the Printers menu, select **Configure Printer**. Select **i350** or **i250**, and click **Select**.



- Click the down-arrow to select **Test Print**.
- Click the **Print Head Alignment** icon.



- Follow the on-screen instructions.
- Click **OK** (Windows) or **Send** (Macintosh) when finished.