**1** Unpack the Printer

1 Carefully remove all items from the box.






Paper Rest




Documentation and Software Kit



00 Series Print Head Power Cord







NOTE: USB cable is not included.

2 Prepare the Printer


1 Remove the shipping tape from the front of the printer.




2 Plug the power cord into the back of the printer and connect the other end to a power outlet.



3 Press the POWER button.




Open the front cover. The print head holder automatically moves to the center. Remove the protective tape.



Write down the serial number located to the right of the print head. You will need this later to register the product.


**3** Install the Print Head


1 Remove the print head from its package.




2 Remove the orange protective cap from the print head.

**NOTE:** Do not touch the electrical contacts.






3 Raise the lock lever on the printer.




Slide the print head into the holder. The print head will rest at a slight angle.






**5** Lower the lock lever and press it down until it locks into place.




4 Install the Ink Tanks

1 Peel back the orange tab and completely remove the plastic wrapper from the Yellow Ink Tank (BCI-6Y).



2 Twist off and discard the orange protective cap.

NOTE: To avoid spilling ink, never press on the sides of an ink tank.



3 Insert the ink tank into the correct slot. (Refer to the color guide on the print head).


Press down until the ink tank locks into place.



4 Insert the remaining five ink tanks into their assigned slots.



5 Close the front cover, attach the paper rest and extend the paper output tray.





**5** Connect the Printer To Your Computer

**1** TURN THE PRINTER OFF.

IMPORTANT: Be sure the printer is off before continuing, or the computer will attempt to install the printer driver before the printer is ready.

2 Connect one end of the USB cable to the computer, the other to the printer.






Continue with Step 6 on side two.



6 Install the Printer Driver (Windows®)

1 Be sure to **TURN THE PRINTER OFF** before continuing.



- NOTE: For Windows® XP or Windows 2000, log on to Windows as a member of the Administrators group before continuing.
- IMPORTANT: If you see the Found New Hardware Wizard, click Cancel.



- 2 Close any open software applications, then insert the "i9100 Setup Software & User's Guide" CD-ROM. The setup program should run automatically.
  - NOTE: If the setup program does not run, click Start, then Run, then type D:\msetup.exe, where D is your CD-ROM drive.
- 3 Read the License Agreement, then click **Yes** to continue.
- 4 When the main menu appears, click Install.



NOTE: If you are prompted to restart Windows, remove the CD-ROM, then click OK. After the computer restarts, insert the CD-ROM and continue.

When the Printer Port window appears, **TURN THE PRINTER ON.** The software will begin identifying the printer port being used.



- IMPORTANT: If your computer cannot detect a printer port, refer to the Troubleshooting chapter in the "i9100 Quick Start Guide" for instructions.
- **6** When the driver installation is complete, click **Finish**.
- Register your product to ensure product support. Follow the on-screen instructions.



**8** When the software menu appears, click **Install**.



When the software installation is complete, click **OK**, then **Exit**.

IMPORTANT: To ensure highest quality output, continue with Step 7 Align the Print Head.

Install the Printer Driver (Macintosh®)

- Turn on your Mac and your printer and insert the "i9100 Setup Software & User's Guide" CD-ROM.
- Double-click the CD-ROM icon, then the Mac OS X folder, then the Printer Driver folder.



3 Double-click the i9100 180.pkg icon.



- When the "Authenticate" screen appears, enter your administrator name and password, then click **OK**.
- When the "Welcome to the BJ printer driver Installer" screen appears, click **Continue**.
- 6 Read the Software License Agreement and click **Continue**, then click **Agree**.
- Select a destination for the printer driver to be installed. Then click Continue.



8 Click **Install**. When a message asking for your confirmation to proceed with the installation, click **Continue Installation**.



- When the message "The software was successfully installed" appears, click Restart.
- O Access your CD-ROM again. From the Application folder, double-click on the software to be installed.



- Follow the on-screen instructions. When the "Installation has finished" screen appears, click OK.
  - NOTE: Be sure to register your product. The serial number is located on the inside of the printer, to the right of the print head.

IMPORTANT: To ensure highest quality output, continue with Step 7 Align the Print Head.

Before using the printer, align the print head

Align the Print Head

1 Load a sheet of blank paper in the paper rest.

to ensure the best quality printing.

2 Start the alignment procedure.

## Windows:

- a. For Windows XP/2000 click Start, select Control Panel, Printers and Other Hardware, then Printers and Faxes.
- **b.** Right-click the *i***9100 icon**, then click **Printing Preferences**.
- NOTE: For Windows 98/Me click Start, then select Settings, Printers. Right-click the *i*9100 icon, then click Properties.
- c. Click the Maintenance tab, then click on the Print Head Alignment icon.
- **d**. When asked to start print head alignment, click **OK**.



e. Follow the on-screen instructions.

## Macintosh OS X:

a. Double-click the Macintosh HD icon, then Applications folder. Double-click the Utilities folder, then the Print Center icon. When the Printer List screen appears, select i9100.



Under Printers menu, select **Configure Printer**. Select **i9100**, and click **Select**.



- **b.** Click the down-arrow to select **Test Print**.
- c. Click the **Print Head Alignment** icon.



- 3 Follow the on-screen instructions.
- 4 Click **OK** (Windows) or **Send** (Macintosh) when finished.

Part no. QA7-2669-V01
© 2003 Canon U.S.A., Inc.
Canon is a Registered Trademark of Canon Inc.
All other products and brand names are registered trademarks or trademarks of their respective owners.
Specifications subject to change without notice.
40-42430-1102
Printed in Thailand