Canon

Start Here Easy Setup Instructions

1 Unpack the Printer	2 Prepare the Printer	3 Install the Print Head	4 Instal
1 Carefully remove all items from the box.	 Remove the shipping tape from the front and sides of the printer. 	1 Remove the print head from its package.	 Pull the oral (BCI-6Y), the plastic wrap
S9000 Photo Printer	Shipping Tape	2 Turn the print head over, then remove the orange protective cap.	2 Twist off an protective c
	Plug the power cord into the back of the printer and connect the other end to a power outlet.		
		NOTE: Do not touch the electrical contacts.	NOTE: To avo the sides of a
Paper Rest		Electrical contacts	Insert the in (Refer to the Press down into place.
	3 Press the POWER button.	8 Raise the gray lock lever.	
Documentation and Software Kit	POWER POWER Button Lamp		Insert the re their assign
S9000 Print Head Power Cord	Open the front cover. The print head holder automatically moves to the center. Remove	Gently slide the print head into the holder. The print head will rest at a slight angle. Do not press it down.	
	the protective tape.		5 Close the fraction of the second
Ink Tanks BCI-6C Cyan BCI-6M Magenta BCI-6BK Black BCI-6Y Yellow	Protective tape	Solution Lower the lock lever and gently press it down until it locks into place.	
	Serial number		
BCI-6PC Photo Cyan BCI-6PM Photo Magenta	Write down the serial number located to the right of the print head. You will need this later to register the product.		



all the Ink Tanks

range tab off the yellow ink tank then remove and discard the rapper.



and discard the orange ve cap.




- avoid spilling ink, never press on of an ink tank.
- e ink tank into the correct slot. the color guide on the print head.)
- wn gently until the ink tank locks



e remaining five ink tanks into igned slots.





e front cover, attach the paper rest and the paper output tray.



5 Connect the Printer To Your Computer

- **1** Turn the printer off.
 - IMPORTANT: Be sure the printer is off before continuing, or the computer will attempt to install the printer driver before the printer is ready.
- 2 Connect one end of the USB cable to the computer, the other to the printer.





Continue with Step 6 on side two.




Canon


6 Install the Printer Driver (Macintosh[®]) **6** Install the Printer Driver (Windows[®]) **1** Be sure to **TURN THE PRINTER OFF** before **5** When the Printer Port window appears, **1** Turn on your Mac and insert the "S9000 TURN THE PRINTER ON so the printer port continuing. Setup Software & User's Guide" CD-ROM. (connection) can be automatically detected. then **Chooser**. POWER POWER Button Lamp **NOTE:** Screen shots may differ depending on the operating system used. **2** Open the Printer Driver folder on the CD-ROM, then double-click the Installer icon. CANON BI **NOTE:** For Windows[®] XP or Windows 2000, log on to Windows as a member of the Administrators The software will begin identifying the group before continuing. printer port being used. the right panel. 6 rhend, bern K availab ÷ **IMPORTANT:** If your computer cannot A **IMPORTANT:** If you see the Add New detect a printer port, refer to the Hardware Wizard, click Cancel. Troubleshooting chapter in the "S9000 Quick Start Guide" for instructions. 8 Read the License Agreement and click Accept, if you agree. 6 When the Terminate Installation window appears, click OK. 4 Click Install. The printer driver will load automatically. 7 Follow the on-screen instructions to continue Test Canal with Product Registration. Kany Inchail 8 **NOTE:** Remember to register your product Out "Indat" in motal the follows to ensure product support. The serial number 2 Close any open software applications, is located on the inside of the printer, to the **9** Close the Chooser. right of the print head. then insert the "S9000 Setup Software & User's Guide" CD-ROM. The setup program should run automatically. (bestall 8 When the main menu appears, make sure that Application is selected, then click **NOTE:** If the setup program does not run, click Start, then Run, then type D:\msetup.exe, Install. where D is your CD-ROM drive. **5** If the message "No other applications can be running..." displays, click Continue. Canon 8 Read the License Agreement, then click Yes, if you agree. No other applications can be running during this installation. Click Continue to Applicate smatically guit all other run plications. Click Cancel to leave yo **4** When the main menu appears, make sure Cancel Car that the Printer Driver is selected, then - Net click Install. **6** When the "Installation was successful" click OK. Canon screen displays, **Restart** your computer. 9 When the Terminate Installation window 1206422 appears, click OK, then Exit. Printer Dates **NOTE:** For more information, refer to the "S9000 Quick Start Guide" or view the Continue Reviart electronic documentation on the CD-ROM. - Net **NOTE:** Register your product to ensure product ① Click **Yes** if you are prompted to restart your support. The serial number is located on the computer. inside of the printer, to the right of the print **NOTE:** If you are prompted to restart Windows, head. remove the CD-ROM, then click **OK**. After the computer restarts, insert the CD-ROM and 1 To insure highest quality output, continue continue.

with Step 7 Align the Print Head.

After the computer restarts, TURN THE **PRINTER ON.** Select the **Apple** menu,



8 Click the **S9000** icon in the Chooser. The printer name will highlight and move to



NOTE: To use the BJ Print Monitor, click the Backgrounding button to the On position.

Access your "S9000 Setup Software & User's Guide" CD-ROM again. From the Application folder, double-click on the software to be installed.

C	34	ancepes	二氏石
8%	E Anna . I	arro X acadadia	
1	1_	Passing	
-			

1 Follow the on-screen instructions. When the "Installation has Finished" screen appears,

NOTE: For more information, refer to the "S9000 Quick Start Guide" or view the electronic documentation on the CD-ROM

When prompted, restart your computer.

To insure highest quality output, continue with Step 7 Align the Print Head.

Align the Print Head

Before using the printer, align the print head to ensure the best quality printing.

- **1** Add a stack of blank paper to the sheet feeder.
- **2** Start the alignment procedure.
 - Windows:
 - a. Click **Start**, then **Settings**, then **Printers**. **NOTE:** For Windows XP, select **Start**, then Control Panel. Then click on Printers and Other Hardware, then Printers and Faxes.
 - b. Right-click the Canon S9000 icon, then click **Properties**.
 - c. Click the Maintenance tab, then click the Print Head Alignment icon.



Macintosh:

- a. From the **File** menu in a software application, click Page Setup.
- b. Click the **Utilities** button.
- c. Click the down-arrow to select Test Print.
- d. Click the Print Head Alignment icon.



- 3 Click Yes (Windows) or OK (Macintosh) when prompted if the pattern printed successfully.
- 4 Compare the different patterns for each color on the printout:

-	-	-	and and	-
-	_	-	-	and so its
- 8400	_	-	(result	1000
-	_	_		
-	-	_		
	_	_	1.000	10000
-		_	1000	-
-	_	_	1000	
-	_	_	10000	-
			1000	
-	_	-		-
		_		
		-		
		-		
		=		
		_		

5 For each color on the test printout, enter the number in the Print Head Alignment window that corresponds with the smoothest looking test pattern.

	Adjand address storage 2 + 4/3		
	A. Black:	#1121	Anti-Line (Control
	R. Crest		-
	C. Magnita:		and the second have
11211	B. Multi-Lyan I		titut II
-	E. Photo Magnotia		Riber II
Ξ.	Adjust halfs ways (-5-4	19	Diama I
-	5. Belli Wash	· 1	Other .
÷.,	Clane		Eternen IT
	- Cranta	\smile	dollari foresh Ta
		1 M	Filmand .

6 Click **OK** (Windows) or **Send** (Macintosh) when finished.