



1 Unpack the Printer

- 1 Carefully remove all items from the box.



i960 Series
Photo Printer



Documentation
and Software Kit







Photo Paper Tray



Power Cord



i960 Series Print Head




BCI-6BK Black BCI-6Y Yellow BCI-6M Magenta BCI-6C Cyan
BCI-6PM Photo Magenta BCI-6PC Photo Cyan

Ink Tanks


2 Prepare the Printer

- 1 Remove the shipping tape from the front and back of the printer.




Shipping Tape

- 2 Plug the power cord into the back of the printer and connect the other end to a power outlet.




- 3 Press the POWER button. The printer will initialize.



POWER
Button

POWER
Lamp

- 4 Open the front cover. The print head holder automatically moves to the center. Remove the protective tape.




Protective
Tape

Serial Number

- 5 Write down the serial number located to the right of the print head holder. You will need this later to register the product.

3 Install the Print Head


- 1 Remove the print head from its package.



Tear at notch to open

- 2 Remove the orange protective cap from the print head nozzles.


NOTE: Do not touch the electrical contacts or the print head nozzles.




Print Head Nozzles

Electrical Contacts


- 3 Raise the lock lever on the printer.



- 4 Slide the print head into the holder. The print head will rest at a slight angle.




- 5 Lower the lock lever and press it down until it clicks into place.




4 Install the Ink Tanks

- 1 Peel back the orange tab and completely remove the plastic wrapper from the Magenta Ink Tank (BCI-6M).



- 2 Twist off and discard the orange protective cap.


NOTE: To avoid spilling ink, never press on the sides of an ink tank.




Protective Cap

- 3 Insert the ink tank into the correct slot. (Refer to the color guide on the print head holder.)


Press down until the ink tank clicks into place.



- 4 Insert the remaining ink tanks into their assigned slots.



- 5 Close the front cover and extend the paper rest and paper output tray.



Paper Rest

Paper Output Tray

NOTE: The printer will perform a print head cleaning after the cover is closed.

5 Connect the Printer and Load Paper

IMPORTANT: Be sure the printer is off before continuing, or the computer will attempt to install the printer driver before the printer is ready.


USB Ports:

- 1 TURN THE PRINTER OFF.
- 2 Connect one end of the USB cable to the computer, the other to the appropriate USB port on the printer.

If your computer and operating system support USB 2.0 Hi-Speed, use the top port. Otherwise, use the bottom port.

NOTE: The i960 Series Photo Printer is equipped with both USB 2.0 Hi-Speed and USB 1.1 ports. If you do not know your USB version number, connect using the lower port.

Do not switch port after installation.




Top Port:
USB 2.0
Hi-Speed

Bottom Port:
USB 1.1

USB Cable

- 3 Pinch the paper guide and slide it to the left. Load a sheet of blank paper in the paper rest. Slide the guide toward the left edge of the paper.



Paper
Guide


Continue with Step 6
on side two.



6 Windows® Printer Driver Installation and Print Head Alignment


Windows

- 1 Be sure to **TURN THE PRINTER OFF** before continuing.



NOTE: For Windows® XP or Windows 2000, log on to Windows as an Administrator before continuing.

IMPORTANT: If you see the Found New Hardware Wizard, click **Cancel**.




- 2 Close any open software applications, then insert the “Setup Software & User's Guide” CD-ROM. The setup program should run automatically.


NOTE: If the setup program does not run, click **Start**, then **Run**, then type **D:\msetup.exe**, where **D** is your CD-ROM drive.

- 3 Read the License Agreement, then click **Yes** to continue.

- 4 When the main menu appears, click **Install**.



- 5 When the Printer Port window appears, **TURN THE PRINTER ON**. The software will begin identifying the printer port being used.




IMPORTANT: If your computer cannot detect a printer port, click **Help** and refer to the online instructions.

- 6 Register your product to ensure product support. Follow the on-screen instructions.

- 7 When the Terminate Installation window appears, click **OK**.

- 8 When the software menu appears, click **Install** and follow the on-screen instructions.



- 9 When the Terminate Installation window appears, click **OK**, then **Exit**.

- 10 Click **Yes** when you are prompted to restart your computer.

- 11 Start the print head alignment procedure.


a. For Windows XP/2000 click **Start**, select **Control Panel**, **Printers and Other Hardware**, then **Printers and Faxes**.

b. Right-click the **i960** icon, then click **Printing Preferences**.


NOTE: For Windows 98/Me click **Start**, then select **Settings**, **Printers**. Right-click the **i960** icon, then click **Properties**.

c. Click the **Maintenance** tab, then click on the **Print Head Alignment** icon.

d. When asked to start the simple head alignment, click **OK** and follow the on-screen instructions.



e. Look at the printed patterns and input the values for each pattern that shows no flaws (least number of white stripes). Then click **OK**.



f. The rest of the print head alignment process will take place automatically. Load two more sheets of paper and follow the on-screen instructions. This process will take a few minutes.

- 12 Click **OK** to exit the Maintenance tab. Print head alignment is now complete.


6 Mac® OS X Printer Driver Installation and Print Head Alignment

Macintosh


NOTE: For Mac OS 8.6 to 9.x printer driver instructions, refer to the "Appendix" of the *Quick Start Guide*.

- 1 Turn on your Mac and your printer and insert the “Setup Software & User's Guide” CD-ROM.

- 2 Double-click the CD-ROM icon, then the **Mac OS X** folder, then the **Printer Driver** folder.



- 3 Double-click the **i960 220.pkg** icon.




- 4 When the “Authenticate” screen appears, enter your administrator name and password, then click **OK**.


- 5 When the “Welcome to the BJ printer driver Installer” screen appears, click **Continue**.

- 6 Read the Software License Agreement and click **Continue**, then click **Agree**.

- 7 Select a destination for the printer driver to be installed. Then click **Continue**.




- 8 Click **Install**. When a message asking for your confirmation to proceed with the installation appears, click **Continue Installation**.



- 9 When the message “The software was successfully installed” appears, click **Restart**.


- 10 When the message asking you to align the print head appears, click **OK**.




- 11 Start the print head alignment procedure.

a. Double-click the **Macintosh HD** icon, then **Applications** folder. Double-click the **Utilities** folder, then the **Print Center** icon.


b. When the Printer List screen appears, select **i960**, then click the **Configure** icon.



c. Select **i960** and click **Select**.



d. Click the down-arrow to select **Test Print**. Click the **Print Head Alignment** icon and follow the on-screen instructions.




e. Look at the printed patterns and input the values for each pattern that shows no flaws (least number of white stripes). Then click **Send**.

f. The rest of the print head alignment process will take place automatically. Load two more sheets of paper and follow the on-screen instructions. This process will take a few minutes.

- 12 Click **Quit** to exit the BJ Printer Utility. Print head alignment is now complete.

- 13 Access your CD-ROM again. From the **Application** folder, double-click on the software to be installed.




- 14 Follow the on-screen instructions. When the “Installation has finished” screen appears, click **OK**.


- 15 Register your product to ensure product support. Double-click on the **Product Registration** icon, found in the **Mac OS X** folder. Follow the on-screen instructions.

7 Optional Photo Paper Tray


- 1 With the paper rest open, pinch and slide the paper guide to the left end.



- 2 Install the Photo Paper Tray. Put the Photo Paper Tray along the paper rest and insert it until it clicks into place.




- 3 Open the Photo Paper Tray cover, adjust the paper guide and load the paper, printing side up. Close the cover.



- 4 You can print from both paper trays.

4" x 6" : Turn the knob to the left until it points at **PRINT**.

Letter: Turn the knob to the right until it points at **REMOVE**.



- 5 If you want to remove the Photo Paper Tray, turn the knob so that it points at **REMOVE** and push the lever up while lifting the Photo Paper Tray out.

