

NETWORK VIDEO RECORDER

VK-64/VK-16

Administrator's Manual



Introduction

Thank you for purchasing Network Video Recorder VK-64 v2.2 (hereafter referred to as VK-64). VK-64 is a network video recording and monitoring system and consists of the Storage Server and Viewer. Please read this manual prior to operation. This manual also explains how to use the Network Video Recorder VK-16 v2.2 (hereafter referred to as VK-16), VK-Lite v2.2 (hereafter referred to as VK-Lite), and Viewer-Only use. See P. 1-6 for the difference between the VK-64 and VK-16. See P. 1-30 for the difference between VK-64/VK-16 and VK-Lite. See P. 5-8 for the functions not available in the Viewer Only mode.

* VK-16 and VK-Lite have the same functionality as VK-64 outlined in this manual, unless explicitly indicated otherwise

Request to Customers

- 1. Canon owns the copyright of this manual. The unauthorized transfer of all or any part of the contents of this Manual is forbidden.
- 2. The contents of this manual are subject to change without any notice.
- 3. This document has been prepared with the utmost attention to accuracy. However, if you have any comment, please contact the Customer Service Center indicated on the back cover.
- 4. Irrespective of items (2) and (3) above, Canon cannot bear responsibility for any effects resulting from operation.
- 5. When procedures that involve using the control panel are described in this manual, the operations are described as shown in Windows Vista Basic.

Disclaimer

Malfunction and failure of the software, or other factors may cause problems, such as recording failure, recorded data corruption or loss. Canon shall have no liability whatsoever for any loss or damages incurred by the user as a result of such problems.

Support Information

For various types of information relating to support, including updated product software (patch installer), User's Manual, operating environment, etc., please see the Canon Web site.

Copyright Information

Videos, images or sounds recorded with your camera may not be utilized or published, without consent of copyright holders, if any, except in such a way as permitted for personal use under the relevant copyright law.

Trademark Notice

- Canon and the Canon logo are registered trademarks of Canon Inc.
- Microsoft, Windows, Windows Server, Windows Vista and Internet Explorer are registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- Windows is legally recognized as Microsoft Windows Operating System.
- QuickTime is a trademark of Apple Inc.
- Apache is a trademark of the Apache Software Foundation.
- Pentium is a trademark of Intel Corporation.
- All other company or product names used in this manual are trademarks or registered trademarks of their respective holders.

Icons Used in this Manual

The following icons are used in this guide to indicate descriptions that you should read in particular.

Icon	Explanation
	Important information that must be observed or actions that are prohibited during an operation. These notes must be read to prevent possible faults or errors during operation.
🎉 Tip	Supplementary information or a reference to an operation. Users are recommended to read these memos.

Storage Server includes software developed by the Apache Software Foundation (www.apache.org). Apache software is protected by the copyright law (Copyright© 2000-2003 Apache Software Foundation). For the license terms associated with this software, please see the file APACHE_LICENSE in the LICENSE folder, in the installation directory.

MPEG-4

NOTICE ABOUT THE MPEG-4 VISUAL STANDARD: THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL, INTERNAL AND COMMERCIAL USES AND ADDITIONAL LICENSING MAY BE OBTAINED FROM MPEG LA, LLC. SEE HTTP://WWW.MPEGLA.COM.

This product is licensed under AT&T patents for the MPEG-4 standard and may be used for encoding MPEG-4 compliant video and/or decoding MPEG-4 compliant video that was encoded only (1) for a personal and non-commercial purpose or (2) by a video provider licensed under the AT&T patents to provide MPEG-4 compliant video. No license is granted or implied for any other use for MPEG-4 standard.

Open Source Software

This product contains open source software modules. Each module's license conditions are also available in the OpenSourceSoftware folder in the LICENSE folder on the accompanying Setup CD-ROM.

Software	License	License Agreement
Apache	Apache Software License, Version 1.1	Apache
FastCGI	Open Market License	FastCGI
Expat	MIT License	Expat

Purpose of This Manual

This manual is written for the System Administrator installing and operating the VK-64/VK-16 system.

It explains the functions of VK-64/VK-16 and introduces more appropriate system deployment methods. Use this manual as a reference when making a backup of data or troubleshooting a problem.

Contents

■Introduction	ii
■ Purpose of This Manual	iv
■ About Manuals	xii
■ Important: Before Starting Operations	xiii
Chapter 1 System Overview	
Chapter Overview	1-2
Preparation Flow	1-4
System Operation Overview	1-6
Communication Mechanism of VK-64/VK-16	
Typical System Configuration	
Operating Environment	1-10
Supported Camera Servers	
System Environment	
ViewerStorage Server	
■ Notes on Operating Environment	
Notes on Use with Windows XP	
Notes on Use with Windows XP/Vista	
Windows Server 2003/Windows Server 2008	
Windows Server 2008	
Windows Vista/Windows Server 2008	1-16
System Design Concept	1-17
System Configuration Example	1-17
When using multiple Storage Servers	
When using Viewer alone	
Server Sizing Concept	
Approximate Video Data Volume per Second	
Required Hard Disk Capacity	
Sensor Event Recording and Motion Detection Recording Concept Storage Server Performance	
Notes on Viewer Sizing	
Network Bandwidth Concept	
■VK-Lite	1-28
■ Specification Comparison of VK-64/VK-16 and VK-Lite	
Chapter 2 Installation	
■ Chapter Overview	
■ Installation Procedures	
Start up the Installer	
Upgrade from Version 1.0, 1.1, 1.2, 1.3, 1.4, 2.0 and 2.1 Preparation and Precaution	
r reparation and r recaution	∠-1

Chapter 3 Storage Server Configuration Reference

Chapter Overview	3-2
■[Storage Server Configuration] Dialog	3-3
How to Start-Up	
Screen Configuration	3-4
■ Set the [Settings] Tab	3-8
How to Display the [Settings] Tab	
How to set the [Settings] Tab	
Message	3-15
[Logon As Service] Privilege	3-15
■ Important: Disk Space Management	3-17
Disk Space Management Level	
Handling at Each Level	3-17
[Low disk space warning level] Calculation Method	3-19
Threshold Level Calculation Method	
Limit Level Calculation Method	
Calculation Example for Each Level	3-20
Set [Events] Tab	3-21
How to Display the [Events] Tab	
How to Set the Events Tab	3-22
■ Set the [Event Notification] Tab	3-23
How to Display the [Event Notification] Tab	
How to Set the [Event Notification] Tab	
■ Set [User Management] Tab	3-25
How to Display the [User Management] Tab	
Administrator and Operator Status User	
How to Set the [User Management] Tab	
Change User to Administrator	
Delete a User	
Request User Authentication at Tool Startup	3-27
Chapter 4 Register Camera Server and Set Recording Scl	hedule
■ Chapter Overview	4-2
Launch VK Viewer and Display the [Configuration and Preferences] Screen .	1 -9
How to Launch VK-64/VK-16	
How to Start VK-Lite	
Launch by Connecting to the Localhost	
Launch Storage Server by Specifying the IP address	
Access to the Configuration and Preferences screen	4-7
■[Storage and Camera Server Summary] Windows	4-8
Display the [Storage and Camera Server Summary] Windows	
[Storage Server] and [Locations / Zones] options	
Other Functions in Both Tabs	

Location and Zone	4-10
Add a Location and Zone	4-12
Edit a Location and Zone	
Delete a Location and Zone	4-13
Add Storage Server	4-14
Display [Storage and Camera Server Summary] Windows	4-14
Add Storage Server	
Edit Storage Server	
Delete Storage Server	4-16
Register Camera Server	4-17
Register the Camera Server (by Search)	
Edit Camera Server	4-24
Delete Camera Server	4-26
Overview of Recording Schedule Setting	4-27
Recording Schedule	4-28
Set Normal Schedule	4-31
Create Normal Schedule	
Change Camera Carrier Cattings	4.41
Change Camera Server Settings	
■ Batch-Setting Schedules	4-44
Set Continuous Recording	4-45
Set Motion Detection Recording	4-46
Set Motion Detection Recording Settings	
Edit Motion Detection Recording Settings	4-47
Set Sensor Event Recording	4-53
Set Sensor Event Recording Settings	
Edit Sensor Event Recording Settings	
Set Preset Tour	4 50
Set Preset Tour	
Set a Special Day Schedule	
Special Day Recording	
Add, Edit and Delete a Schedule Type	
Add and Delete a Day	
Display Recording Setting Summary	
Check Summary Information of a Recording Schedule	
Check Summary Information of Storage Server	4-69

Chapter 5 Viewer Reference

■ Chapter Overview	
■ Viewer Operation Flow	5-4
Start the Viewer	5-6
How to Launch	
Launch by Connecting to the localhost	
Launch Storage Server by Specifying the IP address	
Launch without Storage Server (Viewer Only Mode)	
Functions not Available in Viewer Only Mode	
Viewer Start-up Window	5-10
Viewer Start-up Option	5-11
■ Menu Bar of Viewer Screen	5-12
Functions of Menu Bar	5-12
■ Viewer Setting	
[Viewer Settings] window	
Set the Tab for Administrator	5-14
Set whether to select the Master Storage Server when the Viewer starts up	
Set layout of the Viewing Screen	
Set Event Popups	
Set Event Notifications	
Set the Tab for Guest User	
Frame Rate Setting for live video	
Automatic Audio Termination Setting	
Focus Operation Setting	
Proxy Server Setting Superimpose the Date and Time on Still Frames	
Save Viewer Settings	
■ Arrange and Save Layouts	
Manage Video Layouts	
Layout menu	
Organize Layouts and Layout Sequences	
Save a Layout or Layout Sequence	
Arrange Layout Sequences	
Layout Grids	
Alignment Grid	
Custom Grid	
Hide and Show Task Areas	5-29
■ Basic Video Window Functions	5-30
Select Cameras for Viewing	
Camera Selection Area	
Camera Thumbnails	
Locations and the Zones	
Basic Video Window Functions	
Create, scale and move Video Windows	5-32

■Arrange Video Windows	5-35
Select Multiple Video Windows	5-35
Video Window Status	5-36
Video Window Properties	5-36
Video Window states	5-36
Pan, Tilt, Zoom Control	5-38
Other Video Window Functions	5-43
Change the Video Window size	5-43
Change the Received Video size (VB-C500VD, VB-C500D, VB-C60,	
VB-C50i/VB-C50iR, VB-C50FSi, VB-C50Fi only)	5-44
Enable Exposure Compensation	5-45
Other Menu Options	5-46
Viewer Shade Control	5-47
Audio Panel	5-47
■Use Timeline and View Events	5-48
Timeline Overview	
Monitor Live Video in relation to the Timeline	
Use the Timeline to play and extract video	
One-minute manual recording (Record Now)	
Shoot a Snapshot	
Daylight Savings Indicator	
Extract video to save to a file	
View and Search Events	
[Live Events Log] list	
Display the [Live Events Log] list	
Overview of Alert Parameters	
Search Events	
Select Criteria for Searching	5-59
View retrieved recorded video	5-60
Popup Video upon Event occurring	5-61
Chapter 6 Operation and Management	
■ Chapter Overview	6-2
■ Health Check for Storage Server	6-3
VK Events (Timeline for VK Viewer)	
Number of Frames Queued for Processing	
-	
Operation Guideline for Recording and Viewing	
Live-View Frame Rate Adjustment	
Recording Frame Rate Adjustment	6-5
Operational Guideline for Sensor Event Recording	6-6
Proper Operation of Sensor Event Recording	
Optimization of Sensor Arrangement and Sensitivi	ty)6-6
Ontimization of Motion Detection Recording (Index)	6.7
■ Optimization of Motion Detection Recording (Index)	/

Chapter 7 Backup Scheme

■ Chapter Overview	7-2
■Purpose	7-3
■ Preparation	7-4
Backup Device	7-4
Backup Tool	
Restore Server for Archiving	7-4
Files to Make a Backup	7-5
Storage Location of Video Data, Audio Data, and Event Data	7-5
■ Backup for Data Protection	7-8
About Backup	7-8
■ Backup for Archiving (Long-Term Storage of Data)	7-9
■Backup Procedure for Video Data and Event Data	7-10
■ Restoration Procedure	7-11
Restore Data from Backup for Data Protection	7-11
Restore Data from Backup for Data Archiving	7-12
■Examples	7-13
Configuration 1: Backup for Data Protection 1	7-13
Configuration 2: Backup for Data Protection 2	
Configuration 3: Backup for Data Archiving	
Configuration 4: Backup from Multiple Storage Servers (Backup for Data Protection) Chapter 8 System Maintenance	7-14
■ Chapter Overview	8-2
■Upgrade VK-64/VK-16	8-3
■ Reinstall VK-64/VK-16	8-5
When You Have the Released Version	8-5
When You Do Not Have the Released Version 2.2	8-5
■ Procedure for Restoring Previous Version	8-6
Required Media and Data	8-6
■ Camera Server Maintenance	8-7
Procedure for Updating Camera Firmware	8-7

Chapter 9 Troubleshooting

■ Chapter Overview	9-2
■Troubleshooting for Recording	9-3
■VK Troubleshooting	9-4
Viewing Screen and Video Windows	9-4
Timeline	9-6
Extract Video	9-7
Scheduling and Recording	9-7
Connection Problems	
Configuration Problems	
Upgrade Problems	9-9
■Messages List	9-10
Operation Messages and Error Messages	9-10
VK-64/VK-16 Recording Engine Logs	
Access Engine Log	9-29
VK-64/VK-16 Viewer Logs	9-30
Log Storage Destination	9-30
Error Codes in Log File	9-31
VK Event Information	9-34
Chapter 10 Appendix	
Camera Server Control	10-2
■ Hard Disk	10-3
Lifetime of Hard Disk	10-3
RAID Reconfiguration	10-3
■ How To Check Software Version	10-5
Storage Server Configuration tool	
VK Viewer	
■Functional Limitations on MPEG-4	10-6
Index	10.7

About Manuals

VK-64/VK-16 comes with three manuals including this document.

• Setup Guide

A manual that introduces this software.

Be sure to read this manual when using the software for the first time.

• Viewer Operation Guide

A simplified manual for the VK Viewer.

Be sure to read the Administrator's Manual for details.

• Administrator's Manual (this manual - pdf file)

This manual is intended for the System Administrator to install and operating this software.

Be sure to read this manual to ensure proper system operation.

Important: Before Starting Operations

It is recommended that you perform tests under actual conditions before starting operations.

- This recording software may not operate as your settings in recording or displaying live video, depending on the capabilities of your PC and the network environment.
- When load on your computer CPU and hard disk is high, the specified frame rate may not be available, or the video recording may be interrupted or the Viewer operation may take longer. Also, when available disk space is low, the disk load may increase and the video recording may be interrupted.
- The performance of storage servers and viewers may be negatively affected on the PC, where anti-virus software or firewall is running.
- If you use a proxy server, recording frame rate may not be achieved as specified or live video monitoring may be interrupted. Also, communication between the Storage Server and Viewer may occasionally be disconnected. (→ P. 3-9, P. 4-5)
- If you are operating using IPSec, the recording and display performance may be degraded.
- See "Notes on Operating Environment" (→ P. 1-12 ~ P. 1-16) for information on OS you use.
- When recording to a NAS server, it is recommended to separate the communication networks for the camera and NAS.
- Use recommended NAS servers with Windows Storage Server 2003 or Windows Storage Server 2003 R2.
- Although the audio function of the VB-C500VD, VB-C500D, VB-C60, VB-C300, VB-C50i, VB-C50iR, and VB-C50FSi can also be used, take note of the following warnings.
 - The VK Viewer supports audio transmission and reception.
 - Audio data can be recorded. However, audio data cannot be recorded individually, and must be recorded together with video data.
 - Only when playing video, the recorded video (<u>JPEG</u>) is synchronized with the recorded audio. However, the audio and images may not synchronize depending on the environment (→ P. 4-35).
 - The audio stream may be interrupted due to the performance of your PC and the network environment.
 - The audio function is not available via a proxy server.
 - Audio may be interrupted on the PC where anti-virus software is running.
- The software may not be able to record video, if you use it under the condition where the IP address of storage servers or camera servers are occasionally changed. So, please be sure to use fixed IP addresses.

System Overview

Chapter Overview

This chapter provides preliminary information you should know before using the VK-64/VK-16 and explains the operating environment and basic concept you need to understand to design your system.

Preparation Flow

Explains the flow from setting up the VK-64/VK-16 to starting the operation.

System Operation Overview

Explains the system operating environment such as the number of Camera Servers available for the Storage Server, product types, and the number of licenses for each product.

Communication Mechanism of VK-64/VK-16

Explains the communication mechanism of the VK-64/VK-16 with, using a typical system configuration.

Operating Environment

Explains operating environment of the VK-64/VK-16 and points of notice regarding the OS environment.

Notes on Operating Environment

Explains about each version of Windows OS.

System Design Concept

Explains the concept and points of notice when you design the system.

VK-Lite

Explains about functional limitations and the specification comparison between VK-Lite and VK-64/VK-16.

Preparation Flow

The following explains the flow from setting up the VK-64/VK-16 to starting the operation.




The first step is to set up your Camera Servers. See your Camera Server manuals for connection in detail.

For details regarding supported camera servers, see P. 1-10.

Step2 Install Storage Server and Viewer

The Storage Server and Viewer can be installed on one PC. The Viewer can be installed on other computers on the network, and it will access recorded video from the Storage Server through the network.

Server setting, event notification to users and user privilege configuration can be set via [Storage Server Configuration] dialog.



Step3 Configure Recording Settings

Register Camera Servers and Storage Servers and set up recording schedules.



Step4

Camera Servers

Create and save Viewer Layout

Monitoring live video and playing back recorded events can be done by the Viewer application. And also you can customize the Viewing Area and save Layouts.



System Operation Overview

VK-64/VK-16 Overview

Network Video Recorder

Network Video Recorder is software for viewing video, recording video and audio, and playing back video from multiple network cameras (hereafter referred to as **Camera Servers**). This supports viewing and recording JPEG and MPEG-4 video, bidirectional audio communication, and recording audio.

Composition of Network Video Recorder

Network Video Recorder consists of two software component: a Storage Server and a Viewer.

The Storage Server can record video from multiple Camera Servers, and can also record event information from motion detection and external device inputs. The Viewers can show the live video from multiple Camera Servers, and playback video recordings saved on a Storage Server.

Product Type

Number of Camera Servers Used

Product Name	Storage Server	Viewer
Network Video Recorder VK-64 v2.2	1 license	1 license
Network Video Recorder VK-16 v2.2	1 license	1 license
Network Video Recorder VK-64 v2.2 Viewer	-	1 license
Network Video Recorder VK-16 v2.2 5 Viewers	-	5 licenses

Network Video Recorder VK-64

Network Video Recorder VK-64 (hereafter referred to as **VK-64**) can register and use up to a maximum of 64 Camera Servers.

Network Video Recorder VK-16

Network Video Recorder VK-16 (hereafter referred to as VK-16) has the same basic functionality as VK-64, but is only able to register up to 16 Camera Servers.

A comparison between VK-64 and VK-16 is as follows.

Туре	Storage Server	Viewer
VK-64	Maximum number of registered Camera Servers: 64 units	
VK-16	Maximum number of registered Camera Servers: 16 units All other functions are the same as the VK-64	Same

^{*} The Viewer for VK-64 and VK-16 is the same.

VK-64 Viewer (Using the Viewer Only)

If you want to use additional Viewers, purchase the required number of viewer license. If you do not need to record video, the Viewer can be used in a standalone configuration.

You can perform live viewing and camera control of up to 64 units (cannot use functions such as recording and playback, display event information from motion detection and external device inputs, or still frames).

Upgrading from a Previous Version

To upgrade from an older version (v1.1, v1.2, v1.3, v1.4, v2.0 or v2.1) to v2.2, download the free patch install from our website. License keys from older versions can also be valid in v2.2.

Network Video Recorder VK-Lite


The Network Video Recorder VK-Lite which is bundled with the VB-C500VD, VB-C500D and VB-C60 is a simplified version of VK-64/VK-16. VK-Lite can display video, record video and audio, and playback for up to 4 Camera Servers.

Communication Mechanism of VK-64/VK-16

The following explains the communication mechanism of the VK-64/VK-16, with using atypical system configuration.


Typical System Configuration


VK-64/VK-16 provides video viewing and recording from Camera Servers via an IP network such as a LAN. Since VK-64/VK-16 makes use of IP networks, cameras can be installed easily. And also addition of new camera or change of camera location can be done flexibly.



Application Types and Functions

Application	Function
Storage Server	Save logs information of such as video, audio, and events.
Viewer	User can view recorded information, monitor live-video and check and search events from recording server. Administrator can configure the storage server setting.





Operating Environment

Supported Camera Servers

The table below shows the Camera Servers supported by VK-64/VK-16.

This information is as of September 2009. For the latest information, please access to Canon Web site.

Camera Server	Firmware Versions	
VB-C500VD	Ver. 1.1 0	
VB-C500D	Ver. 1.0 0 or later	
VB-C60	Ver. 1.0 0 or later	
VB-C300	Ver. 1.0 Rev. 02 or later Ver. 1.1 Rev. 0 or later	
VB-C50iR VB-C50iR	Ver. 1.2 Rev. 77 or later	
VB-C50FSi	Ver. 1.0 Rev. 77 or later	
VB-C50Fi	Ver. 1.0 Rev. 77 or later	
VB-C10 VB-C10R	Ver. 1.0 Rev. 26 or later	
VB150	Ver. 1.1 Rev. 41 or later	

Mote

- If using VB150 with multiple cameras, there are restrictions on frame rate.
 See your VB150 User's Manual for details (→ P. 1-25).
- This version of the Storage Server and Viewer do not support IPv6. Operate VB-C60 and VB-C500VD, VB-C500D using IPv4.
- The VB-C10, VB-C10R, and VB150 are not supported by VK-Lite.

System Environment

This information is as of September 2009. For the latest information, please access to Canon Web site.

Viewer

	Minimum Configuration		
CPU	Pentium 4 2.2GHz or faster (Pentium 4 3.4GHz or higher when using MPEG-4)		
Operating System	Windows XP Professional (SP2, SP3) Windows Server 2003 Standard Edition (SP2) Windows Server 2003 R2 Standard Edition (SP2) Windows Vista Business/Enterprise/Ultimate (SP1) Windows Server 2008 Standard Edition		
Memory	1GB or more		
Hard Disk	2GB or more		
Display	1024 x 768 or higher resolution for the effective display area Color display of 16 bits or more A high performance video card is recommended. In case of using PCI video cards, display performance may be reduced.		
Sound	Audio playback support is necessary for event notification alert sounds (→ P. 5-15).		

- * VK-Lite also supports Windows Vista Home Premium.
- * Only 32-bit Edition of Windows XP and Windows Server 2003 are supported.
- * 32-bit Edition/64-bit Edition of Windows Vista are supported.
- * 32-bit Edition/64-bit Edition of Windows Server 2008 are supported.

Storage Server

	Minimum Configuration	
CPU	Pentium 4 2.2GHz or faster (Pentium4 3.4GHz or higher when using MPEG-4)	
Operating System	Windows XP Professional (SP2, SP3) Windows Server 2003 Standard Edition (SP2) Windows Server 2003 R2 Standard Edition (SP2) Windows Vista Business/Enterprise/Ultimate (SP1) Windows Server 2008 Standard Edition	
Memory	1GB RAM or more For using more than 48 Camera Servers, 1.5GB or more required.	
Hard Disk	20GB HDD or more, SCSI or IDE, NTFS formatted	

- * The requirements for Storage Server will vary due to the operating environment (number of Camera Servers, setting of recording frame rate etc.). It is also dependent on pre-event recording settings. Please contact dealers that handle Canon products for further information.
- * VK-Lite also supports Windows Vista Home Premium.
- * Only 32-bit Edition of Windows XP and Windows Server 2003 are supported.
- * 32-bit Edition/64-bit Edition of Windows Vista is supported.
- * 32-bit Edition/64-bit Edition of Windows Server 2008 are supported.

Notes on Operating Environment

Notes on Use with Windows XP

If your Storage Server is installed to the PC on Windows XP SP2 or SP3 and your viewer is installed to another PC, it is necessary to change your [Windows firewall] settings for Windows XP SP2 or SP3.

* The following setting is not required if you install the Storage Server and Viewer on the same PC.

After installation of the Storage Server:

- 1. Click [Control Panel] from the Windows [Start] menu to launch the [Control Panel].
- 2. In [Control Panel], select [Windows Firewall]. If [Windows Firewall] is not shown, select [Security Center] and then select [Windows Firewall].
- 3. When the [Windows Firewall] dialog is shown, select the [Exception] tab and then click [Add Port].
- 4. In the [Add a Port] dialog, enter a name for the Storage Server, e.g., "VK-64/VK-16 Storage Server". And then enter the Port number as "80". Make sure the TCP protocol is selected and click [OK].
- 5. In the [Windows Firewall] dialog, your additional Storage Server is now listed. Make sure the check box is marked. Click [OK] to close the dialog.

Setting is now complete.

Notes on Use with Windows XP/Vista

In cases where you cannot access more than 10 camera servers due to power or network failures, the movie server's operations or viewer's configuration changes may take time or images may not be viewable including those on camera servers you can connect to.

Also, if the auto-switch interval is set to 20 seconds or less, images may not be displayed in the viewer.

Windows Server 2003/Windows Server 2008

The default setting of security level of Windows Server 2003/Windows Server 2008 for the Internet or intranet sites in Internet Explorer is [High].


Therefore, a content block dialog box is displayed when you access pages such as the camera server's top page or setting page, and commands cannot be carried out. To ensure normal operation, carry out the procedure below to register the site as a trusted site.

 When you access the Camera Server top page using Internet Explorer, the dialog box shown at below appears.



2. Click [Add], and then the [Trusted sites] dialog box appears.

If [Require server verification (https:) for all sites in this zone] is selected, clear the selection.



3. Check that the IP address of your camera server displayed in the [Add this Web site to the zone] box is correct, and then click [Add] to register the camera as a trusted site.


For more information on registration to the trusted sites, click [Learn more about Internet Explorer's Enhanced Security Configuration] in the dialog box shown in step 1 and see the summary provided.

If you have enabled the [Windows Firewall] settings, please see the "Notes on Use with Windows XP" (\rightarrow P. 1-12) and follow the instructions.

Additionally, even when a content block dialog box is not displayed, JavaScript may be disabled under standard security settings, limiting the available operations in the camera's settings page or the VB-C500/VB-C60 Viewer. JavaScript will be enabled automatically once trusted site registration is complete, so please carry out registration.

If the content block dialog box is not displayed, you can use the procedure below to display the dialog box for adding a trusted site.

- 1. On the [Tools] menu in Internet Explorer, click [Internet Options] to display the [Internet Options] dialog box.
- 2. Next, click the [Security] tab.
- 3. Select [Trusted sites], and click the [Sites] button.



Settings for registering Trusted sites are now complete.


Windows Server 2008

Enable Sound to Use Audio Functions

The sound function is disabled by default in Windows Server 2008.

To receive audio signals using the VB-C500/VB-C60 Viewer, follow the procedure below to enable sound function.

1. In the [Control Panel], click [Hardware and Sound].





If the [Control Panel] is set to [Classic View], double click [Sound].

2. Next, click [Sound].



3. The [Audio Service Not Running] dialog box is displayed. Click [Yes].



4. Finally, the [Sound] dialog box is displayed. In the [Playback] tab, confirm that an audio device is installed. (If no audio device is installed, check the user manual for your computer.)

Windows Vista/Windows Server 2008

When using VK-64/VK-16 on Windows Vista Business/Enterprise/Ultimate/Windows Server 2008, pay attention to the following restrictions.

Upgrade your PC

Please note that before upgrading your PC to Windows Vista/Windows Server 2008, you need to upgrade this software to v2.2, if the version is older than v2.2.


If you upgrade your PC to Windows Vista/Windows Server 2008 before upgrading the software to v2.2, you will not able to complete upgrade installation to v2.2. In this case, follow the procedure below.

- 1. Right click on the [Storage Server Configuration] icon on the desktop, then choose [Properties].
- 2. Click the [Compatibility] tab and check the [Run this program as an administrator] check box.
- 3. Double click the [Storage Server Configuration] icon to launch the Storage Server Configuration tool.
- 4. Click the [Stop Storage Server] button in the [Storage server status].
- 5. Click the [Retry] button on the installer wizard for VK version 2.2.

Warning dialog appeared when opening the Storage Server Configuration dialog

If User Account Control is enabled on Windows Vista/Windows Server 2008, the [User Account Control] dialog will appear when you launch the Storage Server Configuration tool.

Click the [Continue] button to launch the Storage Server Configuration tool.



Notes for when the Windows Firewall Function is Enabled

When the Windows Firewall function is enabled, carry out the same settings as in the Windows XP section of the Notes on Operating Environment.

Storage location of recorded video

On Windows Vista/Windows Server 2008, snap shots and video files cannot be saved into the Windows folder or the Program Files folder on the system drive.


Shadow backup

You cannot use shadow backup of Windows Vista/Windows Server 2008. So, if once you delete a configuration file of VK-64/VK-16, you cannot restore the file with shadow backup.(→ P. 7-7)

System Design Concept

System Configuration Example

When Viewing and Recording with one PC




Record video to the Storage Server Storage Server

Display live and recorded video *Viewer*

Load on PC may increase depending on the number of camera servers and recording schedule. Consider your system configuration referring to "Server Sizing Concept" (\rightarrow P. 1-20).

When Viewing and Recording with one Storage Server and Multiple Viewers




Mote

- If many Viewers accessing to the same Camera Servers and Storage Servers simultaneously, it will affect system performance.
- Installation of both Storage Server and Viewer on a single PC may cause a heavy load on your PC depending on the number of camera servers or recording schedule. If you use VK-64/VK-16 with many Camera Servers, install each application on different PCs. Viewing with a low capacity PC may take longer, the specified frame rate may not be achieved, recording frame rate may be lower, or recording may be interrupted (→ P. 1-21).

When using multiple Storage Servers and Viewers

One or more Storage Servers can be used on the same network and Viewer applications can be configured to play video from more than one Storage Server. For each Viewer, Master Storage Server (→ P. 1-19) needs to be specified for saving information such as zones and locations of cameras, as well as saving Viewer layouts created by the user.




Note

- You can operate VK-64/VK-16 with up to ten Storage Servers using any combination of VK-64 Storage Server and VK-16 Storage Server. Up to 192 Camera Servers can be operated.
- Up to 10 Viewers can be connected to a Storage Server at the same time.
- If the Storage Server and/or Viewer are installed on multiple PCs, you need to purchase the necessary license separately (→ P. 1-6).
- You can not use multiple Storage Servers with VK-Lite.

When using multiple Storage Servers

If multiple Storage Servers are being used, you should specify the Master Storage Server. A typical multiple Storage Server arrangement is shown below.



A master storage server is a server, which viewers connect to in the first place. Master storage servers store information about camera servers, locations, zones and viewer layouts, which range over multiple storage servers. Viewers extract those information from a master storage server.



- All of the Viewers within a system should use the same Storage Server as the Master Storage Server. This makes it possible to use the same Zones, Locations, and Viewer Layouts in all of the Viewers.
- Ensure if the Storage Server and Viewer installed to the PC is operated with correct daytime setting regularly. We recommend that you use NTP function to set the time for Storage Server automatically.
- Adjusting the time of Storage Server during recording may cause problems to the recording video.
- When multiple Storage Servers are operated, if the Storage Servers other than the Master Storage Server are stopped, it takes time to display the Configuration and Preferences screen (approximately up to 30 seconds).

When using Viewer alone

The Viewer can be used by itself without connecting to the Storage Server. Although there are some restrictions on functions such as recording and Event Search, Viewer-Only mode allows to view live videos.

Server Sizing Concept

Determine your server configuration (components and the number of units) depending on 1) required hard disk capacity and 2) video data volume per second.

1) Required hard disk capacity: Consider the required hard disk capacity based on continuous recording

with fixed frame rate, resolution, and quantity.

2) Video data volume per second: If the video data volume per second by server exceeds values shown

below, you should consider multiple servers or review the recording

conditions.

Mote

• Every operation environment of VK-64/VK-16 is different (due to different requirements and different hardware specifications) and the figures provided below are just for the reference.

• Data volume per drive should be less than 2TB.

Approximate Video Data Volume per Second

The recording performance of VK-64/VK-16 v2.2 is as follows.

 For dedicated Storage Server: Maximum amount of recorded data per server = 5.5 MB/sec or less (when using SCSI, SAS disk)

	VGA	QVGA	
JPEG	150 fps	440 fps	
MPEG-4	Total 44Mbit/sec.		

• For Storage and Playback Server: Maximum amount of recorded data per server = 3 MB/sec or less

	VGA	QVGA	
JPEG	90 fps	260 fps	
MPEG-4	Total 24Mbit/sec.		



Data-writing performance may be reduced than the approximate values given above depending on the hard disk or the RAID card in the PC.

Required Hard Disk Capacity

The size of the images varies depending on the configuration of the Camera Server (the settings for Quality and Resolution) and the complexity of the actual image.

Determining Required Hard Disk Capacity

Determine the required hard disk capacity as follows.

- 1. Determine the required number of Camera Servers and required video data size.
- 2. Select the Image Quality of each Camera Server.

The video quality improves in proportion to the set value, but the data volume also becomes larger.

- 3. Determine the frame rate for recording video (i.e., the number of frames per second).
 - For general security purposes, 1 to 2 fps is common. Higher frame rate requires more hard disk space.
- 4. Determine the recording period per day and duration to retain data.
- 5. After determining the conditions above, calculate the required hard disk capacity due to the video data size (in KB).
- 6. If you record audio, to calculate the amount of hard disk space required for the audio data. The data size for recording audio is 8 KB/s regardless of the type of Camera Server.

When determining hard disk sizes it is important to take into account that there needs to be considered about 10 to 20% additional room.

Example 1: JPEG recording

- Using 16 Camera Servers (VB-C60) for recording,
- With each camera set to Medium Size for video data size and Image Quality set to 3 (data size per 1 frame: 12.5KB),
- · Recording frame rate is set at 2 fps, and
- Data size per second is approximately 25 KB (= 12.5 KB x 2fps).
 Although actual data size depends on objects shot by each Camera Server, this calculation assumes the typical size shown above.
- Audio recording as also performed simultaneously on 2 of the Camera Servers.

For the above configuration, when JPEG images from 16 camera servers are being recorded continuously at 2 frames per second all day, every day, the required hard disk space is approximately 33GB per day (=25KB x 16 cameras x 60 seconds x 60 minutes x 24 hours = 34560000KB per day).

When audio is recorded by 2 camera server, the required hard disk space is approximately 1.3 GB per day (=8 KB x 2 units x 60 seconds x 60 minutes x 24 hours = 1382400 KB).

Example 2: MPEG-4 recording

- Using 8 Camera Servers (VB-C60) for recording,
- With each camera set to Medium Size (320 x 240) and Video Quality is set to 3,
- Recording frame rate is set at 30 fps, and
- Data size per second is approximately 150 KB.
 Although actual data size depends on objects shot by each Camera Server, this calculation assumes the typical size shown above.

For the above configuration, when MPEG-4 video from 8 Camera Servers are being recorded continuously at 30 fps all day, every day, the hard disk space required is approximately 99GB per day (=150KB x 8 cameras x 60 seconds x 60 minutes x 24 hours = 103680000KB per day).

* For the above figures please note that the bandwidth is calculated as 1000Kbps = 1Mbps, and the disk size as 1024KB = 1MB.

The following tables give some typical data sizes per frame (in kilobytes) for various combination of quality and resolution values referring to a VB-C500VD, VB-C500D, VB-C600, VB-C300 and VB-C50i.

However the actual data size may be different from the data size in the table below depending on the weather condition and complexity of the image. For example, images of an empty corridor would typically be smaller than these values and images of an intricate pattern such as a crowded shopping mall may be larger than these.

Example of frame size with VB-C500VD/VB-C500D/VB-C60* (JPEG)

Quality	Resolution		
	JPEG Small (160x120)	JPEG Medium (320x240)	JPEG Large (640x480)
1	3.5	9.6	27.5
2	4.0	11.0	31.7
3	4.4	12.5	35.8
4	5.6	16.4	47.8
5	15.8	52.7	171.4

(KB)

Example of bit rate with VB-C500VD/VB-C500D/VB-C60* (MPEG-4)

	Resolution and Frame Rate								
Quality	10fps		15fps		30fps				
	MPEG-4 Medium (320x240)			MPEG-4 Medium (320x240)	MPEG-4 Large (640x480)				
1	0.28	0.76	0.35	0.94	0.54	1.43			
2	0.39	1.08	0.50	1.30	0.78	2.02			
3	0.60	1.67	0.75	2.02	1.20	3.31			
4	0.69	1.93	0.91	2.43	1.38	3.98			
5	0.81	2.31	1.05	2.87	1.68	4.86			

(Mbps)

MPEG-4 data size may increase when recording the video of strenuous movement.

Example of frame size with VB-C300*

Quality	Resolution				
Quality	JPEG Small (160x120)	JPEG Medium (320x240)	JPEG Large (640x480)		
1	3.2	8.8	24.2		
2	3.7	10.2	28.3		
3	4.1	11.5	32.0		
4	5.3	15.4	43.2		
5	15.5	52.8	170.6		

(KB)

Example of frame size with VB-C50i*

The data size of VB-C50iR and VB-C50FSi is the same as VB-C50i's.

Quality	Resolution				
Quality	JPEG Small (160x120)	JPEG Medium (320x240)	JPEG Large (640x480)		
30	3.1	8.2	24.7		
40	3.6	9.7	29.8		
50	4.1	10.9	34.2		
60	4.6	12.5	40.3		
70	5.3	14.8	49.7		
80	6.5	18.8	64.9		
90	9.4	28.4	106.4		

(KB)

* All of the data in the previous page sizes are only rough guide, and may increase or decrease depending on the object being shot. Please be sure to confirm under the actual installation conditions before starting operations. Select [Video Information] from the [View] menu of the Viewer (bundled with the Camera Server) to check the data quantity per frame (VB-C300, VB-C50i, VB-C50iR, VB-C50FSi).

∏ Note

Please note that data size may increase enormously when video quality is set to 100 with the VB-C50i, VB-C50iR, VB-C50FSi, VB-C50Fi.

The size of audio data is 8 KB/s.

Sensor Event Recording and Motion Detection Recording Concept

Notes on Sensor Event Recording and Motion Detection Recording

- When an event, such as sensor input or motion detection, occurs, video data will be stored in the Storage Server as an operation record.
- As the number of stored operation records increased, the operation and search speed at event detection and response speed of viewers may be affected.

Notes on Motion Detection Recording

- The Motion Detection function detects motion where no motion occurred before.
 Do not use this function where the motion detection may operate too frequently, e.g., where many people pass through.
- Motion detection should be set on the Camera Server. If motion detection is set on the Storage Server, the processing load on the PC will increase, and this may have an effect on the storage performance. (except VB-C300)



See "Operational Guideline for Sensor Event Recording" (\rightarrow P. 6-6) and "Optimization of Motion Detection Recording (Index)" (\rightarrow P. 6-7) for details.

Storage Server Performance

<case 1:="" in="" jpeg=""></case>	<case 2:="" in="" jpeg=""></case>
Camera Servers: 24 units of VB-C60 Resolution: High (640 x 480) Quality: 3 Frame Rate: 10 fps	Camera Servers: 48 units of VB-C60 Resolution: Medium (320 x 240) Quality: 3 Frame Rate: 1 fps
[Recording] Example of Storage Server PC specifications CPU: Pentium 4 3GHz Memory: 1GB HDD: Please see "Important: Disk Space Management" (→ P. 3-17) (Sample specifications for 3-day storage: about 708 GB for each Storage Server) Three Storage Servers with the above PC specifications (one master Server, two slave Servers)	[Recording] Example of Storage Server PC specifications CPU: Pentium 4 3GHz Memory: 1GB HDD: Please see "Important: Disk Space Management" (→ P. 3-17) (Sample specifications for 14-day storage: about 693 GB) One Storage Server with the above PC specifications
[Live View, Recorded Video Playback] Example of Viewer PC specifications CPU: Pentium 4 3.8GHz Memory: 1GB Video graphics board: NVIDIA Quadro FX 1400	[Live View, Recorded Video Playback] Example of Viewer PC specifications CPU: Pentium 4 3.0GHz Memory: 1GB Video Graphics Board: On-chip board

- These data above are rough guide. As many factors can influence the actual performance possible (including networking equipment, disk write speed, complexity of camera image, etc), the actual performance of VK-64/VK-16 recording in a specific installation will vary. Please be sure to confirm under the actual installation conditions before starting operations.
- If there are many registered Camera Servers, it is recommended that you use two or more PCs or configure to use the Layout frequency.

Notes on Storage Server Operation

It is recommended to use the Storage Server exclusively for the VK-64/VK-16.

Be sure to avoid the following forms of operation.

• Using the Storage Server with a Web Server

As Storage Server, you cannot use a PC where Web server software such as Windows standard IIS (Internet Information Server) or Apache has been already installed.

Since the Storage Server uses the HTTP protocol to communicate with the Camera Server, therefore it may not work properly if other Web applications exist on the same platform.

The HTTP port number used by the VK-64/VK-16 should be fixed to "80".

• Using the Storage Server with a Database Server (e.g., SQL Server, Oracle)

If the hard disk is heavily loaded in database processing, recording may not work normally. Conversely, the database server may be affected by the VK-64/VK-16 when it need hard disk performance to complete its task.

Using the Storage Server with a File Server

Accesses to the hard disk may be too frequent and recording may not work normally. Also, the disk capacity for the VK-64/VK-16 may run short.

Using the Storage Server with other applications

The processing load of other applications may have a negative effect on the storage performance.

This software uses 3 ports: TCP 80/TCP 9080/TCP 10080. If you are running another application which uses the same ports on your PC at the same time, please use another port.

Notes on Viewer Sizing

Consider the following points when selecting the PC for viewer (installed).

Live-video viewing and recorded video playback performance of the VK-64/VK-16 largely depends
on the CPU and graphics board performance on the PC. The CPU performance affects image
capturing and video data generation, and the graphics board performance affects image drawing.

See the following example when selecting the PC for the viewer installed.

In this example, the OS is Windows XP Professional.

1. CPU: Pentium 4 3.0GHz, memory: 1GB, graphics board: Quadro FX570 When using the VB-C60 with Resolution=340 x 240 and Quality=3:

Total frame rate:

```
JPEG image---Max. 220 fps
MPEG-4 video---Max. 180 fps
```

2. CPU: Pentium 4 3.6GHz, memory: 1GB, graphics board: Quadro FX1700 When using the VB-C60 with Resolution=340 x 240 and Quality=3: Total frame rate:

```
JPEG image---Max. 260 fps
MPEG-4 video---Max. 210 fps
```

 CPU: Pentium 4 3.8GHz, memory: 1GB, graphics board: Quadro FX1700 When using the VB-C60 with Resolution=340 x 240 and Quality=3: Total frame rate:

JPEG image---Max. 280 fps MPEG-4 video---Max. 240 fps



- The total frame rate is calculated as: Number of Camera Servers in the Viewer window x Frame rate. That means, with 10 Camera Servers and 10 fps frame rate, the total frame rate is 100 fps.
- Note that the total frame rate above varies depending on the combination of the PC and graphics board. It is also affected by other applications (e.g., anti-virus application) running on the same PC.
- When displaying MPEG-4 video in VGA, the maximum frame rates are the one-forth of the above frame rates.

Network Bandwidth Concept

You should consider the network bandwidth when recording video or viewing live video from the network

The network bandwidths should be calculated separately for recording and live viewing.

Example

With one recording server (QVGA, 1 fps) and two live viewing servers (QVGA, 5 fps):

· Bandwidth for recording

12.5 (KB/frame) x 1 (frame/sec) x 8 (bits) = 100 Kbps

• Bandwidth for live viewing (per server)

12.5 (KB/frame) \times 5 (frame/sec) \times 8 (bits) = 500 Kbps

Therefore, required network bandwidth is calculated as follows:

100 Kbps x 1 + 500 Kbps x 2 = 1100 Kbps = Approx. 1.1 Mbps

Note that the line speed unit is bps (bits per second).

VK-Lite

VK-Lite is bundled with VB-C500VD, VB-C500D and VB-C60. This is a simplified version of the Network Video Recorder VK-64/VK-16. The differences in functionality between the VK-64/VK-16 and VK-Lite product versions are summarized below.

Functional Limitations in VK-Lite

- The maximum number of cameras that can be registered is 4 units.
- It is recommended that 8 or less video windows are displayed in the Viewer Window (a warning is displayed if 9 or more video windows are displayed).
- The maximum frame rate is as follows.

Video recording 5 fps or less (JPEG)

Record now Fixed at 5 fps

- The reduce frame rate under high load is fixed on.
- The maximum file size is fixed at 1 GB per day, and cannot be changed.
- The supported cameras are as follows.

VB-C500VD, VB-C500D, VB-C60, VB-C300, VB-C50i, VB-C50iR, VB-C50Fi, and VB-C50FSi

- The VK-Lite Viewer cannot connect to VK-64/VK-16 Storage Server.
- The VK-64/VK-16 Viewer can connect to VK-Lite Storage Server.

However, older versions of the VK-64/VK-16 Viewer cannot connect to VK-Lite Storage Server.

Mote

You cannot connect to the following cameras.
 VB-C10, VB-C10R, VB150

Functions that cannot be used in VK-Lite

- · Storage Server
 - Recording to NAS
 - MPEG-4 recording
 - Motion detection recording
 - · Sensor recording
 - · A Special day recording
 - Send mail on event function
 - · Customization of event priority
 - Connection via HTTP proxy
 - Remote trigger
- VK Viewer
 - Layout frequency
 - Simultaneous monitoring of multiple storage servers
 - Designated schedules
 - Connection via HTTP proxy
 - Registration of slave storage servers
 - Viewer control API



Functions that cannot be used with the VK-Lite Viewer or VK-Lite Server are indicated by the following marking in the text.



Other

- Windows Vista Home Premium is also supported in addition to the VK-64/VK-16 system environments (→ P. 1-10).
- It is possible to upgrade VK-Lite to VK-64/VK-16.

Specification Comparison of VK-64/VK-16 and VK-Lite

This section explains what you need to know before using the VK-64/VK-16, and the required operating environment and considerations when designing a system.

Type	Main functional limitations	VK-64/VK-16 v2.2	VK-Lite v2.2	
	Max. number of camera servers	64 / 16	4	
Camera server connection	Available camera servers	VB-C500VD, VB-C500D, VB-C60, VB-C300, VB-C50 series, VB-C10/R, VB150	VB-C500VD, VB-C500D, VB-C60, VB-C300, VB-C50 series	
	Automatic camera server search	✓	✓	
	Recording format	JPEG, MPEG-4	JPEG only	
	Max. recording frame rate	30 fps ^{*1}	5 fps	
	Video recording mode	Normal Schedule recording (Continuous recording, Sensor event recording, Motion detection recording) Special Day Schedule recording Manual recording	Normal Schedule recording (Continuous recording) Manual recording	
	Max. file size setting	available 32~1024MB, 1~24 hours	Fixed 1GB/day (1024MB)	
Storage Server	Max. retained history of recorded video	999 weeks*1	12 weeks (90 days)	
	Audio recording / playback	V	~	
	Recording to NAS servers	✓	-	
	Other functional limitations	-	Following functions are unavailable. Sending mail when an event occurs Customizing priorities of events Connection via HTTP proxy Remote trigger	
	Live video format	JPEG, MPEG-4	JPEG, MPEG-4	
	Max. displaying frame rate	30 fps ^{*1}	30 fps*1	
	Max. number of video windows on the viewer	Unlimited*1	8 or less is recommended.	
	Two-way audio	✓	V	
Viewer	Registration of multiple storage servers*2	V	-	
	Layout Sequences*3	✓	-	
	Other functional limitations	-	Following function is unavailable. Connection via HTTP proxy	

^{*1} Operational limits apply depending on the number of cameras, the PC performance and hard disk capacity, and the amount of network traffic.

^{*2} In case of using VK-64/VK-16 with multiple storage servers, you can unify management of cameras registered to each storage server and the recorded data, if you set one master storage server. When connecting to each storage server using VK-Lite viewer, you need to switch connection one by one.

^{*3} Layout Sequences is a function to switch displayed viewer windows at set intervals.



Installation

Chapter Overview

This chapter explains how to install VK-64/VK-16.

Setting up the Camera Servers

Firstly set up Camera Server. For connection in detail, see the manual for Camera Server.

Install the Storage Server and Viewer



Before the installation, read Chapter 1 and "Preparation and Precaution" (→ P. 2-7) carefully.

When you install VK-64/VK-16, icons for two applications composing VK-64/VK-16 is created on the desktop.





Server Configuratio



- See Chapter 3 for how to use the Storage Server.
- See Chapter 4 for how to use VK Viewer.
- The following icons are displayed if VK-Lite is installed.



Storage Server Configuratio



Viewer v2.2

Installation Procedures

Note


- Types and number of license has been determined for VK-64 and VK-16. If you want to add the Storage Server or Viewer, you need to purchase necessary software (→ P. 1-6).
- The hard disk where the software will be installed should be formatted in the NTFS (→ P. 2-7).

Start up the Installer

1. To start installing VK-64/VK-16, insert the installation CD-ROM into the CD drive, and then the Welcome screen appears. Click [Next] to continue.

If the installer does not automatically launch, open the CD-ROM directory in Explorer and double-click v22setup.exe. Then, installation process starts.

To start installing VK-Lite, double-click VKLiteInstall.exe in the APPLICATIONS folder on the VB-C500VD/VB-C500D/VB-C60 Setup CD-ROM.



The [Software License Agreement] screen appears. Read the agreement carefully.Click the radio button, [I accept the terms in the license agreement] and then click [Next] to continue.




- 3. Enter your License Key(s) and click [Next] to install VK-64/VK-16. Your License Key is indicated on the "About License Key" included in the package.
 - * VK-Lite that comes with VB-C500VD, VB-C500D and VB-C60 has a license for one Storage Server and one Viewer.





No License Key registration window appears for VK-Lite installation.

- 4. Depending on your entered License Key for VK-64/VK-16, one or both of the following applications shown below:
 - Viewer
 - Storage Server





You cannot change the application to be installed in this window. To change the application, you need to go back to the registration window and enter the license key again.

For VK-Lite, both of the following applications are installed.

- Viewer
- Storage Server

When you need to install either one of the above, right-click on the application icon which you will not install, and choose [This feature will not be available].

It is recommended not to change the designated installation directory. Click [Change] to choose another installation path if necessary, and then select the directory to install the software.


Click [Next] to continue.



Click [Space] and then a list of drives is shown. And also the amount of required disk space for the installation of VK-64/VK-16/VK-Lite.

5. Click [Install].

The installation process begins, and a progress bar is displayed.



6. When the [InstallShield Wizard Completed] screen is displayed, click [Finish].

Installation is now completed.



Upgrade from Version 1.0, 1.1, 1.2, 1.3, 1.4, 2.0 and 2.1

If you upgrade the Viewer from an older version, all the settings are taken over to the new version and video data recorded with older version can be played back with Version 2.2. It is recommended to confirm your settings after the upgrading.

For the details, see "Upgrade VK-64/VK-16" (→ P. 8-3).

Note

- If you are using VK-64/VK-16 with NAS server, you need to set up log-on settings again after upgrading VK from v1.3, 1.4, 2.0, 2.1 to v2.2.
- Version 2.2 of the Viewer is able to connect to versions 1.2, 1.3, 1.4, 2.0 and 2.1 of the Storage Server. All
 of the versions are able to be selected as the Master Storage Server. However, the following functions are
 specific to version 2.2, and cannot be used on previous versions of the Storage Server.
- VB-C500VD registration
- Audio-related settings (Can be used with version 2.0, 2.1 Storage Servers)
- Retrieving summary information from a Storage Server (Can be used with version 2.0, 2.1 Storage Servers)
- Viewer v2.2 cannot connect to the Storage Server v1.0 or v1.1.
- Older version of Viewer cannot connect to the Storage Server v2.2.
- Version 2.2 of the Storage Server can continue to use the video data and storage settings from previous versions.
- When upgrading from any versions before 1.1.2.27, you need to set motion detection (→ P. 4-46) again.
 You can check your version information from the version information (→ P. 10-5) of the Storage Server and the Viewer.

Preparation and Precaution

Use NTFS-formatted hard disk

The hard disk where the software will be installed and video data will be stored should be formatted in the NTFS.

You can convert the current hard disk into the NTFS format using the following command at the command prompt.

convert <Name of the drive>:/fs:ntfs

Example: To convert Drive C into the NTFS format:

convert c:/fs:ntfs



Select [All Programs], [Accessories], and [Command Prompt] from the [Start] menu to display the command prompt. If you press the [Enter] key following the command shown above, a series of questions appears, then conversion starts. Reboot the PC after the process completes conversion. Any data on the hard disk is not lost by conversion.

Stop other applications

You should stop other applications including anti-virus program before starting installation.

3

Storage Server Configuration Reference

Chapter Overview

The Storage Server can record videos and events (sensor input and motion detection) data from multiple camera servers.

This chapter explains how to set the installed Storage Server to use the storage server.

Use the [Storage Server Configuration] dialog to set the Storage Server.

In the [Storage Server Configuration] dialog, you can configure settings for disk management, event management, event notification, and user management.

[Settings] Tab

In the [Settings] tab, specify the Storage Server name, Proxy Server, and recording options.

[Event] Tab

You can set the Storage Server to send an e-mail to the user when an event has occurred.

In the [Event] tab, specify the priority for each event type.

[Event Notification] Tab

In the [Event Notification] tab, configure the settings for sending an e-mail when an event has occurred.

[User Management] Tab

In the [User Management] tab, add users and assign privileges to them.

[Storage Server Configuration] Dialog

How to Start-Up

Double-click the [Storage Server Configuration v2.2] desktop icon.




Alternatively, from the Windows [Start] menu select: [All Programs] > [WebView Livescope] > [Network Video Recorder VK Series v2.2] > [Storage Server Configuration v2.2].

If the [Require authentication when starting this tool] is selected (→ P. 3-27), the [Login] dialog appears.



In this case, enter your user name and password, and click [Login].

If User Account Control is enabled on Windows Vista/Windows Server 2008, the [User Account Control] screen will appear.



In this case, click the [Continue] button.



To configure the Storage Server, you should log into Windows with the Windows Administrator privilege.

Screen Configuration


The [Storage Server Configuration] dialog has the following four tabs.

- [Settings] Tab
- [Events] Tab
- [Event Notification] Tab
- [User Management] Tab

[Settings] Tab

In the [Storage Server Configuration] dialog, [Settings] tab allows you to configure these items below.

- Storage Server Name
- Proxy Server
- · Recording options






VK-64/VK-16 can save video data on the network drive.

[Events] Tab

You can set the Storage Server to send an e-mail to the user when an event has occurred.

In the [Storage Server Configuration] dialog, [Events] tab allows you to configure the priority for types of the event.

E-mails are sent according to the priorities set in the [Events] tab.



Note

- Events associated with [Recording engine started], [Data file set], [User log in], and [Failed to map a network drive] do not appear in a Viewer's Timeline (→ P. 5-48), [Live Events Log] (→ P. 5-56), or [Event Search] Dialog (→ P. 5-58).
- The priority of an event created by a manual recording using [Record Now] (→ P. 5-52) will always be Priority 1. It cannot be changed from this dialog above.

[Event Notification] Tab


In the [Storage Server Configuration] dialog, [Event Notification] tab allows you to configure the setting of the e-mail sent to the user when the event occurs.

E-mails are sent according to the priorities set in the [Events] tab.

Example event notification e-mail

An event of priority 3 occurred on 12/05/2006 at 15:15:17 +1000.

Parking Lot 1: Sensor on





You can only register one e-mail address in the To Address field.

If you want to send the e-mail to multiple addresses, use a group address.


[User Management] Tab

In the [Storage Server Configuration] dialog, [User Management] tab allows you to set up users and their privileges.

[User Management] tab allows you to configure the following privileges:

- Administrator
- Not Administrator (Operator)

Administrator has access to the Viewer including Camera Server setup, recording schedules and Viewer setup.



Users who have Operator Status cannot configure, register and change Camera Servers, or configure and change recording schedules.

By default, a user called "admin" is created. The password is "NVR". It is strongly recommended that this should be changed after installation.

It is necessary to set up users on all Storage Servers. A particular user should be set up to have the same password on each Storage Server.

Set the [Settings] Tab


In the [Storage Server Configuration] dialog, [Settings] tab allows you to configure the items below.

- Storage Server name
- Proxy Server
- · Settings for storing recorded video
- Start and stop of Storage Server
- Logon Account for Storage Server

How to Display the [Settings] Tab

Double-click the [Storage Server Configuration] desktop icon.

The [Storage Server Configuration] dialog appears and the [Settings] tab is displayed.



How to set the [Settings] Tab

Changing the Storage Server name

Enter a new name in [Storage Server Name] to change the Storage Server name (You can use up to 20 characters).





It is recommended to use an easy-to-understand name if you are using multiple Storage Servers.

Enter the Storage Server Proxy Address VK-64/16

If the Storage Server needs to access Camera Servers via proxy server, you may need to configure proxy settings.


- * See P. xiii if you use a proxy server.
- 1. In the [Storage Server Ploxy] field, tick the [Enable the following ploxy server] box.
- 2. Enter the [Proxy server] address and [Port].



For more information on proxy server usage, contact your Camera Server administrator.

Enter [Recorded Video Settings]

1. [Maximum retained history] - Check the [Maximum retained history] option and enter a value from 1 to 999 and then select [Days] or [Weeks] from the pull-down menu.



2. VK-64/16

[Maximum file size / duration] - Check the [Maximum file size / duration] option, enter a value, and select [MB] or [Hours]. You can enter 32 - 1024 for [MB] and 1 - 24 for [Hours]. If you do not enter a value, 1024 MB or 24 hours is used for the Maximum file size/duration value.

3. [Low disk space warning level] - Enter a percent value.

When the remaining space falls below the specified value, the event will be displayed and a notification will be e-mailed (\rightarrow P. 3-5, P. 3-23).

4. VK-64/16

[Reduce recording frame rate when disk is under high load] - When disk is highly loaded, recording frame rate is temporarily reduced to prevent the recording from stopped. See Chapter 6 for details. This function is available for JPEG video recording. It cannot be used for MPEG-4 video recording (VB-C500VD, VB-C500D, VB-C60).

🄃 Tip

If [Reduce recording frame rate when disk is under high load] is selected, you will receive an event notification such as "Effective Recording rate (< recording rate before change> \rightarrow < recording rate after change> %)" when the recording frame rate drops.

Ex. Effective Recording rate (100.0 → 90.0 %)

Mote

When the free disk space has fallen below the value specified in the [Low disk space warning level] field, an event occurs and an event notification mail is sent. Also, if the used disk space exceeds the value specified in the [Maximum disk space used] field, recorded video will not be saved until the required free disk space is secured. See P. 3-17 for the disk space management.

Select [Disk Drive Settings]

- 1. [Drive] Select the disk drive to configure, from the drop-down menu.
- 2. [Maximum disk space used] Check the box and enter a value in Megabytes (MB) or Gigabytes (GB), for example, "50".

This establishes the maximum disk space used for all video files on the specified drive.



3. [Add Network Drive] - Add a disk drive on the network used as the network drive.

The added network drive is shown on the [Drive] drop-down menu.

4. [Delete Network Drive] - Delete an added network drive.

Adding/Removing a Network Drive VK-64/16

By adding a network drive, you can save recorded video data on a network drive such as NAS (Network Attached Storage) in addition to the internal HDD.

If you add a network drive in the [Storage Server Configuration] window, the drive will be added to the list of the pull-down menu of the [Add Camera Server] and [Edit Camera Server] dialog (→ P. 4-18, P. 4-24).




Use recommended NAS servers with Windows Storage Server 2003 or Windows Storage Server 2003 R2.



When using the Storage Server with the local system account, the [Add Network Drive] and [Delete Network Drive] buttons are disabled.

To add a network drive


1. Click [Add Network Drive].



2. The [Add Network Drive] dialog appears.


Select a drive to add as a network drive and enter a path assigned to the drive.

You can also enter a path automatically by selecting a folder.



When selecting a folder with [Browse]

Click [Browse], select a folder where you want to save recorded video data in the [Browse for Folder] dialog. Click [OK] to enter the path of the selected folder in the path field.



3. Enter the user name and password to access the network drive in the respective fields, and click [OK].

Be sure to use different user name and password from the logon user name and password for the local system account.

If addition is successful, the added drive appears on the drive selection pull-down menu.

To remove a network drive

- Click [Delete Network Drive].
- 2. Select a network drive and click [OK] to delete the selected drive from the Storage Server.



👍 Note

About Network Drive

VK-64/VK-16 can record videos on a drive on the network. The drive type is shown at the head of the [Drive] drop-down menu as "Internal disk: [local], Network drive: [network]".

- About Video Recording Operation If disk space is not enough to cover the specified value configured with [Maximum disk space used], the retained duration of recorded video may be shorter than the specified period or the recording may be temporarily stopped. Please be sure to perform sufficient tests before starting operations.
- For details about disk space management on the Storage Server, see "Important: Disk Space Management" (→ P. 3-17).
- Windows does not allow a user who has logged in with a [local system account] (used for normal service management) to add a network drive. The [Add network drive] and [Delete network drive] items are disabled while you are logging into Windows with a [local system account]. To set the network drive, click [Stop Storage Server] to stop the Storage Server, and click the [Logon settings] and switch to an account which is allowed to use the network drive (i.e., account with Windows' Administrator and [Logon As Service] privileges). see "[Logon As Service] Privilege" (→ P. 3-15).
- You cannot use a UNC path or removable disk when adding a network drive.
- If you add or delete a network drive, the Storage Server program will reboot.
- Multiple Storage Servers cannot use the same network drive simultaneously.
- Single network drive cannot allocate to multiple drivers.
- If the selected network drive cannot be accessed because the network is disconnected, the selected drive is powered off, or you entered a wrong path, the following error message will appear.
 - "Network path cannot be found."
- While the network drive is not operating (e.g., due to network disconnection), video will not be recorded until the drive recovers.
- If a storage server is booted when the storage server is unable to connect to a NAS server, video image data won't be written to or recorded data won't be read from NAS server even after the NAS server recovers. In such case, reboot the storage server.

Start or Stop the Storage Server Program

Click [Stop Storage Server] to stop the Storage Server.

Click [Start Storage Server] to start the Storage Server.





If you need to stop the Storage Server Program, you should inform all users connected to the storage server before you stop the storage server.

Change the [Logon settings]


1. If you need to log onto the Storage Server with another account when using a network drive, click [Stop Storage Server].

After the Storage Server stops, click [Logon settings].

The [Log on as] dialog appears.



2. If you are logging onto the Storage Server with a [Local System account], select [Local System account]. If you are log onto the Storage Server with another account, enter the account name in [This account] and password in [Password] and confirm password.



- 3. Click [OK].
- 4. Click [Start Storage Server] to start the Storage Server with the specified account.



If you are using VK-64/VK-16 with NAS server, you need to set up log-on settings again after upgrading VK from v1.3, v1.4, v2.0 or v2.1 to v2.2.

Message

When you have changed items affecting recording settings:

When you click [Apply] or [End], the following message will appear.

"An item which affects recording settings was changed. Please inspect the "Record Settings Summary" dialog on the Recording Schedules window to check the effects of the change."

When you have changed the [Maximum retained history] setting:

When you click [Apply] or [End], the following message will appear.

"The new retained history settings may result in the deletion of some existing video files. Do you wish to continue?"

When you have added or deleted a network drive:

When you click [Apply] or [End] before restarting the storage server, the following message appears.

"Drive use settings have changed. Do you wish to restart the recording server?"

[Logon As Service] Privilege


When you want to add the [Logon As Service] privilege to an existing Windows account so that you may be able to configure network drive settings, perform the following steps before configuring the [logon settings].

1. Click [Control Panel], [Performance and Maintenance], [Administration Tool], and [Local Security Policy] from the Windows' [Start] menu.

The [Local Security Policy] dialog appears.

- 2. Select [Local Policy] and [User Rights Assignment] from the tree to the left.
- 3. Double-click [Logon as Service] from the list to the right.

The [Log on as a service Properties] dialog appears.



4. Click [Add User or Group].

The [Select Users or Groups] dialog appears.



5. Enter the Windows account name in the [Enter the object names to select] field.

Enter or change the object name, location, and detail settings as required.

Be sure to enter a Windows account with Administrator privileges.



6. Click [OK].

The [Log on as a service Properties] dialog reappears.

7. Click [OK].

The [Local Security Settings] dialog reappears.

8. Close the [Local Security Settings] dialog.

Important: Disk Space Management

Disk Space Management Level

The Storage Server monitors the remaining disk space to check the current disk space management level and takes a measure according to the current level.

- 1. [Low disk space warning level]
- 2. Threshold Level
- 3. Limit Level

Administrator can set the [Low disk space warning level] 1. using the Low disk space warning level field in the [Settings] tab.

The Storage Server calculates the values for Threshold Level 2. and Limit Level 3. based on various conditions and settings.


Handling at Each Level

The Storage Server performs the following when the disk space reaches each level.

In case of [Low disk space warning level]

The Storage Server generates an event when the disk space available for recording (i.e., free space from the Maximum disk space used value) has fallen down to a certain level.

If the [Maximum disk space used] field is not set, the entire drive capacity of the drive specified in the [Drive] field is considered to be the maximum disk space used.



Note


The event notification e-mail is sent when the priority specified for the [Low disk space warning level] option in the [Events] tab of the [Storage Server Configuration] dialog is equal to or higher than the priority specified in the [Event Notification] tab. See P. 3-21 and P. 3-23 for how to set the [Events] and [Event Notification | tabs.

Tip

Event notification allows early control by an administrator to avoid problems due to running out of disk space (for example, removing unnecessary recording schedules).

In case of Threshold Level

The Storage Server continues recording video; however, it starts deleting the video files from the oldest one, and generates an event.






Old video files may be deleted even if these are within the [Maximum retained history] period. However if the oldest file is currently used in the Viewer (for example for playback of recorded video), it would not be deleted and the next oldest file will be deleted instead. Deletion will continue until the free space rises above this threshold again.

In case of Limit Level

See Chapter 7 for saving files.

The Storage Server stops recording video when the free disk space goes down to this level, and generates an event.

When the free disk space increases above this level by deleting old video files, the Storage Server resume recording video and generates an event.



[Low disk space warning level] Calculation Method

The [Low disk space warning level] occurs when the Storage Server fulfills the condition 1. or 2. below.

1. When the Storage Server disk space used exceeds the following value:

 $M \times (100 - A)/100$

M: Value for [Maximum disk space used]

A: Value for [Low disk space warning level]

Example: In case of the value for [Maximum disk space used] is 100 GB and the value for [Low disk space warning level] is 10%, the Storage Server reaches the [Low disk space warning level] when the remaining free disk space becomes 10 GB or less.

2. When free disk space falls below the following value:

Disk capacity x A/100

A: Value for [Low disk space warning level]

Example: In case of the value for disk capacity is 80 GB and the value for [Low disk space warning level] is 10%, the Storage Server reaches the [Low disk space warning level] when the remaining free disk space becomes 8 GB or less.



If other applications are also using the same hard disk, you need to review the condition 2). Even if the Storage Server uses a small quantity of disk space, it may reach the [Low disk space warning level] because other applications has consumed disk space.

Threshold Level Calculation Method

The Threshold Level occurs when the Storage Server fulfills the condition 1) or 2) below.

- 1. When the Storage Server disk space used exceeds the following value:
 - a. When [Maximum disk space used] is set 384 MB or more, [Maximum disk space used] 96MB
 - b. When [Maximum disk space used] is set 384 MB or less, [Maximum disk space used] x 3/4
- 2. When free disk space falls below the following value:

(Number of Camera Servers + 1) x 32MB + 96MB

Limit Level Calculation Method

The Limit Level occurs when the Storage Server fulfills the condition 1. or 2. below.

- 1. When the Storage Server disk space used exceeds the following value:
 - [Maximum disk space used]
- 2. A When free disk space falls below the following value:

(Number of Camera Servers + 1) x 32MB

Calculation Example for Each Level

Disk Drive	Disk Capacity	Free Disk Space	Max. Disk Space Used	Camera Server No.
C Drive	100GB	50GB	40GB	19 units
D Drive	Drive 200GB 200GB		200GB	19 units

The following is a table of values for each level calculated based on the examples above.

Disk Drive		Low Disk Warning Level		Threshold Level	Limit Level
C Drive	1. 2.	40GB x (100-10) / 100=36GB 100GB x 10 / 100=10GB	1. 2.	40GB-96MB= 39.904GB (19+1) x 32MB+96MB= 736MB	 40GB (19+1) x 32MB= 640MB
D Drive	1. 2.	200GB x (100-10) / 100=180GB 200GB x 10 / 100=20GB	1. 2.	200GB-96MB= 199.904GB (19+1) x 32MB+96MB= 736MB	 200GB (19+1) x 32MB= 640MB

∏ Note

- Threshold Level can be used as a protective level to avoid achieving Limit Level. It is recommended that you take measures when [Low disk space warning level] event notification is generated, such as deleting unnecessary video files.
- Storing video data above the Threshold Level increases load over the Storage Server and may cause recording interruption.
 - It is strongly recommended to use the Storage Server below the Threshold Level.
- See "Operation Guideline for Recording and Viewing" (→ P. 6-5) for detailed of operation.
- If e-mail notification for each levels is selected, the system can be configured to provide e-mail notifications when one of these levels is reached (→ P. 3-23).
- The requirements of Threshold Level may be achieved before the requirements of [Low disk space warning level] are satisfied, depending on circumstances. For example, large numbers of cameras with limited disk capacity may bring a larger value for (Numbers of camera +1) x 32 MB + 96 MB, compared with the value of Disk capacity x [Low disk space warning level]/100.

Set [Events] Tab VK-64/16

[Events] tab in the [Storage Server Configuration] dialog allows you to specify event priorities.

If you have configured the event notification e-mail settings, e-mails are sent based on the priorities set in the [Events] tab.

How to Display the [Events] Tab

Double-click the [Storage Server Configuration] desktop icon.

The [Storage Server Configuration] dialog appears and the [Settings] tab is displayed.

Click the [Events] tab to open it.



How to Set the Events Tab

Set the Priority for the Event

Select the priority for the event from drop-down menu for each setting item.

Item	Setting
Recording engine started	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
Remote trigger	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
Recording	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
Data file set	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
User log in	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
Low disk space warning	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
Low disk space deletion	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
Low disk space rec. suspended	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
Camera Server Connection error	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
Change recording frame rate	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest
Failed to map a network drive	1. Highest, 2. High, 3. Medium, 4. Low, 5. Lowest

Values shown in bold are the initial setting priority.



- Events associated with [Recording], [User log in], and [Failed to map a network drive] do not appear in a Viewer's Timeline (→ P. 5-48), [Live Events Log] (→ P. 5-56), or [Event Search] Dialog (→ P. 5-58).
- To detect such a event, set the e-mail notification using the [Event Notification] tab (→ P. 3-23).

Set the [Event Notification] Tab VK-64/16



[Event Notification] tab in the [Storage Server Configuration] dialog allows you to configure.

Configure the e-mail notification settings based on the priorities set in the [Events] tab.

How to Display the [Event Notification] Tab

Double-click the [Storage Server Configuration] desktop icon.

The [Storage Server Configuration] dialog appears and the [Settings] tab is displayed.


Click the [Event Notification] tab to open it.



How to Set the [Event Notification] Tab

Set the Event Notification Priority

- 1. Check the [Send email when events are recorded] option and select the priority level for sending e-mails from the [Priority] drop-down menu. Events of the setting priority and above will lead to e-mail notification.
- 2. Enter a subject in the [E-mail subject] line (e.g., "Immediate Action Required"), recipient's address in the [To Address]: line, and sender's address in the [From Address]: line.






You can enter each of the subject, recipient's address, and sender's address in up to 100 characters.



You can only register one e-mail address in the [To Address] field. If you want to send the e-mail to multiple addresses, use a group address.


3. Enter the host name or IP address of the [SMTP server] in SMTP Server and port number in [Port].



Note

Enter the host name in up to 255 characters.

4. If you wan to use POP-before-SMTP for user authentication, check the [Enable authentication (POP-before-SMTP)] option, and enter the user name used for authentication in [User Name] and password in [Password]. Also, enter the host name or IP address of the POP server in [POP Server] and port number in [Port].



Mote

- Enter the user name in up to 100 characters.
- Enter the password in up to 20 characters.
- Enter the host name in up to 255 characters.

🄃 Tip

If this function is enabled, the Storage Server will attempt to perform a POP login before sending e-mail that may be required for some SMTP servers.

Example event notification e-mail

An event of priority 3 occurred on 12/05/2006 at 15:15:17 +1000.

Parking Lot 1: Sensor on

Set [User Management] Tab

[User Management] tab in the [Storage Server Configuration] dialog allows you to set up users and their privileges.

How to Display the [User Management] Tab

Double-click the [Storage Server Configuration] desktop icon.

The [Storage Server Configuration] dialog appears and the [Settings] tab is displayed.

Click the [User Management] tab to open it.



Administrator and Operator Status User

Administrators can access to the Viewer to perform Camera Server setup, recording schedules and Viewer setup.

Operator Status Users can only access the Viewer windows (→ P. 5-13) created by Administrator. Also, they only can access to live video and recorded video on Storage Servers they have permission to access.

Note

- Users who have Operator Status cannot configure, register and change Camera Servers, or configure and change recording schedules.
- By default, a user called "admin" is created. Its password is "NVR". It is strongly recommended to change
 the user name and password after installation.
- It is necessary to set up user settings on all Storage Servers. A particular user, who operates multiple recording servers, should be set up to have the same password on each Storage Server.

How to Set the [User Management] Tab

Add a User

1. Click [Add] on the [User Management] tab.

The [Add User] dialog appears.

- 2. Enter the user's [User Name] (up to 20 characters, including alphanumeric letters and underscore "_").
- 3. Enter the user's [Password] (up to 20 characters, including alphanumeric letters and underscore "_"). Reenter the password you have entered in the [Confirm Password] field to confirm it.
- 4. Click [OK].

The dialog closes and the new user is displayed in the User List.

Change User to Administrator

- 1. Check the [Administrator] option of a user in the User List to enable the user to have the Administrator privileges. Do not check the option if you do not want to enable the user to have the Administrator privileges.
- 2. Click [Apply] to save changes.



The VK-64/VK-16 Administrator status is not related to the Windows Administrator status.

Change User Password

- 1. Click to select a user in the User List to change the password.
- 2. Click [Edit] button below in the user list to bring up the [Edit User] dialog.
- 3. Enter the user's new password into the [Password] (up to 20 characters, including alphanumeric letters and underscore "_"). Re-enter the new password you have entered in the [Confirm Password] field.
- 4. Click [OK].

The new password is saved.

Delete a User

- 1. Click to select a user in the User List to delete it.
- 2. Click [Remove].

The user is deleted.

Request User Authentication at Tool Startup

Check the [Require authentication when starting this tool] if user authentication is required when launching the tool. If this option is selected, the [Login] dialog appears before the [Storage Server Configuration] dialog appears.

Require authentication when starting this tool



Register Camera Server and Set Recording Schedule

Chapter Overview

This chapter explains how to store Camera Servers registration necessary for creating recording schedules on the Storage Server, as well as the procedure to create recoding schedules.

To store the Camera Servers registration and create recording schedules, launch the VK Viewer and use the [Camera Summary] window and [Recording Schedules] window under the [Configuration and Preferences] screen.

Launch VK Viewer and Display the [Configuration and Preferences] Screen

How to Launch VK-64/VK-16

Double-click the [VK Viewer v2.2] desktop icon.



Alternatively, from the Windows [Start] menu select: [All Programs] > [WebView Livescope] > [Network Video Recorder VK Series v2.2] > [VK Viewer v2.2].

The connect option menu (Start-up Screen) for Storage Server is displayed. Select [Master Storage Server] option and click [Connect].

Start-up Screen



[localhost]

Connects to Storage Server and starts the Viewer. Select this option to use the local PC where Viewer is installed as the Master Storage Server.

[Use IP address]

Connects to Storage Server and starts the Viewer by specifying its IP address. Select this option when the Storage Server and the Viewer are installed on separate PCs.

[Not use Storage Server]

Select this option to use the Viewer only without connecting to a Storage Server.



If you want to add a Storage Server to the connect option menu, login the desired Storage Server by specifying its IP address and click [Add Storage Server] in the [Viewer Settings] window (\rightarrow P. 5-14).

🌣 Tip

- If multiple Storage Servers are being used, you can setup one of them as the Master Storage Server.
- If the Storage Servers v1.2, v1.3, v1.4, v2.0, v2.1 or v2.2 coexist in the system, either Storage Server can be specified as the Master Storage Server.
- Older viewer than Viewer 2.2 cannot connect to the Storage Server v2.2.
- If you want to connect to the Storage Server directly without displaying Start-up Screen, uncheck [Select
 a Master Storage Server when starting] in the [Viewer Settings] window (→ P. 5-14).

How to Start VK-Lite

Double-click on the icon [VK-Lite Viewer v2.2] on the desktop.

Alternatively, from the Windows [Start] menu > [All Programs] > [WebView Livescope] > [Network Video Recorder VK-Lite v2.2] > [VK-Lite Viewer v2.2].



The following procedure is the same as VK-64/VK-16.

Launch by Connecting to the Localhost

If you want to use the local PC for viewer as well as Master Storage Server, connect to recording server on local PC to start the Viewer.

1. Select [localhost] from the drop-down menu.



- 2. Click [Connect].
- 3. Enter your [User Name] and [Password], and click [Login].



Note

• The default user name and password are as follows:

User name: admin Password: NVR

It is strongly recommended to change the user name and password after installation.

The Viewer can be launched directly without displaying Start-up Screen and [Login] dialog (→ P. 5-11).

Launch Storage Server by Specifying the IP address

If you installed the Viewer and Storage Server on separate PC, specify an IP address of Storage Server and connect Viewer to the Storage Server.

1. Select [Use IP address] from the drop-down menu.



- 2. Click [Connect].
- 3. Enter the IP address or host name of the Master Storage Server in [Host Name or IP], and the port number in [Port].



- 4. Click [Connect].
- 5. Enter your [User Name] and [Password], and then click [Login].




Mote

- If you use a proxy server, you should change the Internet option settings in the following procedure:
 - 1. Select [Start] > [Control Panel] > [Network and Internet] > [Internet Options].
 - 2. Select the Connection tab.
 - Click LAN settings. Change the proxy server settings.
- If using a proxy server between a Viewer and a Storage Server, it should not perform response buffering. The Proxy Server which is configured to perform response buffering may lead to delays in sending small amounts of data (such as events) from the Storage Server to the Viewer. You cannot use the Apache proxy server since it perform response buffering.
- You cannot send or receive audio when using a proxy server.



The dialog for entering the IP address will also be displayed even when connection to the Storage Server failed.

When the Viewer accesses to a Master Storage Server which has not been set up with camera server information, the entire Viewing Screen is initially blank as shown below. You should configure the Viewer using the [Configuration and Preferences] screen.





It is strongly recommended that only one Administrator perform configuration on each network.

Access to the Configuration and Preferences screen


To open the [Configuration and Preferences] screen, the following operation should be performed.

In the Menu Bar, select [View] → [Configuration]

The menu bar is located at the top left of the Viewing Screen.

In the Menu Bar, select [View] → [Configuration].

The [Configuration and Preferences] screen appears.



[Storage and Camera Server Summary] Windows

Use the [Storage and Camera Server Summary] screen to create a location and zone, to add the Storage Server, and to add the Camera Server.

Display the [Storage and Camera Server Summary] Windows

- 1. Launch the VK Viewer and display the [Configuration and Preferences] screen.
- 2. Click the [Camera Summary] tab.

The [Storage and Camera Server Summary] windows appear.



The window consists of two sub-windows which are opened by their respective tabs, [Storage Servers] and [Locations / Zones].

When the [Storage Servers] tab is selected




Click and drag scrollbar(s) to view any portions of the Summary Area that are not visible.



If you are using the Viewer only, the Camera Server, Location/Zone, and Camera Type are only displayed in the Camera Server List.

Click and drag divider line to the right to show full items.



[Storage Servers] and [Locations / Zones] options

The following options are available via the [Storage Servers] tab.

[Add Storage Server] - Allows you to register a Storage Server with the system (up to ten Servers are recommended).

[Edit] - Allows you to change the address of the selected Storage Server.



Select a Storage Server from the tree in the left panel. The right panel will update with a list of Camera Servers recorded by the Storage Server you selected.

The following options are available via the [Locations / Zones] tab.

[Add Location] - Allows you to add a new location to the system.

[Add Zone] - Allows you to add zones to locations.



When you select a zone within a location in the left panel, a list of cameras in that zone is displayed in the right panel.

Other Functions in Both Tabs



Camera server functions are located on the right-hand panel regardless of which tab is selected.


- [Find Camera Servers] Allows you to initiate a network search for unlisted Camera Servers on the LAN and register it.
- [Add Camera Server] Allows you to add a Camera Server to the system.
- [Edit Camera Server] Allows you to edit an existing Camera Server's settings.
- [Remove Camera Server] Allows you to remove a Camera Server from the system.

Location and Zone

Create a location and zone for the preparation of registering the Camera Server.


Cameras are grouped into Locations and Zones. Locations are for example, an office building, shop or school. Zones are a part of Locations, that is, a zone could be assigned o each floor in the office building and specific areas in a shop such as a cash register area.

The diagram below illustrates an example of physical Locations and Zones on a VK-64/VK-16 network. Viewer access is performed via the [Location] and [Zone] drop-down menus.



When a Location is selected from the drop-down menu at left, all of the Zones associated with the Location will appear to the right as camera thumbnail images.

This tab containing four thumbnail images indicates that there are four cameras in the Zone.



This tab containing six thumbnail images indicates that there are six cameras in the Zone.

Note

- The Location/Zone hierarchy is independent of the grouping of cameras into Storage Servers. For example, a single Storage Server may record video from multiple Locations, and cameras from a single Location can be recorded to multiple Storage Servers.
- When multiple Storage Servers are used and a Storage Server which already has registered Camera Servers is changed to the Master Storage Server, thumbnails of registered Camera Servers may not be displayed. In this case, update the thumbnails by clicking [Connect] on the [Edit Camera Server] dialog for each Camera Server on the Master Storage Server.

Add a Location and Zone

Step 1: Click [Add Location] on the [Locations / Zones] tab

- 1. In the [Camera Summary] window, select the [Locations / Zones] tab if it is not selected yet.
- 2. Click [Add Location] to bring up the [Add Location] dialog.




3. Enter the new location name (up to 20 characters), then click [OK].



Step 2: Click [Add Location] on the [Locations / Zones] tab

- 1. In the [Camera Summary] window, select the [Locations / Zones] tab if it is not selected yet.
- 2. Click [Add Zone] to bring up the [Add Zone] dialog.



- 3. Enter the new zone name (up to 20 characters).
- 4. Select a location from the drop-down menu in the [Location] field, then click [OK].

The selected zone will now appear in the specified Location folder.




Note

- If you want to add a Zone to another location not listed, you should first create the Location before you add the Zone.
- Each Location name must be unique and each Zone name within a Location must be unique as well.
- There is no limitation on the number of Zones and Locations that can be added.

Edit a Location and Zone

- 1. Double-click a location or zone. The [Edit Location] or [Edit Zone] dialog appears.
- 2. Change the settings and click [OK].



Delete a Location and Zone

- 1. Click a location or zone in the list to highlight it and select [Delete] from the [Edit] menu. Alternatively, click a location or zone to select it, then press the [Delete] key on your keyboard.
- 2. A confirmation dialog will appear. Click [Yes]. Click [No] to cancel deletion.

Add Storage Server VK-64/16



If you are using multiple Storage Servers, add each Storage Server as directed below. You need not perform these steps if you are using only one Storage Server and that Storage Server has already been added.

By adding the Storage Server, you can select the Camera Servers managed by each Storage Server from the Viewer screen.



If you are using the Viewer only, the [Storage Servers] tab is not shown and you cannot add the Storage Server.



You can operate VK-64 with up to 10 Storage Servers, and up to 192 Camera Servers can be operated.

Display [Storage and Camera Server Summary] Windows


Launch the VK Viewer and display the [Storage and Camera Server Summary] window.

Add Storage Server

- 1. In the [Storage and Camera Server Summary], select the [Storage Servers] tab.
- 2. Click [Add Storage Server] to bring up the [Add Storage Server] dialog.



3. Enter connection settings and click [OK].




Note

- Do not add the same Storage Server more than once.
- If you add a Storage Server with a different configuration (such as one managed by another Master Storage Server), your original Locations and Zones will be invalid.
- You need to change Windows settings of a storage server to be added before if you are using Windows XP SP2 or Windows Server 2003. See "Notes on Operating Environment" (→ P. 1-12~P. 1-16).
- Do not change the port number.

Edit Storage Server

1. In the [Storage and Camera Server Summary], select the [Storage Servers] tab.

A list of Storage Servers which have already been added is displayed.



2. Double-click the Storage Server in the list.

Alternatively, select the Storage Server and click [Edit].

This will bring up the [Edit Storage Server] dialog.

3. Change the settings and click [OK].



- You should change the setting of Storage Server in case of the IP address of Storage Server has been changed.
- The Master Storage Server cannot be edited.
- 4. To save changes, click [Save Changes] at the bottom right-hand corner of the [Camera Summary] window. Click [Discard Changes] to cancel any changes you have made.



Delete Storage Server

1. In the [Storage and Camera Server Summary], select the [Storage Servers] tab.

A list of Storage Servers which have already been added is displayed.

2. Click a Storage Server in the list to highlight it and select [Delete] from the [Edit] menu.

Alternatively, click a Storage Server to select it, then press the [Delete] key on your keyboard.

3. A confirmation dialog will appear. Click [Yes].

Click [No] to cancel deletion.

4. To save changes, click [Save Changes] at the bottom right-hand corner of the [Camera Summary] window.

Click [Discard Changes] to cancel any changes you have made.



Note

- If a Storage Server is deleted, all Location, Zone, thumbnail and Layout information for cameras associated with this Storage Server will be deleted as well.
- The Master Storage Server cannot be edited.

Register Camera Server

After preparing for Camera Server registration (i.e., creating a location and zone, and adding the Storage Server), you should register the Camera Server.

You should register the desired Camera Server on the Storage Server if it has not been registered yet.

Register the Camera Server (by Search)

After registering the Camera Server, you can select the Camera Server from the Viewer screen.



- Up to 192 Camera Servers can be operated. Up to 4 camera servers can be operated with VK-Lite.
- To connect to the Camera Server managed by another Storage Server, you should first add that Storage Server (→ P. 4-14).

Display the [Storage and Camera Server Summary] Windows


Launch the VK Viewer and display the [Storage and Camera Server Summary] window.

Find the Camera Server

In the [Camera Summary] window, click [Find Camera Servers] which is located above the right-hand panel.



The [Search Results] dialog appears and a list of detected Camera Servers will be displayed.



Note

- When you initiate the [Find Camera Servers] function, PC searches the Viewer's local subnet for all Camera Servers connected to it. Camera Servers on another subnet cannot be searched and should be added using [Add Camera Server] (→ P. 4-18).
- The camera names in the list are those specified by the Camera Server. See the Camera Server's User's Manual for more information on setting the name ("Camera Name" for VB-C500VD, VB-C500D, VB-C60, VB-C50i/ VB-C50iR, VB-C50FSi, VB-C50Fi and VB-C10/VB-C10R, "Device Name" for VB150, "VB-C300NA" or "VB-C300PA" for VB-C300).



- If you cannot find the Camera Server, click [Add Camera Server] to add it.
- For the Camera Servers which have already been registered, [Registered] is displayed in the [Register] column. The [Register] columns for unregistered Camera Servers are blank.


Add the Camera Server


- 1. In the [Search Results] dialog, click a Camera Server in the search results list to select it.
- 2. Click [Add Camera Server].

The [Add Camera Server] dialog appear.

Alternatively, double-click an item to bring up the [Add Camera Server] dialog.

Continue settings on the [Add Camera Server] dialog.





Note

Recording schedules should be set in order to record video. Even though you click [OK], video recording will not start immediately.




Contents of the [Add Camera Server] dialog will be different depending on the type of connected Camera Server.

Connect to Camera

1. Enter the Host Name or IP address in [Host Name or IP], then enter the port number for the Camera Server in [Port].

The [Host Name or IP] should be 255 characters or less (each label, separated by a period, must be 63 characters or less), the IP address must be 15 characters or less (each label, separated by a period, must be 3 characters or less), and the [Port] must be a figure within the range from 1 to 65535.



2. Enter the user name and password to connect to the Camera Server. Enter the user name in [User Name] and password in [Password].

The settings are then saved to the Storage Server.

Note

- Use the user name and password configured on the Camera Server. If the user name and password are not sure, ask for the System Administrator of the Camera Server.
- Storage servers and VK Viewers do not support IPv6.
- 3. Click [Connect].

Once the Viewer has connected with the Camera Server, a tab is shown next to the [Add Camera Server] dialog.

Note

- You must click [Connect] before clicking [OK] to close the dialog (the [OK] button is disabled until you do so).
- When two or more cameras are used with VB150 (when [Video Input] is set to [Multiple]), two through four tabs are added. The number of tabs shown for a VB150 does not indicate the physical number of cameras connected, but indicates the number of cameras which have been enabled using the VB150 [Camera and Video Settings] Page. Please see Chapter 3, P. 36 of the VB150 User's Manual for more details.
- If [Video Input] is set to [Single] for VB150, the camera name displayed as the Camera Server Name is the first camera name in the server's camera name list when [Use Camera] is selected on the [Camera and Video Settings] Page. Therefore, it is recommended that the Administrator should set the first camera name to be a general name, applicable to the entire Camera Server.
- If you are using a VB150 with the [Settings Web page URL] other than the default setting "admin", a connection error occurs when you click [Connect]. Restore the default setting and try again.




If you have a Multi-Terminal Module VB-EX50 unit plugged into a VB-C50i/VB-C50iR, VB-C50FSi, VB-C50Fi and have configured the [Use External Video Input], video seen in the Viewer may be taken from cameras connected to the Multi-Terminal Module. Switch the video at the Admin Viewer as required.

Select a Storage Server

1. Select a [Storage Server] from the drop-down menu which lists pre-configured Storage Servers and enter the Host Name or IP address in [Host Name or IP] and Port number in [Port].

The [Host Name or IP] must be 255 characters or less (each label, separated by a period, must be 63 characters or less) and the [Port] number must be a figure within the range from 1 to 65535.



2. If you do not want the Camera Server to record video, select [Do not record] from the drop-down menu of [Storage Server].

Note

- Recording schedules should be set in order to record video.
- There is a maximum number of 64 Camera Servers that can be registered on one Storage Server with VK-64 (or 16 cameras with Network Video Recorder VK-16).
- If you are using the Viewer only, the Storage Server cannot be configured.
- If you have changed the Camera Server's IP address, you also need to change the host names in the [Connection Settings] and [Storage Server Settings] dialogs.

Configure Recording Stream Usage (VB-C500VD, VB-C500D, VB-C60)

VB-C500VD, VB-C500D and VB-C60 has a video recording stream function that temporarily saves images in the camera memory as a function to handle packets dropped due to network interruptions, etc.

To use the recording streams, select the [Use the recording-mode stream] checkbox.



■ Note

- Even if you have selected the [Use the recording-mode stream] checkbox for a camera server set up for a [Recording Schedules], the settings will not be reflected until the current recording schedule is finished. If you have selected the [Use the recording-mode stream] checkbox, please restart the storage server.
- The recording streams can only be used for JPEG recording at 10 fps or less. They cannot be used for JPEG recording at rates higher than 10 fps or for MPEG-4 recording.
- The recording streams cannot accept requests from multiple Storage Server.
 If recording stream requests are made to one VB-C500VD, VB-C500D or VB-C60 from multiple clients, the second and subsequent requests return errors and connect in normal mode.

Configure External Device Input

To switch On or Off the external device input, check the [Invert the state of the following external] option.

One or more inputs may be shown depending on the type of the Camera Server. It is not necessary to change this setting if it is not required.



Assign a location and zone

1. If multiple [Cam] tabs are shown to the right of the screen, select a tab for the Camera Server to edit settings.



2. Change the name of the Camera Server in the [Camera Name] field as required.



Note

- Enter the [Camera Name] in up to 15 characters.
- Changing the [Camera Name] setting here does not change the camera name of the Camera Server.
- 3. In the [Location] field, select a location for the Camera Server from the drop-down menu.
- 4. In the [Zone] field, select a zone for the Camera Server from the drop-down menu.


If necessary, click [Add] to add another Location or Zone.

The [Add Location] or [Add Zone] dialog opens.

Enter the [Location Name] or [Zone Name] and click [OK].



When you add a Zone in the [Add Zone] dialog, you should also add it to a Location in the same dialog. Select a location from the drop-down menu.



See P. 4-12 for how to add locations and zones.

Update or Set the Viewer Thumbnails

- 1. In the [Preview] area, click [Update] to recapture an image used for the thumbnail of the Viewer screen.
- 2. To change the camera angle or zoom magnification by using the mouse, click [Start Control].



Move the mouse cursor around the image. Arrows will appear and you can click and drag the cursor in that direction. The preview will change accordingly. When you move the mouse cursor to the center of the image, a zoom in or zoom out control will appear.

Hold down the mouse on "+" to zoom in.

Hold down the mouse on "-" to zoom out.



Note

- When using VB-C500VD, VB-C500D, VB-C50FSi and VB-C50Fi, pan and tilt operation is not available.
 You cannot use zoom operations with the VB-C500VD, VB-C500D if digital zoom is set to [Disable] on the camera.
- If a fixed camera or an external camera such as VC-C50i is connected to VB-C50i, you cannot use pan, tilt, and zoom operations.



If you want to change the thumbnail and the preview area is blank (and the [Update] and [Start Control] buttons are disabled), click [Connect] (located in the [Connection Settings] field).

3. You can also select an already specified camera position from the [Preset] dropdown menu.



[Preset] cannot be selected as VB-C500VD and VB-C500D do not support this function.



Presets should be configured in advance. Please see the Camera Server User's Manual for details on setting camera presets.

4. The exposure compensation settings can also be made from [Exposure Compensation] dropdown menu ([High], [Medium], [Low] and [Off] in VB-C300, VB-C50i/VB-C50iR, VB-C50FSi, VB-C50Fi). In VB-C500VD, VB-C500D and VB-C60, [0], [+1], [+2], [+3], [-3], [-2], and [-1] can be selected.



Select the drive to save video data

In the [Drive] drop-down menu, select a hard disk drive on the Storage Server.





- Network drives registered via Storage Server Configuration are also shown on the [Drive] drop-down menu. See "Adding/Removing a Network Drive" (→ P. 3-11) for the details.
- If you are using the Viewer only, the drive cannot be configured.

Close the [Add Camera Server] Dialog

Click [OK] to close the [Add Camera Server] dialog.


If you open the [Add Camera Server] dialog from the [Search Results] screen, you will return to the [Search Results] screen.

In this case, click [Cancel] to return to the [Camera Summary] window.

If you clicked [Add Camera Server] to open the [Add Camera Server] dialog, you will return to the [Camera Summary] window.

Save Settings

To save Camera Server settings, click [Save Changes] at the bottom right-hand corner of the [Camera Summary] window.



Click [Discard Changes] to cancel any changes you have made.

Return to the Viewer Screen

If you wish to return to the Viewer Screen, select [Viewing Screen] from the [View] menu bar.

Edit Camera Server

The right-hand portion of the [Camera Summary] window features [Edit Camera Server] for Editing the Camera Server(s) on your system, regardless of which tab you have selected ([Storage Servers] or [Locations / Zones]). The same dialog as [Add Camera Server] (→ P. 4-18) appears.

Start Editing Camera Server

1. In the [Camera Server] list, click a Camera Server to highlight it.



2. Click [Edit Camera Server].

The [Edit Camera Server] dialog appear. The Edit Camera Server is identical to the [Add Camera Server] dialog (you can also open the dialog by double-clicking the menu).



Change the Camera Server's Settings

Change the Camera Server settings as directed in P. 4-17 through P. 4-19.

Finish Editing

Click [OK] when finished. The [Camera Summary] window reappears.

Save Edit Contents

To save edited Camera Server settings, click [Save Changes] at the bottom right-hand corner of the [Camera Summary] window.



Click [Discard Changes] to cancel any modifications you have made.

Delete Camera Server


The right-hand portion of the [Camera Summary] window features [Remove Camera Server] for removing the Camera Server(s) from your system, regardless of which tab you have selected ([Storage Servers] or [Locations / Zones]).

Delete a Camera Server

1. In the [Camera Server] list, click a Camera Server to highlight it.



2. Click [Remove Camera Server] (you can also press the [Delete] key on your keyboard).



3. A confirmation dialog will appear. Click [Yes].

Click [No] to cancel deletion.



Reflect Deletion

To reflect Camera Server deletion, click [Save Changes] at the bottom right-hand corner of the [Camera Summary] window.



Click [Discard Changes] to cancel any modifications you have made.

Overview of Recording Schedule Setting

After you have registered the Camera Server, you can set recording schedules.

Note

- If you are using the Viewer only, you cannot set recording schedules.
- Be sure to perform operational tests after setting schedules.

You can record videos by specifying when and what to record with recording schedule function.

When - Select from the following:

- Specified day of the week (Normal Schedule)
- Specific day (Special Day Schedule)

🌣 Tip

- Use a Normal Schedule for normal recording operation.
- See P. 4-31 for how to use the [Normal Schedule] dialog.

Example of [Normal Schedule]: Record video from 7:00 A.M. through 8:30 A.M. on every

Wednesday and Friday.

• See P. 4-62 for how to use the [Special Day Schedule] dialog.

Example of [Special Day Schedule]: Record video during the winter holidays from December 28

through January 3.

What - Select one or more from the following:

- Record video throughout the specified period of time (Continuous recording)
- Record video by Motion Detection during the specified time period (Motion Detection recording)
- Record video by sensor during the specified time period (Sensor Event recording)

The Motion Detection recording starts recording video when a motion has been detected. See "Set Motion Detection Recording" (→ P. 4-46) for details.

The Sensor Event recording starts recording video when a sensor input has occurred. See "Set Sensor Event Recording" (→ P. 4-53) for details.



Only continuous recording is available with VK-Lite.

🄃 Tip

One recording schedule can have Continuous, Motion Detection, and Sensor Event recording settings. You can record a Camera Server continuously at 1 frame per second and, for example, set recording to increase to 5 frames per second when motion occurs.


Recording Schedule

Two types of recording schedules are available: Normal Schedule and Special Day Schedule.

For both types of schedules, you must set the recording schedule for each Camera Server in the [Recording Schedules] screen.


Display the [Recording Schedules] screen


- Launch the VK Viewer and in the Menu Bar, select [View] → [Configuration].
 The [Configuration and Preferences] screen appears.
- 2. Click the [Recording Schedules] tab to display the [Recording Schedules] screen.
- 3. Click the [Normal Schedule] tab to display the [Normal Schedule] screen.




4. VK-64/16

Click the [Special Day Schedule] tab to display the [Special Day Schedule] screen.








Mote

- The scheduling area functions the same as the Normal Recording Schedule but only covers a single day (from 00:00 hrs. to 24:00 hrs). To have a special day schedule run over a long weekend (Fri, Sat & Sun), all dates of three days must be added to the list of days to use the schedule.
- When Special Day Schedules are running, Normal Schedules are disabled. If an invalid schedule exists, the following warning message will be displayed. "There is a camera to which the recording schedule is not registered. Is it OK to leave it like this?"

Set Normal Schedule

The [Normal Schedule] consists of:

- [Storage Server] list Select the Storage Server to edit the recording schedule.
 - When the [Recording Schedules] window first appears, the first Storage Server in the list is shown with its associated schedule to the right.
- Schedule Area Set up standard day-to-day recording schedules settings.



Create Normal Schedule

Display the [Recording Schedules] screen

- 1. In the Menu Bar, select [View] → [Configuration].
 - The [Configuration and Preferences] screen appears.
- 2. Click the [Recording Schedules] tab to display the [Recording Schedules] screen.
- 3. Click the [Normal Schedule] tab to display the [Normal Schedule] screen.

Change the Storage Server

If you wish to display another Storage Server's schedule, click the [Storage Server] menu, otherwise proceed to the next step.



The menu may list more assigned Storage Servers. If you select another Storage Server, the Schedule Area will refresh and associated schedule zones will be shown.

Create a Normal Schedule


Click and drag a time period for a camera name and release the mouse button. The [Add Schedule Item] dialog is displayed.



Alternatively, right-click anywhere in the Schedule Area alongside a camera name and click [Add Schedule] from the context menu.




You can click and drag the schedule area of several cameras to bring up the [Add Schedule Item - multiple cameras] dialog. This allows you to easily set schedules for multiple cameras. Once created, settings for each camera can be customized later.





- The shortest recording time for a schedule is 15 minutes.
- You cannot create overlapped schedule items within a single Camera Sever.



Configuration is discussed on the following pages.

Set the recording period

Click the hours or minutes fields to select, then click the up/down arrows or directly enter a value to change time.





- Time period could be set for overnight recording such as [Start] 22:00 to [End] 08:00.
- Click [All Day] if you want 24 hour recording. The [Start] and [End] times will be set at 00:00 respectively.

Select a day of the week to record video

In the [Repeat on] area, check the days you wish to repeat the recording period you have set in the [Times] area above.



■ Note

- If you have defined any special day schedules, at that time the schedules will override normal schedule times for the whole day.
- Times are given in 24 hours.
- If Camera Server has been configured with [Service time restricted], VK-64/VK-16 will not be able to record from the Camera Server during restricted times.
- The time zone used for the recording schedule will be the time of PC where the Storage Server is running.
- The Storage Server will adjust for Daylight Savings if configured in the operating system.

Set Continuous Recording

1. Click the [Continuously at Max.] box if you want to set continuous recording for the duration of the time period.



2. Select a frame rate for recorded video from the drop-down menu, or input a value from the keyboard.

You can set the frame rate from 0.1 frames per second to 30 frames per second. The default is 5 frames par seconds. The upper limit is 5 frames per second with VK-Lite.

See P. 4-45 for details of Continuous Recording.

Configure Motion Detection Recording and Sensor Recording Settings VK-64/16

 Check the [On motion detection] box if you want recording activated when motion is detected during this time period.



- 2. Check the [On sensor event] box if you want recording activated from a sensor event during this time period.
- 3. Click [Settings] to change the details.

See P. 4-45 and P. 4-53 for details of Motion Detection and Sensor Event recordings.

Configure Audio Recording

If you want to record audio when video recording mode is selected, select the [Audio recording] checkbox.

Audio-only recording is not available, so Audio recording should be set as an addition to video recording.



Note


- Audio recording is available on camera servers that support audio transmission function (VB-C500VD, VB-C500D, VB-C60, VB-C300, VB-C50i, VB-C50iR, VB-C50FSi). On camera servers that do not support the function, the Audio recording checkbox is disabled.
- Audio recording is enabled when video recording mode is on. It is not possible to setup schedules that only record audio without recording video.
- When the resolution (→ P. 4-38) is set to JPEG, recorded video and the audio are synchronized. However, the synchronization is not guaranteed.
- Live video and audio are not synchronized.
- Audio is recorded at 8 KB/s. The communication volume is 64 kbps.
- After [Audio recording] is enabled, related indications are changed to show that, such as [Record + Sensor (Audio)], in the [Configuration and Preferences] screen > [Camera Summary] tab (→ P. 4-8), and the [Configuration and Preferences] screen > the [Recording Schedules] tab (P. 4-28).
- The timeline on the Viewer screen (→ P. 5-48) does not show whether audio recording is enabled or not.
- [Audio recording] via a proxy server is not supported.

Set the Preset Camera Angle and Exposure Compensation

1. In the [Preview] field a live preview is given of the selected camera view when connected.

Select a camera position from [Preset] drop-down menu of available camera angles, to retain a live preview from that angle.

Alternatively, move your mouse pointer in the [Preview] area to display controls and clicking to pan, tilt and zoom (→ P. 4-22).



2. Check [Preset Tour] to move among multiple preset positions sequentially (VB-C60, VB-C300, VB-C50i/ VB-C50iR only). Click [Settings] to specify the order to switch among presets.

See P. 4-58 for how to set the Preset Tour.

However, [Preset Tour] is grayed out in VB-C500VD and VB-C500D as this function is not supported.

3. Select [On] or [Off] from the [Exposure Compensation] drop-down menu (You can set the exposure compensation to [High], [Medium], [Low] or [Off] for VB-C300, VB-C50i/VB-C50iR, VB-C50FSi and VB-C50Fi. On VB-C500VD, VB-C500D and VB-C60, the options include: 0, +1, +2, +3, -3, -2, -1).

Select [Not Specified] to accept the currently configured Camera Server exposure settings.

Note

- Camera angle can be changed by moving your mouse pointer in the [Preview] area to display controls.
 By clicking, pan, tilt and zoom function can be controlled (→ P. 4-22).
- After the camera server control finishes, the [Preset] is set to [Custom], and the current setting values of exposure compensation and the camera server position are used for recording.
- If you select [Not Specified] for [Preset], Storage Server records video the Camera Server currently displays. However if camera angle is changed from the Viewer, the video will be recorded at the changed position of the Camera Server.
- In the following cases, the Storage Server records what the Camera Server currently displays;
- Multiple number of cameras are connected to VB150 with the [Video Input] set to [Single].
- VB-C50i/VB-C50iR, VB-C50FSi, VB-C50Fi with an external camera connected and have configured the [Use External Video Input].
- During initializing the camera head position of VB-C50i/VB-C50iR, VB-C300 or VB-C60, the camera head
 moves to face front, and then moves back to the current position. Please note that video will be recorded
 in the meantime continuously.
- The [On Motion Detection], [Exposure compensation], and additional options are not available, if you use the [Preset Tour] function.
- If you use the [Camera Control] Panel to do the pan, tilt, or zoom operation, the value in the [Preset] drop-down menu will changed to [Custom].
- Preset used for the [Preset Tour] are created on the Camera Server. Please see the Camera Server User's Manual for details on making camera presets.
- Although the VB-C300 does not allow [Preset Tour] on the Camera Server, the [Preset Tour] is available via this setting.
- If [Preset Tour] is selected, [Exposure Compensation] is not available.
- If [Exposure] is selected, the [Exposure Compensation] option is set to [Not Specified].
- With VB-C60, when the optical zoom exceeds the threshold and shifted to digital zoom, [Custom] in the
 [Preset] pull-down menu is not available. Even if you click [OK] in the [Add Schedule Item] and [Edit
 Schedule Item] dialog or the [Sensor Event Settings] dialog, an error message will appear and the
 settings will not be applied.
- Preset Tour settings cannot be made with the VB-C500VD, VB-C500D, VB-C50FSi, and VB-C50Fi.

Set the Night Mode and Resolution (VB-C500VD, VB-C500D, VB-C60, VB-C300, VB-C50i/VB-C50iR, VB-C50FSi, VB-C50Fi and VB150)

1. Select the [Night Mode] from the drop-down menu. You can select from [Not specified], [Disabled], [Enable], and [Auto].



Note

- If you select [Enabled], the [Night Mode] status will be back to [Disabled] after the configured recording schedule finishes.
- A higher resolution results in larger disk usage. Make sure you have enough disk space.
- If you set [Night Mode] to [Auto], please make sure that [Exposure] mode is set to [Auto] on the [Camera Control] Panel.
- The Auto setting for Night Mode can only be set with the VB-C500VD, VB-C500D, VB-C60, and VB-C300.
- The [Night Mode], [Day Mode], and [Not specified] options for the Night Mode function can only be set with VB-C500VD, VB-C500D, VB-C60, VB-C300, VB-C50i series, and VB150.
- Video turns to monochrome in the [Night Mode].
- If you specify [Auto], you cannot control the [Night Mode] using the [Camera Control] Panel.
- You cannot use the built-in infrared lamp if you are using the optional dome housing.

🄃 Tip

- In the [Night Mode], set to [Enable]. After the schedule expires, the [Night Mode] will be disabled.
- In the [Auto] mode, the mode automatically switches according to the brightness.
- 2. Select a [Resolution] for recording from the drop-down menu. You can select from [JPEG Small], [JPEG Medium], [JPEG Large], [MPEG-4] or [Not specified].

If you select [Not specified], the Storage Server does not attempt to change the setting, rather it accepts whatever [Night Mode] setting and resolution the Camera Server offers.



[MPEG-4] can be selected for VB-C500VD, VB-C500D and VB-C60.



The actual image size in relation to the specified resolution size is as follows.

JPEG Small	160 x 120
JPEG Medium	320 x 240
JPEG Large	640 x 240 (VB150 only) 640 x 480
MPEG-4	the size specified in the setting page (VB-C500VD/VB-C500D/VB-C60)
Not specified	the size that has been specified in the setting page at the time of starting recording (VB-C500VD/VB-C500D/VB-C60) the size specified in the setting page

Set Additional Options

To enable the [Exposure], [WB] (White Balance), [Smart Shade Control], and/or [Focus] on the [Camera Control] Panel, check the each check box.




Note


- The additional option is available with VB-C500VD/VB-C500D/VB-C60/VB-C300. [Smart Shade Control] is available with VB-C500VD, VB-C500D and VB-C60. Additionally, Focus is not available for the VB-C500VD and VB-C500D.
- If the [Exposure] box is selected, the [Exposure Compensation] option will be disabled.
- If [Preset Tour] is enabled, you cannot use additional options.
- The additional option settings will be return to the original settings if the Camera Server settings are changed during schedule execution.

Set External Device Output

 Click [External Outputs Setting] to control any external devices that may be connected to your Camera Server.



- Click [Setup] to change the details of external outputs. If you do not change the settings, the defaults will be used.
- 3. If [Setup] is clicked, click the drop-down menu for the target external device and set [External Outputs] to [On] or [Not specified] on the [External Outputs Setting] dialog.





For VB-C300, only one target external device can be configured on the [External Outputs Setting] dialog.

Finish Setting

Click [OK] to save the new settings and close the dialog.

Click [Cancel] to discard the new settings.

When you click [OK], the [Preset] and [Exposure Compensation] settings are effective on Video Windows in the Viewer. Control the camera as required by clicking [Camera Control].

Save Schedules

1. To save the Normal Schedule, click [Save Schedule] at the bottom right-hand corner of the [Normal Schedule] window.



Click [Discard Changes] to cancel any modifications you have made.

2. If you wish to return to the Viewer, select [Viewing Screen] from the [View] menu bar.




Camera Servers have feature to record videos on memory of the camera with sensor input or schedule. If settings are enabled on the Camera Server, they take precedence over any settings made in VK-64/VK-16. This may cause some confusion if your VK-64/VK-16 recording schedules fail to record with the correct camera preset. You should disable such Camera Server features if you wish VK-64/VK-16 settings to take precedence.

Change Camera Server Settings

Click [Setup] in the [Add Schedule Item] and [Edit Schedule Item] dialog, and then Camera Server's top page appears after Internet Explorer launches (VB-C500VD/VB-C500D).



Click [Setting Page] to display the Setting Page to change Camera Server settings.



Items related to recording schedule setting are as follows. See the Camera Server's manual for details.

User Name and Password

Set the user name and password for the Camera Server. You cannot set them with VK-64/VK-16.

Motion detection recording

- If the Camera Server is VB-C500VD, VB-C500D, VB-C60, VB-C50i/VB-C50iR, VB-C50FSi, VB-C50Fi, or VB150, you can configure the Motion Detection settings on the Camera Server.
- To configure the Motion Detection settings on VB-C500VD, VB-C500D, VB-C60, VB-C50i/VB-C50iR, VB-C50FSi, VB-C50Fi, or VB150, use the VB Administration Tools supplied with the Camera Server.
- For VB150 ([Video Input] should be set to [Single]), the Motion Detection settings are configured using the VK-64/VK-16 [Motion Detection Settings] dialog (→ P. 4-47).
- The Motion Detection function is not suitable for conditions where high reliability is required. It is not
 recommend using this function in situations where high reliability is required, such as for monitoring
 purposes. Canon accepts no liability whatsoever for faults, etc. resulting from the use of the Motion
 Detection.

Image/Video Quality

 You can set the image/video quality. The Motion Detection settings may be affected by the video quality setting of the Camera Server. When changing the video quality on the Camera Server, be sure to check the settings for Motion Detection.

Camera Name

 Set the name of the camera displayed in the [Camera Server] list. You cannot set them with VK-64/ VK-16.

Preset

- Presets should be set on the Camera Server in advance. You cannot set them with VK-64/VK-16.
- If the recording settings using a preset are used on the Camera Server, the preset position will override camera positions set by VK-64/VK-16, including those in recording schedules and Camera Server position. The camera control will be lost when starting to control the camera at the Camera Server.
- If predefined presets are not shown in the [Preset] drop-down menu even though they have been defined on the Camera Server, click [Get Camera Control] to display the [Camera Control] Panel, obtain camera control, then configure the settings again.

Restrict Service Time

 If a Camera Server has been configured with [Service time restricted] enabled, VK-64/VK-16 will be able to record from the Camera Server during restricted times.

External Device

- Specify the name of the external device, such as sensor name. You cannot configure it with VK-64/ VK-16.
- If the external device is not set on the Camera Server, VK-64/VK-16 cannot configure it.

Sensor Input, Recording to Camera Memory

 Camera Servers have certain features to capture image into its memory based on sensor input or schedule. If settings are enabled on the Camera Server, those settings take precedence.

Batch-Setting Schedules

When you set schedule, you can set multiple schedules at one time.

Create Multiple Camera Schedules

You can click and drag schedule area covering several cameras to bring up the [Add Schedule Item - multiple cameras] dialog. This allows you to easily set recording schedules for multiple cameras. Once created, settings for each camera can be customized.



Example: Drag over the Schedule area covering three Camera Servers to set the same schedule for the three Camera Servers.

Change or Move Multiple Camera Server Schedules

While holding down the [Ctrl] key, click on individual schedule items to select them, and then drag the mouse to change or move multiple recording schedules.





Set Continuous Recording

You can set Continuous Recording with the frame rate of 0.1 to 30 frames per second when creating a Normal Schedule or Special Day Schedule (The upper limit is 5 fps with VK-Lite).

Specify the number of still images to record every second from the [fps] drop-down menu.

Higher [fps] value generates smooth video, however, the load on the Storage Server or network goes higher. Video data quantity also increases to consume hard disk space.

To configure the Camera Server for recording:

Set Recording Mode

1. Check the [Continuously at Max.] check box if you want to set continuous recording for the time period.



2. Select a frame rate for recorded video from the drop-down menu, or input a value from the keyboard.

You can set the frame rate from 0.1 to 30 frames per second. The default setting is 5 seconds.

Note

- When the load on Storage Server CPU and hard disk is higher, recording at the specified frame rate may not be available, or the video recording may be interrupted.
- Higher frame rates for result in larger disk usage. Please ensure that you have enough disk space.
- The specified frame rate is the frame rate that the Storage Server will attempt to record, however may not be the actual frame rate used for recording video. Factors such as the number of Viewers, load on the Camera Server and the Storage Server, and network traffic may reduce the actual frame rate recorded. Also, the maximum frame rate for a VB-C10 configured with a resolution of 640 x 480 is 10 frames per second, and for a VB150 with 4 cameras is 2 to 3 frames per second.
- While the [Resolution] is set to [MPEG-4], the frame rate drop-down menu is gray out. However, the video is recorded at the frame rate specified in VB-C500VD, VB-C500D or VB-C60 setting page at that point.

Set Motion Detection Recording VK-64/16



Set Motion Detection Recording Settings

The Motion Detection recording starts when a motion has been detected.

Configure the Motion Detection recording settings in the [Motion Detection Settings] window which appears when you click [Settings].

Some items in the [Motion Detection Settings] window overlap with the items in the [Add Schedule Item] and [Edit Schedule Item] dialog. In Motion Detection recording, the settings in the [Motion Detection Settings] window take precedence. [Preset] and [Exposure Compensation] settings in the [Add Schedule Item] and [Edit Schedule Item] dialog are applied to the Motion Detection recording.

Note


- The Motion Detection function is not suitable for conditions where high reliability is required. It is not recommend using this function in situations where high reliability is required, such as for monitoring purposes. Canon accepts no liability whatsoever for faults, etc. resulting from the use of the Motion Detection.
- Motion detection is performed by the Storage Server or Camera Server (whichever selected in the [Motion Detection Settings] window). If the Camera Server executes motion detection, motion detection is not available while the Camera Server is performing the pan, tilt, or zoom operation (motion detection by the Storage Server is available during these operations).
- If the recording schedule expires during Motion Detection recording, the Motion Detection recording also terminates.

Edit Motion Detection Recording Settings

You can specify the detection area and the amount of sensitivity for Motion Detection Recording. The area for detection can also be modified which is ideal, for example, if the field of view has two entrances and you wish to monitor motion for one entrance.

Step 1: Click [Settings] next to [On Motion Detection]

The [Motion Detection Settings] dialog appears (The dialog for VB-C60 is shown below).



Mote

This dialog box is only valid when connected to VB-C60, [Detect Motion Using] is set to [Camera Server] and [Notice events with the area name when motions are detected] is selected. On VB-C500VD, VB-C500D and VB-C60, recording settings can be configured separately on each of the four detection areas (tabs).

recording triggered by motion.

- If [Detect Motion Using] is set to [Storage Server], or you are connected to a different camera, or [Notice events with the area name when motions are detected] is not checked, the video recording settings apply to the entire region.
- If the [On sensor event] is also enabled and motion detection and sensor input occur simultaneously, the [On sensor event] takes precedence. See "Priorities of Motion Detection and Sensor Event Recordings" (→ P. 4-57) for details.
- You cannot use the [Preset Tour] and the Motion Detection recording together.

device output.

Step 2: Set Motion Detection Options

Set the following options on the [Motion Detection Settings] dialog.

1. In the [Detect Motion Using] menu, select one of the following:

[Storage Server]

Obtains video from the Camera Server and detects motion with the Storage Server.

[Camera Server]

Uses the Motion Detection function of the Camera Server to detect motion (This menu is only active for VB150 servers with the [Video Input] set to [Single] or VB-C500VD, VB-C500D, VB-C60, VB-C50i/VB-C50iR, VB-C50FSi, VB-C50Fi).



2. In the [Analysis Frame Rate] menu, select from 0.1 to 30 frames per second.

If you select the [Camera Sever] to detect motion, [Settings] becomes available. [Settings] is now enabled. Click to launch your VB Admin Motion Detection Setting Tool. Install the VB Admin Tools that is bundled with the VB-C500VD, VB-C500D, VB-C60, VB-C50i/VB-C50iR, VB-C50FSi, and VB-C50Fi in advance. See the Camera Server's User's Manual for how to configure the motion detection settings.

■ Note

- To use the Motion Detection function of the VB-C50i/VB-C50iR, VB-C50FSi and VB-C50Fi, it is necessary to configure schedules from the VB Admin Schedule Setting Tool.
- Setting motion detection at the Storage Server causes high CPU load. It is strongly recommended to set motion detection at the Camera Server whenever it has the motion detection function.
- [Detect Motion Using] cannot be set to [Storage Server] when the [Resolution] is set to [MPEG-4].
- To configure motion detection settings on the camera server side in VB-C500VD/VB-C500D, VB-C60, please install VB Admin Tools Ver 5.1.

Step 3: Set the active region for recording

In the [Active Region] field, adjust the region where motion detection is triggered. By default, the [Active Region] is the full area. In addition you cannot use pan, tilt, and zoom operations in this window.

- 1. Click one of the corner or edge handles and hold down the mouse button.
- 2. Drag the handle to change the motion-trigger boundary (dotted frame).



The [Motion Detection Options] field also allows you to set the sensitivity for Motion Detection within the [Active Region]. [Sensitivity] and [Area Ratio] are selected by using the two sliding bars.


Motion detection status can be confirmed by the [Detection Indicator] during operation.



[Detection Indicator] Colors

Motion is displayed in the [Detection Indicator] as a green color bar and will remain green if the level of motion is below the configured [Sensitivity] and within a defined [Area Ratio]. If motion reaches the set [Sensitivity] and [Area Ratio], the color bar changes to yellow and if the detected motion remains at the yellow level for the specified duration period, a red color bar is displayed and an event is triggered. The behavior of the [Detection Indicator] is described as follows.

Green color bar - Changed area is less than the specified [Area Ratio], i.e., activity remains at the left
of the [Area Ratio] marker.



 Yellow color bar - Changed area is equal to or greater than the specified [Area Ratio] (activity peaks on or to the right of the Area Ratio Marker) but the required continuance of motion has not met the specified duration in order to trigger an event.



[Area Ratio] marker.

· Red color bar - The amount of change that meets the defined detection conditions and motion is detected, triggering an event, i.e., the required amount of motion has been detected for the specified duration.



[Area Ratio] marker.

Set the [Sensitivity]

[Sensitivity] is the degree of change which is detected as motion.

Drag the slide bar to adjust [Sensitivity] to the required value. Can be specified in increments of 10 from 1 to 250.





The sensitivity can be set to [Low - Med] or [Med - High]. To set, check the [Detail Settings] checkbox and click the [Settings] button. When the [Detail Settings] dialog box is displayed, click [Low - Med] to set the sensitivity in the range of 1 to 128, or [Med - High] to set in the range of 129 to 256.

Set the [Area Ratio]

[Area Ratio] is the degree of change of area (ratio against the defined detection area) detected as motion.

Click and drag the [Area Ratio] slide bar to any position from 0% to 100%. This establishes the proportion of image inside the Active Region (dotted frame) allowed before motion is detected.



When you drag the slide bar, the black vertical line in the Detection Indicator will move to reflect the change in specified [Area Ratio].




[Area Ratio] marker.



Although the duration for recognizing motion is fixed at 0.2 seconds, this can also be changed if necessary. To change this setting, select the [Detail Settings] checkbox and click the [Settings] button. The [Detail Settings] dialog box is displayed, and the value can be change in the range of 0.0 to 5.0 seconds.

Step 4: Set the Detection Regions (VB-C500VD/VB-C500D/VB-C60)

- 1. If you want to partition the detection region for notifications, check area the [Notice events with the area name when motions are detected] checkbox.
- 2. Check the [Record on this area] checkbox on the recording settings tab.





This operation is not necessary if you want configure the recording settings over the entire region without partitioning the detection regions.

Step 5: Set the event priority status

In the [Priority] field, select the priority for the event to be generated for this motion from a menu of five options, ranging from [1. Highest] to [5. Lowest]. Priorities are color-coded in the Timeline in the Viewing Screen.






When the same priority level is set to multiple detection areas, the schedule is executed in the order of Area 1, 2, 3 and 4.

Step 6: Set frame rate and pre and post event recording duration

1. [Max. Frame Rate] - select a maximum frame rate for recorded video from the drop-down menu. Choose from 0.1 frames per second to 30 frames per second (5 is the default).



2. [Record for] [sec. before event] - enter a number of seconds for the amount of recording time before the event occurs (up to 30 seconds).

Note

- If [Continuously at Max.] is also selected, Record for before event is not available.
- If Record for before event is set, it will take approximately 10 seconds after event occurrence until its display in the viewer.
- If the resolution is set to MPEG-4, the frame rate set in the VB-C500VD, VB-C500D or VB-C60 becomes enabled.
- 3. [Record for] [sec. after event] enter a number of seconds for the amount of recording time after the event occurs (up to 999 seconds).

Step 7: Set the [External Outputs]

Click the drop-down menu for the target external device and set [On] or [Not specified].



☑ Note

Available external outputs depend on the Camera Server.

Click [OK] to save the new settings and close the dialog.

Click [Cancel] to discard the new settings.

☑ Note

Even with 0 seconds set to [Recorded for __ sec. before event] and [Recorded for __ sec. after event] fields, video is still recorded while motion is being detected.



See Chapter 6 for optimizing the Motion Detection operation.

Set Sensor Event Recording VK-64/16



Set Sensor Event Recording Settings

The Sensor Event recording starts when a sensor input has occurred.

Configure the Sensor Event recording settings in the [Sensor Event Settings] window which appears when you click [Settings].

Some items in the [Sensor Event Settings] window overlap with the items in the [Add Schedule Item] and [Edit Schedule Item] dialog. When the Sensor Event recording is executed, the settings in the [Sensor Event Settings] window take precedence.



If the recording schedule expires during Sensor Event recording, the Sensor Event recording also terminates.




If using a VB150 with multiple cameras and [Video Input] is specified, you can configure different Sensor Event recording settings for each camera (or you can specify [Do not record]).

Edit Sensor Event Recording Settings

You can specify recording settings based on the occurrence of a sensor event. A number of tabs in the [Sensor Event Settings] dialog are shown to reflect the number of sensors on each camera. You can modify the recording settings for each sensor.

Step 1: Click [Settings] next to [On sensor event]

The [Sensor Event Settings] dialog appears.



Note

- Frequent sensor events result in high CPU load on the Storage Server. If you have 10 or more sensor
 events per minute continuously, it is recommended that you should set continuous recording.
- If setting [Night Mode] on VB-C50iR, IR cut filter will be inactive. It will not turn on the built-in IR light. To turn on the IR light, perform the operation from the Video Window menu.

Step 2: Enable recording and set an event priority

- 1. Check [Record on this sensor] to enable recording when a sensor is triggered.
- 2. In the [Priority] field, select the priority for the event to be generated for this motion from 5 options, ranging from [1. Highest] to [5. Lowest]. Priorities are color-coded as events in the Timeline in the Viewing Screen.



Step 3: Specify a camera angle when the sensor is triggered



In [Camera Angle], select a preset camera angle from the [Preset] drop-down menu. When the sensor is triggered, the camera will be moved to this position.

If you select [Not specified], the camera will not be moved.

The camera angle can also be changed by moving your mouse pointer in the [Preview] area to display controls and clicking to pan, tilt and zoom (→ P. 4-22). After the camera has been controlled, the [Preset] will be set to [Custom].

Mote

- If you set the viewing angle to the preset position of VB-C300 in the digital zoom region, the actual angle may be misaligned from the set angle.
- Camera Servers have functions to record video on memory of the camera by the sensor input or schedule. If the settings are enabled on the Camera Server, they take precedence.
- The [Preset] location cannot be selected as VB-C500VD and VB-C500D do not support this function.

🎉 Tip

- Click the [Exposure Compensation] drop-down menu and select [On] to compensate for camera views with strong backlighting. The setting will be used when the sensor is triggered. This is useful, for example, if a camera angle would change from an indoor view to an outdoor view when the sensor is triggered.
- If you set the [Preset] option in the [Sensor Event Settings] window, the pre-event recording position may be different from the specified position because the Camera Server moves when a sensor input occurs. Also, if you specify the post-event recording time to "0", and the sensor input occurs for a short period of time, recording may terminate before the Camera Server reaches the preset position.
- If you are using a normal close type sensor, you need to set the presets with the Camera Server recording screen. See "Configure External Device Input" (→ P. 4-21) for the details.

Step 4: Set the Night Mode (VB-C500VD, VB-C500D, VB-C60, VB-C300, VB-C50i/ VB-C50iR, VB-C50FSi, and VB-C50Fi)

Select the [Night Mode] from the drop-down menu. You can select from [Disabled], [Enabled], or [Not specified].



Step 5: Set Additional Options (VB-C500VD, VB-C500D, VB-C60, VB-C300)

To use the Exposure, White Balance, Shade Control, and/or Focus settings on the [Camera Control] Panel, check the corresponding check box.




■ Note

- The additional options are available with VB-C500VD/VB-C500D/VB-C60/VB-C300. [Smart Shade Control] is available with the VB-C500VD/VB-C500D/VB-C60. Additionally, Focus is not available for the VB-C500VD/VB-C500D.
- If [Exposure] is selected, the [Exposure Compensation] option is set to [Not Specified].

Step 6: Set frame rate and pre and post event recording duration

In the [Record Video At] field:

1. [Max. Frame Rate] - select a maximum frame rate for recorded video from the drop-down menu, or enter a value from the keyboard. Choose from 0.1 to 30 frames per second (5 is the default).



Mote

- The frame rate specified is the frame rate that the Storage Server will attempt to record, and may not be the actual frame rate used for recording video. Factors such as the number of Viewers, the number of Camera Servers used, network traffic and load on the Camera Server and the Storage Server may reduce the actual frame rate recorded.
- While the [Resolution] is set to [MPEG-4], the frame rate drop-down menu is gray out. However, the video is recorded at the frame rate specified in the VB-C500VD/VB-C500D/VB-C60 setting page at that point.
- 2. [Record for __ sec. before event] enter a number of seconds for the amount of recording time before the event occurs (up to a maximum of 30 seconds).

Mote

- If [Continuously at Max.] is also set, [Record for ___ sec. before event] is not available.
- If [Record for __ sec. before event] is selected, it will take approximately 10 seconds after event
 occurrence until its display in the viewer.

3. [Record for __ sec. after event] - enter a number of seconds for the amount of recording time after the event has transpired (up to a maximum of 999 seconds).

Click [OK] to save the new settings and close the dialog.

Click [Cancel] to discard the new settings.




- If the [Record for __ sec. before event] or [Record for __ sec. after event] event fields are set to 0 seconds, video will still be recorded while the sensor is activated.
- Longer pre-event recording will increase memory usage. Longer pre-event recording with insufficient memory may greatly reduce performance when the disk-based virtual memory runs short.

Step 7: Set the External Outputs

 Click [External Outputs Setting] to control any external devices that may be connected to your Camera Server.



- 2. Click [Setup] to change the details of external outputs. Otherwise the default settings will be applied.
- 3. If [Setup] is clicked, click the drop-down menu for the target external device and set [External Outputs] to [On] or [Not specified] on the [External Outputs Setting] dialog.





Available external outputs depend on the Camera Server.

Priorities of Motion Detection and Sensor Event Recordings

You can specify events priorities for the Motion Detection and Sensor Event recordings, and if the events occur simultaneously, the recording with the higher priority is performed first.

When using the Motion Detection and Sensor Event recordings together and motion detection and sensor input occur simultaneously, the Sensor Event recording takes precedence.

If two events with the same priority occur, the earlier event takes precedence. When the earlier event terminates and the later event still remains, the later event will be handled.

Set Preset Tour

Use the Preset Tour function to move among multiple preset positions sequentially.

In the [Add Schedule Item] and [Edit Schedule Item] dialog, there are two options available for setting the Preset Tour function. Procedure to set the Preset Tour function in as follows.

Note


- When Preset Tour and MPEG-4 are used together, the video data size becomes very large.
- The durability of camera Pan/Tilt mechanism may be affected depending on the Preset Tour setting (→ P. 4-61).
- In the Preset Tour, the camera position returns to the first preset after the last preset.
- When the Preset Tour is used, the Motion Detection recording, Exposure compensation, and additional options are not available.
- Presets used for Preset Tour are created on the Camera Server. Please see the Camera Server's User's Manual for details on creating camera presets.
- Preset Tour can be used with VB-C60, VB-C300, VB-C50i, and VB-C50iR only.

Set Preset Tour

Add a Preset

- 1. Check the [Preset Tour] box and click [Settings].
 - The [Preset Tour Settings] dialog appears.
- 2. Click [Add].

The [Preset Tour (Add)] dialog appears.



3. Select a preset to add from the [Preset] drop-down menu.



- 4. For the selected preset, configure the [Speed (PT)], [Speed (Z)], and [Pause (sec)] settings.
- 5. Check the settings and click [OK].

This returns to the [Preset Tour Settings] dialog.

Test the Preset Tour

1. Check the [Preset Tour] box and click [Settings].

The [Preset Tour Settings] dialog appears.

2. Click [Start Test].

After clicking [Start Test], the Preset Tour is executed once and you can confirm the operation.

Change the Preset Settings

1. Check the [Preset Tour] box and click [Settings].

The [Preset Tour Settings] dialog appears.

2. Select a preset to change from the list and click [Edit].

The [Preset Tour (Edit)] dialog appears.



- 3. For the selected preset, change the [Speed (PT)], [Speed (Z)], or [Pause (sec)] settings.
- 4. Check the settings and click [OK].

This returns to the [Preset Tour Settings] dialog.



For VB-C300 and VB-C60, you can return the focus to the default setting by checking the [Return to the default focus setting when the camera is operated] option.

Change the Preset Order

1. Check the [Preset Tour] box and click [Settings].


The [Preset Tour Settings] dialog appears.

2. Select a preset to change the order from the list, and click [Move Up] or [Move Down].

Delete a Preset

1. Check the [Preset Tour] box and click [Settings].

The [Preset Tour Settings] dialog appears.



- 2. Select a preset to delete from the list and click [Remove].
- 3. Click [OK].

This returns to the [Preset Tour Settings] dialog.




When you delete camera server's presets, please be sure to check presets of VK-64/VK-16.

Note

If the following warning appears, change the settings according to the tables below.

Warning example



Click [Cancel] to return to the setting screen.

Click [OK] to save the current settings.

(If you are using the Preset Setting Tool, click [Save] on the setting page of the tool)

Endurance of VB-C50i and VB-C300's pan/tilt mechanisms are approximately 100,000 round trips* at the full range. The total tour time depends on the combination of the movement rate, movement range, and still time. See the following tables.

Total tour time for 100,000 round trips in the pan direction (estimated).

Movement rate (PT) is 1.

Still time (sec.)	Movement range in the pan direction (angle)		
(SEC.)	± 50	±100	±150
0	3872	3825	3809
10	5666	4722	4407
20	7555	5666	5037
30	9444	6611	5666

Movement rate (PT) is 2.

Still time	Movement range in the pan direction (angle)		
(sec.)	±50	±100	± 150
0	1983	1936	1920
10	3777	2833	2518
20	5666	3777	3148
30	7555	4722	3777

(Unit: Time)

(Unit: Time)

Example: If the movement rate (PT) is 1, still time is 30 seconds, and movement range (angle) in the pan direction is 50 degrees, it takes approximately 9,444 hours for 100,000 round trips in the pan direction.

Endurance of VB-C60's pan/tilt mechanism is approximately 300,000 round trips* at the full range.

Total tour time for 300,000 round trips in the pan direction (estimated).

Movement rate (PT) is 1.

Movement range in the pan direction (angle)		
± 50	±100	±150
11616	11475	11427
17000	14166	13222
22666	17000	15111
28333	19833	17000
	pan di ± 50 11616 17000 22666	pan direction (and ±50 ±100 11616 11475 17000 14166 22666 17000

Movement rate (PT) is 2.

Still time (sec.)	Movement range in the pan direction (angle)		
(SEC.)	± 50	±100	±150
0	5950	5808	5761
10	11333	8500	7555
20	17000	11333	9444
30	22666	14166	11333

(Unit: Time)

(Unit: Time)

^{*} According to our company's estimations.

Set a Special Day Schedule VK-64/16




Special Day Recording

[Special Day Schedule] window is used for configuring particular days such as public holidays. When [Special Day Schedule] is selected, [Normal Schedule] that conflict with [Special Day Schedule] is disabled.



In [Configuration and Preferences] Screen, click [Recording Schedules] tab and ensure [Special Day Schedule] is selected. [Special Day Schedule] consists of:

- [Storage Server] Select Storage Server from the list to add/edit schedules for that server. Associated Locations and Zones are displayed in the Schedule Area.
- [Special Day Schedule] Allows you to select a schedule type. These are user-defined schedules such as Public Holidays and Long Weekends.
- [Days] list Allows you to choose a day to use this schedule.
- Schedule Area Covers a single day, 24 hours. Overrides a Normal day schedule.



Add, Edit and Delete a Schedule Type

[Add Schedule Type] dialog allows you to create a name for a new schedule type, for example, a public holiday. You should create a schedule type first before you can associate days with it. There is no limit to the number of schedule type that can be added.

To launch the dialog and add a Special Day Schedule.

[Add Schedule Type]

1. Click [Add].

The [Add Schedule Type] dialog appears.



- 2. Enter name in the [Schedule Name] area, for example "Company Holidays".
- 3. Click [OK].

The schedule type is added and the dialog closes.

The new name will appear in the [Special Day Schedule] list.



- The scheduling area functions are the same as the Normal Recording Schedule but only covers a single day (from 00:00 hrs. to 24:00 hrs). To have a special day schedule run over a long weekend (Fri, Sat & Sun), all dates of three days should be added to the list of days to use the schedule.
- When Special Day Schedules are running, Normal Schedules are disabled. If an invalid schedule exists, the following warning message will be displayed. "There is a camera to which the recording schedule is not registered. Is it OK to leave it like this?"

Edit a Schedule Type

- 1. In the [Special Day Schedule] window, click a schedule type in the [Special Day Schedule] list to select it.
- 2. Click [Edit].



This will bring up the [Edit Schedule Type] dialog.

Enter a new name. For example, you may wish to change the name "Company Holidays" to "Company Special Days".

3. Click [OK].

The new settings are saved and the dialog closes.



Delete a Schedule Type

- 1. In the [Special Day Schedule] window, click a schedule type in the [Special Day Schedule] list to select it.
- 2. Click [Delete].

The schedule type is deleted.





If you delete a schedule type where there are dates associated with that schedule, a warning will appear. Delete the associated dates before deleting the schedule type.

Add and Delete a Day

[Select Date] calendar allows you to select a day that can be used for the schedule type.

To add a day, operate as follows:

Add a Day


1. In the [Special Day Schedule] window, click a schedule type in the Schedule Type list, for example, "Company Holidays" (created on P. 4-62) and then in the [Days] list click [Add].





This will bring up the [Select Date] calendar (see below).

2. Click to select a day in the calendar, then click [OK].



Click [Add] again to add another day to the same schedule type if you wish.

Added days are shown in the [Days] list (see example on next page).

Other calendar selection methods are shown on the next page.

Alternatively, click the current month and a month list will appear.



To select another year, click the current year and scroll down or back up, using the up/down arrows.

Delete a Day


- 1. In the [Special Day Schedule] window, click a schedule type in the [Special Day Schedule] list, for example, "Company Holidays" and then in the [Days] list click one of the days associated with the schedule type.
- 2. Click [Delete] below the [Days] list. The day is deleted from the schedule type.



∏ Note

- If you attempt to associate the same day with different special day schedules, a warning brings up and asked to delete the other entry before creating a new one.
- Expired days are listed in italics.

Save Changes





The bottom right-hand corner of the [Recording Schedules] window consists of two buttons, [Save Schedule] and [Discard Changes].

1. Click [Save Schedule] to keep all your settings

The settings are then saved to the Storage Server.


Click [Discard Changes] to cancel any changes you have made.

2. If you wish to return to the Viewer, select [View] > [Viewing Screen] from the menu bar.

Display Recording Setting Summary

Check Summary Information of a Recording Schedule

Display the summary information of the set recording schedule.



[Display Record Settings Summary] is located at the center-bottom of the [Special Day Schedule] window.

Click [Display Record Settings Summary] to display the [Record Settings Summary] dialog.



The [Record Settings Summary] dialog shows the following information for the time period where the highest load is expected when the schedule is performed.

Count of camera

Count of motion detection camera

Total record frame rate

Total record frame rate (Continuous recording)

Total record frame rate (Sensor event/motion detection)

Max. Storage Period

Max. File Size/h

Disk usage

After confirming information, check the details and click [OK] to close the [Record Settings Summary] dialog.




If the load is too high, adjust the recording schedule.



Click [Copy] to copy the contents of the [Record Settings Summary] dialog to the Clipboard.

Check Summary Information of Storage Server

You can check summary information of a specified Storage Server.



The [Display Storage Server Summary] button is in the bottom center of the [Camera Summary] screen.



- The [Display Storage Server Summary] button is gray out in Storage Servers in older version.
- When the [Locations / Zones] tab is selected, the [Display Storage Server Summary] button is gray out.

Click the [Display Storage Server Summary] button to display the [Storage Server Summary] dialog box.



The following information is displayed in the [Storage Server Summary] dialog box.

Total network band (units of Mbps)

Number of frames waiting to write for each drive

Check the details and click [OK] to close the [Storage Server Summary] dialog box.

Note

- The [Storage Server Summary] dialog box displays information about the Storage Server selected in the Storage Server List. It does not display the totals for all Storage Servers.
- The number of frames queued for writing displayed here is the number of frames queued for recording.
- If the number of frames queued for writing always exceeds 5,000, reduce the video recording frame rate, or decrease the image size or quality to reduce the number of frames queued for writing. If the number of frames queued for writing exceeds 10,000, dropped frames occur.
- Click the [Copy] button to copy the contents of the [Storage Server Summary] dialog box to the clipboard.
- Click the [Update] button to update display the latest data and update the camera list display.

🎉 Tip

You can check the number of frames queued for processing for the entire frame queue of each camera on the [Camera Summary] screen (\rightarrow P. 4-8).

Viewer Reference

Chapter Overview

This chapter explains how to use and configure the Viewer.

Set Viewer

Explains how to configure settings that are specific to the Viewer.

Arrange and Save Layouts

Explains how to arrange layouts and set layout sequences.

Video Window Operation

Explains how to create a video window and display it in the Viewing Area and control the Camera Server.

Use Timeline and View Events

Explains how to use the Timeline for live and recorded viewing as well as view and search events.

Viewer Operation Flow

[Location] list (→ P. 5-31)

Drop-down menu indicating locations available in the system.

[Zone] list (→ P. 5-31)

Drop-down menu indicating zones within a location.

[Camera Control] Panel (→ P. 5-39) [Camera Control] Panel enables you to control a camera and quickly determine a camera position.

Event indicator (→ P. 5-37)

Color bar is displayed at the top of live Video Windows when an event occurs (if enabled).

Viewing Area for Video Windows (→ P. 5-10)

Video Windows can be arranged here. Video Windows can be re-sized as well.

They can also be arranged into a uniform grid.

Video Window (→ P. 5-32)

Recorded videos and live videos are displayed in these windows.

Camera Server (→ P. 5-48)

Name of the Camera Server currently selected.

Playback control (→ P. 5-48)

Click the VCR-like controls to play, rewind, fast forward or jump to previous and next events.

Timeline control (→ P. 5-48)

Scroll forwards through the current day or jump forward incrementally by day or week.

Timeline (→ P. 5-48)

Past date and time as well as events which occurred are displayed here. Events are displayed as bars colored according to the priority. Click and drag the Time bar to go back or forwards in time.

Menu bar

Access common menus from here.



[Record Now] button (→ P. 5-52) A instant manual

recording for one minute.

[Capture Still Frame] button (→ P. 5-53) Click to keep the current image on a Video Window.

Camera Selection Area (→ P. 5-30)

Thumbnails of Camera Servers added to each zone are displayed here. Thumbnail can be dragged onto the Viewing Area for viewing.

Video window menu icon (→ P. 5-43) Select preset camera angles, custom pan, tilt and zoom, and select a Video Window size.

- FX

[Live Events Log] list (→ P. 5-56) Indicates events that have been recorded on Storage Servers after the Viewer was launched.



[Zoom In] [Zoom Out] buttons (→ P. 5-53)

Click to zoom in or out the Timeline.

[Event Search] button (→ P. 5-58) Click to bring up a dialog and enter searching condition such as time range, Location/Zone and priority to find the event which occurred in the past.

[Jump to Time] button (→ P. 5-51) Click to enter a specific date and time to jump to, to start playing recorded video. The Timeline moves to the specified time.

[Extract Video] button (→ P. 5-54) Click to extract a segment of video to save as file.

[Return to Live] button (→ P. 5-55) Click to return the Timeline Playhead to the current time. If you click this button while playing recorded video, the selected Video Window will return to live video.

Timeline control (→ P. 5-49) Scroll forwards through the current day or jump forward incrementally by day or week.



Timeline Play Head (→ P. 5-50)

Drag the play head to a position on the Timeline to start playing back recorded video from that time.

Start the Viewer



To start the Viewer, you need the user name and password set for the VK-64/VK-16 Storage Server.

■ How to Launch

Before launching the Viewer, make sure your monitor resolution is set to 1024 x 768 pixels or more.

Start the Viewer

To start the VK-Lite Viewer, double-click [VK-Lite Viewer v2.2] on the desktop.

Or, from the Windows [Start] menu, click [Programs] > [WebView Livescope] > [Network Video Recorder VK-Lite v2.2] > [VK-Lite Viewer v2.2].



To start the VK-64/VK-16 viewer, double click [VK Viewer v2.2] on the desktop.

Or, from the Windows [Start] menu, click [Programs] > [WebView Livescope] > [Network Video Recorder VK Series v2.2] > [VK Viewer v2.2].



The connect option menu for Storage Server appears. Select the [Master Storage Server] option and click [Connect].

Start-up Screen



[localhost]

Connects to Storage Server and launches Viewer. Select this option to use the local PC where Viewer is installed as Master Storage Server.

[Use IP address]

Connects to Storage Server and launches the Viewer by specifying its IP address. Select this option when Storage Server and the Viewer are installed on separate PCs.

[Not use Storage Server]

Select this option to use Viewer only without connecting to Storage Server.



A connection error may occur when the Master Storage Server is not operating.

■ Launch by Connecting to the localhost

If you want to use the local PC where Viewer is installed as Master Storage Server, select localhost to start Viewer.

1. Select [localhost] from the drop-down menu.



- 2. Click [Connect].
- 3. Enter your [User Name] and [Password], and click [Login].





The user name and password for VK-64/VK-16 entered in this step are configured by [Storage Server Configuration] dialog. They are different from the user name and password used to log Windows.

■ Launch Storage Server by Specifying the IP address

If you installed Viewer and Storage Server on separate PCs, specify IP address of Storage Server and connect Viewer to the Storage Server.

1. Select [Use IP address] from the drop-down menu.



- 2. Click [Connect].
- 3. Enter IP address or host name of Master Storage Server in [Host Name or IP], and the port number in [Port].



- 4. Click [Connect].
- 5. Enter your [User Name] and [Password], and click [Login].





- If you need to use proxy server, you need to change the Internet option settings in the following procedure:
 - 1. Select [Start] > [Control Panel] > [Internet Options].
 - 2. Select the [Connections] tab.
 - Click [LAN settings].Change the proxy server settings.
- If using proxy server between Viewer and Storage Server, it should not perform response buffering.
 Proxies which are configured to perform response buffering may lead to delays in sending small amounts of data (such as events) from the Storage Server to the Viewer. Apache proxy server does perform response buffering so is not recommended.
- You cannot transmit or receive audio when using proxy server.

■ Launch without Storage Server (Viewer Only Mode)

You can use the Viewer only without connecting to a Storage Server. When Storage Server is not used, some functions are not available.

Use Viewer only

1. Select [Not use Storage Server] from the drop-down menu.



2. Click [Connect].

■ Functions not Available in Viewer Only Mode

When you launch the Viewer with Viewer Only Mode, the following functions are not available.

Viewing Screen


- Timeline is not displayed. [Timeline] under the [View] menu cannot be used.
- [Capture Still Frame] feature cannot be used.
- [Search Events] under the [Edit] menu cannot be used.
- [Live Events] under the [View] menu cannot be used.
- [Shared Layouts] are not displayed.
- In the [Add Layout Sequence] dialog, a type of layout is fixed to [Personal Layout Sequence].

Configuration and Preference Screen

- [Recording Schedules] tab is not displayed (→ P. 4-28). Some functions such as video recording, sensor events, and motion detection are not available.
- In the [Storage and Camera Server Summary], [Storage Server] tab is not displayed (→ P. 4-8).
- In the [Storage and Camera Server Summary], the Camera Server list shows only Camera Server, Locations / Zones and Type (→ P. 4-8).
- In the [Add Camera Server] and [Edit Camera Server] dialog, the following items are gray (disabled):
 - [Save Recorded Video on]
 - [Camera Server Settings]
 - [Camera Settings] > [Save video in]
- In the [Viewer Settings] window (→ P. 5-13), items in the [Event Notification Settings] area are gray (disabled).

■ Viewer Start-up Window

When you start VK-64/VK-16 for the first time when no Layouts have been configured, you will notice that the Viewing Area is blank as shown below. Previously-configured cameras on the network will appear as thumbnail images in the Camera Selection Area on the top of the screen. These can be dragged onto the Viewing Area for monitoring. If your Administrator has already created a Layout for you, then the Viewing Area will display the first Personal Layout (or first Shared Layout if there are no Personal Layouts) as shown in the example on the previous pages.



See P. 5-19 for details on editing layouts.



While the Viewer Screen is active, your PC does not automatically enter the Sleep or Standby mode.

■ Viewer Start-up Option

You can set the start-up option of the Viewer to omit the display of Start-up screen (\rightarrow P. 4-3) and login screen to enter a user name and password (\rightarrow P. 4-5, P. 5-7).

You can place a shortcut icon on the Desktop for your convenience by following the method described below.

For this setting, you cannot use the shortcut icon that was automatically created on the Desktop after installing this software, which is used for starting the Viewer.



Password can be referred through the Properties of the shortcut icon. You need to make sure that the Password is secure.

1. Right-click on the icon for NVR_Viewer.exe located in the installation directory and select [Create Shortcut] from the menu. The shortcut icon will be created. Move it to the Desktop.


The default destination directory is shown below. <System Drive>:\Program Files\Canon\WebView\NVR



🄅 Tip

<System Drive> is a drive that contains a directory (folder) in which the Operating System files are stored. For example, if the Operating System is installed on Drive C, your system drive is Drive C.

2. Right-click on the shortcut icon that was moved onto the Desktop and select [Properties] from the menu.



Specify [Target] as follows (using alphanumeric characters)

-h=<IP address of the Storage Server>

This specification is mandatory (→ P. 4-5, P. 5-7).

-p=<port number> It can be omitted. When omitted, 80 is specified

(→ P. 4-5).

-u=<user name> Specify the user name (→ P. 4-4).

-pw=<password> Specify the password (→ P. 4-4).

-u and -pw can be omitted. When omitted, the start-up screen will not be displayed (→ P. 4-3, P. 5-6). Instead, the login screen for entering a username and password is displayed. When you use the Viewer alone, you also need to specify "nohost" for -h.

Example

"C:\Program Files\Canon\WebView\NVR\NVR_Viewer.exe" -h=192.168.100.1 -p=80 -u=admin -pw=NVR

Make sure to enter a space after "C:\Program Files\Canon\WebView\NVR\NVR_Viewer.exe".

Menu Bar of Viewer Screen

■ Functions of Menu Bar

The following functions are available from the menu bar.



Menu	Submenu	Function
File	Change Master Storage Server	Switches master storage servers. The connection menu for storage servers is displayed.
	Exit	Closes the application.
Edit	Cut	A selected video window is deleted and transferred to the clipboard, so that the window can be pasted into the same layout or another layout.
	Сору	A selected video window is copied into the clipboard, so that the window can be pasted into the same layout or another layout.
	Paste	A cut/copied video window is pasted into the current layout.
	Delete	A selected video window is deleted from the current layout.
		Select Delete in the [Storage and Camera Server Summary] screen, so that a selected storage server/camera server/location/zone is deleted.
		Select Delete in the [Recording Schedules] screen, so that a selected normal schedule/special day schedule is deleted.
	Select All	Selects all of the video windows in the current layout.
	Search Events	Displays the [Event Search] dialog.
View	Configuration	Select Configuration while the viewer window is open, so that the window switches to the [Configuration and Preferences] screen.
	Viewing Screen	Select Configuration while the [Configuration and Preferences] screen is open, so that the window switches to the viewer screen.
	Fullscreen	The menu bar and the title bar are hid and the area for displaying video windows becomes larger. Press the [Esc] key to return to the previous status (return to the mode before selecting the Fullscreen mode).
	Captions	Switches display and hide video window's title bar.
	Camera Selector	Switches display and hide the Camera Selection Area.
	Timeline	Switches display and hide Timeline.
	Live Events	The [Live Events Log] window is displayed at the same position and in the same size as previously displayed. The checkmark in the menu means that the window is open. Select the menu item again to close the window and the menu item is unchecked.
	Camera Control	Displays the [Camera Control] panel], allowing the display position settings or zoom.
	Audio Panel	Displays the [Camera Control] panel, allowing the display position settings or zoom.
	Status Bar	Switches display and hide the status bar. Several information is displayed in the status bar, such as the total frame rate, CPU %, the number of displayed events, and the number of video windows.
Help	About	The [version information] dialog appears, showing the version information.

Viewer Setting

[Viewer Settings] window

The [Viewer Settings] window is used for settings such as notification priorities and the live viewing frame rate. Settings are stored on the Viewer PC, not on the Master Storage Server.



The [Viewer Settings] screen is divided into tabs for administrators and guest users depending on the settings. The [Viewer Settings (Admin)] tab is displayed only when the user logs in as an Administrator. Each of these tabs consists of the following settings.

[Viewer Settings (Admin)] tab

- [Master Storage Server] You can switch to display or not to display the Master Storage Server option window (connection menu) on start-up, and also add/delete Master Storage Server into/from the connect menu.
- [Layout setting] Confirm if the layout was preserved when quitting or when the screen changes.
- [Video Window Popup Setting] Enables you to set whether video is displayed at the same time as
 events occur.
- [Event Notification Settings] Set operator notification and adjust duration in seconds, set operator acknowledgement (recognition) of an event, set an audio alert, and suppress event display.

[Viewer Settings] tab

- [Video Viewing Settings] Select the maximum viewing frame rate for live videos.
- [Proxy Setting] Use this option to make an access to Storage Server via proxy server.
- [Audio Setting] Set automatic termination of audio transmission after a specified period of time.
- [Focus Operation Setting] Set the focus position to return to the default setting of the camera when operating the camera.
- [Still Frame Capture Setting] Enables you to configure the date and time to be additionally displayed on still frames.




Be sure to perform the operational tests after setting the viewer.

Set the Tab for Administrator

■ Set whether to select the Master Storage Server when the Viewer starts up

A Master Storage Server maintains settings for Camera Servers and Layouts.



The following settings are available.

- Select the [Select a Master Storage Server when starting] checkbox to enable you to select the Master Storage Server when the Viewer starts.
- 2. Click [Add Storage Server] to add the current Storage Server to the connection menu.
- 3. Click [Delete Storage Server] to delete the current Storage Server from the connection menu.

Set layout of the Viewing Screen

If you wish to confirm whether the layout information has already been saved when finishing the Viewer or when switching to the Viewing Screen, tick the [Confirm if the layout is saved when quitting or when the screen changes] check box and restart the Viewer. If not ticked, the layout information will not be saved.



■ Set Event Popups


Select the [Popup a video window automatically when an event occurs] checkbox to display the live video in the foreground and begin live viewing when an event such as a sensor on occurs.



■ Set Event Notifications

When an event occurs, it is indicated in the [Live Events Log] in the Viewer. In [Event Notification] Settings in the [Viewer Settings] window, [Event Notification Settings] area, you can set up actions based on events according to the priority of the event.

Set alert of event in each priority level



In the Priority area, you configure the following settings:

1. Tick the [Operator Notification for] box to enable a notification period when an event occurs.

Select a notification period in seconds from the [Seconds] drop-down menu or enter it from the keyboard (0 - 99). When a event occurs, the event flashes in the [Live Events Log] window for the period of time specified using this option, and a color bar indicating the event's priority light on the top of a live Video Window for one minute.

If you specify 0 second, an event which has occurred will not flash and a color bar will light for one minute.

2. Tick the [Operator acknowledgement] box for the event.

When an event occurs it will flash in the [Live Events Log] and the audio alert will sound (if specified) until the operator double-clicks on the event (that is, the notification time will not apply to the event in the event log).

3. Tick the [Audio Alert] box to have an audio alert play during the event notification period.

The Windows system sound [Exclamation] is used for audio alerts (For a PC with no sound port installed, a beep sound is used). This sound repeats for the duration of the [Operator Notification for ___ seconds]. If [Operator Notification for ___ seconds] is not set, the audio alert is played once.

4. Tick the [Don't show events] to have the event not displayed on the Timeline of the Viewing screen or on the [Live Events Log] window even if the event occurs.




Even if [Don't show events] is ticked, events are shown in the [Search Results] in the [Event Search] dialog.

About Priorities

Set up notifications by priority from 1 (highest) to 5 (lowest). Priorities are color-coded as follows.

Color	Priority
Red	Highest
Orange	High
Yellow	Medium
Light Green	Low
Dark Green	Lowest



Lower priority items can have less notification settings associated with them.

Set the Tab for Guest User

■ Frame Rate Setting for live video

The maximum frame rate when displaying live video can be configured. Select the value of the frame rate from the drop-down menu. Select the [Auto Adjust Frame Rate] checkbox to have the frame rate adjusted automatically.



Note

- If a high maximum frame rate is specified, the load on the computer CPU will be high and Viewer operations may take longer. When [Auto Adjust Frame Rate] is ticked, frame rate is automatically reduced when CPU load becomes high.
- If the resolution is set to MPEG-4, the [Max. Live Frame Rate] and [Auto Adjust Frame Rate] settings are ignored. In this case, the frame rate setting of the VB-C500VD/VB-C500D/VB-C60 is active.

■ Automatic Audio Termination Setting

The camera which is sending or receiving audio to a Viewer cannot interact with other Admin or NC Viewers. Audio transmission and reception can be terminated automatically even if you forget to disconnect the audio connection.



When using this option, tick [Close the audio session after] check box, and specify the period within the range from 1 to 60 minutes (default is 10 minutes). When the specified period of time passes during audio transmission, it will be terminated automatically.



Automatic termination works even while audio is being transmitted/received. However, if switching the video window to another, the audio function will become available again.

■ Focus Operation Setting

You can set the camera to return its focus mode to the default setting when the camera orientation is changed. The focus mode returns to default if it has been changed to Manual after any focus operation using a preset with focus setting defined or via Camera Control Panel.



Use this option by ticking the [Return to the default focus setting on the camera side when the camera is operated] check box.

■ Proxy Server Setting VK-64/16

When you wish to access the Storage Server Using the proxy server set in the Internet Option, tick [Use internet proxy settings] and restart the Viewer.






To use a proxy server, you need to set the [Internet options] settings (\rightarrow P. 5-7).

■ Superimpose the Date and Time on Still Frames

Select the [Superimpose the date and time on the still frame] checkbox to additionally display the date and time of capture on still frames.



■ Save Viewer Settings



The bottom right-hand corner of the [Viewer Settings] window consists of two buttons, [Save Changes] and [Discard Changes].

· Click [Save Changes] to keep all your settings. The Viewer settings are then saved to the local disk.



Click [Discard Changes] to cancel any modifications you have made.

If you wish to return to the Viewer, select [View] > [Viewing Screen] from the menu bar.

Arrange and Save Layouts

This chapter details how to create and save Video Window Layouts and Layout Sequences.

Manage Video Layouts

■ Layout menu


The Layout menu allows you to save particular Video Window layouts for easy monitoring.

The name of the currently-displayed layout can be found in the top-left corner of the Viewing Area, next to the Layout button. You can create a new layout, save a layout or open and rename a previously-saved layout.



Click the Layout button to open the Layout menu. You can also right-click anywhere in the Viewing Area to display the Layout menu.

Below the Layout menu options, existing Layouts are displayed and divided into two sections.






The layout displayed when launching the Viewer is the first layout listed in the Personal Layouts (or in the Shared Layouts if there is no Personal Layouts).

To create a new layout (a previously-saved layout is displayed):


Click the Layout button open the menu, and then select [New Layout].

The Viewing Area will become blank and the default layout name [Untitled] will be displayed.

The process of creating folders and saving a layout could be done in the following order:



Drag the Camera Server's thumbnails onto the Viewing Area to create the layout.




■ Organize Layouts and Layout Sequences

The [Organize Layouts & Layout Sequences] dialog allows you to create folders and sub-folders in which to save item (layouts and layout sequences). To display the dialog:

Open the Layout menu and select [Organize]

The [Organize Layouts & Layout Sequences] dialog opens (Administrator version shown). The [Shared Layouts] folder will not display if you have logged in as an Operator.



Create a new folder


- 1. In the [Organize Layouts & Layout Sequences] dialog, click on a shared or personal folder and then click [Create Folder]. The Folder Name dialog appears.
- 2. Enter a name up to 50 characters and click [OK].



The new folder will appear in the [Organize Layouts & Layout Sequences] dialog.

Move or Copy a layout or layout Sequence to another folder

- In the [Organize Layouts & Layout Sequences] dialog, click an item to highlight it, then click [Move to Folder].
 The [Select destination folder] dialog opens showing a list of created folders.
- 2. Click to select the target folder in the list and click [OK].



The item will be moved into that folder.

If you selected [Copy to Folder], you can copy items in the same manner.

Move an entry up or down

Click an item or folder to highlight it, then click [Move Up] or [Move Down]. The item will move up or down within a folder.

Edit or delete a layout or folder

Click an item or folder to highlight it, then click [Edit]. The respective [Layout Name] or [Folder Name] dialog will appear for you to overwrite a new name.

Click an item or folder to highlight it, then click [Delete]. If you have Operator status, you will not be able to delete a shared layout or layout sequence.




- You cannot change the parent folder names, [Shared Layouts] or [Personal Layouts].
- You need Administrator privilege to manage shared folders (→ P. 3-25).

Save a Layout or Layout Sequence

Administrators and Operators can save layouts and layout sequences to an existing folder or a new folder via the [Save Layout] dialog.

Step 1: Open the Layout menu and select [Save] or [Save As]

The Save Layout dialog opens. A New Folder button and Name field is also available for you to create a new name and location for the copied layout or layout sequence.



Step 2: Create a name for the layout or layout sequence

- 1. Change [Untitled] or an existing layout name to save the item with a new name.
- 2. Click a location in the list. Click to select the folder to save the layout and click [OK].

The item is saved to that folder.

Alternatively, click [Create Folder] to create a new folder (→ P. 5-21) and save the item in there. For example, if you wish to save an Administrator-shared layout to a personal folder.


Once you have saved an item, the name will appear next to the Layout button in the Viewing Area.



Open a previously-saved layout

Click the Layout button to open the menu and then click a layout or layout sequence in the list. The item will be loaded onto the Viewing Area.


If you select another item without saving the current item, a dialog will appear prompting you to save the current layout or layout sequence (if the [Layout setting] (→ P. 5-14) in the [Viewer Settings] window is ticked).



■ Arrange Layout Sequences VK-64/16

You can set up an automated sequence of shared and personal layouts to display in the Viewing Area at set intervals.

- 1. From the Layout menu, select [New Layout Sequence]. The [Add Layout Sequence] dialog displays.
- 2. Enter a sequence name for the new layout sequence and choose a [Type] of layout sequence from the menu, [Personal Layout Sequence] or [Shared Layout Sequence] (you can switch between the two as you add layouts).
- 3. Use the [Add Layout >] button to add layouts to the new sequence. Click [Up] and [Down] to change the display sequence of layouts. Click [Delete] to delete the layout.
- 4. In the [Duration] menu, select a set duration of display time for each layout or enter a custom time, overwriting the existing time.



Shared Layout Sequence:

All the users can share these layouts. You need Administrator privilege to create a layout sequence. Normal users cannot modify these layouts.

Personal Layout Sequence:

Lists layouts created by the current user. Other users cannot use them.




- You can only save layouts as a layout sequence.
- For details about intervals, see "Notes on Operating Environment" (→ P. 1-12), "VK Troubleshooting" (→ P. 9-4).

Start Layout Sequences

To start the layout sequence, select it from the Layout menu.


When a layout sequence is running, further options are available in the Layout menu.



- Click [Edit Layout Sequence] to change settings in the currently-running layout sequence. The current sequence will be indicated as [Paused].
- Click [Resume Layout Sequence] to play the current layout sequence.

Layout Grids

You can customize your layouts by applying one of the following grids:




- [None] You can arrange Video Windows freely.
- [Alignment Grid] display a grid of dots in the Viewing Area. You can re-size Video Windows using the grid.
- [Small Grid], [Medium Grid] and [Large Grid] display a small (160x120), medium (320x240) or large (640x480) grid where you can place Video Windows using the grid.
- [Custom Grid] You can set the grid size (→ P. 5-28).

■ Alignment Grid

Select the [Alignment Grid] from the [Layout Grids] sub-menu. The Viewing Area displays a grid of dots. When you place a Video Window, it snaps to the grid boundaries.

Drag, drop and re-size a Video Window

1. In the Camera Selection Area, click a thumbnail image and drag its selection boundary onto the Viewing Area grid.



2. Move it to the position you want to display. When you release the mouse, the size and position are adjusted to match the layout frame.



To re-size the Video Window, click any corner and drag the image outwards to snap to a larger grid area. Release the mouse button. When you release the mouse, the size and position are adjusted to match the layout frame.

Create and align more Video Windows

Click and drag other camera thumbnails onto the Viewing Area to create Video Windows for monitoring, and resize the window. A layout example is shown to the right.




Small, Medium and Large Grids

When you select [Small Grid], [Medium Grid] or [Large Grid] from the [Layout Grids] sub-menu, the Viewing Area displays cells for Video Windows. These are boundaries indicating a uniform size which is used to display Video Windows in a tile-like manner.

Drag a camera thumbnail image into a blank tile

- 1. In the Camera Selection Area, click a thumbnail image and drag its selection boundary onto the Viewing Area grid.
- 2. Move it to the position you want to display. When you release the mouse, the size and position are adjusted to match the layout frame.





- The Layout menu is also available by right-clicking anywhere in the Viewing Area.
- A Video Window can be increased in size to take up a number of tiles, (for example 4 tiles, 9 tiles etc) so that Video Windows of different sizes/priorities can be viewed.
- The size of the image immediately after dragging it over the Viewing Area is fixed at 160x120.

The Viewing Area with a [Small Grid]




The Viewing Area with a [Medium Grid]





The number of viewers that can be simultaneously displayed will depend on your PC's video card, CPU performance, the Viewer's Maximum Frame Rate setting (→P. 5-16), and the size/image quality of video sent from the Camera Server. A maximum of 16 cameras is recommended in the Layout Area. If the number of video windows displaying MPEG-4 live video exceeds 20, a warning message will appear.

The Viewing Area with a [Large Grid]




In this example, the Camera Selection Area and Timeline are hidden (→ P. 5-29).

■ Custom Grid

The Custom Grid fallows you to set customize a grid for displaying Video Windows.

Set a custom grid

- 1. Select [Custom Grid] from the [Layout Grids] sub-menu. The [Custom Grid] dialog appears. Values are given in pixels.
- 2. In the [Horizontal] or [Vertical] field, overwrite the existing value with a custom value, or use the up/down arrows to select a value. When you adjust the value in one field, you'll notice the value change in the other field. This is because the proportions of the re-sized Video Window are constrained and the dimensions are scaled accordingly.



3. Click [OK] to close the dialog. The grid will re-size to your new settings.



Using Custom Grid may cause high CPU load.

Hide and Show Task Areas

The [View] menu allows you to show/hide task areas and other display elements in the Viewer. When you unselect [Camera Selector] and [Timeline] and then select [Fullscreen], the result is a large area in the Viewer for displaying more Video Windows as shown below in the Large Grid example. Pressing the [Esc] key returns the menu bar. You can also select to hide Video Window [Captions], the [Camera Control] and [Live Events].

The number of Video Windows in the display achieved is dependent on the display resolution. A higher resolution will result in more Video Windows displayed.



[View] → [Fullscreen] (Large grid, 1280x1024). Pressing the [ESC] key to display the task bar.



Basic Video Window Functions

This section shows you how to create Video Windows for viewing in the Viewing Area and how to adjust camera angles.

Select Cameras for Viewing

■ Camera Selection Area

The Camera Selection Area is used to display thumbnails of all the cameras. You can select another set of thumbnails of currently-available cameras via the [Location] and [Zone] drop-down menus and then place them into the Viewing Area as Video Windows.

- The [Location] drop-down menu lists the physical locations of cameras on the system.
- The [Zone] drop-down menu lists the groups of areas within each location.



When you select a location, its associated zones will be listed below.

■ Camera Thumbnails

When a Location is selected, the thumbnail images of the Camera Servers registered in that Location will appear. Depending on the number of cameras in the selected Location, a scrollbar at the base of the Camera Selection Area can be used to scroll the display of thumbnails.




Each Zone is grouped into camera thumbnail images and these can be dragged onto the Viewing Area to create Video Windows.



You can hide the Camera Selection Area. From the [View] menu, select [Camera Selector] to hide/show the Camera Selection Area.

■ Locations and the Zones

Selection is performed in the following order:



Step 1: Select a Location from the drop-down menu

Click the [Location] drop-down menu or on the down arrow.

A list of pre-configured locations appears.

Click a location in the list. Zones for that list will appear in the thumbnail section to the right.



Step 2: Select a Zone from the menu or thumbnail folder region

Click the [Zone] drop-down menu or on the down arrow.

A list of pre-configured zones appears.

Click a zone in the list.

Once a Zone is selected from the drop-down menu, the Camera Selection Area for the selected Zone moves to the left.



Alternatively, click the scrollbar located under the Camera Selection Area. Drag it to the right until the desired Zone is displayed.



Basic Video Window Functions

■ Create, scale and move Video Windows

Once you have chosen a location and chosen a zone, you are ready to view one or more cameras in that zone. Camera thumbnail images are used to create Video Windows in the Viewing Area. The Viewing Area can support multiple Video Windows for live monitoring and viewing recorded video simultaneously.

Click and drag a camera thumbnail onto the Viewing Area

- 1. Click the thumbnail image and, while holding down the mouse button, drag its boundary anywhere onto the Viewing Area.
- 2. Release the mouse button. The re-sized outline becomes a live Video Window.



When placed, the Video Window is re-sized according to the [Layout Grids].






An error message will appear if an error occurs in video windows. See P. 9-10 for details.

Re-size a Video Window


- 1. Click a Video Window to highlight it. An arrow icon will appear in the lower right corner. Click the arrow icon and drag outwards. You can also click on the other corners and drag to re-size the window.
 - Release the mouse button when you have reached the desired size.
- 2. Alternatively, click the Video Window menu button and select [Video Display Size]. Select [Small], [Medium], [Large], or [Default] from the sub-menu. The same menu is available by right-clicking the view window.

A right-click action on the Video Window will also bring up the same menu.



Move a Video Window

Click anywhere on a Video Window and drag it to any position in the Viewing Area.





When Video Windows that are other than a standard resolution (160x120, 320x240, 640x480) are displayed, the load on the computer CPU will be high and Viewer operations may take longer.

Add more Video Windows

Click and drag other camera thumbnails onto the Viewing Area to create Video Windows for monitoring if necessary. Your Viewing Screen could look like this.



Note

- Even if you are using the NTP server when the VB-C500 on-screen display is shown on multiple cameras ("On-screen Display" in *Operation Guide*), each camera's date & time may be different.
- Even if the VB-C500 on-screen display is being shown ("On-screen Display" in *Operation Guide*), the date & time shown may be different to the VK date & time.

Arrange Video Windows

There are various ways you can manage the layout of Video Windows in the Viewing Area (→ P. 5-26).



- In the Viewer, the number of Video Windows you can display simultaneously will depend on your video card, the resolution and quality settings of the camera and the Live Video Viewing Settings (frame rate) set in the [Viewer Settings] window of the [Configuration and Preferences] screen.
- If the load on the computer CPU is high, Viewer operations may take longer.

■ Select Multiple Video Windows


You can select multiple video windows easily. You can also move, cut, or copy selected multiple windows simultaneously.

Select Multiple Video Windows

There are three ways to select multiple windows:

- On your keyboard, hold down the [Ctrl] key and click each Video Window to select them, or.
- Click outside the Video Windows and drag a selection box around the Video Windows you want selected, as shown below. Only windows contained within the selection box are selected. Dragging around part of an image in the selection box will not select it.
- If you wish to select all Video Windows, click [Select All] from the [Edit] menu (or on your keyboard press [Ctrl] + [A]).







- Video Windows from different zones and locations can be displayed in the same Layout.
- You can copy and paste a multiple selection of Video Windows at one time which can be pasted into and saved as a new Layout

Video Window Status

■ Video Window Properties


- Title bar indicates name of camera, live or recorded video viewing.
- Video display displays live or recorded video.
- Recorded video indicator displays a time/date stamp in the title bar for recorded footage.
- Event indicator displays a colored bar across the top of the Video Window.
- Pan, tilt and zoom controls when the Video Window is double-clicked or the Video Window menu item, [Get Camera Control] is selected, controls appear to enable pan, tilt and zoom.

■ Video Window states

Video Windows can be displayed in the Viewing Area according to their conditions:

- Live Displays live video from a Camera Server.
- Recorded Displays recorded video from a Storage Server.





[Live Events Log] list


Double-click an event to view it in the corresponding Video Window. The [Live Events Log] opens automatically when you launch the Viewer, if left open in a previous session.

Recorded Events

Click to view recorded footage in the corresponding Video Window.

Each Video Window displays video from an individual camera. Video Windows can be re-sized, repositioned or closed.

- Title bar The title bar consists of menu, camera name and live or recorded status.
- · Video display conditions




Recorded Video Indicator



Event Indicator

If the option for [Operator Notification for] has been set, a color bar will flash on top of a live Video Window when an event occurs. The color indicates the event priority. The bar will flash for a pre-defined time and then remain steady for one minute until disappearing. An audio alert may also sound if pre-defined.

Color	Priority
Red	Highest
Orange	High
Yellow	Medium
Light Green	Low
Dark Green	Lowest



Note

If you use the VB-C500 on-screen display feature to configure the positions of display items to [Lower right] or [Lower left] ("On-screen Display" in *Operation Guide*), some characters may be hidden by the video window title bar, recording indicator or event indicators.

Pan, Tilt, Zoom Control

This is done in one of three ways:

- Directly from within the Video Window
- Using the Camera Control Panel
- · Selecting a Preset

Note

- For VB-C500VD, VB-C500D, VB-C50FSi and VB-C50Fi, Pan and Tilt are not available. You cannot use zoom operations with the VB-C500VD, VB-C500D if digital zoom is set to [Disable] on the camera.
- If a fixed camera or an external camera such as VC-C50i is connected to VB-C50i, you cannot use pan, tilt, and zoom operations.

Using the Camera Directly from within the Video Window

Enable the controls by double-clicking on a live Video Window.

Alternatively, click the down-arrow at the base of the Video Window (or right-click on the window). A drop-down menu will appear. Select [Get Camera Control].

Front Entrance

If the camera is being used by the Viewers or another VB Administration Tools associated with the Camera Server, a "Can't get camera control" message will appear. You may have to wait a few moments and attempt to get control later.

Arrows will appear in the cursor position when you have gained control of the camera. When you move the mouse cursor over a Video Window, the mouse cursor changes its shape. Click and drag the cursor in the direction of the arrow for pan and tilt. When you move the mouse cursor to the center of the image, a zoom in or zoom out control will appear.



Hold down the mouse on "+" to zoom in. Hold down the mouse on "-" to zoom out.

When you have finished, select [Release Camera Control] from the Video Window menu.


🏩 Tip

- If you have camera control, you can only drag the window by clicking and holding the title bar.
- If you did not make any control for 30 seconds, the message of "Control will be lost in 10 seconds" appears, and a 10-second countdown will start.
- You can still manipulate a camera that is currently recording. If the recording position has been set, the Camera Server will return to that position after the Viewer release camera control.

Using the Camera Control Panel

To display, select [View] > [Camera Control] from the menu bar, or click the Video window menu icon (or right-click in the Video Window) to bring up a context menu and select [Camera Control].


If a Video Window is not selected, the preview window will be blank. Click on a Video Window to control the camera.



Note

- When using the VB-C500VD/VB-C500D/VB-C60/VB-C300, you cannot use Night Mode in the following cases:
- When [Day/Night] is set to [Auto] on the [Camera] setting page of VB-C500VD/VB-C500D/VB-C60 or [Video and Camera] setting page of VB-C300
- When the [Night Mode] is set to [Auto] with a recording schedule
- Panorama picture needs to be set on the Camera Server in advance. VB-C500VD/VB-C500D/VB-C50FSi/ VB-C50Fi cannot display panorama picture.

Exposure Control Items (when the Exposure Mode is Auto)



Set the Exposure Mode to [Auto] (VB-C500VD, VB-C500D, VB-C60, VB-C300). [Auto]: Automatically adjusts the exposure. [Flickerless]:

This mode is only for the VB-C500VD, VB-C500D and VB-C60. See the *Users Manual* of the camera for details.

[Auto (shutter priority)]:

Allows the value of the shutter speed to be specified.

Selects the Exposure Compensation value. (VB-C300, VB-C50i series)

[Off]: Exposure compensation is off. [Low]: Performs a low level of exposure

compensation.

[Medium]: Performs a medium level of exposure

compensation.


[High]: Performs a high level of exposure

compensation.

Note

- Exposure can be adjusted for VB-C500VD, VB-C500D, VB-C60 and VB-C300.
- For VB-C500VD, VB-C500D and VB-C60, the values of exposure compensation are -3, -2, -1, 0, +1, +2, +3.
- The [Metering Mode] is available for VB-C500VD, VB-C500D and VB-C60. The mode is deactivated when using other models.

Exposure Control Items (when the Exposure Mode is Manual)



Set the Exposure Mode to [Manual] (VB-C500VD, VB-C500D, VB-C300, VB-C60).


[Manual]: Dragging slide bars adjust the aperture value, shutter speed, and gain value.

(Aperture is not available for the VB-C500VD,

VB-C500D).

Drag each slide bar to adjust the aperture value, shutter speed, or gain value.

White Balance Control Items



Drag each slide bar to adjust each gain value.

To forcibly adjust the white balance, capture a white object (e.g., a piece of white paper) and click [One-Shot WB].

Select the White Balance mode from the drop-down menu. The following modes are available

(VB-C500VD, VB-C500D, VB-C60, VB-C300).

[Auto]: Automatically adjusts the white balance.

[fluorescent H] (VB-C300) or

[Daylight Fluorescent] (VB-C500VD, VB-C500D, VB-C60):

Select this option when day-light fluorescent lamp.

[fluorescent] (VB-C300) or

[White Fluorescent] (VB-C500VD, VB-C500D, VB-C60):

Select this option when using the camera under a day-light or white fluorescent lamp.

[Warm Fluorescent]:

Select when shooting under warm-color fluorescent lights.

[Mercury lamp]:

Select this option when using the camera under a mercury lamp.

[Sodium lamp]:

Select this option when using the camera under orange-colored sodium-vapor lamp.

[Halogen lamp]:


Select this option when using the camera under a halogen or incandescent lamp.

[Manual]: Drag each slide bar to adjust the parameter (R or B gain).

Note

White Balance control is available with VB-C500VD, VB-C500D, VB-C60 and VB-C300 only.


Smart Shade Control





The Smart Shade Control function is available for VB-C500VD, VB-C500D and VB-C60.

Other items



Switch between Auto Focus and Manual Focus.

[Auto]: Adjust the focus automatically.

[Auto(for domes)]:

When the optional dome housing is used, select this option to automatically adjust the focus without focusing on the wall surface.

[Fixed at infinity]:

Focus is fixed at a point of infinity.

[Manual]: Press and hold [Far] or [Near] button to adjust the focus. Clicking [One Shot AF] adjusts the focus just once automatically (VB-C60, VB-C300).


Note

- Focus is not available for the VB-C500VD, VB-C500D.
- [Auto (for domes)] is not available for VB-C500VD/VB-C500D/VB-C60.
- [Pan / Tilt] speed cannot be changed for VB-C500VD, VB-C500D. Additionally, [Zoom] speed cannot be changed if digital zoom is set to [Disable].

Select a Preset Camera Angle

If preset camera angles have been set up and stored as presets, they will be available from the [Preset] drop-down menu of the Camera Control panel or a sub-menu. The following explains how to select a preset from a sub-menu.

- 1. Double-click a Video Window or select [Get Camera Control] from the Video Window menu.
- 2. From the Video Window menu, click [Preset Camera Angles].
- 3. Select a preset position from the sub-menu.





The [Preset] item is grayed out as VB-C500VD and VB-C500D do not support this function.

Other Video Window Functions


Change the Video Window size

Apart from manually clicking on the corner and dragging out the Video Window to a new size, you can also select a set size from the Video Window menu.

To change the display size of a Video Window via the menu:

Open the Video Window menu and select [Video Display Size].

- 1. Click the Video window menu icon, or right-click in the Video Window to bring up a context menu.
- 2. Select [Video Display Size] from the menu, and then select [Small], [Medium], [Large], or [Raw] from the submenu. A [Raw] selection displays the Video Window selected at the [Selection of receiving image].




■ Change the Received Video size (VB-C500VD, VB-C500D, VB-C60, VB-C50i/ VB-C50iR, VB-C50FSi, VB-C50Fi only)

You can select a video size received by the Viewer. To change the size of received video via the menu.

Open the Video Window menu and select [Selection of receiving image].


- 1. Click the Video window menu icon, or right-click in the Video Window to bring up a context menu.
- 2. Select [Selection of receiving image] from the menu, and then select [JPEG Small], [JPEG Medium], [JPEG Large], or [Default] from the sub-menu.

Selecting [Default] displays the Video Window in the size received from the Camera Server.



Mote

• If you are using the VB-C500VD/VB-C500D/VB-C60, the menu items are as follows.




- The [MPEG-4] setting can be made on VB-C500VD/VB-C500D/VB-C60.
- If you specify MPEG-4 and perform live viewing on VB-C500VD/VB-C500D/VB-C60, the video and audio are not synchronized.
- When multiple Video Windows from a single Camera Server are displayed and the Video Receive Size is changed from one of them, the change will apply to all Video Windows.
- Selected video receive sizes are saved when the layout is saved.
- The [Selection of receiving image] used for [Default] is determined when first displaying video from the Camera Server starts. Even if you change the size from the Camera Server after the connection is made, it will not apply.

■ Enable Exposure Compensation

Exposure compensation is to compensate for camera views with strong backlighting. It can be enabled from the Video Window menu.

While Camera Control is active, select [Exposure Compensation].

- 1. Click menu bar of the Video window, or right-click in the Video Window to bring up a context menu.
- 2. Select [Exposure Compensation] from the menu and select [Off], or [On] from the sub-menu.






- A checkmark (black circle) is attached to the selected item. However, it is not displayed in front of the control.
- Choose "0" to disable Exposure Compensation.

■ Other Menu Options

Other functions available from the Video Window menu include:



■ Note

It is recommended to install the Viewer and/or NC Viewer in advance.


selected Video Window by pressing the [Delete] key.

- The camera server which is sending or receiving audio cannot interact with other Viewer or Admin Viewers.
- Viewer Shade Control cannot be applied to multiple Video Windows.
- Viewer Shade Control is performed by using image processing within the Viewer and not on the Camera Server. It can be used on live or recorded video (see below).

■ Viewer Shade Control


Viewer Shade Control compensates darker regions of images and makes them lighter.

Correction only applies to the displayed Video Window in the Viewer.



Darker regions are most affected by Viewer Shade Control.

■ Audio Panel




Clicking this button after selecting a Video Window, or selecting a Video Window after clicking this button starts audio playback.

Clicking this button after selecting a Video Window, or selecting a Video Window after clicking this button starts audio transmission.

When ticked, audio is played back even when a microphone is used.

Click this button to display silent detection control.



When ticked, silent interval is detected while transmitting audio. For a silent interval, network load can be mitigated by reducing data to transmit.

Tick this option to detect silent intervals with predefined sensitivity.

Tick this option to manually specify the detection sensitivity. Drag the slide bar to adjust the detection sensitivity.

Note


- You cannot transmit and receive audio when using a proxy server.
- Audio playback is only performed during regular playback.
 Audio playback is not performed in the following cases.
 If multiple image windows are selected.
 While paused, or during fast forward, nudge forward, nudge back, or rewind

Use Timeline and View Events

This chapter shows you how to use the Timeline for live and recorded viewing as well as view and search events.

■ Timeline Overview

On the Viewing Screen, a timeline of past events associated with displayed cameras is shown in the Timeline Area at the bottom of the Viewer as colored bars. Selecting a colored bar moves the playhead to the event and the associated Video Window is switched to playback mode.



Click in this area of the

Playhead shaft and drag to

positions on the Timeline.


Play/Pause ——Nudge Forward

Fast Forward -

Next Event -

■ Monitor Live Video in relation to the Timeline

When a Video Window is created from a camera thumbnail, video is seen live. The Playhead (shown below) will be in a **live** position. The **live** position represents the present time. The playhead remain fixed as time scrolls to the left underneath, representing the passage of real time.



■ Use the Timeline to play and extract video

You can view recorded video by moving the playhead control in the Timeline or entering a timecode and jumping to it. Methods include:

Use the Playback Controls

You can control to play, rewind, fast forward or jump to previous and next events.

The fast forward and rewind speeds change by 1x, 2x, 5x and 10x each time you click the buttons.





- Rewind and nudge back cannot be performed on video recorded in MPEG-4 format.
- The fast forward speed of video recorded in MPEG-4 format is fixed at 2 times.
- If a schedule that had previously been recording in MPEG-4 format is switched to recording in JPEG
 format, when rewind playback from the JPEG format time range enters the MPEG-4 time range, although
 the rewind playback continues, the video is not displayed and an error stating "No Recorded Video." is
 displayed.



- You can simultaneously play videos from multiple camera servers at the same time.
- You can simultaneously play multiple videos from one camera server, which were captured at different times.

Drag the Playhead to a new time

Click and drag the Playhead shaft to another location. When you move the Playhead, you are effectively controlling all Video Windows that have been selected.



Click in the Event Display Area of the Timeline

Click in the Event Display Area of the Timeline. The Playhead will move to that location and playback of recorded video commences from that time.



Mote

- When you choose to play back video, the video is played. The response and smoothness of the play back may depend on network traffic and other properties of the network.
- The time displayed on the Timeline is the time of PC where the Viewer is running.

Click and drag the time bar to move through the Timeline

Move your mouse pointer over the time bar and it becomes a hand. Click and drag to the left or right to move back or forward in time. You can only scroll right to the current time, or live time.



Jump to time entered

1. Select a Video Window and click [Jump to Time].




- 2. The [Jump To Time] dialog opens. Select a day and/or time.
- 3. Click [OK].

The Playhead and Timeline will move to the time selected. If no Video Windows are selected, only the timeline is moved.



Using the calendar is shown below.





If you use the VB-C500 on-screen display window ("On-screen Display" in *Operation Guide*), the date & time shown in the bottom-right may be different to the recording time.

■ One-minute manual recording (Record Now)

A manual recording with duration of one minute can be initiated at the maximum frame rate. The manual recording is displayed on the Timeline and [Live Events Log] as [Manual recording (<username>)]. This is handy for capturing random events not associated with sensor recording or outside preset recording times.

To initiate manual recording:

- 1. Select a Video Window for manual recording.
- 2. Click [Record Now].



Mote

- The [Record Now] function records at the maximum frame rate. Extended recording time will use additional disk space on the Storage Server. It is limited to 5 fps for VK-Lite.
- The [Record Now] function is only enabled if a Storage Server is configured for the camera.
- Recording will be for approximately one minute. The actual duration of recorded video may vary depending on settings and network delays.
- The priority of an event created by a manual recording using [Record Now] will always be Priority 1.
- The [Record Now] function allows recording video in JPEG format. However, video will be recorded in the MPEG-4 format if and only if recording in MPEG-4 is scheduled (VB-C500VD, VB-C500D, VB-C60).
 If audio transmission is enabled on the camera, audio recording is also performed.

■ Shoot a Snapshot

Click Capture Still Frame to keep the current image on a Video Window.

- 1. Select a Video Window to capture a still image.
- 2. Click [Capture Still Frame].



Note

- On Windows Vista/Windows Server 2008, don't specify the Windows folder or the Program Files folder on the system drive to store snapshots and video files, as image and video files can't be saved in those folders.
- If [Superimpose the date and time on the still frame] is selected in the Viewer settings, the date and time are displayed in the lower right corner of the still frames (the position, font, size, and color are fixed). If you use the VB-C500 on-screen display window ("On-screen Display" in *Operation Guide*), it is recommended that you position the window either in the top-right or top-left of the screen.



- The VB-C500 on-screen display window time & date ("On-screen Display" in Operation Guide) and the Capture Still Frame time & date may differ.
- Capture Still Frame images are saved in bitmap format.

Zoom In and Out of the Timeline


Click [Zoom In] to zoom into a time period in the Event Display Area.

Click [Zoom Out] to zoom out a time period in the Event Display Area.



Click event to select it

When you click an event to select it, the associated Video Window will display the event(s).



■ Daylight Savings Indicator

The Storage Server will adjust for [Automatically adjust clock for Daylight Saving Time] if configured in [Date and Time] property of the control panel as follows:

- When normal time has changed to Daylight Savings time, time that is skipped is displayed in the Timeline as missing.
- When gaining time (rewinding the clock back from 02:00 to 01:00), the extra time is duplicated.





Where [Daylight Saving] changes have occurred, the Timeline display is still continuous. Only the labels are affected.

■ Extract video to save to a file

A portion of video can be saved to another location. Files are automatically saved as QuickTime .mov format and can be viewed in a QuickTime player or any other player that supports .mov files. A maximum of one hour of video can be extracted at a time. If you do not have a QuickTime player installed, visit http://www.guicktime.com for a free download.

Select a Video Window and time period then click [Extract Video].


- 1. Click a Video Window to highlight it, then click and drag a time period for it in the Timeline.
- 2. Click [Extract Video]. The [Extract Video] dialog opens.



- 3. [Date]: Click the down arrow to select the date, or click on the date to directly input the date.
- 4. Click up/down arrows to select a time or click each time segment and overwrite existing value.



5. Click [OK] to display the [Save As] dialog. The [Save As] dialog opens. Browse to a suitable folder in which to save the extracted video, and click [Save].



Note

- You must select only one Video Window to extract video.
- QuickTime player version 6.5.1 or later is recommended.
- On Windows Vista/Windows Server 2008, don't specify the Windows folder or the Program Files folder on the system drive to store snapshots and video files, as image and video files can't be saved in those folders.
- When recording video and audio together, you cannot save only the video data or only the audio data. The video + audio are saved in a single MOV file.
- If you specify two or more MPEG-4 recorded footages for writing, only the older/oldest footage will be saved.
- If you specify JPEG and MPEG-4 recorded footages together for writing, only the older footage will be saved.

Return to Live Video


To return to the live video, click [Return to Live]. The Playhead returns to the live position in the Timeline.



View and Search Events

■ [Live Events Log] list

The [Live Events Log] displays events that have occurred with one or more cameras after the Viewer has been launched. Events are color coded according to priority.



The bell icon is displayed when the event is acknowledged by double-clicking. Double-clicking the event to acknowledge it changes the icon to a dot.



Only the most recent 200 events are shown in the [Live Events Log].

Tip

The [Live Events Log] window automatically opens when you launch the Viewer, if you left it open after closing VK-64/VK-16.

■ Display the [Live Events Log] list


To display the [Live Events Log] List:

Select [Live Events] from [View] Menu

From the VK-64/VK-16 menu bar, select [View] and [Live Events].

[Live Events Log] list opens.

■ Overview of Alert Parameters



Acknowledge and View Events

A new event entry will appear at the top of the [Live Events Log] list and will flash for a defined period if configured. If Operator Acknowledgement is required, the event will flash indefinitely if not acknowledged.

- 1. In the [Live Events Log], double-click on the event to acknowledge. Double-click again if you need to check the video.
- 2. In the bottom right corner of the Viewer, click [Return to Live →] when you have finished viewing the event. The Video Window will return to live viewing.


■ Search Events


If you have multiple events, you can initiate a search for a particular event via the [Event Search] dialog. To launch the [Event Search] Dialog:

Click [Event Search]

On the Timeline, click [Event Search].

The [Event Search] dialog opens.





Double-click an event to view it in the Video Window, or click an event to highlight it and then click [View Event in Camera] to view it.

■ Select Criteria for Searching

When you initiate a search, certain criteria can be specified such as Priority, Location and Zone on the network, a date range when the event may have occurred and a time period.

To initiate a search:

Step 1: Select a date and time range to search

Click in the [From] and [To] date panels and overwrite the existing entries for month/day/year and time.

Alternatively, click the down arrow next to each date panel to bring up the calendar. Click off the calendar to close it again.

In the [Event Search] dialog, you can also scroll through time using the up/down arrows. Click an hours, minutes or seconds segment to highlight it and then click the up or down arrow.



Step 2: Select a camera

Select the camera you want to search by from the drop-down menu. Once you have selected a specific camera, the Location and Zone specified in [Where] are ignored.



Step3: Select a Location and Zone to search

From the [Where] fields, select a Location and Zone from the drop-down lists.



Step 4: Select a type of Event

Select a type of Event from the drop-down list.



Step 5: Select a State

Select a State for the event, whether it was [On] or [Off] during the period. Alternatively, select [All States].



Step 6: Select a Priority

Select a Priority from the drop-down list.



Step 7: Click [Search]

When you have entered the day and time range, click [Search] to initiate the event search. Events that are found will be listed in the window below. If necessary, stop a search at any time by clicking [Stop Search].



You can search events by keywords, such as "deleting", "recording" or "frames" etc, when using [Description]. Found events will be event tips based on entered events.




■ View retrieved recorded video

To view video of when an event occurs, click the event to highlight it and click [View Event in Camera] to view it in a Video Window.

You can also view recorded video by double-clicking the event.

Clicking [Cancel] stops any searching and closes the dialog.





When you have finished viewing an event in a Video Window, click [Return to Live \rightarrow] in the Timeline to return the Video Window to live viewing.

Popup Video upon Event occurring

Select the [Popup a video window automatically when an event occurs] checkbox under the [Video Window Popup Setting] administrator tab in the [Viewer Settings] screen to display the corresponding video window in the foreground and begin live viewing when a sensor input or motion detection occurs.





- If the video window that pops up is in the Viewer Area, that window is automatically displayed in the foreground.
- The size of video windows that are displayed automatically is [Medium] (320x240).

Operation and Management

Chapter Overview

This chapter explains points to notice concerning the Storage Server when you operating and maintaining the network camera system, as well as guidelines for operating the system.

Health Check for Storage Server

Explains the messages displayed for VK events and gives example resolutions, and also explains the number of frames queued for processing for each camera.

Operation Guideline for Recording and Viewing

Explains frame rates for recording and live viewing via the Viewer.

Operation Guideline for Sensor Event Recording

Explains operation tips concerning the sensor event recording, including points to notice and counteractions against troubles.

Optimization of Motion Detection Recording (Index)

Explains operation tips concerning the Motion Detection recording, including points to notice and counteractions against troubles.

Health Check for Storage Server

VK Events (Timeline for VK Viewer)

If any of the events listed in the table below occurs, you may have to take the specified counteraction.


The text within < > in each message depends on the situation.

Event type	Message	Description	Counteraction example
Indicates the free space on the disk	warning (on) / ok (off) Disk space on drive <drive name=""> <situation></situation></drive>	This event occurs when the disk free space has run under the specified value or the used disk space has exceeded the specified valued. In this case, data may be deleted before the designated storage time elapses. Disk capacity indication is only effective when it is on.	Review the recording and Camera Server settings (→ P. 3-10, P. 4-24)
Starts and stops deletion due to space shortage. (*)	starting (on) / stopping (off) <situation> deleting files on drive <drive name=""> due to low disk space</drive></situation>	This event occurs when the disk free space has run under the threshold value or the used disk space has exceeded the threshold valued.	
Pauses and resumes recording due to space shortage. (*)	starting (on) / stopping (off) <situation> suspension of recording on drive <drive name=""> due to low disk space</drive></situation>	This event occurs when the disk free space has run under the threshold value or the used disk space has exceeded the threshold valued.	
Connection error to the Camera Server	error (on) / ok (off) Connection to host <camera address="" server="">: <port> <situation></situation></port></camera>	This event occurs when an error has occurred while connecting to the Camera Server. However, it does not necessarily occur for every connection failure. When this event occurs, the recording engine tries for reconnection and a COMM error occurs if the retry fails.	Review the network connection (→ P. 4-19).
Recording frame rate change	Effective recording rate (<recording before="" change="" rate=""> → <recording after="" change="" rate=""> %) Example: Ex. "Recording rate (100.0 > 90.0 %)" Note: This is not an On/Off event.</recording></recording>	This event indicates that the recording frame rate has been reduced due to increased server load.	Review the recording settings or consider adding the Storage Server (→ P. 4-14).

For the items marked with (*), see "Important: Disk Space Management" (\rightarrow P. 3-17).

Number of Frames Queued for Processing

The [Camera Summary] screen displays the number of frames queued for processing for each camera, allowing you to check the load conditions of the PC.



This information is updated at every 5 seconds.



If the number of frames queued for processing exceeds 500, either reduce the video recording frame rate, or reduce the image size or quality, etc. in order to reduce the number of frames queued for processing. If the number of frames queued for processing exceeds 1,000, dropped frames may occur in the recorded video.

Operation Guideline for Recording and Viewing

The following explains the automatic frame rate adjustment function for viewing and recording.

This function checks the load of the PC on which the Storage Server and the Viewer are running and adjusts the frame rate for video recording and live viewing.



Note

Using this function is recommended; however, make sure you perform tests under actual conditions before starting operations.

Live-View Frame Rate Adjustment

[Auto Adjust Frame Rate] in the [Viewer Settings] (→ P. 5-16)

* This option is enabled by default (recommended).

When displaying live video, the Viewer requests the camera to send the video at the specified frame rate (→ [Max. Live Frame Rate] on P. 5-16).

If you use this function, you can maintain a stable display of live video with a temporarily lowered frame rate even if your PC temporarily becomes highly loaded for some reasons.

If you do not use this function, menu operation or display response may be affected when the load on your PC is high.

For video in MPEG-4 format, the [Max. Live Frame Rate] and [Auto Adjust Frame Rate] settings are ignored, and the frame rate that is sent from the camera is displayed.

Recording Frame Rate Adjustment

[Reduce recording frame rate when disk is under high load] in the [Storage Server Configuration dialog (→ P. 3-10)

* This option is enabled by default (recommended).

When the network recording software writes images received from cameras into the hard disk, if the load (mainly the load of writing into the hard disk) of the PC on which the Storage Server is running is too high, the software cannot write the images immediately.

If the amount of the image that is waiting to be written increases for a certain period of time, the Storage Server considers the PC to be highly loaded. When this happens, the Storage Server stores images at intervals rather than storing all of the images the Storage Server received, in order to reduce the PC load.

If you use this function, you can avoid recording failure as much as possible even if your PC temporarily becomes highly loaded for some reasons. When using this setting, adjust the video recording frame rate so that it does not drop below 0.5 fps.

Note that events are generated when the network recording software starts and ends the operation of the function (→ P. 9-35, "Changing the recording frame rate"). You can check the operating status of the function via the Event Search dialog (→ P. 5-58).

If you do not use this function, recording may be interrupted when the load on your PC is high. This software cannot detect the recording interruption.

This function is disabled when the [Resolution] is set to [MPEG-4].

Operational Guideline for Sensor Event Recording

Proper Operation of Sensor Event Recording (Optimization of Sensor Arrangement and Sensitivity)

Frequent sensor events result in high CPU load on your PC, and the recording frame rate may be reduced or recording may be interrupted. If you have 10 or more sensor events per minute continuously, we recommend continuous recording.

For each Storage Server, it is recommended to lower the sensor sensitivity or use continuous recording.

- 20,000 or more sensor events occur a day.
- 10 or more sensor events occur every minute.



Check the number of sensor events with the status bar.

Optimization of Motion Detection Recording (Index)

The Motion Detection recording is not suited to applications where high levels of reliability are required. Therefore, it is recommended to use continuous recording for monitoring or other purposes if consistently high levels of reliability are required. Canon accepts no liability whatsoever for faults, etc. resulting from the use of the Motion Detection recording.

Frequent motion detection events result in high CPU load on your PC, and the recording frame rate may be reduced or recording may be interrupted. If you have 10 or more motion detection events per minute continuously, we recommend continuous recording.

Frame Rate indicates the number of frames for Motion Detection recording. Lowering this value mitigates load on the Storage Sever.



- Longer before-event recording with insufficient memory may lead to the use of disk-based virtual memory which will greatly reduce performance. Shorter before-event recording will reduce memory usage.
- The full requested duration of post event recording may not be available due to data size and network delays.

Motion Detection Setting for Each Camera Model

VB-C500VD, VB-C500D, VB-C60, VB-C50i/VB-C50iR, VB-C50FSi, VB-C50Fi, VB150

Configure the Motion Detection settings on the Camera Server.

Please see the Camera Server User's Manual for details.

For the VB150, [Video Input] must be set to [Single].

VB-C300

Configure the Motion Detection settings on the Storage Server.

See "Set Motion Detection Recording" (→ P. 4-46) for details on how to set the Motion Detection parameters.

Typically, set the total frame rate to 150 fps (e.g., 30 fps with five cameras) with the display resolution of QVGA.

Backup Scheme

Chapter Overview

This chapter explains how to make backups for each purpose.

Since the volume of video data the largest among various data types requiring backup, you must carefully choose backup equipment and learn the backup techniques.

Purpose

Purposes of backup include.

• Backup for Data Protection

Prevents data from system crush or hard disk failure. This type of back up targets video data, event data, and configuration files.

• Backup for Archive

Stores recorded video data and event data on other media for a long period of time.

Preparation

Backup Device

Prepare necessary equipment for backup depending on the data quantity of the VK-64/VK-16. Basically, you should use the DDS-4 type device if a single backup copies several Gigabytes through 40 GB of data, and DAT72 or AIT if it copies around 70 GB of data.

Further, if backup data quantity reaches 100 through 400 GB, you should use the LTO device. If you need more capacity or want to omit media replacement, you can consider auto loaders for the LTO device.

• Backup Example for VK-64/VK-16

If 10 Camera Servers record video for 30 days at 1 fps (10 KB)

the required data capacity is 300 GB per month, 70 GB per week, and 10 GB per day.

In this case, it is recommended to use the LTO device (Ultrium tape device). This type of device records 100 through several hundreds GB of data at the average transfer speed of 25 through 30 MB/sec (or 40 through 60 MB/sec when data is compressed).

The time required for making backup of data for 30 days (300GB) is approximately 12,000 seconds (i.e., 3.5 hours). The time is shortened to approximately 2.5 hours when data is compressed (Although the hardware specifications mention that the transfer speed will be doubled by compressing data, the expected compression ratio depends on data formats. Therefore, it is dangerous to think so).

The time required for making backup of data for a week (70GB) is approximately 2,800 seconds (i.e., a little longer than 46 minutes).

The time required for making backup of data for one day (10GB) is approximately 400 seconds (i.e., 6 minutes 40 seconds).



Recording does not stop while making a backup of data; however, the recording frame rate may be reduced from the specified value due to disk I/O load and CPU load.



Video data for VK-64/VK-16 is irreversible compressed data. Compression process done by tape or other devices is not necessary.

Backup Tool

It is recommended to use a third-party backup tool for Windows. Read the manual of the tool for deployment.

Restore Server for Archiving

If the purpose of backup is archive, you should prepare a separate PC for the Storage Server to which data will be restored. This PC must have the same drive configuration (e.g., hard disk configuration). For example, if the source server's system drive is C and data storage drive is D, and video data drive is E, you must configure the PC with the same drive configuration. However, the hard disk capacity must be determined according to data to restore.

Files to Make a Backup

Storage Location of Video Data, Audio Data, and Event Data

Video data being recorded is saved in a temporary file (See "About Temporary File" below), and the file is settled and saved as video data when its size reaches 1 GB (by default) to the storage drive.

Audio data is recorded using the G71 μ Law format, and saved in the QuickTime file format. The audio recording bit rate is 64 Kbps.

The recorded video data, audio data, and event data are saved in the following folders according to your settings for [Save video in] and [Drive] when you register Camera Servers (→ P. 4-23).

Recorded Video data

<Save video in>: \WebView-NVR\videofiles

The following two file types are backed up:

File name =

(For JPEG Video)

File name =

NVR_MEDIA_xxxxxxxxxxxxxxxxyyyymmdd_hhmmss_yyyymmdd_hhmmss.avi

OR

(For MPEG-4 Video)

File name =

NVR_MPEG4_xxxxxxxxxxxxxxxxyyyymmdd_hhmmss_yyyymmdd_hhmmss.mov



These two files are used in pairs. Be sure to back up both files.

🌣 Tip

The recorded video data file name contains the Greenwich Mean Time as the time stamp.

About Temporary File

File name = NVR_STANDBY_MEDIA_xxxxxxxxxxxxxxxxxxxxxxxyyyymmdd_hhmmss.avi

File name = NVR_STANDBY_MEDIA_xxxxxxxxxxxxxxxxxxyyyymmdd_hhmmss.avi.tmp

File name = NVR_STANDBY_MEDIA_xxxxxxxxxxxxxxxxxxyyyymmdd_hhmmss.mov

File name = NVR_STANDBY_MPEG4_xxxxxxxxxxxxxxxxxxxyyyymmdd_hhmmss.mov

These four files are not yet settled by the system.

· Recorded Data Concept

Video data being recorded is saved in a temporary file, and the file is settled and saved as video data when its size reaches 1 GB (by default) to the storage drive. This recording unit can be changed in the [Maximum file size / duration] field, in the [Storage Server Configuration] window's [Settings] tab $(\rightarrow P. 3-10)$.

Temporary files cannot be backed up in the normal procedure.

Recording (For JPEG Videos)



Recorded video data (after settled)

NVR_INDEX_xxxxxxxxxxxxxxxyyyymmdd_hhmmss_yyyymmdd_hhmmss.mov NVR_MEDIA_xxxxxxxxxxxxxxxxyyyymmdd_hhmmss_yyyymmdd_hhmmss.avi NVR_EVENT_xxxxxxxxxxxxxxxxxxxxxxyyyymmdd_hhmmss.evt

Audio data

<Save video in>: \WebView-NVR\videofiles

The following file types are backed up.

File name =



The recorded audio data file name contains the Greenwich Mean Time as the time stamp.

· Temporary files

The following files are the files before being settled by the system.

File name =NVR_STANDBY_AUDIO_xxxxxxxxxxxxxxxxxxxyyyymmdd_hhmmss.avi

Event data

<Save video in>: \WebView-NVR\eventfiles

The following file types are backed up:

File name = NVR_EVENT_xxxxxxxxxxxxxxxxxxyyyymmdd_hhmmss.evt

Camera ID Recording start date_time



The recorded event data file name contains the Greenwich Mean Time as the time stamp.

Configuration files

The configuration files for the Storage Server and Viewer are saved in the following folders of the PC where each program is installed.

Configuration file path for OS other than Windows Vista/Windows Server 2008

<System Drive>:\Documents and Settings\All Users\Application Data\Canon\WebView\NVR\

Configuration file path for Windows Vista/Windows Server 2008

<System Drive>:\ProgramData\Canon\WebView\NVR\

Back up the entire contents of this folder.



- The configuration file names do not appear if the [Show hidden files and folders] is not checked under the Windows [Folder Options].
- You cannot use the shadow backup function of Windows Vista/Windows Server 2008.

Backup for Data Protection

About Backup

When making a backup of data for protection, you must back up the following data:

- Recorded video data ---- It is recommended to make an incremental backup of this data. See P. 7-5
 for the file names and storage location.
- Event data ------ It is recommended to make an incremental backup of this data. See P. 7-7 for the file names and storage location.
- Configuration file -------- Usually, make a backup of the configuration file when the system is installed, and do it again each time you change the settings of the VK-64/VK-16. However, if the management is complicated, you can perform a full backup every day. See P. 7-7 for the storage location.

Notes on Backing Up Recorded Video Data

Video data being recorded is saved in a temporary file on a hard disk drive. The temporary file cannot be backed up in the normal procedure. See "Recorded Video data" (→ P. 7-5) for details.

The temporary file cannot be backed up until it is converted into video data.

You should choose the backup hardware best suited for the backup data quantity. Basically, you should use the DDS type device if a single backup copies 1 through 10 GB of data, and AIT device if it copies 10 GB through 100 GB of data, and LTO device if it copies 100 through 400 GB of data. If you need more capacity, you need to consider multiple backup devices. Also, it is recommended to use a backup device with a high data transfer rate.

If the total capacity of the hard disk reaches several terabytes, you should rather consider, than making backups, using hot-spare hard disks or highly reliable storage system, or further reliable and available RAID system.

Backup for Archiving (Long-Term Storage of Data)

When making a backup of data for long-term archive, you must back up the following data:

- Recorded video data ---- It is recommended to make an incremental backup of this data. See P. 7-5 for the file names and storage location.
- Event data ------ It is recommended to make an incremental backup of this data. See P. 7-7 for the file names and storage location.
- Configuration file ------ Usually, make a backup of the configuration file when the system is installed, and do it again each time you change the settings of the VK-64/ VK-16. However, if the management is complicated, you can perform a full backup every day. See P. 7-7 for the storage location.

Notes on Backing Up Recorded Video Data

Video data being recorded is saved in a temporary file, and the file is settled and saved as video data when its size reaches 1 GB (by default) to the storage drive. The temporary file cannot be backed up in the normal procedure. Therefore, backup only the settled files. See "Backup for Data Protection" (\rightarrow P. 7-8) for details.

When choosing the backup device, consider the backup unit. For example, if the backup unit is 100 through 400 GB, use a high-density tape device called **LTO device**. If it is around 2TB (far beyond 400 GB), consider LTO auto loader device.

Backup Procedure for Video Data and Event Data

Back Up Recorded Video Data and Event Data.

1. Estimate the total quantity of recorded video data for backup.

The video data quantity per day can be calculated as: Image file size per frame x Frame rate x Number of Camera Servers x Recording time (seconds) per day.

See "Server Sizing Concept" (→ P. 1-20) for details.

- 2. Prepare the backup device and backup tool for Windows according to the estimated quantity.
- 3. Set up the backup tool as directed on P. 7-4.

Be sure to exclude the temporary files from the backup target.

■ Note

If the VK-64/VK-16 continues recording video while making a backup, you must take into account the increased I/O load on the hard disk due to data transfer to the backup device. If the recording frame rate of the Storage Server is reduced by performing the backup, consider the following:

- Lower the recording frame rate during backup in the Recording Schedule Setting window.
- Establish multiple I/O channels (e.g., RAID cards) on the Storage Servers to deploy multi-storage configuration and distribute the recorded video data among servers. Choose a backup device according to the storage configuration.
- Use multiple Storage Servers and use a dedicated backup device for each server. See P. 1-19 for how to use multiple Storage Servers.

Restoration Procedure

Restore Data from Backup for Data Protection

The following explains how to reconstruct the Storage Server for the VK-64/VK-16 for maintenance or recovery from a failure.

- 1. Check that the PC hardware environment has been restored to the former state. Be sure to use the same folder organization as before.
- 2. Install the VK-64/VK-16.
- 3. After installation completes, stop the Storage Server from the [Storage Server Configuration] window.
- 4. Restore the VK-64/VK-16's configuration file to the former location.

The default location is as follows:

Configuration file path for OS other than Windows Vista/Windows Server 2008

<System Drive>:\Documents and Settings\All Users\Application Data\Canon\WebView\NVR\

Configuration file path for Windows Vista/Windows Server 2008

<System Drive>:\ProgramData\Canon\WebView\NVR\

5. Restore the recorded video data file to the former location.

The default location is as follows:

<Save video in>:\WebView-NVR\videofiles

6. Restore the event data file to the former location.

The default location is as follows:

<Save video in>:\WebView-NVR\eventfiles

- 7. Start the Storage Server from the [Storage Server Configuration] window.
- 8. Check that the recording operation is performed correctly. Also check that restored video data is played back correctly.



If the [Maximum retained history] setting is used in the [Storage Server Configuration] window and the restored video data contains data exceeding the retaining period, that data will be deleted when the Storage Server starts.

Restore Data from Backup for Data Archiving

The following explains how to restore only necessary files from the data backup for archive.

1. Check that the drive configuration of the PC to which the files are restored is the same as the PC from which the files were backed up.

Be sure that the hard disk has a capacity larger than the total size of the video data files to restore.

- 2. Install the VK-64/VK-16.
- 3. Restore the VK-64/VK-16's configuration file to the former location. The default location is as follows:

Configuration file path for OS other than Windows Vista/Windows Server 2008
<System Drive>:\Documents and Settings\All Users\Application Data \Canon\WebView\NVR\

Configuration file path for Windows Vista/Windows Server 2008

- <System Drive>:\ProgramData\Canon\WebView\NVR\
- 4. Uncheck the [Maximum retained history] option in the [Storage Server Configuration] window.
- 5. Launch the Viewer and delete all the schedules for all the Camera Servers in the [Recording Schedules] tab under the [Settings] screen.
- 6. After deleting schedules, stop the Storage Server from the [Storage Server Configuration] window.
- 7. Restore video data files matching the date and time you want to play back to the former location. The default location is as follows:
 - <Save video in>:\WebView-NVR\videofiles
- 8. Restore event data files matching the date and time you want to play back to the former location. The default location is as follows:
 - <Save video in>:\WebView-NVR\eventfiles
- 9. Start the Storage Server from the [Storage Server Configuration] window.
- 10. Also check that restored video data is played back correctly.

Notes on Restoring Data from Backup for Data Archiving

- When restoring the configuration file, also the old recording setting information is restored as well.
 After restoration, the PC may start recording video according to the old recording schedule. If you do not want to record video, delete the recording schedules after restoration.
- If the [Maximum retained history] setting is used on the Storage Server, uncheck this option. If this option is enabled, the past data may be lost.

Examples

Configuration 1: Backup for Data Protection 1

Premise

5 units of VB-C50i

Recording condition

Frame rate is 1 fps (one frame per second), Camera Server video quality is 50, resolution is 320x240, the size for one image data is 15 KB.

The [Maximum file size / duration] option in the [Storage Server Configuration] window is set to six hours.

Under this condition, the video file size per Camera Server per day is 310 MB x 4 files.

Therefore, the video data quantity per Camera Server per day is 1.25 GB and 6.25 GB for five Camera Servers.

Hardware requirement

6.25 GB per day x 30 days = 190 GB Hard disk capacity of around 240 GB is required.

If the storage period of video data on the Storage Server is 30 days, an archive backup for 1-week data can be saved on 50-GB tape with an AIT drive. To save 30-day data on a single cassette of tape, a 200-GB LTO drive is necessary.

Configuration 2: Backup for Data Protection 2

Premise

10 units of VB-C50i

Recording condition

Frame rate is 1 fps (one frame per second), Camera Server video quality is 50, resolution is 320x240, and the size for one image data is 15 KB.

The [Maximum file size / duration] option in the [Storage Server Configuration] window is set to six hours.

Under this condition, the video file size per Camera Server per day is 310 MB x 4 files.

Therefore, the video data quantity per Camera Server per day is 1.25 GB and 12.5 GB for ten Camera Servers.

Hardware requirement

12.5 GB per day x 30 days = 375 GB Hard disk capacity of around 450 GB is required.

If the storage period of video data on the Storage Server is 30 days, and the required archive period is 180 days, an archive backup for 1-week data can be saved on 100-GB tape with an LTO drive (Ultrium). If you use a 400-GB LTO drive, you can save 30-day data on a single cassette of tape.

Configuration 3: Backup for Data Archiving

Premise

5 units of VB-C50i

Recording condition

Frame rate is 1 fps (one frame per second), Camera Server video quality is 50, resolution is 320x240, and the size for one image data is 15 KB.

The [Maximum file size / duration] option in the [Storage Server Configuration] window is set to six hours.

Under this condition, the video file size per Camera Server per day is 310 MB x 4 files.

Therefore, the video data quantity per Camera Server per day is 1.25 GB and 6.25 GB for five Camera Servers.

Hardware requirement

6.25 GB per day x 30 days = 190 GB Hard disk capacity of around 240 GB is required.

If the storage period of video data on the Storage Server is 30 days, and the required archive period is 180 days, an archive backup for 1-week data can be saved on 50-GB tape with an AIT drive. If you use a 100-GB LTO drive, you can save 1-week backup data.

However, if the tape capacity for archive is too large, we should consider that it takes too long to find desired data from the restored data.

Configuration 4: Backup from Multiple Storage Servers (Backup for Data Protection)

Premise

100 units of VB-C50i

Recording condition

Frame rate is 1 fps (one frame per second), Camera Server video quality is 50, resolution is 320x240, and the size for one image data is 15 KB.

Twenty Camera Servers are registered in five Storage Servers to record video.

The [Maximum file size / duration] option in the [Storage Server Configuration] window is set to six hours.

Under this condition, the video file size per Camera Server per day is 310 MB x 4 files.

Therefore, the video data quantity per Camera Server per day is 1.25 GB and 25 GB for twenty Camera Servers.

Hardware requirement

25 GB per day x 30 days = 750 GB

Ten servers is required (for each Hard disk capacity of 900 GB or more).

In this case, it is ideal to prepare one backup device for each server for backup. If you use a 400-GB LTO drive, you can save 2-week data on a single cassette of tape. Alternatively, you can prepare two or three servers dedicated for backup, and use network backup for central management.



System Maintenance

Chapter Overview

This chapter describes about the version upgrade, reinstallation and restoration of the older version for VK-64/VK-16, and about the version upgrade of camera's firmware.

This section describes how to upgrade previous versions of VK-64/VK-16.

Upgrade from Version1.0

- 1. Obtain the released version of v2.2 (you cannot use the upgrade program).
- 2. Back up the following folders that are in the Storage Server of v1.0.

<All drives>:\WebView-NVR

Please note that the capacity of this folder is large.

3. Install the new version.

If a failure occurs, restore the previous version by following "Procedure for Restoring Previous Version" (\rightarrow P. 8-6).

Upgrade from v1.1, 1.2, 1.3, 1.4, 2.0 and 2.1

1. Obtain the v2.2 upgrade program (free program).

Available from Canon Web site.

2. Back up the following folders that are in the Storage Servers of v1.1, v1.2, v1.3, v1.4, v2.0 and v2.1.

Configuration file path for OS other than Windows Vista/Windows Server 2008

<All drives>:\WebView-NVR

Configuration file path for Windows Vista/Windows Server 2008

<Startup drive for OS>:\ProgramData\Canon\WebView\NVR\

<All drives >:\WebView-NVR

3. Install the new version by following the upgrade procedure described at our WebView Product web page.

If a failure occurs, restore the previous version by following "Procedure for Restoring Previous Version" (→ P. 8-6).

Mote

- When upgrading your PC to Windows Vista or Windows Server 2008, first upgrade the software to v2.2 before upgrading to Windows Vista or Windows Server 2008.
- If you are using VK-64/VK-16 with NAS server, you need to set up log-on settings again after upgrading VK from v1.3, v1.4, v2.0 and v2.1 to v2.2.

Version upgrade from VK-Lite

- 1. First, you need to buy VK-64/VK-16 v2.2 (there are no upgrade program available).
- 2. Back up following folders of the VK-Lite storage server.

For OS other than Windows Vista/Windows Server 2008

For Windows Vista/Windows Server 2008

- <Startup drive for OS>:\ProgramData\Canon\Webview\NVR
- <All drives>:\WebView-NVR
- 3. Uninstall VK-Lite in [Add or Remove Programs] in [Control Panel] ([Uninstall a program] or [Programs and Features] in Windows Vista or Windows Server 2008).
- Install VK-64/VK-16 v2.2. If it failed, follow the instruction in "Procedure for Restoring Previous Version" (→ P. 8-6) to restore VK-Lite.

Reinstall VK-64/VK-16

You cannot reinstall the software if you use the upgrade program.

When You Have the Released Version

- 1. Uninstall v2.2.
- 2. Back up the following folders that are in the Storage Servers of v1.1, v1.2, v1.3, v1.4, v2.0 and v2.1.

Configuration file path for OS other than Windows Vista/Windows Server 2008

<Startup drive for OS>:\Documents and Settings\All Users\Application Data\Canon\Webview\NVR <All drives> :\WebView-NVR

Configuration file path for Windows Vista/Windows Server 2008

- <Startup drive for OS>:\ProgramData\Canon\WebView\NVR\
- <All drives>:\WebView-NVR
- 3. Install the new version by following the upgrade procedure described at our WebView Product web page.

If a failure occurs, restore the previous version by following "Procedure for Restoring Previous Version" (→ P. 8-6).

When You Do Not Have the Released Version 2.2

- 1. Uninstall v2.2.
- 2. Install the previous version.
- 3. Obtain the v2.2 upgrade program (free program).

Available from Canon Web site.

4. Execute the v2.2 upgrade program.



When You Want to Perform the Full New Installation If you have removed the application from [Programs and Features] in the [Control Panel], the application folder, including its setting files and recorded data, remains undeleted. To delete all these files, delete all the following folders.

- <System drive> :\Program Files\Canon\Webview\NVR
- <System drive> :\Webview-NVR (storage folder for recorded and event data)

Regarding the storage folder for configuration files, see <Startup drive for OS> in the Configuration file path above.

Procedure for Restoring Previous Version

Required Media and Data

Make sure that you have the installation CD, patch installer and backed-up data for the previous version.

- 1. Delete [Canon Network Video Recorder VK Series v2.2] from [Add or Remove Programs] in [Control Panel].
- 2. Delete the following folders.

Configuration file path for OS other than Windows Vista/Windows Server 2008

Configuration file path for Windows Vista/Windows Server 2008

- <Startup drive for OS>:\ProgramData\Canon\WebView\NVR\
- <All drives>:\WebView-NVR
- 3. Install the previous version by using the installation CD and patch installer for the previous version.
- 4. Stop the Storage Server in the Storage Server configuration. Quit the Viewer.
- 5. Replace the existing folders with the following backed-up data.

In case of Version 1.1, 1.2, 1.3, 1.4, 2.0 and 2.1

Configuration file path for OS other than Windows Vista/Windows Server 2008

<Startup drive for OS>:\Documents and Settings\All Users\Application Data\Canon\Webview\NVR

Configuration file path for Windows Vista/Windows Server 2008

<Startup drive for OS>:\ProgramData\Canon\WebView\NVR\

In case of Version 1.0

6. Start up the Storage Server.

Camera Server Maintenance

The information about the latest firmware and backup/restore tools can be obtained on Canon Web site.

Procedure for Updating Camera Firmware

When updating firmware, use proper tools for each model.

- 1. Obtain the latest firmware including the firmware update tool as well as backup and restore tools for configured values.
- 2. Save the values configured in the Camera Server by using the backup tool for configured values.
- 3. Perform the Firmware update by using the firmware update tool.

If a failure occurs in step 3, restore the settings by using the restore tool for configured values.

Troubleshooting

Chapter Overview

This chapter explains the chart of countermeasures against failures, measures to be taken when a trouble occurs (troubleshooting), error messages, and log files.

Troubleshooting for Recording

When a recording trouble occurs when playing back recorded vide data (e.g., data is not found), you can guess the cause by checking the Event Logs of the VK-64/VK-16 and Storage Server Log (re_log).

Log		Cause		Countermeasure
Event	Storage Server		Cause	Countermeasure
Connection to <camera address="" ip="" server's=""> error: Error occurred (<error no.="">: <description>) Ex. Connection to 192.168.100.1 error: Error occurred (10060: Connection time-out)</description></error></camera>	ERROR (connect): socket type= (IMAGE/EVENT/COMMAND), cameraserver= (<host>:<port>) win32_error= (<winsock error<br="">Code>:<error message="">)</error></winsock></port></host>	Error No. 10050 10054 10060 10061 10064	Description Network may be out of service. A Camera Server's network problem or session disconnection due to Camera Server's reboot has occurred.	Check the network (HUB, cables, etc.) for any problem and confirm that the Camera Server is operating normally.
Effective recording rate (<recording before="" change="" rate=""> → <recording after="" change="" rate=""> %) Ex. Effective recording rate (100 → 90.0%)</recording></recording>	Camera <camera> Effective recording rate (y%->z%) If the following message is also recorded, a large amount of captured data may have been discarded: Camera <camera>: <x>/<y> frames discarded due to busy frame queue in last 1 minutes.</y></x></camera></camera>	The effective recording rate is too low (below 50 %). Sensor and motion detection events occur too frequently, exceeding the standard given by the guideline. CPU load of the Storage Server PC may be high.		 Adjust the recording schedule and sensitivity of motion detection. Check the CPU usage and terminate any applications which are putting heavy loads to the CPU.
N/A	Camera <camera>: <x>/<y> frames discarded due to busy drive thread in last 1 minutes.</y></x></camera>	Load due to writing recorded video data onto HDD may be too high.		Use the Windows' Performance Monitor to check the writing status of HDD. Review the recording schedule or add servers as required.
N/A	Camera <camera>: <x>/<y> frames discarded due to busy frame queue in last 1 minutes.</y></x></camera>	CPU load of the Storage Server PC may be too high.		 Use the Task Manager to find out the application causing the problem. If the VK-64/VK-16 module (AE.EXE) is causing the problem, the event generation frequency may be too high. Try the following: Shorten the Maximum retained history setting for the recorded data Reduce the number of events to generate Add servers to distribute the load.
N/A	Error writing frame for camera <camera>: <error message=""> If the following messages are also recorded, a large amount of captured data may have been discarded: • Camera <camera>: <x>/<y> frames discarded due to busy frame queue in last 1 minutes. • Camera <camera>: <x>/y> frames discarded due to busy drive thread in last 1 minutes.</x></camera></y></x></camera></error></camera>	 The specified drive may be unable to be written. The time setting of the VK-64/VK-16 Storage Server PC may have been changed to the past (in the NTP operation environment). 		 Check the drive for recording video data. If you are using NTP to adjust time, shorten the synchronization interval with NTP (e.g., 7 days 1 day).
Recording to E:\drive is on standby due to shortage of free HDD space.	No Storage Server Log		writing recorded video data nay be too high.	Shorten the Maximum retained history or add HDD. Also, review the recording schedule.

VK Troubleshooting

Viewing Screen and Video Windows

This section describes how to solve problems that may occur when you are using VK-64/VK-16.

• Some of the thumbnails are not showing in the Camera Selection Area.

Situation You do not have enough thumbnails on display to make the scrollbar appear, but some of the

thumbnails that were displayed before are no longer shown.

Solution Most likely you have selected another Zone or Location from the drop-down menu that is

further down the list and the thumbnails have been scrolled to the left to show the selected

Zone (→ P. 5-31). Check the selected Location and Zone.

• Cannot Pan, Tilt or Zoom a Camera Server in a Video Window.

Situation You have clicked a Video Window to get Camera Server control, but the shape of the mouse

cursor is not changed to operate the Camera Server.

Solution Double-click the Video Window or select [Get Camera Control] from the Video Window menu

(→ P. 5-38). Alternatively, check whether recorded video is not being played. If video is not

being played, the title bar of the Video Window will be gray, not black (→ P. 5-37).

 The [Record Now] feature is gray and disabled in one Video Window menu, however it is enabled in other Video Window menus.

Situation You have clicked a Video Window to display a Video Window menu and [Record Now] is gray

(disabled). However, other Video Windows have the function enabled.

Solution Check if a Camera Server in the Video Window has the setting that disables recording (when

the Camera Server was configured, [Do not Record] was selected).

• Layouts set up by another user cannot be seen.

Situation In the [Organize Layouts & Layout Sequences] dialog, you have clicked in the [Personal

Layouts] folder in order to open a Layout created by another user.

Solution Layouts saved in the [Personal Layouts] folder cannot be seen by other users. To show a

created Layout to all users, it should be created by a user with Administrator privileges and

saved to the [Shared Layouts] folder (→ P. 5-19).

• Live and recorded video is not good quality (this does not relate to [Resolution]).

Situation In a Video Window, the live video quality is lower than that of another Video Window and

recorded video (when you play back video) is also not good quality.

Solution The quality of live and recorded video cannot be changed in VK-64/VK-16. The video quality

may vary from one Video Window to another because of Camera Server settings. The quality

can be changed to a higher one in the admin screens of Camera Servers.

• Recording cannot be performed.

Situation 1) Recording cannot be performed by all of the network cameras.

Situation 2) Recording cannot be performed by a certain network camera.

Solution

In the case of 1), check the following:

- The network cable of the server is plugged in.
- The power supply has been cut off.
- [Do not Record] is not specified in the [Special Day Schedule] settings and others.
- Link lamps on the hub (switching hub) and on the network connector for the server are on.
- ⇒If the lamps are off, there may be defects in the cable, hub (switch), or network connector for the server.

In the case of 2), check the following:

- The power source or network of the Camera Server have no problem.
- The ping command succeeds for the network camera.
- You can view live video of the Camera Server using VB-C500 Viewer, VB-C60 Viewer, NC Viewer, PC Viewer or other viewers.
- [Do not Record] is specified in the [Special Day Schedule] settings and others.
- Sensor recording or motion detection recording is selected or not.
- · Cannot log into a Storage Server from a Viewer.

Situation You cannot log into a Storage Server from a Viewer.

Solution

Check the following:

- The login user name and password are correct.
- The network between the server and the Viewer has no problem.
- The IP address of the server to which you want to login is correct.
- The ping command succeeds for the server from the Viewer.
- When the proxy is configured in Internet Explorer, change the settings to exclude the VK server.
- Is TCP Port 9080 being used by any application other than VK?
- Cannot view live video.

Situation You cannot view live video.

Solution

Check the following:

- If "Could not connect to camera" is displayed in the Video Window, check whether the power source of the Camera Server and the network have no problem.
- An error is displayed in the Timeline in the Viewer.
- ⇒If "Connection to host <Camera Server IP Address>: error" is displayed, check whether the power source of the Camera Server and the network have no problem.
- The screen goes black when layout is switched, but video is displayed after a few seconds.
- ⇒Too many Camera Servers that exceed the performance of your PC are displayed in the Viewer, or a live frame rate that exceeds the performance of your PC is set. Reduce the number of Camera Servers to be displayed, or decrease the live frame rate.

• It may take time to perform various viewer configuration changes or storage server operations.(If you are using Windows XP/Vista)

Situation

It may take time to perform storage server operations or configuration changes such as camera or schedule registrations sent by the viewer. (P. 1-12 Cases)

Solutions

- Be sure to register no more than 10 camera servers for one storage server.
- In case you do register more than 10 camera servers to one storage server, please use Windows Server 2003/2008.
- Live video is no longer displayed. (If you are using Windows XP/Vista)

Situation

Video from all camera servers is no longer displayed. (P. 1-12 Processes)

Solutions

- Be sure to connect no more than 10 camera servers to one viewer. (If you are using Autoswitching, set the interval to 20 seconds or longer).
- In case you do connect more than 10 camera servers to one viewer, please use Windows Server 2003/2008.
- When a layout sequence is running in the Viewer, the Video Window suddenly goes black and video
 of the Camera Server cannot be displayed.

Situation

When a layout sequence is running, the Video Window goes black and video of the Camera Server cannot be displayed.

Solution

When many Camera Servers are placed in one layout and a layout sequence is run in a short time, system resources required for communication may run short. Reduce the number of Camera Servers to be displayed in a layout, or make the switching interval for layout sequences longer.

• Viewer operation seems to slow down.

Situation

Viewer operation slows down.

Solution

The performance of a Viewer depends largely on CPU specifications and graphics specifications of the PC on which the Viewer is installed. When Viewer operation slows down, try to reduce the number of Camera Servers to be displayed or decrease a live frame rate. If the video quality of Camera Servers is set high or the resolution is set to VGA, processing may take a long time because the size of image data is large. In this case, review the video quality or video size in the Camera Server settings.

Timeline

• The Playback controls are inactive.

Situation

You have clicked any of the Playback controls but nothing happens.

Solution

Move the Playhead away from the Live position. Playback controls will then be active. A Video Window needs to be selected for playback. Also, the nudge buttons (\rightarrow P. 5-48) and the [Extract Video] button (\rightarrow P. 5-54) are enabled only when one Video Window is selected.

Extract Video

Cannot save video as no data could be found.

Situation You have attempted to extract video, but an error message appears stating that no video can

be found in the selected segment.

Solution Check that the selected segment of video has recorded footage (→ P. 5-56).

Scheduling and Recording

• Cannot initiate [Record Now] on a camera.

Situation You have selected a Video Window to initiate [Record Now], but the menu option is not

available.

Solution In the [Edit Camera Server] dialog of the [Configuration and Preferences] screen, [Do not

Record] is probably set for the Camera Server. Change the option to enable recording to the

Storage Server (→ P. 4-20).

· Cannot configure the Camera Server not to record.

Situation You have attempted to modify the Camera Server and set [Do not Record] in the [Edit

Camera Server] dialog. A message appears stating that the Camera Server is already set up

without recording settings.

Solution In the Camera Server list displayed on the [Locations / Zones] tab of the [Storage and

Camera Server Summary] screen, the selected Camera Server probably has more than one listing. Click the listing which has an associated Storage Server listed beside it and then click

[Remove Camera Server]. Make sure you save your changes to permanently remove the

deleted Camera Server

• Storage Server free disk space is extremely low.

Situation Storage Server disk usage is far in excess of the calculated level (→ P. 1-20, P. 3-17) and

there is little free space.

Solution When the Camera Server video quality is set high, there is a large amount of data per frame.

Also, if you are using anti-virus software, communication between Storage Servers and Camera Servers is being recorded and that file may be several gigabytes in size. Please alter

the anti-virus software settings to eliminate Storage Servers from virus scanning targets.

Connection Problems

Cannot connect to a Camera Server.

Situation In the Viewer the screen has gone black and a message appears stating "Could not connect

to camera".

Solution Check whether the network is down, whether the physical connection to the Camera Server is

broken, or whether the camera is not powered.

• Cannot connect to a Master Storage Server.

Situation You have attempted to launch the Viewer and a connection to the Master Storage Server error

message appears.

Solution Check whether the specified Master Storage Server works properly. On the Storage Server

computer, open the [Storage Server Configuration] utility. If the Storage Server is not running,

click [Start Storage Server] (→ P. 3-14).

• The [Configuration and Preferences] screen takes a long time to open.

Situation When you switch from the Viewing Screen to the [Configuration and Preferences] screen, a

message "Please wait" appears and remains on screen for a while.

Solution Check whether you do not have a lot of Camera Servers to disconnect. Waiting time is

dependent on the time required for disconnecting from each Camera Server on the network. It is recommended that you remove non-essential or low priority Camera Servers from your

Viewing Screen.

• Fails to connect to Storage Servers when switching to the [Configuration and Preferences] screen.

Situation You have attempted to switch to the [Configuration and Preferences] screen and an error

message appears stating a failure to connect to a particular Storage Server (name), although

it can still connect to the Master Storage Server.

Solution Check whether the specified Storage Server works properly. A network error may have

caused this situation.

Configuration Problems

• Camera Servers are not displayed in the [Camera Summary] window.

Situation In the list of Camera Servers on the [Camera Summary] window, some of the Camera Servers

are not displayed.

Solution Only Camera Servers associated with the item selected on the [Storage Servers] tab or the

[Locations / Zones] tab will be shown in the list. Also, if you have the [Storage Servers] tab

displayed, Camera Servers configured as [Do not Record] will not be shown.

• Motion detection setting cannot be performed on the camera server side.

Situation If the [Settings] button in [Motion Detection Settings] is not enabled, motion detection cannot

be configured on the camera side.

Solutions Please install VB Admin Tools bundled with the camera. For VB-C500VD/VB-C500D and

VB-C60, please install VB Admin Tools Ver. 5.1.

Upgrade Problems

Software cannot be upgraded to v2.2.

Situation

When you try to upgrade the software from v1.1, 1.2 or v1.3 to v2.2 after upgrading your OS to Windows Vista/Windows Server 2008, the Storage Server does not stop and installation cannot be completed.

Solution

Follow the procedure below:

- 1. Right click on the [Storage Server Configuration] icon on the desktop, then choose [Properties].
- 2. Click the [Compatibility] tab and check the [Run this program as an administrator] check box.
- 3. Double click the [Storage Server Configuration] icon to start the Storage Server Configuration tool.
- 4. Click the [Stop Storage Server] button in the [Storage server status] field.
- 5. Click the [Retry] button on the installer wizard for VK version 2.2.

Messages List

Operation Messages and Error Messages

Error messages and operation messages displayed during normal recording and operation of VK-64/VK-16 are shown below.

Video Windows Error Messages

	Messages	Cause	
Video window	Connecting to camera.	The viewer is in the process of connecting to the camera.	
	Could not connect to camera.	The viewer cannot connect to the camera server and the live video cannot be displayed.	
	Getting camera control.	The message is displayed before starting camera control after sending a camera control request.	
	Can't get camera control.	Another user with higher user authority has already been controlling the camera when you sent a camera control request.	
	Control will be lost in ' <count down="">' seconds.</count>	If the camera is left uncontrolled for 30 seconds, this message is displayed and a countdown starts. It counts down starting from 10 to 0 by 1 second.	
	Camera control lost.	Time out occurred while the viewer is controlling the camera or a camera control request was sent from another user with higher user authority. This message will close in three seconds.	
	No recorded video.	No recorded video exists during the time where the Playhead is positioned now, when playing recorded video.	
	Can't connect to storage server.	It is unable to connect to the storage server to play recorded video.	
	Not set up to record.	You attempted to play recorded video with the camera set to [Do not Record]	
	Please wait	It may take time until the MPEG-4 live/ recorded video is displayed. This message will close in several seconds.	

Storage Server Configuration Error Messages

	Messages	Cause
Login settings	This account does not have the right to logon as services. Please check the rights by the "Local Security Policy Editor" of "Windows". The service's account is changed to "Local system account".	Logged on using an account which does not have sufficient permissions to log on as a service.
	The recipient's e-mail address contains invalid characters.	A character other than alphanumeric characters and underscore (_) was entered in the address of the recipient.
	The recipient's e-mail address field must not be empty.	The address of the recipient was not entered.
	The sender's e-mail address contains invalid characters.	A character other than alphanumeric characters and underscore (_) was entered in the address of the sender.
	The sender's e-mail address field must not be empty.	The address of the sender was not entered.
	The SMTP host name is invalid.	The host name of the SMTP server contains an invalid character.
	The SMTP host name must not be empty.	The host name of the SMTP server was not entered.
Event	The SMTP port must be a number between 1 and 65535.	The port number of an invalid SMTP server was used.
notification	The user name must be between 1 and 100 characters in length.	The user name was out of the valid number of characters range (This includes when the user name was not entered).
	The user name contains invalid characters.	An invalid character was entered in the user name.
	The password must be between 1 and 20 characters in length.	The password was out of the valid number of characters range (This includes when the password was not entered).
	The password contains invalid characters.	An invalid character was entered in the password. Only alphanumeric characters and underscore (_) can be used.
	The POP host name is invalid.	An invalid character was entered in the host name of the POP server.
	The POP host name must not be empty.	The host name of the POP server was not entered.
	The POP port must be a number between 1 and 65535.	The port number of an invalid POP server was used.

	Messages	Cause
	An account with this user name already exists.	An attempt was made to add a user in the Storage Server by using a user name that is already registered.
	The user name contains invalid characters.	An attempt was made to add a user by entering a user name that contains a character other than alphanumeric characters and underscore (_).
User management	The password contains invalid characters. Valid characters include all alphanumeric characters and '_'.	An attempt was made to add a user by entering a password that contains a character other than alphanumeric characters and underscore (_).
	Please ensure that the password and confirmation match exactly.	An attempt was made to add a user by entering a password in the [Confirm Password] field, which does not match the entered password.
	Are you sure you wish to remove this user?	An attempt was made to delete the user.
	The storage server name must be between 1 and 20 characters in length.	The Storage Server name was out of the valid number of characters range (This includes when the Storage Server name was not entered).
	The proxy host name must not be empty.	The host name of the proxy server was not entered.
	The proxy host name is invalid.	The host name of an invalid proxy server was used.
	The proxy port must be a number between 1 and 65535.	The port number of an invalid proxy server was used.
	Proxy settings changed. Do you wish to restart the recording server?	The proxy server settings have changed.
Configuration	The maximum retained history field must not be empty.	The value of the maximum retention period was not entered.
	The maximum retained history must be greater than or equal to 1 day.	An attempt was made to configure the maximum retention period using a value of less than 1 day.
	The maximum file size or duration field must not be empty.	The value of the maximum file size/duration was not entered.
	The maximum file size must be less than or equal to 1024 MB.	An attempt was made to configure the maximum file size using a value larger than 1024MB.
	The maximum file size must be greater than or equal to 32 MB.	An attempt was made to configure the maximum file size using a value less than 32MB.

	Messages	Cause
	The maximum file time must be less than or equal to 24 hours.	An attempt was made to configure the maximum file duration using a value larger than 24 hours.
	The maximum file time must be greater than or equal to 1 hour.	An attempt was made to configure the maximum file size using a value less than 1 hour.
Configuration	The maximum disk space used field must not be empty.	The value of the maximum disk space used was not entered.
	The maximum disk space used must be greater than or equal to 32 MB.	An attempt was made to configure the maximum disk space used using a value less than 32MB.
	The low disk space warning level must not be empty.	The value of the low disk space warning level was not entered.
	The following error occurred saving the configuration file.	An error occurred while saving the Storage Server settings.
When exiting the application	The following error occurred writing the user file.	An error occurred while saving the user management information (the users.txt file).
or approving the change in all tabs	The new retained history settings may result in the deletion of some existing video files. Do you wish to continue?	The maximum retention period was changed to a shorter period.
	Do you wish to save your changes?	An attempt was made to exit the application without saving the setting change.
All tabs	Initialization of network communication has failed.	Communication initialization was interfered with due to an internal program or OS error that occurred when the Storage Server installation was activated.

Viewer Confirmation Messages

The < > part of the message differs depending on the situation.

	Messages	Cause
Registering Storage Servers and Camera Servers	Are you sure you want to delete camera server ' <camera name="" server="">'?</camera>	An attempt was made to delete the camera server.
Another Add Camera Server dialog	Proceeding will delete any schedules associated with the following: ' <camera number="">'. Click Yes to proceed, No to reconsider.</camera>	When you attempted to edit the VB150 settings, it was detected that the camera configuration has been changed on the VB150 side and the camera for which the schedule was configured no longer exists.
	This will replace an existing layout of the same name. Are you sure?	An attempt was made to save the current layout using the same name as a layout that already exists.
Saving/ Managing Video Layouts	Are you sure you want to delete the selected layout? <layout name=""></layout>	An attempt was made to delete the layout.
22,340	Are you sure you want to delete the selected folder, including layouts and layout sequences within the folder? <folder name=""></folder>	An attempt was made to delete the layout folder.

Viewer Warning Messages

	Messages	Cause
	The audio transmission function of the camera is not available. Please confirm the camera settings.	The audio transmission function of the camera is disabled.
Add Recording Schedule	A setup of the stream for recording is applied only to the JPEG recording not more than maximum frame rate 10fps. It is applied to neither JPEG recording of 10 or more fps nor MPEG-4 recording.	You attempted to apply video recording stream settings to high rate JPEG video or MPEG-4 video.
	MPEG-4 recording with Preset Tour could consume disk space rapidly. Do you wish to continue?	The data volume of MPEG-4 video becomes several times bigger if the video contains a lot of motion of subjects. You need attention when using Preset Tour together with MPEG-4 recording, as a whole image moves during Preset Tour.
Preset Tour Settings	Attention: The current Preset Tour settings might require you to repair the Pan/Tilt machine soon. Please note that the repair of consumable mechanical parts such as the Pan/Tilt machine may not be covered by the guarantee. Recommended Preset Tour settings to reduce the machine load: Change the Preset Tour duration within <hh>: <nn> at the [Start Time] and [End Time] setting. Adjust the Preset Tour configuration so that the total amount of camera movement (angle/time) becomes small. Set the pause time to the preset position longer than the Pause (sec) setting. Click the [Cancel] button to return to the setting screen.</nn></hh>	The configured settings exceed the endurance limit of 100,000 pans and tilts (300,000 for the VB-C60) within one year on the VB-C50i or VB-C300.

Viewer Error Messages

The < > part of the message differs depending on the situation.

	Messages	Cause
Starting the Viewer	Failed to connect to Master Storage Server. Please check the details and try again.	An attempt was made to start the Viewer, however a connection to the specified Master Storage Server could not be established.
	Failed to connect to Master Storage Server ' <ip address="" of="" server="" storage="">' because of version mismatch.</ip>	You attempted to connect to an older version (v1.1 or earlier) of the Storage Server as the Master Storage Server. Alternately, you attempted to connect to a v2.2 Master Storage Server from an older version (v1.2, v1.3, v1.4, v2.0 or v2.1) Viewer.
	Recording settings for camera servers on the storage server (' <storage name="" server="">') will not be available. Version mismatch.</storage>	You attempted to connect to an older version (v1.1 or earlier) of the Storage Server as a Slave Storage Server. Alternately, you attempted to connect an older version (v1.2, v1.3, v1.4, v2.0 or v2.1) Viewer to a v2.2 Slave Storage Server.
Configuration and Preferences screen	Recording settings for camera servers on the storage server (' <storage name="" server="">') will not be available. <cause error="" of="" the=""></cause></storage>	A connection to a Storage Server other than the Master Storage Server failed when you accessed the [Configuration and Preferences] screen.
	The changes you are trying to save cannot be sent to the storage server (' <storage name="" server="">') and will be lost.</storage>	An attempt was made to save the changes in the Camera Server list in the [Configuration and Preferences] screen, however a connection to the Storage Server could not be established.
	The configuration on the Master Storage Server has been modified by another administrator. Please restart your Viewer. Changes you have made to thumbnails, locations, zones and camera names have not been saved.	An attempt was made to save the changes in the Camera Server list, however another administrator has conducted changes.
	The configuration on the Master Storage Server has been modified by another administrator. Please restart your Viewer.	Another administrator changed the Master Storage Server settings while the Camera Server list was displayed.

	Messages	Cause
	You cannot assign this name to a Storage Server.	An attempt was made to register a Storage Server by specifying a loop back host/address ("local host", "127.0.0.1" or "localhostlocaldomain").
	This storage server has already been added. Please check your settings and try again.	An attempt was made to add a Storage Server that has been already registered.
Adding/	The Master Storage Server cannot be edited.	An attempt was made to edit the Master Storage Server.
Editing/ Deleting the Storage	Please save or discard your changes before changing your Storage Server settings.	An attempt was made to change/delete the Storage Server while there are camera server settings that have not been saved.
Server	The Master Storage Server cannot be deleted.	An attempt was made to delete the Master Storage Server.
	The storage server host name is invalid. Please specify a valid host name or IP address.	The host name or IP address was invalid when [OK] was pressed.
	The storage server port is invalid. Please specify a value between 1 and 65535.	The port number was invalid when [OK] was pressed.
	The Storage Server host name cannot be blank.	Attempted to add or edit a storage server without entering a name for it.
	A location with this name already exists. Please use a different name and try again.	An attempt was made to register a location name that is already registered.
	A location cannot have an empty name. Please specify a name and try again.	An attempt was made to register a location without entering the name.
	This location has zones in it. Please remove these before deleting the location.	An attempt was made to delete the location for which a zone has been added.
Adding/Editing a Location and Zone	Please select a location for this zone	An attempt was made to add a zone while the location has not been registered.
	A zone with this name already exists in this location. Please use a different name and try again.	An attempt was made to add a zone with a name that has been already registered.
	A zone cannot have an empty name. Please specify a name and try again.	An attempt was made to register a zone without entering the name.
	This zone has camera servers in it. Please remove these before deleting the zone.	An attempt was made to delete the zone for which a camera server has been added.

	Messages	Cause
	This camera server has already been set up to record to the selected storage server. Please check your settings and try again.	Even though video of a camera server is configured to be recorded in the Storage Server, the IP address and port used are the same as the camera server that has been configured in the Storage Server.
	Please select a location and a zone.	An attempt was made to add a camera server without selecting a location and zone.
	Please select a location and a zone. <camera number=""></camera>	An attempt was made to add a camera server without selecting a location and zone. This is displayed when VB150 is in the [simultaneous] mode and multiple cameras are connected.
Adding a Camera Server	A camera server with the same host name and port is currently queued for deletion. You must save changes before adding this camera server.	After deleting the camera server, an attempt was made to add the camera server again when the changes have not been saved.
	The camera server host name for live viewing is invalid. Please specify a valid host name or IP address.	An attempt was made to connect with an invalid host name/IP address.
	The camera server port for live viewing is invalid. Please specify a value between 1 and 65535.	An attempt was made to connect with an invalid port number.
	The camera server host name for the storage server is invalid. Please specify a valid host name or IP address.	An attempt was made to connect to the Storage Server with an invalid host name/IP address.
	The camera server port for the storage server is invalid. Please specify a value between 1 and 65535.	An attempt was made to connect to the Storage Server with an invalid port number.
	There has been a problem modifying schedule day ' <schedule name="">' for camera '<camera name="">' on storage server '<storage name="" server="">'. This change may not have been reflected on the storage server.</storage></camera></schedule>	The destination Storage Server was not found when you attempted to save the schedule.
Recording Schedule	There has been a problem deleting schedule day ' <schedule name="">' from camera '<camera name="">' on storage server '<storage name="" server="">'. This change may not have been reflected on the storage server.</storage></camera></schedule>	The destination Storage Server was not found when you attempted to delete the schedule.
	There has been a problem retrieving schedules from storage server ' <storage name="" server="">'.</storage>	The Storage Server in which the schedule is to be saved was not found when you attempted to display the [Recording Schedules] window or to switch the Storage Server.

	Messages	Cause
	This schedule item overlaps a previously scheduled item. Please check your settings and try again.	The recording schedules are overlapping.
	Schedule items must be at least 15 minutes long. Please check your settings and try again.	An attempt was made to register a schedule with a shorter period than 15 minutes.
Recording Schedule	Do you want to save your schedule changes?	An attempt was made to close the Normal or Special Day Schedule screen without saving the change.
Scriedule	The following cameras will not be part of this multiple schedule creation because they have schedules that clash with the requested time range:	The Recording Schedules window was dragged in order to add multiple recording schedules, however the camera server for which a schedule has already been configured exists.
	Multiple schedule creation failed - all selected cameras have schedules that clash with the new schedule time range.	A layout or layout sequence with the same name exists in the folder to which the layout or layout sequence is moved or copied.
	This schedule type has days set up for it to be used on. These need to be removed before deleting the schedule type.	An attempt was made to delete the special day schedule that is planned to execute.
Special Day Schedule	This day has already been set up to use another schedule type ' <special day="" name="" schedule="">'. To use a different schedule type, the day needs to be deleted from the other schedule type first.</special>	An attempt was made to use the data for which another special day schedule is already configured.
	Special day schedules start from 0000 and end at 2400. Please adjust the end time for this schedule and try again.	An attempt was made to register a schedule that passes 24:00.
	A schedule with this name already exists. Please use a different name and try again.	An attempt was made to add a special day schedule with a name that is already registered.

	Messages	Cause
	Communication with the Storage Server ' <storage name="" server="">' has failed. To ensure that event and video data is available from this storage server, identify and resolve the problem and then press 'OK' to reconnect to the Storage Server. If you press 'Cancel' then some event data, including all future events, for camera servers recording to this Storage Server will not be available.</storage>	When displaying the Viewing Screen, the Viewer connects to a Storage Server. An error occurred during this process. When multiple Storage Servers are registered, the Viewing Screen may be displayed for each of the servers. If this error frequently occurs, check that the TCP 10080 port for the storage server is being used by an application other than VK.
	The following layouts cannot be found and have been removed from this layout sequence: <layout name=""> Click OK to continue viewing this sequence.</layout>	There is a layout that can only be seen while the layout sequence is being executed, and the user has the right to edit the layout sequence.
Viewing Screen	The following layouts cannot be found. Contact your system administrator to have these removed from the sequence : <layout name=""> Click OK to continue viewing this sequence.</layout>	The shared layout sequence was started, however there is a layout that cannot be seen and the user does not have the administrator privilege.
	None of the layouts in this sequence can be found.	The shared layout sequence was started, however there are no layouts that can be seen and the user does not have the administrator privilege.
	None of the layouts in this sequence can be found. Click OK to edit this sequence or Cancel to return to the previous layout.	The layout sequence was started, however there are no layouts that can be seen. You have the right to edit the layout sequence.
	Do you want to save changes to this layout?	Designated a Windows or Program Files folder as the save destination for Capture Still Frame images.
	The image could not be saved.	The Windows folder or the Program Files folder was specified as the destination folder for snapshots.
	Could not save video because there was no data to record.	There are no recorded videos for the selected segment thus they could not be saved.

	Messages	Cause
Viewing	Failed to trigger manual recording for camera ' <camera name="">' on storage server '<storage name="" server="">'. *The following message is added when the number of camera servers exceeds the licensing restrictions. Number of licenses exceeded.</storage></camera>	Manual recording could not be started.
Screen	This will replace an existing layout of the same name. Are you sure?	An attempt was made to save the layout sequence using a name that is already been registered as a layout or layout sequence.
	The number of MPEG-4 video windows exceeds 20. Do you wish to switch this video window to display MPEG-4?	The number of videos where MPEG-4 was selected as the [Selection of receiving image] exceeds 20.
Saving/ Managing Video Layouts	You cannot delete <layout name=""> because it is the current layout or it contains the current layout or layout sequence.</layout>	An attempt was made to delete a layout that is currently being used.
j	You must enter a non blank name. Please check your settings and try again.	An attempt was made to add a layout folder without entering the name.
	Could not save video because there was no data to record.	There are no recorded videos for the selected segment thus they could not be saved.
Extracting Video	The image could not be saved.	The Windows folder or Program Files folder was specified as the destination folder for files.
	Failed to create the MOV file. Please check the write permission of the file.	An error occurred when the image file was being created or while settings were being saved.

	Messages	Cause
Adding/Editing a Camera Server	This camera server has already been set up without recording. Please check your settings and try again.	When a camera server configured as [Do not record] is already added, an attempt was made to add or edit a camera server using the same hot name/IP address and port number.
	Connection to the camera server could not be established. Please verify that the host name or IP address, user name, and password are correct. <communication -="" details="" error="" messages=""></communication>	Could not connect to the camera server.
	The storage server of this version does not support the specified camera.	You attempted to register VB-C500VD, VB-C500D, VB-C60 or VB-C300 with an older version of the Storage Server.
Add/Edit Camera Server dialog, Add/Edit Recording Schedule dialog, Motion Detection Settings dialog, Sensor Event Settings dialog	Connection to the camera server has been lost.	An error relating to the camera server connection occurred.
	Failed to connect a camera server.	An unknown error relating to the camera server connection occurred.
	At least one day must be selected.	[OK] was pressed without specifying the weekday.
Add/Edit Recording Schedule dialog	At least one type of recording must be selected.	[OK] was pressed without selecting the recording mode check box.
	The recording frame rate must be between ' <fps>' and '<fps>'.</fps></fps>	[OK] button was pressed after entering an invalid frame rate.
	You cannot use digital zoom when [Custom] is selected.	Attempted to close the Add (Edit) Schedule Item with VB-C60 digital zoom specified while [Custom] was still selected.
	If Night Mode is set to [Auto], please confirm that exposure is set to [Auto] in the camera control panel.	[Night Mode] was set to [Auto] while exposure was not set to [Auto] in the camera control panel.

	Messages	Cause
	The changes you are trying to save cannot be sent to the storage server (<storage name="" server="">) and will be lost. <communication -="" details="" error="" messages=""></communication></storage>	An error occurred while saving the settings in the Camera Summary window.
	Are you sure you want to delete storage server ' <storage name="" server="">'?</storage>	An attempt was made to delete a Storage Server other than the Master Storage Server.
Camera	Are you sure you want to delete location ' <location name="">'?</location>	An attempt was made to delete the location.
Summary window	Are you sure you want to delete zone ' <zone name="">'?</zone>	An attempt was made to delete the zone.
	Are you sure you want to delete camera server ' <camera name="" server="">'?</camera>	An attempt was made to delete the camera server.
	Do you want to save your configuration changes?	An attempt was made to close the [Camera Summary] window without saving the changes.
	There has been an error saving the configuration on the Master Storage Server.	An attempt was made to save the settings, however, saving the Master Storage Server settings failed.
Connect to Master Storage	The master storage server host name is invalid. Please specify a valid host name or IP address.	An attempt was made to connect with an invalid host name/IP address.
Server dialog, Connection Error dialog	The master storage server port is invalid. Please specify a value between 1 and 65535.	An attempt was made to connect with an invalid port number.
Edit Camera Server dialog	Proceeding will delete any schedules associated with the following: <camera name="" server="">. Click Yes to proceed, No to reconsider.</camera>	[OK] was pressed in the [Edit Camera Server] dialog when a change was made to the camera registered in the camera server.
Event Search dialog	There are no events to display	No events to be displayed in Event Search were found.
	The length of the extracted video may not exceed 1 hour.	An attempt was made to configure the time using a value longer than 1 hour.
Extract Video dialog	Could not save video because there was no data to record.	The recorded video at the specified time cannot be read.
	Failed to extract the video after https://www.css/https://www.css/www.css/www.css/www.css/www.css/www.css/www.css/www.css/www.css/https://www.css/www.css/https://www.css/www.css/w	You attempted to use [Extract Video] to save recorded video for a time range that spans two or more MPEG-4 recording schedules.
Folder Name dialog	You must enter a non blank name. Please check your settings and try again.	An attempt was made to add a layout folder without entering the name.

	Messages	Cause
Layout Sequence dialog	Shared layout sequences may not contain personal layouts. The following layouts must be removed before the layout can be saved as a shared layout sequence:	An attempt was made to change the layout sequence that contains a personal layout sequence to a shared layout sequence.
	The analysis frame rate must be between ' <fps>' and '<fps>'.</fps></fps>	An invalid value was selected for the motion detection frame rate.
Motion Detection	The recording frame rate must be between ' <fps>' and '<fps>'</fps></fps>	An invalid value was selected for the motion detection recording frame rate.
Settings dialog	The pre-event time must be no greater than 30.	[OK] was pressed after configuring a value exceeding 30 seconds for the pre-event time value.
Normal or Special Day Schedule window and Add/Edit Camera Server dialog	Recording settings for camera servers on the storage server ' <storage name="" server="">' will not be available. <communication -="" details="" error="" messages=""></communication></storage>	An error occurred while connecting to the Storage Server, when the Normal or Special Day Schedule window is opened or the Storage Server in the Recording Schedules window is changed. Or, a communication error occurred when you were adding/editing a Storage Server.
	This will replace the current layout. Are you sure?	There is a layout with the same name in the destination to which the layout is moved and the name is the same as the layout that is being currently used.
	You cannot delete ' <layout name="">' because it is the current layout or it contains the current layout or layout sequence.</layout>	An attempt was made to delete the current layout or the folder that contains the current layout or layout sequence.
Organize Layouts &	Are you sure you want to delete the selected layout? <layout name=""></layout>	An attempt was made to delete a layout that is not currently being used.
Layout Sequences dialog	Are you sure you want to delete the selected folder, including layouts and layout sequences within the folder? 	An attempt was made to delete the layout folder.
	Are you sure you want to delete the selected layout sequence?	An attempt was made to delete the layout sequence.
	You cannot delete ' <layout name="">' because it is the current layout sequence.</layout>	An attempt was made to delete a layout that is registered in the current layout sequence.
	You cannot overwrite ' <layout name=""> ' because it is used by the current layout sequence.</layout>	An attempt was made to change or overwrite the layout that is being used in the currently active layout sequence.

	Messages	Cause
	Unable to create folder. The name ' <folder name="">' already exists.</folder>	An attempt was made to create a new folder with a name that is already being used.
	Unable to change layout name. The name ' <layout name="">' already exists.</layout>	An attempt was made to change the name of a layout or layout sequence to a name that is already being used.
Organize	Unable to change layout folder name. The name ' <folder name="">' already exists.</folder>	An attempt was made to change the name of a folder to a name that is already being used.
Layouts & Layout Sequences	This will replace an existing layout of the same name. Are you sure?	A layout or layout sequence with the same name exists in the folder to which the layout or layout sequence is moved or copied.
dialog	The layout or the folder of the same name has already been registered.	A folder with the same name as the folder to which the layout or layout sequence is moved or copied exists. Or, a layout or layout sequence with the same name exists in the folder to which the folder is moved or copied.
	You cannot delete ' <layout name="" sequence=""> ' because it is the current layout sequence.</layout>	An attempt was made to delete the current layout sequence.
	The recording frame rate for sensor ' <sensor name="">' must be between 0.1fps and 30fps.</sensor>	An invalid recording frame rate was entered.
Sensor Event Settings dialog	The pre-event time for sensor ' <sensor name="">' must be no greater than 30.</sensor>	[OK] was pressed after configuring a value exceeding 30 seconds for the pre-event time value.
	You cannot use digital zoom when [Custom] is selected.	Attempted to close the [Sensor Event Settings] dialog with VB-C60 digital zoom specified while [Custom] was still selected.
Viewer Settings window	Do you want to save your Viewer Settings changes?	An attempt was made to close the Viewing Screen without saving the changes.

VK-64/VK-16 Recording Engine Logs

A list of messages shown in the Storage Server log file nvr_re_log_<N>.txt (<N> is either 0 or 1) is shown below. These messages are generated by the recording engine (Win32 service) that runs as part of a Storage Server.

Messages	Cause	Action
Camera <camera>: <x>/<y> frames discarded due to busy drive thread in last 1 minutes.</y></x></camera>	x frames out of y frames are discarded because there were a large number of frames that have been requested to be written in the disk. It is difficult for the current settings of the recording engine to process this amount of tasks. This message is recorded when recording failure occurs when disk is under a heavy load.	Reduce the system load using the following methods. Reduce the amount of data to record (For example, lower the resolution or frame rate). Install an additional hard disk. Implement an action such as upgrading the CPU, or increasing memory or existing hard disk space.
Camera <camera>: <x>/<y> frames discarded due to busy frame queue in last 1 minutes.</y></x></camera>	x frames out of y frames are discarded because there were a large number of unprocessed frames. It may be that CPU or hard disk drive is unable to process data at the same speed rate as the data reception. This message is recorded when recording failure occurs due to motion detection or too many event occurrences.	Reduce the system load using the following methods. 1. Reduce the amount of data to record (For example, lower the resolution or frame rate). 2. Install an additional hard disk. 3. Implement an action such as upgrading the CPU, or increasing memory or existing hard disk space.
Error resolving name for POP server host: port Error: <winsock code="" error="">: <error message=""></error></winsock>	When sending E-mail, the recording engine could not resolve the host name of the POP server.	See the corresponding Winsock error code in "Error Codes in Log File" (→ P. 9-31).
Error connecting socket for POP server host: port Error: <winsock code="" error="">: <error message=""></error></winsock>	When sending E-mail, the recording engine could not connect to the POP server.	See the corresponding Winsock error code in "Error Codes in Log File" (→ P. 9-31).
POP connection error: 0 POP response: <pop response=""></pop>	When sending E-mail, an error occurred in the first response sent after connecting to the POP server.	See "Error Codes in Log File" (→ P. 9-31).
POP user error: 0 POP response: <pop response=""></pop>	When sending E-mail, the user name entered for the POP server could not be authenticated.	Check the Storage Server configuration to see if the entered user name is correct.
POP password error: 0 POP response: <pop response=""></pop>	When sending E-mail, the password entered for the POP server could not be verified.	Check the Storage Server configuration to see if the entered password is correct.

Messages	Cause	Action
Error resolving name for SMTP server host: port Error: <winsock code="" error="">: <error message=""></error></winsock>	When sending E-mail, the recording engine could not resolve the host name of the SMTP server.	See the corresponding Winsock error code in "Error Codes in Log File" (→ P. 9-31).
Error connecting SMTP to server host: port Error: <winsock code="" error="">: <error message=""></error></winsock>	When sending E-mail, the recording engine could not connect to the SMTP server.	See the corresponding Winsock error code in "Error Codes in Log File" (→ P. 9-31).
Error sending E-mail. SMTP server log follows: <smtp error="" message=""></smtp>	The recording engine could not send E-mail due to a communication error with the SMTP server. Please see the SMTP server log for details.	See the corresponding SMTP error code in "Error Codes in Log File" (→ P. 9-31).
NVR recording engine stopping	This is always displayed when the recording engine stops.	No action is required.
NVR Recording Engine startup complete. Log level = (<log level="">)</log>	This is always displayed when the recording engine starts. The value in Log Level indicates the log level that is currently being configured (The default is 1).	No action is required.
Unable to register a drive for camera <host>:<port>.</port></host>	The storage destination drive configured for this camera server has been deleted.	Change the storage destination drive of the camera server in [Configuration] of the Viewer.
Error deleting old file <windows error="" message="">.</windows>	A system error occurred when deleting the file. This file is probably being used by the access engine or other application. When this file is being used for playing a recorded video, this error is normal.	There is no necessary action.
Error writing frame for camera <camera>: <error message=""></error></camera>	Cannot write data in the hard disk.	Check to ensure that the specified drive is not configured as read-only. In addition, ensure that all directories in this path are writable. When the drive cannot be used due to the above reason, configure it in a way so that there are no camera servers records on this drive. *This is also recorded when the date & time of the PC is reset to past. When this occurs, this error will no longer be recorded when the date and time is reset to the current date and time.

Messages	Cause	Action
ERROR(timeout): socket type=(IMAGE/ EVENT/ COMMAND), cameraserver=(<ho st="">:<port>)</port></ho>	A timeout occurred while waiting for a response from the specified camera server. This normally occurs when the camera server is offline. IMAGE == Process of getting image EVENT == Process of getting camera server status implemented by GetNotice COMMAND == Camera server operation/configuration change command process	Check to ensure that the camera server is on and connected to the network. If a proxy server is configured using the Storage Server Configuration tool, check to ensure that the proxy server is running.
ERROR(connect): socket type=(IMAGE/ EVENT/ COMMAND), cameraserver=(<ho st="">:<port>) win32_error=(<wins code="" error="" ock="">: <error message="">)</error></wins></port></ho>	An error occurred when connecting to the specified camera server. IMAGE == Process of getting image EVENT == Process of getting camera server status implemented by GetNotice COMMAND == Camera server operation/configuration change command process * same applies for "ERROR (WSAConnect)".	See the corresponding Winsock error code in "Error Codes in Log File" (→ P. 9-31).
ERROR(http): socket type=(IMAGE/ EVENT/ COMMAND), cameraserver=(<ho st="">:<port>) http_status=(<http code="" error="">)</http></port></ho>	An HTTP error occurred when connecting to the camera server. IMAGE == Process of getting image EVENT == Process of getting camera server status implemented by GetNotice COMMAND == Camera server operation/configuration change command process	See the corresponding HTTP error code in "Error Codes in Log File" (→ P. 9-31).
Failed to write camera configuration file	Cannot overwrite the camera server configuration file. The setting changes conducted after the recording engine started cannot be saved.	Check to ensure that you have the write privilege for the LocalSystem account in the VK-64/VK-16 configuration directory.
ERROR: Out of memory please check configuration of this PC	Failed to reserve memory in the recording engine since the system memory is under a heavy load because unprocessed frames continued to increase. An application error will occur in a few seconds and the Storage Server functions will stop.	Reduce the system load using the following methods. Reduce the amount of data to record (For example, lower the resolution or frame rate). Install an additional hard disk. Implement an action such as upgrading the CPU, or increasing memory or existing hard disk space.

Messages	Cause	Action
Camera <camera> Effective recording rate (<y>% -> <z>%)</z></y></camera>	The recording frame rate has been changed from y% to z% because the load of the recording engine continued to increase (decrease).	Even though there is no necessary action, you can reduce the system load using the following methods if you want to avoid frame rate decrease events. 1. Reduce the amount of data to record (For example, lower the resolution or frame rate). 2. Install an additional hard disk. 3. Implement an action such as upgrading the CPU, or increasing memory or existing hard disk space.
ERROR(http): socket type= (Image), cameraserver= (<host>:<port>) http_status=400</port></host>	An HTTP 400 error occurred when getting the image.	It may be connected to SNC-P5, DF40N in the MPEG mode. Change it to the JPEG mode. For other causes, see the corresponding HTTP error code in "Error Codes in Log File" (→ P. 9-31).
Failed to start the recording-mode stream for Camera <ip address="" camera="" of="">.</ip>	Recording video stream requests were made to the VB-C500VD/VB-C500D/VB-C60 from multiple Storage Servers.	Change the settings such that the recording video stream request is only made by one unit.

Access Engine Log

A list of messages shown in the Storage Server log file nvr_ae_log_<N>.txt (<N> is either 0 or 1) is shown below. These messages are generated by the access engine (Win32 service) that runs as part of a Storage Server.

Messages	Cause	Action
NVR Access Engine startup complete. Log level = <log level=""></log>	It indicates that startup of the access engine has been completed.	No action is required.
NVR Access Engine has finished shutting down.	The access engine has been stopped.	No action is required.

VK-64/VK-16 Viewer Logs

A list of messages shown in the VK Viewer log file nvr_viewer_log_<N>.txt (<N> is either 0 or 1) is shown below.

Messages	Cause	Action
CHttpVbSetngThread: inet error= <wininet error code>, winsock error=<winsock error<br="">code>, count=<number of<br="">occurrences></number></winsock></wininet 	A network error occurred while communicating with the camera server (This is recorded when a problem occurs in configuration protocol communications).	See the corresponding Winsock error code in "Error Codes in Log File" (→ P. 9-31).
vbc_HttpCommand:in et error= <wininet error<br="">code>, winsock error=<winsock error<br="">code>, count=<number of<br="">occurrences></number></winsock></wininet>	A network error occurred while communicating with the camera server (This is recorded when a problem occurs in WV-HTTP protocol communications).	See the corresponding Winsock error code in "Error Codes in Log File" (→ P. 9-31).

Log Storage Destination

 The Storage Server logs are stored in the following folder in the PC where the Storage Server is installed.

For Windows Vista/Windows Server 2008

<System drive>:\ProgramData\Canon\Webview\NVR

For OS other than Windows Vista/Windows Server 2008

- <System drive>:\Documents and Settings\All Users\Application Data\Canon\Webview\NVR\logs
- The Apache logs used by the Storage Server are stored in the following Storage Server installation folder.
 - <Storage server installation folder>:\websrvr\logs\
- The Viewer logs are stored in the following folder in the PC where the Viewer is installed.

For Windows Vista/Windows Server 2008

<System drive>:\ProgramData\Canon\Webview\NVR

For OS other than Windows Vista/Windows Server 2008

<System drive>:\Documents and Settings\All Users\Application Data\Canon\Webview\NVR\logs

Error Codes in Log File

Winsock Error Codes

Codes	Error Messages	Description
10038	An operation was attempted on something that is not a socket.	This may be recorded in Version 1.1, however, there is no necessary action.
10048	Only one usage of each socket address (protocol/network address/port) is normally permitted.	All resources for communication are being used. This frequently occurs when a black screen problem occurs in Viewer layout sequences.
10050	A socket operation encountered a dead network.	This occurs when the PC recognizes that the network is not available because the closest router or Hub to the PC is powered off. Normally, this cannot be recognized, therefore it is rare that this error is reported.
10051	A socket operation was attempted to an unreachable network.	This occurs when another network device recognizes that the network is not available because the router or Hub is powered off. Normally, this cannot be recognized, therefore it is rare that this error is reported.
10054	An existing connection was forcibly closed by the remote host.	The connection is disconnected by the camera server due to camera server restart or other cause. This may occur when the camera server is restarted using the restart button on the configuration page on the software-side. However, this rarely occurs.
10060	A connection attempt failed because the connected party did not properly respond after a period of time, or established connection failed because connected host has failed to respond.	A timeout occurred in the TCP connection with the camera server (This occurs when the camera server is down).
10061	No connection could be made because the target machine actively refused it.	The camera server rejected the TCP connection (This occurs when the port number specification is incorrect or other cause).
10064	A socket operation failed because the destination host was down.	This is recorded when the camera server is down (Normally, 10060 occurs).
10065	A socket operation was attempted to an unreachable host.	There are no routes to connect to the camera server (This may also occur when there is a failure in the network cable connected to the PC or HUB).

Codes	Error Messages	Description
10091	WSAStartup cannot function at this time because the underlying system it uses to provide network services is currently unavailable.	There is a failure on the PC network board.
11001	No such host is known.	The host name in DNS could not be resolved.
11004	The requested name is valid, but no data of the requested type was found.	The host name in DNS could not be resolved (11004 may occur instead of 11001 in 2003).

SMTP Error Codes

Codes	Error Messages	Description
421	<domain> Service not available, closing transmission channel</domain>	The communication is terminated because the mail server stopped.
450	Requested mail action not taken: mailbox unavailable	The requested mail process was not executed because the mailbox is not available.
451	Requested action aborted: local error in processing	The requested execution was canceled because an error occurred in the mail server.
502	Command not implemented	The mail server does not support the command that was sent.
550	Requested action not taken: mailbox unavailable	The request was not executed because the mailbox is not available.

HTTP Error Codes

Codes	Error Messages	Description
400	Bad Request	When more than 4 Storage Servers are connected when a Sony camera is used. This is recorded when the operation mode of the camera server is mpeg4.
401	Unauthorized	The user authentication or password for connecting to the camera server is incorrect.
403	Forbidden	This is recorded when the connection cannot be established due to the IP address restriction on the camera server side (It may also be returned by the proxy server).
500	Internal Server Error	This occurs when the webview server is not running even when the HTTP server is running. This may also be recorded even during normal operation if the camera server is restarted.
502	Bad Gateway	This is recorded when the proxy server returned an HTTP 502 error (which occurs when the proxy server receives an error from the upper proxy).

Codes	Error Messages	Description
503	Service Unavailable	This occurs when the camera server is temporarily unable to process requests due to server overload (excessive requests from multiple clients), an uncompleted start-up process on the camera server, or other reasons. This is recorded when the proxy server returned an HTTP 503 error (which occurs when the proxy server failed to connect to the camera server).
504	Gateway Time-out	This is recorded when the proxy server returned an HTTP 504 error (which occurs when the proxy server could not receive a reply from the upper proxy).

Wininet Error Codes

Codes	Error Messages	Description
12002	The request has timed out.	A request timeout occurred. It indicates that connection or request transmission failed.
12005	The URL is invalid.	The URL is incorrect (Normally, this does not occur, however, it may occur when an attempt is made to connect to an unsupported camera server).
12007	The server name could not be resolved.	The host name could not be resolved (This error indicates when a host name that is not registered in DNS is specified or that a problem occurred in communication with DNS).
12017	The operation was canceled, usually because the handle on which the request was operating was closed before the operation completed.	The communication was canceled (This error is not a problem, it may be recording during normal operation).
12029	The attempt to connect to the server failed.	The connection to the camera server failed (Normally 12002 is recorded).
12030	The connection with the server has been terminated.	The connection to the camera server has been disconnected (The disconnect process itself is recorded when it is executed normally).
12031	The connection with the server has been reset.	The connection to the camera server has been disconnected forcibly.

POP Error Codes

Error Messages	Description	
ERR never heard of mailbox name	The mail address is incorrect.	
ERR invalid password	The password is incorrect.	
ERR unable to lock maildrop	The mailbox cannot be used (Another program is already using it).	

VK Event Information

Event type	Displayed Messages
Starting or stopping the recording engine	starting (on)/stopping (off) Recording Engine <status></status>
User logon	on User (<username>) logged <status></status></username>
Sensor	on/off Sensor <sensor name=""> <status>.</status></sensor>
Motion detection	on/off Motion <status>.</status>
Starting or stopping recording	starting (on)/stopping (off) Recording stopping or Recording starting. <frame rate=""/> fps Pre-event recording for <configured duration=""> secs.</configured>
Starting or stopping the recording settings	Created (on)/Closed (off) File Set <number> <status></status></number>
Manual recording and remote trigger	starting (on)/stopping (off) For manual recording: Manual recording (<user name="">) <status></status></user>
	For remote trigger: <custom by="" client="" provided="" text="" the="" triggered=""></custom>
Disk space warning	warning (on)/ok (off) Disk space on drive <drive> <status></status></drive>
Starting or stopping deleting due to low disk space	Starting (on)/Stopping (off) <status> deleting files on drive <drive> due to low disk space</drive></status>
Starting or stopping recording due to low disk space	Starting (on)/Stopping (off) <status> suspension of recording on drive <drive> due to low disk space</drive></status>

Displayed Messages

Error (on)/ok (off) Connection to host <camera address="" server=""> : <port> <status></status></port></camera>
Recording continuing
Effective recording rate (<recording before="" change="" rate=""> → <recording after="" change="" rate=""> %) Recording rate is the ratio of received images that are actually being recorded. If the rate is 100%, then all received images are recorded. If 50%, 1 frame per 2 frames is recorded.</recording></recording>
Course

Error Number: Error Description	Cause
10048: Address in use	A socket for the communication could not be generated because a large number of TCP connections are used in the PC.
10050: Network down	The network is down (when a failure occurs in a HUB or router located near the PC).
10051: Network unreachable	A failure occurred in a HUB or router near the camera server.
10054: Forced disconnection from camera	The TCP connection is disconnected because the camera server was restarted or another cause.
10060: Connection timeout	A timeout occurred in the TCP connection with the camera server (This occurs when the camera server is down).
10061: Camera connection refused	The camera server rejected the TCP connection (This occurs when the port number specification is incorrect or another cause).
10064: Camera power off	The camera server is down (Normally, 10060 occurs).
10065: Camera unreachable	There are no routes to connect to the camera server (This may also occur when there is a failure in the network cable connected to the PC or HUB).
10091: Network board not ready	There is a failure on the PC network board.
11001: Host not found	The host name in DNS could not be resolved.
11004: Host not found	The host name in DNS could not be resolved (11004 may occur instead of 11001 in 2003).
Empty character string	Other Winsock Errors
HT401: Authentication required	The user authentication or password for connecting to the camera server is incorrect. Check to ensure that it is not an on/off event.
HT403: Host/IP address restricted	Cannot connect due to the IP address restriction on the camera server side.
HT502: Bad Gateway 502	The proxy server returns an HTTP 502 error (which occurs when the proxy server receives an error from the upper proxy).
HT503: Service unavailable 503	The proxy server returned an HTTP 503 error (which occurs when the proxy server failed to connect to the camera server).
HT504: Gateway Timeout 504	The proxy server returned an HTTP 504 error (which occurs when the proxy server could not receive a reply from the upper proxy).

Event type

Connection error to the camera server

Changing the recording frame rate

Continuing recording

Error Number: Error Description	Cause
WV407: Recording-mode streams unavailable	The following settings were configured for the stream for recording. a) JPEG recording at over 10fps b) MPEG-4 recording c) Image upload function is activated on VB-C500VD/VB-C500D/VB-C60
WV408: Conflict of recording-mode streams	While connecting using the stream for recording, another request for the recording stream was received.
WV601: No audio transmission	Audio transmission from the camera server is disabled.

10

Appendix

Camera Server Control

The following figure shows the order of priority for Camera Server control.

Strong

	Application
F	Panorama Creation Tool
٧	WebView Admin Viewer/NC Viewer (Administrator)/VB-C500 Admin Viewer/VB-C60 Admin Viewer
	Motion Detection Settings Tool (VB-C500VD/VB-C500D/VB-C60/VB-C50i Series VB Administration Tool)
٧	/B-C500/VB-C60 Admin Viewer (Registered User)
٧	/K-64/VK-16 Storage Server (when a preset is specified for sensor recording)
Λ	Motion Detection Module (VB-C500VD/VB-C500D/VB-C60/VB-C50 Series)
C	Operating the Camera Server in the VK-64/VK-16 settings window
٧	/K-64/VK-16 Viewer (when the Camera Server is operated in the Viewer)
٧	/K-64/VK-16 Storage Server (when a recording position is specified) VK Preset Tour
	/B-C500/VB-C60 Viewer (Guest User), NC Viewer (Authorized User), Viewer for PC/Viewer or Java (VB-C50i Series)
٧	/B-C60, VB-C50 Preset Tour

Weak

When a recording position is specified in VK-64/VK-16, you cannot operate the camera server using VB-C500/VB-C60 Viewer (Guest User), NC Viewer, Viewer for PC, or Viewer for Java.

Hard Disk

Lifetime of Hard Disk

A hard disk is a storage device that works physically, and has a limited lifetime. It is a kind of consumables. It is said that the average lifetime of a RAID system composed of SCSI hard disks is three years. However, this lifetime is considered to be true for standard file servers or business servers. The disk failure rate of VK-64/VK-16 systems is higher than that of general file servers. It is reasonable to assume that the lifetime of hard disks in a VK-64/VK-16 system is about half of that of a standard file server (one and a half years).

Therefore, when you build a VK-64/VK-16 system, it is advisable to provide a hot-spare (spare hard disks that are active) for RAID configuration.

RAID Reconfiguration

If one of hard disks in RAID1 and RAID5 systems breaks down, you can restore the system by replacing the broken hard disk before other disks break.

Restoring the data stored on the broken hard disk after replacement is referred to as rebuilding.

During RAID rebuilding, a recording error may occur because disk system performance deteriorates.

RAID Rebuilding Time

When a failure occurs in a hard disk in a RAID system and you want to replace it with a hot-spare or new one, the rebuilding time is to be considered as follows:

- Rebuilding takes about one minute per 1GB when no I/O is performed in a SCSI RAID card.
- When a RAID system is composed of four SCSI hard disks of 300GB each, the total disk size of the hard disks is 1200GB. To rebuild this system, 1200 minutes (20 hours) are required on the condition that there no I/O is performed.
- If rebuilding takes 20 hours when there is no I/O, the rebuilding time for a VK-64/VK-16 system where I/O is continuously performed can be assumed to be about 20 x 2 hours. Thus, when you perform rebuilding without stopping recording, it takes about 40 hours.
- There is no problem if rebuilding only takes a long time. However, the other hard disks may break
 down one after another during such rebuilding. If another hard disk breaks down during rebuilding,
 all of the stored data will be lost. Therefore, it is preferable to reduce rebuilding time as far as
 possible.

Configuration for Reducing Rebuilding Time

As described in the preceding section, it is important to shorten rebuilding time as far as possible. You can reduce rebuilding time by configuring hard disks as follows:

For example, when you create two configurations including three 146GB hard disks and a hot-spare, instead of creating one configuration (900GB) including three 300GB hard disks and a hot-spare, rebuilding requires less time and risks are reduced.

Measures to be Taken When Rebuilding

To reduce the load on the PC during rebuilding and to shorten the rebuilding time, it is also recommended to implement the following measures:

- Stop the Storage Server program before rebuilding.
- Temporarily reduce the recording frame rate during rebuilding.

Notes on Consistency Check of RAID Configuration Information

For stable operation of hard disks, you need to regularly perform consistency check of RAID configuration information. This is especially effective for preventing data inconsistency when rebuilding is performed. However, as with rebuilding, the consistency check of RAID configuration information imposes a burden on the PC for a long period of time.

In a consistency check of RAID configuration information, measures such as configuring hard disks in the same way as in rebuilding and reducing the load on the PC, are also important. See "Measures to be Taken When Rebuilding".

Follow the procedure below to check the version of the software.


Storage Server Configuration tool

- 1. Open the [Storage Server Configuration] dialog.
- 2. Right-click the title bar of the dialog and select [About Storage Server Configuration].
- 3. Check the software version in the dialog displayed.



VK Viewer

- 1. Launch the VK Viewer.
- 2. Select [About VK Viewer] from the [Help] menu.
- 3. Check the software version in the dialog displayed.



Functional Limitations on MPEG-4

VB-C500VD, VB-C500D and VB-C60 supports MPEG-4 format video in addition to JPEG format video.

However, this are several functional limitations as follows.

Live Viewing

- The following video window settings become disabled, and the frame rate setting of the camera takes
 effect.
 - Max. Live Frame Rate
 - Auto Adjust Frame Rate
- Synchronization of audio and video is not guaranteed.
- A message is displayed if you attempt to display 21 or more MPEG-4 video windows.

Video Recording

- The recording frame rate cannot be set for the following recording modes.
 - · Constant recording
 - · Motion detection recording
 - Sensor recording
- The [Reduce recording frame rate when disk is under high load] setting in the Storage Server Settings
 Tool becomes disabled.
- [Record Now] only supports the JPEG format, and cannot record in MPEG-4 format.

Playback

- Although the following controls can be used when playing back video recorded in MPEG-4 format, the rewind and nudge back controls do not function.
 - Specify playback time using the timeline
 - Begin playback from the live event viewing window and event search window
 - Pause, fast forward, nudge forward, previous event, next event
- If a schedule that had previously been recording in MPEG-4 format is switched to recording in JPEG
 format, when rewind playback from the JPEG format time range enters the MPEG-4 time range,
 although the rewind playback continues, the video is not displayed and an error stating "No
 Recorded Video." is displayed.
- If you attempt to save a time range of recorded video that spans multiple recording schedules, only the video recorded in the oldest schedule is saved.
- The MPEG-4 format video recorded using this software cannot be played back in other software.

A		ט	
Add Camera Server	4-18	Daylight Savings	5-54
[Add Camera Server] dialog	4-18	Disk Space Management	3-17
[Add Schedule Item] dialog4-32		Calculation Example	3-20
Additional Options	4-38	Limit Level	3-18
Continuous recording	4-45	Low disk space warning level	3-17, 3-19
Exposure Compensation	4-35, 5-45	Threshold Level	3-18
External Outputs Setting	4-39		
Motion Detection Recording	1-24, 4-46	E	
Night Mode		_	0.5
Preset Camera Angle	4-35	Event	
Resolution		Event Notification	
Sensor Event Recording	4-34, 4-53	Priority Level	
Audio Data		Event Data	
Audio Panel		Extract Video to save	5-54
Audio Recording	4-35	_	
_		F	
В		Find Camera Servers	4-17
Backup	7-1	Firmware	
Backup Device	7-4	Frame Size	1-22, 1-23
Backup for Archiving			
Backup for Data Protection		G	
Backup Tool		0-1-0	F 00 F 00
Configuration files	7-7	Get Camera Control	5-36, 5-38
Event Data	7-5, 7-10		
Examples	7-13	Н	
Restoration	7-11	Hard Disk	1-20, 10-3
Temporary File	7-5	Lifetime	
Video Data	7-5, 7-8	RAID Reconfiguration	
Before Starting Operation	xiii	How To Check Software Version	
С		1	
Camera Control Panel	5-39	Installation	2-1
Exposure Control	5-40	Preparation and Precaution	
Camera Server	4-17	Reinstalling	
Change Settings	4-41	Restore Previous Version	
Delete		Upgrade from Previous Version	
Edit	4-24	opgrade nem revieds version	
Register	4-17		
Search	4-17	L	
Camera Server Control	10-2	Layout Grids	5-24
Cameras for Viewing	5-30	Custom Grid	5-28
Camera Thumbnails	5-30	Grid	5-24
[Location],[Zone] drop-down menu	5-31	Layouts	5-19
Locations and Zones	5-31	Optional Layout Menu	5-19
Communication Mechanism	1-8	Personal Layouts	5-19
[Configuration and Preferences] screen	4-7	Shared Layouts	5-19
Configuration Files	7-7	License	1-6
Continuous Recording	4-45		

Location and Zone		S	
Add		Search Events	5-58
Delete		Criteria for Searching	
Edit		Date and Time Range	
Logs		[Event Search]	
A List of Error Codes		[Live Event Log] list	
Storage Destination	9-30	View retrieved recorded video	
		Sensor Event Recording	
M		Set [Preset Camera Angles]	
Manual Recording	5 52	Shade Control	
Master Storage Server		Snapshot	
Message List		Special Day Recording	
Motion Detection Recording		Special Day Schedule	
Optimization		Add	
MPEG-4		Add a Day	
WI LG-4	10-0	Delete	
		Delete a Day	
N		Edit	
Normal Schedule	4-31	Still Frame	
		Storage and Camera Server	
0		Summary] Windows4	I-8. 4-14
O		Storage Server	
Operating Environment	1-10	Add	
Notes		Delete	
Storage Server	1-11	Edit	4-15
Supported Camera Servers		Health Check	6-3
System Environment		How to Start-Up	
Operation and Management		Performance	
Operational Guideline		Storage Server Configuration tool	
Event Recording		[Storage Server Configuration] dialog	
Live-View Frame Rate Adjustment		[Event Notification] Tab3	
Recording Frame Rate Adjustment	6-5	[Events] Tab3	
		[Settings] Tab	
P		[User Management] Tab3	
Pan, Tilt, Zoom	E 20	Supported Camera Servers	
		System Configuration	
Preparation Flow		System Design Concept	1-17
rieset ioui	4-50	Hard Disk Capacity	
		Network Bandwidth	1-27
R		Server Sizing	1-20
Recording Schedule	4-27	System Configuration	1-17
Batch-Setting		Video Data Volume	
Normal Schedule		Viewer Sizing	1-26
Special Day Schedule4-29		When using multiple Storage Servers	1-19
Recording Setting Summary		When using multiple Storage Servers and	t
Summary Information of a Recording		Viewers	
Summary Information of Storage Server		When using Viewer alone	1-19
Restoration Procedure		System Operation Overview	1-6

Т	
Task Areas. Timeline	5-48 5-53 5-54 5-51 5-50 -48, 5-50 5-52 5-55 5-53
U	
Upgrade	8-7 2-6, 8-3 3-25
V Video Data Video Window	-25, 5-43

Viewer	4-3
How to Launch	4-3
Operation Flow	5-4
Viewer Setting	5-13
Administrator Tab	5-14
Audio Transmission Setting	5-17
Focus Operation Setting	5-17
Launch by Connecting to the	
Localhost	4-4, 5-7
Launch Storage Server by Specifying the	ne
IP address	4-5, 5-7
Proxy Server Setting	5-17
Select Master Storage Server	5-14
Set Event Notifications	5-15
Set Event Popups	5-14
Set layout of the Viewing Screen	5-14
Start-up Option	5-11
Superimpose Date and Time	5-18
Viewer Only Mode	. 1-19, 5-8
Viewer Shade Control	5-47
VK Event Information	9-34
VK Events	6-3
VK Viewer	4-3
VK-Lite	1-28

Canon

CANON INC.

30-2, Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, Japan

CANON U.S.A..INC.

One Canon Plaza Lake Success, NY 11042-1198 USA

 If you have any questions, call the CANON U.S.A. Information Center toll-free at 1-800-828-4040 (U.S.A. only)

CANON CANADA INC. NATIONAL HEADQUARTERS

6390 Dixie Road, Mississauga, Ontario L5T 1P7

CANON CANADA INC. CALGARY

2828, 16th Street, N.E, Calgary, Alberta T2E 7K7

CANON CANADA INC. MONTRÉAL

8801 Trans Canada Hwy, St. Laurent Québec H4S 1Z6

 If you have any questions, call the CANON CANADA Customer Information Centre toll-free at 1-800-OK-CANON (652-2666) (Canada only)

CANON MEXICANA, S. DE R.L.DE C.V.

Boulevard Manuel Avila Camacho, No. 138 PB, Pisos 15, 16 y 17

Col Lomas de Chapultepec C.P. 11000 México, D.F. México

CANON SINGAPORE PTE. LTD.

1 HarbourFront Avenue, #04-01, Keppel Bay Tower Singapore 098632

CANON HONGKONG CO., LTD.

19/F., The Metropolis Tower, 10 Metropolis Drive, Hunghom, Kowloon, Hong Kong

CANON AUSTRALIA PTY.LTD.

1 Thomas Holt Drive, North Ryde, Sydney, N.S.W. 2113, Australia

CANON EUROPA N.V.

Bovenkerkerweg 59-61, P.O. Box 2262, 1185 XB Amstelveen, The Netherlands

CANON EUROPE LTD.

3 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

CANON FRANCE SAS

17, quai du Président Paul Doumer, 92414 Courbevoie, France

CANON (UK) LTD.

Woodhatch, Reigate, Surrey RH2 8BF, United Kingdom

CANON DEUTSCHLAND GmbH

Europark Fichtenhain A 10, 47807 Krefeld, Germany

CANON ITALIA S.p.A.

Via Milano, 8, 20097, San Donato Milanese (MI), Italy

CANON (Schweiz) A.G.

Industriestrasse 12, 8305 Dietlikon, Switzerland

CANON BELGIUM N.V./S.A

Berkenlaan 3, 1831 Diegem (Mechelen), Belgium

CANON AUSTRIA GmbH

Oberlaaer Strasse 233, A-1100 Wien, Austria

CANON ESPAÑA,S.A.

Avda. de Europa, 6 Alcobendas, 28108 Madrid, Spain

CANON SVENSKA AB

Gustav III:s, Boulevard 26, 169 88 Solna, Sweden

CANON NORGE A/S

Hallagerbakken 110, P.O. Box 33, Holmlia, N-1201 Oslo, Norway

CANON OY

Huopalahdentie 24, P.O. Box 1, FIN-00351 Helsinki, Finland

CANON DANMARK A/S

Knud Hoejgaards Vej 1, DK-2860, Soeborg, Denmark