


Large Format Printer

iPF8300S

User's Guide

| Basic Printing Workflow | 1) |
|--------------------------------------|------|
| Enhanced Printing Options | 20) |
| Windows Software | 201 |
| Mac OS X Software | 486 |
| Print Job Operations | 719 |
| Handling Paper | 773) |
| Adjustments for Better Print Quality | 847 |
| Printer Parts | 895 |
| Control Panel | 913 |
| Network Setting | 958 |
| Maintenance and Consumables | 995) |
| Troubleshooting | 1054 |
| Error Message | 1092 |
| Specifications | 1122 |
| Appendix | 1128 |





ENG

Note

In order to be printed easily, this PDF-format manual is converted from the HTML-format instruction manual included on the "User Manuals CD-ROM" supplied with the printer. Thus, there are descriptions that are applied only in HTML format, and functions (video display function, etc.) that cannot be used. We appreciate your understanding.

Contents

| Basic Printing Workflow | 1 |
|---|--|
| Printing procedure Printing Options Using Rolls and Sheets Turning the Printer On and Off Loading and Printing on Rolls Loading and Printing on Sheets Printing in Windows Printing from Mac OS X | |
| Canceling Print Jobs from the Control Panel Canceling Print Jobs from Windows Canceling Print Jobs from Mac OS X | 15 |
| Pausing Printing Pausing Printing | 19 |
| Enhanced Printing Options | 20 |
| Choosing Paper for Printing Choosing a Paper for Printing Specifying Paper in the Printer Driver | |
| Printing Photos and Office Documents | 22 |
| Printing Photos and Images Printing Photos and Images (Windows) Printing Photos and Images (Mac OS X) Printing from Photoshop Printing Adobe RGB Images (Windows) Printing Adobe RGB Images (Mac OS X) Printing Office Documents Printing Office Documents (Windows) Printing Office Documents (Mac OS X) Using PosterArtist to Compose Originals | 23 25 29 30 34 38 38 |
| Printing CAD Drawings | 47 |
| Printing Line Drawings and Text Printing Line Drawings and Text (Windows) Printing Line Drawings and Text (Mac OS X) Printing from AutoCAD | 47 49 |
| Adjusting Images | 55 |
| Adjusting the Color in the Printer Driver Fine-Tuning Colors of Photos and Images (Windows) Fine-Tuning Colors of Photos and Images (Mac OS X) Giving Priority to Particular Graphic Elements and Colors for Printing Choosing the Document Type and Printing Conditions (Windows) Choosing the Document Type and Printing Conditions (Mac OS X) | |
| Printing enlargements or reductions | 73 |
| Resizing Originals to Match the Paper Size | 73 |

| Resizing Originals to Match the Paper Size (Windows) | |
|---|-----|
| Resizing Originals to Match the Paper Size (Mac OS X) | |
| Resizing Originals to Fit the Roll Width | |
| Resizing Originals to Fit the Roll Width (Windows) | |
| Resizing Originals to Fit the Roll Width (Mac OS X) Resizing Originals by Entering a Scaling Value | |
| Resizing Originals by Entering a Scaling Value (Windows) | |
| Resizing Originals by Entering a Scaling Value (Mac OS X) | |
| | |
| Printing at full size | 93 |
| Printing on Oversized Paper | |
| Printing at Full Size (Windows) | |
| Printing at Full Size (Mac OS X) | |
| Borderless Printing at Actual Size | |
| Borderless Printing at Actual Size (Windows) Borderless Printing at Actual Size (Mac OS X) | |
| | |
| • | 107 |
| Borderless Printing on Paper of Equivalent Size | |
| Borderless Printing by Resizing Originals to Match the Paper Size (Windows) | |
| Borderless Printing by Resizing Originals to Match the Paper Size (Mac OS X) | |
| Borderless Printing by Resizing Originals to Fit the Roll Width | |
| Borderless Printing by Resizing Originals to Fit the Roll Width (Mac OS X) | |
| | |
| Printing banners or at other non-standard sizes | 122 |
| Printing Vertical or Horizontal Banners (Large-Format Printing) | |
| Printing Vertical or Horizontal Banners (Large-Format Printing; Windows) | |
| Printing Vertical or Horizontal Banners (Large-Format Printing; Mac OS X) | |
| Printing on Non-Standard Paper Sizes | |
| Printing on Non-Standard Paper Sizes (Windows) Printing on Non-Standard Paper Sizes (Mac OS X) | |
| | |
| | 139 |
| Printing Multiple Originals Next to Each Other | |
| Printing Multiple Originals Next to Each Other (Windows) | |
| Printing Multiple Originals Next to Each Other (Mac OS X) | |
| Printing Multiple Pages Continuously | |
| Printing Multiple Pages Continuously (Mac OS X) | |
| Printing Multiple Pages Per Sheet | |
| Printing Multiple Pages Per Sheet (Windows) | |
| Printing Multiple Pages Per Sheet (Mac OS X) | |
| Printing Posters in Sections | |
| Printing Large Posters (Windows) | 157 |
| Centering originals | 160 |
| Printing Originals Centered on Rolls | 160 |
| Printing Originals Centered on Rolls (Windows) | |
| Printing Originals Centered on Rolls (Mac OS X) | |
| Printing Originals Centered on Sheets | 166 |
| Printing Originals Centered on Sheets (Windows) | |
| Printing Originals Centered on Sheets (Mac OS X) | 169 |
| Conserving roll paper | 172 |
| Conserving Roll Paper by Rotating Originals 90 Degrees | 172 |
| | |

| Conserving Roll Paper by Rotating Originals 90 Degrees (Windows) | 172 |
|---|-----|
| Conserving Roll Paper by Rotating Originals 90 Degrees (Mac OS X) | 174 |
| Conserving Roll Paper by Printing Originals Without Top and Bottom Margins | 178 |
| Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Windows) | 178 |
| Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Mac OS X) | |
| Checking Images Before Printing | 184 |
| Checking the Layout in a Preview Before Printing | 184 |
| Other useful settings | 186 |
| Printing With Watermarks | 186 |
| Printing with Watermarks— COPY, FILE COPY, and so on (Windows) | |
| Making the Original Orientation Match the Paper Orientation | |
| Making the Original Orientation Match the Paper Orientation (Windows) | |
| Making the Original Orientation Match the Paper Orientation (Mac OS X) | |
| Using Favorites | |
| Cutting Roll Paper After Printing | |
| Cutting Roll Paper After Printing (Windows) | |
| Cutting Roll Paper After Printing (Mac OS X) | |
| • • • • • • • • • • • • • • • • • • • | |
| Windows Software | 201 |
| William Was Sold Wall | 201 |
| Printer Driver | 202 |
| Printer Driver Settings | |
| Specifying Paper in the Printer Driver | |
| Confirming Print Settings | |
| Checking the Layout in a Preview Before Printing | |
| Using Favorites | |
| Accessing the Printer Driver Dialog Box from Applications | 211 |
| Accessing the Printer Driver Dialog Box from the Operating System Menu | |
| Main Sheet | |
| Paper Information on Printer Dialog Box | |
| Paper Detailed Settings Dialog Box | |
| View Settings Dialog Box for the Printing Application | |
| Color Adjustment Sheet: Color | |
| Object Adjustment dialog box: Color | |
| Matching Sheet | |
| Ambient Light Adjust dialog box | |
| Light Source Check Tool | |
| Color Adjustment Sheet: Monochrome Object Adjustment dialog box: Monochrome | |
| Gray Adjustment Sheet | |
| Page Setup Sheet | |
| Output Method dialog box | |
| Paper Size Options Dialog Box | |
| Layout Sheet | |
| Page Options Dialog Box | |
| Special Settings Dialog Box | |
| Favorites Sheet | |
| Utility Sheet | |
| Support Sheet | |
| Settings Summaries Dialog Box | |
| Device Settings Sheet | |
| Preview | |
| FIEVIEW | 248 |

| The Features of Preview | . 248 |
|--|-------|
| Operating Environment | . 248 |
| Starting Preview | |
| Preview Main Window | . 250 |
| Dialog Area | . 253 |
| Enlarge/Reduce the screen display | |
| Moving a Page | |
| Using the ruler | |
| Priority setting for rotating 90 degrees | |
| Printing with Selecting the Layout | |
| Print on the Center | . 259 |
| Not Print Spaces at the Top/Bottom | . 260 |
| Free Layout | 261 |
| The Features of Free Layout | . 261 |
| Operating Environment | |
| Starting Free Layout | |
| Free Layout Main Window | |
| Detailed Settings | |
| Preferences Dialog Box | |
| Page Options Dialog Box | |
| Zoom Dialog Box | |
| Format Dialog Box | |
| Laying out a Multiple-File Document on One Page | |
| Laying out a Document Created with Multiple Application Programs on One Page | |
| Selecting an Object | |
| Changing the Object Size | |
| Moving an Object | |
| Rotating an Object | |
| Laying out Objects Automatically | |
| Aligning Objects | |
| Changing the Object Overlapping Order | |
| Pasting a Copied or Cut Object | |
| Folded Duplex Window | |
| Finished Size Settings Dialog Box | |
| Binding Settings Dialog Box | |
| Prints using Folded Duplex | |
| | |
| Color imageRUNNER Enlargement Copy | 292 |
| The Features of Color imageRUNNER Enlargement Copy | |
| Operating Environment | |
| Starting Color imageRUNNER Enlargement Copy | |
| Color imageRUNNER Enlargement Copy Dialog Box | |
| Hot Folder | |
| Creating a New Hot Folder | |
| Specifying an Existing Shared Folder as a Hot Folder | |
| Setting the Print Parameters | |
| Printing Enlargements of Scanned Originals from a Color imageRUNNER | . 304 |
| Print Plug-In for Photoshop/Digital Photo Professional | 307 |
| The Features of Print Plug-In | . 308 |
| Operating Environment | |
| Installation Procedures | |
| Uninstall Procedures | |
| Starting from Photoshop | |
| Starting from Digital Photo Professional | |

| Print Plug-In Main Window | . 315 |
|---|-------|
| Preview Area | . 317 |
| Main Sheet | . 318 |
| Page Setup Sheet | . 322 |
| Color Settings Sheet | |
| Print History Sheet | . 326 |
| Support Sheet | |
| Paper Detailed Settings Dialog Box | |
| Set Configuration Dialog Box | |
| ICC Conversion Options dialog box | |
| Roll Paper Options Dialog Box | |
| Size Options Dialog Box | |
| Curves Dialog Box | |
| Print History Details Dialog Box | |
| Utilize Three Types of Previews | |
| Check Image with Print Area Layout | |
| Check the original image with Image | |
| Check Image with Roll Paper Preview | |
| Print with a Desired Picture Quality | |
| Adjust the Colors and Print | |
| Adjust the Colors while Checking the Preview (for Color) | |
| Adjust the Colors while Checking the Preview (for Monochrome) | |
| Adjust the Colors by Color Matching | |
| Print High-Quality Adobe RGB16bit Images | |
| Prints monochrome photographs with high quality | |
| Using Adobe CMM | |
| Perform Black Point Compensation | |
| Perform Printing Press Simulation Print | |
| Enlarge/Reduce and Print | |
| Enlarge/Reduce and Print Matching Output Media Size | |
| Enlarge/Reduce and Print Matching Width of Roll Paper | |
| Specify Scaling, Enlarge/Reduce and Print | |
| Print with No Borders | |
| Customize Media Settings | |
| Utilize Print History | |
| Confirm Print History Details | |
| Apply Print History to an Image | |
| Store Print History to Print Preferences | |
| Delete Print History | |
| Export Print History from Print Preferences | |
| Import Print History to Print Preferences | |
| Delete Print History from Print Preferences | |
| Set Information to Print with Image | . 3/1 |
| Print Plug-In for Office | 373 |
| Print Plug-In for Office features | 373 |
| Operating Environment | |
| Steps to install | |
| Steps to uninstall | |
| When Print Plug-In for Office is not displayed | |
| To start from Microsoft Word | |
| Print Matching Roll Width (Word) | |
| Borderless Printing (Word) | |
| Multi-Page Printing (Word) | |
| Register the settings(Word) | . 394 |
| Print Using Registered Settings (Word) | . 395 |

| Portrait Orientation / Landscape Orientation (Word) To start from Microsoft PowerPoint | 399 |
|---|-----|
| Print Matching Roll Width (PowerPoint) | |
| Multi-Page Printing (PowerPoint) | 406 |
| Register the settings(PowerPoint) | |
| Portrait Orientation / Landscape Orientation (PowerPoint) | |
| To start from Microsoft Excel | |
| Print Entire Sheet (Excel) | |
| Configuring Binding (Excel) | 423 |
| Configuring Special Settings | 424 |
| Status Monitor | 426 |
| The Features of imagePROGRAF Status Monitor Job Management Using imagePROGRAF Status Monitor | |
| Accounting | 429 |
| Accounting Manager | |
| Launching the Accounting Manager | |
| Accounting Manager Main Window | |
| Accounting Manager Basic Procedures | 434 |
| Configuring Unit Costs in Accounting Manager Setting the Unit Cost for Ink | |
| Setting the Unit Cost for Paper | |
| Setting the Unit Cost for Items Other Than Ink and Paper | |
| Configuring Units and Display Settings in Accounting Manager Automatically Acquiring Print Job Logs at Regular Intervals | |
| Canceling Regular Print Job Log Acquisition | |
| Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs | 439 |
| Exporting Print Job Data as a CSV File | |
| Showing, Saving and Loading Selected Unit Cost Data | |
| Showing the Total Amount of Ink and Paper Consumed | |
| Digital Photo Front-Access | 442 |
| Digital Photo Front-Access | 442 |
| Device Setup Utility | 443 |
| imagePROGRAF Device Setup Utility | |
| Installing imagePROGRAF Device Setup Utility | |
| Media Configuration Tool | 448 |
| The Features of Media Configuration Tool | |
| Operating Environment Installation Procedures | |
| Starting the Media Configuration Tool | |
| Media Configuration Tool Main Window | 453 |
| Editing Media Type Information | |
| Adding Media Types | |
| Deleting Media Types You Have Added | |
| Switching Media Types Display Show/Hide | 461 |

| Changing the Display Order of Media Types | |
|---|-----|
| Updating Media Types | |
| Using Paper Other Than Genuine Paper/Feed Confirmed Paper | |
| Compatible Paper | 40 |
| Add Custom Paper | 46 |
| Delete Custom Paper | |
| Edit Custom Paper | 47 |
| Export Custom Media Information | |
| Import Custom Media Information | 48 |
| Warnings | 48 |
| Mac OS X Software | 48 |
| Printer Driver | 48 |
| Printer Driver Settings | |
| Specifying Paper in the Printer Driver | 48 |
| Confirming Print Settings | 49 |
| Checking the Layout in a Preview Before Printing | 49 |
| Using Favorites | 49 |
| Accessing the Printer Driver Dialog Box from Applications | 49 |
| Main Pane | |
| Paper Information on Printer Dialog Box | 49 |
| Paper Detailed Settings Dialog Box | 50 |
| View settings Dialog Box for the Printing Application | 50 |
| Matching pane | 50 |
| Ambient Light Adjust dialog box | 50 |
| Light Source Check Tool | 50 |
| Color Settings Pane: Color | 50 |
| Object Adjustment dialog box: Color | 51 |
| Color Settings Pane: Monochrome | 51 |
| Object Adjustment dialog box: Monochrome | 51 |
| Gray Adjustment Pane | 51 |
| Page Setup Pane | 51 |
| Utility Pane | 51 |
| Additional Settings Pane | 51 |
| Support Pane | 5 |
| Preview | 51 |
| The Features of Preview | |
| Operating Environment | |
| Starting Preview | |
| Preview Main Window | |
| Paper Settings Panel | |
| Easy Settings | |
| Advanced Settings | |
| Output Settings Panel | |
| Color Settings Panel | |
| Color Adjustment | |
| Gray Adjustment | |
| Matching | |
| Driver Matching Mode | |
| ICC Matching Mode | |
| | E / |
| ColorSync Preferences Dialog Box | |

| Go to Page Dialog Box | |
|--|------|
| Print with No Borders | 543 |
| Print on the Center | 543 |
| Not Print Spaces at the Top/Bottom | 544 |
| Print Page Rotated 90 Degrees | |
| Display with Fitting to the Width of the Paper | |
| Display with All | |
| Display with Actual Size | |
| Moving a Page | |
| Free Layout | 550 |
| The Features of Free Layout | 550 |
| Operating Environment | |
| Starting Free Layout | |
| Free Layout Main Window | |
| Paper Settings Panel | |
| Easy Settings | |
| Advanced Settings | |
| Color Settings Panel | |
| Color Adjustment | |
| | |
| Gray Adjustment | |
| Matching | |
| Driver Matching Mode | |
| ICC Matching Mode | |
| ColorSync | |
| Preferences Dialog Box | |
| Page Setup Dialog Box | |
| Zoom Dialog Box | |
| Format Dialog Box | |
| Laying out a Multiple-File Document on One Page | |
| Laying out a Document Created with Multiple Application Programs on One Page | |
| Selecting an Object | |
| Changing the Object Size | 576 |
| Moving an Object | 577 |
| Rotating an Object | 578 |
| Laying out Objects Automatically | 579 |
| Aligning Objects | 579 |
| Changing the Object Overlapping Order | 581 |
| Pasting a Copied or Cut Object | 583 |
| Color imageRUNNER Enlargement Copy | 584 |
| The Features of Color imageRUNNER Enlargement Copy | 584 |
| Operating Environment | |
| Starting Color imageRUNNER Enlargement Copy | |
| Color imageRUNNER Enlargement Copy Dialog Box | |
| Hot Folder | |
| Creating a New Hot Folder | |
| Editing a Hot Folder (Setting Print Conditions) | |
| Deleting a Hot Folder | |
| Setting the Print Parameters | |
| Paper Settings Panel | |
| Easy Settings | |
| Advanced Settings | |
| Output Settings Panel | |
| Color Settings Panel | |
| LOIOT Settings Panel | nii/ |

| ICC Matching Mode | 604 |
|---|-----|
| ColorSync | |
| Printing Enlargements of Scanned Originals from a Color imageRUNNER | 606 |
| Print Plug-In for Photoshop/Digital Photo Professional | 609 |
| The Features of Print Plug-In | 610 |
| Operating Environment | |
| Installation Procedures | |
| Uninstall Procedures | |
| Starting from Photoshop | 615 |
| Starting from Digital Photo Professional | |
| Print Plug-In Main Window | 617 |
| Preview Area | |
| Main Sheet | 621 |
| Page Setup Sheet | 624 |
| Color Settings Sheet | 627 |
| Print History Sheet | |
| Support Sheet | 629 |
| Paper Detailed Settings Dialog Box | 630 |
| Set Configuration Dialog Box | |
| ICC Conversion Options dialog box | |
| Roll Paper Options Dialog Box | |
| Size Options Dialog Box | |
| Curves Dialog Box | |
| Print History Details Dialog Box | 637 |
| Utilize Three Types of Previews | |
| Check Image with Print Area Layout | |
| Check the original image with Image | |
| Check Image with Roll Paper Preview | |
| Print with a Desired Picture Quality | |
| Adjust the Colors and Print | |
| Adjust the Colors while Checking the Preview (for Color) | |
| Adjust the Colors while Checking the Preview (for Monochrome) | |
| Adjust the Colors by Color Matching | 648 |
| Print High-Quality Adobe RGB16bit Images | |
| Prints monochrome photographs with high quality | |
| Using Adobe CMM | 651 |
| Perform Black Point Compensation | 653 |
| Perform Printing Press Simulation Print | 654 |
| Enlarge/Reduce and Print | 655 |
| Enlarge/Reduce and Print Matching Output Media Size | 655 |
| Enlarge/Reduce and Print Matching Width of Roll Paper | 657 |
| Specify Scaling, Enlarge/Reduce and Print | 658 |
| Print with No Borders | 659 |
| Customize Media Settings | 660 |
| Utilize Print History | 661 |
| Confirm Print History Details | 661 |
| Apply Print History to an Image | |
| Store Print History to Print Preferences | |
| Delete Print History | 665 |
| Export Print History from Print Preferences | 667 |
| Import Print History to Print Preferences | |
| Delete Print History from Print Preferences | |
| Set Information to Print with Image | 672 |
| | |

| The Features of imagePROGRAF Printmonitor | 674 675 |
|---|---|
| Media Configuration Tool | 677 |
| The Features of Media Configuration Tool | 677 |
| Operating Environment | |
| Procedures for Installing | |
| Procedures for Uninstalling | |
| Starting the Media Configuration Tool | 684 |
| Media Configuration Tool main window | 685 |
| Editing Media Type Information | 686 |
| Adding Media Types | |
| Changing Media Names | |
| Deleting Media Types You Have Added | |
| Switching Media Types Display Show/Hide | |
| Changing the Display Order of Media Types | |
| Updating Media Types | |
| Using Paper Other Than Genuine Paper/Feed Confirmed Paper | |
| Compatible Paper | |
| Add Custom Paper | |
| Delete Custom Paper | |
| Edit Custom Paper | |
| Import Custom Media Information | |
| Warnings | |
| The trinings | ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,, |
| Print Job Operations | 719 |
| | |
| Basic Print Job Operations | 720 |
| | |
| Using the Printer Hard Disk | 720 |
| Using the Printer Hard Disk | |
| Using the Printer Hard Disk | |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) | |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) | 720 722 725 728 730 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs | 720 722 725 728 730 737 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs | 720 722 725 728 730 737 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Advanced Print Job Operations | 720 722 725 728 730 737 741 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs | 720 722 725 728 730 737 741 747 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver | 720 722 725 728 730 737 741 747 747 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box | 720 722 725 728 730 737 741 747 747 749 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Saving Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes | 720 722 725 728 730 737 741 747 747 749 749 753 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes Naming Personal Boxes Displaying a List of Saved Jobs Printing a List of Saved Jobs | 720 722 725 728 730 737 741 747 747 749 753 758 762 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes Naming Personal Boxes Displaying a List of Saved Jobs Printing a List of Saved Jobs Displaying Details of Saved Jobs | 720 722 725 728 730 737 741 747 747 749 753 758 762 763 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes Naming Personal Boxes Displaying a List of Saved Jobs Printing a List of Saved Jobs | 720 722 725 728 730 737 741 747 747 749 753 758 762 763 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes Naming Personal Boxes Displaying a List of Saved Jobs Printing a List of Saved Jobs Displaying Details of Saved Jobs | 720 722 725 728 730 737 741 747 747 749 753 758 762 763 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes Naming Personal Boxes Displaying a List of Saved Jobs Printing a List of Saved Jobs Displaying Details of Saved Jobs Renaming Saved Jobs Renaming Saved Jobs Handling Paper | 720 722 725 728 730 737 741 747 747 749 749 753 758 762 763 767 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes Naming Personal Boxes Displaying a List of Saved Jobs Printing a List of Saved Jobs Displaying Details of Saved Jobs Renaming Saved Jobs Renaming Saved Jobs Handling Paper Paper | 720 722 725 728 730 737 741 747 749 749 753 758 762 763 767 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes Naming Personal Boxes Displaying a List of Saved Jobs Printing a List of Saved Jobs Displaying Details of Saved Jobs Renaming Saved Jobs Handling Paper Paper Types of Paper | 720 722 725 728 730 737 741 747 747 749 753 758 762 763 7773 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes Naming Personal Boxes Displaying a List of Saved Jobs Printing a List of Saved Jobs Displaying Details of Saved Jobs Renaming Saved Jobs Handling Paper Paper Types of Paper Paper Sizes | 720 722 725 728 730 737 741 747 747 749 753 758 762 763 767 |
| Using the Printer Hard Disk Saving Print Jobs on the Printer Hard Disk Managing the Job Queue (Deleting or Preempting Other Jobs) Managing Pending Jobs (Printing or Deleting Jobs on Hold) Printing Saved Jobs Deleting Saved Jobs Moving Saved Jobs Moving Saved Jobs Advanced Print Job Operations Saving Print Jobs Sent from Sources Other than the Printer Driver Printing Without Saving Jobs in the Common Box Setting Passwords for Personal Boxes Naming Personal Boxes Displaying a List of Saved Jobs Printing a List of Saved Jobs Displaying Details of Saved Jobs Renaming Saved Jobs Handling Paper Paper Types of Paper | 720 722 725 728 730 737 741 747 747 749 749 753 758 762 763 767 774 774 774 775 777 |

| Handling rolls | 782 |
|--|---------------------------------|
| Attaching the Roll Holder to Rolls | |
| Loading Rolls in the Printer | |
| Changing the Type of Paper | |
| Specifying the Paper Length | |
| Removing the Roll Holder from Rolls | |
| Feeding Roll Paper Manually | |
| Keeping Track of the Amount of Roll Paper Left | |
| Specifying the Ink Drying Time for Rolls | |
| Specifying the Cutting Method for Rolls | |
| Cutting the Leading Edge of Roll Paper Automatically | |
| | |
| Handling sheets | 813 |
| Loading Sheets in the Printer | |
| Printing From a Desired Starting Point | |
| _ | 620 |
| Output Stacker | 822 |
| Output Stacker | |
| Using the Output Stacker | |
| Storing the Output Stacker | 829 |
| Media take-up unit | 831 |
| Media Take-up Unit (Optional) | |
| Using the Media Take-up Unit (Optional) | |
| Enabling Roll Take-Up | |
| Loading the Rewind Spool on the Media Take-up Unit | |
| Removing Printed Documents from the Media Take-up Unit (Optional) | |
| | |
| Adjustments for Better Print Quality | 847 |
| Adjustment for high-precision printing | 848 |
| Enhancing Printing Quality | 848 |
| Adjusting the Printhead | 850 |
| Adjusting the Printhead | 850 |
| Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.) | |
| Manual Adjustment to Straighten Lines and Colors (Head Posi. Adj.) | |
| Troubleshooting Paper Abrasion and Blurry Images (Head Height) | 854 |
| Adjusting the feed amount | 856 |
| Adjusting the Feed Amount | |
| Selecting a Feed Amount Adjustment Method (Feed Priority) | 856 |
| Automatic Banding Adjustment (Adj. Quality) | |
| Manual Banding Adjustment (Adj. Quality) | 857 |
| Manual Banding Adjustment (Adj. Quality) | 857 859 |
| Manual Banding Adjustment (Adj. Quality) Fine-Tuning the Paper Feed Amount (Adj. Fine Feed) Adjusting Line Length (Adjust Length) | |
| Fine-Tuning the Paper Feed Amount (Adj. Fine Feed) | |
| Fine-Tuning the Paper Feed Amount (Adj. Fine Feed) Adjusting Line Length (Adjust Length) | |
| Fine-Tuning the Paper Feed Amount (Adj. Fine Feed) Adjusting Line Length (Adjust Length) Adjusting the Vacuum Strength (VacuumStrngth) | 857 859 861 861 863 |

| Printing in Ideal Colors for Light in the Viewing Environment | |
|---|---|
| Selecting Color Tones on Charts Before Printing (Windows) | |
| Selecting Color Tones on Charts Before Printing (Mac OS X) | |
| Printing in Colors Matching the Measured Ambient Light (Windows) | |
| Printing in Colors Matching the Measured Ambient Light (Mac OS X) | |
| Printing Images to Match Monitor Colors | |
| Printing Images to Match Monitor Colors (Windows) | |
| Printing Images to Match Monitor Colors (Mac OS X) | 892 |
| Printer Parts | 895 |
| Printer parts | 896 |
| Front | 896 |
| Back | |
| Top Cover (Inside) | |
| Carriage | |
| Ink Tank Cover (Inside) | 901 |
| Stand | |
| Media Take-up Unit (Optional) | 904 |
| Hard Disk | 906 |
| Printer Hard Disk Operations | 906 |
| Checking the Free Hard Disk Space | |
| Erasing Data on the Printer's Hard Disk | 909 |
| Optional accessories | 911 |
| Roll Holder Set | 911 |
| Roll Holder Set | |
| Media Take-up Unit | |
| Media Take-up Unit | 911 |
| Media Take-up Unit Control Panel | 911 913 |
| Media Take-up Unit Control Panel Operations and Display Screen | 911 913 914 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel | 913 914 914 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display | 913 914 914 916 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate | 913 914 914 916 919 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations | 913 914 914 916 919 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu | 913 914 914 916 919 921 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu Printer Menu Operations | 913 914 914 914 916 919 921 924 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu Printer Menu Operations Menu Operations | 913 914 914 914 916 919 921 924 924 925 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu Printer Menu Operations Menu Operations Menu Structure | 913 914 914 914 916 919 921 924 924 925 928 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu Printer Menu Printer Menu Operations Menu Operations Menu Structure Menu Settings | 913 914 914 914 916 919 921 924 924 925 928 938 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu Printer Menu Operations Menu Operations Menu Structure Menu Settings Menu Settings Menu Settings (During Printing) | 913 914 914 914 916 919 921 924 924 925 928 938 949 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu Printer Menu Printer Menu Operations Menu Operations Menu Structure Menu Settings | 913 914 914 914 916 919 921 924 924 925 928 938 949 |
| Control Panel Operations and Display Screen Control Panel Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu Printer Menu Operations Menu Operations Menu Structure Menu Settings Menu Settings Menu Settings (During Printing) Status Print | 913 914 914 914 916 919 921 924 924 925 928 938 949 |
| Control Panel Operations and Display Screen Control Panel Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu Printer Menu Operations Menu Operations Menu Structure Menu Settings Menu Settings Menu Settings (During Printing) Status Print | 913 914 914 914 916 919 921 924 924 925 928 938 949 |
| Media Take-up Unit Control Panel Operations and Display Screen Control Panel Control Panel Display How to View Instructions With Navigate Checking Instructions During Printer Operations Printer Menu Printer Menu Operations Menu Operations Menu Structure Menu Settings Menu Settings Menu Settings (During Printing) Status Print Printing Interface Setting Reports | 913 914 914 914 916 919 921 924 924 925 928 938 949 951 |
| Control Panel Operations and Display Screen Control Panel Control Panel | 913 914 914 914 916 919 921 924 924 925 928 938 949 951 954 |
| Control Panel Operations and Display Screen Control Panel | 913 914 914 914 916 919 921 924 924 925 928 938 949 951 954 |

| Initial Settings | 965 |
|---|--|
| Configuring the IP Address on the Printer | |
| Configuring the IP Address Using the Printer Control Panel | |
| Configuring the IP Address Using ARP and PING Commands Configuring TCP/IPv6 Network Settings | |
| Configuring the Printer Driver Destination (Windows) | |
| Configuring the Printer Driver Destination (Mac OS X) | |
| Configuring the Printer's TCP/IP Network Settings With RemoteUI | |
| NetWare Settings | 974 |
| Configuring NetWare Network Settings | |
| Specifying the Printer's Frame Type | |
| Specifying NetWare Print Services | |
| Configuring the Printer's NetWare Network Settings With RemoteUI | |
| Mac OS X Settings | 984 |
| Configuring the Destination in TCP/IP Networks | |
| Configuring the Destination for Bonjour Network | |
| Configuring the Destination for AppleTalk Networks | |
| Configuring the Printer's AppleTalk Network Settings | 989 |
| Other Settings | 991 |
| Specifying Printer-Related Information | |
| Configuring the Communication Mode Manually Email Notification When Printing is Finished or Errors Occur | |
| Initializing the Network Settings | |
| milanzing the receiving | |
| M: (IC II | 00= |
| Maintenance and Consumables | 995 |
| | |
| Ink Tanks | 996 |
| Ink Tanks Ink Tanks | 996 996 |
| Ink Tanks Ink Tanks Replacing Ink Tanks | 996 |
| Ink Tanks Ink Tanks | 996 996 997 1008 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks | 996 996 997 1008 1009 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads | 996 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead | 996 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads | 996 996 997 1008 1009 1011 1011 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging | 996 996 997 1008 1009 1011 1011 1011 1012 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead | 996 996 997 1008 1009 1011 1011 1011 1012 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead Replacing the Printhead | 996 ——————————————————————————————————— |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead Replacing the Printhead Cutter Unit | 996 996 997 1008 1009 1011 1011 1011 1012 1013 1024 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead Replacing the Printhead Cutter Unit Cutter Unit | 996 996 997 1008 1009 1011 1011 1011 1012 1013 1024 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead Replacing the Printhead Cutter Unit Cutter Unit Replacing the Cutter Unit | 996 997 1008 1009 1011 1011 1011 1012 1013 1024 1024 1024 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead Replacing the Printhead Cutter Unit Cutter Unit Replacing the Cutter Unit Maintenance Cartridge Maintenance Cartridge Replacing the Maintenance Cartridge | 996 996 997 1008 1009 1011 1011 1011 1012 1013 1024 1024 1024 1028 1028 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead Replacing the Printhead Cutter Unit Cutter Unit Cutter Unit Replacing the Cutter Unit Maintenance Cartridge Maintenance Cartridge Replacing the Maintenance Cartridge Capacity | 996 996 997 1008 1009 1011 1011 1011 1012 1013 1024 1024 1024 1028 1028 1028 1028 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead Replacing the Printhead Replacing the Printhead Cutter Unit Cutter Unit Replacing the Cutter Unit Maintenance Cartridge Maintenance Cartridge Replacing the Maintenance Cartridge Checking the Remaining Maintenance Cartridge Capacity When to Replace the Maintenance Cartridge | 996 996 997 1008 1009 1011 1011 1011 1012 1013 1024 1024 1024 1028 1028 1028 1028 1037 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead Replacing the Printhead Cutter Unit Cutter Unit Cutter Unit Replacing the Cutter Unit Maintenance Cartridge Maintenance Cartridge Replacing the Maintenance Cartridge Checking the Remaining Maintenance Cartridge Cleaning the Printer | 996 997 997 1008 1009 1011 1011 1011 1013 1024 1024 1024 1028 1028 1028 1028 1037 |
| Ink Tanks Ink Tanks Replacing Ink Tanks Checking Ink Tank Levels When to Replace Ink Tanks Printheads Printhead Checking for Nozzle Clogging Cleaning the Printhead Replacing the Printhead Replacing the Printhead Cutter Unit Cutter Unit Replacing the Cutter Unit Maintenance Cartridge Maintenance Cartridge Replacing the Maintenance Cartridge Checking the Remaining Maintenance Cartridge Capacity When to Replace the Maintenance Cartridge | 996 997 997 1008 1009 1011 1011 1011 1012 1013 1024 1024 1024 1028 1028 1028 1037 1037 |

| Other Maintenance | 1044 |
|---|------|
| Preparing to Transfer the Printer Updating the Firmware | |
| Consumables | 1053 |
| | |
| Troubleshooting | 1054 |
| Frequently Asked Questions | 1055 |
| Frequently Asked Questions | 1055 |
| Problems Regarding Paper | 1057 |
| Clearing Jammed Roll Paper | 1057 |
| Clearing a Jammed Sheet | 1061 |
| Roll paper cannot be inserted into the paper feed slot | |
| Cannot load sheets | |
| Paper is not cut straight | |
| Paper is not cut | |
| The media take-up unit continues rotating The size of clear film cannot be detected | |
| Margins are wide | |
| Printing does not start | 1068 |
| The Data lamp on the Control Panel does not light up | |
| The printer does not respond even if print jobs are sent | |
| Ink Filling. is displayed | |
| The display screen indicates Agitating | |
| The printer stops during a print job | 1070 |
| An error message is shown on the Display Screen | 1070 |
| The printer ejects blank, unprinted paper | |
| Problems with the printing quality | 1071 |
| Printing is faint | 1071 |
| Paper rubs against the printhead | |
| The edges of the paper are dirty | |
| The surface of the paper is dirty | |
| The back side of the paper is dirty | |
| Immediately after borderless printing, the trailing edge margin is soiled during regular printing | |
| Printed colors are inaccurate | |
| Colors in printed images are uneven | |
| Image edges are blurred or white banding occurs | |
| Setting the Blue Switch on the Platen | |
| The contrast becomes uneven during printing | 1080 |
| The length of printed images is inaccurate in the feeding direction | |
| Images are printed crooked | |
| Documents are printed in monochrome | |
| Line thickness is not uniform Lines or colors are misaligned | |
| Problems with the printing quality caused by the type of paper | |
| | |
| Cannot print over a network | 1083 |
| Cannot connect the printer to the network | |
| Cannot print over a TCP/IP network | 1083 |


| Installation problems108Removing Installed Printer Drivers108Other problems108The printer does not go on108The printer takes time to start up108 | 35 37 37 38 38 38 |
|--|----------------------------------|
| Removing Installed Printer Drivers 108 Other problems 108 The printer does not go on 108 The printer takes time to start up 108 | 37 37 38 38 38 |
| Other problems108The printer does not go on108The printer takes time to start up108 | 37 37 38 38 38 |
| The printer does not go on | 37 37 38 38 |
| The printer takes time to start up | 37 38 38 38 |
| | 38 38 38 |
| If the Printer Makes a Strange Sound | 38 38 |
| Messages advising to check the maintenance cartridge are not cleared | |
| The printer consumes a lot of ink | 39 |
| Ink Level Detection | |
| Error Message 109 | 2 |
| Error Messages 109 |)3 |
| Messages regarding paper 109 | 15 |
| Paper mismatch | |
| MediaType Mismatch 109 | |
| The paper is too small. | |
| The paper is too small | |
| PaprWidth Mismatch 109 | |
| Paper size not detected. | |
| Insufficient paper for job | |
| Roll printing is selected. | |
| Roll printing is selected, but sheets are loaded. | |
| The roll is empty | |
| No sheets | |
| Sheet printing is selected. | |
| Regular printing is selected, but a roll is loaded. 110 Paper loaded askew. 110 | |
| Cannot feed paper. | |
| Cannot cut this paper | |
| End of paper feed |)4 |
| Rel lever is in wrong position. | |
| Rewinding error 110 | |
| Media take-up unit ready. | |
| Turn on the media take-up unit | |
| Paper position not suitable for borderless printing. | |
| Messages regarding ink | 17 |
| Ink insufficient | 17 |
| No ink left | |
| Remaining level of the ink cannot be correctly detected. | |
| Close Ink Tank Cover | |
| Not much ink is left. | |
| No ink tank loaded | |
| Wrong ink tank | |
| Messages regarding printing or adjustment | 0 |
| Cannot execute this command. Use other paper | 0 |

| Appendix 1 | 128 |
|--|--|
| Specifications Print Area | |
| Printer Specifications | 1123 |
| Specifications 1 | 122 |
| ERROR Exxx-xxxx (x represents a letter or number) Hardware error. xxxxxxxx-xxxx (x represents a letter or number) Top cover is open. Prepare for parts replacement. Parts replacement time has passed. Unknown file. Calibration There is a problem with the multi-sensor. Multi-sensor error | . 1119 . 1120 . 1120 . 1120 . 1120 . 1121 |
| Other Messages GARO Wxxxx (x represents a number) | 1119 |
| Hard disk error. File read error. The mail box is full. Mail box full. Now printing without saving data. Mail box nearly full. Maximum jobs stored. Mail box full. Delete unwanted data | 1117 . 1117 . 1117 . 1117 . 1118 . 1118 . 1118 |
| | 1117 |
| No maintenance cartridge. Wrong maintenance cartridge. Maint. cart. The level is low No Maintenance Cartridge capacity. Maintenance cartridge full. Maintenance cartridge problem. | . 1115 . 1115 . 1115 . 1115 |
| Messages regarding the maintenance cartridge | 1115 |
| Cannot adjust printhead. PHeads: wrong pos. Wrong x printhead. (x is L, R, or not displayed) x printhead error (x is L, R, or not displayed) No x printhead (x is L, R, or not displayed) Execute printhead cleaning. | . 1113 . 1113 . 1114 . 1114 |
| Messages regarding printheads | 1113 |
| Please execute calibration. Please calibrate using above paper. Borderless printing not possible. Paper stretched or shrank. Before borderless printing, move the blue platen switch. Blue platen switch is dirty. Move the blue platen switch No.xx to the right. (xx represents a number) Cannot adjust paper feed. Check printed document. | . 1111 . 1111 . 1112 . 1112 . 1112 |
| Cannot calibrate. Excessive temperature or humidity. | . 1111 |

| How to use this manual | 1129 |
|--|------|
| About This User Manual | |
| Searching Topics HTML Version of the Manual for Printing | |
| Disposal of the product | 1139 |
| WEEE Directive | 1140 |

Basic Printing Workflow

| Printing procedure | 2 |
|----------------------|-----|
| Canceling print jobs | 1.4 |
| Canceling print jobs | 14 |
| Pausing Printing | 19 |



Printing procedure

| Printing Options Using Rolls and Sheets | 2 |
|---|----|
| Turning the Printer On and Off | 3 |
| Loading and Printing on Rolls Loading and Printing on Sheets | |
| Printing in Windows | |
| Printing from Mac OS X | 12 |

Printing Options Using Rolls and Sheets

The printer supports both rolls and sheets.

This section introduces the main features of each, as well as the main printing methods available. Select rolls or sheets to suit your particular printing application.



Note

- For information on the types of paper the printer supports, refer to the Paper Reference Guide. (See "Types of Paper.") —P.774
- A variety of other ways to print are available besides those introduced here. Choose the printing method that suits your particular printing application, referring to "Working with Various Print Jobs" and "Enhanced Printing Options" from the table of contents.

Roll printing

Media in spooled rolls is generally called Roll Media. Rolls are loaded on the Roll Holder, which are in turn loaded in the printer.

Rolls can be used to print large photos or create posters or banners that cannot be printed on regular sheets.

• Large-format printing

Easily print vertical or horizontal banners from familiar applications such as Microsoft Office applications. (See "Printing Vertical or Horizontal Banners (Large-Format Printing).") —P.122

• Borderless printing

Print without a margin (border) around posters or photos.

(See "Borderless Printing on Paper of Equivalent Size.") →P.107

(See "Borderless Printing by Resizing Originals to Fit the Roll Width.") —P.114

(See "Borderless Printing at Actual Size.") →P.100

Banner printing

You can print multiple pages as a single continuous image, without margins between pages.

(See "Printing Multiple Pages Continuously.") →P.144

• 90-degree rotation before printing

Originals in portrait orientation are rotated 90 degrees when possible to use paper more efficiently. (See "Conserving Roll Paper by Rotating Originals 90 Degrees.") —P.172

Enlarged/reduced printing

You can freely adjust the size of originals by enlarging or reducing originals before printing.

(See "Resizing Originals to Match the Paper Size.") —P.73

(See "Resizing Originals to Fit the Roll Width.") →P.79

(See "Resizing Originals by Entering a Scaling Value.") -P.85

• Free Layout function

Print multiple documents from multiple applications (such as word-processing programs, spreadsheet programs, and so on) next to each other.

(See "Printing Multiple Originals Next to Each Other.") —P.139

Sheet printing

Sheets refer to individual sheets of paper.

Insert the sheet between the Platen and the Paper Retainer.

- Enlarged/reduced printing
 - You can freely adjust the size of originals by enlarging or reducing originals before printing.
 - (See "Resizing Originals to Match the Paper Size.") —P.73
 - (See "Resizing Originals by Entering a Scaling Value.") P.85
- Free Layout function

Print multiple documents from multiple applications (such as word-processing programs, spreadsheet programs, and so on) next to each other.

(See "Printing Multiple Originals Next to Each Other.") →P.139

Turning the Printer On and Off

Turning the printer on


1. Press the **Power** button to turn on the printer. The printer will now start up.

After the Display Screen shows the Canon logo, "Starting up... Please wait." is displayed.



2. The **Power Lamp** is lit when the printer finishes starting up, and the printer is now in **Standby**.





The printer will not go into **Standby** in the following situations. Take the appropriate action.

• The Top Cover is open Close the Top Cover.

The Ink Tank Cover is open

Close the Ink Tank Cover.

· The Printhead is not installed

see "Replacing the Printhead." →P.1013

· An Ink Tank is not installed

see "Replacing Ink Tanks." →P.997

• If ERROR is shown on the Display Screen

see "Error Messages." →P.1093

• The **Power Lamp** and **Message Lamp** are not lit (even once), and nothing appears on the Display Screen

Make sure the printer is plugged in correctly. Check the connection at the plug and electrical outlet.

· No paper is loaded

Load paper. (See "Loading and Printing on Rolls.") —P.5 (See "Loading and Printing on Sheets.") —P.9



Important

• Starting the printer when it is connected via the USB cable to a Macintosh computer that is off may cause the computer to start up at the same time. To prevent this, disconnect the USB cable before starting the printer. Connecting the printer to the computer via a USB hub may solve this issue.

Turning the printer off



Important

- Never disconnect the printer's power supply or unplug it during a print job. This may damage the printer.
- 1. Make sure no print jobs are in progress.

 If the **Message Lamp** is flashing, check the message on the Display Screen and take action as necessary. (See "Error Messages.") —P.1093



1

If the Data Lamp is flashing, the printer is receiving a print job. Turn off the printer only after printing is finished.



2. Hold down the **Power** button for more than a second.



After "Shut Down.. Please Wait.." is shown on the Display Screen, the printer shuts off.

Loading and Printing on Rolls

These are the basic steps for loading and printing on rolls. Follow these steps to load and print on rolls.

- For details on using the Output Stacker, see "Using the Output Stacker." —P.823
- For details on using the optional Media Take-up Unit, see "Media Take-up Unit." —P.911



Important

• If you are not using the optional Media Take-up Unit when printing long documents such as banners, spread a clean cloth or paper on the floor. Use the Output Stacker to prevent long printed documents from being soiled by the floor after they are printed. (See "Using the Output Stacker.")

P.823



Note


- For details on supported sizes and types of rolls, see **Paper Sizes** or the Paper Reference Guide. (See "Paper Sizes.") —P.775 (See "Types of Paper.") —P.774
- To wait until the ink dries after printing before cutting the roll, set **Drying Time** in the printer driver. (See "Specifying the lnk Drying Time for Rolls.") —P.800
- Once you have used all the paper on a roll, clean the platen. If the Platen inside the Top Cover becomes dirty, it may soil the underside of paper. (See "Cleaning Inside the Top Cover.") →P.1040

 1_{\bullet} Turn the printer on. (See "Turning the Printer On and Off.") $\longrightarrow \hspace{-0.5em} \text{P.3}$







2. Load the roll on the Roll Holder. (See "Attaching the Roll Holder to Rolls.") \rightarrow P.782



3. Load the roll in the printer. (See "Loading Rolls in the Printer.") —P.786







Important

• When printing without borders, definitely set the blue Switch on the platen to the ● side. If the switch is set incorrectly, print quality may deteriorate. (See "Setting the Blue Switch on the Platen.")

→P.1078

4. Select the type of paper. (See "Changing the Type of Paper.") →P.791






Note

• If no barcode has been printed on the roll and you have set **ManageRemainRoll** to **On**, specify the roll length after the type of paper. (See "Specifying the Paper Length.") P.793



- **5.** Complete settings in the printer driver for the type of paper and other details.
 - Specifying Paper in the Printer Driver (Windows) →P.204
 - Specifying Paper in the Printer Driver (Mac OS X) →P.489





- **6.** Send the print job.
 - Printing in Windows →P.11
 - Printing from Mac OS X →P.12



The printer now starts printing the print job.

Loading and Printing on Sheets

These are the basic steps for loading sheets and then printing. Follow the steps below to load and print on sheets.



Note


- For details on supported types and sizes of paper, see **Paper Sizes** or the Paper Reference Guide. (See "Paper Sizes.") —P.775 (See "Types of Paper.") —P.774
- Borderless printing is not supported on sheets. For the features and the main printing methods available for sheet printing, see "Printing Options Using Rolls and Sheets."

 P.2
- 1. Turn the printer on. (See "Turning the Printer On and Off.") \longrightarrow P.3





- 2. Complete settings in the printer driver for the type of paper and other details.
 - Specifying Paper in the Printer Driver (Windows) →P.204
 - Specifying Paper in the Printer Driver (Mac OS X) →P.489






11

- 3. Send the print job.
 - Printing in Windows →P.11
 - Printing from Mac OS X →P.12



4. Load the sheet. (See "Loading Sheets in the Printer.") —P.813



Start printing.

Printing in Windows

Print from the application menu.



Important

• We recommend exiting unnecessary applications before printing. Running several applications while printing may interrupt the transfer of print data and affect printing quality.

iPF8300S Printing in Windows


- 1. In the source application, select **Print** from the **File** menu to display the dialog box for printing conditions.
- 2. After confirming that the printer is selected in the dialog box, click **Print** or **OK** to start printing.



Note

• The appearance of the dialog box varies depending on the software application. In most cases, the dialog box includes basic printing options and enables you to choose the printer, specify the range of pages, number of copies, and so on.

Example: Print dialog box displayed by the application



• If another printer is selected, select the printer you want to use under **Select Printer** or in the dialog box displayed after clicking **Printer**.

Settings for many printing methods (including enlarged or reduced printing, borderless printing, and so on) are displayed in the printer driver dialog box. There are two ways to access the printer driver dialog box, as follows.

- From the application
 (See "Accessing the Printer Driver Dialog Box from Applications (Windows).") →P.211
- From the operating system menu (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows).") →P.213

Printing from Mac OS X

Print from the application menu after registering the printer.



12

Important

• We recommend exiting unnecessary applications before printing. Running several applications while printing may interrupt the transfer of print data and affect printing quality.

Registering the printer

Before printing, you must register the printer in **imagePROGRAF PrinterSetup.app**. For instructions on registering the printer, see "Configuring the Printer Driver Destination (Mac OS X)." —P.970

Important

• During this setup process, the printer will not be listed among available printers if it is off or disconnected.


Printing from the application software

1. In the application software, select **Print** from the **File** menu to display the dialog box for printing conditions.




Note

- This dialog box includes basic printing options and enables you to choose the printer, specify the range of pages, number of copies, and so on.
- 2. Select the printer in the **Printer** list.



3. Click **Print** to start printing.

As shown in the following illustration, you can switch to other panes in this dialog box to complete settings for various methods of printing, including enlarged and reduced printing, borderless printing, and so on.



Canceling print jobs

| Canceling Print Jobs from the Control Panel | 14 |
|---|----|
| Canceling Print Jobs from Windows | 15 |
| Canceling Print Jobs from Mac OS X | 16 |

Canceling Print Jobs from the Control Panel


To cancel printing or reception of print jobs, press the **Stop** button on the Control Panel.



When you press the **Stop** button during printing, printer operation varies depending on the current status.

• If you press the **Stop** button before printing starts


Pressing the **Stop** button before printing starts will display a confirmation message. To cancel the print job, select "Yes".



The Printer does not print.

• If you press the Stop button during printing

Pressing the **Stop** button during printing will display a confirmation message. To cancel the print job immediately, select "Yes".



The printer stops immediately.

Canceling Print Jobs from Windows

In the printer window, you can cancel jobs that are being sent to the printer.


Using imagePROGRAF Status Monitor, you can cancel print jobs that have already been received by the printer or that are currently being printed.

 ${f 1}$. Click the printer icon in the taskbar to display the printer window.




Note

- You can also display this window by double-clicking the printer icon in the **Printers and Faxes** (or **Printers**) folder, accessible through the Windows **start** menu.
- 2. Right-click the job to cancel and select Cancel.



3. If the job to cancel is not shown in the printer window (that is, if the print data has already been received by the printer), double-click the taskbar icon to display imagePROGRAF Status Monitor.

4. On the Printer Status sheet, click Cancel Job.





Note

• The screen may differ slightly depending on the model you are using.

Canceling Print Jobs from Mac OS X

In the printer window, you can cancel jobs that are being sent to the printer.


Otherwise, you can cancel jobs from imagePROGRAF Printmonitor if they have been received by the printer or are currently being printed.




Note

- Print jobs are shown in the printer window while they are being sent from the computer. After transmission, jobs are not displayed even during printing.
- Print jobs are displayed in the imagePROGRAF Printmonitor window from the moment the printer starts receiving the print data until the moment printing is finished. They are not displayed before print data is sent to the printer, even if the computer has started preparing the print data.
- 1. Click the printer icon in the **Dock** to display the printer window.

2. Click Pause Printer to stop printing.




3. If there are no jobs in the printer window that can be canceled, (that is, if the print data has already been sent to the printer), click **Utility** to display imagePROGRAF Printmonitor.



4. Select the print job to cancel and click



to delete the print job.





Note

• The screen may differ slightly depending on the model you are using.

The job sent to the printer is canceled.

5. Exit imagePROGRAF Printmonitor. In the printer window, click **Resume Printer**.



Important

• Always follow these steps if you cancel print jobs from imagePROGRAF Printmonitor. If you do not restart job processing, the next job cannot be printed.

Pausing Printing

Pausing Printing

During printing, if you set **Pause Print** in the Control Panel menu to **On**, printing is stopped at that point and the printer enters a state in which printing is paused. (See "Control Panel Display.") —P.916

Printing from the job queue is not possible in this state.

To restore normal operation after this state, set Pause Print to Off.



Note

- In the following cases, the status is cleared even if you do not set **Pause Print** to **Off**, and printing from the job queue resumes.
 - · When paper is advanced
 - When you execute Chg. Paper Type in the Paper Menu
- 1. During printing, on the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (....).





Note


• If the **Tab Selection screen** is not displayed, press the **Menu** button.

- 2. Press the **OK** button.
 The **Job Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Pause Print**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select **On** or **Off**, and then press the **OK** button.

iPF8300S Pausing Printing

Enhanced Printing Options

| Choosing Paper for Printing | 21 |
|---|-----|
| Printing Photos and Office Documents | 22 |
| Printing CAD Drawings | 47 |
| Adjusting Images | 55 |
| Printing enlargements or reductions | 73 |
| Printing at full size | 93 |
| Borderless Printing | 107 |
| Printing banners or at other non-standard sizes | 122 |
| Tiling and multiple pages per sheet | 139 |
| Centering originals | 160 |
| Conserving roll paper | 172 |
| Checking Images Before Printing | 184 |
| Other useful settings | 186 |



Choosing Paper for Printing

| Choosing a Paper for Printing | . 21 |
|--|------|
| Specifying Paper in the Printer Driver | . 21 |

Choosing a Paper for Printing

Choosing the right paper for your particular printing application will give you the best printing results.

• Media Type

The printer and printer driver offer print settings optimized for various paper characteristics.



Note

- For information on the types of paper the printer supports, refer to the Paper Reference Guide.(See "Types of Paper P.774")
- The types of paper indicated in the printer driver and related software (as well as on the Control Panel) are updated when you install the Media Configuration Tool from the User Software CD-ROM or if you change paper information by using the Media Configuration Tool. For information about the Media Configuration Tool, see the Media Configuration Tool —P.448 (Windows) or Media Configuration Tool —P.677 (Macintosh).
- An error message may be displayed on the printer Control Panel if the type of paper as specified in the printer driver does not match the type specified on the printer. Although you can print under these conditions, the printing results may not be suitable.
- If the paper type is not listed for selection
 - If the type of paper loaded cannot be selected, try specifying glossy paper or proofing paper as a special paper (Special 1 to Special 5, in this order). BK (Black Ink) is used as the black ink. Try specifying other types of paper as Special 6 to Special 10. MBK (Matte Black Ink) is used as the black ink. Note that higher numbers in this setting enable more vivid colors but may also cause colors to run together.

Furthermore, **Register Custom Paper** can also be performed using the Media Configuration Tool.

For information about the Media Configuration Tool, see Media Configuration Tool →P.448 (Windows) or Media Configuration Tool →P.677 (Macintosh).

For instructions on specifying the paper type before printing, refer to the following topics.

Changing the Type of Paper →P.791

Specifying Paper in the Printer Driver

If you replace the paper, complete the printer driver settings for the paper type and size.

For instructions on configuring paper settings in the printer driver, refer to the following topics, as appropriate for your computer and operating system.

- Specifying Paper in the Printer Driver (Windows) →P.204

Printing Photos and Office Documents

| Printing Photos and Images | 22 |
|---|----|
| Printing Photos and Images (Windows) | |
| Printing Photos and Images (Mac OS X) | |
| Printing from Photoshop | 29 |
| Printing Adobe RGB Images (Windows) | |
| Printing Adobe RGB Images (Mac OS X) | |
| Printing Office Documents | 38 |
| Printing Office Documents (Windows) | |
| Printing Office Documents (Mac OS X) | |
| Using PosterArtist to Compose Originals | 44 |

Printing Photos and Images

By selecting the following **Print Target** from **Easy Settings** of the printer driver, you can easily configure the printing of illustrations and photos.

| | Print Target | Description |
|-------------|-----------------------------|---|
| SRGB | Photo (Color) | Print photographic images from digital cameras with an optimal setting. |
| | Photo (Monochrome) | Print monochrome photos with an optimal setting. |
| BCDS | Poster | An optimal setting for posters. Print in vivid colors with impact and high saturation. |
| | Faithful Color Reproduction | Print with minimum color difference. Suitable for printing scanner images and when print results are too vivid. |
| Adobe RGB | Photo (Adobe RGB) | Setting suitable for printing images created using the color space of Adobe RGB in optimal color. |



Important

• Depending on the **Media Type** setting, some **Print Target** options may not be available.



Note

- You can check the settings values for each print target by clicking View Settings.
- You can also fine-tune these values as needed. (Advanced Settings)
 For details on Advanced Settings, refer to "Giving Priority to Particular Graphic Elements and Colors for Printing —P.64".

For instructions on printing photos and images, refer to the following topics, as appropriate for your computer and operating system.


- Printing Photos and Images (Windows) →P.23
- Printing Photos and Images (Mac OS X) →P.25

Printing Photos and Images (Windows)

This topic describes how to print photos based on the following example.

- Document: Photo image from a digital camera
- Page size: 10×12 inches (254.0×304.8 mm)
- Paper: Roll
- Paper type: Glossy Photo Paper HG 170
- Roll paper width: 10 inches (254.0 mm)
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")

3. Make sure the **Main** sheet is displayed.



4. In the A Media Type list, select the type of paper that is loaded. In this case, click Glossy Photo Paper HG 170. In the A Media Type, choose the type of paper used for printing, such as Glossy Paper, Coated Paper, and so on. Make sure the paper you select is loaded in the printer.



Note


- The paper type setting in the printer driver and related software (as well as on the Control Panel) is updated when you install the Media Configuration Tool from the User Software CD-ROM or if you change paper information by using the Media Configuration Tool. For details, see Media Configuration Tool —P.448.
- 5. After confirming that DEasy Settings is selected, click Photo (Color) in the EPrint Target list.




Note

• You can check the settings values selected in the **E Print Target** list by clicking **G View Settings**.

6. Click the Page Setup tab to display the Page Setup sheet.



- 7. In the A Page Size list, click the size of the original as specified in the application. In this case, click 10"x12".
- **8.** Select and click a roll paper in the **L Paper Source** list.
- 9. Select the width of the loaded roll in the MRoll Paper Width list—in this case, 10-in. Roll (254.0mm).
- 10. Specify additional printing conditions.
 For details on available printing conditions, see "Printer Driver Settings (Windows) —P.202
- 11. Confirm the print settings and print as desired.




Printing Photos and Images (Mac OS X)

This topic describes how to print photos based on the following example.


- Document: Photo image from a digital camera
- Page size: 10×12 inches (254.0×304.8 mm)
- · Paper: Roll paper
- Paper type: Glossy Photo Paper HG 170
- Roll paper width: 10 inches (254.0 mm)

1. This sets the **B** Format for and **C** Paper Size.



- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click 10"x12".
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.



6. In the A Media Type list, select the type of paper that is loaded. In this case, click Glossy Photo Paper HG 170. Make sure the paper you select is loaded in the printer.



Note


- The types of paper indicated in the printer driver and related software (as well as on the Control Panel) are updated when you install the Media Configuration Tool from the User Software CD-ROM or if you change paper information by using the Media Configuration Tool. For details, see Media Configuration Tool —P.677.
- 7. After confirming that D Easy Settings is selected, click Photo (Color) in the E Print Target list.




Note

- For information on settings optimized for printing photos and images, see "Printing Photos and Images P.22"
- You can check the settings values selected in the **EPrint Target** list by clicking **GView set.**.
- 8. Make your selection in the F Print Quality list.


9. Access the **Page Setup** pane.



- 10. Select and click a roll paper in the A Paper Source list.
- 11. Make sure the width of the loaded roll is displayed in the B Roll Width list—in this case, 10 in. (254.0mm).



12. Make sure C Page Size on the Page Setup pane shows the original size as specified in C Paper Size in the Page Attributes dialog box—in this case, 10"x12".



- 13. Specify additional printing conditions.

 For details on available printing conditions, see "Printer Driver Settings (Mac OS X) P.487"
- 14. Confirm the print settings, and then click $\frac{\mathsf{M}}{\mathsf{Print}}$ to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) -P.492 "

Printing from Photoshop

You can print images in the Adobe RGB color space that you have created in Photoshop, the Adobe Systems photo retouching application. Using the dedicated Photoshop printer driver plug-in (provided with the printer) makes it easy to print Adobe RGB images more attractively.

- Using the Plug-in to Print
 The imagePROGRAF Print Plug-In for Photoshop is a dedicated plug-in provided with the printer that you can load in
 Photoshop and customize for your printing needs. By using the plug-in, you can print while preserving the 16-bit RGB
 data from Photoshop without losing the exceptional color gradations of original image. Some of the settings and customizations available in the plug-in are as follows.
 - Automatic detection of the color space (sRGB or Adobe RGB) for automatic selection of the optimal profile. This feature eliminates the need to complete intricate settings when printing Adobe RGB images.
 - Advanced gray adjustment, including adjustment of tone curves, in addition to an array of standard adjustments for color balance, brightness, contrast, highlight, and shadow.
 - Fine-tune color tones in Photoshop while viewing a preview that accurately reproduces printing results.
 - With print log management, you can save and load setting parameters from past print jobs.



Note

• imagePROGRAF Print Plug-In for Photoshop for Windows and Macintosh are provided with the printer.

iPF8300S Printing from Photoshop

For instructions and details on which versions of Photoshop are compatible with the imagePROGRAF Print Plug-In for Photoshop, refer to the following topics, as appropriate for your computer and operating system.

- Print Plug-In for Photoshop/Digital Photo Professional —P.307
- Print Plug-In for Photoshop/Digital Photo Professional →P.609
- Using the Printer Driver to Print

The printer driver offers the following settings and adjustments.

- Choose the standard sRBG color space or Adobe RGB as desired.
- Adjust the color balance, brightness, contrast, saturation, and gray levels.

For instructions on using the printer driver to print Adobe RGB images created in Photoshop, refer to the following topics, as appropriate for your computer and operating system.

- Printing Adobe RGB Images (Windows) →P.30
- Printing Adobe RGB Images (Mac OS X) →P.34

Printing Adobe RGB Images (Windows)

This topic describes how to print Adobe RGB images based on the following example.

- Document: Adobe RGB image created in Photoshop
- Page Size: 10×12 inches (254.0×304.8 mm)
- · Paper: Roll
- Paper type: Glossy Photo Paper HG 170
- Roll Paper Width: 10 inches (254.0 mm)



Important


- In Photoshop, select no color-matching.
- In the printer driver settings, select Driver Matching Mode and choose Adobe RGB in Color Space.
- ${f 1}$. In Photoshop, create an image in the Adobe RGB color space.




Note

- The following procedures are based on the example of Photoshop CS2.
- For instructions on creating Adobe RGB images, refer to the Photoshop documentation.
- 2. Choose **Print with Preview** from the **File** menu to display the **Print** dialog box.
- **3.** Make sure the setting mode is **Color Management**.
- 4. In the Color Handling list in Options, click No Color Management.
- **5.** Click **Print** to display the **Print** dialog box.
- **6.** Select the printer and click **Properties** to display the printer driver dialog box.

7. Make sure the **Main** sheet is displayed.



- 8. In the A Media Type list, select the type of paper that is loaded. In this case, click Glossy Photo Paper HG 170.
- **9.** Click **D** Advanced Settings to switch the print mode.





10. Click Image in the Eprint Priority list.


11. Select the print quality in the F Print Quality list.



- Note
- Options displayed in the **F Print Quality** list vary depending on the paper type.
- 12. Click Color in the ${\color{red} {\sf G}}$ Color Mode list.
- 13. Click H Color Settings to display the Color Settings dialog box.









- 15. In A Matching Mode, click Driver Matching Mode.
- 16. In C Color Space, click Adobe RGB.
- $17 \boldsymbol{.}$ Click $o_{\boldsymbol{K}}$ to close the Color Settings dialog box.

18. Click the Page Setup tab to display the Page Setup sheet.



- 19. In the A Page Size list, click the size of the original as specified in the source application. In this case, click 10"x12".
- 20. Select and click a roll paper in the LPaper Source list.
- 21. Select the width of the loaded roll in the MRoll Paper Width list. In this case, click 10-in. Roll (254.0mm), and then click OK.
- **22.** Confirm the print settings and print as desired.



Printing Adobe RGB Images (Mac OS X)

This topic describes how to print Adobe RGB images based on the following example.

- Document: Adobe RGB image created in Photoshop
- Page size: 10×12 inches (254.0×304.8 mm)
- · Paper: Roll
- Paper type: Glossy Photo Paper HG 170
- Roll paper width: 10 inches (254.0 mm)




Important

- In Photoshop, select no color-matching.
- In the printer driver settings, select Driver Matching Mode and choose Adobe RGB in Color Space.
- ${f 1}_{ullet}$ In Photoshop, create an image in the Adobe RGB color space.




Note

- The following procedures are based on the example of Photoshop CS3/CS4/CS5.
- For instructions on creating Adobe RGB images, refer to the Photoshop documentation.
- 2. Choose **Print with Preview** from the Photoshop menu to display the **Print** dialog box.
- **3.** Make sure the setting mode is **Color Management**.
- 4. In the Color Handling list, click Printer Manages Colors.
- 5. Click Print.
- **6.** Access the Main pane.



7. In the A Media Type list, select the type of paper that is loaded. In this case, click Glossy Photo Paper HG 170.

8. Click **D** Advanced Settings to switch the print mode.




- 9. Click Image in the E Print Priority list.
- 10. Select the print quality in the F Print Quality list.




- 11. Click Color in the $\frac{\mathsf{H}}{\mathsf{Color}}$ Mode list.
- 12. Click | Set to display the Color Settings dialog box.
- 13. Click Matching to display the Matching pane.
- 14. In Matching Mode, click Driver Matching Mode.
- 15. In Color Space, click Adobe RGB.
- 36 16. Click OK to close the Color Settings dialog box.

17. Access the Page Setup pane.



- 18. Select and click a roll paper in the A Paper Source list.
- 19. Make sure the width of the loaded roll paper is displayed in the BRoll Width list—here, 10-in. Roll (254.0mm).



20. Make sure C Page Size in the Page Setup pane matches the size of the original as specified in Photoshop—in this case, 10"x12".

21. Confirm the print settings, and then click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X)." —P.492

Printing Office Documents

By selecting **Office Document** from **Easy Settings** of the printer driver, you can easily configure settings for printing office documents.

| | Print Target | Description |
|--------|-----------------|---|
| albba. | Office Document | Setting optimized for printing general office documents such as materials for distribution so that they can be viewed easily. |



Note

- You can check the settings values for each print target by clicking View Settings.
- You can also fine-tune these values as needed. (Advanced Settings)
 For details on Advanced Settings, refer to "Giving Priority to Particular Graphic Elements and Colors for Printing —P.64".

For instructions on printing office documents, refer to the following topics, as appropriate for your computer and operating system.


- Printing Office Documents (Windows) →P.38
- Printing Office Documents (Mac OS X) →P.40

Printing Office Documents (Windows)

This topic describes how to print office documents based on the following example.

- Document: Office document created using word-processing or spreadsheet programs
- Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- · Paper: Sheets
- Paper type: Plain Paper
- Paper size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) P.211")






- 4. In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. After confirming that D Easy Settings is selected, click Office Document in the E Print Target list.



6. Click the **Page Setup** tab to display the **Page Setup** sheet.



- 7. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4.
- **8.** Click **Cut Sheet** in the **L Paper Source** list.
- 9. Specify additional printing conditions.
 For details on available printing conditions, see "Printer Driver Settings (Windows) P.202"
- 10. Confirm the print settings and print as desired.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "


Printing Office Documents (Mac OS X)

This topic describes how to print office documents based on the following example.

- Document: Office document created using word-processing or spreadsheet programs
- Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- Paper: Sheets
- Paper type: Plain Paper
- Paper size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])


Printing Office Documents (Mac OS X)

1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4 for Paper Tray (Large Margins).
- 4. If you configured the settings using the Page Attributes dialog box, click FOK to close the dialog box, and then select Print from the application software menu.

5. Access the Main pane.




- **6.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. After confirming that D Easy Settings is selected, click Office Document in the E Print Target list.




8. Make your selection in the **F Print Quality** list.

9. Access the **Page Setup** pane.



- 10. Click Cut Sheet in the A Paper Source list.
- 11. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, ISO A4 for Paper Tray (Large Margins).



- 12. Specify additional printing conditions.
 For details on available printing conditions, see "Printer Driver Settings (Mac OS X) →P.487
- 13. Confirm the print settings, and then click M Print to start printing.




Using PosterArtist to Compose Originals


You can print a variety of source documents from word-processing or spreadsheet programs or screen shots from web browsers after composing an original with them using PosterArtist.

This topic describes how to use PosterArtist to compose originals from multiple applications, creating a poster layout for printing.


- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows).") P.211
- **3.** Make sure the **Main** sheet is displayed.



4. Click the **Layout** tab to display the **Layout** sheet.



- 5. Select the A Page Layout check box.
- 6. Click in the Edit Using PosterArtist in the A Page Layout list.
- 7. When you attempt to print, PosterArtist starts up and the PageCapture window is displayed. (At this point, the document will not be printed yet.)



8. Choose the page to load in PosterArtist.

9. Edit and rearrange the image in the PosterArtist window as desired. Without closing the PosterArtist window, repeat steps 1-8 to arrange originals from multiple applications on the same page.



Note

• For details on how to edit and sort images, refer to the PosterArtist Manual.

10. Print from the PosterArtist menu.

Printing CAD Drawings

| Printing Line Drawings and Text | 47 |
|--|----|
| Printing Line Drawings and Text (Windows) | |
| Printing Line Drawings and Text (Mac OS X) | |
| Printing from AutoCAD | |

Printing Line Drawings and Text

By selecting the following **Print Target** from **Easy Settings** of the printer driver, you can easily configure setting for printing line drawings and characters.

| | Print Target | Description |
|---|--------------------------|--|
| 3 | Perspective, GIS | Settings optimized for printing 3D CAD drawings, perspective drawings, and maps, including GIS maps. |
| | CAD (Color Line Drawing) | Settings optimized to print intricate lines in CAD drawings clearly. |



Note

- You can check the settings values for each print target by clicking View Settings.
- You can also fine-tune these values as needed. (Advanced Settings)
 For details on Advanced Settings, refer to "Giving Priority to Particular Graphic Elements and Colors for Printing —P.64".

For instructions on printing line drawings and text, refer to the following topics, as appropriate for your computer and operating system.


- Printing Line Drawings and Text (Windows) →P.47
- Printing Line Drawings and Text (Mac OS X) →P.49

Printing Line Drawings and Text (Windows)

This topic describes how to print line drawings based on the following example.

- Document: CAD drawing
- Page size: A3 (297.0 \times 420.0 mm [11.7 \times 16.5 in])
- · Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- **1.** Choose **Print** in the application menu.


- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) P.211")
- **3.** Make sure the **Main** sheet is displayed.



- **4.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. After confirming that D Easy Settings is selected, click CAD (Color Line Drawing) or CAD (Monochrome Line Drawing) in the E Print Target list.



6. Click the Page Setup tab to display the Page Setup sheet.



- 7. In A Page Size, click the size of the original as specified in the application. In this case, click ISO A3.
- **8.** Select and click a roll paper in the **L Paper Source** list.
- 9. Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 10. Specify additional printing conditions.
 For details on available printing conditions, see "Printer Driver Settings (Windows) —P.202
- 11. Confirm the print settings and print as desired.



Note


- For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "
- You can conserve roll paper by configuring settings suitable for the document.
 For details on how to conserve paper and print, refer to "Conserving Roll Paper by Rotating Originals 90 Degrees (Windows) →P.172 ".

Printing Line Drawings and Text (Mac OS X)

This topic describes how to print line drawings based on the following example.


- Document: CAD drawing
- Page size: A3 (297.0 \times 420.0 mm [11.7 \times 16.5 in])
- Paper: Roll
- Paper type: Plain Paper

- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A3.
- 4. If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the **Main** pane.




- **6.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. After confirming that D Easy Settings is selected, click CAD (Color Line Drawing) in the E Print Target list.




8. Make your selection in the **F Print Quality** list.


9. Access the **Page Setup** pane.



- 10. Select and click a roll paper in the A Paper Source list.
- 11. Make sure the width of the loaded roll is displayed in the B Roll Width list—in this case, ISO A2/A3 (420.0mm).



12. Make sure C Page Size on the Page Setup pane shows the original size as specified in C Paper Size in the Page Attributes dialog box—in this case, ISO A3.



- 13. Specify additional printing conditions.

 For details on available printing conditions, see "Printer Driver Settings (Mac OS X) P.487"
- 14. Confirm the print settings, and then click M Print to start printing.



Note

- For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) —P.492 "
- You can conserve roll paper by configuring settings suitable for the document.

 For details on how to conserve paper and print, refer to "Conserving Roll Paper by Rotating Originals 90 Degrees (Mac OS X) —P.174.

Printing from AutoCAD

Printer Driver Optimization Module for AutoCAD is software for printing optimally from AutoCAD with the printer driver. By optimally controlling the processing resolution of raster data and the memory to be used in image processing of Auto-CAD, printing superior in reliability and productivity is realized.

If you install Printer Driver Optimization Module for AutoCAD on a computer on which supported AutoCAD is installed, it will be installed automatically.



Note

• Printer Driver Optimization Module for AutoCAD is applied automatically when you print from AutoCAD, and optimal printing is performed.

Confirming the Installation of Printer Driver Optimization Module for AutoCAD


You can confirm whether Printer Driver Optimization Module for AutoCAD is installed by the following method.

1. From the **File** menu of AutoCAD, select **Print**.

iPF8300S Printing from AutoCAD

2. The **Printing** dialog box is displayed.

Printer Driver Optimization Module for AutoCAD is installed if in **Plotter** of **Printer/plotter** this is displayed: **iPFxxxx** - **Optimized driver** - **by Canon Inc.**.



Installation of Printer Driver Optimization Module for AutoCAD

If Printer Driver Optimization Module for AutoCAD is not installed, install it by the following method.

- 1. Insert User Software CD-ROM in the CD-ROM drive and start the installer.
- 2. In the Setup Menu window, click Install Individual Software.
- **3.** Click **Install** of Printer Driver Optimization Module for AutoCAD.
- **4.** Follow the instructions on the screen.

54

Printing from AutoCAD iPF8300S

Adjusting Images

| Adjusting the Color in the Printer Driver | 55 |
|--|----|
| Fine-Tuning Colors of Photos and Images (Windows) | |
| Fine-Tuning Colors of Photos and Images (Mac OS X) | |
| Giving Priority to Particular Graphic Elements and Colors for Printing | 64 |
| Choosing the Document Type and Printing Conditions (Windows) | 67 |
| Choosing the Document Type and Printing Conditions (Mac OS X) | 70 |

Adjusting the Color in the Printer Driver

Color settings specified in the application for your documents are essentially given priority over other settings for each print job, but further color adjustment is possible in the printer driver.

Color Mode

Choose how the printer driver processes color, as desired.

The available options vary depending on the color mode.

| Color Mode | Description | Color Adjustment |
|--------------------------|---|---|
| Color | Print in color. | You can select the color balance and color matching functions. |
| Monochrome (Photo) | Grayscale printing optimized for monochrome photos. | You can adjust the color balance in ways tailored to monochrome photos. |
| Monochrome | Print in grayscale. | You can adjust the color balance. |
| No color correction (*1) | Prints without performing color- matching in the printer driver. | You can adjust the color balance. |

^{*1:} If No color correction is selected, the Matching sheet / Matching pane is not displayed.

Color Adjustment

You can adjust colors separately for images, graphics, and text documents.

| Adjustment Item | Description | |
|-----------------|--|--|
| Cyan | Fine-tune color tones by adjusting the levels of Cyan, Magenta, and Yellow. | |
| Magenta | | |
| Yellow | | |
| Gray Tone | Adjust the grayscale, in a range from cool, blue tones to warm, red tones. | |
| Brightness | Adjust the brightness of printed images while keeping the darkest and lightest portions intact. | |
| Contrast | Adjust the contrast of the darkest and lightest portions relative to each other. For soft gradation, decrease the contrast. For hard gradation, increase the contrast. | |
| Saturation | Adjust the level of color saturation, in a range from subdued to vivid. | |



Note

• Click **Object Adjustment** to open the **Object Adjustment** dialog box, which allows you to select the color adjustment target from **Image**, **Graphics**, and **Text**.

Matching

You can choose the color-matching mode and method.

By adjusting the color-matching mode and method, you can make printed colors match the colors of on-screen images more closely.



Important

• If No color correction is selected under Color Mode, the Matching cannot be changed.

| Matching Mode | Description | Remarks |
|----------------------|---|--|
| Driver Matching Mode | Enables printing of optimal color tones using a driver specific color profile. | You should normally select this mode. You should also select this mode if you want to use ambient light adjustment. |
| ICC Matching Mode | Enables color matching using ICC profiles. Select this if you want to print by specifying the input profile, printer profile, and matching method in detail. | This allows you to use ICC profiles for digital cameras and scanners, ICC profiles created using the profile creation tool, etc. |
| Driver ICM Mode | Enables color matching by the printer driver using the ICM function of printer driver. Select this if you want to print by only specifying the matching method. | Available when using Windows. |
| Host ICM Mode | Enables color matching by the host computer using the ICM function of Windows. Select this if you want to print from an application that supports the ICM function. | |
| ColorSync | Enables color matching by using the ColorSync function of Mac OS. Select this if you want to perform soft proofing using ColorSync before printing. | Available when using Mac OS. |

| Matching Method | Description | Remarks |
|-----------------|---|---|
| Auto | Color-matching optimized for images, graphics, or text. | The available options and their display order vary depending on your selected |
| Perceptual | Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software. | color-matching mode, as well as the operating system. |

| Matching Method | Description | Remarks |
|--------------------------------|---|---|
| Colorimetric | Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric. | The available options and their display order vary depending on your selected color-matching mode, as well as the operating system. |
| Colorimetric (No Wht-pnt Corr) | The processing method of color- matching is identical to Colorimetric. Use this when you want to further re- produce the target paper material col- or of the image data. Generally, this also is called absolute colorimetric. | |
| Saturation | Color-matching optimized for printing posters, etc., vividly. | |
| Monitor Matching | Suitable for optimized printing to match the appearance on the monitor. Color-matching optimized for accurately reproducing colors on the calibrated sRGB or AdobeRGB monitor. | |

Gray Tone Adjustment

The following settings can be adjusted if **Monochrome (Photo)** is selected in Color Mode.

| Gray Adjustment Items | Description | |
|-----------------------|--|--|
| Color Balance | Adjust the gray tone to suit the images of monochrome photos. Choose cool black (tinged with blue), pure black (neutral), warm black (tinged with red), and so on. Select the color tone in the color region or from the list. | |
| Brightness | Adjust the brightness of printed images while keeping the darkest and lightest portions intact. | |
| Contrast | Adjust the contrast of the darkest and lightest portions relative to each other, as desired. For soft gradation, decrease the contrast. For hard gradation, increase the contrast. | |
| Highlight | Adjust levels of image highlight areas. | |
| Shadow | Adjust levels of image shadow areas. | |



Note

• Be sure to calibrate your monitor colors correctly if you adjust the colors for printing. If monitor colors are not calibrated correctly, you may not obtain the desired printing results. For instructions on monitor calibration, refer to the documentation for your monitor and operating system.


For instructions on color adjustment, refer to the following topics, as appropriate for your computer and operating system.

- Fine-Tuning Colors of Photos and Images (Windows) —P.58
- Fine-Tuning Colors of Photos and Images (Mac OS X) →P.61


Fine-Tuning Colors of Photos and Images (Windows)


You can specify your own print settings instead of using the **Print Target** presets. This topic describes how to fine-tune the color tone of photos before printing.

- 1. Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")
- **3.** Make sure the **Main** sheet is displayed.



4. In the **A Media Type** list, select the type of paper that is loaded.





- **6.** Click Color in the **G** Color Mode list.
- 7. Click H Color Settings to display the Color Settings dialog box.




8. On the **Color Adjustment** sheet, adjust the color tones, brightness, and so on as desired.

| Adjustment Item | Description | |
|---------------------|--|--|
| D Cyan | Fine-tune color tones by adjusting the levels of Cyan, Magenta, and Yellow. | |
| E Magenta | | |
| F Yellow | | |
| G Gray Tone | Adjust the gray tone to suit the images of monochrome photos. Choose cool black (tinged with blue), pure black (neutral), warm black (tinged with red), and so on. Select the color tone in the color region or from the list. | |
| H Brightness | Adjust the brightness of printed images while keeping the darkest and lightest portions intact. | |
| Contrast | Adjust the contrast of the darkest and lightest portions relative to each other. For soft gradation, decrease the contrast. For hard gradation, increase the contrast. | |
| J Saturation | Adjust the level of color saturation, in a range from subdued to vivid. | |



Note

- Click **Object Adjustment** to open the **Object Adjustment** dialog box, which allows you to select the color adjustment target from **Image**, **Graphics**, and **Text**.
- **9.** Close the **Color Settings** dialog box.
- 10. Click the Page Setup tab to display the Page Setup sheet.



11. Confirm the settings of \triangle Page Size, \bot Paper Source, and so on.

12. Confirm the print settings and print as desired.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "

Fine-Tuning Colors of Photos and Images (Mac OS X)


You can specify your own print settings instead of using the **Print Target** presets. This topic describes how to fine-tune the color tone of photos before printing.

1. This sets the **B** Format for and **C** Paper Size.



Note

• The configuration method varies depending on the OS and application software you are using. If **Page Setup** is displayed in the application menu, the settings are configured by opening the **Page Attributes** dialog box from **Page Setup**.




If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.




- 2. Select the printer in the A Printer list.
- **3.** Choose the original size in the **F** Paper Size list.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.




- **6.** In the **A Media Type** list, select the type of paper that is loaded.
- **7.** Click **D** Advanced Settings to switch the print mode.



8. Click Color in the H Color Mode list.

9. Click | Set to display the Color Settings dialog box.



10. On the Color Adjustment pane, adjust the color tones, brightness, and so on as desired.

| Adjustment Item | Description | |
|---------------------|--|--|
| D Cyan | Fine-tune color tones by adjusting the levels of Cyan, Magenta, and Yellow. | |
| E Magenta | | |
| F Yellow | | |
| G Gray Tone | Adjust the gray tone to suit the images of monochrome photos. Choose cool black (tinged with blue), pure black (neutral), warm black (tinged with red), and so on. Select the color tone in the color region or from the list. | |
| H Brightness | Adjust the brightness of printed images while keeping the darkest and lightest portions intact. | |
| Contrast | Adjust the contrast of the darkest and lightest portions relative to each other. For soft gradation, decrease the contrast. For hard gradation, increase the contrast. | |
| J Saturation | Adjust the level of color saturation, in a range from subdued to vivid. | |




Note

• Click **Object Adjustment** to open the **Object Adjustment** dialog box, which allows you to select the color adjustment target from **Images**, **Graphics**, and **Text**.

11. Click **OK** to close the **Color Settings** dialog box.

12. Access the **Page Setup** pane.



- 13. Confirm the settings of A Paper Source and C Page Size.
- 14. Confirm the print settings, and then click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) P.492 "

Giving Priority to Particular Graphic Elements and Colors for Printing

You can specify detailed print settings as desired for the quality level, colors, and other criteria.

Advanced Settings

For printing results that appear just as expected for your original, you can specify which graphic elements and colors to prioritize for printing.



Note

• Easy Settings are also available, providing convenient presets. To use the presets, simply choose the printing application.

For details on **Easy Settings**, refer to the following topics.

- Printing Photos and Images →P.22
- Printing Line Drawings and Text →P.47
- Printing Office Documents →P.38

Print Priority

Choose the graphic elements that you want to emphasize for printing.

| Print Priority (*1) | Description | |
|---------------------|---|--|
| Image | A setting for posters or other documents made up mainly of photos or images, or for emphasizing photos or images in printed documents. | |
| Line Drawing/Text | Choose this setting for CAD drawings made up mainly of intricate lines, or to enhance the finishing of fine text. However, the quality may not be sufficient when printing photos or images that require a lot of color coverage. In this case, choose Image instead. | |
| Office Document | Choose this setting for better legibility of documents combining text and graphics, such as documents and presentation material created with typical office applications. | |
| Proof | This is a setting for enhancing the reproduction of text, illustrations, and photos on print proofs. However, this takes more time than regular printing. | |

^{*1:} Options suitable for the selected type of paper are listed under Print Priority.

Print Quality

Choose the print quality.

The printing mode is determined by a combination of the print quality and resolution.

| Print Quality (*1) | Description | Print Priority |
|--------------------|---|--|
| High | Choose this setting to print at high resolution when quality is most important. Printing takes longer and consumes more ink than in Standard or Fast modes, but this mode offers exceptional printing quality. | Image Line Drawing/Text Proof |
| Standard | Choose this setting to print at standard resolution when quality and speed are both important. Printing takes less time than in High mode. | Image Line Drawing/Text Office Document Proof |
| Fast | Choose this setting to print faster. Printing in fast mode can help you work more efficiently when checking layouts. | Image Line Drawing/Text Proof |

^{*1:} Options suitable for the selected Print Priority are listed under Print Quality.

Color Settings

| Setting Item | Options | Description |
|-----------------------------|--|---|
| Color Mode (*1) | Color Monochrome (Photo) Monochrome No color correction | Choose whether to print in color or monochrome. (Refer to "Adjusting the Color in the Printer Driver →P.55") |
| Color Adjustment (Images) | Cyan | You can adjust the levels of cyan, ma- |
| Color Adjustment (Graphics) | Magenta Yellow | genta, and yellow as well as the brightness, contrast, saturation, and gray tone |
| Color Adjustment (Text) | Gray Tone | separately for images, graphics, and |
| | Brightness | text documents. |
| | Contrast | If you choose Monochrome in Color |
| | Saturation | Mode only Brightness and Contrast can be adjusted. |

| Setting Item | Options | Description |
|----------------------------|--|--|
| Gray Adjustment | Color Balance Brightness Contrast Highlight Shadow | Choose the gray tone color balance (Cool Black or Warm Black) and adjust levels of brightness, contrast, highlight, and shadow as desired. These levels can be adjusted when Monochrome (Photo) is selected in Color Mode. |
| Color-Matching Modes | Driver Matching Mode ICC Matching Mode | Choose the color-matching mode. Other color-matching modes may be provided by the computer operating system, such as ICM and ColorSync. |
| Color-Matching Method (*2) | Auto Perceptual Saturation Monitor Matching Colorimetric other | Choose the color-matching method. The available options vary depending on your selection in Color-Matching Mode. |
| Color Space (*3) | sRGB Adobe RGB | Choose a standard color space (sRGB) or an expanded color space (Adobe RGB). |

^{*1:} Options suitable for the selected **Print Priority** and **Media Type** are listed under **Color Mode**.

Enhancing printing quality

| Setting Item | Description | |
|--------------------------------|---|--|
| Highest quality | This prints at the highest resolution. Printing takes longer and consumes more ink than in other modes, but this mode offers superior printing quality. | |
| Thicken Fine Lines | Prints making fine lines appear thicker. | |
| Unidirectional Printing | Prints by suppressing color variations and misaligned ruled lines. However, this takes more time than regular printing. | |
| Economy Printing | When this mode is selected, the quality is diminished from that of regular printing, however less ink is consumed. Select this mode if you want to conserve ink when printing to check drawings, for example. Depending on the Media Type and Print Quality settings, this mode may not be available. | |



Note

• To print at a higher level of quality, in the printer driver, choose **High** in **Print Quality**, and select **Highest quality** and print.

For instructions on specifying the print quality and color settings before printing, refer to the following topics, as appropriate for your computer and operating system.

- Choosing the Document Type and Printing Conditions (Windows) →P.67
- Choosing the Document Type and Printing Conditions (Mac OS X) →P.70


^{*2:} The order of options displayed varies depending on the operating system.

^{*3:} Adobe RGB is not available if an incompatible combination of the paper type and print quality is selected.

Choosing the Document Type and Printing Conditions (Windows)


You can specify your own print settings instead of using the **Print Target** presets. This topic describes how print photographic images in monochrome.

- 1. Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (Refer to "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")
- **3.** Make sure the **Main** sheet is displayed.




4. In the **A Media Type** list, select the type of paper that is loaded.

5. Click DAdvanced Settings to switch the print mode.



- **6.** Click **Image** in the **E Print Priority** list.
- 7. Click High (600dpi) in the F Print Quality list.



• Options displayed in the **F Print Quality** list vary depending on the type of paper.


- **8.** Click **Monochrome** in the **G** Color **Mode** list.
- **9.** To adjust the brightness and contrast, click **H** Color Settings.




Note

Note

For instructions on adjusting brightness and contrast, see "Adjusting the Color in the Printer Driver."





- 11. Confirm the settings of A Page Size, L Paper Source, and so on.
- 12. Confirm the print settings and print as desired.




Note

• For details on how to check the printing settings, refer to "Confirming Print Settings (Windows) ".

Choosing the Document Type and Printing Conditions (Mac OS X)


You can specify your own print settings instead of using the **Print Target** presets. This topic describes how print photographic images in monochrome.

1. Choose Page Setup from the application menu to display the Page Attributes dialog box.




- 2. Select the printer in the B Format for list.
- **3.** Choose the original size in the **C** Paper Size list.
- **4.** Click **FOK** to close the dialog box.
- **5.** In the application menu, choose **Print**.

6. Access the **Main** pane.



- 7. In the A Media Type list, select the type of paper that is loaded.
- **8.** Click **D** Advanced Settings to switch the print mode.



9. Click Image in the E Print Priority list.

10. Click High (600dpi) in the F Print Quality list.




Note

- Options displayed in the **F Print Quality** list vary depending on the paper type.
- **11.** Click **Monochrome** in the **H** Color **Mode** list.
- 12. To adjust the brightness and contrast, click | Set.



Note

- For instructions on adjusting brightness and contrast, see "Adjusting the Color in the Printer Driver —P.55"
- 13. Access the Page Setup pane.



- 14. Confirm the settings of A Paper Source and C Page Size.
- 15. Confirm the print settings, and then click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) →P.492 "

Printing enlargements or reductions

| Resizing Originals to Match the Paper Size | 73 |
|---|----|
| Resizing Originals to Match the Paper Size (Windows) | |
| Resizing Originals to Match the Paper Size (Mac OS X) | |
| Resizing Originals to Fit the Roll Width | 79 |
| Resizing Originals to Fit the Roll Width (Windows) | 79 |
| Resizing Originals to Fit the Roll Width (Mac OS X) | |
| Resizing Originals by Entering a Scaling Value | 85 |
| Resizing Originals by Entering a Scaling Value (Windows) | 86 |
| Resizing Originals by Entering a Scaling Value (Mac OS X) | |
| | |

Resizing Originals to Match the Paper Size


You can freely adjust the size of originals by enlarging or reducing them as desired.

• Enlarged/Reduced Printing

Enlarge or reduce the original in the printer driver, as desired.

Fit Paper Size

Enlarge or reduce the original to match the size of the paper you are using.



For instructions on resizing originals to match the paper size, refer to the following topics, as appropriate for your computer and operating system.

- Resizing Originals to Match the Paper Size (Windows) —P.73
- Resizing Originals to Match the Paper Size (Mac OS X) P.75



Note


• For better printing results when enlarging photos from a digital camera in TIFF or JPEG format, use an image-editing application software such as Adobe Photoshop to specify an image resolution of 150 dpi or more at actual size.

Resizing Originals to Match the Paper Size (Windows)

This topic describes how to enlarge originals before printing to match the paper size, based on the following example.


- Document: Any Type
- Page size: A4 (210.0×297.0mm)/Letter (8.3 × 11.7 in)

- Paper: Roll
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) P.211")
- **3.** Make sure the **Main** sheet is displayed.



- **4.** In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. Select the printing application in the **E** Print Target list.

6. Click the Page Setup tab to display the Page Setup sheet.



- 7. Select and click a roll paper in the L Paper Source list.
- 8. Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 9. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4.
- 10. Select the C Enlarged/Reduced Printing check box.
- 11. Select the D Fit Paper Size check box.
- 12. Click ISO A3 in the G Paper Size list.
- 13. Confirm the print settings and print as desired.



Note


• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "

Resizing Originals to Match the Paper Size (Mac OS X)

This topic describes how to enlarge originals before printing to match the paper size, based on the following example.


- Document: Any Type
- Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- · Paper: Roll paper

- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.




- 6. In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. Make your selection in the **EPrint Target** list.
- **8.** Make your selection in the **F Print Quality** list.
- 9. Access the Page Setup pane.




10. Select and click a roll paper in the A Paper Source list.

11. Make sure the width of the loaded roll is displayed in the B Roll Width list—in this case, ISO A2/A3 (420.0mm).



12. Make sure C Page Size on the Page Setup pane shows the original size as specified in C Paper Size in the Page Attributes dialog box—in this case, ISO A4.



- **78**
- 13. Select the DEnlarged/Reduced Printing check box.
- **14.** Make sure **E** Fit Paper Size is selected.
- 15. Click ISO A3 in the Paper Size list.

16. Confirm the print settings, and then click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) P.492 "

Resizing Originals to Fit the Roll Width


You can freely adjust the size of originals by enlarging or reducing them as desired.

• Enlarged/Reduced Printing

Enlarge or reduce the original in the printer driver, as desired.

• Fit Roll Paper Width

Enlarge or reduce the original as a whole to match the roll paper width, as desired.



For instructions on resizing originals to match the roll paper width, refer to the following topics, as appropriate for your computer and operating system.

- Resizing Originals to Fit the Roll Width (Windows) →P.79
- Resizing Originals to Fit the Roll Width (Mac OS X) →P.82



Note

• For better printing results when enlarging photos from a digital camera in TIFF or JPEG format, use an image-editing application software such as Adobe Photoshop to specify an image resolution of 150 dpi or more at actual size.

Resizing Originals to Fit the Roll Width (Windows)

This topic describes how to enlarge originals before printing to match the roll width, based on the following example.

• Document: Any type

• Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)


· Paper: Roll

• Paper type: Plain Paper

• Roll paper width: 16 inches (406.4 mm)

,


- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")
- **3.** Make sure the **Main** sheet is displayed.



- **4.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. Select the printing application in the **EPrint Target** list.



6. Click the Page Setup tab to display the Page Setup sheet.




- 7. Select and click a roll paper in the Paper Source list.
- 8. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").

9. Select the C Enlarged/Reduced Printing check box.



Note

• If the C Enlarged/Reduced Printing check box is not displayed on the Page Setup sheet, clear the B Borderless Printing check box.



10. Click E Fit Roll Paper Width.



Note

- After you click **E** Fit Roll Paper Width, the Information dialog box is displayed. Select the width of the loaded roll in the Roll Paper Width list and click OK.
- Make sure the roll paper width you specify matches the width of the loaded roll.
- 11. Confirm the print settings and print as desired.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "

Resizing Originals to Fit the Roll Width (Mac OS X)

This topic describes how to enlarge originals before printing to match the roll width, based on the following example.

• Document: Any Type


• Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])

• Paper: Roll paper

• Paper type: Plain Paper


• Roll paper width: 16 inches (406.4 mm)

1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.



- **6.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. Make your selection in the E Print Target list.
- **8.** Make your selection in the **F Print Quality** list.
- **9.** Access the **Page Setup** pane.




10. Select and click a roll paper in the A Paper Source list.

11. Make sure the width of the loaded roll is displayed in the B Roll Width list—in this case, 16 in. (406.4mm).



Note

- If the width of the roll loaded in the printer is not shown in B Roll Width, click Printer Information on the Main pane to update the printer information.
- 12. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, ISO A4.



- 13. Select the DEnlarged/Reduced Printing check box.
- 14. Click F Fit Roll Paper Width.
- 15. Confirm the print settings, and then click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) →P.492 "

Resizing Originals by Entering a Scaling Value


You can freely adjust the size of originals by enlarging or reducing them as desired.

• Enlarged/Reduced Printing

Enlarge or reduce the original in the printer driver, as desired.

Scaling

Enlarge or reduce originals by a particular amount, as desired.



For instructions on entering a scaling value to resize originals, refer to the following topics, as appropriate for your computer and operating system.

- Resizing Originals by Entering a Scaling Value (Windows) →P.86
- Resizing Originals by Entering a Scaling Value (Mac OS X) →P.88



Note

• For better printing results when enlarging photos from a digital camera in TIFF or JPEG format, use an image-editing application software such as Adobe Photoshop to specify an image resolution of 150 dpi or more at actual size.

Resizing Originals by Entering a Scaling Value (Windows)

This topic describes how to enlarge originals before printing by entering a scaling value, based on the following example.

- Document: Any Type
- Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- · Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])




Important


• In borderless printing, you cannot resize originals by entering a scaling value.

- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")

3. Make sure the **Main** sheet is displayed.



- **4.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. Select the printing application in the **EPrint Target** list.
- 6. Click the Page Setup tab to display the Page Setup sheet.




- 7. Select and click a roll paper in the **L** Paper Source list.
- 8. Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 9. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4.
- 10. Select the C Enlarged/Reduced Printing check box.
- 11. Click ISO A4 in the G Paper Size list.
- 12. Click F Scaling and enter 120.



Note

- You can specify enlargement that exceeds the paper size, but in this case, the portions off the bottom and right edges of the paper will not be printed.
- If the original size after enlargement or reduction is smaller than the paper size, the original is printed in the upper-left corner. In this case, you can center originals by selecting **E Print Centered** on the **Layout** sheet.



13. Confirm the print settings and print as desired.



Note


• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "

Resizing Originals by Entering a Scaling Value (Mac OS X)

This topic describes how to enlarge originals before printing by entering a scaling value, based on the following example.


• Document: Any Type

- Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- · Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- 1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4.
- 4. If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.




- **6.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. Make your selection in the **E** Print Target list.
- **8.** Make your selection in the **F Print Quality** list.
- **9.** Access the **Page Setup** pane.




10. Select and click a roll paper in the A Paper Source list.

11. Make sure the width of the loaded roll is displayed in the BRoll Width list—in this case, ISO A2/A3 (420.0mm).



12. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, ISO A4.



13. Select the DEnlarged/Reduced Printing check box.

14. Click G Scaling and enter 120.



Note

- You can specify enlargement that exceeds the paper size, but in this case, the portion off the edge of the paper will not be printed.
- If the original size after enlargement or reduction is smaller than the paper size, the original is printed in the upper-left corner. In this case, you can center originals by selecting the **J Print Centered** check box.
- 15. Confirm the print settings, and then click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) P.492 "

Printing at full size

| Printing on Oversized Paper | 93 |
|---|-----|
| Printing at Full Size (Windows) | |
| Printing at Full Size (Mac OS X) | |
| - | |
| Borderless Printing at Actual Size | 100 |
| Borderless Printing at Actual Size (Windows) | 101 |
| Borderless Printing at Actual Size (Mac OS X) | |

Printing on Oversized Paper

Except in borderless printing, the actual printing area corresponds to your selected paper size minus the space for a margin (See "Print Area —P.1126"). To print documents or images you prepare without a margin at actual size, use an oversized paper size.

For example, to print a A4-sized original without a margin at A4 size, print it on paper larger than A4 size and cut away the excess margin.




Note

• If you prepare an original for printing without a margin and print it on paper of regular size, the image near the edge will not be printed.

Oversize

The margin required by the printer is added around the **outside** of a regular paper size. For example, when printing a A4-sized original (210×297 mm), you have the following options.



- (a) Regular paper size: Gray area not printed
- (b) Page Size
- (c) Oversized paper size: Print area matches the page size (b)



Important

- When printing on oversize paper, load paper larger than the page size—a size that includes the margin required by the printer.
 - Sheets: Load paper that is at least 10 mm (0.39 in) wider and 28 mm (1.10 in) higher than the page size
 - Rolls: Load paper that is at least 10 mm (0.39 in) wider and 10 mm (0.39 in) higher than the page size



Note

- Paper larger than the maximum size supported by the printer cannot be used as paper for oversized printing.(See "Paper Sizes P.775")
- Oversized printing (selecting **Oversize** in **Page Size**) is only available in Windows.
- To perform oversized printing on a Macintosh computer, you must specify a non-standard page size and print on it.
- To specify a non-standard paper size in oversized printing, register the paper size as a Custom Paper Size. Oversized printing is not available with **Custom Size**. (See "Printing on Non-Standard Paper Sizes —P.131")

For instructions on oversized printing, refer to the following topics, as appropriate for your computer and operating system.

- Printing at Full Size (Windows) →P.94
- Printing at Full Size (Mac OS X) →P.96


Printing at Full Size (Windows)

This topic describes how to print at full size based on the following example. (Oversized Printing)


- Document: Any Type
- Page Size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- · Paper: Roll
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) (>P.211)")



3. Make sure the **Main** sheet is displayed.



- **4.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. Click the Page Setup tab to display the Page Setup sheet.



6. Click Osize Options to display the Paper Size Options dialog box.

- 7. In the Paper Size Options dialog box, select the Oversize check box in Display Series.
- **8.** Click **OK** to close the **Paper Size Options** dialog box.
- 9. Click Oversize ISO A4 in the A Page Size list.
- 10. Select and click a roll paper in the L Paper Source list.
- 11. Select the width of the loaded roll in the NRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 12. Confirm the print settings and print as desired.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Windows) —P.207 "

Printing at Full Size (Mac OS X)

This topic describes how to print at full size based on the following example. (Oversized Printing)

• Document: Any Type


• Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])

• Paper: Roll paper

• Paper type: Plain Paper


• Roll paper width: A2/A3 roll (420.0 mm [16.5 in])

1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In F Paper Size, click the size of the original. In this case, click ISO A4 Oversize.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.




- 6. In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. Make your selection in the **E Print Target** list.
- **8.** Make your selection in the **F Print Quality** list.
- **9.** Access the **Page Setup** pane.




10. Select and click a roll paper in the A Paper Source list.

11. Make sure the width of the loaded roll is displayed in the BRoll Width list—in this case, ISO A2/A3 (420.0mm).



12. Make sure C Page Size shows the original size as specified in C Paper Size in the Page Attributes dialog box—in this case, ISO A4 - Oversize.



13. Confirm the print settings, and then click M Print to start printing.



Borderless Printing at Actual Size

Take advantage of borderless printing to print documents such as posters (made up mainly of photos or images) without a surrounding margin, or border.

· Borderless Printing

In regular printing, a margin required by the printer is added around the original. With borderless printing, you can print documents without the margin, so that the printed image covers the entire surface of the paper.



Important


- Borderless printing is only available with rolls.
- Always set the blue Switch on the Platen to the side for borderless printing. Printing quality may be affected if the Switch is incorrectly set.
- Paper you can use for borderless printing is restricted to particular types of paper and rolls of particular widths. For information on types of paper compatible with borderless printing, refer to the Paper Reference Guide. (See "Types of Paper" —P.774")
- Paper incompatible with the printer's auto cut function can be printed without borders on the left and right sides only.
- These features cannot be used in combination with borderless printing: special page layouts, centering originals, and printing cut lines on rolls.
- If **Fit Paper Size** or **Print Image with Actual Size** (Windows only) is selected when performing borderless printing, **Rotate Page 90 degrees** (**Conserve Paper**) cannot be selected.
- When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be uneven at the edges. If you require higher image quality, specify **No** in **Auto Cut** in the printer driver. In this case, the paper can be printed without borders on the left and right sides only. After ejecting and cutting the printed document, use scissors to cut away the top and bottom edges.
- When CutDustReduct. is set to On, print without borders only on the left and right sides.
- When you are using paper that takes longer for ink to adhere for borderless printing and the Cutter Unit touches printing surfaces that are not dry yet, it may damage the paper or the edge of the document that is cut, depending on frequency of use. In this case, follow these steps to change the ink drying time.
 - On the Main sheet of the printer driver, click Settings in Media Type.
 - Select the ink drying time in the **Between Pages** list of **Drying Time**.

Borderless Printing Method

Choose the method of borderless printing that suits the original, as desired.

· Print Image with Actual Size

Prints originals at actual size, without enlarging or reducing them. Originals must be prepared in a size that exceeds the dimensions of the paper by 3 mm (0.12 in) on each side.





Note

- Not all page sizes are available.
- Even if you prepare originals of the same size as the paper size, the originals are automatically enlarged when you print borderlessly in combination with resizing originals to match the paper size. This may affect image quality. When image quality is most important, make the original 3 mm longer on each side than the paper size so that the image can be printed at actual size in borderless printing.

For instructions on borderless printing of photos and images at actual size, refer to the following topics, as appropriate for your computer and operating system.

- Borderless Printing at Actual Size (Windows) →P.101
- Borderless Printing at Actual Size (Mac OS X) →P.103

Borderless Printing at Actual Size (Windows)

This topic describes how to print borderlessly at actual size based on the following example.


- Document: Any type
- Page size: 10×12 inches (254.0×304.8 mm)
- · Paper: Roll
- Paper type: Heavyweight Coated Paper
- Roll paper width: 10 inches (254.0 mm)
- 1. Create the original in the source application 3 mm (0.12 in) larger on each side than 254.0×304.8 mm (10×12 in) —that is, 260.0×310.8 mm (10.2×12.2 in)




Note

- If you can specify the margin, as in Microsoft Word, set the margin at 0 mm. For instructions on specifying the margin, refer to the software documentation.
- The extra 3 mm (0.12 in) on each side will not be printed. Create the original so that it fits inside the paper area to be printed on.
- **2.** Choose **Print** in the application menu.
- 3. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")


4. Make sure the **Main** sheet is displayed.




- 5. In the A Media Type list, select the type of paper that is loaded. In this case, click Heavyweight Coated Paper.
- 6. Select the print target in the **EPrint Target** list.
- 7. Click the Page Setup tab to display the Page Setup sheet.



- 8. In the A Page Size list, click the size of the original as specified in the source application. In this case, click 10"x12".
- 9. Select and click a roll paper in the Paper Source list.
- 10. Select the Borderless Printing check box to display the Information dialog box.



- 11. Select the width of the loaded roll in the Roll Paper Width list—in this case, click 10-in. Roll (254.0mm).
- 12. Click **OK** to close the **Information** dialog box.
- 13. In C Borderless Printing Method, click F Print Image with Actual Size.
- **14.** Confirm the print settings and print as desired.



Borderless Printing at Actual Size (Mac OS X)

This topic describes how to print borderlessly at actual size based on the following example.


- Document: Any Type
- Page size: 10 × 12 inches (254.0×304.8 mm)–Borderless
- · Paper: Roll paper
- Paper type: Heavyweight Coated Paper

- Roll paper width: 10 inches (254.0 mm)
- 1. This sets the ${\color{red}\mathsf{B}}$ Format for and ${\color{red}\mathsf{C}}$ Paper Size.




Note

The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.



- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, choose a paper size supported for borderless printing. Here, click 10"x12" Borderless.




Note


• Paper sizes supported for borderless printing are indicated by —**Borderless**.

4. If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the **Main** pane.




- **6.** In the A Media Type list, select the type of paper that is loaded. In this case, click Heavyweight Coated Paper.
- 7. Make your selection in the **EPrint Target** list.
- **8.** Make your selection in the **F Print Quality** list.
- **9.** Access the **Page Setup** pane.




10. Select and click a roll paper in the A Paper Source list.

11. Confirm that the roll paper width matches the paper size.

Make sure the width of the loaded roll is displayed in the B Roll Width list—in this case, 10 in. (254.0mm).



12. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, 10"x12" - Borderless.



13. Confirm the print settings, and then click M Print to start printing.



Borderless Printing

| Borderless Printing on Paper of Equivalent Size | 107 |
|--|-----|
| Borderless Printing by Resizing Originals to Match the Paper Size (Windows) | |
| Borderless Printing by Resizing Originals to Match the Paper Size (Mac OS X) | |
| Borderless Printing by Resizing Originals to Fit the Roll Width | 114 |
| Borderless Printing by Resizing Originals to Fit the Roll Width (Windows) | |
| Borderless Printing by Resizing Originals to Fit the Roll Width (Mac OS X) | |

Borderless Printing on Paper of Equivalent Size

Take advantage of borderless printing to print documents such as posters (made up mainly of photos or images) without a surrounding margin, or border.

Borderless Printing

In regular printing, a margin required by the printer is added around the original. With borderless printing, you can print documents without the margin, so that the printed image covers the entire surface of the paper.



Important


- Borderless printing is only available with rolls.
- Always set the blue switch on the platen to the side for borderless printing. Printing quality may be affected if the switch is incorrectly set.
- Paper you can use for borderless printing is restricted to particular types of paper and rolls of particular widths. For information on types of paper compatible with borderless printing, refer to the Paper Reference Guide. (Refer to "Types of Paper —P.774")
- Paper incompatible with the printer's auto cut function can be printed without borders on the left and right sides only.
- These features cannot be used in combination with borderless printing: special page layouts, centering originals, and printing cut lines on rolls.
- If Fit Paper Size or Print Image with Actual Size (Windows only) is selected when performing borderless printing, Rotate Page 90 degrees (Conserve Paper) cannot be selected.
- When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be slightly uneven at the edges. If you require higher image quality, specify No in Auto Cut in the printer driver. In this case, the paper can be printed without borders on the left and right sides only. Cut the printed document ejected from the printer, then use scissors to cut away the edges on the top and bottom.
- When CutDustReduct. is set to On, print without borders only on the left and right sides.
- When you are using paper that takes longer for ink to adhere for borderless printing and the Cutter Unit touches printing surfaces that are not dry yet, it may damage the paper or the edge of the document that is cut, depending on frequency of use. In this case, follow these steps to change the ink drying time.
 - On the Main sheet of the printer driver, click Settings in Media Type.
 - Select the ink drying time in the **Between Pages** list of **Drying Time**.

Borderless Printing Method

Choose the method of borderless printing that suits the original, as desired.

· Fit Paper Size

Enlarge or reduce the original to match the size of the paper you are using.





Note

• The printer driver automatically enlarges originals 3 mm (0.12 in) past the dimensions of the paper on each side. The 3 mm portion beyond the edge on each side is not printed.

For instructions on borderless printing of photos, images, and other documents to match the paper size, refer to the following topics, as appropriate for your computer and operating system.

- Borderless Printing by Resizing Originals to Match the Paper Size (Windows) →P.108
- Borderless Printing by Resizing Originals to Match the Paper Size (Mac OS X) →P.110

Borderless Printing by Resizing Originals to Match the Paper Size (Windows)

This topic describes how to enlarge originals before borderless printing to match the paper size, based on the following example.

• Document: Any type

• Page size: 10×12 inches (254.0×304.8 mm)

· Paper: Roll

• Paper type: Heavyweight Coated Paper

• Roll paper width: 10 inches (254.0 mm)


1. In the application, create an original that takes up the entire space of the paper size.




Note

- If you can specify the margin, as in Microsoft Word, set the margin at 0 mm. For instructions on specifying the margin, refer to the software documentation.
- **2.** Choose **Print** in the application menu.
- 3. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")


4. Make sure the **Main** sheet is displayed.



- 5. In the A Media Type list, select the type of paper that is loaded. In this case, click Heavyweight Coated Paper.
- **6.** Select the print target in the **E Print Target** list.
- 7. Click the Page Setup tab to display the Page Setup sheet.



- 8. In the A Page Size list, click the size of the original as specified in the application. In this case, click 10"x12".
- **9.** Select and click a roll paper in the **L** Paper Source list.
- 10. Select the Borderless Printing check box to display the Information dialog box.



- 11. Select the width of the loaded roll in the Roll Paper Width list—in this case, click 10-in. Roll (254.0mm).
- 12. Click **OK** to close the **Information** dialog box.
- 13. In C Borderless Printing Method, click D Fit Paper Size.
- 14. Click Match Page Size in the G Paper Size list.
- 15. Confirm the print settings and print as desired.



Note


• For tips on confirming print settings, see "Confirming Print Settings (Windows) —P.207 "

Borderless Printing by Resizing Originals to Match the Paper Size (Mac OS X)

This topic describes how to enlarge originals before borderless printing to match the paper size, based on the following example.

- Document: Any Type
- Page size: 10×12 inches (254.0×304.8 mm)

- · Paper: Roll paper
- Paper type: Heavyweight Coated Paper
- Roll paper width: 10 inches (254.0 mm)
- 1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click 10"x12".




• All sizes are available in borderless printing if you resize originals to match the paper size.

4. If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.




- **6.** In the A Media Type list, select the type of paper that is loaded. In this case, click Heavyweight Coated Paper.
- 7. Make your selection in the E Print Target list.
- **8.** Make your selection in the **F Print Quality** list.
- **9.** Access the **Page Setup** pane.




10. Select and click a roll paper in the A Paper Source list.

11. Make sure the width of the loaded roll is displayed in the B Roll Width list—in this case, 10 in. (254.0mm).



12. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, 10"x12".



- 13. On the Page Setup pane, select the DEnlarged/Reduced Printing check box.
- **14.** Select the **H** Borderless Printing check box.
- 15. Click E Fit Paper Size under D Enlarged/Reduced Printing.
- 16. In Paper Size, click the paper size. In this case, click 10"x12" Borderless.

17. Confirm the print settings, and then click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) P.492 "

Borderless Printing by Resizing Originals to Fit the Roll Width

Take advantage of borderless printing to print documents such as posters (made up mainly of photos or images) without a surrounding margin, or border.

Borderless Printing

In regular printing, a margin required by the printer is added around the original. With borderless printing, you can print documents without the margin, so that the printed image covers the entire surface of the paper.



Important


- Borderless printing is only available with rolls.
- Always set the blue Switch on the Platen to the side for borderless printing. Printing quality may be affected if the Switch is incorrectly set.
- Paper you can use for borderless printing is restricted to particular types of paper and rolls of particular widths. For information on types of paper compatible with borderless printing, refer to the Paper Reference Guide. (See "Types of Paper P.774")
- Paper incompatible with the printer's auto cut function can be printed without borders on the left and right sides only.
- These features cannot be used in combination with borderless printing: special page layouts, centering originals, and printing cut lines on rolls.
- If **Fit Paper Size** or **Print Image with Actual Size** (Windows only) is selected when performing borderless printing, **Rotate Page 90 degrees** (**Conserve Paper**) cannot be selected.
- When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be uneven at the edges. If you require higher image quality, specify **No** in **Auto Cut** in the printer driver. In this case, the paper can be printed without borders on the left and right sides only. After ejecting and cutting the printed document, use scissors to cut away the top and bottom edges.
- When CutDustReduct. is set to On, print without borders only on the left and right sides.
- When you are using paper that takes longer for ink to adhere for borderless printing and the Cutter Unit touches printing surfaces that are not dry yet, it may damage the paper or the edge of the document that is cut, depending on frequency of use. In this case, follow these steps to change the ink drying time.
 - On the Main sheet of the printer driver, click Settings in Media Type.
 - Select the ink drying time in the **Between Pages** list of **Drying Time**.

Borderless Printing Method

Choose the method of borderless printing that suits the original, as desired.

· Scale to fit Roll Paper Width

Enlarge or reduce the original as a whole to match the roll paper width.





Note

• You can combine this function with rotating pages 90 degrees before printing so that the original width (relative to portrait orientation) matches the roll paper width in borderless printing.

For instructions on borderless printing of photos, images, and other documents to match the roll paper width, refer to the following topics, as appropriate for your computer and operating system.

- Borderless Printing by Resizing Originals to Fit the Roll Width (Windows) →P.115
- Borderless Printing by Resizing Originals to Fit the Roll Width (Mac OS X) -P.117

Borderless Printing by Resizing Originals to Fit the Roll Width (Windows)

This topic describes how to enlarge originals before borderless printing to match the roll width, based on the following example.


- Document: Any type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- Paper: Roll
- Paper type: Heavyweight Coated Paper
- Roll paper width: 10 inches (254.0 mm)
- $oldsymbol{1}$. In the application, create an original that takes up the entire space of the paper size.




Note

- If you can specify the margin, as in Microsoft Word, set the margin at 0 mm. For instructions on specifying the margin, refer to the software documentation.
- **2.** Choose **Print** in the application menu.
- 3. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) (>P.211)")


4. Make sure the **Main** sheet is displayed.



- 5. In the A Media Type list, select the type of paper that is loaded. In this case, click Heavyweight Coated Paper.
- **6.** Select the print target in the **E** Print Target list.
- 7. Click the Page Setup tab to display the Page Setup sheet.



- 8. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").
- 9. Select and click a roll paper in the Paper Source list.
- 10. Select the Borderless Printing check box to display the Information dialog box.



- 11. Select the width of the loaded roll in the Roll Paper Width list—in this case, click 10-in. Roll (254.0mm).
- 12. Click **OK** to close the **Information** dialog box.
- 13. In C Borderless Printing Method, make sure E Scale to fit Roll Paper Width is selected.
- **14.** Confirm the print settings and print as desired.



Borderless Printing by Resizing Originals to Fit the Roll Width (Mac OS X)

This topic describes how to enlarge originals before borderless printing to match the roll width, based on the following example.

- Document: Any Type
- Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- · Paper: Roll paper
- Paper type: Heavyweight Coated Paper


- Roll paper width: 10 inches (254.0 mm)
- ${f 1}_{f \cdot}$ This sets the ${f B}$ Format for and ${f C}$ Paper Size.



Note

• The configuration method varies depending on the OS and application software you are using.

If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.



If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4.




Note

- All sizes are available in borderless printing if you resize originals to fit the roll width.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the **Main** pane.




- **6.** In the A Media Type list, select the type of paper that is loaded. In this case, click Heavyweight Coated Paper.
- 7. Make your selection in the **EPrint Target** list.
- **8.** Make your selection in the **F Print Quality** list.
- **9.** Access the **Page Setup** pane.




10. Select and click a roll paper in the A Paper Source list.

11. Make sure the width of the loaded roll is displayed in the Broll Width list—in this case, 10 in. (254.0mm).



12. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, ISO A4.



- 13. Select the DEnlarged/Reduced Printing check box.
- 14. Select the H Borderless Printing check box.
 This ensures that F Fit Roll Paper Width is automatically selected in D Enlarged/Reduced Printing.

15. Confirm the print settings, and then click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) →P.492 "

Printing banners or at other non-standard sizes

| Printing Vertical or Horizontal Banners (Large-Format Printing) | 122 |
|---|-----|
| Printing Vertical or Horizontal Banners (Large-Format Printing; Windows) | 123 |
| Printing Vertical or Horizontal Banners (Large-Format Printing; Mac OS X) | |
| Printing on Non-Standard Paper Sizes | 131 |
| Printing on Non-Standard Paper Sizes (Windows) | |
| Printing on Non-Standard Paper Sizes (Mac OS X) | |

Printing Vertical or Horizontal Banners (Large-Format Printing)


On this printer, large-format printing of up to 18.0 m is available using rolls.

If you use Print Plug-In for Office or PosterArtist, you can easily print maximum 18.0 m vertical or horizontal banners. (Refer to "Print Plug-In for Office features —P.373" and "Using PosterArtist to Compose Originals —P.44".) However, you may not be able to print 18.0 m due to restrictions in the settable document size according to the application software.

Fit Roll Paper Width

To match the width of vertical and horizontal banners with the width of rolls, use the printer driver function for automatically enlarging/reducing and printing.

For example, if you automatically enlarge a document created with application software such as Microsoft Word, you can print the full width of the roll easily.



For instructions on printing vertical or horizontal banners, refer to the following topics, as appropriate for your computer and operating system.

- Printing Vertical or Horizontal Banners (Large-Format Printing; Windows) —P.123



122

Important

- Before printing, check how much of the roll paper is left. If you have activated automatic detection of the remaining roll paper, a warning message is displayed when there is not enough roll paper left.
- If not much ink is left, prepare replacement ink tanks.
- To print at a higher level of quality, in the printer driver, choose **High** in Print Quality, and choose **Unidirectional Printing** as the direction of printing.

Printing Vertical or Horizontal Banners (Large-Format Printing; Windows)

By automatic enlargement of a document created with an application software by the printer driver, you can print maximum 18.0 m vertical or horizontal banners.

However, you may not be able to print 18.0 m due to restrictions in the settable document size according to the application software.

This topic describes how to print a banner about five times as long as the roll width based on the following example.

- Document: A horizontal banner created in Microsoft Word
- Page size: Non-standard (100×500 mm [3.9×19.7 in])
- · Paper: Roll
- Paper type: Plain Paper
- Roll paper width: 16 in (406.4 mm)

The print procedure is as follows.


- Register a Custom Paper Size in the printer driver.
 Call a non-standard paper size registered in the printer driver with Custom Paper Size.
 Once you register Custom Paper Size, you then can select it repeatedly from the paper size list.
 Custom Paper Size can be set up to 18.0 m.
- **2.** In the application, create an original in the size you registered.
- **3.** Print the banner, using the settings that correspond to banners.

Registering a Custom Paper Size

This example describes how to register a paper size that is horizontally elongated and suitable for banners in either horizontal or vertical format.

1. Display the printer driver dialog box.(See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) P.213")

2. Click the Page Setup tab to display the Page Setup sheet.



- 3. Select and click a roll paper in the **L** Paper Source list.
- **4.** Click Osize Options to display the Paper Size Options dialog box.
- 5. Enter a desired paper name in Custom Paper Size Name. My Horizontal Banner is used in this example.
- 6. In Units, click mm.
- 7. Under Paper Size, enter 100 in Width and 500 in Height.
- **8.** Click **Add** to add the paper size of **My Horizontal Banner**.
- 9. Click OK to close the Paper Size Options dialog box.
- 10. Close the printer driver dialog box.



124

Note

• Although you can even set **Custom Size** for the paper size, the maximum settable size is 3.2 m. The setting of **Custom Size** is disabled when you exit the application software.

For more information, see "Printing on Non-Standard Paper Sizes (Windows) —P.132 "

Creating the banner in the application

Follow the steps below to create the banner in Microsoft Word using the Custom Paper Size you registered.

1. Start Microsoft Word.

- 2. Choose Page Setup from the File menu to display the Page Setup dialog box.
- 3. Under Paper Size, click the Custom Paper Size you registered—My Horizontal Banner in this example.




Important

- If My Horizontal Banner is not listed, make sure this printer is selected as the printer to use.
- In applications such as Microsoft PowerPoint that do not enable you to choose registered paper sizes, use the custom paper size setting in **Custom** and specify 100×500 mm (3.9×19.7 in)
- **4.** Set the printing orientation to horizontal.
- **5.** Create the banner.

Printing the banner


Follow these steps to print the banner using the corresponding banner settings.

- ${f 1}_{f \cdot}$ Choose **Print** in the Microsoft Word menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")
- **3.** Make sure the **Main** sheet is displayed.




- **4.** In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. After confirming that D Easy Settings is selected, click Poster in the E Print Target list.

6. Click the Page Setup tab to display the Page Setup sheet.



- 7. In the A Page Size list, click the size you registered, My Horizontal Banner.
- 8. Select the C Enlarged/Reduced Printing check box.




- 9. Select and click a roll paper in the **L** Paper Source list.
- 10. After you click **E** Fit Roll Paper Width, the Information dialog box is displayed.
- 11. Select the width of the loaded roll in the Roll Paper Width list. In this case, click 16-in. Roll (406.4mm), and then click OK.
- **12.** Confirm the print settings and print as desired.




If printing is unsuccessful, you may be able to print after completing the following setting.

1. On the Layout sheet, click J Special Settings to display the Special Settings dialog box.



2. In the FineZoom Settings list, click Yes.



Printing Vertical or Horizontal Banners (Large-Format Printing; Mac OS X)

By automatic enlargement of a document created with an application software by the printer driver, you can print maximum 18.0 m vertical or horizontal banners.

This topic describes how to print a banner about five times as long as the roll width based on the following example.

- Document: An original designed for a horizontal banner
- Page Size: Non-standard (100×500 mm [3.9×19.7 in])
- · Paper: Roll
- Paper type: Plain Paper
- Roll paper width: 16 inches (406.4 mm)

The print procedure is as follows.

- 1. In the application, create an original in the format of a horizontal or vertical banner.
- 2. In Page Setup, register Custom Page Sizes (Mac OS X 10.4.11–10.5) / Custom Paper Sizes (Mac OS X 10.6).

 Once you register Custom Page Sizes / Custom Paper Sizes, you then can select it repeatedly from the paper size list.

 Custom Page Sizes / Custom Paper Sizes can be set up to 18.0 m.
- **3.** Print the banner, using the settings that correspond to banners.



Note

• The following procedures are based on Mac OS X 10.5. The method of setting up non-standard paper sizes varies depending on the version of Mac OS X.

Register a Custom Page Sizes

This example describes how to register and print using a page size that is horizontally elongated and suitable for banners in either horizontal or vertical format.

- **1.** Create the document in the application.
- **2.** Choose **Print** in the application menu.




128

3. Select the printer in the A Printer list.

Cancel

OK



4. Click Manage Custom Sizes in the C Paper Size list to display the Custom Page Sizes dialog box.

- 5. Double-click Untitled in the list at left, and then enter a name for the page size you want to register. Here, enter 100*500.
 - If the **Untitled** size is not listed at left, click + below the list.

?


- **6.** Under Page Size, enter 10 in Width and 50 in Height. Here, measurements are entered in centimeters.
- 7. Specify the margins by entering **0.3** in **Printer Margins**. Here, too, measurements are entered in centimeters.
- **8.** Click **OK** to close the **Custom Page Sizes** dialog box.
- 9. In the C Paper Size list, click the size of the original. In this case, click 100*500, the size you registered.
- 10. In Orientation, click the icon of the document in landscape orientation.
- 11. Click **FOK** to close the dialog box.

Print the banner


Follow the steps below to print the banner using the corresponding banner settings.

1. Choose **Print** in the application menu.

2. Access the Main pane.




- 3. In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- **4.** Make your selection in the **EPrint Target** list.
- **5.** Make your selection in the **F Print Quality** list.
- **6.** Access the **Page Setup** pane.



7. Select and click a roll paper in the A Paper Source list.

8. Make sure the width of the loaded roll is displayed in the B Roll Width list—in this case, 16 in. (406.4mm).



- 9. In C Page Size, make sure 100*500 is displayed, as registered in Page Setup.
- 10. Select the DEnlarged/Reduced Printing check box.
- 11. Click F Fit Roll Paper Width.
- 12. Confirm the print settings, and click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) →P.492 "

Printing on Non-Standard Paper Sizes

For printing on non-standard size paper, first register the paper size in the printer driver.

Once you register a paper size, you then can select it repeatedly from the paper size list. The paper size can be set up to 18.0 m.



Note

• In Windows, although you can even set **Custom Size** for the paper size, the maximum settable size is 3.2 m. The setting of **Custom Size** is disabled when you exit the application software.

For instructions on specifying non-standard paper sizes for printing, refer to the following topics, as appropriate for your computer and operating system.

- Printing on Non-Standard Paper Sizes (Windows) →P.132
- Printing on Non-Standard Paper Sizes (Mac OS X) →P.135

Printing on Non-Standard Paper Sizes (Windows)

For printing on non-standard size paper, first register the paper size in the printer driver. Call a non-standard paper size registered in the printer driver with Custom Paper Size. Once you register Custom Paper Size, you then can select it repeatedly from the paper size list. Custom Paper Size can be set up to 18.0 m.




Note

• Although you also can set **Custom Size** for the paper size temporarily, the maximum settable size is 3.2 m. Also, the setting of **Custom Size** is disabled when you exit the application software.


Registering and Printing With a Custom Paper Size

This topic describes how to register a non-standard paper size by the name of **430 mm Square**and print based on the following example.

- Document: Any Type
- Page Size: A square sheet $(430 \times 430 \text{ mm} [16.9 \times 16.9 \text{ in}])$
- Paper: Sheets
- Media Type: Any type
- Paper Size: A square sheet $(430 \times 430 \text{ mm} [16.9 \times 16.9 \text{ in}])$
- 1. Load the square paper $(430 \times 430 \text{ mm} [16.9 \times 16.9 \text{ in}])$ in the printer.
- **2.** Choose **Print** in the application menu.
- 3. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")
- **4.** Make sure the **Main** sheet is displayed.



- 5. In the A Media Type list, select the type of paper that is loaded.
- 6. After confirming that D Easy Settings is selected, select from the E Print Target list.
- 7. Click the Page Setup tab to display the Page Setup sheet.



- 8. Click Osize Options to display the Paper Size Options dialog box.
- 9. Enter a desired paper name in Custom Paper Size Name. 430 mm Square is used in this example.
- 10. Select mm in Units.
- 11. Enter 430 (16.9 in) in both Width and Height.



Note

- If you select the **Fix the Ratio of the Width to Height** check box, after you enter a value in either **Width** or **Height**, the other value will be automatically applied based on the original aspect ratio.
- 12. Click Add to register 430 mm Square.
- 13. Click OK to close the Paper Size Options dialog box.
- 14. Click Cut Sheet in the L Paper Source list.
- 15. In the A Page Size list, click the size you added,430 mm Square.

16. Confirm the print settings and print as desired.




• For tips on confirming print settings, see "Confirming Print Settings (Windows) -P.207"

Printing by using Custom Size


This section describes how to print using **Custom Size** based on the following example.

- Document: Any Type
- Page size: Square of non-standard dimensions (430×430 mm [16.9×16.9 in])
- Paper: Sheets
- Paper type: Any type
- Paper Size: A square sheet $(430 \times 430 \text{ mm} [16.9 \times 16.9 \text{ in}])$
- **1.** Load the square paper $(430 \times 430 \text{ mm} [16.9 \times 16.9 \text{ in}])$ in the printer.
- **2.** Choose **Print** in the application menu.
- 3. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) →P.211 ")
- **4.** Make sure the **Main** sheet is displayed.




- 5. In the A Media Type list, select the type of paper that is loaded.
- **6.** After confirming that **D** Easy Settings is selected, select from the **E** Print Target list.

7. Click the Page Setup tab to display the Page Setup sheet.



- 8. Click Cut Sheet in the L Paper Source list.
- 9. Click Custom Size in the A Page Size list to display the Custom Size Settings dialog box.
- **10.** Confirm that **mm** is selected in **Units**.
- 11. Enter 430 (16.9 in) in both Width and Height.
- 12. Click OK to close the Custom Size Settings dialog box.
- 13. Confirm the print settings and print as desired.



Printing on Non-Standard Paper Sizes (Mac OS X)

For printing on non-standard size paper, first register the paper size in the printer driver.

Call a non-standard paper size registered in the printer driver with **Custom Page Sizes** (Mac OS X 10.4.11-10.5)/ **Custom Paper Sizes** (Mac OS X 10.6).

Once you register Custom Page Sizes / Custom Paper Sizes, you then can select it repeatedly from the paper size list. Custom Page Sizes / Custom Paper Sizes can be set up to 18.0 m.

This topic describes how to register a non-standard paper size by the name of **430*430** and print based on the following example.


• Document: Any Type

- Page Size: A square sheet $(430 \times 430 \text{ mm} [16.9 \times 16.9 \text{ in}])$
- · Paper: Sheets
- Media Type: Any type
- Paper Size: A square sheet (430 × 430 mm [16.9 × 16.9 in])




Note

- The following procedures are based on Mac OS X 10.5. The method of setting up non-standard paper sizes varies depending on the version of Mac OS X.
- 1. Create the document in the application.
- 2. Load the square paper $(430 \times 430 \text{ mm} [16.9 \times 16.9 \text{ in}])$ in the printer.
- **3.** Choose **Print** in the application menu.




- **4.** Select the printer in the **A Printer** list.
- 5. Click Manage Custom Sizes in the C Paper Size list to display the Custom Page Sizes dialog box.




6. In Page Size, enter the height and width of the original. Here, enter 43.00 cm in Height and Width.

- 7. In **Printer Margins**, enter **0.5** for the top and side margins and **2.3** for the bottom margin. Here, measurements are entered in centimeters.
- 8. Double-click **Untitled** in the list at left in the **Custom Page Sizes** dialog box and enter the paper name—in this case, 430*430.
- 9. Click OK to close the Custom Page Sizes dialog box.
- 10. In the C Paper Size list, click the size of the original. In this case, click 430*430, the size you registered.
- 11. If you configured the settings using the Page Attributes dialog box, click FOK to close the dialog box, and then select Print from the application software menu.
- 12. Access the Main pane.



- 13. In the A Media Type list, select the type of paper that is loaded.
- 14. After confirming that D Easy Settings is selected, select from the E Print Target list.
- 15. Make your selection in the F Print Quality list.

16. Access the Page Setup pane.



- 17. Click Cut Sheet in the A Paper Source list.
- 18. In C Page Size, make sure 430*430 is displayed, as registered in Page Setup.
- 19. Confirm the print settings, and then click M Print to start printing.



Tiling and multiple pages per sheet


| Printing Multiple Originals Next to Each Other | 139 |
|---|-----|
| Printing Multiple Originals Next to Each Other (Windows) | |
| Printing Multiple Originals Next to Each Other (Mac OS X) | |
| Printing Multiple Pages Continuously | 144 |
| Printing Multiple Pages Continuously (Windows) | |
| Printing Multiple Pages Continuously (Mac OS X) | |
| Printing Multiple Pages Per Sheet | 149 |
| Printing Multiple Pages Per Sheet (Windows) | |
| Printing Multiple Pages Per Sheet (Mac OS X) | |
| Printing Posters in Sections | 156 |
| Printing Large Posters (Windows) | |
| e e , , , , , , , , , , , , , , , , , , | |

Printing Multiple Originals Next to Each Other

By arranging originals from word-processing or spreadsheet programs or web browser screen shots next to each other on single sheets, you can create highly expressive presentation materials, easy-to-understand meeting materials, and a variety of other printed documents.

• Free Layout (Windows)

Besides combining multiple pages in a single-page layout, you can combine originals from multiple files—even multiple source applications—in a single-page layout.






Note

• Free Layout cannot be used in 64-bit version of Windows.

• imagePROGRAF Free Layout (Macintosh)

Besides combining multiple pages in a single-page layout, you can combine originals from multiple files—even multiple source applications—in a single-page layout.



For instructions on arranging originals from multiple applications, refer to the following topics.

- Printing Multiple Originals Next to Each Other (Windows) —P.140
- Printing Multiple Originals Next to Each Other (Mac OS X) →P.142

Printing Multiple Originals Next to Each Other (Windows)


This topic describes how to arrange multiple originals using the Free Layout function.




Note

- Free Layout cannot be used in 64-bit version of Windows.
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) P.211")

3. Make sure the **Main** sheet is displayed.




4. Click the **Layout** tab to display the **Layout** sheet.



- 5. Select the A Page Layout check box.
- 6. Click Free Layout in the A Page Layout list.

7. When you attempt to print, the imagePROGRAF Free Layout window is displayed. (At this point, the document will not be printed yet.)



8. Edit and rearrange the image in the imagePROGRAF Free Layout window as desired.



Note

- Without closing the imagePROGRAF Free Layout window, repeat steps 1–7 to arrange originals from multiple applications on the same page.
- For instructions on editing and rearranging images, refer to the imagePROGRAF Free Layout help topic.
- **9.** Print from the imagePROGRAF Free Layout menu.



Note


• For details on imagePROGRAF Free Layout functions, refer to Free Layout P.261 .

Printing Multiple Originals Next to Each Other (Mac OS X)


This topic describes how to use the Free Layout function to arrange multiple originals next to each other before printing.

1. Choose **Print** in the application menu.

2. Access the Page Setup pane.



- 3. Select the N Free Layout check box.
- 4. Click M Print.
- 5. The Canon imagePROGRAF Free Layout window is displayed.



6. Edit and rearrange the image in the **Canon imagePROGRAF Free Layout** window as desired.



Note

- Without closing the **Canon imagePROGRAF Free Layout** window, repeat steps 1 to 4 to arrange originals from multiple applications on the same page.
- For instructions on editing and rearranging images, refer to the Canon imagePROGRAF Free Layout help topic.
- 7. Print from the Canon imagePROGRAF Free Layout menu.




Note

• For details on Canon imagePROGRAF Free Layout functions, refer to Free Layout P.550 .

Printing Multiple Pages Continuously

You can print multiple pages as a single continuous image, without margins between pages.

• Roll paper (banner)





Important

- This feature is only available with rolls. It cannot be used when printing on sheets.
- During banner printing, settings for conserving paper, number of copies, borderless printing, enlargement or reduction, and other layout-related settings are disregarded.

For instructions on borderless printing of photos and images at actual size, refer to the following topics, as appropriate for your computer and operating system.

- Printing Multiple Pages Continuously (Windows) →P.145
- Printing Multiple Pages Continuously (Mac OS X) →P.147


Printing Multiple Pages Continuously (Windows)

This topic describes how to print multiple pages as a single continuous image, without margins between pages.




Important

- This feature is only available with rolls. It cannot be used when printing on sheets.
- During banner printing, settings for conserving paper, number of copies, borderless printing, enlargement or reduction, and other layout-related settings are disregarded.
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) P.211 ")
- **3.** Make sure the **Main** sheet is displayed.




4. In the **A Media Type** list, click the type of paper that is loaded.

5. Click the Page Setup tab to display the Page Setup sheet.



- **6.** Select and click a roll paper in the **L Paper Source** list.
- 7. Click N Roll Paper Options to display the Roll Paper Options dialog box.



- 8. Select the Banner Printing check box.
- 9. Click OK.
- 10. Confirm the print settings and print as desired.



Printing Multiple Pages Continuously (Mac OS X)

This topic describes how to print multiple pages as a single continuous image, without margins between pages.



Important


- This feature is only available with rolls. It cannot be used when printing on sheets.
- During banner printing, settings for conserving paper, number of copies, borderless printing, enlargement or reduction, and other layout-related settings are disregarded.
- 1. This sets the **B** Format for and **C** Paper Size.




Note

• The configuration method varies depending on the OS and application software you are using.

If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.




If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.




- 2. Select the printer in the A Printer list.
- **3.** Click the original size in the **C** Paper Size list.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.



- **6.** In the **A Media Type** list, click the type of paper that is loaded.
- 7. Make your selection in the E Print Target list.
- **8.** Make your selection in the **F Print Quality** list.
- **9.** Access the **Page Setup** pane.



10. Click Roll Paper (Banner) in the A Paper Source list.

11. Confirm the print settings, and then click M Print to start printing.




Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) →P.492 "

Printing Multiple Pages Per Sheet

To conserve paper, you can print several pages of the original on a single sheet by reducing the original and dividing the sheet into areas for each page.



Page Layout

Specify a number of pages of the original to print on a single sheet, in a layout of multiple pages per sheet.



Important

- This function cannot be combined with the following options.
 - Borderless Printing
 - Scaling Originals (Windows)
 - Banner Printing (Windows)
- When printing using this function, the **Print Centered** setting is disabled.



Note

- You can print up to 16 pages of the original on a single sheet.
- You can also change the page layout order and print page boundary lines, as desired.

For instructions on printing multiple pages per sheet, refer to the following topics, as appropriate for your computer and operating system.


- Printing Multiple Pages Per Sheet (Windows) —P.149
- Printing Multiple Pages Per Sheet (Mac OS X) →P.152

Printing Multiple Pages Per Sheet (Windows)


This topic describes how to print four pages of originals together on a single sheet based on the following example.


- Document: Any Type
- Page size: A3 (297.0×420.0 mm [11.7×16.5 in])
- Paper: Roll

- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) P.211")
- **3.** Make sure the **Main** sheet is displayed.




- **4.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. Make your selection in the **EPrint Target** list.
- **6.** Make your selection in the **F Print Quality** list.





- 8. In A Page Size, click the size of the original as specified in the application software. In this case, click ISO A3 or Letter (8.5"x11").
- **9.** Select and click a roll paper in the **L Paper Source** list.
- 10. Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).

11. Click the **Layout** tab to display the **Layout** sheet.



- 12. Select the A Page Layout check box.
- 13. Click 4 Pages/Sheet in the A Page Layout list.



Note

- You can select the layout order for placing four pages on a sheet and a frame border in the Page Layout Printing dialog box by clicking B Set.
- 14. Confirm the print settings and print as desired.



Note


• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "

Printing Multiple Pages Per Sheet (Mac OS X)

This topic describes how to print four pages of an original on a single sheet, based on the following example.


- Document: Any Type
- Page size: A3 (297.0 \times 420.0 mm [11.7 \times 16.5 in])
- · Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])

1. This sets the **B** Format for and **C** Paper Size.



- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A3.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Layout pane.




6. Click 4 in the A Pages per Sheet list.



Note


• You can choose the layout order and specify a boundary line for the four pages in **B Layout Direction** and **C Border**.

7. Access the Main pane.




- 8. In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- **9.** Make your selection in the **E Print Target** list.
- 10. Make your selection in the F Print Quality list.


11. Access the Page Setup pane.



- 12. Select and click a roll paper in the A Paper Source list.
- 13. Make sure the width of the loaded roll is displayed in the B Roll Width list—in this case, ISO A2/A3 (420.0mm).



14. Make sure C Page Size shows the original size as specified in C Paper Size in the Page Attributes dialog box—in this case, ISO A3.



15. Confirm the print settings, and then click M Print to start printing.




Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) —P.492 "

Printing Posters in Sections

You can enlarge an original to print it in sections on several sheets. By assembling the printed sheets, you can create a poster larger than the maximum supported paper size of the printer.



Page Layout

Choose poster printing.



Important

• When printing using this function, the Print Centered, Watermark, No Spaces at Top or Bottom (Conserve Paper), and Page Options settings are disabled.

For instructions on printing large posters, refer to the following topics, as appropriate for your computer and operating system.

Printing Large Posters (Windows) →P.157



Note

• This method of poster printing is supported in Windows.

Printing Large Posters (Windows)

You can enlarge an original to print it in sections on several sheets. By assembling the printed sheets, you can create a poster larger than the maximum supported paper size of the printer. This topic describes how to enlarge an A2 original for printing it in sections on four sheets, based on the following example.


· Document: Poster

• Page size: A2 (420.0 \times 594.0 mm [16.5 \times 23.4 in])

• Paper: Sheets


• Paper Size: A2 (420.0 × 594.0 mm [16.5 × 23.4 in])

- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) P.211 ")
- **3.** Make sure the **Main** sheet is displayed.




- **4.** In the **A Media Type** list, select the type of paper that is loaded.
- 5. Click Poster in the E Print Target list.

6. Click the **Page Setup** tab to display the **Page Setup** sheet.



- 7. In A Page Size, click the size of the original as specified in the application. In this case, click ISO A2.
- 8. Click Cut Sheet in the L Paper Source list.
- **9.** Click the **Layout** tab to display the **Layout** sheet.



- 10. Select the A Page Layout check box.
- 11. Click Poster (2 x 2) in the A Page Layout list.



Note

- Follow the steps below to print only a portion of the poster as divided for printing.
 - Click B Set under A Page Layout to display the Pages to Print dialog box.
 - On the Pages to Print dialog box, clear the check boxes of the portion you do not want to print.
 - Click **OK** to close the **Pages to Print** dialog box.
- 12. Confirm the print settings and print as desired.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "

Centering originals

| Printing Originals Centered on Rolls | 160 |
|--|-----|
| Printing Originals Centered on Rolls (Windows) | |
| Printing Originals Centered on Rolls (Mac OS X) | |
| Printing Originals Centered on Sheets | 166 |
| Printing Originals Centered on Sheets (Windows) | |
| Printing Originals Centered on Sheets (Mac OS X) | 169 |

Printing Originals Centered on Rolls


You can print originals centered on a page—for example, if the paper is larger than the original, or if you are reducing the original.

· Centering originals relative to roll paper width

If you use originals smaller than the roll paper width, you can center them relative to the width when printing.

Print Centered

Aligns the center of the original with the center of the roll, relative to the width.



For instructions on centering originals when printing on rolls, refer to the following topics, as appropriate for your computer and operating system.


- Printing Originals Centered on Rolls (Windows) →P.160
- Printing Originals Centered on Rolls (Mac OS X) →P.162

Printing Originals Centered on Rolls (Windows)


This topic describes how to center originals before printing on rolls based on the following example.

- Document: Any type
- Page size: A4 (210.0×297.0 mm)/Letter (8.3 × 11.7 in)
- · Paper: Roll
- Paper type: Plain Paper
- Roll width: A3/A4 roll (297.0 mm [11.7 in])
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")


3. Make sure the **Main** sheet is displayed.



- **4.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. Select the print target in the **EPrint Target** list.
- **6.** Click the **Page Setup** tab to display the **Page Setup** sheet.



- 7. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").
- **8.** Select and click a roll paper in the **L Paper Source** list.
- 9. Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A3/A4 Roll (297.0mm).
- 10. Click the Layout tab to display the Layout sheet.



- 11. Select the E Print Centered check box.
- 12. Confirm the print settings and print as desired.



Note


• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "

Printing Originals Centered on Rolls (Mac OS X)

This topic describes how to center originals before printing on rolls based on the following example.


- Document: Any Type
- Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- · Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A3/A4 roll (297.0 mm [11.7 in])

1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.




- **6.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. Make your selection in the **E** Print Target list.
- **8.** Make your selection in the **F Print Quality** list.
- **9.** Access the **Page Setup** pane.




10. Select and click a roll paper in the A Paper Source list.

11. Make sure the width of the loaded roll is displayed in Broll Width—in this case, ISO A3/A4 (297.0mm).



12. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, ISO A4.



- 13. Select the J Print Centered check box.
- 14. Confirm the print settings, and then click M Print to start printing.



Printing Originals Centered on Sheets


You can print originals centered on a page—for example, if the paper is larger than the original, or if you are reducing the original.

· Centering originals on sheets

If you use paper larger than the original size or print originals after reduction, the printed images may be aligned in the upper-left corner of the paper. In this case, you can center originals on sheets when printing.

Print Centered

Aligns the center of the original with the center of the sheet.



For instructions on centering originals when printing on sheets, refer to the following topics, as appropriate for your computer and operating system.


- Printing Originals Centered on Sheets (Windows) —P.166
- Printing Originals Centered on Sheets (Mac OS X) →P.169

Printing Originals Centered on Sheets (Windows)


This topic describes how to reduce an original 50% for printing centered on a sheet.

- Document: Any Type
- Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- Paper: Sheets
- Paper type: Plain Paper
- Paper size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) (-P.211)")


3. Make sure the **Main** sheet is displayed.



- **4.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. Make your selection in the **EPrint Target** list.
- 6. Click the Page Setup tab to display the Page Setup sheet.



- 7. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4.
- 8. Select the C Enlarged/Reduced Printing check box.
- 9. Click Match Page Size in the G Paper Size list.
- 10. Click F Scaling and enter 50.
- 11. Click Cut Sheet in the L Paper Source list.
- 12. Click the Layout tab to display the Layout sheet.



- 13. Select the EPrint Centered check box.
- 14. Confirm the print settings and print as desired.



Importan^{*}

• If you have selected **Cut Sheet** as the paper source, follow the instructions on the printer control panel to enter the paper size.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Windows) —P.207 "

Printing Originals Centered on Sheets (Mac OS X)

This topic describes how to center originals for printing on sheets, based on the following example.


• Document: Any Type

Page size: A4Paper: Sheets


Paper type: Plain PaperPaper size: Non-standard

Note

1. This sets the **B** Format for and **C** Paper Size.




If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4 Cut Sheet.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.




- **6.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. Make your selection in the **E** Print Target list.
- **8.** Make your selection in the **F Print Quality** list.
- **9.** Access the **Page Setup** pane.



10. Click Cut Sheet in the A Paper Source list.

11. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, ISO A4 - Cut Sheet.



- 12. Select the J Print Centered check box.
- 13. Confirm the print settings, and then click M Print to start printing.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) →P.492 "



Important

• If you have selected **Cut Sheet** as the paper source, follow the instructions on the printer control panel to enter the paper size.

Conserving roll paper


| Conserving Roll Paper by Rotating Originals 90 Degrees | 172 |
|---|-----|
| Conserving Roll Paper by Rotating Originals 90 Degrees (Windows) | |
| Conserving Roll Paper by Rotating Originals 90 Degrees (Mac OS X) | |
| Conserving Roll Paper by Printing Originals Without Top and Bottom Margins | 178 |
| Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Windows) | 178 |
| Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Mac OS X) | 180 |

Conserving Roll Paper by Rotating Originals 90 Degrees

You can conserve roll paper by specifying particular settings as suitable for your original.

• Rotate Page 90 degrees (Conserve Paper)

When originals are printed in portrait orientation, the original is rotated 90 degrees before printing if it fits within the roll width. This enables you to conserve paper.





Important

• If the page would exceed the roll paper width after rotation, use this function with Scale to fit Roll Paper Width to print rotated pages.

For tips on conserving roll paper, refer to the following topics, as appropriate for your computer and operating system.

- Conserving Roll Paper by Rotating Originals 90 Degrees (Windows) →P.172
- Conserving Roll Paper by Rotating Originals 90 Degrees (Mac OS X) →P.174

Conserving Roll Paper by Rotating Originals 90 Degrees (Windows)

This topic describes how to conserve paper by rotating originals 90 degrees before printing, based on the following example.

• Document: Any type

• Page size: A4 (210.0×297.0 mm)/Letter (8.3×11.7 in)

· Paper: Roll


• Paper type: Plain Paper

• Roll paper width: A3/A4 roll (297.0 mm [11.7 in])


This example illustrates how to rotate an A4 ($210.0 \times 297.0 \text{ mm}$)/Letter ($8.3 \times 11.7 \text{ in}$) original in portrait orientation 90 degrees to fit within the width of A3/A4 roll paper (297.0 mm [11.7 in]), which enables you to conserve paper.

1. Choose **Print** in the application menu.

- 2. Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")
- **3.** Make sure the **Main** sheet is displayed.



- 4. In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. Click the Page Setup tab to display the Page Setup sheet.



- 6. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").
- 7. Select and click a roll paper in the **L** Paper Source list.
- 8. Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A3/A4 Roll (297.0mm).
- 9. Select the K Rotate Page 90 degrees (Conserve Paper) check box.
- 10. Confirm the print settings and print as desired.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Windows) —P.207 "

Conserving Roll Paper by Rotating Originals 90 Degrees (Mac OS X)

This topic describes how to conserve roll paper by rotating originals 90 degrees before printing, based on the following example.

• Document: Any Type

• Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])


· Paper: Roll paper

• Paper type: Plain Paper

• Roll paper width: A3/A4 roll (297.0 mm [11.7 in])


This example illustrates how to rotate an A4 ($210.0 \times 297.0 \text{ mm}$)/Letter ($8.3 \times 11.7 \text{ in}$) original in portrait orientation 90 degrees to fit within the width of A3/A4 roll (297.0 mm [11.7 in]), which enables you to conserve paper.

1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.




- **6.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. Access the Page Setup pane.




8. Select and click a roll paper in the **A Paper Source** list.

9. Make sure the width of the loaded roll is displayed in Broll Width—in this case, ISO A3/A4 (297.0mm).



10. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, ISO A4.



- 11. Select the LRotate Page 90 degrees check box.
- 12. Confirm the print settings, and then click M Print to start printing.




Conserving Roll Paper by Printing Originals Without Top and Bottom Margins

You can conserve roll paper by specifying particular settings as suitable for your original.

No Spaces at Top or Bottom (Conserve Paper)

You can print without feeding the paper for blank portions of originals if there are top and bottom margins in originals. This enables you to conserve as much paper as the size of the margins.





Important

- Printing without the top and bottom margins is not supported in the following cases.
 - · Banner printing
 - If you have chosen poster as the type of page layout



Note

- Even during borderless printing, you can print without the top and bottom margins.
- Printing without the top and bottom margins may cause inconsistency in the size of printed documents, depending on the layout of images or text in your originals.

For tips on conserving roll paper, refer to the following topics, as appropriate for your computer and operating system.

- Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Windows) →P.178
- Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Mac OS X)

 →P.180

Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Windows)

This topic describes how to conserve roll paper when printing originals that have a top and bottom margin, based on the following example.

• Document: Any type

• Page size: A4 (210.0×297.0mm)/Letter (8.3 × 11.7 in)


• Paper: Roll

• Paper type: Plain Paper


• Roll paper width: A3/A4 roll (297.0 mm [11.7 in])

- 1. Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) P.211")

3. Make sure the **Main** sheet is displayed.




- **4.** In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 5. Click the Page Setup tab to display the Page Setup sheet.



6. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").

- 7. Select and click a roll paper in the **L** Paper Source list.
- 8. Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A3/A4 Roll (297.0mm).
- **9.** Click the **Layout** tab to display the **Layout** sheet.



- 10. Select the GNo Spaces at Top or Bottom (Conserve Paper) check box.
- 11. Confirm the print settings and print as desired.



Note

• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "

Conserving Roll Paper by Printing Originals Without Top and Bottom Margins (Mac OS X)

This topic describes how to conserve roll paper when printing originals that have a top and bottom margin, based on the following example.

• Document: Any Type


• Page size: A4 (210.0 × 297.0 mm [8.3 × 11.7 in])

• Paper: Roll paper

• Paper type: Plain Paper


• Roll paper width: A3/A4 roll (297.0 mm [11.7 in])

1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the Main pane.




- 6. In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- 7. Access the Page Setup pane.




8. Select and click a roll paper in the **A Paper Source** list.

9. Make sure the width of the loaded roll is displayed in Broll Width—in this case, ISO A3/A4 (297.0mm).



10. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, ISO A4.



- 11. Select the KNo Spaces at Top or Bottom check box.
- 12. Confirm the print settings, and then click M Print to start printing.




Checking Images Before Printing

Checking the Layout in a Preview Before Printing

You can check the print layout on the preview screen.

• Open Preview When Print Job Starts (Windows)

While viewing the preview screen, you can also adjust orientation or other settings, and your changes will be instantly applied on the preview screen.






Note

• Under some settings and in some environments, PageComposer may be started.

• Preview (Macintosh)

While viewing the preview screen, you can also adjust layout or size settings, and your changes will be instantly applied on the preview screen.



For instructions on how to check the layout before printing, refer to the following topics:

- Checking the Layout in a Preview Before Printing (Windows) →P.208
- Checking the Layout in a Preview Before Printing (Mac OS X) →P.493

Other useful settings

| Printing With Watermarks | 186 |
|--|-----|
| Printing with Watermarks— COPY, FILE COPY, and so on (Windows) | 187 |
| Making the Original Orientation Match the Paper Orientation | 190 |
| Making the Original Orientation Match the Paper Orientation (Windows) | 190 |
| Making the Original Orientation Match the Paper Orientation (Mac OS X) | |
| Using Favorites | 196 |
| Cutting Roll Paper After Printing | 196 |
| Cutting Roll Paper After Printing (Windows) | 196 |
| Cutting Roll Paper After Printing (Mac OS X) | |
| J , , , , , , , , , , , , , , , , , , , | |

Printing With Watermarks

You can add watermarks (background images) to documents that require special handling.





Watermark

Watermarks are applied to all pages of your document.



Important

• Watermarks are not printed if you select poster as the type of page layout.

The following watermarks are provided:

- CONFIDENTIAL
- COPY
- DRAFT
- FILE COPY
- FINAL
- PRELIMINARY
- PROOF
- TOP SECRET

You can also create your own watermarks. Specify the following options to customize your watermark.

- Watermark string: Specify the font, size, color, and so on. Surround the watermark with a frame, if desired.
- Watermark position: Specify the position on the page, the angle, and so on.

Watermark printing method: Specify whether to print the watermark superimposed or under the document image.
 You can also print the watermark only on the first page, if desired.



Note

- Watermarks are supported in Windows.
- In addition to the provided watermarks, you can create up to 50 original watermarks in Windows.

For detailed instructions on printing with watermarks, refer to the following topics:

Printing with Watermarks— COPY, FILE COPY, and so on (Windows) →P.187

Printing with Watermarks— COPY, FILE COPY, and so on (Windows)

This topic describes how to print with watermarks, based on the following example of printing with a **FILE COPY** watermark.

• Document: Any type


• Page size: A2 (420.0 \times 594.0 mm [16.5 \times 23.4 in])

· Paper: Roll paper

• Paper type: Plain Paper

• Roll paper width: A2/A3 roll (420.0 mm [16.5 in[)


- 1. Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")
- **3.** Make sure the **Main** sheet is displayed.



- **4.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- **5.** Make your selection in the **E Print Target** list.




6. Click the Page Setup tab to display the Page Setup sheet.



- 7. In A Page Size, click the size of the original as specified in the application software. In this case, click ISO A2.
- **8.** Select and click a roll paper in the **L** Paper Source list.
- 9. Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).

10. Click the Layout tab to display the Layout sheet.



- 11. Select the C Watermark check box.
- 12. Click FILE COPY in the Watermarks list.



Note

- Click DEdit Watermark to open the Edit Watermark dialog box. In the Edit Watermark dialog box, you can create custom watermarks and change the position and angle of watermarks.
- 13. Confirm the print settings and print as desired.



Note


• For tips on confirming print settings, see "Confirming Print Settings (Windows) →P.207 "

Making the Original Orientation Match the Paper Orientation

You can specify the original orientation to match the orientation of the paper for printing.

Orientation

Paper is usually loaded in the printer in portrait orientation. When you have an original in landscape orientation, you can specify the printing orientation so that the original is printed in landscape orientation.



Rotate 180 degrees

The original is rotated 180 degrees to print it upside down.

Mirror

A mirror image of the original is printed.

For instructions on specifying the original orientation before printing, refer to the following topics, as appropriate for your computer and operating system.


- Making the Original Orientation Match the Paper Orientation (Windows) →P.190
- Making the Original Orientation Match the Paper Orientation (Mac OS X) →P.192

Making the Original Orientation Match the Paper Orientation (Windows)

This topic describes how to print an original in landscape orientation after matching the paper orientation, based on the following example.


- Document: An original in landscape orientation
- Page size: A4 (210.0 × 297.0 mm)/Letter (8.3 × 11.7 in)
- · Paper: Roll
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then open the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) P.211 ")

3. Make sure the **Main** sheet is displayed.




- **4.** In the **A Media Type** list, select the type of paper that is loaded. In this case, click Plain Paper.
- **5.** Make your selection in the **E Print Target** list.
- **6.** Make your selection in the **F Print Quality** list.

7. Click the Page Setup tab to display the Page Setup sheet.



- 8. In the A Page Size list, click the size of the original as specified in the application. In this case, click ISO A4 or Letter (8.5"x11").
- 9. In H Orientation, click J Landscape.
- 10. Select and click a roll paper in the L Paper Source list.
- 11. Select the width of the loaded roll in the MRoll Paper Width list—in this case, ISO A2/A3 Roll (420.0mm).
- 12. Confirm the print settings and print as desired.




Making the Original Orientation Match the Paper Orientation (Mac OS X)

This topic describes how to print an original in landscape orientation after matching the paper orientation, based on the following example.


- Document: An original in landscape orientation
- Page size: A4 (210.0 \times 297.0 mm [8.3 \times 11.7 in])
- · Paper: Roll paper
- Paper type: Plain Paper
- Roll paper width: A2/A3 roll (420.0 mm [16.5 in])

1. This sets the **B** Format for and **C** Paper Size.




- 2. Select the printer in the A Printer list.
- 3. In the F Paper Size list, click the size of the original. In this case, click ISO A4.
- **4.** In **D** Orientation, click the icon of the document in landscape orientation.
- 5. If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

6. Access the **Main** pane.




- 7. In the A Media Type list, select the type of paper that is loaded. In this case, click Plain Paper.
- **8.** Make your selection in the **E Print Target** list.
- **9.** Make your selection in the **F Print Quality** list.
- 10. Access the Page Setup pane.




11. Select and click a roll paper in the A Paper Source list.

12. Make sure the width of the loaded roll is displayed in the BRoll Width list—in this case, ISO A2/A3 (420.0mm).



13. Make sure the C Page Size setting matches the original size as selected in C Paper Size in the Page Attributes dialog box—in this case, ISO A4.



14. Confirm the print settings, and then click M Print to start printing.



Using Favorites

You can register print settings as **Favorites** to reuse settings from a particular job that met your expectations, or settings for a particular page size that you will use repeatedly.

Favorites

Registering a favorite for later use. You can choose the settings you have registered from a list before printing, and you can check the settings details.



Note

• You can also save the favorite settings as files. Using these files is a convenient way to print under the same conditions on another computer. (In Windows.)

For instructions on using favorites to print, refer to the following topics, as appropriate for your computer and operating system.

- Using Favorites (Windows) →P.209
- Using Favorites (Mac OS X) →P.494

Cutting Roll Paper After Printing

Roll paper can be automatically cut after printing.



Note

• It may not be possible to cut certain types of paper, such as adhesive paper. For details on types of paper that cannot be used with the auto cut feature, see the Paper Reference Guide. (See "Types of Paper P.774")

Automatic Cutting

Roll paper is cut automatically after printing. If you prefer, you can print continuously without cutting the roll, or you can print a cut line.

For instructions on cutting roll paper after printing, refer to the following topics, as appropriate for your computer and operating system.

- Cutting Roll Paper After Printing (Windows) →P.196
- Cutting Roll Paper After Printing (Mac OS X) →P.198

Cutting Roll Paper After Printing (Windows)

This topic describes how to cut roll paper automatically after printing (using the auto cut function), as well as how to print a cut line for manual cutting.




196

Note


- The auto cut function is activated on the printer by default and when the printer driver is installed. Follow the steps below to reactivate the function if it is disabled, or to select the setting for printing a cut line instead.
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")

Using Favorites iPF8300S

3. Click the Page Setup tab to display the Page Setup sheet.



- **4.** Select and click a roll paper in the **L Paper Source** list.
- 5. Click N Roll Paper Options to display the Roll Paper Options dialog box.



- **6.** To enable automatic cutting, click **Yes** in the **Automatic Cutting** list. If you prefer to cut the paper later yourself, click **Print Cut Guideline**.
- 7. Click **OK** to close the **Roll Paper Options** dialog box.
- **8.** Confirm the print settings and print as desired.



Roll paper will be automatically cut after printing.

Cutting Roll Paper After Printing (Mac OS X)

This topic describes how to cut roll paper automatically after printing (using the auto cut function), as well as how to print a cut line for manual cutting.




Note

- The auto cut function is activated on the printer by default and when the printer driver is installed. Follow the steps below to reactivate the function if it is disabled, or to select the setting for printing a cut line instead.
- 1. This sets the **B** Format for and **C** Paper Size.




Note

The configuration method varies depending on the OS and application software you are using.
 If Page Setup is displayed in the application menu, the settings are configured by opening the Page Attributes dialog box from Page Setup.




If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.




- 2. Select the printer in the A Printer list.
 - **3.** Choose the original size in the **C** Paper Size list.
 - **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.

5. Access the **Page Setup** pane.




- **6.** Select and click a roll paper in the **A Paper Source** list.
- 7. Access the Main pane.



8. In the **A Media Type** list, select the type of paper that is loaded.

9. Click C Set to display the Paper Detailed Settings dialog box.



10. To enable automatic cutting, click **Printer Default** in the **H** Automatic Cutting list. If you prefer to cut the paper later yourself, click **Print Cut Guideline**.



Important

- If the automatic cut function has been deactivated on the printer, change the auto cut setting on the printer Control Panel.
- 11. Click **OK** to close the **Paper Detailed Settings** dialog box.
- 12. Confirm the print settings, and then click M Print to start printing.




Note

• For tips on confirming print settings, see "Confirming Print Settings (Mac OS X) →P.492 "

Windows Software

| Printer Driver | 202 |
|--|-----|
| Preview | 248 |
| Free Layout | 261 |
| Color imageRUNNER Enlargement Copy | 292 |
| Print Plug-In for Photoshop/Digital Photo Professional | 307 |
| Print Plug-In for Office | 373 |
| Status Monitor | 426 |
| Accounting | 429 |
| Digital Photo Front-Access | 442 |
| Device Setup Utility | 443 |
| Media Configuration Tool | 448 |



Printer Driver


| Printer Driver Settings | 202 |
|--|-----|
| Specifying Paper in the Printer Driver | 204 |
| Confirming Print Settings | |
| Checking the Layout in a Preview Before Printing | |
| Using Favorites | 209 |
| Accessing the Printer Driver Dialog Box from Applications | 211 |
| Accessing the Printer Driver Dialog Box from the Operating System Menu | 213 |
| Main Sheet | 215 |
| Paper Information on Printer Dialog Box | 219 |
| Paper Detailed Settings Dialog Box | 220 |
| View Settings Dialog Box for the Printing Application | 222 |
| Color Adjustment Sheet: Color | 222 |
| Object Adjustment dialog box: Color | 224 |
| Matching Sheet | |
| Ambient Light Adjust dialog box | |
| Light Source Check Tool | |
| Color Adjustment Sheet: Monochrome | |
| Object Adjustment dialog box: Monochrome | |
| Gray Adjustment Sheet | |
| Page Setup Sheet | |
| Output Method dialog box | |
| Paper Size Options Dialog Box | |
| Layout Sheet | |
| Page Options Dialog Box | |
| Special Settings Dialog Box | |
| Favorites Sheet | |
| Utility Sheet | |
| Support Sheet | |
| Settings Summaries Dialog Box | |
| Device Settings Sheet | 247 |

Printer Driver Settings

For instructions on accessing the Windows printer driver, refer to the following topics.

- Accessing the Printer Driver Dialog Box from Applications →P.211
- Accessing the Printer Driver Dialog Box from the Operating System Menu —P.213

For information on the Windows printer driver settings, refer to the following topics.



Main Sheet →P.215

You can specify the type of paper, color processing, print quality, print preview, and other settings. Choose **Easy Settings** to specify basic print settings based on the printing application or **Advanced Settings** to complete more detailed settings as desired.

- Paper Detailed Settings Dialog Box →P.220
- Color Adjustment Sheet: Color →P.222
- Object Adjustment dialog box: Color →P.224
- Matching Sheet →P.225
- Ambient Light Adjust dialog box →P.227
- Light Source Check Tool →P.229
- Color Adjustment Sheet: Monochrome →P.230
- Object Adjustment dialog box: Monochrome →P.231
- Gray Adjustment Sheet →P.232
- Page Setup Sheet →P.233

You can specify the page size of the original, borderless printing, enlargement or reduction, the orientation, the paper size and feed source, and automatic cutting.

- Output Method dialog box →P.236
- Paper Size Options Dialog Box →P.237
- Layout Sheet →P.238

You can specify the page layout, watermarks, the orientation, the number of copies, and print processing options.

- Page Options Dialog Box →P.240
- Special Settings Dialog Box —P.241
- Favorites Sheet →P.242

iPF8300S Printer Driver Settings


Groups of print settings you select on each sheet can be saved as a favorite. Favorites you have added can be edited or used at the time of printing as desired.

• Utility Sheet →P.244

You can specify settings related to maintenance for the Printhead and feed amount, as well as settings for Color imageRUNNER Enlargement Copy.

Support Sheet →P.245

You can view support information and the user manual.



• Device Settings Sheet P.247

You can display settings for optional equipment installed on the printer and see the version information for the printer driver.

imagePROGRAF Free Layout is a feature for freely arranging originals from various source applications on a single page as desired before printing. For details, see Free Layout →P.261 .

Color imageRUNNER Enlargement Copy is a feature for automatic enlargement and printing of scanned originals from a Color imageRUNNER. For details, see Color imageRUNNER Enlargement Copy —P.292 .



Note

• Color imageRUNNER Enlargement Copy and imagePROGRAF Free Layout cannot be used on 64-bit version of Windows.

Specifying Paper in the Printer Driver

If you have replaced the paper, you must complete the following settings in the printer driver.




Important

• Always specify the same type and size of paper in the printer menu and printer driver.

 ${f 1.}$ Choose **Print** in the application menu.

- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications —P.211")
- **3.** Make sure the **Main** sheet is displayed.



4. In the **A Media Type** list, select the type of paper that is loaded.




Note

• Click the **B** Get Information button to display the Paper Information on Printer dialog box. On the Paper Information on Printer dialog box, you can obtain information on the paper in the printer and configure printer driver settings for the feed source and type of paper.

This function requires that the **Status Monitor** be installed.

5. Click the Page Setup tab to display the Page Setup sheet.



- **6.** In the A Page Size list, select the size of the original as specified in the application.
- 7. In the **L** Paper Source list, select how paper is supplied.
- 8. If you have selected roll paper in Paper Source, select the width of the loaded roll in MRoll Paper Width.



Note


• A variety of settings are available in the printer driver to suit different printing applications. For details on available printing conditions, see "Printer Driver Settings P.202"

Confirming Print Settings

There are two ways to confirm the print settings, as follows.

Checking a preview of the settings

A preview of the settings is displayed on the left side of the **Main**, **Page Setup**, and **Layout** sheets. By checking illustrations and numerical values in the preview, you can confirm current settings for the page size, orientation, paper source, layout, and so on.



| Display Area | Information Displayed |
|-------------------------|---|
| P Top illustrations | Illustrations indicate the orientation, page layout, borderless printing selection, color mode, and other settings information. |
| Q Middle, bordered area | The page size, paper size, and method and percentage of enlargement or reduction are indicated. |
| R Bottom illustrations | Illustrations indicate the feed source, orientation, borderless printing selection, and other settings information. |



Note

• To confirm the **Print Target** specified in **Easy Settings**, click **G View Settings** on the **Main** sheet to display the **View Settings** dialog box.

· Checking a print preview

You can check an image of the original just as it will be printed.


When you activate this feature, imagePROGRAF Preview or PageComposer is started before printing. Confirming how documents will be printed this way helps prevent printing errors.

For details on print previews, see "Checking the Layout in a Preview Before Printing P.184"

Checking the Layout in a Preview Before Printing


This topic describes how to preview images of print jobs before actually printing them.

- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications —P.211")
- 3. Make sure the Main sheet is displayed.



4. Select the LOpen Preview When Print Job Starts check box.

5. After you click **OK**, when you print a job, the **imagePROGRAF Preview** window will be displayed.





Note

- If PageComposer is running, access the **Special Settings** dialog box from the **Layout** sheet and clear **Enable Preview Switching**.
- **6.** On the main window, you can check the layout and change settings as needed.
- 7. To print, click **Print** in the **File** menu.



Note

• For details on imagePROGRAF Preview functions, see Preview —P.248 .

Using Favorites


This topic describes how to register favorites and print using favorite settings.

Registering a favorite


This section describes the procedure for registering printing settings that have been changed in the driver as Favorites.

- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (Refer to "Accessing the Printer Driver Dialog Box from Applications P.211")
- **3.** Perform normal printing settings. The favorite is registered from here.

4. Click the **Favorites** tab to display the **Favorites** sheet.



5. Click **H Add** to display the **Add** dialog box.



- 6. Enter a desired name in Name, such as Photos for Presentations or Monthly Report.
- 7. Choose a fitting icon for these print settings in the **Icon** list.
- **8.** In **Comment**, enter a description of the favorite to be added, as desired.
- 9. Click **OK** to close the **Add** dialog box.

 The favorite you have added is now displayed in **A Favorites**.



Note


• To save a favorite as a file, click **JExport** and specify the file to save.

Using Favorites iPF8300S

Printing using the favorite

Follow the steps below to print using the favorite you have registered.

- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications →P.211 ")
- 3. Click the Favorites tab to display the Favorites sheet.



4. In the **A Favorites**, choose the favorite you registered.



- To import a favorite, click **Import** and specify the favorite file.
- 5. Click DApply Favorite to replace the favorite settings with the current print settings.
- **6.** Confirm the print settings and print as desired.



For instructions on confirming print settings, see "Confirming Print Settings" —P.207 "

Accessing the Printer Driver Dialog Box from Applications


1. Choose **Print** from the **File** menu to display the dialog box for printing conditions.

2. Select the printer, and then display the printer driver dialog box.




Note

- The dialog box for specifying printing conditions varies depending on the source application. In some cases, when you select the printer, a sheet for configuring the printer driver is added to the dialog box. In the following case, click **Preferences**.
- Example: Print dialog box displayed by the application software



Six sheets of print settings are displayed by the printer driver: Main, Page Setup, Layout, Favorites, Utility, and Support.





Note

• The titles of dialog boxes may vary depending on the application, and sheets other than these six sheets may be displayed.



Important


- If you access the printer driver dialog box from the source application, changes you make to the settings will only apply temporarily to that application. Because these are sizes you specify temporarily in the printer driver, the sizes will not be available after you exit the application.
- You can also access the printer driver dialog box from the Windows system menu.

 To use the settings continuously in all applications, open the printer driver from the system menu to make the settings.
 - See "Accessing the Printer Driver Dialog Box from the Operating System Menu (-P.213)".


Accessing the Printer Driver Dialog Box from the Operating System Menu

1. Click start > Printers and Faxes (or Printers).

2. Select the printer, and then display the printer properties dialog box.



3. Click **Printing Preferences** to display the **Printing Preferences** dialog box, titled with the name of this printer.




214



• The **Device Settings** sheet is also an extension of the printer driver.(See "Device Settings Sheet —P.247")

Six sheets of print settings are displayed by the printer driver: Main, Page Setup, Layout, Favorites, Utility, and Support.





Important

- If you access the printer driver dialog box from the operating system menu, changes you make to the settings will apply to all applications you use for printing.
- You can also access the printer driver dialog box from applications.

 See "Accessing the Printer Driver Dialog Box from Applications →P.211 ".

Main Sheet

The following settings are available on the **Main** sheet. For details on settings items, refer to the printer driver help file.




Note

• On the **Main** sheet, choose **Easy Settings** to specify basic print settings based on the particular printing application, or switch to **Advanced Settings** to complete more detailed settings as desired.

iPF8300S Main Sheet

Common Items



A Media Type

Select the type of paper.

For information on the types of paper the printer supports, refer to the Paper Reference Guide. (See " Paper Reference Guide ".)

B Get Information

Displays **Paper Information on Printer**. You can update the printer driver settings for the feed source, media type, and roll width by selecting the feed source.

Paper Information on Printer Dialog Box →P.219

C Advanced Settings

Displays **Paper Detailed Settings**. You can configure the printing settings to match the type of media, such as the ink drying time.

Paper Detailed Settings Dialog Box →P.220

L Open Preview When Print Job Starts

If you turn this on, imagePROGRAF Preview starts before printing.

This allows you to check on-screen previews of documents before printing.

Checking the Layout in a Preview Before Printing →P.184

M Status Monitor

Starts imagePROGRAF Status Monitor.

You can check the printer status, job status, and other conditions.

You can also set up email notification if printer errors occur by completing the **Email Notice** settings.

For details, refer to the Status Monitor help file.

• N About


Displays version information for the printer driver.

Main Sheet iPF8300S

• S Defaults

Restores all settings on the sheet to the default values.

Configuration using Easy Settings



• E Print Target

Choose presets that match the type of document to be printed.

- Printing Photos and Images →P.22
- Printing Line Drawings and Text →P.47
- Printing Office Documents →P.38

Depending on the AMedia Type setting, some EPrint Target options may not be available.

• F Print Quality

Choose the level of print quality.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.64

G View Settings


Displays the **EPrint Target** setting values.

You can view and change the order of **EPrint Target** setting values.

View Settings Dialog Box for the Printing Application —P.222

iPF8300S Main Sheet

Configuration using Advanced Settings



• E Print Priority

Choose the graphic elements that you want to emphasize for printing.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.64

• F Print Quality

Choose the level of print quality.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.64

Thighest quality

If you select this option, the document will be printed with enhanced quality at the highest resolution. Compared to the other options, more time and ink are consumed in printing, however you will attain print results with the highest quality.



Note

• If you set **F** Print Quality to High, you can select **T** Highest quality. However, depending on **A** Media Type and **E** Print Priority, you may not be able to select **T** Highest quality.

• U Economy Printing

If you select this option, you can print with less ink consumed. However, print quality is lower than in regular printing. Select this option to save ink, such as when printing to check drawings. Depending on the settings of A Media Type and F Print Quality, you may not be able to select this option.



Note

• If you set **F** Print Quality to Fast, you can select **U** Economy Printing. However, depending on **A** Media Type and **E** Print Priority, you may not be able to select **U** Economy Printing.

Main Sheet iPF8300S

G Color Mode

Choose the color mode.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.64



Note

• Depending on the A Media Type setting, some G Color Mode options may not be available.

H Color Settings

Click to display the **Color Settings** dialog box for more advanced color settings.

Adjusting the Color in the Printer Driver →P.55

Thicken Fine Lines


Activate this option to print fine lines more distinctly.

J Unidirectional Printing

Select this checkbox to prevent problems such as misaligned lines and improve the print quality. However, the printing speed becomes slower.

Paper Information on Printer Dialog Box

On the **Paper Information on Printer** dialog box, you can obtain information on the paper in the printer and configure printer driver settings for the paper source and media type.





Note

 To display the Paper Information on Printer dialog box, on the Main sheet, click Get Information by Media Type.(See "Main Sheet →P.215")

A Paper Source


Shows the paper source supported by the printer, as well as information about the loaded paper. To update the paper source and media type settings in the printer driver, select the desired **Paper Source** option and click **OK**.

Paper Detailed Settings Dialog Box

In the **Paper Detailed Settings** dialog box, you can set **Drying Time** for the paper selected with **Media Type** of the **Main** sheet, etc.

You can display this dialog box by clicking **Settings** of **Media Type** on the **Main** sheet. (Refer to "Main Sheet —P.215".)

As for the items for which you can select**Printer Default** in this dialog box, you also can set them from the control panel of the printer. (Refer to "Menu Settings P.938".)



A Drying Time

Specify the time that the printer waits for ink to dry, as needed. The **Drying Time** setting is only valid for rolls.

• B Between Pages

You can set the time to wait after printing 1 document page until ejecting the paper. Since waiting time is required for ink to dry before a roll is cut, you can deliver paper in the Output Stacker with the ink dried even if **Cutting Mode** is set to **Automatic**.

| Setting Item | Details |
|--|--|
| Printer Default | The setting of the control panel of the printer is applied. |
| Off | Paper is ejected immediately after printing completes. |
| 30 sec. / 1 min. / 3 min. / 5 min. / 10 min. / 30 min. / 60 min. | Paper is ejected when the set time elapses after printing completes. |

C Between Scans

You can set the time to wait after printing 1 line on a page until printing the next line. Set this to avoid bleeding or color unevenness such as when bleeding occurs on a page or when color unevenness occurs during borderless printing.

| Setting Item | Details |
|---------------------------------------|--|
| Printer Default | The setting of the control panel of the printer is applied. |
| Off | The next line is printed immediately after a line is printed. |
| 1 sec. / 3 sec. / 5 sec. / 7 sec. / 9 | The next line is printed when the set time elapses after a line is printed. |
| sec. | * Increase the time according to the occurrence condition of bleeding or unevenness. |

D Roll Paper Margin for Safety

You can specify the length of a margin on the leading edge of paper to ensure that paper susceptible to curling is held firmly against the Platen.

• E Near End Margin

Specify the length of the Near End Margin (the leading edge margin) of the roll, as needed.

| Setting Item | Details |
|-----------------|--|
| Printer Default | The setting of the control panel of the printer is applied. |
| 5 mm (0.2 in) | The document is printed in the standard size. |
| | * Select this when you do not have any problems in printing. |
| 20 mm (0.8 in) | Select this when rubbing against the printhead occurs such as when using paper that tends to curl. |

F Cut Speed

Select the speed of automatic cutting, as needed. You can adjust this setting if paper is not cut well when automatic cutting is used.

| Setting Item | Details |
|-----------------|--|
| Printer Default | The setting of the control panel of the printer is applied. |
| High Speed | When the Standard setting does not result in cutting the surface cleanly, select this. |
| Standard | Select this when you do not have any problems in automatic cutting. |
| Low Speed | This helps prevent adhesive from sticking to the cutter and keeps the cutter sharp if you select it when using adhesive paper. |

H Calibration Value

You can specify whether to apply the results of calibration performed on the printer to image processing.


| Setting Item | Details |
|-----------------|---|
| Printer Default | The setting of the control panel of the printer is applied. |
| Enabled | Print using the calibration results. |
| Disabled | Print without using the calibration results. Select this to avoid the changing of the color of images during printing by color calibration. |

G Mirror

Specify whether to print a mirror image, as needed. Select this option to print a version of the document or image with the left and right sides inverted.

View Settings Dialog Box for the Printing Application

In the View Settings dialog box, you can check details of the selected printing application.





Note

• To display the View Settings dialog box, on the Main sheet, click View Settings by Print Target. (See "Main Sheet —P.215")

A Print Target

Shows all **Print Target** options (settings items for the printing application).

• B Name


Identifies the item selected in **Print Target** by its name and an icon.

C Details

Here, you can confirm detailed settings values for each listed item for the selected Print Target.

Color Adjustment Sheet: Color

If the color tone as printed is not as you expected, you can adjust it on the Color Adjustment sheet.





Note

• To display the Color Adjustment sheet, on the Main sheet, click Color Settings by Color Mode in Advanced Settings. (See "Main Sheet →P.215")

A Sample Type

Choose a sample image from Standard, Portrait, Landscape, or Graphics.

B View Color Pattern

Select this checkbox to display the color pattern.

C Apply to Sample

Select this checkbox to apply the changed settings to the sample image.

D Cyan / E Magenta / F Yellow

Fine-tune color tones by adjusting the levels of each color.

G Gray Tone

Adjust the color tone of grays as desired. Choose Cool Black (tinged with blue) or Warm Black (tinged with red).

H Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

• | Contrast

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the **Contrast** makes images sharper, and reducing the **Contrast** softens images.

J Saturation

Adjust the color intensity as desired. Increasing the **Saturation** setting makes colors more vivid, and reducing the **Saturation** makes colors more subdued.

KObject Adjustment

Select this option to display the **Object Adjustment** dialog box, in which you can specify objects subject to color adjustment.

Object Adjustment dialog box: Color →P.224

S Defaults

Click to restore all settings on the sheet to the default values.




Note

• For details on settings items, see "Adjusting the Color in the Printer Driver —P.55"

Object Adjustment dialog box: Color

In the **Object Adjustment** dialog box, you can specify what type of print jobs to apply color adjustment to. If an original comprises images, graphics, and text, you can specify which portion to apply color adjustment to.





Note

• To display the Object Adjustment dialog box, click Object Adjustment on the Color Adjustment sheet.

• Almage

Select this option to apply color adjustment to image areas, such as photos.

• B Graphics

Select this option to apply color adjustment to graphics, such as lines and circles.

C Text

Select this option to apply color adjustment to text.

Matching Sheet

On the **Matching** sheet, you can specify color matching to compensate for differences in the appearance of colors on various devices.



Important

• If **No color correction** is selected under **Color Mode**, the **Matching** sheet is not displayed.




Note

• To display the Matching sheet, on the Main sheet, click Color Settings in Color Mode in Advanced Settings, and then click the Matching sheet. (Refer to "Main Sheet ¬P.215")

Driver Matching Mode

The following options are available when you select **Driver Matching Mode** in the A Matching Mode list.



A Matching Mode

Select the color matching mode to use, as desired.

Normally, select **Driver Matching Mode**. For color matching based on ICC profiles, select **ICC Matching Mode**, **Driver ICM Mode**, or **Host ICM Mode**, depending on your color matching system.

B Matching Method

Select the color matching method that suits the document to be printed. Various **Matching Method** options are available depending on your selection in **Matching Mode**.

Color Space

Select the applicable color space as desired.

D Monitor White Point

Enter the color temperature set on the monitor.

Displayed when the **B** Matching Method is set to Monitor Matching.

iPF8300S Matching Sheet

• EUse ambient light adjustment

Select this option for adjustment of colors to suit the ambient light in the viewing environment.


F Ambient Light Adjust

Click to display the **Ambient Light Adjust** dialog box, which enables you to complete settings for printing to match the ambient light.

Ambient Light Adjust dialog box →P.227

ICC Matching Mode, Driver ICM Mode and Host ICM Mode

The following options are available when you select ICC Matching Mode, Driver ICM Mode, or Host ICM Mode in the A Matching Mode list.



A Matching Mode

Select the color matching mode to use, as desired.

• B Input Profile Settings

You can select Image, Graphics, or Text. You can choose Matching Method and Input Profile.

Various options are available depending on your selected **Matching Mode**.

To apply the same input profile automatically for **Graphics** and **Text**, select **Use the Same Profile for All Objects**. To apply separate input profiles to **Graphics** and **Text**, clear **Use the Same Profile for All Objects** and specify the individual settings.

C Printer Profile Settings

Specify the printer profile as desired. Normally, select **Auto Settings**.



Note


• For details on settings items, see "Adjusting the Color in the Printer Driver —P.55"

Matching Sheet iPF8300S

Ambient Light Adjust dialog box

The **Ambient Light Adjust** dialog box is used to select the setting method and to enter and select the information required for the settings.

When you select By selecting a chart number in Setting Method



A Setting Method

You can choose configuration based on the printed Chart or based on using the i1 colorimeter.

• B Print Chart

Click to start the **Light Source Check Tool**, for printing **Chart**. The **Light Source Check Tool** must be installed to use this function.

• Light Source Check Tool →P.229

• C Chart Number

In Chart, select the number of the pattern with your desired colors.


D Color Temperature

Enter the Color Temperature measured during monitor calibration. Displayed when the A Matching Method is set to Monitor Matching on the Matching sheet.

• Ellluminance

Enter the **Elluminance** measured during monitor calibration. Displayed when the **A Matching Method** is set to **Monitor Matching** on the **Matching** sheet.

When you select By entering values directly in Setting Method



A Setting Method

You can choose configuration based on the printed **Chart** or based on using the i1 colorimeter.

• B Lighting Source Type

Select the light source measured using the i1 colorimeter.

• D Color Temperature

Enter the Color Temperature measured using the i1 colorimeter.

• Ellluminance

Enter the **Illuminance** measured using the i1 colorimeter.

Displayed when the A Matching Method is set to Monitor Matching on the Matching sheet.




Note

• For details on settings items, see "Adjusting the Color in the Printer Driver —P.55"

Light Source Check Tool

The Light Source Check Tool enables you to print Chart.



A Printer Name

The printer name is displayed here.

• B Media Type

Select the paper type.(See "Types of Paper →P.774")

C Paper Source

Choose the paper source, as desired.


Options displayed in the list vary depending on the selection in **B Media Type** in the **Main** sheet.

• D Print

Click to print the Chart.

Color Adjustment Sheet: Monochrome

On the Color Adjustment sheet for monochrome printing, you can adjust the brightness and contrast.





Note

• To display the Color Adjustment sheet, on the Main sheet, click Color Settings by Color Mode in Advanced Settings. (See "Main Sheet P.215")

A Sample Type

Choose a sample image from Standard, Portrait, Landscape, or Graphics.

B View Color Pattern

Select this checkbox to display the color pattern.

C Apply to Sample

Select this checkbox to apply the changed settings to the sample image.

• D Cyan / E Magenta / F Yellow

Not available.

Gray Tone

Not available.

H Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

• | Contrast

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the **Contrast** makes images sharper, and reducing the **Contrast** softens images.

J Saturation

Not available.

K Object Adjustment

Select this option to display the **Object Adjustment** dialog box, in which you can specify objects subject to color adjustment.

Object Adjustment dialog box: Monochrome →P.231

S Defaults

Click to restore all settings on the sheet to the default values.




Note

• For details on settings items, see "Adjusting the Color in the Printer Driver →P.55"

Object Adjustment dialog box: Monochrome

In the **Object Adjustment** dialog box, you can specify what type of print jobs to apply color adjustment to. If an original comprises images, graphics, and text, you can specify which portion to apply color adjustment to.





Note

• To display the Object Adjustment dialog box, click Object Adjustment on the Color Adjustment sheet.

• A Image

Select this option to apply color adjustment to image areas, such as photos.

B Graphics


Select this option to apply color adjustment to graphics, such as lines and circles.

C Text

Select this option to apply color adjustment to text.

Gray Adjustment Sheet

On the Gray Adjustment sheet, you can adjust the color balance, brightness, contrast, and other image qualities.





Note

- To display the **Gray Adjustment** sheet, on the Main Sheet —P.215, select **Monochrome (Photo)** by **Color Mode** in **Advanced Settings**, and then click **Color Settings**.
- Monochrome (Photo) is not available for all types of paper.

A Sample Type

The image at left is updated to reflect any changes you make to setting items on the sheet, enabling you to check the results of adjustment.

• B Sample List

Select a sample image, as desired.

Color Balance

Click the list to select a color balance that suits the printing application.

• DX / EY

Adjust the color balance as you check the color tone in the adjustment area.

You can adjust the square area in the center by clicking or dragging it.

Drag the vertical or horizontal scroll bars for adjustment, as desired.

You can click the arrows by the **D** X (horizontal) and **E** Y (vertical) boxes or enter the values directly.

• F Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

Gray Adjustment Sheet iPF8300S

• G Contrast

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the **G** Contrast makes images sharper, and reducing the **G** Contrast softens images.

• H Highlight

Adjust the brightness of the lightest portion.

• Shadow


Adjust the brightness of the darkest portion.

• S Defaults

Click to restore all settings on the sheet to the default values.

Page Setup Sheet

The following settings are available on the **Page Setup** sheet. For details on settings items, refer to the printer driver help file.




A Page Size

Select the page size as specified in the source application.

For details on available page sizes, see "Paper Sizes →P.775"

iPF8300S Page Setup Sheet

• B Borderless Printing



Borderless printing is available if roll paper is selected in the **L Paper Source** list. Choose from the following options when this setting is activated.

- Borderless Printing on Paper of Equivalent Size →P.107
- Borderless Printing by Resizing Originals to Fit the Roll Width →P.114
- Borderless Printing at Actual Size →P.100

D Fit Paper Size

Scales the document image to match the paper size.

• EScale to fit Roll Paper Width

Scales the document image to match the roll width.

• F Print Image with Actual Size

Prints documents at their actual size. This function is available when you have selected the size same as the width of **Roll Paper** for either the length or width of the document from the **A Page Size** list.

• G Paper Size


Available when **D** Fit Paper Size is selected.

Choose the size of the paper you will print on.

For details on available paper sizes, see "Paper Sizes →P.775"

Paper sizes compatible with borderless printing are shown in the list.

C Enlarged/Reduced Printing



Choose from the following options when this setting is activated.

- Resizing Originals to Match the Paper Size →P.73
- Resizing Originals to Fit the Roll Width →P.79
- Resizing Originals by Entering a Scaling Value →P.85

D Fit Paper Size

Scales the document image to match the paper size.

• E Fit Roll Paper Width

Scales the document image to match the roll width.

Page Setup Sheet iPF8300S

F Scaling

Resizes the document image based on a specified scaling value. Enter a value in a range of 5-600.

G Paper Size

Choose the size of the paper you will print on.

For details on available paper sizes, see "Paper Sizes -P.775"

H Orientation

Choose the printing orientation.

Making the Original Orientation Match the Paper Orientation →P.190

K Rotate Page 90 degrees (Conserve Paper)

Activate this setting to rotate the document image by 90 degrees before printing.

Conserving Roll Paper by Rotating Originals 90 Degrees →P.172

• L Paper Source

Choose the feed source, as desired.

Options displayed in the list vary depending on the selection in **Media Type** on the **Main** sheet.


• M Roll Paper Width

Choose the roll width.

For details on available roll widths, see "Paper Sizes P.775"

• N Roll Paper Options

Complete optional roll paper settings. Click to display the Roll Paper Options dialog box.



Under A Automatic Cutting, you can specify Yes or No and Print Cut Guideline.

Cutting Roll Paper After Printing →P.196

Select Banner Printing when printing multiple pages continuously.

Printing Multiple Pages Continuously →P.144

P Output Method

Click to display the **Output Method** dialog box, which enables you to complete the **Output Method** and **Name of data to be saved** settings.

Output Method dialog box →P.236

OSize Options

Click to display the **Paper Size Options** dialog box, which enables you to register additional paper sizes or select the size system for use.

Paper Size Options Dialog Box →P.237


• S Defaults

Restores all settings on the sheet to the default values.

iPF8300S Page Setup Sheet

Output Method dialog box

The Output Method dialog box allows you to select the Output Method and set the save settings when saving to the box.





Note

• To display the **Output Method** dialog box, on the **Page Setup** sheet, click **Output Method**. (Refer to "Page Setup Sheet —P.233")

A Output Method

If **Print** is selected, the print job is saved to the printer hard disk after printing has finished.

If **Save in mail box** is selected, the print job is saved to the printer hard disk. If you choose **Save in mail box**, also specify the destination personal box in the **Mail box** list.

If **Print after reception is complete** is checked, the print job is first saved completely on the printer hard disk before printing begins.

These can be selected as **Print** options.

B Name of data to be saved

To use the file name, choose **Use file name**.

Otherwise choose Enter name and enter a name in Name.

• C Mail box


Displays a list of mail boxes. If you choose **Save in mail box**, also specify the destination personal box from the list.

D Acquire Mail Box Name

When this is clicked, the box name acquired from the printer main unit is displayed in **Mail box**.

Paper Size Options Dialog Box

In the **Paper Size Options** dialog box, you can create and register your own Custom Paper Size. The sizes you define are listed with standard paper sizes for selection later as needed.





Note

• To display the **Paper Size Options** dialog box, on the **Page Setup** sheet, click **Paper Size Options**.(See "Page Setup Sheet —P.233")

A Paper Size List

Shows the names and sizes of paper that can be used with the printer driver.

• B Delete

Custom paper sizes created by users can be deleted from the A Paper Size List, as needed.

However, they cannot be deleted in the following situations.

- If a standard paper size of the printer driver is selected.
- If an oversized paper size is selected.
- If a paper size marked with a red circle is selected.

C Custom Paper Size Name

You can name Custom Paper Size as desired.

• D Units

Specify the desired unit of measure for the Custom Paper Size height and width.

• E Paper Size

Specify the desired Width and Height. You can make your selection from sizes that are compatible with Borderless Printing by selecting Borderless Printing Size. To maintain the aspect ratio of the Width and Height as you resize the paper, select Fix the Ratio of the Width to Height.

FAdd


Enables you to register the custom paper size you have specified or overwrite an existing custom paper size.

G Display Series

You can limit the number of options shown in Page Size, Paper Size, and Paper Size List.

Layout Sheet

The following settings are available on the **Layout** sheet. For details on settings items, refer to the printer driver help.



A Page Layout

Activate this setting to select a particular page layout.

- Printing Multiple Pages Per Sheet →P.149
- Printing Posters in Sections →P.156
- Printing Multiple Originals Next to Each Other →P.139
- Using PosterArtist to Compose Originals →P.44

• B Set

Click to display one of the following dialog boxes depending on the selection in A Page Layout. In these dialog boxes, you can specify layout details and which pages to print, as well as other settings.

- Page Layout Printing
- · Pages to Print
- Free Layout Settings

C Watermark

Activating this option makes two settings available, **Watermarks** and **DEdit Watermark**.

Printing With Watermarks →P.186

Watermarks

Lists the provided watermarks. Choose the watermark to print.

Layout Sheet iPF8300S

• D Edit Watermark

Click to display the **Edit Watermark** dialog box for creating your own, original watermark.

• E Print Centered

Activate this setting to print document images in the center of the paper.

- Printing Originals Centered on Rolls →P.160
- Printing Originals Centered on Sheets →P.166

• F Rotate 180 degrees

Activate this option to rotate document images by 180 degrees before printing.

• G No Spaces at Top or Bottom (Conserve Paper)

Activate this setting to print the next image skipping blank areas above and below printable data in documents, which enables you to conserve the paper.

H Copies

Enter the number of copies to print, in a range of **1–999**.

Reverse Order

Activate this option to print pages in reverse order.

Page Options

Click to display the **Page Options** dialog box, which enables you to complete settings for printing the user name, date, or page number in the header or footer.

Page Options Dialog Box →P.240

J Special Settings

If the printing results are not as you expected, click this option to change how printing is processed.

Special Settings Dialog Box →P.241


• S Defaults

Click to restore all settings on the sheet to the default values.

iPF8300S Layout Sheet

Page Options Dialog Box

The **Page Options** dialog box offers the following settings.





Note

• To display the Page Options dialog box, on the Layout sheet, click Page Options. (See "Layout Sheet —P.238")

A Print Date

Select where the date is printed, as desired. To print the time as well, select B Print Time Also.

C Print User Name


Select where the user name is printed, as desired.

• D Print Page Number

Select where the page number is printed, as desired.

• E Format Settings

Click to display the Format Settings dialog box, which enables you to complete format-related settings.



240




Note

- If you specify the same position for multiple items, the items are printed from left to right in this order: date, user name, and page number.
- When you print multiple pages per sheet using **Page Layout Printing** or similar functions, these items will be printed for each page.

Special Settings Dialog Box

If the printing results are not as you expected, you can change how printing is processed in the **Special Settings** dialog box.





Note

• To display the **Special Settings** dialog box, on the **Layout** sheet, click **Special Settings**.(See "Layout Sheet ¬P.238")

A FineZoom Settings

This function is used in large-format printing. Normally, choose **Auto**. If documents are not printed correctly on large-format paper, it may help to select **Yes**, and if fine lines are not visible or if images are distorted when printed, it may help to select **No**.

• B Application Color Matching Priority

You can give applications priority in color management.

C Enable Preview Switching

When this option is selected, PageComposer starts if you print with **Open Preview When Print Job Starts** selected on the **Main** sheet.

D Fast Graphic Process

If image colors are inconsistent in printed documents or if lines are printed in varying thicknesses, clearing this option may help produce the expected results.



Note


• This function cannot be used on 64-bit version of Windows.

• Extend print pass

If you are concerned about uneven colors in the print result of **Highest quality**, selecting this option may improve printing results. However, printing may take longer.

Favorites Sheet

The following settings are available on the **Favorites** sheet. For details on settings items, refer to the printer driver help.



A Favorites

Printing favorites you have created are listed with **Default Settings** favorites.

Using Favorites →P.196

B Settings Details

Displays details of the favorite selected in the **A Favorites**.

• C Comment

Displays notes registered in the favorite.

D Apply Favorite

Click to change the current print settings to those of the favorite selected in the **A Favorites**.

• EApplication Settings Priority

Activate this setting to use settings values specified in the source application in preference to favorite settings selected in the A Favorites, when clicking D Apply Favorite. For details on the settings items used in preference, refer to the printer driver help.

• F Delete

Click to delete the selected favorite from the A Favorites list.


• G Edit

Click to display the **Edit** dialog box, which enables you to change the name and icon for the favorite selected in the **A Favorites** list.

Favorites Sheet iPF8300S

• HAdd

Click to display the Add dialog box, which enables you to add the current print settings as a favorite.



• Import

Click to display the **Open** dialog box, which enables you to import favorite settings saved as a file.

J Export

Click to display the Save As dialog box, which enables you to save the favorite settings as a file.

• KUp

Click to move the selected favorite up in the A Favorites list.


• L Down

Click to move the selected favorite down in the A Favorites list.

iPF8300S Favorites Sheet

Utility Sheet

The following items can be executed on the **Utility** sheet. For details on the utilities, refer to the relevant utility help.



A Maintenance

Click to start the imagePROGRAF Status Monitor, which offers the following maintenance for the printer.

- · Nozzle (ink ejecting outlet) check
- Nozzle (ink ejecting outlet) cleaning
- · Head alignment adjustment
- · Feed amount adjustment

• B Color imageRUNNER Enlargement Copy

Click to launch Color imageRUNNER Enlargement Copy (iR enlargement copy), which enables you to create hot folders used for Color imageRUNNER Enlargement Copy and assign print settings to hot folders.

Printing Enlargements of Scanned Originals from a Color imageRUNNER →P.304

For details, see Color imageRUNNER Enlargement Copy -P.292 .




Note

• This function is not available on 64-bit version of Windows.

Utility Sheet iPF8300S

Support Sheet

On the **Support** sheet, you can view support information and the user's manual.



• A Support Information

Click to access the Canon support webpage, where you can find the latest information on the printer and consumables, check for printer driver updates, and browse other information.

B User Manual

Click to view the printer user's manual. This function requires the user's manual to be installed on your computer.


C Settings Summaries

Click to display the View Settings dialog box, which enables you to confirm the settings for the Main, Page Setup, Layout, and Favorites sheets.

iPF8300S Support Sheet

Settings Summaries Dialog Box

The Settings Summaries dialog box enables you to confirm the settings for the Main, Page Setup, Layout, and Favorites sheets.




• A Copy

Click to copy the settings information to the clipboard. You can paste the settings information into a file created with a text editor or similar application.

Device Settings Sheet

Many settings items on the printer properties sheets are controlled by Windows applications. However, the **Device Settings** sheet is for configuring the printer, and it is an extension of the printer driver.

The following settings are available on the **Device Settings** sheet.



• A About

You can display version information for the printer driver.

iPF8300S Device Settings Sheet

Preview

| The Features of Preview | 248 |
|--|-----|
| Operating Environment | |
| Starting Preview | 249 |
| Preview Main Window | 250 |
| Dialog Area | |
| Enlarge/Reduce the screen display | 254 |
| Moving a Page | |
| Using the ruler | |
| Priority setting for rotating 90 degrees | |
| Printing with Selecting the Layout | |
| Print on the Center | |
| Not Print Spaces at the Top/Bottom | |
| and the same of th | |

The Features of Preview

The main features of Preview are as follows.

- While viewing this screen, you can adjust layout settings of a document created with application software.
- You can not only adjust layout settings but also your changes will be instantly applied on the preview screen, and you can print the preview screen as it is seen.



Note

• The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Preview settings.

Operating Environment

You can use the Preview in the following environments.

- · Compatible Operating System
 - 32 bit edition Windows OS Windows XP, Windows Server 2003, Windows Server 2003 R2, Windows Vista, Windows Server 2008, Windows 7
 - 64 bit edition Windows OS Windows XP, Windows Server 2003, Windows Server 2003 R2, Windows Vista, Windows Server 2008, Windows Server 2008 R2, Windows 7



Note

- For the Windows OS, use the latest version of Service Pack.
- Software that requires installation imagePROGRAF Printer Driver

The Features of Preview iPF8300S


Starting Preview

Follow the procedure below to start the Preview.

- 1. Start the apllication software which you use.
- 2. From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



- Note
- Normally, select **Print** from the **File** menu.
- **3.** On the **Main** sheet, click on the **Open Preview When Print Job Starts** check box. Click the **OK** button to save the settings.






Note

- Your printer is depicted in the lower-left area of this screen.
- **4.** On the **Print** dialog box in the application software, click the **Print** button.


iPF8300S Starting Preview

5. Preview main window is displayed.



Preview Main Window

The Preview main window consists of the menu and tool bars, preview and dialog area and status bar.



250



• You can use the View menu to show or hide the tool bar.

Preview Main Window iPF8300S


Menu Bar

This allows you to select menus required for operations.




• Tool Bar

This allows you to select tool buttons required for major operations.



Preview Area

You can check the settings you made in this area.




Dialog Area

This allows you to set the print conditions and perform a print job.

iPF8300S Preview Main Window

For more information about Dialog Area, see "Dialog Area." —P.253



• Status Bar


This shows the message, Pages and Output Size.

Rotating images 90 degrees can conserve paper. Pages : 1/1 Output Size : 11.7in × 16.5in

Preview Main Window iPF8300S

Dialog Area

You can select the layout and print on the center.



• Media Type / Paper Source / Paper Size

You can confirm the information that is set.

Layout Selection

You can print which conserves paper by selecting the layout.

For more information about Layout Selection, see "Printing with Selecting the Layout."

P.257

· Center Originals Across Roll

You can print on the center of the media loaded in the printer.

For more information about Center Originals Across Roll, see "Print on the Center." —P.259



Note

• Available only if rolls are selected in Paper Source.

No Spaces at Top or Bottom

You can save paper on not to feed roll paper for the empty spaces when the print data contains spaces at the top or bottom.

For more information about No Spaces at Top or Bottom, see "Not Print Spaces at the Top/Bottom." (\$\infty\$P.260)

iPF8300S Dialog Area



Note

• Available only if rolls are selected in **Paper Source**.

• Print Button

Click the button to start printing.

• Cancel Button

Click the button to stop printing.

Printer Information

You can confirm the information acquired from the printer.

• Update Printer Information Button

Click the button to update the printer information with connecting to the printer.

• Status Monitor Button

Click the button to start Status Monitor.

Enlarge/Reduce the screen display

You can enlarge or reduce the screen display when you select Zoom from the View menu.

| Setting | Details |
|--------------|---|
| Fit Screen | Display all. |
| Fit to Width | Display to the width of the paper. |
| Reduce | Display at half of the standard size. |
| Standard | Display at the standard size. |
| Enlarge | Display with the double of the standard size. |
| Enlarge More | Display with the triple of the standard size. |



Note

• This item can be selected even if you have clicked the ▼ button in the toolbar **Zoom**.

Moving a Page


You can move a page to display when you select Go to Page from the View menu.

| Setting | Details |
|---------------|---------------------------|
| First Page | Go to the first page. |
| Previous Page | Go to the previous page. |
| Next Page | Go to the next page. |
| Last Page | Go to the last page. |
| Go To Page | Go to the specified page. |



Note

• You can also move a page by clicking



on the tool bar.

Using the ruler


You can confirm the layout with using the ruler.

- Switching the ruler Show/Hide
 In the **View** menu, select **Ruler** to switch the ruler Show/Hide.
- Changing the ruler unit
 You can set the ruler unit when you select **Units** from the **View** menu.

| Setting | Details |
|---------|-------------------------------|
| mm | Use mm as the ruler unit. |
| inch | Use inches as the ruler unit. |

Priority setting for rotating 90 degrees


You can select Rotate 90 Degrees If Possible or Use Driver Settings from the Options menu.




| Setting | Details |
|-------------------------------|--|
| Rotate 90 Degrees If Possible | Rotates pages in portrait orientation 90 degrees before printing. Pages are only rotated if they can fit lengthwise across the roll. |
| Use Driver Settings | Follows printer driver settings when determining whether to rotate pages. |

iPF8300S Using the ruler

Selecting Rotate 90 Degrees If Possible or Placing a checkmark for Rotate Page 90 degrees (Conserve Paper) on the printer driver




Selecting Use Driver Settings




Printing with Selecting the Layout

You can print which conserves paper by selecting the layout.

1. In Layout Selection, click the layout button to use.




| Button | Details |
|--------------|---------------------------|
| Upper Button | Turn at the position of . |
| Right Button | Turn at the position of |
| Left Button | Turn at the position of . |





Note

- **Right Button** or **Left Button** can be selected only when the rotated pages can fit lengthwise across the roll.
- By clicking **Right Button** or **Left Button**, you can save paper by printing in landscape orientation on roll paper.
- You can select only Upper Button or Lower Button if Cut Sheet is selected.



| Button | Details |
|--------|-----------------------------------|
| R | The button is selected currently. |
| R | The button can be selected. |
| R | The button can not be selected. |

2. Click the Print Button.

Printing on the selected layout begins.

Print on the Center

You can print on the center of the media loaded in the printer.

1. Click the Center Originals Across Roll check box on.



2. Click the **Print** button

Printing on the center begins.



Note


• Available only if rolls are selected in Paper Source.

iPF8300S Print on the Center

Not Print Spaces at the Top/Bottom

You can save paper on not to feed roll paper for the empty spaces when the print data contains spaces at the top or bottom.

1. Click the No Spaces at Top or Bottom check box on.



2. Click the Print button.

Printing on the settings with no spaces at top or bottom begins.


Free Layout

| The Features of Free Layout | 261 |
|--|-----|
| Operating Environment | 262 |
| Starting Free Layout | |
| Free Layout Main Window | 265 |
| Detailed Settings | |
| Preferences Dialog Box | |
| Page Options Dialog Box | |
| Zoom Dialog Box | |
| Format Dialog Box | |
| Laying out a Multiple-File Document on One Page | |
| Laying out a Document Created with Multiple Application Programs on One Page | |
| Selecting an Object | |
| Changing the Object Size | |
| Moving an Object | |
| Rotating an Object | |
| Laying out Objects Automatically | |
| Aligning Objects | |
| Changing the Object Overlapping Order | |
| Pasting a Copied or Cut Object | |
| | |
| Folded Duplex Window | |
| Finished Size Settings Dialog Box | |
| Binding Settings Dialog Box | 289 |
| Prints using Folded Duplex | 290 |

The Features of Free Layout

The main features of Free Layout are as follows.

- Allows you to lay out at will and print a document created with application software.
- You can not only lay out multiple pages on one page but also lay out and print a multiple-file document on one page, or lay out and print a document created with multiple application programs on one page.
- Any two pages can be arranged and printed in a layout that becomes duplex on folding. This can be used such as for advertising posters that are suspended from the ceiling.



Note

• The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Free Layout settings.

Operating Environment

You can use the Free Layout in the following environments.

Compatible Operating System
 Windows XP, Windows Server 2003, Windows Server 2003 R2, Windows Vista, Windows Server 2008, Windows 7



Note

- This function is not available on 64-bit version of Windows.
- For the Windows OS, use the latest version of Service Pack.
- Software that requires installation imagePROGRAF Printer Driver

Starting Free Layout

Follow the procedure below to start the Free Layout.

- 1. Start the application software which you use.
- 2. From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



Note

• Normally, select **Print** from the **File** menu.

3. From the list, select the printer and select the **Layout** sheet.





Note

- Your printer is depicted in the lower-left area of this screen.
- **4.** In the **Layout** sheet, click on the **Page Layout** check box and select Free Layout from the list. Click the **OK** button to save the settings.



Note

• When you select Free Layout, all other setting items will be disabled.

iPF8300S Starting Free Layout

5. On the **Print** dialog box in the apllication software, click the **Print** button. Free Layout main window is displayed.



Starting Free Layout iPF8300S

Free Layout Main Window

The Free Layout main window consists of the menu and tool bars, layout area and status bar.





Note

• You can use the View menu to show or hide the tool and status bar.

Menu Bar

This allows you to select menus required for operations.



• Tool Bar

This allows you to select tool buttons required for major operations.



Free Layout Main Window

· Layout Area

This allows you to lay out objects and edit the object size and orientation.




• Status Bar

This shows the paper size, unit of length, and number of objects.

Roll Paper : 24-in. Roll (609.6mm) Units:inch Number of Objects:4

Detailed Settings

The printer driver opens when you select **Detailed Settings** from the **File** menu. The printer driver is used to configure basic settings to match the type of media loaded in the printer.



Refer to Printer Driver —P.202 for details on the printer driver.




Note

• When you select the **Detailed Settings**, the only three sheets displayed are the **Main** sheet, the **Page Setup** sheet, and the **Layout** sheet. Some of the printer driver settings may be disabled.

iPF8300S Detailed Settings

Preferences Dialog Box

This dialog box appears when you select **Preferences** from the **File** menu. This allows you to configure the preferences of Free Layout.



• Units

Set the unit for paper length, margins, and so on.

Gridlines

You can input a grid line width value in numerical characters so that they serve as a guide to laying out objects.



Note

- You can input between 10.0 and 200.0(mm) (between 0.39 and 7.88(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Divisions

You can change the number of divisions of grid lines so that they serve as a guide to laying out objects.



Note

- You can input between 1 and 10.
- You can change the numbers by clicking either ▲ button or ▼ button.

Grid Color

Select the grid line color.

Auto Arrange Spacing

Change the object-to-object spacing to be applied in the operation of laying out objects automatically.



Note

- You can input between 0.0 and 100.0(mm) (between 0.00 and 3.94(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Preferences Dialog Box

• Object Frame Style


You can select the object frame style for printing.

The following settings are available for the object frame style.

| Setting | Details |
|--------------------|---|
| None | You can print with no frame style. |
| Solid Line | You can print the solid line as the frame style. |
| Dotted Line | You can print the dotted line as the frame style. |
| Dashed Line | You can print the dashed line as the frame style. |
| Crop Marks | You can print with the crop marks. |

Page Options Dialog Box

This dialog box appears when you select **Page Options** from the **File** menu. This allows you to configure the roll paper length, object layout order, and margins of Free Layout.



Roll Paper Length

Set the length of one page to print on roll paper.

The following settings are available for roll paper length.

| Setting | Details |
|-----------------|--|
| Auto Settings | The one-page length to be printed on roll paper is automatically set so that the laid- out objects are printed on one page. |
| Manual Settings | You can input the length of one page to print on roll paper in numerical characters. |

iPF8300S Page Options Dialog Box



Note

- Available only if rolls are selected in **Paper Source**.
- You can input between 203.2 and 18000.0(mm) (between 8.00 and 708.66(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Order

Set the object layout order.

The following settings are available for order.

| Setting | Details |
|----------------------|---|
| Upper Left to Right | The objects are laid out from upper left to right. |
| Upper Left to Bottom | The objects are laid out from upper left to bottom. |
| Upper Right to Left | The objects are laid out from upper right to left. |
| Lower Left to Top | The objects are laid out from lower left to top. |



Note

- When you have selected Roll Paper Length > Auto Settings and Paper Orientation > Vertical, you can choose Upper Left to Right or Upper Right to Left.
- When you have selected Roll Paper Length > Auto Settings and Paper Orientation > Horizontal, you can choose Upper Left to Bottom or Lower Left to Top.

Margins

You can input the paper margins in numerical characters.




Note

- You can input between 0.0 and 50.0(mm) (between 0.00 and 1.97(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Zoom Dialog Box

This dialog box appears when you select **Zoom** from the **View** menu. You can enlarge or reduce the screen display.



• Scaling

Set the magnification for enlargement or reduction of the screen display.



Note

- You can input between 25 and 400.
- You can change the numbers by clicking ▼ button.


Zoom Dialog Box iPF8300S

Format Dialog Box

This dialog box appears when you select Format from the Object menu after you select an object.

Size Sheet

You can rotate, enlarge, or reduce an object.





Note

• When the objects are not selected, you can not select **Format**.

Rotate

When you place a checkmark here, you can select Rotate Right or Rotate Left.

| Setting | Details |
|--------------|---|
| Rotate Right | Rotates the object 90 degrees clockwise. |
| Rotate Left | Rotates the object 90 degrees counterclockwise. |



Note

• When several objects are selected, you cannot select **Rotate**.

• Enl./Red.

When you place a checkmark here, you can select Scaling, Fit Paper Size, or Fit Photo Size.

| Setting | Details |
|---------|---|
| Scaling | Allows you to input the value of the enlargement or reduction ratio of an object. |

iPF8300S Format Dialog Box

| Setting | Details |
|----------------|---|
| Fit Paper Size | Prints by enlarging or reducing each object to match the paper size. If you are using roll paper, objects are enlarged or reduced so that the width of each object matches the width of the roll paper. |
| Fit Photo Size | Prints all of the objects at the specified photo size. |




Note

- You can input between 25 and 600.
- You can change the numbers by clicking either ▲ button or ▼ button.

Position Sheet

You can rotate, enlarge, or reduce an object.





Note

• When the objects are not selected, you can not select **Format**.

Object Position

You can move the object position by changing the values.

| Setting | Details |
|----------------|--|
| Vertical Pos | You can input the number of the vertical position in numerical characters. |
| Horizontal Pos | You can input the number of the horizontal position in numerical characters. |
| Page Pos | You can input the number of the page position in numerical characters. |

Object Size

You can confirm the object size.

Format Dialog Box iPF8300S



Note

• When several objects are selected, you cannot display **Object Size**.

Laying out a Multiple-File Document on One Page


You can lay out and print a multiple-file document on one page.

1. From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



Note

- Normally, select **Print** from the **File** menu.
- 2. Click **Properties** to open the **Properties** dialog box.




3. In the Page Setup sheet, select Paper Source.





Note


- Your printer is depicted in the lower-left area of this screen.
- 4. In the Layout sheet, click on the Page Layout check box and select Free Layout from the list.





Note

- Your printer is depicted in the lower-left area of this screen.
- When you select Free Layout, all other setting items will be disabled.
- **5.** Click the **OK** button to save the settings.
- **6.** In the **Print** dialog box, select the pages to print and the number of copies, and click the **OK** button.



Free Layout starts, laying out the document created with application software in the layout area as an object.



. . .

7. Leaving Free Layout running, open other files with the application software and repeat the above steps.

Laying out a Document Created with Multiple Application Programs on One Page

You can lay out and print a document created with multiple application programs on one page.


1. From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.




Note

• Normally, select **Print** from the **File** menu.


2. Click **Properties** to open the **Properties** dialog box.



3. In the Page Setup sheet, select Paper Source.




- Note
- Your printer is depicted in the lower-left area of this screen.
- 4. In the Layout sheet, click on the Page Layout check box and select Free Layout from the list.






Note

- Your printer is depicted in the lower-left area of this screen.
- When you select Free Layout, all other setting items will be disabled.
- **5.** Click the **OK** button to save the settings.
- **6.** In the **Print** dialog box, select the pages to print and the number of copies, and click the **OK** button.



Free Layout starts, laying out the document created with application software in the layout area as an object.



7. Leaving Free Layout running, open other files with other application software and repeat the above steps.

Selecting an Object


When an object is selected, a select box (blue border) appears around the object.





Note

- To select an object, click that object.
- To select multiple successive objects, click them while holding down the Shift key.
- To select multiple arbitrary objects, click them while holding down the Ctrl key.
- To select all objects, select **Select All** from the **Edit** menu.
- When you specify the area with dragging the mouse, the object in the area is selected.



iPF8300S Selecting an Object

Changing the Object Size

You can change the object size by means of mouse operation or by specifying a scaling value.




Note

• The vertical-to-horizontal ratio remains unchanged when the object is enlarged or reduced.

Resizing by means of mouse operation

- 1. Select an object.
- 2. Place the pointer at a corner of the selection box around the object to show the arrow handle, and drag this handle to change the object size.



Resizing by specifying a scaling value

- 1. Select an object.

 Click on the Enl./Red. checkbox in the Format Dialog Box P.271 and select Scaling.
- 2. You either enter numbers directly.



Note


- You can input between 25 and 600.
- You can change the numbers by clicking either ▲ button or ▼ button.
- **3.** Click the **OK** button.

Moving an Object

You can move the object position.

1. Select an object.

2. Place the pointer inside the selection box of the object to show the crosshair handle, and drag it to move the object. Alternatively, you can move the **Object Position** by changing the values in **Vertical Pos**, **Horizontal Pos** and **Page Pos** in the Format Dialog Box P.271.




Rotating an Object

You can rotate the object.


- 1. Select an object.
- 2. Select Rotate Left 90 Degrees or Rotate Right 90 Degrees from the toolbar.

 Alternatively, you may click on the Rotate check box in the Format Dialog Box —P.271 then select Rotate Right or Rotate Left, and click the OK button.



iPF8300S Rotating an Object

Click **Auto Arrange Object** in the tool bar. This automatically lays out objects. Alternatively, you may select **Auto Arrange Object** from the **Object** menu.



Note

• The object layout order varies depending on the **Order** setting in the Page Options Dialog Box —P.269 dialog box.

Aligning Objects


You can align objects systematically.

- 1. Select multiple objects.
- 2. Click the align button from the toolbar.

 Alternatively, you may select the align menu from the **Object** menu.

Align Top


Lays out the objects, justifying them to the top.



J


Center Vertically

Lays out the objects, justifying them to the vertical center.




Align Bottom

Lays out the objects, justifying them to the bottom.




Align Left

Lays out the objects, justifying them to the left.




iPF8300S Aligning Objects

Lays out the objects, justifying them to the horizontal center.



Align Right

Lays out the objects, justifying them to the right.



Changing the Object Overlapping Order

You can change the object overlapping order.

- 1. Select an object.
- 2. Select the Overlapping Order menu from the **Object** menu.




Note

- The order of overlapping affects the order of objects automatically laid out.
- You can also select by clicking the right button of the mouse on an object.

3


Bring to Front

Moves the object to the frontmost position.




Send to Back

Moves the object to the backmost position.




Bring Forward

Moves the object one position to the front.



Send Backward

Moves the object one position to the back.



Pasting a Copied or Cut Object

- 1. Click Copy or Cut from the toolbar.

 Alternatively, you may select Copy or Cut from the Edit menu.
- 2. Click Paste from the toolbar.
 Alternatively, you may select Paste from the Edit menu.



Note

- The copied or cut object is laid out at the end of the page.
- You can also select by clicking the right button of the mouse on an object.
- In order to paste an object on any position that you like, you can paste the object with **Pointed Paste** by clicking the right button of the mouse on any position that you want.

Folded Duplex Window

This window is displayed if you select **Folded Duplex** from the **Edit** menu after selecting an object. Using the **Folded Duplex** function allows you to print with fold lines added.

The Folded Duplex window consists of the menu and tool bars, layout area and status bar.





Note

• The toolbar and status bar can be toggled between hidden and displayed from the View menu.

• Menu Bar

This allows you to select menus required for operations.



Tool Bar


This allows you to select tool buttons required for major operations.



iPF8300S Folded Duplex Window

· Layout Area

This allows you to check the arrangement and orientation of objects.




· Status Bar

This shows the paper source, roll paper width, and output size.

Roll Paper Width:17-in. Roll (431.8mm) Output Size:17.00inch x 44.26inch

Finished Size Settings Dialog Box

This dialog box is displayed when you select **Finished Size Settings** from the **Edit** menu. This allows you to configure finished size settings.



Finished Size


Selects the method for setting the finished size.

The following settings are available for the finished size.

| Setting | Details |
|---|--|
| Fit Roll Paper Width | Prints by automatically enlarging or reducing the entire document so that the width of the document matches the roll paper width. |
| Specify Folded Size | Prints by automatically enlarging or reducing the entire document to match the size of the paper. Select the actual size of the paper you want to print on in Fit Paper Size . |
| Rotate Page 90 degrees (Conserve Paper) | Prints by rotating pages by 90 degrees. Pages are automatically rotated if they will fit within the roll paper width when rotated, and are not rotated if they will not fit within the roll paper width. |

Binding Settings Dialog Box

This is displayed when you select **Binding Settings** from the **Edit** menu. This allows you to configure the binding edge settings.



Binding Edge

Configures the binding edge when folding paper.

The following settings are available for the binding edge.

| Setting | Details |
|---------|--|
| Bottom | Prints by placing the binding margin (gutter) at the bottom of the document. |
| Тор | Prints by placing the binding margin (gutter) at the top of the document. |

Binding

Configures the binding margin (gutter).

Prints by creating a binding margin (gutter) of the specified size. Enter the margin size as a number.



Note

• The values that can be entered are 0 to 50 (mm).

Print Fold Lines

Configures the color and type of fold lines.



Note

• To not print fold lines, clear the **Print Fold Lines** checkbox.

Fold Line Color

You can select the fold lines.

Fold Line Type

You can select the fold lines.

The following settings are available for the fold line type.

| Setting | Details |
|--------------------|---|
| Solid Line | You can print the solid line as the frame style. |
| Dotted Line | You can print the dotted line as the frame style. |
| Dashed Line | You can print the dashed line as the frame style. |

• Only Print Center and Edges

To print fold lines at the center and both edges, select the **Only Print Center and Edges** checkbox.

Prints using Folded Duplex

This prints 2 pages consecutively. Folding back the paper at the fold lines of the center substitutes for duplex printing.

- $f l_{ullet}$ Select two objects from the layout area of Free Layout.
- 2. Select Folded Duplex from the Edit menu of Free Layout.

 Open the Folded Duplex window and arrange the selected objects in the layout area.
- 3. Open the Finished Size Settings dialog box from the Edit menu.
- 4. Select Fit Roll Paper Width or Specify Folded Size in Finished Size.



Note

- Rotate Page 90 degrees (Conserve Paper) is also available when Specify Folded Size is selected.
- **5.** Click **OK** to save the settings.
- **6.** Open the **Binding Settings** dialog box from the **Edit** menu.
- 7. Select **Bottom** or **Top** in **Binding Edge**.
- **8.** Specify the **Binding** width in **Binding**.

9. Configure the Fold Line Color and Fold Line Type from Print Fold Lines.



Note

- When the **Only Print Center and Edges** checkbox is selected, fold lines are only printed at the three locations of the center and both edges.
- 10. Click o_K to save the settings.
- 11. Confirm the print setting and begin printing.

Color imageRUNNER Enlargement Copy

| The Features of Color imageRUNNER Enlargement Copy | 292 |
|---|-----|
| Operating Environment | |
| Starting Color imageRUNNER Enlargement Copy | |
| Color imageRUNNER Enlargement Copy Dialog Box | 294 |
| Hot Folder | 295 |
| Creating a New Hot Folder | 296 |
| Specifying an Existing Shared Folder as a Hot Folder | |
| Setting the Print Parameters | 303 |
| Printing Enlargements of Scanned Originals from a Color imageRUNNER | |

The Features of Color imageRUNNER Enlargement Copy

The main features of Color imageRUNNER Enlargement Copy are as follows.

- Allows the document scanned with the Color imageRUNNER to be automatically enlarged and printed.
- You can perform basic printer settings such as printer selection, media type and output profile selection, and matching
 methods, in addition to borderless printing and enlargement/reduction process without growing through the printer
 driver.



Note

• The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Color imageRUNNER Enlargement Copy settings.

Operating Environment

You can use the Color imageRUNNER Enlargement Copy in the following environments.

 Compatible Operating System Windows XP, Windows Server 2003, Windows Server 2003 R2, Windows Vista, Windows Server 2008, Windows 7



Note

- This function is not available on 64-bit version of Windows.
- For the Windows OS, use the latest version of Service Pack.
- Software that requires installation imagePROGRAF Printer Driver

292

Starting Color imageRUNNER Enlargement Copy


Follow the procedure below to start the Color imageRUNNER Enlargement Copy.

To start by selecting **Printers and Faxes** from the **start** button


1. Open the folder of the OS you are using for configuring printers.

For example, on Windows XP click the **start** button on the desktop, and then select **Printers and Faxes**.

2. Right-click the Printers icon and select **Printing Preferences** to open the **Printing Preferences** dialog box. In the **Utility** sheet, click the **Color imageRUNNER Enlargement Copy** button.



3. The Color imageRUNNER Enlargement Copy dialog box displays.



Note


• If you click on the **Add to Startup folder** check box in the **Color imageRUNNER Enlargement Copy** dialog box, the icon of Color imageRUNNER Enlargement Copy utility will appear on the task bar when starting Windows thereafter.

To start by selecting Color imageRUNNER Enlargement Copy from the start button

 ${f 1.}$ From the Windows start button, select Color imageRUNNER Enlargement Copy.




2. The Color imageRUNNER Enlargement Copy dialog box displays.



Color imageRUNNER Enlargement Copy Dialog Box

The explanation below is on the Color imageRUNNER Enlargement Copy dialog box.



294



• For the step to open the Color imageRUNNER Enlargement Copy dialog box, see "Starting Color image-RUNNER Enlargement Copy." →P.292

Hot Folder

The hot folder list appears.

Add Button

Click the button to open the **Easy Setup Wizard** dialog box so that you can add a hot folder.

• Edit Button

From the **Hot Folder** list, select a hot folder and click the button to open the **Add/Edit Hot Folder** dialog box that allows you to edit the hot folder.

• Delete Button

From the **Hot Folder** list, select a hot folder and click the button to delete the hot folder.

• Start Button

Clicking the button changes the status of the selected **inactive** Hot Folder to **active**.

• Stop Button

Clicking the button changes the status of the selected active Hot Folder to inactive.

Add to Startup folder

Register the application in the Windows startup menu.

Save Printed Data

Automatically saves printed data.

About Button

Click the button to display the name and the version number of the utility.

• Operation Guide Button

Click the button to display the Color imageRUNNER Enlargement Copy Setup Manual.

Hot Folder

Hot folder refers to a folder used for Color imageRUNNER Enlargement Copy.

- When transferred to the PC's hot folder, the document data scanned with the Color imageRUNNER is printed in enlarged size from the printer according to the print conditions set in the hot folder.
- You can create a new hot folder, edit or delete an existing one, and set print conditions at will.




Note

• You can create up to 20 hot folders.

iPF8300S Hot Folder

Creating a New Hot Folder

1. Open the Color imageRUNNER Enlargement Copy dialog box, and then click the Add button.






Note

- For the step to open the Color imageRUNNER Enlargement Copy dialog box, see "Starting Color imageRUNNER Enlargement Copy." —P.292
- 2. The Easy Setup Wizard dialog box displays. Click the Next button.



3. Select the type of printer to use. Click the **Next** button.




4. Select the media type to print.




Note

• If the **Borderless Printing** checkbox is checked, only media types that can be used for borderless printing are displayed in the list.


Click the Next button.



5. Select roll paper or cut sheet to print. Also, select the media size to print. Click the **Next** button.



6. Select the color matching method. Click the **Next** button.




7. To receive a document scanned with the Color imageRUNNER, you need to share a folder. Enter the folder shared name in Shared Name.
Click the Next button.




Note


- This shared name is used as the name of the hot folder.
- You cannot use the **Back** button, after clicking the **Next** button here.



8. Click Finish button to close the Easy Setup Wizard dialog box.




The hot folder you have created appears in the **Hot Folder** list in the **Color imageRUNNER Enlargement Copy** dialog box.



Specifying an Existing Shared Folder as a Hot Folder

- 1. Share the folder you want to specify as a hot folder.
- 2. Open the Color imageRUNNER Enlargement Copy dialog box, and then click the Add button.



300




• For the step to open the Color imageRUNNER Enlargement Copy dialog box, see "Starting Color imageRUNNER Enlargement Copy." →P.292


3. The **Easy Setup Wizard** dialog box displays. Click the **Manual Settings** button.




4. The **Add/Edit Hot Folder** dialog box displays. Enter the hot folder name in **Name**. Click the **Browse** botton, with selecting **Specify a folder**, to set the existing shared folder.




5. The location of the folders will appear.
Select the folder to specify a hot folder, and click the **OK** button.



6. As necessary, set the print conditions in the hot folder. (See "Setting the Print Parameters.") P.303 Click the OK button to close the Add/Edit Hot Folder dialog box.




The hot folder you have created appears in the **Hot Folder** list in the **Color imageRUNNER Enlargement Copy** dialog box.



Setting the Print Parameters

The printer driver opens when you click the **Properties** button in the **Add/Edit Hot Folder** dialog box. The printer driver is used to configure basic settings to match the type of media loaded in the printer.



Refer to Printer Driver —P.202 for details on the printer driver.



Note

• The only three sheets displayed are the **Main** sheet, the **Page Setup** sheet, and the **Layout** sheet. Some of the printer driver settings may be disabled.

Apply Sharpness

Place a checkmark here to set the sharpness.

Drag the slider bar to the left or right to adjust. You can also adjust by directly entering a number in the numeric input field.



Note

- You can input between 0 and 500.
- You can change the numbers by clicking either ▲ button or ▼ button.
- You cannot be applied to PDF files.

Printing Enlargements of Scanned Originals from a Color imageRUNNER

Scanned originals from a Color imageRUNNER can be enlarged and printed automatically.

Originals you create by scanning with a Color imageRUNNER are transferred to a "hot folder" and printed automatically after enlargement according to printing conditions you specify for that folder.

This processing sequence is called the Color imageRUNNER Enlargement Copy function.

To use Color imageRUNNER Enlargement Copy, first complete these settings in the following order.

- 1. Register a hot folder on your computer.

 Register a hot folder on your computer for storing scanned originals from the Color imageRUNNER and complete the settings for enlargement copy.
- **2.** Complete the scanning settings on the Color imageRUNNER. Configure the Color imageRUNNER to send scanned originals to the hot folder.


After these settings are complete, you can print enlarged copies of scanned originals from the Color imageRUNNER.

Registering a hot folder on your computer

Folders used for **Color imageRUNNER Enlargement Copy** (iR enlargement copy) are called hot folders. Register a hot folder on your computer for storing scanned originals from the Color imageRUNNER. You can specify printing conditions (such as the image quality and paper size), based on which originals transferred to the hot folder will be printed. Follow these steps to register and modify hot folders.

1. Display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from the Operating System Menu .") →P.213

2. Click the **Utility** tab to display the **Utility** sheet.



- 3. Click Color imageRUNNER Enlargement Copy to start the Color imageRUNNER Enlargement Copy utility.
- **4.** Use the Color imageRUNNER Enlargement Copy utility to register or modify hot folders. For instructions on registering and modifying hot folders, refer to the help file for the Color imageRUNNER Enlargement Copy utility.

Completing the scanning settings on the Color imageRUNNER.

Configure the Color imageRUNNER to send scanned originals to the hot folder. It is easy to send scanned originals to the hot folder if you assign the scanning settings and destination to a **Favorites** button on the Color imageRUNNER. For instructions on assigning scanning settings and destinations to a **Favorites** button, refer to the setting manual, displayed by clicking **Color imageRUNNER Enlargement Copy Setup Manual** button of Color imageRUNNER Enlargement Copy utility, or refer to the Color imageRUNNER manual.

Scanning the original and print an enlargement

Follow the steps below to scan an original on the Color imageRUNNER for enlarged printing on the printer. For detailed instructions, refer to the Color imageRUNNER manual.

- 1. Load the original on the platen glass or document feeder of the Color imageRUNNER.
- 2. Press **Send** to display the screen for transmission.
- **3.** Press **Favorites**, and then press the **Favorites** button assigned to the hot folder.

4. Press **Start** on the control panel. If you scan originals on the platen glass, after scanning all originals, press **Done** on the touch-panel display.

Scanned originals are sent to the hot folder and automatically enlarged and printed following the conditions you specified for the folder.

Print Plug-In for Photoshop/Digital Photo Professional

| The Features of Print Plug-In | 308 |
|--|-----|
| Operating Environment | |
| Installation Procedures | 309 |
| Uninstall Procedures | 312 |
| Starting from Photoshop | 312 |
| Starting from Digital Photo Professional | |
| Print Plug-In Main Window | |
| Preview Area | 317 |
| Main Sheet | 318 |
| Page Setup Sheet | 322 |
| Color Settings Sheet | |
| Print History Sheet | |
| Support Sheet | 327 |
| Paper Detailed Settings Dialog Box | 328 |
| Set Configuration Dialog Box | |
| ICC Conversion Options dialog box | 331 |
| Roll Paper Options Dialog Box | 332 |
| Size Options Dialog Box | 333 |
| Curves Dialog Box | 334 |
| Print History Details Dialog Box | 335 |
| Utilize Three Types of Previews | 336 |
| Check Image with Print Area Layout | 337 |
| Check the original image with Image | 338 |
| Check Image with Roll Paper Preview | |
| Print with a Desired Picture Quality | |
| Adjust the Colors and Print | |
| Adjust the Colors while Checking the Preview (for Color) | |
| Adjust the Colors while Checking the Preview (for Monochrome) | |
| Adjust the Colors by Color Matching | |
| Print High-Quality Adobe RGB16bit Images | |
| Prints monochrome photographs with high quality | |
| Using Adobe CMM | |
| Perform Black Point Compensation | |
| Perform Printing Press Simulation Print | |
| Enlarge/Reduce and Print | |
| Enlarge/Reduce and Print Matching Output Media Size | |
| Enlarge/Reduce and Print Matching Width of Roll Paper | |
| Specify Scaling, Enlarge/Reduce and Print Print with No Borders | |
| Customize Media Settings | |
| Utilize Print History | |
| Confirm Print History Details | |
| Apply Print History to an Image | |
| Store Print History to Print Preferences | |
| Delete Print History | |
| Export Print History from Print Preferences | |
| Import Print History to Print Preferences | |
| Delete Print History from Print Preferences | |
| Set Information to Print with Image | |
| ∵ | |

The Features of Print Plug-In

The main features of Print Plug-In are as follows.

- You can automatically detect the color space of Adobe RGB or sRGB-use images, etc., and automatically set optimal
 profiles. Thus, you can print without the trouble of configuring settings.
- You can directly process image data on Photoshop, and forward the image data to a printer. In this way, you can process 16-bit image data in addition to 8-bit image data.
- By using the preview function for images based on real images, and the preview function for layouts based on image positioning by media size, you can use this software to make color adjustments and confirm print layout.
- You can perform basic printer settings such as printer selection, media type and output profile selection, and matching
 methods, in addition to borderless printing and enlargement/reduction process without growing through the printer
 driver.
- By using the print history management function, you can import past print settings parameters. Additionally, you can save preferences as a file.



Note

- The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Print Plug-In settings (the arrangement of the image in the layout preview, the print start position, and the media size).
- Loss of gradation in dark areas can be reduced by performing black point compensation.



Note

- Adobe CMM is required in order to use the black point compensation function.
- You can perform printing press simulation printing by specifying the printing press profile.

Operating Environment

The Print Plug-In operating environment is as follows.

- Compatible Operating System Windows XP, Windows Vista, Windows 7
- Compatible Photoshop Version Photoshop CS5, Photoshop CS4, Photoshop CS3
- Compatible Digital Photo Professional Version Digital Photo Professional 3.8x or later
- Software needed for Print Plug-In Installation Photoshop or Digital Photo Professional, imagePROGRAF Printer Driver



Note

- For the Windows OS, use the latest version of Service Pack.
- The version of supporting OS differs for each version of Photoshop, For details, consult Adobe Incorporated.
- 32-bit Print Plug-In in 32-bit Photoshop and 64-bit Print Plug-In in 64-bit Photoshop must be installed.
- The supported OS version differs for each version of Digital Photo Professional.

Installation Procedures

The procedures to install Print Plug-In are as follows.

 $oldsymbol{1}$. Insert the User Software CD-ROM into the CD-ROM drive to start the installer.



Note

- If the installer screen does not appear, open the CD-ROM icon in My Computer and click on setup.exe to open the icon.
- 2. Click imagePROGRAF Print Plug-in button.




- $\bf 3.$ Click the appropriate Install button for your Print Plug-In.
 - For 32-bit Windows



iPF8300S Installation Procedures


• For 64-bit Windows



Note

- If a version of Photoshop that is not compatible with Print Plug-In is installed, the message **No** target software exists. is displayed. Install Print Plug-In in a computer with a compatible Photoshop installed. (See "Operating Environment.") —P.308
- If the folder for the Photoshop Plug-In to install Print Plug-In cannot be found, **Specify the destination for installation of the plug-in?** will appear. In this case, refer to the Photoshop manual then specify a folder for the Plug-In.
- The Print Plug-In cannot be installed in Photoshop until after Photoshop has been installed and then opened at least once on a PC. Install the Print Plug-In after installing, opening and quitting Photoshop.

4. Click Next button.




310

Installation Procedures iPF8300S

5. After you have read the Licensing Agreement, select I accept the terms of the license agreement and click the Next button.




6. Click Install button.



iPF8300S Installation Procedures

7. Click Finish button.



Print Plug-In installation is complete.

Uninstall Procedures

The procedures for uninstalling the Print Plug-In are as follows.

- Uninstall the Print Plug-In for Photoshop
 - 1. Select start in Control Panel menu.
 - 2. Open Add or Remove Programs (For Windows 7 and Windows Vista, Programs and Features).
 - 3. Select Canon iPFxxxx Print Plug-In for Photoshop xx, then click Change/Remove.
- Uninstall the Print Plug-In for Digital Photo Professional
 - 1. Select start in Control Panel menu.
 - 2. Open Add or Remove Programs (For Windows 7 and Windows Vista, Programs and Features).
 - 3. Select Canon iPFxxxx Print Plug-In for Digital Photo Professional, then click Change/Remove.



Note

• iPFxxxx is the name of your printer.

Starting from Photoshop

Follow the procedure below to start the Print Plug-In from Photoshop.

1. Start Photoshop.


Uninstall Procedures iPF8300S

- 2. Open the image that you wish to print.
- **3.** If required, select the print range.



Note

- Images for use with Print Plug-In are less than 60,000 pixels in width and height. Reduce the selection range or reduce the image with processing for images more than 60,000 pixels in width and height, and then attempt step 3.
- 4. Select Export(or Data Export) from the File menu and then select the output plug-in that matches your printer. The imagePROGRAF Print Plug-In for Photoshop window (known below as the Print Plug-In window) is displayed.





Important

• When a profile is created with a commercially available profile creation tool, it may be created in ICCv4 format. When an image source profile is ICCv4, you must install AdobeCMM or use Print Plug-In in a Windows Vista or later environment.

When Adobe CMM is not installed in a Windows XP environment, a message is displayed, and the source profile changes to Adobe RGB. To use an ICCv4 profile in a Windows XP environment, exit Plug-In and then install Adobe CMM. For details on installing Adobe CMM, refer to Using Adobe CMM P.349.



Note

• If the message below is displayed but the Print Plug-In window is not displayed, install the newest imagePROGRAF printer driver and then attempt step 3.

The imagePROGRAF Printer Driver for iPFxxxx is either not installed correctly or not installed at all. Please install.

(The iPFxxxx portion of the above message will reflect your printer name.)

- If the message below is displayed but the Print Plug-In window is not displayed, convert the color space of the image to either RGB color, grayscale, or CMYK color and then attempt step 3.

 Set the color space of the image to either RGB color, grayscale, or CMYK color.
- When the color space of the entry screen is CMYK, it changes to AdobeRGB due to processing with Print Plug-In. Also, [Relative Colorimetric] is used for the matching method.

iPF8300S Starting from Photoshop

Starting from Digital Photo Professional


Follow the procedure below to start the Print Plug-In from Digital Photo Professional.

- **1.** Start Digital Photo Professional.
- 2. Open the RGB color image that you want to print.
- **3.** If required, select the print range.



Note

- Images for use with Print Plug-In are less than 6,000 pixels in width and height. Reduce the selection range or reduce the image with processing for images more than 6,000 pixels in width and height, and then attempt step 3.
- 4. Select **File** from the **Plug-in printing** menu and then select the output plug-in that matches your printer. The imagePROGRAF Print Plug-In for Digital Photo Professional window (hereinafter referred to as the Print Plug-In window) is displayed.






Important

• When a profile is created with a commercially available profile creation tool, it may be created in ICCv4 format. When an image source profile is ICCv4, you must install AdobeCMM or use Print Plug-In in a Windows Vista or later environment.


When Adobe CMM is not installed in a Windows XP environment, a message is displayed, and the source profile changes to Adobe RGB. To use an ICCv4 profile in a Windows XP environment, exit Plug-In and then install Adobe CMM. For details on installing Adobe CMM, refer to Using Adobe CMM P.349.

The Print Plug-In main window consists of the sheet selection area, and the preview and button area.



· Sheet Selection Area

The tabs used to switch between each sheet on the Print Plug-In window are displayed.




When you select a tab, a sheet is displayed. The settings available on each sheet are as follows.

- Main Sheet →P.318
- Page Setup Sheet →P.322
- Color Settings Sheet →P.325
- Print History Sheet →P.326
- Support Sheet →P.327

· Preview Area


You can check the settings you made on the image in this area.



About the settings available on the preview area, see "Preview Area." —P.317

· Button Area

This contains the buttons Print, Quit and Help



• PrintButton


Click this button to begin printing.

- QuitButton
 - Click this button to close the Print Plug-In window and return to application software.
- HelpButton

Click this button to display the Print Plug-In Help file.

Preview Area

You can check the settings you made on the image in this area.



• Preview

Select the preview display method.

For more information about preview, see "Utilize Three Types of Previews." -P.336

| Setting | Details |
|--------------------|--|
| Print Area Layout | Displays the print range and the area out of the print range in the layout matching the Paper Size set. |
| | *You can change the image print position when you drag the image while the cursor is displayed as . |
| Image | The entire image is displayed. |
| | *You can select the print range when you drag the image while the cursor is displayed as *When you click the image while the cursor is displayed as deselected. |
| Roll Paper Preview | Display the media size and roll paper information on the top in the layout printing on roll paper. |
| | *To select Roll Paper Preview, select Roll Paper in Paper Source. |

• Print Selected Range

Place a checkmark here to only print the selected range.



Note

• When you select **Preview** in the **Image**, then select a portion of the image on the preview display, this becomes valid.

• Perform Proof in Preview

Place a checkmark here to simulate the colors of the output product in the preview.

iPF8300S Preview Area




Note

- If Auto (Color) is selected under Output Profile, some media types are enabled.
- If ICC profile is selected under **Output Profile**, this is always enabled.
- The actual color balance of the print product and the simulation product may differ with some environments and conditions. In addition, when you have selected an ICC Profile with **Output Profile** and it is not compatible with the printer or media that you are using, the color balance of the actual print product will differ.

• Image Properties button

When you click the button to open the **Image Properties** dialog box, where **Image Size**, **Resolution**, **Bit** and **Color Space** information of the image imported to Print Plug-In are displayed. Click the **Close** button to return to Print Plug-In.



Main Sheet

You can use this sheet to perform basic settings such as selecting a printer, setting the media type, or adjusting image quality.



Printer

The printer types are displayed.

Main Sheet iPF8300S

• Select button

Click this button to display the **Select Printer** dialog box.

When you click the **OK** button after selecting the printer in the **Select Printer** dialog box, you can change the printer that corresponds with Print Plug-In.

Media Type

This allows you to select the media type.

For more information about Media Type, see "Customize Media Settings." —P.358



Note

• Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.

· Advanced Settings button

Click the button to display the Paper Detailed Settings dialog box.

For more information about the media detailed settings, see "Paper Detailed Settings Dialog Box." - P.328

Input Resolution to Plug-in

You can select the resolution to process the image with Print Plug-In.

The following settings are available for resolution.

| Setting | Details |
|----------------------|--|
| Accuracy 300ppi | This processes images at an accurate resolution. This can control print speed and memory capacity. |
| High Accuracy 600ppi | This processes images at a more accurate resolution. This setting results in the best print quality, but this takes more time to print than Accuracy 300ppi while also requiring more memory capacity. *This may not be displayed depending on how you set Media Type |

· Input Bit to Plug-in

You can select the bit number to process with Print Plug-In.

The following settings are available for the input bit number.

| Setting | Details |
|-------------------------|--|
| High Gradation 8bit | This processes images with at 8bit/channel (24 bit). |
| Highest Gradation 16bit | This processes images with at 16bit/channel (48 bit). |
| | *This may not be displayed depending on how you set Media Type and Input Resolution to Plug-in . |

Print Mode

Selecting the printing mode strikes the balance between the quality of the printed image and printing speed. The following settings are available for the print mode.

| Setting | Details |
|---------|---|
| Highest | A setting for printing at the highest resolution when quality is most important. Printing takes longer and consumes more ink than in other modes, but this mode offers superior printing quality. |

iPF8300S Main Sheet

| Setting | Details |
|------------------------------|--|
| High | Choose this setting to print at high resolution when quality is most important. Printing takes longer and consumes more ink than in Standard or Fast modes, but this mode offers exceptional printing quality. |
| Standard | Choose this setting to print at standard resolution when quality and speed are both important. Printing takes less time than in Highest or High mode. |
| Fast | Choose this setting to print faster. Printing in fast mode can help you work more efficiently when checking layouts. |
| Highest (Max. No. of Passes) | If you are concerned about uneven colors in the print result of Highest quality , selecting this option may improve printing results. However, printing may take longer. |



Note

• The selectable fields may vary according to the Media Type, Input Resolution to Plug-in and Input Bit to Plug-in settings.

Output Profile

You can select the output profile.

The following settings are available for the output profile.

| Setting | Details |
|----------------------------|--|
| Auto (Color) | Performs the optimum color conversion from the input image data color space information (sRGB, Adobe RGB), media settings etc. You should normally select these settings. |
| Auto (Monochrome Photo) | Performs the best color conversion to monochrome from the input image data color space information (sRGB, Adobe RGB), media settings etc. |
| None (No Color Correction) | You cannot perform color conversion with a plug-in. This is useful for creating an original ICC profile. |
| External ICC Profiles | This selects printer ICC profiles to be output to ICC profiles saved in the OS standard folder. Use the color space of the input data as well as the select ICC profile to perform color conversion. |



Important

• To use an ICCv4 profile, you must install AdobeCMM or use Print Plug-In in a Windows Vista or later environment. For details on installing Adobe CMM, refer to Using Adobe CMM P.349.



Note

• Auto (Monochrome Photo) can only be selected for the corresponding media types.

Proof

This is displayed when an ICC profile is selected as the **Output Profile**.

When this is checked, you can perform printing press simulation prints.

Refer to Perform Printing Press Simulation Print —P.352 for details on printing press simulation prints.

Matching Method

You can select the processing method when performing color conversion.

The following settings are available for the matching method.

Main Sheet iPF8300S

| Setting | Details |
|-----------------------|--|
| Perceptual | This converts the image to an image with natural color balance and gradation. This is useful for pictures. |
| Saturation | This converts the image to an image with heightened color saturation. The color balance of pictures and drawings may change. |
| Relative Colorimetric | This converts the image with emphasis on color balance before the conversion or on visual color balance. This is useful for pictures and drawings. |



Note

• When the **Output Profile** you have set is **Auto (Monochrome Photo)** or **None (No Color Correction)**, you cannot select a matching method.

• ICC Conversion Options button

This is displayed when an ICC profile is selected as the **Output Profile**.

When this button is clicked, the ICC Conversion Options dialog box is displayed allowing you to configure color conversion related settings.

Refer to ICC Conversion Options dialog box P.331 for details on ICC Conversion Options.

Copies

You can input the number of print copies in numerical characters.



Note

- The maximum value is 99.
- You can change the numbers by clicking either ▲ or ▼.

• Set Configuration button

Clicking the button opens the **Set Configuration** dialog box that provides settings for the adjustment of image sharpness and image enlargement method.

For more information about Set Configuration, see "Set Configuration Dialog Box." (\$\infty\$P.330)


• Defaults button

Click the button to return all of the settings on the **Main** sheet to their defaults.

iPF8300S Main Sheet

Page Setup Sheet

You can use this sheet to set the size of the image to be printed, the media size, and whether to enlarge/reduce the image.



Input Image Size

The size of the image imported to Print Plug-In is displayed.

Borderless Printing

When you place a checkmark here, the **Specify Roll Paper Width** dialog box is displayed and you can print an image without borders.

For more information about **Borderless Printing**, see "Print with No Borders." (¬P.357)



Note

• Available only if rolls are selected in **Paper Source**.

• Enlarged/Reduced Printing

When you place a checkmark here, you can print enlarged/reduced images.

When printing an enlarged/reduced image, select the method for enlargement/reduction. The image size sent to the printer is displayed matching the selected method in **Output Image Size**.

The following settings are available for enlarged/reduced printing.

| Setting | Details |
|----------------------|--|
| Fit Paper Size | This automatically enlarges/reduces the entire image imported to Print Plug-In to match the export media size when printing. |
| Fit Roll Paper Width | This automatically enlarges/reduces the entire image imported to Print Plug-In to match the width of the roll paper with the width of the image when printing. *Displayed only if rolls are selected in Paper Source . |
| Scaling | This enlarges/reduces the entire image by the specified scaling value. Input the scaling value in numerical characters. You can specify a range between 5-600%. *You can change the numbers by clicking either ▲ or ▼. |

Page Setup Sheet iPF8300S



Note

• This is not displayed when a checkmark is placed in Borderless Printing.

Output Image Size

The output image size is displayed up to one place after the decimal point in millimeters.



Note

• When Paper Size is smaller than Output Image Size, part of the image may not print.

Paper Size

You can select the size of the print media.



Note

- This is not displayed when a checkmark is placed in Borderless Printing.
- This is not displayed when Fit Roll Paper Width is set in Enlarged/Reduced Printing.

Orientation

This selects the print orientation.

The following settings are available for orientation.

| Setting | Details |
|-----------|--|
| Portrait | Prints the image on the media as it appears on the screen. |
| Landscape | Prints the image on the media rotated 90 degrees. |

Layout

You can select the print position of an image on the media.

The following settings are available for layout.

Layout

| Setting | Details | |
|------------------------------------|---|---|
| Upper-Left of Output Paper Size | Prints the image with fitting the top left of the active print area for Paper Size . | |
| Center of Output Paper Size | Prints the center of the image on the center of the selected Paper Size . | |
| Specify Print Start Position | You can print with specifying the top and left printing start positions in From Top Margin and From Left Margin for Paper Size. | |
| | From Top Margin | Input the margin from the top of the media in numbers. |
| | | *You can input between -9999 and 9999 mm. |
| | From Left Margin | Input the margin from the left of the media in numbers. |
| | | *You can input between -9999 and 9999 mm. |

Note

• Select Print Area Layout or Image in Preview when you select Layout.

Roll Paper Layout

iPF8300S Page Setup Sheet

| Setting | Details |
|--------------------------|---|
| Upper-Left of Roll Paper | Prints the top left of Media Size on the top left of the selected roll paper. |
| Center of Roll Paper | Prints the center of Media Size on the center of the selected roll paper. |



Note

• Select Roll Paper Preview in Preview when you select Roll Paper Layout.

Paper Source

You can select the media source.

The following settings are available for media source.

| Setting | Details |
|------------|-----------------------------------|
| Roll Paper | Select to print on roll paper. |
| Cut Sheet | Select to print on the cut sheet. |

• Roll Paper Options button

Click this button to open the **Roll Paper Options** dialog box, where you can set roll paper width and perform auto cut settings.

For more information about the roll paper options, see "Roll Paper Options Dialog Box." (->P.332)

Size Options

Click the Size Options button to open the **Size Options** dialog box and you can select a media name, size and other settings.

For more information about the size options, see "Size Options Dialog Box." —P.333


• Defaults button

Click the button to return all of the settings on the **Page Setup** sheet to their defaults.

Page Setup Sheet iPF8300S

Color Settings Sheet

You can use this sheet to adjust image Color, **Brightness**, [Contrast, Saturation, and you can set the color balance of print product more to your liking.



· Cyan / Magenta / Yellow

You can adjust the strength or weakness of a color by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

Gray Tone

You can adjust gray tone from cool black (cool tones) to warm black (red tones) by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

Brightness

You can adjust the brightness of the printed image without losing the brightest and darkest areas by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

Contrast

You can relatively adjust the brightness of the brightest and darkness areas by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

iPF8300S Color Settings Sheet

Saturation

You can adjust the saturation of vivid color balance to dark color balance by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

• Curves button

Click the button to open the **Curves** dialog box then set the **Channel** and other settings. For more information about **Curves**, see "Curves Dialog Box."


P.334

• Defaults button

Click the button to return all of the settings on the **Color Settings** sheet to their defaults.

Print History Sheet

You can use this sheet to apply settings history used in printing, and to print information, such as the image file name, with the image.



Print History and Favorites

This displays a list of print preferences.

Select **Restore Defaults** and click the **Apply** button to restore all settings to their initial settings.



Note

• You can check the 3 print preferences in the preview display.

Apply button

When you click the button, the print setting content applies to the current image selected with **Print History and Favorites**.

Print History Sheet iPF8300S

3

• **Details** button

Click the Details button to open the **Print History Details** dialog box, where you can manage print history. For more information about the print history details, see "Print History Details Dialog Box." —P.335

Print Information

When you place a checkmark here, you can print the file name and print time and date on the image. The following settings are available for the print position and content.

For more information about **Print Information**, see "Set Information to Print with Image." —P.371


| Setting | Details | |
|----------------------------|---|--|
| Information Print Position | Selects the information print position. | |
| | Top (Header) | Information is printed on the top of the image. |
| | Bottom (Footer) | Information is printed on the bottom of the image. |
| Print History Number | Place a checkmark here to print the print history number. | |
| File Name | Place a checkmark here to print the file name. | |
| Printed at | Place a checkmark here to print the time and date. | |
| Color Adjustment Value | Place a checkmark here to print the color adjustment value. | |
| Printer Name | Place a checkmark here to print the printer name. | |
| Comment | Place a checkmark here to print the comment details. | |
| Comment Details | Place a checkmark here to display the comment details. | |

• Edit Comment button

Click the button to display the **Edit Comment** dialog box, where you can edit the comment.

Support Sheet

You can display product support information and the electronic manual.



iPF8300S Support Sheet

• Support Information button

Click the button to display websites that contain the latest product information.



Note

• An Internet connection is needed to view the websites.

· User Manual button

Click the button to display the printer manuals installed on the computer.



Note


• You must have User Manual installed on your computer.

About button

Click the button to open the version information window of the Print Plug-In. Click the **OK** button in the version information window to return to the Print Plug-In window.

Paper Detailed Settings Dialog Box

This dialog box appears when you click the **Advanced Settings** button on the **Main** Sheet. You can set **Drying Time** and **Roll Paper Margin for Safety** by media type.



Drying Time

Between Pages

This sets the wait time for the ink to dry between each completely printed sheet and the output of the sheet.

| Setting | Details |
|---|--|
| Printer Default | The settings of the printer operating panel are applied. |
| None | The paper is ejected immediately after printing. |
| 30sec. / 1min. / 3min. / 5min. / 10min. / 30min. / 60min. | The sheet is ejected when the specified time after printing has elapsed. |

Between Scans

This sets the wait time between line scans during printing.

| Setting | Details |
|---------------------------------------|--|
| Printer Default | The settings of the printer operating panel are applied. |
| None | The printing continues to the next line immediately after the last line. |
| 1sec. / 3sec. / 5sec. / 7sec. / 9sec. | The printing continues to the next line after the set time. |
| | *For the media type that has problems, such as ink smears on the page or colors that seem uneven during borderless printing etc., increase the value for this setting. |

Roll Paper Margin for Safety

Near End Margin

This sets the length of the near end margin of the roll paper.

| Setting | Details |
|-----------------|--|
| Printer Default | The settings of the printer operating panel are applied. |
| 5mm | Print at a standard size. *Select for Media Type that has no problem when printing with a standard size margin. |
| 20mm | Select this when rubbing against the printhead occurs such as when using paper that tends to curl. |

Cut Speed

This selects the auto cut speed.

| Setting | Details |
|-----------------|--|
| Printer Default | The settings of the printer operating panel are applied. |
| Fast | Select this setting if cutting with the Standard setting is not clean. |
| Standard | Select this setting when you are not experiencing problems. |
| Slow | This helps prevent adhesive from sticking to the cutter and keeps the cutter sharp if you select it when using adhesive paper. |

Calibration Value

When calibration has been carried out on the printer, use this setting to choose whether or not to use the results.

| Setting | Details |
|-----------------|---|
| Printer Default | The settings of the printer operating panel are applied. |
| Use Value | The calibration results are used for printing. |
| Disregard Value | The calibration results are not used for printing. Select this option to avoid changes to image color tones during printing due to color calibration. |

Mirror

Specify whether to print a mirror image, as needed. Select this option to print a version of the document or image with the left and right sides inverted.

Unidirectional Printing

Select this checkbox to prevent problems such as misaligned lines and improve the print quality. However, the printing speed becomes slower.

· High-Precision Text and Fine Lines

Print increasing ink impact accuracy, particularly for sharper text and fine lines. However, this takes more time than regular printing.



Note

• When **Highest (Max. No. of Passes)** is selected as the print mode, **High-Precision Text and Fine**Lines cannot be selected.

Set Configuration Dialog Box

This dialog box appears when you click the **Set Configuration** button on the **Main** Sheet. You can set the adjustment of image sharpness and image enlargement method.



Sharpen

Performs adjustment of the sharpness (outline) settings.

Image Enlargement Method

You can select the image enlargement method.

The following settings are available for the image enlargement method.

| Setting | Details |
|------------------|---|
| Nearest Neighbor | Performs simple enlargement. |
| Bilinear | Performs line vector enlargement. |
| Bicubic | Adjust pixels with calculation of elements such as a color or brightness of neighboring pixels. |

· Close Plug-in After Printing

When you place a checkmark here, the plug-in closes after printing finishes.



Note

• If printing does not finish correctly because it was canceled or an error occurred, the plug-in does not close.

Output Method

You can select the output method.

The following settings are available for the output method.


| Setting | Details |
|-----------------------------------|--|
| Print | Normal printing. The print job data is stored temporarily in the box as the job prints. |
| Save in mail box | Saves the print data in the mail box. If you select Save in mail box, you must specify Name of data to be saved. |
| Print after reception is complete | When you place a checkmark here, you can print after saving jobs in the temporary storage space. This cannot be used when Save in mail box is selected. |

• Initialize all warning dialog boxes

When this is checked, all of the warning dialog boxes that have been set to "Do not show this screen again" become displayed.

ICC Conversion Options dialog box

This is displayed when an ICC profile is selected in the **Output Profile** list in the **Main** sheet and the **ICC Conversion Options** button is clicked. This allows you to configure detailed color matching related settings.



Conversion Engine

Selects the conversion engine to use when converting colors.



Note

• Adobe CMM needs to be installed in order to use **Adobe CMM**. Refer to **Using Adobe CMM**. P.349 for details on how to install Adobe CMM.

Black Point Compensation

Check this check box to perform black point compensation. Loss of gradation in dark areas can be improved by performing black point compensation.



Note

• This can be used if **Adobe CMM** is selected as the **Conversion Engine**.

Proof Options


Configures settings related to printing press simulation.

The proof options consist of the following settings.

| Setting | Details |
|----------------------|--|
| Simulate Paper Color | Select this when performing paper color simulation. When this is on, Simulate Black Ink is automatically turned on and becomes grayed out. |
| Simulate Black Ink | Select this when performing simulation of black ink. In order to enable this setting, Adobe CMM needs to be selected under Conversion Engine . |

Roll Paper Options Dialog Box

This dialog box appears when you click the **Roll Paper Options** button on the **Page Setup** Sheet. You can set the roll paper width and perform the auto cut settings.



Roll Paper Width

This selects the width of the roll media set to the printer.

Automatic Cutting

You can set the printer to cut roll paper automatically or print a guideline for cutting. The following settings are available for automatic cutting.


| Setting | Details |
|---------------------|---|
| Available | Each page is automatically cut after it is printed. |
| None | Each page is not cut after it is printed and printing continues without interruption. |
| Print Cut Guideline | A print cut guideline is printed after each page and printing continues without interruption. |

No Spaces at Top or Bottom (Conserve Paper)

When you place a checkmark here, the print data is printed without margins.

Size Options Dialog Box

This dialog box appears when you click the **Size Options** button on the **Page Setup** Sheet. You can select a media name, size and other settings.



Paper Size List

Displays all the standard sizes and custom media sizes.

Custom Paper Size Name

You can enter any name up to 63 characters.

• Units

You can select the units of measure to use when you define custom media size. Switching this setting resets the units of measure for the entire Plug-In.

Paper Size

Width

Enter the width of the media size.

Height


Enter the height of the media size.

Add button

Click the button to register the contents of the settings.

Curves Dialog Box

This dialog box appears when you click the **Curves** button on the **Color Settings** Sheet. You can set **Channel** and other settings.



Channel

Select from among RGB, Red, Green, or Blue.



Note

• Gray is displayed for monochrome printing and this selection cannot be changed.

Input

Enter an input value.



Note

- The allowed entry range is 0 to 255.
- You can change the numbers by clicking either ▲ button or ▼ button.

Output

Enter an output value.



Note

- The allowed entry range is 0 to 255.
- You can change the numbers by clicking either ▲ button or ▼ button.

Load Curves button

Click the button to load stored data for a tone curve.


• Save Curves button

Click the button to stores the current tone curve settings.

Curves Dialog Box iPF8300S

Print History Details Dialog Box

This dialog box appears when you click the **Details** button on the **Print History** Sheet. This controls print history. For more information about **Print History Details**, see "Utilize Print History." \rightarrow P.359



Print History

Print History appears in list format.

| Display Items | Details |
|----------------------|-------------------------------------|
| Print History Number | Displays the print history number. |
| File Name | Displays image file name. |
| Printed at | Displays time and date of printing. |
| Comment | Displays comment details. |



Note

- Up to 200 print history items can be displayed. All items above 200 are deleted.
- When you cannot print properly because you canceled the printing or an error occurred, appears × to the left of the print history number.

• **Delete** button

Click the button to delete the selected print history.

· Add button

Click the

e button to add the selected print history to preferences.



Note

• Up to 200 print preference items can be added.

Favorites

The print history stored in print preferences displays in list format.



Note

• You can change the order by selecting an item and dragging it to another place.

• Import button

Click the button to import print history saved as a file.

• Export button

Click the button to save print history as a file that is stored in print preferences.

• Delete button

Click the button to delete print history stored in print preferences.

Settings

Displays the print history settings selected from the **Print History** or **Favorites**.

| Setting | Details |
|----------------|--|
| Main | When you select this the Main sheet settings are displayed. |
| Page Setup | When you select this the Page Setup sheet settings are displayed. |
| Color Settings | When you select this the Color Settings sheet settings are displayed. |


Utilize Three Types of Previews

You can use Print Plug-In to check an image in three types of previews. The preview types are as follows.

- Check Image with Print Area Layout →P.337
- Check the original image with Image →P.338
- Check Image with Roll Paper Preview →P.339

Check Image with Print Area Layout

Displays the print range and the area out of the print range in the layout matching the media size set in the print area layout. Select **Print Area Layout** in **Preview**.






Note

- When the cursor on the preview is displayed as on the preview, you can specify the print position by dragging the image.
- When the cursor is displayed as on the preview, the below conditions on the **Page Setup** sheet have all been met.
 - There is no checkmark in **Borderless Printing**.
 - There is no checkmark in Enlarged/Reduced Printing or Scaling has been selected.

Check the original image with Image

In the image preview you can check the entire image that you have input. Select **Image** in **Preview**.




Note

- When the cursor appears as a small magnifying glass the **Selected Range** feature is enabled and you an drag the cursor on the image and select an area for printing.
- When you click the image while the cursor is displayed as on the preview, the selected area is deselected

Check Image with Roll Paper Preview

Display the media size and roll paper information on the top in the layout printing on roll paper in Roll Paper Preview Select **Roll Paper Preview** in **Preview**.






Note

• To select Roll Paper Preview in Preview, select Roll Paper in Paper Source.

Print with a Desired Picture Quality

You can specify and print at the resolution you desire.

1. Display the Main sheet.



2. Select the media set to the printer in Media Type.



Note

- Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.
- Choose either Accuracy 300ppi or High Accuracy 600ppi for the resolution to process images in Input Resolution to Plug-in.



Note

- When you select **Accuracy 300ppi** images are processed at an accurate resolution. This can control print speed and memory capacity.
- When you select **High Accuracy 600ppi** images are processed at a more accurate resolution. This setting results in the best print quality, but this takes more time to print than **Accuracy 300ppi** while also requiring more memory capacity.
- High Accuracy 600ppi will not display with some Media Type settings.
- 4. Choose either **High Gradation 8bit** or **Highest Gradation 16bit** for the bit number when processing images in **Input Bit to Plug-in**.



Note

- When you select **High Gradation 8bit**, images are processed at 8 bit/channel (24 bit).
- When you select **Highest Gradation 16bit**, images are processed at 16bit/channel (48 bit).
- Highest Gradation 16bit will not display with some Media Type or Input Resolution to Plug-in settings.
- 5. Select the mode to be printed when processing images in **Print Mode**.



Note

• The settings that can be selected differ by Media Type, Input Resolution to Plug-in, and Input Bit to Plug-in selected.

6. Click the **Print** button.

Printing begins.

Adjust the Colors and Print

You can adjust the colors to your liking and print images.

The explanation below is on 6 ways to adjust the colors using Print Plug-In.

- Adjust the Colors while Checking the Preview (for Color) P.341
- Adjust the Colors while Checking the Preview (for Monochrome) →P.342
- Adjust the Colors by Color Matching →P.346
- Print High-Quality Adobe RGB16bit Images →P.347
- Prints monochrome photographs with high quality →P.349
- Using Adobe CMM →P.349

Adjust the Colors while Checking the Preview (for Color)


You can adjust the colors while checking the adjustments in the preview. The following explanation is on the procedures for adjusting example image below.

- · Low for Cyan
- · High for Yellow
- Low for Saturation
- Warm Black for Gray Tone
- Enhance brightness for the curves

The above image adjustments are reflected in the before and after images below.



1. Display the Color Settings sheet.




2. Drag the slide bar in the direction of Low in Cyan.

- **3.** Drag the slide bar in the direction of **High** in **Yellow**.
- **4.** Drag the slide bar in the direction of **Low** in **Saturation**.
- 5. Drag the slide bar in the direction of Warm Black in Gray Tone.



Note

- You can change the numbers by inputting in numerical characters.
- You can change the numbers by clicking either ▲ button or ▼ button.
- **6.** Click the **Curves** button then click near the center of the curve.
- 7. Enter 120 in **Input** and 135 in **Output** then click the **OK** button.



8. Click the **Print** button.

The adjustments are reflected in the image and printing begins.

Adjust the Colors while Checking the Preview (for Monochrome)

You can adjust the colors while checking the adjustments in the preview.


The following explanation is about the procedures for adjusting example image below.

- · Low for Contrast
- Light for Highlight
- · Light for Shadow
- Enhance brightness for the curves


The unapplied and the applied images of the above image adjustments are as below.



- 1. Open the Main sheet.
- 2. Select Auto (Monochrome Photo) in Output Profile.



3. Open the Color Settings sheet.




- **4.** In **Contrast**, drag the slide bar toward **Low**.
- **5.** In **Highlight**, drag the slide bar toward **Light**.
- **6.** In **Shadow**, drag the slide bar toward **Light**.



Note

- You can change the numbers by inputting in numerical characters.
- You can change the numbers by clicking either ▲ button or ▼ button.
- 7. Click the Curves button then click near the center of the curve.

8. Enter 120 in **Input** and 135 in **Output** then click the **OK** button.




9. Click the Print button.

This applies the image adjustments and starts the print job.

Adjust the Colors by Color Matching

When you print a color image imported from a scanner or a digital camera, the image may appear different from the image on the screen. That is due to the differences in color on the screen and in the printer. In Print Plug-In, you can get the color balance of the print product closer to the color balance displayed on the screen through performing ICC (International Color Consortium) color profile settings, matching method settings, and settings for the internal profile, which performs optimum color conversion in response to media and resolution settings.

1. Display the Main sheet.



2. Select the profile in Output Profile.



Note

- When you place a checkmark in **Perform Proof in Preview**, you can check the color matching in the preview. This may not be displayed depending on how you set **Media Type**.
- The details of **Output Profile** you have set is saved even when you close the Print Plug-In, but when the specified profile cannot be located it is set to **Auto (Color)**.
- If an ICC profile is selected as the **Output Profile**, Adobe CMM can be selected as the color conversion engine. Refer to Using Adobe CMM —P.349 for details.
- 3. Select the profile matching method in **Matching Method**.
- **4.** Click the **Print** button.


Printing begins with the output profile and matching method that you have set.

Print High-Quality Adobe RGB16bit Images


This prints a high-quality Adobe RGB16bit image taken with a high-end digital camera. Print Plug-In allows you to print high color gamut and high tone images, when the Adobe RGB16bit image data has been retouched in Photoshop, without compromising the level of tone in the image.

1. Select the Adobe RGB16bit image data in Photoshop and start Print Plug-In. (See "Starting from Photoshop.")


P.312



- 2. Click button.
- 3. Check that Adobe RGB is displayed in Color Space, and 16bit/channel is displayed in Bit in the Image Properties dialog box, and click the Close button.



4. Display the **Main** sheet.



- 5. Select High Accuracy 600ppi in Input Resolution to Plug-in.
- 6. Select Highest Gradation 16bit in Input Bit to Plug-in.
- 7. Select the highest quality possible in **Print Mode**.
- **8.** If required, adjust the colors using color matching.




9. Click the **Print** button.

Printing of the Adobe RGB16bit image begins.

Prints monochrome photographs with high quality

Prints images captured with a scanner or digital camera in monochrome with high quality. Provides stable monochrome photo images without color casts and minimizes the influences of the difference of the light source.

1. Display the Main sheet.



2. Select Auto (Monochrome Photo) in Output Profile.



Note

• Auto (Monochrome Photo) can be selected only after a compatible Media Type has been selected.

3. Click the **Print** button.

Performs conversion to the most suitable monochrome and printing begins.

Using Adobe CMM

Adobe CMM is a color conversion engine made by Adobe. Using Adobe CMM makes it possible to obtain uniform color conversion results and to use the black point compensation function.

- How to Obtain Adobe CMM
 - Adobe CMM can be obtained using the following procedure.
- 1. Open the Adobe website (http://www.adobe.com).
- 2. Enter "Adobe CMM" in the search input box on the screen.
- ${f 3.}$ Search for the "Adobe Color Management Module (CMM)" item and select the Windows version.
- **4.** Download the file by following the on-screen directions.

5. Start the installer in the downloaded file to perform the installation.



Important

• Use version 1.1 or higher of Adobe CMM.

• Adobe CMM System Requirements

The system requirements for Adobe CMM are as follows.

- Supported OS Windows XP SP2, Windows Vista
- Supported CPU Intel Xeon, Xeon Dual, Intel Centrino, Pentium 4 processor




Note

• Check with Adobe for details.

• How to Use Adobe CMM

The procedure for using Adobe CMM is as follows.


1. Display the Main sheet.



- **2.** Select one of the ICC profiles as the **Output Profile**.
- **3.** Click the ICC Conversion Options button.

Using Adobe CMM iPF8300S

4. In the ICC Conversion Options dialog box, select Adobe CMM from Conversion Engine.




5. Click the **OK** button to close the **ICC Conversion Options** dialog box.

Perform Black Point Compensation

Black point compensation that is equivalent to Photoshop can be performed using the following procedure. Use this to avoid saturation in the black areas of images.


- Important

 Adobe
 - Adobe CMM needs to be installed in order to use black point compensation. Refer to Using Adobe CMM —P.349 for details on how to install Adobe CMM.
- 1. Display the Main sheet.



- **2.** Select one of the ICC profiles as the **Output Profile**.
- **3.** Click the **ICC Conversion Options** button to open the **ICC Conversion Options** dialog box.

- **4.** Select **Adobe CMM** as the **Conversion Engine**.
- 5. Check the Black Point Compensation check box.




6. Click the **OK** button to close the **ICC Conversion Options** dialog box.

Perform Printing Press Simulation Print


You can perform printing press simulation prints by specifying ICC profiles such as Japan Color or SWOP, and specifying an ICC profile for the printing press.

1. Display the Main sheet.



- **2.** Select one of the ICC profiles as the **Output Profile**.
- 3. Check the **Proof** check box and select the profile for the printing press you want to target from the list on the right.

4. Click the ICC Conversion Options button to open the ICC Conversion Options dialog box.



5. Configure the **Proof Options** as needed.



Note

- The proof options are **Simulate Paper Color** and **Simulate Black Ink**. The settings that can be selected vary depending on the **Conversion Engine** settings.
- **6.** Click the **OK** button to close the **ICC Conversion Options** dialog box.
- 7. Click the **Print** button. Printing begins.

Enlarge/Reduce and Print

You can enlarge or reduce an image in Print Plug-In.

Three methods to enlarge/reduce and print are as follows.

- Enlarge/Reduce and Print Matching Output Media Size →P.353
- Enlarge/Reduce and Print Matching Width of Roll Paper →P.355
- Specify Scaling, Enlarge/Reduce and Print →P.356

Enlarge/Reduce and Print Matching Output Media Size

By specifying the media type loaded in the printer, the image can be enlarged or reduced to fit the size of the image area of the media. This feature is useful when you need to print on the full width of Media that you have selected.




Note

- When you need to print on the full width of roll media, see "Enlarge/Reduce and Print Matching Width of Roll Paper." P.355
- When you do the procedure below to print on roll media, the print job will match the size of the output with the media selected with the **Paper Size** setting.

iPF8300S Enlarge/Reduce and Print

1. Display the Page Setup sheet.



2. Select the size of the media that you want to print in Paper Size.



Note

- This is not displayed when a checkmark is placed in Borderless Printing.
- This is not displayed when Fit Roll Paper Widthis set in Enlarged/Reduced Printing.
- 3. Select either Portrait or Landscape as the media orientation for the image in Orientation.



Note

- When you select Portrait, the image on the media prints as it appears on the screen.
- When you select Landscape, the image on the media prints rotated 90 degrees.
- 4. Click the Enlarged/Reduced Printing check box on.



Note

- This is not displayed when a checkmark is placed in Borderless Printing.
- 5. Select Fit Paper Size.
- **6.** Click the **Print** button.

The image prints filling the entire output media surface.


Enlarge/Reduce and Print Matching Width of Roll Paper

You can enlarge/reduce and print an image matching the width of the roll paper set in the printer. This is useful when you wish to print an image that covers the entire width of the roll paper.



Note

- Printing will not occur properly when a print roll is not set to the printer.
- 1. Display the Page Setup sheet.



- 2. Select Roll Paper in Paper Source.
- 3. Click the Roll Paper Options button.
- **4.** Set the roll paper options and click the **OK** button.



Note

- For more information about the Roll Paper Options dialog box, see "Roll Paper Options Dialog Box." →P.332
- Click the **Defaults** button to return all of the roll paper option settings to their defaults.
- 5. Select either **Portrait** or **Landscape** as the media orientation for the image in **Orientation**.



Note

- When you select **Portrait**, the image on the media prints as it appears on the screen.
- When you select **Landscape**, the image on the media prints rotated 90 degrees.
- **6.** Click the **Enlarged/Reduced Printing** check box on.



Note

• This is not displayed when a checkmark is placed in **Borderless Printing**.


- 7. Select Fit Roll Paper Width.
- **8.** Click the **Print** button.

The image prints covering the entire width of the roll paper.

Specify Scaling, Enlarge/Reduce and Print

You can specify scaling to enlarge/reduce an image and print. This is useful when you wish to print an image at a specific size.

1. Display the Page Setup sheet.



2. Select the size of the media that you want to print in Paper Size.



Note

- This is not displayed when a checkmark is placed in **Borderless Printing**.
- Fit Roll Paper Widthis set in Enlarged/Reduced Printing.
- 3. Select either Portrait or Landscape as the media orientation for the image in Orientation.



Note

- When you select **Portrait**, the image on the media prints as it appears on the screen.
- When you select **Landscape**, the image on the media prints rotated 90 degrees.
- 4. Click the Enlarged/Reduced Printing check box on.



Note

• This is not displayed when a checkmark is placed in **Borderless Printing**.

5. Select Scaling and input the scaling factor or drag the four corners of the image in the Preview display.



Note

- You can specify scaling rate in intervals of 0.01%.
- You can specify a range between 5.00-600.00%.
- The size of the width and height proportionally grow when the image is enlarged/reduced.
- 6. Either drag the image on the **Print Area Layout** preview, or set the print position **Layout**.
- 7. Click the **Print** button.

Printing begins at the set scaling rate.


Print with No Borders

You can use the borderless printing function to print without margins surrounding the image.



Note

- With some media borderless printing can be performed only between two edges.
- To use the borderless printing function, the specified media must be set to the printer.
- 1. Display the Page Setup sheet.




- 2. Select Roll Paper in Paper Source.
- **3.** Click the **Borderless Printing** check box on.



Note

• Select the width for roll paper set in the printer in Roll Paper Width in the Specify Roll Paper Width dialog box, and click OK.

iPF8300S Print with No Borders



4. Click the **Print** button.

Borderless printing begins.


Customize Media Settings

You can customize media settings.

3

358

1. Display the Main sheet.



2. Select the media type that you wish to customize in **Media Type**.



Note

- Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.
- 3. Click the Advanced Settings button.
- **4.** Perform the settings in the Paper Detailed Settings Dialog Box —P.328 and click the **OK** button.

Customize Media Settings iPF8300S

Utilize Print History

When you perform various settings and print in Print Plug-In, those settings are saved as print history. Also, you can export and import as files. You can store often-used print history under a specified name in print preferences.



Note

• You can save up to 200 print history items. All items over 200 are deleted in chronological order.


You can do the following things using print history.

- Confirm Print History Details →P.359
- Apply Print History to an Image →P.361
- Store Print History to Print Preferences →P.361
- Delete Print History →P.364
- Export Print History from Print Preferences →P.366
- Import Print History to Print Preferences →P.367
- Delete Print History from Print Preferences →P.369
- Set Information to Print with Image →P.371

Confirm Print History Details

You can confirm the print history details.

1. Display Print History sheet.



iPF8300S Utilize Print History

2. Click the **Details** button.



Note

• Select the print history you wish to check the details of, from either **Print History** or **Favorites** in the **Print History Details** dialog box.



 $\bf 3.$ Check the print history details in **Settings**, and click the $\bf OK$ button.




Note

• You can display the print history details by switching the sheets.

Apply Print History to an Image

You can use previous print history, and apply it to an image.

1. Display the **Print History** sheet.



- 2. If required, check the print history details. (See "Confirm Print History Details.") P.359
- 3. Select the print history you wish to apply from **Print History and Favorites**, and click the **Apply** button.

Store Print History to Print Preferences


You can store often-used print history to print preferences. Not only can you store the print history stored under a different name in print preferences, you can also find it with ease.




Note

• You can store up to 200 print history items to print preferences.


1. Display the **Print History** sheet.



- 2. Click the **Details** button.
- 3. Select the print history you wish to store in print preferences from **Print History** in the **Print History Details** dialog box, and check the print history details in **Settings**.




4. Select the print history you wish to store in print preferences from **Print History** and click the button.



5. In the Add Favorites dialog box input the name of the print history in Name, input a comment in Comment, and click the OK button.



6. Click the **OK** button to close the **Print History Details** dialog box.



Delete Print History


You can delete print history.



Important

• Be aware that you cannot undo deletions of print history.


1. Display the **Print History** sheet.



2. Click the **Details** button.

Delete Print History iPF8300S


3. Select the print history you wish to delete from **Print History** in the **Print History Details** dialog box, and click the **Delete** button.



4. Click the **OK** button.



5. Click the **OK**button to close the **Print History Details** dialog box.




iPF8300S Delete Print History

Export Print History from Print Preferences

You can export print history stored in print preferences as a file.


1. Display the **Print History** sheet.



- 2. Click the **Details** button.
- 3. Select the print history you wish to export from Favorites in the Print History Details dialog box, and click the Export button.



4. Input the name of the print history in File Name in the Save As dialog box, and click the Save button.




The print history is exported under the specified file name.

5. Click the **OK** button to close the **Print History Details** dialog box.

Import Print History to Print Preferences


You can import print history in file format and store it to print preferences.

1. Display the **Print History** sheet.




2. Click the **Details** button.

3. Click the Import button in the Print History Details dialog box.



4. Select the print history you wish to import in the **Open** dialog box, and click the **Open** button.




The print history is imported.



Note

- The print history file name suffix is *.pjb.
- You cannot import a print history file exported from a different OS in Print Plug-In.
- You cannot import a print history file exported from a different printer in Print Plug-In.


5. Click the **OK** button to close the **Print History Details** dialog box.



Delete Print History from Print Preferences


You can delete print history store to print preferences. You cannot store more than 200 print history items in print preferences.

1. Display the **Print History** sheet.



2. Click the **Details** button.


3. Select the print history you wish to delete from Favorites in the Print History Details dialog box, and click the Delete button.



4. Click the **OK** button.



5. Click the **OK** button to close the **Print History Details** dialog box.




Set Information to Print with Image

You can print information with an image that is related, such as the file name and the time and date.



Note

- When you use the borderless printing function to print, the information will not be printed. (See "Print with No Borders.") →P.357
- When the printed information is too long as does not fit on the media, a break will appear in the printed information
- The information may print on the image data with some media sizes, enlargement rates and print position values.
- When **Keep Media Size** is set to **On** on the printer, a portion of bottom of the print data is not printed.
- 1. Display the **Print History** sheet.




- 2. Click the **Print Information** check box on.
- 3. Select the position where you wish to print the information in **Information Print Position**.
- **4.** Click the information check box you wish to print on.
- 5. When you wish to edit the comment, click the **Edit Comment** button.




Note

• When you do not wish to edit the comment, move to step 7.

6. Input the comment in the **Edit Comment** dialog box, and click **OK** button.



7. Click the Print button.



Comments are printed with images.

Print Plug-In for Office

| Print Plug-In for Office features | 373 |
|---|-----|
| Operating Environment | 374 |
| Steps to install | 374 |
| Steps to uninstall | |
| When Print Plug-In for Office is not displayed | 378 |
| To start from Microsoft Word | 383 |
| Print Matching Roll Width (Word) | |
| Borderless Printing (Word) | |
| Multi-Page Printing (Word) | |
| Register the settings(Word) | 394 |
| Print Using Registered Settings (Word) | |
| Portrait Orientation / Landscape Orientation (Word) | 397 |
| To start from Microsoft PowerPoint | 399 |
| Print Matching Roll Width (PowerPoint) | |
| Borderless Printing (PowerPoint) | |
| Multi-Page Printing (PowerPoint) | |
| Register the settings(PowerPoint) | |
| Print Using Registered Settings (PowerPoint) | 410 |
| Portrait Orientation / Landscape Orientation (PowerPoint) | 412 |
| To start from Microsoft Excel | 415 |
| Print Entire Sheet (Excel) | |
| Print Selected Area (Excel) | |
| Configuring Binding (Excel) | |
| Configuring Special Settings | 424 |
| | |

Print Plug-In for Office features

Print Plug-In for Office is a Plug-In that enables easy printing from Microsoft Office.

- It is displayed on the toolbar/ribbon, so it is easily accessible.
- It can be set by just selecting from the Wizard.
- Large-Format Printing custom size can also be set in the Wizard from Microsoft Word or Microsoft PowerPoint.
- Custom size can be set automatically from Microsoft Excel.
- The layout can be checked before printing by starting the preview screen.



Important

• The **Print Plug-In for Office** toolbar/ribbon might not be displayed in **Microsoft Office** after installing **imagePROGRAF Print Plug-In for Office**.

Refer to the following topic for details on how to display the **imagePROGRAF Print Plug-In for Office** toolbar/ribbon.

When Print Plug-In for Office is not displayed →P.378

Print Plug-In for Office 's operating environment is as below.

- Compatible Operating System
 - 32 bit edition Windows OS Windows XP, Windows Server 2003, Windows Server 2003 R2, Windows Vista, Windows Server 2008, Windows 7
 - 64 bit edition Windows OS Windows Vista, Windows Server 2008, Windows Server 2008 R2, Windows 7



Note

- 64 bit edition Windows OS operates only on WOW64 (32 bit emulator).
- For the Windows OS, use the latest version of Service Pack.
- Software that requires installation
 Microsoft Office XP/2003/2007/2010
 imagePROGRAF Printer Driver Ver. 3.95 or later
- Hardware
 CPU 2.8 GHz Pentium 4 or better
 RAM 1GB or more(512MB or more for Windows XP and Windows Server 2003)
 HDD (free space) 20GB or more



Important

- If you opened the Office document from **Internet Explorer**, the software will not run correctly.
- If you are editing an embedded object or link object, the software will not run correctly.
- If you added the **imagePROGRAF Print Plug-In** ribbon to the **Microsoft Office 2007/2010** Quick Access toolbar, the software will not run correctly.

Steps to install

Below are the steps to install Print Plug-In for Office.



Note

- You must log into Windows as an Administrator before the installation.
- 1. Insert "User Software CD-ROM" into the CD-ROM drive and start the installer.



Note

• If the installer screen does not display, open the CD-ROM icon from **My Computer**, click **setup.exe**, and open the icon.


374

Operating Environment iPF8300S

2. Click the Install Individual Software button.




3. Click Install in imagePROGRAF Print Plug-In for Office.



iPF8300S Steps to install

4. Click the **Next** button.




5. Read the License Agreement, and click the Yes button.



Steps to install iPF8300S


6. Click the **Start** button.



7. Click the Yes button.



8. Click the **Exit** button.



The installation for **Print Plug-In for Office** is complete.

iPF8300S Steps to install

Important

- When you install this software, the virtual printer Canon imagePROGRAF PrintPlugIn may be installed. If you want to use this software, do not uninstall the virtual printer Canon imagePROGRAF PrintPlugIn.
- The **Print Plug-In for Office** toolbar/ribbon might not be displayed in **Microsoft Office** after installing **imagePROGRAF Print Plug-In for Office**.


Refer to the following topic for details on how to display the **imagePROGRAF Print Plug-In for Office** toolbar/ribbon.

When Print Plug-In for Office is not displayed →P.378

Steps to uninstall

Below are the steps to uninstall Print Plug-In for Office.

- **1.** If **Microsoft Office** is open, close it.
- 2. Select Control Panel from the start menu.
- 3. Open Add or Remove Programs.
- **4.** Select **imagePROGRAF Print Plug-In**, and click the **Remove** button.



378



• You cannot uninstall **Print Plug-In for Office** if an Office application is running. When a message appears, select **Cancel** and close all Office applications that are running.

When Print Plug-In for Office is not displayed

Buttons such as **Start imagePROGRAF Print Plug-In** sometimes do not appear in the **Word**, **PowerPoint** and **Excel** Office applications, and the **Print Plug-In for Office** functions are not available. In this event, re-install **Print Plug-In for Office**.

Steps to uninstall iPF8300S

If you are using **Microsoft Office 2003** or later, you can also enable add-ins to display **Print Plug-In for Office**. See below for the procedure for re-installing the plug-in or enabling add-ins.

Re-installing Print Plug-In for Office

• If a problem occurs, such as the system or an application terminating abnormally, the **Microsoft Office** application disables add-ins as a safety precaution.

In this event, you will need to re-install **Print Plug-In for Office** to display the **imagePROGRAF Print Plug-In** toolbar/ribbon.



Note

You cannot re-install Print Plug-In for Office once an Office application is running. When the message appears, select Cancel and close the active Office application.

Re-install Print Plug-In for Office as follows:

- 1. Close **Microsoft Office** if it is open.
- 2. Install **Print Plug-In for Office**. For information about installing, see "Steps to install." →P.374

Enabling Print Plug-In for Office for items disabled in Office applications


 If a problem occurs, such as the system or an application terminating abnormally, the Microsoft Office application disables add-ins as a safety precaution.

In this event, you will need to restore the disabled add-ins in order to display the **imagePROGRAF Print Plug-In** toolbar/ribbon.

Use the procedure below to restore the add-ins disabled by **Microsoft Office**.


For Microsoft Office 2010

1. Select **Options** from the **File** menu.




2. From the list on the left side of the <application name> options dialog box, select Add-ins.

3. Select Disabled Items in the Manage combo box and click the Go button.



4. If Addin imageprograf print plug-in (ipfaddinif.dll) is displayed in the Disabled Items dialog box, select it and click the Enable button.




5. Close all the dialog boxes and restart the Office application.

For Microsoft Office 2007


1. Click the Office button and then click the <application name> options button.



- 2. From the list on the left side of the <application name> options dialog box, select Add-ins.
- ${f 3.}$ Select **Disabled Items** in the **Manage** combo box and click the ${f Go}$ button.



4. If Addin imageprograf print plug-in (ipfaddinif.dll) is displayed in the Disabled Items dialog box, select it and click the Enable button.



5. Close all the dialog boxes and restart the Office application.


For Microsoft Office 2003

1. Click About <application name> in the Help menu of application.




383

2. Click the **Disabled Items** button in the **About <application name>** dialog box.



3. If Addin imageprograf print plug-in (ipfaddinif.dll) is displayed in the Disabled Items dialog box, select it and click the Enable button.



4. Close all the dialog boxes and restart the Office application.

To start from Microsoft Word

Below are the steps to start Print Plug-In for Office from Microsoft Word.

1. Start Microsoft Word.

iPF8300S To start from Microsoft Word

2. If Start imagePROGRAF Print Plug-In is displayed on the toolbar/ribbon, click it.





Important


- If the imagePROGRAF Print Plug-In toolbar/ribbon is not displayed, refer to the following.
 - When Print Plug-In for Office is not displayed P.378
- 3. Check that the imagePROGRAF Print Plug-In toolbar/ribbon is displayed.



4. Click the buttons on the toolbar/ribbon according to the items you want to set.

| Icon | Contents |
|------------------------------|---|
| imagePROGRAF * | Displays the About , Help , and Special Settings dialog boxes. You can change the settings using the Special Settings dialog box. |
| Menu | Refer to Configuring Special Settings →P.424 for details. |
| Canon iPFxxxx ▼ Printer list | Select Printer. If you select Show All Printers , the imagePROGRAF printers will be displayed again. Select this when you want to display all printer drivers or update the display. |
| Print Print Button | The print Wizard is displayed. The settings Print Matching Roll Width , Borderless Printing , Multi-Page Printing , and Print Using Registered Settings can be set. |
| Paner Settings | Large-Format Wizard is displayed. Settings for Portrait or Landscape Orientation can be set. |
| Paper Settings | |
| Paper Settings Button | |


Printing Wizard dialog box



Important

• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar.

Large-Format Printing Wizard dialog box



385

iPF8300S To start from Microsoft Word



Important

- If you want to change the display to another file or application while the **Large-Format Printing Wizard** is open, close the **Large-Format Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- The layout may collapse if you create a form using existing data. If that is the case, modify the data again.

Print Matching Roll Width (Word)

Prints to the edge of the roll width. You can print large exhibits and posters, and also print Portrait and Landscape orientations made in **Large-Format Printing Wizard**.

- 1. Start Microsoft Word.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.



3. Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon. The **Printing Wizard** dialog box is displayed.




386


Important

• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

4. Click Print Matching Roll Width.



- 5. Select Roll Paper Width that is set in the printer.
- **6.** Select image size.
- 7. Select layout.
- 8. Select Next.



- 9. Select Media Type.
- 10. Select Print Range from All Pages, Current Page, and Pages. If Pages is selected, enter the number of pages.
- 11. Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- The settings are registered when the **One-Touch Registration** is pressed. This is convenient if you to need print multiple times using the same setting.
- Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- When you print to the edge of the roll width, the maximum length will be the lesser of 5.587 times the roll paper width, or 18.0m.
- **12.** Press **Print** to start printing.

Borderless Printing (Word)

Prints up to the border of the media. Photos and posters can be printed without worrying about margins.

- 1. Start Microsoft Word.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.

Start imagePROGRAF Print Plug-In imagePROGRAF Print Plug-In

3. Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon. The **Printing Wizard** dialog box is displayed.






Important

• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

4. Click Borderless Printing.




5. A confirmation dialog box is displayed. If the data fills up the page, confirm that Continue using the plug-in is selected in Choose how to proceed and press OK.




Note

• To adjust the data, select **Return to application** and press **OK**. Exit **Print Plug-In for Office** and return to the application.



- $\mathbf{6}_{ullet}$ Select Roll Paper Width that is set in the printer.
- 7. Select Layout.

8. Select Next.



- 9. Select Media Type.
- 10. Select Print Range from All Pages, Current Page, and Pages. For Pages, insert the page number.
- 11. Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When Saturation is selected, you can print posters, etc., vividly.
- Press the **One-Touch Registration** button to register the settings. This is useful for multiple printing using the same settings.
- Press the **Print Preview** button to display the preview screen. You can confirm and make changes to the layout in the preview screen.
- The maximum length for Borderless Printing is the lesser of 5.587 times the roll paper width, or 18.0m.
- 12. Press Print to start printing.

Multi-Page Printing (Word)


Prints multiple pages as one page. You can print handouts into a single page, or print matter with many pages.

1. Start Microsoft Word.

2. If Start imagePROGRAF Print Plug-In is displayed, click it.




3. Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon. The **Printing Wizard** dialog box is displayed.




Important

• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

4. Click Multi-Page Printing.



- 5. Select the Roll Paper Width that is set in the printer.
- **6.** Select layout from Layout Selection.
- 7. Select Next.



8. Select Media Type.

- **9.** Select **Print Range** from **All Pages**, **Current Page**, and **Pages**. If **Pages** is selected, enter the number of pages.
- 10. Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- The settings are registered when the **One-Touch Registration** is pressed. This is convenient if you to need print multiple times using the same setting.
- Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- The maximum length for Multi-Page Printing is the lesser of 5.587 times the roll paper width, or 18.0m.
- **11.** Press **Print** to start printing.

Register the settings(Word)


If you are going to print multiple times using the same setting, you can select **One-Touch Registration**. Registered settings can be recalled from **Print Using Registered Settings**.

1. Set up to the Print screen from Print Matching Roll Width, Borderless Printing or Multi-Page Printing of Printing Menu.



Note

- Up to 20 items can be registered.
- The available settings are as follows.
 - Print Matching Roll Width (Word) →P.386
 - Borderless Printing (Word) →P.388
 - Multi-Page Printing (Word) →P.391
- 2. Click the One-Touch Registration button.



- **3.** Enter name in Name. Up to 31 characters can be entered.
- 4. Click . The name you entered is displayed in Registered Settings.
- **5.** Click **OK**, and return to the **Print** screen.
- **6.** Click **Print** to print, and click **Cancel** to cancel the print.



Note

• Clicking Cancel in the **Print** screen will not delete the registered settings.

Print Using Registered Settings (Word)

Prints using the registered settings.

- 1. Start Microsoft Word.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.

Start imagePROGRAF Print Plug-In imagePROGRAF Print Plug-In

3. Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon. The **Printing Wizard** dialog box is displayed.







Important

• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

4. Click Print Using Registered Settings.



5. Click the **Next** button.



6. Select Media Type.

- 7. Select Print Range from All Pages, Current Page, or Pages. If Pages is selected, enter the number of pages.
- **8.** Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- The maximum print length when printing with the registered settings is the lesser of 5.587 times the roll paper width, or 18.0m.
- **9.** Press **Print** to start printing.

Portrait Orientation / Landscape Orientation (Word)

Print to the edge of the roll width. You can print large exhibits and posters, or print the Landscape or Portrait Orientation Page Sizes made in the Large-Format Printing Wizard.

Create Page Size in Portrait or Landscape Orientation.

Use the **Large-Format Printing Wizard** to create portrait page sizes for Potrait Orientation, and landscape page sizes for Landscape Orientation.

- 1. Start Microsoft Word.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.


Start imagePROGRAF Print Plug-In imagePROGRAF Print Plug-In

3. Click **Paper Settings** from the **imagePROGRAF Print Plug-In** toolbar/ribbon. The **Large-Format Printing Wizard** dialog box is displayed.



Note

• If you want to change the display to another file or application while the Large-Format Printing Wizard is open, close the Large-Format Printing Wizard dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.




4. Click Portrait Orientation or Landscape Orientation.



Note

• The steps taken to create a Portrait Page Size will be used as an example to explain the procedure.



- **5.** Adjust **Length** from the list-box or slide-bar.
- **6.** Click the **Create Page** button.

7. Click **OK** if the message is displayed.



8. Edit and create the document.



Note

Printing is done in Print Matching Roll Width of the Printing Wizard. For details on Print Matching Roll Width, refer to see "Print Matching Roll Width (Word)." →P.386.



Important

• The layout may collapse if you create a form using existing data. If that is the case, modify the data again.

To start from Microsoft PowerPoint

Below are the steps to start Print Plug-In for Office from Microsoft PowerPoint.

- 1. Start Microsoft PowerPoint.
- 2. If Start imagePROGRAF Print Plug-In is displayed on the toolbar/ribbon, click it.





Important

- If the imagePROGRAF Print Plug-In toolbar/ribbon is not displayed, refer to the following.
 - When Print Plug-In for Office is not displayed →P.378
- **3.** Check that the **imagePROGRAF Print Plug-In** toolbar/ribbon is displayed.



4. Click the buttons on the toolbar/ribbon according to the items you want to set.

| Icon | Contents |
|-----------------------|---|
| imagePROGRAF * | Displays the About , Help , and Special Settings dialog boxes. (See "Configuring Special Settings.") →P.424 |
| Menu | |
| Canon iPFxxxx ▼ | Select Printer. If you select Show All Printers , the imagePROGRAF printers will be displayed again. Select this when you want to display all printer drivers or update the display. |
| Printer list | |
| Print | The print Wizard is displayed. The settings Print Matching Roll Width, Borderless Printing, Multi-Page Printing, and Print Using Registered Settings can be set. |
| Print Button | |
| | Large-Format Wizard is displayed. Settings for Portrait or Landscape Orientation can be set. |
| Paper Settings | |
| Paper Settings Button | |

Printing Wizard dialog box



400



Important


• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.



Note

• If you open a password protected document as read-only, the **Printing Wizard** cannot be run.

Large-Format Printing Wizard dialog box





Important

- If you want to change the display to another file or application while the **Large-Format Printing Wizard** is open, close the **Large-Format Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- The layout may collapse if you create a form using existing data. If that is the case, modify the data again.



Note

• If you open a password protected document as read-only, the **Large-Format Printing Wizard** cannot be run. Remove the password protection.

Print Matching Roll Width (PowerPoint)

Prints to the edge of the roll width. You can print large exhibits and posters, and also print Portrait and Landscape orientations made in Large-Format Printing Wizard.

- 1. Start Microsoft PowerPoint.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.




3. Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon. The **Printing Wizard** dialog box is displayed.




Important

- If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- 4. Click Print Matching Roll Width.



5. Select **Roll Paper Width** that is set in the printer.

- **6.** Select image size.
- 7. Select layout.
- 8. Select Next.



- 9. Select Media Type.
- 10. Select Print Range from All Slides, Current Slide, and Slides. If Slides is selected, enter the slide number.
- 11. Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- The settings are registered when the **One-Touch Registration** is pressed. This is convenient if you to need print multiple times using the same setting.
- Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- When you print to the edge of the roll width, the maximum length will be the lesser of 14.22 times the roll paper width, or 18.0m.
- 12. Press Print to start printing.

Borderless Printing (PowerPoint)

Prints up to the border of the media. Photos and posters can be printed without worrying about margins.

- 1. Start Microsoft PowerPoint.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.



3. Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon. The **Printing Wizard** dialog box is displayed.






Important

• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

4. Click Borderless Printing.




5. A confirmation dialog box is displayed. If the data fills up the page, confirm that Continue using the plug-in is selected in Choose how to proceed and press OK.



Note


• To adjust the data, select **Return to application** and press **OK**. Exit **Print Plug-In for Office** and return to the application.



- 6. Select Roll Paper Width that is set in the printer.
- 7. Select Layout.

406

8. Select Next.



- 9. Select Media Type.
- 10. Select Print Range from All Slides, Current Slide, and Slides. If Slides is selected, enter the slide number.
- 11. Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When Saturation is selected, you can print posters, etc., vividly.
- Press the **One-Touch Registration** button to register the settings. This is useful for multiple printing using the same settings.
- Press the **Print Preview** button to display the preview screen. You can confirm and make changes to the layout in the preview screen.
- The maximum length for Borderless Printing is the lesser of 14.22 times the roll paper width, or 18.0m.
- **12.** Press **Print** to start printing.

Multi-Page Printing (PowerPoint)


Prints multiple pages as one page. You can print handouts into a single page, or print matter with many pages.

1. Start Microsoft PowerPoint.

2. If Start imagePROGRAF Print Plug-In is displayed, click it.




3. Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon. The **Printing Wizard** dialog box is displayed.




Important

• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

4. Click Multi-Page Printing.



- 5. Select the Roll Paper Width that is set in the printer.
- 6. Select layout from Layout Selection.
- 7. Select Next.



8. Select Media Type.

- **9.** Select **Print Range** from **All Slides**, **Current Slide**, and **Slides**. If **Slides** is selected, enter the slide number.
- 10. Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- The settings are registered when the **One-Touch Registration** is pressed. This is convenient if you to need print multiple times using the same setting.
- Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- The maximum length for Multi-Page Printing is the lesser of 14.22 times the roll paper width, or 18.0m.
- **11.** Press **Print** to start printing.

Register the settings(PowerPoint)


If you are going to print multiple times using the same setting, you can select **One-Touch Registration**. Registered settings can be recalled from **Print Using Registered Settings**.

1. Set up to the Print screen from Print Matching Roll Width, Borderless Printing or Multi-Page Printing of Printing Menu.



Note

- Up to 20 items can be registered.
- The available settings are as follows.
 - Print Matching Roll Width (PowerPoint) →P.401
 - Borderless Printing (PowerPoint) →P.404
 - Multi-Page Printing (PowerPoint) →P.406
- 2. Click the One-Touch Registration button.



- **3.** Enter name in **Name**. Up to 31 characters can be entered.
- 4. Click . The name you entered is displayed in **Registered Settings**.
- **5.** Click **OK**, and return to the **Print** screen.
- **6.** Click **Print** to print, and click **Cancel** to cancel the print.



Not

• Clicking Cancel in the **Print** screen will not delete the registered settings.

Print Using Registered Settings (PowerPoint)

Prints using the registered settings.

- 1. Start Microsoft PowerPoint.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.



3. Click **Print** from the **imagePROGRAF Print Plug-In** toolbar/ribbon. The **Printing Wizard** dialog box is displayed.







Important

• If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.

4. Click Print Using Registered Settings.



5. Click the **Next** button.



6. Select Media Type.

- 7. Select Print Range from All Slides, Current Slide, and Slides. If Slides is selected, enter the slide number.
- **8.** Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- The maximum print length when printing with the registered settings is the lesser of 14.22 times the roll paper width, or 18.0m.
- **9.** Press **Print** to start printing.

Portrait Orientation / Landscape Orientation (PowerPoint)

Print to the edge of the roll width. You can print large exhibits and posters, or print the Landscape or Portrait Orientation Page Sizes made in the **Large-Format Printing Wizard**.


Create Page Size in Portrait or Landscape Orientation.

Use the **Large-Format Printing Wizard** to create portrait page sizes for Potrait Orientation, and landscape page sizes for Landscape Orientation.

- 1. Start Microsoft PowerPoint.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.

Start imagePROGRAF Print Plug-In imagePROGRAF Print Plug-In

3. Click Paper Settings from the imagePROGRAF Print Plug-In toolbar/ribbon. The Large-Format Printing Wizard dialog box is displayed.






Important

- If you want to change the display to another file or application while the Large-Format Printing Wizard is open, close the Large-Format Printing Wizard dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- 4. Click Portrait Orientation or Landscape Orientation.



Note

• The steps taken to create a Portrait Page Size will be used as an example to explain the procedure.



- **5.** Adjust **Length** from the list-box or slide-bar.
- **6.** Click the **Create Page** button.
- 7. Click **OK** if the message is displayed.



8. Edit and create the document.



Important

• The layout may collapse if you create a form using existing data. If that is the case, modify the data again.



Note

Printing is done in **Print Matching Roll Width** of the **Printing Wizard**. For details on **Print Matching Roll Width**, refer to see "Print Matching Roll Width (PowerPoint)." —P.401 .

To start from Microsoft Excel

Below are the steps to start Print Plug-In for Office from Microsoft Excel.

- 1. Start Microsoft Excel.
- 2. If Start imagePROGRAF Print Plug-In is displayed on the toolbar/ribbon, click it.





Important


- If the imagePROGRAF Print Plug-In toolbar/ribbon is not displayed, refer to the following.
 - When Print Plug-In for Office is not displayed →P.378
- 3. Check that the imagePROGRAF Print Plug-In toolbar/ribbon is displayed.



4. Click the buttons on the toolbar/ribbon according to the items you want to set.

| Icon | Contents | |
|------------------------------|---|--|
| imagePROGRAF * | Displays the About , Help , and Special Settings dialog boxes. (See "Configuring Special Settings.") →P.424 | |
| Menu | | |
| Canon iPFxxxx • Printer list | Select Printer. If you select Show All Printers , the imagePROGRAF printers will be displayed again. Select this when you want to display all printer drivers or update the display. | |
| Print | The print Wizard is displayed. The settings Print Entire Sheet and Print Selected Area can be set. | |
| Print Button | | |

Printing Wizard dialog box





Important

- If you want to change the display to another file or application while the **Printing Wizard** is open, close the **Printing Wizard** dialog box. Otherwise, you may not be able to change displays or operate the toolbar/ribbon.
- The **Printing Wizard** will not start if you click the **Print** button on the toolbar/ribbon while editing a cell.
- When more than one worksheet is selected, the **Printing Wizard** cannot be run. Select only one worksheet and click **Print** again.
- When an object is selected, the **Printing Wizard** is not started if you click the **Print** button on the toolbar/ribbon.
- If the paper size in Excel is blank, the **Printing Wizard** cannot be run. From the **File** menu in Excel, select **Page Setup** and check **Paper size**.



Note

- If you click the **Print** button with a graph selected, a message dialog box will appear asking if you want to continue printing. If you click **No**, you will return to the application.
- If you click the **Print** button with a page break set, a message dialog box will appear asking if you want to continue printing. If you click **No**, you will return to the application. If you do not use the set page break, check the page break preview and change the setting.
- If you click the **Print** button with a page range set, a message dialog box will appear asking if you want to continue printing. If you click **No**, you will return to the application. If you do not use the set page range, check the page break preview and change the setting.
- If you click the **Print** button with a worksheet or cell protected, a message dialog box will appear asking if you want to continue printing. If you click **No**, you will return to the application. If you want to change the setting, remove the protection from the worksheet or cell.

Print Entire Sheet (Excel)

For resizing the entire sheet to fit the roll width. Choose this option to enlarge the currently displayed sheet before printing.

- 1. Start Microsoft Excel.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.



 $\textbf{3.} \ \, \textbf{Click Print from the imagePROGRAF Print Plug-In toolbar/ribbon}.$




Important


• When more than one worksheet is selected, the **Printing Wizard** cannot be run. Select only one worksheet and click **Print** again.

If a print area is set, a confirmation message dialog box will appear.

To print the entire sheet, cancel the setting of the print area.



The Printing Wizard dialog box is displayed.




417


iPF8300S Print Entire Sheet (Excel)

4. Click Print Entire Sheet.

A message will appear informing you that analysis is in progress.



The Layout menu will appear automatically.




418

Note

- If data analysis requires time, a message dialog will appear. If you select **No**, you will return to the application.
- 5. Select Roll Paper Width that is set in the printer.

- **6.** Select image size.
- 7. Select layout.
- 8. To configure Binding, click the Binding Settings button.

 Refer to Configuring Binding (Excel) —P.423 for details on the procedure for configuring Binding.
- 9. Select Next.



- 10. Select Media Type.
- 11. Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- When you print to the edge of the roll width, the maximum print length is 18.0m.
- 12. If the upper and lower margins are too wide, check No Spaces at Top or Bottom (Conserve Paper). The upper and lower margins can be checked in Print Preview.
- 13. Press Print to start printing.



Important

- If divided into plural pages, try reducing the data size or the range you select.
- You cannot run **Print** or **Print Preview** if you select it for a worksheet with no data displayed.

iPF8300S Print Entire Sheet (Excel)

Print Selected Area (Excel)

For resizing the selected range of cells to fit the roll width. Choose this option to enlarge a particular part of the sheet before printing.

- 1. Start Microsoft Excel.
- 2. If Start imagePROGRAF Print Plug-In is displayed, click it.



3. Click Print from the imagePROGRAF Print Plug-In toolbar/ribbon.




Important


• When more than one worksheet is selected, the **Printing Wizard** cannot be run. Select only one worksheet and click **Print** again.

If a print area is set, a confirmation message dialog box will appear.

To print the selected area, cancel the setting of the print area.



The **Printing Wizard** dialog box is displayed.



4. Click Print Selected Area.




Important

• If only one cell is selected, **Print Selected Area** cannot be selected.

A message will appear informing you that analysis is in progress.



The Layout menu will appear automatically.





Important

• If the range selected in Excel 2007/2010 is too large, it will not be possible to analyze the data. Select a smaller range and then run the analysis.


iPF8300S Print Selected Area (Excel)



Note

- If data analysis requires time, a message dialog will appear. If you select No, you will return to the application.
- 5. Select Roll Paper Width that is set in the printer.
- **6.** Select image size.
- 7. Select layout.
- 8. To configure Binding, click the Binding Settings button.

 Refer to Configuring Binding (Excel) P.423 for details on the procedure for configuring Binding.
- 9. Select Next.



- 10. Select Media Type.
- 11. Enter Copies.



Note

- When **Print in Draft mode** is selected, printing is fast but the print quality is poor.
- When **Saturation** is selected, you can print posters, etc., vividly.
- Press the **Print Preview** button to display the preview screen. You can check and make changes to the layout in the preview screen.
- When you print to the edge of the roll width, the maximum print length is 18.0m.
- 12. If the upper and lower margins are too wide, check No Spaces at Top or Bottom (Conserve Paper). The upper and lower margins can be checked in Print Preview.

Print Selected Area (Excel)

13. Press Print to start printing.



Important

- If divided into plural pages, try reducing the data size or the range you select.
- You cannot run **Print** or **Print Preview** if you select it for a worksheet with no data displayed.

Configuring Binding (Excel)

You can configure **Binding** margins for binding printouts.

- 1. Configure the settings up to Layout Selection in the Layout screen in Print Entire Sheet or Print Selected Area.

 Refer to Print Entire Sheet (Excel) →P.417 and Print Selected Area (Excel) →P.420 for the configuration methods.
- 2. Click the **Binding Settings** button.



Important


- You cannot click the **Binding Settings** button in the following situations.
 - When the Image Size is set to 100%
 - When a graph is selected
 - When page breaks have been set
 - When a sheet or cell is protected

Open the **Binding Settings** dialog box.



- 3. If the **Binding** checkbox is not checked, select it to turn binding on.
- 4. Select Binding Edge.
- 5. Select Binding Margin.

6. Click the **OK** button. Return to the **Layout** screen.




Check that the **Binding** settings are applied in the preview screen.

7. Configure the settings in the **Printing Wizard** dialog box.

Configuring Special Settings

You can configure Special Settings from the imagePROGRAF Print Plug-In toolbar.

1. Click imagePROGRAF in the toolbar, and select Special Settings.



2. Turn the checkbox for the item you want to change on or off.

| Item | Details | |
|--|---|--|
| Show progress indicator during plug-in startup | When this setting is off, hides the progress indicator that appears while the plug-in is starting up. | |
| Center sheets and print areas | When this setting is off, printing is performed without changing the position. When this setting is on, printing is performed with the top, bottom, left, and right margins layed out equally. When this setting is off, printing is performed without changing the position. | |

| Item | Details | |
|---|--|--|
| Center sheets and print areas | This function is only valid in Microsoft Excel . | |
| Ensure image quality when creating page sizes | When this setting is on, documents are created at the maximum size. This reduces the enlargement ratio during actual printing, which minimizes degradation of the quality of photos, etc. This function is only valid in [Microsoft PowerPoint. | |
| Correct the print area when analyzing | For data that cannot be processed with usual data analysis, the print area is corrected and then the data is processed. When data analysis fails, you may be able to print by turning on this checkbox. This function is only valid in Microsoft Excel . | |


 $\textbf{3.} \ \, \text{Click } \textbf{OK} \text{ to close the } \textbf{Special Settings} \text{ dialog box}.$


Status Monitor

| The Features of imagePROGRAF Status Monitor | 426 |
|--|-----|
| Job Management Using imagePROGRAF Status Monitor | 427 |

The Features of imagePROGRAF Status Monitor

imagePROGRAF Status Monitor is a utility for checking the printer status and managing print jobs. Two screens are available in imagePROGRAF Status Monitor: **Printer List** shows a list of printers, and **Status Monitor** shows details for each printer.





• You can view a list of the printers for which printer drivers have been installed on your computer, printers connected to your computer, and printers found on the network.

- If a printer error occurs, you can investigate the corrective action immediately.
- Printer status can be checked in real time on a computer monitor.
- Displays the ink level of every color in the printer. An icon and warning message will notify you when ink levels are low.
- The type of paper loaded in each media source is identified. You can also check to see if paper has run out.
- This way, the utility enables you to check printer information and take care of printer maintenance for optimal printing results.
- You can also set up automatic email notification of any printer problems or errors to email addresses you designate in advance.
- You can check the status of the hard disk and the documents saved on the hard disk.
- You can use the Accounting Manager to collect the print job logs for the printers and check information such as the printing costs.

For details of the Accounting Manager, see Accounting Manager —P.429.




Note

• For details, refer to the imagePROGRAF Status Monitor help.

Job Management Using imagePROGRAF Status Monitor

You can use the **Job** sheet in imagePROGRAF Status Monitor for operations such as pausing and canceling print jobs.



• Preempting Other Jobs

If you select a print job and click the **Preempt Other Jobs** button, the selected job is printed ahead of the job that currently precedes it in the print queue.

Pausing/Resuming Print Jobs

Selecting a print job and clicking the **Pause** button pauses printing of the selected job.

To resume printing of a paused print job, select the print job and click the **Resume** button.



Note

• Once all the print data for a print job has been sent to the printer, the job can no longer be paused/resumed.

· Canceling Print Jobs

Selecting a print job and clicking the **Cancel Job** button cancels printing of the selected job.



Note

• You cannot cancel other users' print jobs.

· Printing Held Jobs

Printing of the job with a **Status** of **Holding** is paused because the paper specified by the driver does not match the paper currently loaded in the printer.

Use the procedure below to print the held job.

- 1. Select the held job and click the **Replace Paper** button.
- 2. Replace the paper in the printer with the correct paper.



Note

- To continue printing without changing the paper in the printer, select the held job and click **Continue to print** button.
- The printing behavior when the paper specified by the driver does not match the paper currently loaded in the printer can be changed by using **Detect Mismatch** in the operation panel menu. Refer to Menu Settings —P.938 for details.

Accounting

| Launching the Accounting Manager 430 Accounting Manager Main Window 430 Job List Area 433 Accounting Manager Basic Procedures 434 Configuring Unit Costs in Accounting Manager 434 Setting the Unit Cost for Ink 435 Setting the Unit Cost for Paper 436 Setting the Unit Cost for Items Other Than Ink and Paper 437 Configuring Units and Display Settings in Accounting Manager 438 Automatically Acquiring Print Job Logs at Regular Intervals 439 Canceling Regular Print Job Log Acquisition 439 Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs 439 Exporting Print Job Data as a CSV File 440 Showing Job Properties 440 Showing, Saving and Loading Selected Unit Cost Data 441 | Accounting Manager | 429 |
|---|---|-----|
| Accounting Manager Main Window 430 Job List Area 433 Accounting Manager Basic Procedures 434 Configuring Unit Costs in Accounting Manager 434 Setting the Unit Cost for Ink 435 Setting the Unit Cost for Paper 436 Setting the Unit Cost for Items Other Than Ink and Paper 437 Configuring Units and Display Settings in Accounting Manager 438 Automatically Acquiring Print Job Logs at Regular Intervals 439 Canceling Regular Print Job Log Acquisition 439 Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs 439 Exporting Print Job Data as a CSV File 440 Showing Job Properties 440 Showing, Saving and Loading Selected Unit Cost Data 441 | | |
| Job List Area | | |
| Configuring Unit Costs in Accounting Manager | | |
| Configuring Unit Costs in Accounting Manager | Accounting Manager Basic Procedures | 434 |
| Setting the Unit Cost for Ink | | |
| Setting the Unit Cost for Paper | | |
| Setting the Unit Cost for Items Other Than Ink and Paper | | |
| Configuring Units and Display Settings in Accounting Manager | | |
| Canceling Regular Print Job Log Acquisition | · · · · · · · · · · · · · · · · · · · | |
| Canceling Regular Print Job Log Acquisition | Automatically Acquiring Print Job Logs at Regular Intervals | 439 |
| Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs | | |
| Showing Job Properties | | |
| Showing Job Properties | Exporting Print Job Data as a CSV File | 440 |
| Showing, Saving and Loading Selected Unit Cost Data | · · · · | |
| | · · · · · · · · · · · · · · · · · · · | |
| Showing the Total Amount of Ink and Paper Consumed | | |

Accounting Manager

The Accounting Manager stores the printer's print job logs so that you can use the information for checking printing costs, etc.

The benefits of using the Accounting Manager are outlined below.

- Print Job Log Collection
 This allows you to check which documents were printed from each printer, who printed them and when.
- Calculation of the Total Pages Used and the Total Cost
 This allows you to use the collected print job logs to calculate totals for items such as the number of pages printed, the amount of paper used and the printing costs incurred.
- Regular Data Acquisition for Print Jobs Job logs can be automatically collected periodically.
- Exporting Print Job Data

 This allows you to export collected print job data as a CSV file.



Important

- The Accounting Manager in Status Monitor displays approximate estimates of the amount of paper consumed and the ink consumed per job. Canon cannot guarantee the accuracy of these estimates. These estimates will also vary depending on the conditions of printer use.
- Print job log collection is not performed when **Set./Adj. Menu** -> **Printer Info** -> **Show Job Log** of the control panel is **Off**. However,
 - even if **Show Job Log** is set to **Off**, regularly acquired jobs that already have been retrieved at that time are displayed.
 - When Show Job Log has been set to On again, all jobs within the printer at that time are displayed.

iPF8300S Accounting Manager

Launching the Accounting Manager

The procedure for launching the Accounting Manager is shown below.


- 1. Open the imagePROGRAF Status Monitor window.
- 2. Select Accounting in the Accounting menu.

 Or, open the Accounting sheet and click the Accounting button.



Accounting Manager Main Window

The Accounting Manager main window consists of a title bar, menu bar, toolbars, listed job selection area, job list area, totals area and status bar.



Title Bar

This displays the printer model, its serial number and the port number it is using.

· Menu Bar

Allows you to select the menu options required for operation.

File Settings View Help

Toolbars

Provide tool buttons and pull-down menus for the main operations.






Note

• You can opt to either show or hide the toolbars in the View menu.

· Listed Job Selection Area

You can use this area to select which job log is displayed.

If you are using regular data acquisition, this area allows you to view the collective job logs for each specified period.




For more information on how to select the job logs displayed, see Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs —P.439 .

· Job List Area


This area lists the details of acquired jobs.

Display a list of jobs within the printer or of jobs collected periodically. For details, refer to Job List Area (\$\infty\$.433)



Totals Area

Displays the total costs for the selected job and the amounts of paper and ink consumed.




Note

• If you are viewing regularly acquired print jobs, selecting a period on the left side of the window displays the total costs for that period and the amounts of paper and ink consumed.

· Status Bar

Displays messages and other information.



Job List Area

The content and items of the jobs displayed in the job list area are as follows.

Job Cost

This is the cost incurred in printing.



Note

• If the Unit Cost of Ink or Paper have not been set, **** is displayed in the Job Cost field.

Document Name

This is the name of the printed document.

Printing Results

Displays OK when printing is executed, and Cancel when it is not executed

Media Type

This is the type of paper used in printing.

Paper Consumed

This is the area of paper used in printing.



Note

• Paper Consumed may differ from the value derived by multiplying Paper Width by Paper Length.

Output Image Size

This is the size of the document used in printing.



Note

• When the job is multiple pages, the size of the last page is displayed.

iPF8300S Job List Area

· Paper Width

This is the width of paper used in printing.



Note

• When the job is multiple pages, the width of the last page is displayed.

Paper Length

This is the length of paper used in printing.

Accounting Manager Basic Procedures

The first time you use the Accounting Manager, use the following procedures to configure the settings.

- 1. Configure unit costs, including the costs of ink and paper.

 For details of the unit cost settings, see Configuring Unit Costs in Accounting Manager —P.434
- 2. Set options such as the units displayed.

 For details of the unit settings, see Configuring Units and Display Settings in Accounting Manager P.438.
- 3. If you are using Regular Data Acquisition, configure the Regular Data Acquisition settings. For details of the Regular Data Acquisition settings, see Automatically Acquiring Print Job Logs at Regular Intervals P.439.
- 4. Specify the jobs to be listed.

 For details of how to select the job logs displayed, see Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs —P.439.

This displays the required print job logs and lists the details.

Configuring Unit Costs in Accounting Manager

Select **Unit Costs** in the **Settings** menu to open the **Unit Costs** dialog box. Configure the unit cost settings in this dialog box.




Note

- When you select a job and then open the **Unit Costs** dialog box, items with unit costs that have not yet been configured for that job are shown highlighted.
- Setting the Unit Cost for Ink →P.435
- Setting the Unit Cost for Paper →P.436
- Setting the Unit Cost for Items Other Than Ink and Paper -P.437

Setting the Unit Cost for Ink

Open the Ink sheet. Set the unit cost for ink in this sheet.



To set the same unit cost for all the inks

- 1. Select the Use same price for all ink checkbox.
- 2. Enter the Tank Capacity and corresponding Price.
- 3. Click the **OK** button.



Important

• Your settings are not applied until you click the **OK** button.

To set different unit costs for each ink color

- 1. Select the ink color to be costed.
- 2. Enter the **Tank Capacity** and corresponding **Price**.

- **3.** Click the **Overwrite** button.
- **4.** Repeat steps 1 to 3 for all the inks.
- **5.** Click the **OK** button.




Important

• Your settings are not applied until you click the **OK** button.

Setting the Unit Cost for Paper

Open the Paper sheet. Set the unit cost for paper in this sheet.



436

- 1. Select a media type from the **Media Type** list.
- 2. Enter the Width and Length of the paper, and the Price per area for the configured width x height.
- 3. Click the Add button. To change the unit cost for a media type you have already set, click the Overwrite button.
- 4. Click the **OK** button.




Important

• Your settings are not applied until you click the **OK** button.

Setting the Unit Cost for Items Other Than Ink and Paper

Open the **Other** sheet. Use this sheet to set any price for items other than inks and paper.



- 1. Enter any name in the Name field.
- 2. Enter a value in Unit Cost.
- **3.** Use **Allocated** to specify whether the costs are allocated as being incurred by the print job.
- **4.** Click the **Add** button. To change the unit cost for a media type you have already set, click the **Overwrite** button.
- **5.** Click the **OK** button.



Important

• Your settings are not applied until you click the **OK** button.




Note

• You can set unit costs for up to 5 items.

Configuring Units and Display Settings in Accounting Manager

Select **Units and Display** in the **Settings** menu to open the **Units and Display** dialog box. Use this dialog box to configure the display settings.



Date Display Format

Use this option to select the display format for dates. "YYYY" indicates the year, "MM" the month and "DD" the day.

Currency Unit

Enter the currency unit. Enter a text string up to 3 characters long.

• 1000 Separator

Use this option to select the symbol used as a separator in numbers. The symbol is inserted every 3 digits.

Decimal Symbol

Use this option to select the symbol used as a decimal point.

Ink Consumed

Use this option to select the unit used for ink consumption.

Paper Width

Use this to select the unit used for paper width.

Paper Length

Use this to select the unit used for paper length.

Area Display Format

Use this to select the unit used for paper area.

Automatically Acquiring Print Job Logs at Regular Intervals

This feature collects print job logs from the printer at regular intervals and saves the logs on your computer.

- 1. Select Regular Data Acquisition in the Settings menu.
- 2. Select Acquire print job logs regularly.
- **3.** Click the **OK** button to close the dialog box.



Important

• Print job log collection is not performed when **Set./Adj. Menu -> Printer Info -> Show Job Log** of the control panel is **Off**. However, even if **Show Job Log** is set to **Off**, regularly acquired jobs that already have been retrieved at that time are displayed.



Note

- Immediately after you configure Regular Data Acquisition, no print jobs are displayed. Wait a few moments and then select **Refresh** in the **View** menu to display the print jobs.
- A maximum of 10,000 records are saved in a print job log. If this number is exceeded, jobs are deleted from the log starting from the oldest record. To save old data, it is recommended that you export the data as a CSV file.

For details of how to export print job logs as CSV files, see Exporting Print Job Data as a CSV File -P.440.

Canceling Regular Print Job Log Acquisition

You can use this procedure to cancel the regular acquisition of print job logs from printers.

- 1. Select Regular Data Acquisition in the Settings menu.
- 2. Uncheck the Acquire print job logs regularly option.
- **3.** Click the **OK** button to close the dialog box.

Switching Between Displaying Jobs on Printer and Regularly Acquired Jobs

The print job logs displayed by the Status Monitor Accounting Manager contain two types of job: Jobs on Printer and Regularly Acquired Jobs.

You can select whether to display Jobs on Printer or Regularly Acquired Jobs in the Listed Job Selection Area on the left side of the window.

Jobs on Printer

This shows a list of the print jobs currently held on printers.

You can change the number of jobs displayed per page using the **Print Jobs Shown Per Page** setting in the **View** menu or the toolbar.

You can skip to a particular page using the **Go to** option in the **View** menu or the toolbar.

3



Note

- For printers with built-in hard disks, you can view up to 500 print jobs per printer.
- For printers without built-in hard disks, you can view up to 32 print jobs per printer. However, only 10 jobs can be displayed if the printer is switched off.

Regularly Acquired Jobs

This shows a list of regularly acquired print jobs.

To view all the jobs in a set period, specify the period using **Period** and then **Starting Date** (or **Starting Day of Week** or **Starting Month**) in the **View** menu or the toolbar.

For example, to view monthly job logs starting on the 1st of each month, set **Period** to **Monthly** and set **Starting Date** to **1**.



Note

• Up to 10,000 regularly acquired jobs are displayed for each printer.

Exporting Print Job Data as a CSV File

You can export the collected print job data in the form of a CSV file by selecting Export Job Cost Data in the File menu.



Note

• You can also select Export Job Cost Data using the icon in the toolbar.

Selected Jobs

Exports the data for the selected print jobs in the job list as a CSV file.



Note

• You can select multiple jobs by holding down the Shift key or Ctrl key as you click the job names.

Listed Jobs

Exports the data for the print jobs currently displayed in the list as a CSV file.

Showing Job Properties

If you select a job in the job list and then select **Show Job Properties** in the **File** menu, the **Job Properties** dialog box appears, allowing you to check information such as detailed cost data.

You can copy text-based information in this dialog box to the clipboard by clicking the **Copy** button.



Note

- You can also open this dialog box by right-clicking the selected job and selecting **Show Job Properties**. Or you can also use the toolbar icon to open the dialog box.
- If you select multiple jobs and open the **Job Properties** dialog box, the total costs for the selected jobs are displayed.

Showing, Saving and Loading Selected Unit Cost Data

Show Unit Cost Data

Select **Show Unit Cost Data** in the **File** menu to open the **Unit Cost Data** dialog box. This lists the unit costs for items such as the selected ink and paper.

You can copy text-based information in this dialog box to the clipboard by clicking the **Copy** button.

Save Unit Cost Data

Select a destination folder using **Save Unit Cost Data** in the **File** menu. The unit cost data for items such as the selected ink and paper is saved as a file.

Load Unit Cost Data

Selecting Load Unit Cost Data in the File menu loads saved unit cost data.

Showing the Total Amount of Ink and Paper Consumed

Select Show Ink and Paper Consumed in the File menu to open the Show Ink and Paper Consumed dialog box.

This lists the total amounts of ink and paper consumed by the printer so far.

You can copy text-based information in this dialog box to the clipboard by clicking the Copy button.




Note

• Up to 7 types of media are listed in order of the amount consumed. The total consumption for other media types is shown as **Other**.

Digital Photo Front-Access

Digital Photo Front-Access

Digital Photo Front-Access is an application that links photos from Canon digital cameras and other image files on your computer with various other applications.



- Simply select an image and click the icon of the application you want to start to launch the application.
- You can also print from Digital Photo Front-Access. In short, Digital Photo Front-Access can help you manage images in many ways from editing to printing as an effective way to work with other applications.
- Digital Photo Front-Access also enables image retouching. For automatic retouching, select an image for retouching and click Image Adjustment.
- Because this application automates the workflow from retouching to display for all of your images, it can save time and work in retouching.



Note

• For details, refer to the Digital Photo Front-Access help.

Device Setup Utility

| imagePROGRAF Device Setup Utility | 443 |
|--|-----|
| Installing imagePROGRAF Device Setup Utility | 443 |
| Configuring the IP Address Using imagePROGRAF Device Setup Utility | 443 |

imagePROGRAF Device Setup Utility

imagePROGRAF Device Setup Utility is a utility to establish communication between the printer and your computer by completing relevant settings. After the printer is installed, for example, you can use imagePROGRAF Device Setup Utility to complete the network settings initially.



- Starting imagePROGRAF Device Setup Utility will show a list of printers found on the network. In this list, select the printer (specifically, the printer's MAC address) that you want to set up, and then configure the basic settings from your computer, such as the printer's IP address and the network frame type.
- You can see which printers are online in the network by checking the printer list. Communication between your computer and these printers is possible.



Note

- We recommend that your network or printer administrator complete the setup work using imagePROGRAF Device Setup Utility.
- For details, refer to the imagePROGRAF Device Setup Utility help.

Installing imagePROGRAF Device Setup Utility

Install imagePROGRAF Device Setup Utility from the User Software CD-ROM provided with the printer as follows:

- 1. Insert the User Software CD-ROM in the CD-ROM drive.
- 2. On the Setup Menu window, click Install Individual Software.
- 3. Click Install in imagePROGRAF Device Setup Utility.
- **4.** Follow the instructions on the screen to proceed with the installation.

Configuring the IP Address Using imagePROGRAF Device Setup Utility

On a computer running Windows, you can use imagePROGRAF Device Setup Utility provided with the printer to configure the printer's IP address. This topic describes how to configure the IP address using imagePROGRAF Device Setup Utility.



Important

• To configure network settings, you must be logged in with administrative rights such as **Administrator** account. We recommend that your network administrator configure the network settings.



Note

• For instructions on installing imagePROGRAF Device Setup Utility, see "Installing imagePROGRAF Device Setup Utility." →P.443


When specifying an IPv4 IP address

1. Start imagePROGRAF Device Setup Utility from the **start** menu.



- 2. In the **Device Name** list displayed, select the printer to configure.
- **3.** Choose **Protocol Settings** from the **Printer** menu.

4. Select the IPv4 tab.



- 5. In the Setting IP Address list, choose Manual.
- **6.** Enter the IP address assigned to the printer and click the **Set** button.
- 7. Click **OK** after the **Confirmation** message is displayed.
- **8.** Exit imagePROGRAF Device Setup Utility.




Note

- To configure the IP address automatically, choose **Auto** in the **Setting IP Address** list and select **DHCP**, **BOOTP**, or **RARP**.
- You can also specify the subnet mask and default gateway.

1. Start imagePROGRAF Device Setup Utility from the **start** menu.



- 2. In the **Device Name** list displayed, select the printer to configure.
- **3.** Choose **Protocol Settings** from the **Printer** menu.
- 4. Select the IPv6 tab.



5. In IPv6, select On.

6. When there is an IPv6-compatible router in the network environment, select **On** in **Stateless Address**. Additionally, when there is an DHCPv6-compatible server in the network environment, select **On** in **DHCPv6**.



Note

- When there is no IPv6-compatible router or DHCPv6-compatible server, select **On** in **Manual** and enter the **IPv6 Address** and **Prefix Length**.
- 7. Click Set.
- $\pmb{8}_{\bullet}$ Click \pmb{OK} after the $\pmb{Confirmation}$ message is displayed.
- **9.** Exit imagePROGRAF Device Setup Utility.

Media Configuration Tool

| The Features of Media Configuration Tool | 448 |
|---|-----|
| Operating Environment | |
| Installation Procedures | |
| Starting the Media Configuration Tool | |
| Media Configuration Tool Main Window | 453 |
| Editing Media Type Information | 454 |
| Adding Media Types | |
| Changing Media Names | |
| Deleting Media Types You Have Added | 460 |
| Switching Media Types Display Show/Hide | |
| Changing the Display Order of Media Types | |
| Updating Media Types | |
| Using Paper Other Than Genuine Paper/Feed Confirmed Paper | 467 |
| Compatible Paper | |
| Add Custom Paper | |
| Delete Custom Paper | |
| Edit Custom Paper | |
| Export Custom Media Information | 480 |
| Import Custom Media Information | |
| Warnings | |
| | |

The Features of Media Configuration Tool

The Media Configuration Tool offers the following features.

- Enables information about additional media (types of paper) supported by the printer to be added to the printer control panel and to the printer driver, through the use of relevant media information files.
- You can rearrange lists of the types of paper on the printer control panel and in printer driver dialog boxes and rename them, in addition to other functions.
- You can add custom paper (paper that is not Canon genuine paper or Canon feed confirmed paper) to the printer control panel and printer driver.



Important

- Normally, the Media Configuration Tool is installed and the media information is configured when you install the printer driver from the User Software CD-ROM. Use this software if you want to add new media information or edit existing media information.
- Administration of paper information using the Media Configuration Tool should be performed by the printer administrator.
- Canon offers absolutely no guarantees regarding the print quality or paper feed properties of customer paper (paper that is not Canon genuine paper or Canon output confirmed paper).
- The paper feed properties cannot be guaranteed if **Add Custom Paper** is used on Canon genuine paper in the Media Configuration Tool.
- The print quality and paper feed properties cannot be guaranteed if **Add Custom Paper** is used on Canon feed confirmed paper in the Media Configuration Tool. Furthermore, Canon does not guarantee the print quality of Canon feed confirmed paper.



Note

• Canon genuine paper and Canon feed confirmed paper are detailed in the Paper Reference Guide. Any other paper is called custom paper.

Operating Environment

You can use Media Configuration Tool in the following environments.

- Compatible Operating System
 - 32 bit edition Windows OS Windows XP, Windows Server 2003, Windows Server 2003 R2, Windows Vista, Windows Server 2008, Windows 7
 - 64 bit edition Windows OS
 Windows XP, Windows Server 2003, Windows Server 2003 R2, Windows Vista, Windows Server 2008, Windows Server 2008 R2, Windows 7



Note

- For the Windows OS, use the latest version of Service Pack.
- Software that requires installation imagePROGRAF Printer Driver

Installation Procedures

The Media Configuration Tool installation screen appears when you start the installation of a new version of the Media Configuration Tool. The installation procedure started from this screen is described below.




Important


- If the printer driver is installed from the User Software CD-ROM, the Media Configuration Tool is also installed and the media information is also configured. Therefore, the following procedure does not normally need to be performed. To install the Media Configuration Tool without using the User Software CD-ROM, such as when you have downloaded a new version of the Media Configuration Tool from the Canon website, use the following procedure.
- You must be logged in as Administrator when installing software in Windows.

iPF8300S Operating Environment

1. Start the Media Configuration Tool installer. Click the **Next** button.



2. The next screen presents selections for the country or area where the printer is used. Select a country or territory then click the **Next** button.




Installation Procedures iPF8300S

3. The License Agreement is displayed.

Select I accept the terms of the license agreement and click the Next button.




4. The **Choose Destination Location** screen appears. Select the destination folder then click the **Next** button.




iPF8300S Installation Procedures

5. The Ready to Install the Program screen appears. Click the Install button.



6. All the required files are copied to your computer and **InstallShield Wizard Complete** screen appears. Click the **Finish** button.



This completes the installation of Media Configuration Tool.

Starting the Media Configuration Tool

Follow the procedure below to start Media Configuration Tool.

From the start menu go to All Programs > iPFxxxx Media Configuration Tool > iPFxxxx Media Configuration Tool.

Media Configuration Tool main window is displayed.



Media Configuration Tool Main Window

The explanation below is on the Media Configuration Tool main window.



Note

• For the step to open the Media Configuration Tool main window, see "Starting the Media Configuration Tool." →P.452

• Add Genuine Paper button

When this button is clicked, the **Edit Media Types** dialog box is displayed, which allows you to add media information files released by Canon to the printer control panel and printer driver. You can also change names, toggle between displaying and hiding, and delete added media types.

You can also change the display order of Canon genuine paper and custom paper.

Refer to Editing Media Type Information —P.454 for details on Add Genuine Paper.

Add Custom Paper button

When this button is clicked, the **Add Custom Paper** dialog box is displayed, which allows you to added custom paper (paper that is not Canon genuine paper or Canon feed confirmed paper) to the printer control panel and printer driver. Refer to Using Paper Other Than Genuine Paper/Feed Confirmed Paper —P.467 for details on **Add Custom Paper**.

• Link to Support Information button


Opens **imagePROGRAF Support Information**. You can check information such as the latest information for the product and software version upgrade information.

• Link to User Manual Button

Click this button to display the User's Guide. This function requires that the User's Guide be installed on your computer.

Editing Media Type Information

Click the **Add Genuine Paper** button in the Media Configuration Tool main window to display the **Edit Media Types** dialog box.



This dialog box presents functions for the following tasks.

- Adding Media Types →P.455
- Changing Media Names →P.458
- Deleting Media Types You Have Added →P.460
- Switching Media Types Display Show/Hide →P.461
- Changing the Display Order of Media Types →P.463



Important

- When you update the media type information, perform the same update on all of the PCs that are using that printer.
- Adding, deleting, toggling display/non-display, and changing the paper name of a media type can only be performed for Canon genuine paper and feed confirmed paper. Refer to "Using Paper Other Than Genuine Paper/Feed Confirmed Paper P.467" for details on adding, editing, and deleting custom paper. Custom paper displays Custom as the Status in the Media Type list.
- To add media types, download the media information file (.amf file) in advance from the Canon website.



Note

• It may not be possible to deleting, showing/hiding, and changing the display order under some conditions.


Adding Media Types

Media information files (.amf files) released by Canon are registered in the printer control panel and printer driver.




Important

- Do not perform printing on the target printer while adding the media types.
- Reinstalling Media Configuration Tool after registering a media information file may delete the registered media information file. In this case, first download and install latest Media Configuration Tool, then download and register the required media information file.
- 1. Open the Edit Media Types dialog box, and then click the Add button.




iPF8300S Adding Media Types

2. The Add Media Type dialog box displays. Click the Browse button.




3. The **Browse for Folder** dialog box opens. Select the folder that contains the media information files (.amf files), and then click the **OK** button.



Adding Media Types iPF8300S


4. The names of media information files in the folder you selected in the Browse for Folder dialog box are displayed under Media Information File in the Add Media Type dialog box. Select the check boxes of paper to add and click the OK button.





Important

- If **Master Media Information File** is displayed as the **Type** of the **Media Information File**, the media type display order and media type display/non-display settings are initialized. Reconfigure these after added the master media information file.
- 5. Click ox when the confirmation message is displayed.
- **6.** In the **Edit Media Types** dialog box, click the **Update** button.



457

iPF8300S Adding Media Types

The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." —P.465




Importan


• Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.

Changing Media Names

1. Open the Edit Media Types dialog box.



2. In the **Media Type** list, select the name to change. Click the **Rename** button.




458

Changing Media Names iPF8300S


3. The **Rename Media** dialog box is displayed.

Edit the names in Name in Printer Driver and Name on Control Panel and click the OK button.





- Note
- To restore the original names, click the **Restore** button.
- **4.** In the **Edit Media Types** dialog box, click the **Update** button.



The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." —P.465




Important

• Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.


iPF8300S Changing Media Names

Deleting Media Types You Have Added

1. Open the Edit Media Types dialog box.



2. In the **Media Type** list, select the name of the media to delete. Click the **Delete** button.




460



Note

• Only paper for which **Status** in the **Media Type** is **Add** can be deleted.

3. In the Edit Media Types dialog box, click the Update button.



The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." —P.465




Important

• Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.


Switching Media Types Display Show/Hide

1. Open the Edit Media Types dialog box.



2. In the **Media Type** list, select the name of the media to switch off or on for display. Click the **Show/Hide** button.


The selected paper is alternately shown or hidden.





Note

- The names of media switched for non-display appear grayed out in the Media Type list.
- Each time you click the **Show/Hide** button, the display mode cycles from showing both the printer driver and printer panel, to hiding both the printer driver and printer panel, and then to showing only the printer panel.
- 3. In the Edit Media Types dialog box, click the Update button.



The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." —P.465




Importan^{*}

• Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.

Changing the Display Order of Media Types


1. Open the Edit Media Types dialog box.




2. Select the paper in the **Media Type** list for which to change the display order, and then click the buttons to move the



The selected item moves one line up or down for every button click.



3. In the Edit Media Types dialog box, click the Update button.



The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." \rightarrow P.465



Important

Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.

Updating Media Types


Clicking the **Update** button on the **Edit Media Types** dialog box opens the **Update Media Types** wizard. You can use this wizard to apply new information about print media in the printer and in the printer driver.

The procedures for updating the media information with the **Update Media Types** wizard are as follows.



Important


- When you update the media type information, perform the same update on all of the PCs that are using that printer.
- 1. Confirm the printer, where media type information is to be updated, to be displayed in **Printer** in the **Update Media Types Select Printer** dialog box, and then click the **Next** button.






Note

• If the printer driver is not installed, the following dialog box is displayed. Select how the printer to update is connected.




2. Communication with the printer starts and the following dialog box is displayed.



iPF8300S Updating Media Types


Important

- Do not attempt to print or turn the printer off while the program is communicating with the printer.
- When the program cannot communicate with the printer, the following warning message is displayed.



3. When the program has finished communicating with the printer, the screen moves to display **Update Media Types - Confirm Update**. Confirm the information received from the printer.

To update click the **Execute** button.





Important

- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the **Cancel** button.
- **4.** Communication with the printer starts and the following dialog box is displayed.




3




Important

- Do not attempt to print or turn the printer off while the program is communicating with the printer.
- When the program cannot communicate with the printer, the following warning message is displayed.



5. Click the **OK** button.





Note

• To apply the same updates to other printers of the same model, click the **Add Genuine Paper** button in the main window to open the **Edit Media Types** dialog box and then click the **Update** button. Select the printer that you want to update in Step 1, and update the media information by following the **Update Media Types** wizard.

Using Paper Other Than Genuine Paper/Feed Confirmed Paper


When the **Add Custom Paper** button is clicked in the Media Configuration Tool main window, the **Add Custom Paper** dialog box is displayed.

Adding custom paper to the printer control panel and printer driver is performed from this screen.



Note

• Custom paper is paper other than Canon genuine paper and feed confirmed paper (paper that is detailed in the Paper Reference Guide).



The following operations can be performed from this screen.

- Add Custom Paper →P.469
- Edit Custom Paper →P.479
- Delete Custom Paper →P.478
- Export Custom Media Information →P.480
- Import Custom Media Information →P.481



Important

- When adding, editing, or deleting custom paper, make the same changes on all of the other PCs that use the target printer. The changes can be made easily by creating a Custom Media Information File (.am1 file) using the custom paper export function and importing the file on the other PCs.
- When using custom paper in another printer, always add the custom paper to that printer before use.
- Canon genuine paper and feed confirmed paper cannot be changed from this dialog box. Refer to "Editing Media Type Information →P.454".
- Changing the display order of media types displayed in the printer control panel and printer driver is performed from the **Edit Media Types** dialog box regardless of whether it is Canon genuine paper or custom paper. Refer to "Editing Media Type Information —P.454".

Compatible Paper

468

Paper specifications

Refer to "Specifications" and "Paper" for specifications such as thickness and size of paper that can be added as custom paper (See "Specifications.") —P.1123

Notes on the operating environment

In low humidity environments (below 40%), your printer may develop the following problems.

• Paper becomes curled or wrinkled.

Compatible Paper iPF8300S

- Paper and the printhead are more likely to touch each other, resulting in a scratched print surface or damaged printhead.
- The cut printed matter sticks to the printer and will not fall down (film media).
- Paper sticks to the printer, making its transfer impossible and preventing its normal ejection (film media).
- Uneven printing (film media)

In high humidity environments (over 60%), your printer may develop the following problems.

- Printed matter will not dry.
- · Wavy paper surface
- Cut edges are ragged (fabric media).
- Margins remain due to borderless printing.



Important

• Canon offers absolutely no guarantees regarding the print quality or paper feed properties of customer paper (paper that is not Canon genuine paper or Canon feed confirmed paper).


Add Custom Paper

In order to add new custom paper to the printer control panel and printer driver, first select the media type to use as the basis from among the Canon genuine paper and feed confirmed paper.. Add this as custom paper after making various changes to the standard paper as necessary.




Important

- Do not execute printing on the target printer while adding custom paper.
- When adding custom paper, check the specifications of paper that can be added using "Compatible Paper P.468".
- Custom paper added using the add custom paper function can only be used by the printer driver. It cannot be used by other software.
- 1. Open the Add Custom Paper dialog box and click the Add button.



iPF8300S Add Custom Paper

2. Check that the printer on which you are updating the media information is displayed in **Printer** in the **Update Media Types - Select Printer** dialog box and click the **Next** button.




3. The Step 1: Select the standard paper dialog box is displayed. In Paper Category, select the category of media type to use as the basis of the custom paper you are adding.



Important

• Select the category that you think is the closest to the custom paper you are adding.



470

Add Custom Paper iPF8300S


4. The media type names of the Canon genuine paper and feed confirmed paper within the selected category are shown in **Media Type Name**. Select the media type to use as the basis of the custom paper, and click the **Next** button.



Note

- If you do not know which media type to use as the basis of the custom paper, click the **Assist** button to open the **Media Type Selection Assistance** dialog box, and then set either the **Weight (grammage)** or the **Thickness**. The Media Configuration Tool automatically selects the appropriate paper from the selected paper category. Alternatively, select the media type called **General** from among the displayed **Media Type Name**.
- Depending on the selected category, there might not be a media type called **General**.
- Depending on the selected category, the **Assist** button may be disabled.
- 5. The Step 2: Set the custom paper name dialog box is displayed.

 Enter an arbitrary name to display in the printer control panel and printer driver, and then click the Next button.





Note

- Paper Name (English) is used in keeping track of the amount of roll paper left, in status print, etc.
- **6.** Load the custom paper in the printer and then click the **OK** button.






Important

• Do not load paper that is curled or that has already been printed on.


iPF8300S Add Custom Paper

7. The Step 3: Paper Source Settings dialog box is displayed. Select the paper source where the custom paper is loaded and then click the OK button.



8. The Step 4: Paper feed adjustment dialog box is displayed. Click the Execute button to execute paper feed adjustment.

The adjustment pattern is printed, and the paper feed is automatically adjusted based on the printing result. Once the paper feed adjustment is complete, click the **Next** button.





Important


- Check that there is no paper left on the ejection guide.
- If **Paper Feed Adjustment** is not executed, horizontal stripes with different color tones may appear in the printed material. Paper feed adjustment does not need to be executed more than once. Execute paper feed adjustment only once each time you add a custom paper.
- **9.** The **Roll Paper Settings** dialog box is displayed.



Note

• If a paper source other than **Roll Paper** is selected in the **Step 3: Paper Source Settings** dialog box, this screen is not displayed.

Add Custom Paper iPF8300S



Configure the following settings as necessary, and then click the **Next** button.

| Setting | Details |
|-----------------------------------|---|
| Automatic Cutting Settings | Configures the method for cutting roll paper when it is ejected after printing. |
| | • Automatic Cut :Roll paper is automatically cut by the cutter unit. |
| | • Eject Cut : When the Cut key is pressed on the printer control panel, the roll paper is cut by the cutter unit. Select this if you do not want the printed material to drop immediately after printing, such as to wait for the ink to dry. |
| | • User Cut :Cutting is not performed by the cutter unit. Cut the roll paper using scissors after each sheet. Select this for paper that cannot be cut by the cutter unit. |
| Drying Time | Specify the time that the printer waits for ink to dry, as needed. |
| | Off : Ejects immediately after printing finishes. |
| | • 30 sec./1 min./3 min./5 min./10 min./30 min./60 min. :Ejects after the specified time has elapsed after printing finishes. |
| Borderless Printing | Configures whether or not to permit borderless printing. |
| | Permit : Borderless printing is permitted. |
| | • Deny : Borderless printing is denied. |

iPF8300S Add Custom Paper




Important

- Depending on the paper, there are types that cannot be cut by the cutter unit, and types that speed deterioration of the blade and cause damage to the cutter. For thick paper, hard paper, etc. do not use the cutter unit, and instead cut the roll paper using scissors, etc. after printing. In this case, select **User Cut** as the **Automatic Cutting Settings**.
- If borderless printing is performed on paper where the ink drying is poor, the cutter unit may leave scratches where it touches the printed surface, or may not cut correctly. In this kind of situation, configure the amount of time to wait for the ink to dry after printing using **Drying Time**. Alternatively, if the paper cannot be cut well by the cutter, set the **Automatic Cutting Settings** to **User Cut** and cut the roll paper using scissors, etc.
- Paper where borderless printing can be performed is limited by the media type and roll paper width. Refer to "Compatible Paper —P.468".
- For custom paper where there is a need to set the **Automatic Cutting Settings** to **User Cut**, set the **Borderless Printing** to **Deny**.

10. The Step 5: Configure the amount of ink used dialog box is displayed.

The upper limit on the amount of ink used to print to the custom paper is set on this screen by selecting from among several levels.

First, click the **Test Print** button to perform a test print of each level.





Important


• If **Newsprint for Proofing** was selected as the standard paper for the custom paper, you cannot perform the test print or configure the maximum ink usage.

474


Add Custom Paper iPF8300S

11. The **Test Print Settings** dialog box is displayed.

Select the print priority and print quality of the test print using **Print Priority** and **Print Quality**. Set the level to test print using **Maximum ink usage** and the image to use using **Image used in test print**, and then click the **Start Print** button.



12. Determine and set the ink level that is thought to give the best visual test print results with no bleeding or scraping of ink




Note

- Select the optimal ink level by referring to the help.
- If you cannot obtain sufficiently high quality printing no matter which maximum ink usage level you select, use the **Step 1: Select the standard paper** dialog box to change the paper that is the basis of the custom paper to another paper.

iPF8300S Add Custom Paper

Important

- Because this settings imposes an upper limit on the amount of ink used during printing, the printing result might not change even if the level is changed depending on the image.
- The color tone cannot be configured using the Media Configuration Tool. Although the color tone may change when the maximum ink usage is changed, at this point you should select the optimal level by only focusing on bleeding and scraping of ink. If the color tone needs to be adjusted, provide an ICC color profile that matches the paper you are using, and select that ICC color profile in your software.
- Depending on the maximum ink usage setting, some of the print qualities in the printer driver may become unselectable.
- 13. Configure **Head Height** and **Vacuum Strength** as required and click the **Next** button. Usually, these do not need to be set.





Important


- If you set the **Head Height** lower than the automatically set height in parentheses (), check that the printhead does not rub against the paper. (If the printhead rubs against the paper, there will be scratches in the printing results.) If the printhead rubs against the paper, this can cause damage to the printhead.
- If you change the **Vacuum Strength**, check that the printhead is not rubbing against the paper. (If the printhead rubs against the paper, there will be scratches in the printing results.) If the printhead rubs against the paper, this can cause damage to the printhead.
- For details on the **Head Height** and **Vacuum Strength**, refer to the help.

476


Add Custom Paper iPF8300S

14. The Step 6: Confirm the settings dialog box is displayed.

Configure the settings of the custom paper, and then click the Next button.



15. The Confirm Update dialog box is displayed. Confirm the updates and then click the Execute button.



The custom paper is added to the control panel of the printer and to the printer driver of the PC you are using.



Important

• If you have added custom paper with the **POP Board** / **Cardboard** category as the Standard Paper, remove the loaded custom paper from the printer.

iPF8300S Add Custom Paper


Note

• When the custom paper is correctly added to the printer driver, the name of the added custom paper is displayed in the **Edit Media Types** dialog box that is opened by **Add Genuine Paper** in the Media Configuration Tool window.

Delete Custom Paper

You can delete custom paper that you have already added from printer control panel and from the printer driver of the PC you are using.


- 1. Open the Add Custom Paper dialog box.
- 2. Select the paper you want to delete from the Added Custom Paper list and then click the Delete button.




478

Delete Custom Paper iPF8300S

3. Select the custom paper you want to delete, and then click the **Next** button.



4. The **Confirm Update** dialog box is displayed. Confirm the updates and then click the **Execute** button.



The custom paper is deleted from the control panel of the printer and from the printer driver of the PC you are using.


Edit Custom Paper

You can change the settings of custom paper you have already added.

1. Open the Add Custom Paper dialog box.

iPF8300S Edit Custom Paper

2. Select the paper you want to edit from the Added Custom Paper list and then click the Edit button.



3. The **Update Media Types - Select Printer** dialog box is displayed. Follow the on-screen directions and change the settings as required.



Note

• Refer to Steps 5 to 15 of the "Add Custom Paper P.469" for details on how to configure each setting.


Export Custom Media Information

You can export to file and save media information about custom paper that you have added.


The saved Custom Media Information File can be used by importing it into another printer or PC. Refer to "Import Custom Media Information".

1. Open the Add Custom Paper dialog box.

2. Select the paper you want to export to media information file from the **Added Custom Paper** list and then click the **Export** button.



3. Specify the location to save the Custom Media Information File.




A Custom Media Information File (.am1 file) is saved.

Import Custom Media Information


You can import a Custom Media Information File that has been saved in a folder, and add the file to the printer control panel and to the printer driver of the PC you are using.

1. Open the Add Custom Paper dialog box.

2. Click the **Import** button.



3. Select the printer to add the custom paper to.




482


Note

• Double-click Custom Media Information File to start the Media Configuration Tool and display this screen.

4. Select the Custom Media Information File (.am1 file) to import.



5. The **Confirm Update** dialog box opens. Click the **Execute** button.



The custom paper is added to the control panel of the printer and to the printer driver of the PC you are using.



Note

When the custom paper is correctly added to the printer driver, the name of the added custom paper is
displayed in the Edit Media Types dialog box that is opened by Add Genuine Paper in the Media
Configuration Tool window.

Warnings

Take note of the following warnings when added custom paper other than Canon genuine paper and feed confirmed paper to the printer driver and the printer itself.

About the Cutter

• Depending on the paper, there are types that cannot be cut by the cutter unit, and types that speed deterioration of the blade and cause damage to the cutter. For thick paper, hard paper, etc. do not use the cutter unit, and instead cut the roll paper using scissors, etc. after printing. In this case, select **User Cut** as the **Automatic Cutting Settings** in the **Roll Paper Settings** dialog box.



Note

- If the cutter is damaged, contact your Canon dealer for assistance.
- Refer to "Specifying the Cutting Method for Rolls" for details on the methods for cutting roll paper. (See "Specifying the Cutting Method for Rolls.") —P.802

About the Printhead

- If the printhead rubs against the paper during printing, this may cause damage to the printhead. If the printhead is rubbing against the paper, configure the Vacuum Strength in the Step 5: Configure the amount of ink used dialog box as follows.
 - For paper-based media such as Heavyweight Coated Paper: Set to Strong or Strongest
 - For film-based media such as CAD Tracing Paper: Set to Standard, Strong, or Strongest
 - For thin paper of thickness 0.1mm or less: Set to Weakest



Note

- If the printhead still rubs even after changing the Vacuum Strength, set the Head Height to be higher in the Step 5: Configure the amount of ink used dialog box.
- Refer to "Paper rubs against the Printhead" for details on how to handle the printhead rubbing against the paper. (See "Paper rubs against the printhead.") —P.1072

About Borderless Printing

When performing borderless printing on paper where the ink does not dry well, the cutter unit may leave scratches where it touches the printed surface, or may not cut correctly. In this kind of situation, configure the amount of time to wait for the ink to dry after printing using **Drying Time** in the **Roll Paper Settings** dialog box.
 Alternatively, if the paper cannot be cut well by the cutter, set the **Automatic Cutting Settings** to **User Cut** in the **Roll Paper Settings** dialog box, and cut the roll paper using scissors, etc.

About the Print Quality

- If the edges of images are blurry, set the Vacuum Strength to be weaker in the Step 5: Configure the amount of ink used dialog box.
- If lines are warped or scratched, set the **Head Height** to be lower in the **Step 5: Configure the amount of ink used** dialog box.
- If the amount of ink used is too much, wrinkles may appear and the ink may bleed in the printed material. Furthermore, if the amount of ink used is too little, color production may be poor and lines may become scratched. In this kind of situation, change the amount of ink used in the Step 5: Configure the amount of ink used dialog box.

Warnings iPF8300S

• If horizontal bands with different color tone appear in the printed material, execute Paper Feed Adjustment in the Step 4: Paper feed adjustment dialog box. If you have already executed Paper Feed Adjustment, execute Adj. Fine Feed from the printer control panel and fine tune the amount of paper feed.



Note

- Refer to "Fine tuning the amount of paper feed (paper feed fine adjustment)" for details on **Adj. Fine**Feed. (See "Fine-Tuning the Paper Feed Amount (Adj. Fine Feed).") P.861
- If horizontal bands appear even after executing **Adj. Fine Feed**, refer to "Banding in different colors occurs" in "Troubleshooting". (See "Banding in different colors occurs.") —P.1075
- If you cannot obtain sufficiently high print quality, change the maximum ink usage, or change the media type used as the basis for the custom paper in the **Step 1: Select the standard paper** dialog box.
- If there is no luster in printed material, set the paper used as the basis for the custom paper to a paper that uses photo ink as the Black ink.
 - The types of Black ink used are displayed on the right side of each media type in the **Step 1: Select the standard paper** dialog box.



Note

• Refer to "Problems with the printing quality" for details on problems with printing quality. (Refer to "Problems with the printing quality —P.1071")


About the Color Tone

- The color tone cannot be configured using the Media Configuration Tool. If the color tone needs to be adjusted, provide an ICC color profile that matches the paper you are using, and select that ICC color profile in your software.
- Custom paper cannot be used with the ambient light adjustment function or Monitor Matching in Color-Matching Method.

iPF8300S Warnings

Mac OS X Software

| Printer Driver | 487 |
|--|-----|
| Preview | 519 |
| Free Layout | 550 |
| Color imageRUNNER Enlargement Copy | 584 |
| Print Plug-In for Photoshop/Digital Photo Professional | 609 |
| Printmonitor | 674 |
| Media Configuration Tool | 677 |




Printer Driver

| Printer Driver Settings | |
|---|-----|
| Specifying Paper in the Printer Driver | 489 |
| Confirming Print Settings | |
| Checking the Layout in a Preview Before Printing | |
| Using Favorites | |
| Accessing the Printer Driver Dialog Box from Applications | |
| Main Pane | 495 |
| Paper Information on Printer Dialog Box | 499 |
| Paper Detailed Settings Dialog Box | 500 |
| View settings Dialog Box for the Printing Application | 503 |
| Matching pane | 503 |
| Ambient Light Adjust dialog box | 506 |
| Light Source Check Tool | 508 |
| Color Settings Pane: Color | 509 |
| Object Adjustment dialog box: Color | 510 |
| Color Settings Pane: Monochrome | 511 |
| Object Adjustment dialog box: Monochrome | 512 |
| Gray Adjustment Pane | 513 |
| Page Setup Pane | 514 |
| Utility Pane | 516 |
| Additional Settings Pane | 517 |
| Support Pane | |

Printer Driver Settings

For instructions on accessing the Mac OS X printer driver, refer to the following topics.

• Accessing the Printer Driver Dialog Box from Applications →P.494



For information on the Mac OS X printer driver settings, refer to the following topics.

Main Pane →P.495

You can specify the media type, color processing, print quality, print preview, and other settings. Choose **Easy Settings** to specify basic print settings based on the printing application or **Advanced Settings** to complete more detailed settings as desired.

- Paper Detailed Settings Dialog Box →P.500
- View settings Dialog Box for the Printing Application →P.503
- Color Settings Pane: Color →P.509
- Object Adjustment dialog box: Color →P.510
- Matching pane →P.503
- Ambient Light Adjust dialog box →P.506
- Light Source Check Tool →P.508
- Color Settings Pane: Monochrome →P.511
- Object Adjustment dialog box: Monochrome →P.512
- Gray Adjustment Pane →P.513
- Page Setup Pane →P.514

You can specify the page size of the original, borderless printing, enlargement or reduction, the orientation, the paper size and source, and automatic cutting.

Utility Pane →P.516

You can specify settings related to maintenance for the Printhead and feed amount, as well as settings for Color imageRUNNER Enlargement Copy.

Printer Driver Settings iPF8300S

- Additional Settings Pane →P.517
 You can specify settings for how print jobs are sent to the printer.
- Support Pane —P.518

 You can view support information and the user's manual.

With the **imagePROGRAF** Free Layout feature, you can arrange originals from various source applications on a single page before printing. For details, see Free Layout —P.550.

With the **imagePROGRAF Preview** feature, you can check the layout before printing and adjust layout or size settings while viewing a preview screen. For details, see Preview —P.519.

With the Color imageRUNNER Enlargement Copy feature, you can automatically enlarge and print scanned originals from a Color imageRUNNER. For details, see Color imageRUNNER Enlargement Copy —P.584.


• The configuration method varies depending on the OS and application software you are using.

Specifying Paper in the Printer Driver


Note

If you have replaced the paper, you must complete the following settings in the printer driver.

 ${f 1}_{f \cdot}$ This sets the ${f B}$ Format for and ${f C}$ Paper Size.




If it is not displayed, the settings are configured in the upper part of the printer driver displayed when you select **Print** from the application software menu.




2. Select the printer in the A Printer list.

489


- **3.** Choose the original size in the **F** Paper Size list.
- **4.** If you configured the settings using the **Page Attributes** dialog box, click **FOK** to close the dialog box, and then select **Print** from the application software menu.
- **5.** Access the **Main** pane.



- **6.** In the **A Media Type** list, select the type of paper that is loaded.
- 7. Access the Page Setup pane.



- **8.** In the **A Paper Source** list, select how paper is supplied.
- 9. If you have selected Cut Sheet in A Paper Source, make sure the size as selected in Page Setup is displayed in C Page Size. If you have selected roll paper in A Paper Source, make sure the width of the loaded roll is displayed in B Roll Width.





Note


• A variety of settings are available in the printer driver to suit different printing applications. For details on available printing conditions, see "Printer Driver Settings P.487"

Confirming Print Settings

There are two ways to confirm what printing conditions have been specified, as follows.

Checking a preview of the settings

A preview of the settings is displayed on the left side of the Main, Page Setup, Utility, and Additional Settings panes. By checking images and numerical values in the preview, you can confirm current settings for the page size, orientation, paper source, and so on.



| Display Area | Information Displayed |
|---|--|
| Pane displayed when the H Images tab is clicked | On top, illustrations indicate the page size of the original, the paper size, orientation, layout, borderless printing selection, color mode, and other settings information. Under this, the page size, paper size, and method and percentage of enlargement or reduction is displayed. |
| Pane displayed when the Size tab is clicked | Paper size details are indicated numerically. |
| Pane with printer and paper illustrations | Illustrations indicate the paper source, orientation, borderless printing selection, and other settings information. |



Note

• To confirm the **Print Target** specified in **Easy Settings**, click **G** View set. on the **Main** pane to display the View settings dialog box.

Checking a print preview

You can check an image of the original just as it will be printed.

Confirming the image of print jobs beforehand helps prevent printing errors.


For details on print previews, see "Checking the Layout in a Preview Before Printing →P.184 "

Confirming Print Settings

Checking the Layout in a Preview Before Printing


This topic describes how to check the layout before printing using the Canon imagePROGRAF Preview function.

- **1.** Choose **Print** in the application menu.
- 2. Access the Main pane.



- 3. Select the OPrint Preview check box.
- 4. Click M Print.

5. The Canon imagePROGRAF Preview window is displayed.



- **6.** Check the layout and adjust settings in the **Canon imagePROGRAF Preview** window as desired.
- 7. Print from the Canon imagePROGRAF Preview menu.



Note

• For details on **imagePROGRAF Preview** functions, refer to Preview —P.519 .

Using Favorites

You can use the **Presets** function in Mac OS X for favorite-based printing.



Note

• In the printing dialog box, click **Save As** in the **Presets** list to save the current print settings. This is a standard feature of the operating system. For details, refer to the Mac OS documentation.

Accessing the Printer Driver Dialog Box from Applications

1. In the application software, select **Print** from the **File** menu to display the dialog box for printing conditions.




Note

• This dialog box includes basic printing options and enables you to choose the printer, specify the range of pages, number of copies, and so on.


Using Favorites iPF8300S

2. Select the printer in the **Printer** list.



3. Click **Print** to start printing.

As shown in the following illustration, you can switch to other panes in this dialog box to complete settings for various methods of printing, including enlarged and reduced printing, borderless printing, and so on.



Main Pane

The following settings are available on the **Main** pane. For details on settings items, refer to the printer driver help.




Note

• On the **Main** pane, choose **Easy Settings** to specify basic print settings based on the print target, or switch to **Advanced Settings** to complete more detailed settings as desired.

iPF8300S Main Pane

Common Items



A Media Type

Select the paper type.

For information on the types of paper the printer supports, refer to the Paper Reference Guide. (See " Paper Reference Guide ".)

• B Get Information

Displays **Paper Information on Printer**. You can update the printer driver settings for the feed source, media type, and roll width by selecting the feed source.

Paper Information on Printer Dialog Box →P.499

• C Set

Displays **Paper Detailed Settings**. You can configure the printing settings to match the type of media, such as the ink drying time.

Paper Detailed Settings Dialog Box →P.500

O Print Preview

If you turn this on, imagePROGRAF Preview starts before printing.

This allows you to check on-screen previews of documents before printing.



Important

• When Free Layout is selected on the Page Setup panel, Free Layout is disabled.


Checking the Layout in a Preview Before Printing →P.184

L Printer Information

Display the **Printer Information** dialog box. You can display information of the printer such as the remaining ink.

Main Pane iPF8300S

Configuration using Easy Settings



• E Print Target

Choose presets that match the type of document to be printed.

- Printing Photos and Images →P.22
- Printing Office Documents →P.38
- Printing Line Drawings and Text →P.47

• F Print Quality

Choose the level of print quality.

• G View set.


Click to display the **View settings** dialog box, which enables you to confirm the settings for the selected item from the **E Print Target** list or change the order of items listed in **E Print Target**.

• View settings Dialog Box for the Printing Application —P.503

497

iPF8300S Main Pane

Configuration using Advanced Settings



• E Print Priority

Choose the graphic elements that you want to emphasize for printing.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.64

F Print Quality

Choose the level of print quality.

• Giving Priority to Particular Graphic Elements and Colors for Printing —P.64

N Highest quality

If you select this option, the document will be printed with enhanced quality at the highest resolution. Compared to the other options, more time and ink are consumed in printing, however you will attain print results with the highest quality.



Note

• If you set **F** Print Quality to High, you can select **N** Highest quality. However, depending on **A** Media Type, you may not be able to select **N** Highest quality.

K Economy Printing

When this mode is selected, you can print with less ink consumed. However, print quality is lower than in regular printing. Select this option to save ink, such as when printing to check drawings. Depending on the A Media Type and F Print Quality settings, this mode may not be available.



Note

• If you set **F Print Quality** to **Fast**, you can select **K Economy Printing**. However, depending on **A Media Type**, you may not be able to select **K Economy Printing**.

Main Pane iPF8300S

G Input Bit Depth

Choose the levels of gradation in print data, either **8-bit** or **16-bit**. Optimal results when printing data with rich gradation are possible by choosing **16-bit**. For example, this option is particularly suited to printing images created after specifying 16 bits per channel in Photoshop.

(Mac OS X 10.4 or later)

R Fast Graphic Process

Select this option to print faster than usual, when possible.

• H Color Mode

Choose the color mode.

Giving Priority to Particular Graphic Elements and Colors for Printing →P.64

• | Set

Click to display the **Color Settings** dialog box for more advanced color settings.

Adjusting the Color in the Printer Driver →P.55

J Unidirectional Printing


Select this checkbox to prevent problems such as misaligned lines and improve the print quality. However, the printing speed becomes slower.

Q Thicken Fine Lines

Activate this option to print fine lines more distinctly.

Paper Information on Printer Dialog Box

On the **Paper Information on Printer** dialog box, you can obtain information on the paper in the printer and configure printer driver media type setting.



499

Note

• To display the Paper Information on Printer dialog box, on the Main pane, click Get Information by Media Type.(See "Main Pane →P.495")

A Paper Source

Shows the **Paper Source** supported by the printer, as well as the type of paper loaded. To update the media type setting in the printer driver, select the desired **Paper Source** option and click **OK**.

Paper Detailed Settings Dialog Box

In the **Paper Detailed Settings** dialog box, you can set **Drying Time** for the paper selected with **Media Type** of the **Main** panel, etc.

You can display this dialog box by clicking **Set** of **Media Type** on the **Main** panel. (Refer to "Main Pane —P.495".) You also can select from the control panel of the printer the items for which you can select **Printer Default** in this dialog box. (Refer to "Menu Settings —P.938".)



500 A Media Type

The paper selected with **Media Type** of the **Main** panel is displayed.

For information on the types of paper the printer supports, refer to the Paper Reference Guide. (See " Paper Reference Guide ".)

B Drying Time

Specify the time that the printer waits for ink to dry, as needed. The **Drying Time** setting is only valid for rolls.

• C Between Pages

You can set the time to wait after printing 1 document page until ejecting the paper. Since waiting time is required for ink to dry before a roll is cut, you can deliver paper in the Output Stacker with the ink dried even if **Cutting Mode** is set to **Automatic**.

| Setting Item | Details | |
|--|--|--|
| Printer Default | The setting of the control panel of the printer is applied. | |
| None | Paper is ejected immediately after printing completes. | |
| 30 sec. / 1 min. / 3 min. / 5 min. / 10 min. / 30 min. / 60 min. | Paper is ejected when the set time elapses after printing completes. | |

D Between Scans

You can set the time to wait after printing 1 line on a page until printing the next line. Set this to avoid bleeding or color unevenness such as when bleeding occurs on a page or when color unevenness occurs during borderless printing.

| Setting Item | Details |
|---------------------------------------|--|
| Printer Default | The setting of the control panel of the printer is applied. |
| None | The next line is printed immediately after a line is printed. |
| 1 sec. / 3 sec. / 5 sec. / 7 sec. / 9 | The next line is printed when the set time elapses after a line is printed. |
| sec. | * Increase the time according to the occurrence condition of bleeding or unevenness. |

E Roll Paper Margin for Safety

You can specify the length of a margin on the leading edge of paper to ensure that paper susceptible to curling is held firmly against the Platen.

• F Near End Margin

Specify the length of the Near End Margin (the leading edge margin) of the roll, as needed.

| Setting Item | Details |
|-----------------|--|
| Printer Default | The setting of the control panel of the printer is applied. |
| 5 mm (0.2 in) | The document is printed in the standard size. |
| | * Select this when you do not have any problems in printing. |
| 20 mm (0.8 in) | Select this when rubbing against the printhead occurs such as when using paper that tends to curl. |

G Cut Speed

Select the speed of automatic cutting, as needed. You can adjust this setting if paper is not cut well when automatic cutting is used.

| Setting Item | Details |
|-----------------|--|
| Printer Default | The setting of the control panel of the printer is applied. |
| High Speed | When the Standard setting does not result in a clean cut surface, select this. |
| Standard | Select this when you do not have any problems in automatic cutting. |
| Low Speed | This helps prevent adhesive from sticking to the cutter and keeps the cutter sharp if you select it when using adhesive paper. |

501

H Automatic Cutting

Set whether to perform roll cutting automatically or print a cut line.

The following settings are available for automatic cutting.

| Setting Item | Details |
|---------------------|--|
| Printer Default | The setting of the control panel of the printer is applied. |
| None | After printing completes, the roll is not cut per page, and the next page of data is printed successively. |
| Print Cut Guideline | After printing completes, a line is printed per page, and the next page of data is printed successively. |

Calibration Value

You can specify whether to apply the results of calibration performed on the printer to image processing.

| Setting Item | Details |
|-----------------|---|
| Printer Default | The setting of the control panel of the printer is applied. |
| Enabled | Print using the calibration results. |
| Disabled | Print without using the calibration results. Select this to avoid the changing of the color of images during printing by color calibration. |

J Mirror


Specify whether to print a mirror image, as needed. Select this option to print a version of the document or image with the left and right sides inverted.

K Extend print pass

If you are concerned about uneven colors in the print result of **Highest quality**, selecting this option may improve printing results. However, printing may take longer.

View settings Dialog Box for the Printing Application

In the View settings dialog box, you can check details of the selected printing application.





Note

• To display the View settings dialog box, on the Main pane, click View settings by Print Target. (See "Main Pane →P.495")

• A Print Target

Shows all **Print Target** options (settings items for the printing application).

• B Name

Identifies the item selected in **Print Target** by its name and an icon.

C Details

Here, you can confirm detailed settings values for each item selected in the **Print Target** list.

Matching pane

On the **Matching** pane, you can specify color matching to compensate for differences in the appearance of colors on various devices.



Important

• If **No color correction** is selected under **Color Mode**, the **Matching** pane is not displayed.




Note

• To display the Matching pane, on the Main pane click Color Settings in Color Mode in Advanced Settings, and then click the Matching tab. (Refer to "Main Pane P.495")

Driver Matching Mode

The following options are available when you select **Driver Matching Mode** in the A Matching Mode list.



A Matching Mode

Select the color matching mode to use, as desired.

Normally, select **Driver Matching Mode**. For color matching based on ICC profiles, select **ICC Matching Mode** depending on your color matching system.

B Matching Method

Select the color matching method that suits the document to be printed. Various **B Matching Method** options are available depending on your selection in **A Matching Mode**.

Color Space

Select the applicable color space as desired.

• D Monitor White Point

Enter the color temperature set on the monitor.

Displayed when the **B** Matching Method is set to Monitor Matching.

• EUse ambient light adjustment

Select this option for adjustment of colors to suit the ambient light in the viewing environment.

F Ambient Light Adjust


Click to display the **Ambient Light Adjust** dialog box, which enables you to complete settings for printing to match the ambient light.

Ambient Light Adjust dialog box →P.506

Matching pane iPF8300S

ICC Matching Mode

The following options are available when you select ICC Matching Mode, in the A Matching Mode list.





Note

• To display the Matching pane, on the Main pane, click Color Settings by Color Mode in Advanced Settings, and then click the Matching tab.(See "Main Pane P.495")

A Matching Mode

Select the color matching mode to use, as desired.

• BInput Profile Settings

You can choose Input Profile.

Various options are available depending on your selected **AMatching Mode**.

C Matching Method

You can choose **C** Matching Method.

Various options are available depending on your selected **AMatching Mode**.

D Printer Profile Settings

Specify the printer profile as desired.



Note


• For details on settings items, see "Adjusting the Color in the Printer Driver →P.55"

iPF8300S Matching pane

Ambient Light Adjust dialog box

The **Ambient Light Adjust** dialog box is used to select the setting method and to enter and select the information required for the settings.

When you select By selecting a chart number in Setting Method



A Setting Method

You can choose configuration based on the printed Chart or based on using the i1 colorimeter.

• B Print Chart

Click to start the **Light Source Check Tool**, for printing **Chart**.

Light Source Check Tool →P.508

• C Chart Number

In **Chart**, select the number of the pattern with your desired colors.


• D Color Temperature

Enter the **D** Color Temperature measured during monitor calibration. Displayed when the **B** Matching Method is set to Monitor Matching on the Matching pane.

• Ellluminance

Enter the **Elluminance** measured during monitor calibration. Displayed when the **BMatching Method** is set to **Monitor Matching** on the **Matching** pane.

When you select By entering values directly in Setting Method



A Setting Method

You can choose configuration based on the printed **Chart** or based on using the i1 colorimeter.

B Lighting Source Type

Select the light source measured using the i1 colorimeter.

• D Color Temperature

Enter the **D** Color **Temperature** measured using the i1 colorimeter.

• Ellluminance

Enter the **E Illuminance** measured using the i1 colorimeter.

Displayed when the **B** Matching Method is set to Monitor Matching on the Matching pane.




Note

• For details on settings items, see "Adjusting the Color in the Printer Driver -P.55"

507

Light Source Check Tool

The Light Source Check Tool enables you to print Chart.



A Printer Name

The printer name is displayed here.

• B Media Type

Select the type of paper. For details on paper types supported by **Driver Matching Mode**, refer to the Paper Reference Guide. (See " Paper Reference Guide ".)

• C Paper Source

Choose the paper source, as desired.

Options displayed in the list vary depending on the selection in **B Media Type** in the **Main** pane.

• D Print


Click to print the Chart.

508

Color Settings Pane: Color

In general, make any needed adjustments to the color of documents in the application used to create them. However, if the color tone as printed is not as you expected, you can also adjust the color in the printer driver.

If the color tone as printed is not as you expected, you can adjust it on the Color Adjustment pane.





Note

• To display the Color Adjustment pane, on the Main pane click Color Settings by Color Mode in Advanced Settings. (See "Main Pane —P.495")

A Sample Type

Choose a sample image from Standard, Portrait, Landscape, or Graphics.

B View Color Pattern

Select this checkbox to display the color pattern.

C Apply to Sample

Select this checkbox to apply the changed settings to the sample image.

D Cyan / E Magenta / F Yellow

Correct color tones by adjusting the levels of each color.

• G Gray Tone

Adjust the color tone of grays as desired. Choose Cool (tinged with blue) or Warm (tinged with red).

H Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

iPF8300S Color Settings Pane: Color

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the **Contrast** makes images sharper, and reducing the **Contrast** softens images.

J Saturation

Adjust the color intensity as desired. Increasing the **Saturation** setting makes colors more vivid, and reducing the **Saturation** makes colors more subdued.



Note

• For details on settings items, see "Adjusting the Color in the Printer Driver —P.55"


K Object Adjustment

Select this option to display the **Object Adjustment** dialog box, in which you can specify objects subject to color adjustment.

Object Adjustment dialog box: Color →P.510

Object Adjustment dialog box: Color

In the **Object Adjustment** dialog box, you can specify what type of print jobs to apply color adjustment to. If an original comprises images, graphics, and text, you can specify which portion to apply color adjustment to.





Note

• To display the Object Adjustment dialog box, click Object Adjustment on the Color Adjustment panel.

• Almages

Select this option to apply color adjustment to image areas, such as photos.

B Graphics

Select this option to apply color adjustment to graphics, such as lines and circles.

• C Text


Select this option to apply color adjustment to text.

1

510

Color Settings Pane: Monochrome

On the Color Adjustment pane for monochrome printing, you can adjust the brightness and contrast.





Note

• To display the Color Adjustment pane, on the Main pane, click Color Settings in Advanced Settings.(See "Main Pane →P.495")

A Sample Type

Choose a sample image from Standard, Portrait, Landscape, or Graphics.

B View Color Pattern

Select this checkbox to display the color pattern.

C Apply to Sample

Select this checkbox to apply the changed settings to the sample image.

• D Cyan / E Magenta / F Yellow

Not available.

• G Gray Tone

Not available.

• H Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

• | Contrast

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the Contrast makes images sharper, and reducing the Contrast softens images.

Color Settings Pane: Monochrome

J Saturation

Not available.



Note

• For details on settings items, see "Adjusting the Color in the Printer Driver →P.55"

K Object Adjustment

Select this option to display the **Object Adjustment** dialog box, in which you can specify objects subject to color adjustment.

Object Adjustment dialog box: Monochrome →P.512

Object Adjustment dialog box: Monochrome

In the **Object Adjustment** dialog box, you can specify what type of print jobs to apply color adjustment to. If an original comprises images, graphics, and text, you can specify which portion to apply color adjustment to.





Note

• To display the **Object Adjustment** dialog box, click **Object Adjustment** on the **Color Adjustment** panel.

• Almages

Select this option to apply color adjustment to image areas, such as photos.

B Graphics

Select this option to apply color adjustment to graphics, such as lines and circles.

C Text

Select this option to apply color adjustment to text.

Gray Adjustment Pane

On the Gray Adjustment pane, you can adjust the color balance, brightness, contrast, and other image qualities.





Note

- To display the **Gray Adjustment** pane, on the Main Pane —P.495, select **Monochrome** (Photo) by Color Mode in Advanced Settings, and then click Color Settings.
- Monochrome (Photo) is not available for all types of paper.

A Sample

The image at left is updated to reflect any changes you make to setting items on the sheet, enabling you to check the results of adjustment.

• B Sample List

Select a sample image, as desired.

Color Balance

Click the list to select a color balance that suits the printing application.

• DX / EY

Adjust the color balance as you check the color tone in the adjustment area.

You can adjust the square area in the center by clicking or dragging it.

Drag the vertical or horizontal scroll bars for adjustment, as desired.

You can click the arrows by the DX (horizontal) and EY (vertical) boxes or enter the values directly.

F Brightness

Adjust the overall image brightness as desired. You can adjust the brightness if the printed document is lighter or darker than the original image (that is, the original photo that was scanned or the original graphic as it appears on the computer screen).

iPF8300S Gray Adjustment Pane

• G Contrast

Adjust the contrast of the darkest and lightest portions relative to each other, as desired. Increasing the **G** Contrast makes images sharper, and reducing the **G** Contrast softens images.

• H Highlight


Adjust the brightness of the lightest portion.

Shadow

Adjust the brightness of the darkest portion.

Page Setup Pane

The following settings are available on the Page Setup pane. For details on settings items, refer to the printer driver help.



A Paper Source

Choose how paper is supplied.

Options displayed in the list vary depending on the selection in A Media Type in the Main pane.

• B Roll Width

Displays the paper width of the roll loaded in the printer. **Unknown** is displayed if the printer cannot detect the roll paper width.

C Page Size

Displays the size of the original, as specified in the page settings of the application. For details on page sizes available in the application. see "Paper Sizes P.775"

D Enlarged/Reduced Printing

Select this checkbox to choose the following options.

- Resizing Originals to Match the Paper Size →P.73
- Resizing Originals to Fit the Roll Width →P.79
- Resizing Originals by Entering a Scaling Value →P.85

Page Setup Pane iPF8300S

• E Fit Paper Size

Resizes the document image to match the paper size.

• F Fit Roll Paper Width

Resizes the document image to match the roll width.

G Scaling

Resizes the document image based on a specified scaling value. Enter a value in a range of 5-600.

H Borderless Printing

Borderless printing is available if roll paper is selected in the A Paper Source list.

Activate this setting for borderless printing to match the size and width of the paper.

- Borderless Printing on Paper of Equivalent Size →P.107
- Borderless Printing by Resizing Originals to Fit the Roll Width →P.114
- Borderless Printing at Actual Size →P.100

Paper Size

Choose the size of the paper you will print on.

Click **Display all selections for Paper Size** to list available sizes.

For details on available paper sizes, see "Paper Sizes -P.775"

• J Print Centered

Select this checkbox to print document images in the center of the paper.

- Printing Originals Centered on Rolls →P.160
- Printing Originals Centered on Sheets →P.166

K No Spaces at Top or Bottom

Select this checkbox to print the next image skipping blank areas above and below printable data in documents, which enables you to conserve the paper.

L Rotate Page 90 degrees

Select this checkbox to rotate the document image by 90 degrees before printing.

Conserving Roll Paper by Rotating Originals 90 Degrees —P.172

N Free Layout

Select this checkbox to start imagePROGRAF Free Layout before printing.

This allows you to print multiple documents next to each other.



Important


• When Print Preview is selected on the Main panel, Print Preview is disabled.

Printing Multiple Originals Next to Each Other →P.139

iPF8300S Page Setup Pane

Utility Pane

The following settings are available on the Utility pane.



• A Set

Click to display the **Printer Information** dialog box, which offers the following maintenance for the printer.

- Nozzle (ink ejecting outlet) cleaning
- Head alignment adjustment
- Feed amount adjustment

• B View

Click to start imagePROGRAF Printmonitor, which enables you to view the status of print jobs.


• C Set

Click to complete the settings for Color imageRUNNER Enlargement Copy (iR enlargement copy). For details, see Color imageRUNNER Enlargement Copy (>P.584).

Utility Pane iPF8300S

Additional Settings Pane

The following settings are available on the **Additional Settings** pane.



• D Send job to

You can configure the method for saving print jobs to the printer hard disk.

- E Print
- F Save in mail box

• G Print after reception is complete

Jobs are printed after they are saved on the hard disk.

Support Pane

On the **Support** pane, you can view support information and the user's manual.



A Support Information

Click to access the Canon support webpage, where you can find the latest information on the printer and consumables, check for printer driver updates, and browse other information.

• BUser Manual

Click to view the printer user's manual. This function requires the user's manual to be installed on your computer.

C Settings

The settings can be saved as a file. Click to display the **Export** dialog box, which enables you to specify where to save the file.

• D About

You can display version information for the printer driver.

518

Support Pane iPF8300S

Preview

| The Features of Preview | 519 |
|--|-----|
| Operating Environment | 519 |
| Starting Preview | 520 |
| Preview Main Window | 521 |
| Paper Settings Panel | 524 |
| Easy Settings | 526 |
| Advanced Settings | 528 |
| Output Settings Panel | 529 |
| Color Settings Panel | 531 |
| Color Adjustment | 532 |
| Gray Adjustment | 535 |
| Matching | 536 |
| Driver Matching Mode | 539 |
| ICC Matching Mode | 540 |
| ColorSync | 541 |
| Preferences Dialog Box | 541 |
| Zoom Dialog Box | |
| Go to Page Dialog Box | 542 |
| Print with No Borders | 543 |
| Print on the Center | 543 |
| Not Print Spaces at the Top/Bottom | 544 |
| Print Page Rotated 90 Degrees | |
| Display with Fitting to the Width of the Paper | |
| Display with All | |
| Display with Actual Size | |
| Moving a Page | |

The Features of Preview

The main features of Preview are as follows.

- While viewing this screen, you can adjust layout settings of a document created with application software.
- You can not only adjust layout settings but also your changes will be instantly applied on the preview screen, and you can print the preview screen as it is seen.



Note

• The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Preview settings.

Operating Environment

You can use the Preview in the following environments.

- Compatible Operating System Mac OS X (10.4.11 to 10.6)
- Software that requires installation imagePROGRAF Printer Driver

iPF8300S The Features of Preview


Starting Preview

Follow the procedure below to start the Preview.

- 1. Start the apllication software which you use.
- 2. From the application software's File menu, select the printer setup menu to open the Print dialog box.



- Note
- Normally, select **Print** from the **File** menu.
- 3. Click **Print Preview** in the **Main** panel to attach a checkmark.
- **4.** Click the **Print** button in the **Print** dialog box.






Note

• Your printer is depicted in the lower-left area of this screen.


Starting Preview iPF8300S

5. Preview main window is displayed.



Preview Main Window

The Preview main window consists of the menu and tool bars, and preview, dialog, drawer and status area.



Note

• You can use the **View** menu to show or hide the tool bar.

iPF8300S Preview Main Window

Menu Bar

This allows you to select menus required for operations.

imagePROGRAF Advanced Preview File Edit View Object Window Help


• Tool Bar

This allows you to select tool buttons required for major operations.



Preview Area


You can check the settings you made in this area.



Preview Main Window iPF8300S

Dialog Area

This allows you to set the print conditions and perform a print job.



• Drawer Area

This allows you to display the thumbnails of a document.

This area appears when you click **Drawer** from the tool bar.

Alternatively, you may select **Drawer** from the **View** menu.



iPF8300S Preview Main Window


Status Area

This shows Input Size and Output Size.

Input Size 16.54 x 23.39 in. Output Size 24.00 x 23.39 in.

Paper Settings Panel

This panel appears when you select **Paper Settings** in the dialog area.



Media Type

This allows you to select the media type.



Note

• Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.

• Easy Settings / Advanced Settings

Two modes are available to provide the optimum print settings for jobs.

The settings available on each mode are as follows.

- Easy Settings →P.526
- Advanced Settings →P.528

524

Paper Settings Panel iPF8300S

Paper Source

You can select the paper source.

The following settings are available for paper source.

| Setting | Details |
|------------|-----------------------------------|
| Cut Sheet | Select to print on the cut sheet. |
| Roll Paper | Select to print on roll paper. |

Roll Paper Width

This selects the width of the roll media set to the printer.



Note

• Available only if rolls are selected in **Paper Source**.

Copies

You can input the number of print copies in numerical characters.



Note

- The maximum value is 999.
- You can change the numbers by clicking either ▲ button or ▼ button.

• Restore Defaults Button

Click the button to reset to the setting when starting Preview.

• Print Button

Click the button to begin printing.


• Update Printer Info. Button

Click the button to acquire printer information.

iPF8300S Paper Settings Panel

Easy Settings

You can easily select the best settings for the print job by just selecting an item from the print target list that matches the content of the document.



Print Target

You can easily select the best settings for the print job simply.

If you select each **Print Target** item the corresponding comment for that item is displayed below the list.

| Setting | Details |
|-----------------------------|---|
| Default Settings | Suitable for printing normal documents that contain a mixture of text, photographs, and graphics. |
| Photo (Color) | Suitable for printing photographic images captured with a digital camera. |
| Photo (Monochrome) | Suitable for optimized printing of monochrome photos. |
| Poster | The best setting for posters.Prints using vivid and high impact colors. |
| Faithful Color Reproduction | Prints by faithfully reproducing the colors of the original image. |
| Photo (Adobe RGB) | Achieves the best color when printing an image created with the Adobe RGB color space feature. |
| CAD (Color Line Drawing) | Prints the fine lines of CAD drawings and other such documents sharp and clear. |
| Perspective, GIS | Suitable for attractive printing of 3D-CAD drawings, perspective drawings, and GIS drawings including maps. |
| Office Document | Suitable for printing handouts as well as general office documents for which print clarity is key. |

Easy Settings iPF8300S

| Setting | Details |
|------------------------|--|
| Custom Settings | Suitable for printing documents for which Advanced Settings have been specified. |



Note

• The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.

| Setting | Details |
|---------------|--|
| Print Quality | Highest quality / High / Standard / Fast |
| Resolution | 600dpi / 300dpi |




Note

- The availability of settings is determined by the media type and print priority selections.
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
- Printing time is shorter and less ink is consumed with **Fast** than with **High**, however, print quality is lower
- For **Highest quality**, the resolution is not displayed.

iPF8300S Easy Settings

Advanced Settings

Presents detailed settings for the print quality, the color mode, and other items so you can select the values for these settings yourself.



• Print Priority

Select a print quality mode that is appropriate for the print job.

| Setting | Details |
|-----------------|---|
| Image | This mode achieves the best results for printing photographic images and illustrations. |
| Line Drawing | This mode is best for printing CAD drawings with fine lines or wall newssheet or other documents that contain large amounts of text. However, you may not achieve the quality you expect with printing photographs or other images with many filled areas. For these types of jobs, select Image . |
| Proof | This is a setting for enhancing the reproducibility of characters, illustrations, and photos with print proofing. However, this takes more time than regular printing. |
| Office Document | Prints common office documents, such as proposals, memos for distribution, etc., so they are easy to read. |



Note

• The number of settings available for selection depends on the media type.

Advanced Settings iPF8300S

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.

| Setting | Details |
|---------------|--|
| Print Quality | Highest quality / High / Standard / Fast |
| Resolution | 600dpi / 300dpi |




Note

- The availability of settings is determined by the media type and print priority selections.
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
- Printing time is shorter and less ink is consumed with **Fast** than with **High**, however, print quality is lower.
- For **Highest quality**, the resolution is not displayed.

Output Settings Panel

This panel appears when you select **Output Settings** in the dialog area.



Enlarged/Reduced Printing

Select the method for enlarged/reduced printing.

The following settings are available for enlarged/reduced printing.

iPF8300S Output Settings Panel

| Setting | Details |
|----------------------|--|
| Fit Paper Size | Enlarges/reduces the whole page automatically to fit the media size selected for output. Select the media size to print from Paper Size . |
| Fit Roll Paper Width | Enlarges/reduces the whole page automatically to fit the width of the roll paper with the page width. |
| | *Make sure that the width of the roll paper in the printer is set correctly for Roll Paper Width in the Paper Settings panel. *Displayed only if rolls are selected in Paper Source. |
| Scaling | Enlarges/reduces the whole page by the scaling rate as specified. Input the scaling value in numerical characters. You can specify a range between 5 and 600%. |
| | *You can change the numbers by clicking either ▲ button or ▼ button. *Although Scaling can be set to make the image larger than the media size, the part that does not fit in the media cannot be printed. *This is not displayed when a checkmark is placed in Borderless Printing . |

Borderless Printing

You can print the media without margins on all sides when the roll paper with the specific width and the specific media type is used.

For more information about **Borderless Printing**, see "Print with No Borders." →P.543



Note

- Available only if rolls are selected in **Paper Source**.
- This is not displayed when a checkmark is placed in **Print Centered**.

Paper Size

You can select the size of the print media.



Note

• This is not displayed when Fit Roll Paper Width is set in Enlarged/Reduced Printing.

Print Centered

You can print on the center of the media loaded in the printer.

For more information about **Print Centered**, see "Print on the Center." →P.543



Note

• This is not displayed when a checkmark is placed in **Borderless Printing**.

No Spaces at Top or Bottom

You can save paper on not to feed roll paper for the empty spaces when the print data contains spaces at the top or bottom.

For more information about No Spaces at Top or Bottom, see "Not Print Spaces at the Top/Bottom." -P.544



Note

• Available only if rolls are selected in **Paper Source**.

Rotate Page

Select the method for rotating page.

The following settings are available for rotating page.

Output Settings Panel iPF8300S

| Setting | Details |
|-------------------------|--|
| Rotate Right 90 Degrees | Rotates the portrait page right 90 degrees and print in landscape orientation. When the rotated page can fit in the width of roll paper, the page is rotated automatically, and when it can not fit in the width of roll paper, the page is not rotated. |
| Rotate Left 90 Degrees | Rotates the portrait page left 90 degrees and print in landscape orientation. When the rotated page can fit in the width of roll paper, the page is rotated automatically, and when it can not fit in the width of roll paper, the page is not rotated. |
| Rotate 180 degrees | Allows you to rotate the image 180 degrees from the vertical to the right. |

• Restore Defaults Button

Click the button to reset to the setting when starting Preview.

• Print Button


Click the button to begin printing.

• Update Printer Info. Button

Click the button to acquire printer information.

Color Settings Panel

This panel appears when you select Color Settings in the dialog area.



Color Mode

You can select a color mode to suit the print job.

iPF8300S Color Settings Panel

| Setting | Details |
|---------------------|---|
| Color | Enables color printing. |
| Monochrome (Photo) | Prints monochrome photo image data in a gray scale that is free of color casting (phenomenon of grays that appear tinted). |
| Monochrome | Disables color printing and converts image from continuous color to grayscaled monochrome. |
| No color correction | Prints without performing color matching in the printer driver. Select this when color matching is performed by the application such as Adobe Photoshop or when you want to print color charts using the profile creation tool. |



Note

• The availability of settings depends on the print priority and media type selections.

• Color Adjustment / Gray Adjustment / Matching

You can set the color adjustment and matching.

- Color Adjustment →P.532
- Gray Adjustment →P.535
- Matching →P.536



Note

- You can select Gray Adjustment only after Monochrome (Photo) has been selected in Color Mode.
- Matching is not displayed if No color correction has been selected in Color Mode.

· Restore Defaults Button

Click the button to reset to the setting when starting Preview.

• Print Button

Click the button to begin printing.

• Update Printer Info. Button

Click the button to acquire printer information.

Color Adjustment

You can set the color adjustment.


Adjusting Color

Normally colors should be adjusted in the software application, but if you see colors in the printout that do not match colors on the screen, you can perform color adjustments.

1. Select Color or Color (Economy) on Color Mode in the Color Settings panel.

Color Adjustment iPF8300S

2. Select Color Adjustment.



3. Drag each slider to the left or right to adjust.

| Setting | Details |
|-----------------|--|
| Cyan | Adjusts the strength of colors to compensate the hues. |
| Magenta | Adjusts the strength of colors to compensate the hues. |
| Yellow | Adjusts the strength of colors to compensate the hues. |
| Brightness | Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature. |
| Contrast | Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast. |
| Saturation | Adjusts the hues for vivid color or dark color. |
| Gray Adjustment | Adjusts gray from cool black (bluish tones) to warm black (reddish tones). |

Note

• You can also click the up or down arrow, or enter the number directly to increase or decrease the value


iPF8300S Color Adjustment

534

Adjusting Monochrome

Use the monochrome setting to print monochrome images of color photographs captured with a scanner or digital camera or other color images.

- 1. Select Monochrome on Color Mode in the Color Settings panel.
- 2. Select Color Adjustment.



3. Drag each slider to the left or right to adjust.

| Setting | Details |
|------------|--|
| Brightness | Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature. |
| Contrast | Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast. |



Note

• You can also click the up or down arrow, or enter the number directly to increase or decrease the value.

Color Adjustment iPF8300S


Gray Adjustment

You can set the gray adjustment.

Adjusting Monochrome (Photo)

Sets monochrome printing for black-and-white photo image data captured with a scanner or digital camera.

- 1. Select Monochrome (Photo) on Color Mode in the Color Settings panel.
- 2. Select Gray Adjustment.



3. Click the **Color Balance** list and select the color settings.

| Setting | Details |
|--------------------|--|
| Cool Black | Adjusts cool black (blue tones) to gray. |
| Pure Neutral Black | Adjusts to neutral gray. |
| Warm Black | Adjusts warm black (red tones) to gray. |



Note

- To perform the adjustments, drag the **X** or **Y** slide bar left and right.
- ullet You can also click the up or down arrow, or enter the number directly to increase or decrease the value by X and Y.

iPF8300S Gray Adjustment

4. Drag each slider to the left or right to adjust.

| Setting | Details |
|------------|--|
| Brightness | Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature. |
| Contrast | Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast. |
| Highlight | Adjusts the brightness of the brightest areas. |
| Shadow | Adjusts the brightness of the darkest areas. |



Note

- You can also click the up or down arrow, or enter the number directly to increase or decrease the value.
- The availability of settings depends on the selected the media type.

Matching


You can set the matching.



Important

• If No color correction is selected under Color Mode, the Matching is not displayed.

Matching iPF8300S



Matching Mode

You can select a matching mode to suit the print job.

| Setting | Details |
|------------------------------|---|
| Driver Matching Mode →P.539 | Enables printing of optimal color tones using a driver specific color profile. You should normally select this mode. |
| ICC Matching Mode →P.540 | Enables color matching using ICC profiles. Select this if you want to print by specifying the input profile, printer profile, and matching method in detail. This allows you to use ICC profiles for digital cameras and scanners, ICC profiles created using the profile creation tool, etc. |
| ColorSync →P.541 | Enables color matching by using the ColorSync function of Mac OS. Select this if you want to perform soft proofing using ColorSync before printing. |

Note

- You need to set each correction on the printer driver.
- Using Mac OS X 10.5 or later, **ColorSync** needs to be selected in the **Color Matching** panel of the driver in order to select **ColorSync**.

Matching Method

You can select a matching method to suit the print job.

Color Space

Select the color space.

iPF8300S Matching



Note

• You can select only after **Driver Matching Mode** has been selected in **Matching Mode**.

Input Profile

Select the input profile.



Note

• You can select only after ICC Matching Mode has been selected in Matching Mode.

Printer Profile

Select the printer profile.



Note

- (Using Mac OS X 10.4)You can select only after ICC Matching Mode or ColorSync has been selected in Matching Mode.
- (Using Mac OS X 10.5 or later)You can select only after ICC Matching Mode has been selected in Matching Mode.

Soft Proof

When you place a checkmark here, ColorSync applies to the preview area.



Note

• You can select only after ColorSync has been selected in Matching Mode.

Matching iPF8300S

Driver Matching Mode

 $\textbf{1.} \ \ \textbf{Under Matching Mode}, \textbf{select Driver Matching Mode}.$



2. Click the Matching Method list, and then select a setting.

| Setting | Details |
|--------------|---|
| Auto | Automatically selects the best color matching method for each Image, Graphics, Text. |
| Perceptual | Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software. |
| Saturation | Color-matching optimized for printing posters, etc., vividly. |
| Colorimetric | Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric. |

3. Select Color Space for the print output.

| Setting | Details |
|---------|--|
| sRGB | Uses color space for a standard monitor. This selection is ideal for most software applications. |

iPF8300S Driver Matching Mode

| Setting | Details |
|-----------|---|
| Adobe RGB | Uses wide color space. Use this setting to print images created with Adobe RGB color space. |

ICC Matching Mode

1. Under Matching Mode, select ICC Matching Mode.



2. Click the Matching Method list, and then select a setting.


| Setting | Details |
|---|---|
| Perceptual | Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software. |
| Saturation | Color-matching optimized for printing posters, etc., vividly. |
| Colorimetric | Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric. |
| Colorimetric (No White-Point Correction) | The processing method of color-matching is identical to Colorimetric . Use this when you want to further reproduce the target paper material color of the image data. Generally, this also is called absolute colorimetric. |

ICC Matching Mode iPF8300S

- **3.** Click the **Input Profile** list and select an input profile.
- **4.** Click the **Printer Profile** list and select a printer profile.

ColorSync

1. Check that ColorSync is selected in Matching Mode.



2. To apply ColorSync to previews, check the Soft Proof check box.

Preferences Dialog Box

This dialog box appears when you select **Preferences** from the **imagePROGRAF Advanced Preview** menu. You can set the preferences for Preview.




iPF8300S ColorSync

Set the unit for paper length, margins, and so on.

Zoom Dialog Box

This dialog box appears when you select **Zoom** from the **View** menu. You can enlarge or reduce the screen display.



Scaling

Set the magnification for enlargement or reduction of the screen display.




Note

- You can input between 10 and 400.
- You can change the numbers by clicking ▼ button.

Go to Page Dialog Box

This dialog box appears when you select Go to Page from the View menu.



Note

• You can not select **Go to Page** if the document is only one page.

• Page

Input the page number in numerical characters to display in the preview area.



Note

• You can change the numbers in the range of the page of the documents.

542

Zoom Dialog Box iPF8300S


Print with No Borders

You can use the borderless printing function to print without margins surrounding the image.



Note

- With some media borderless printing can be performed only between two edges.
- To use the borderless printing function, the specified media must be set to the printer.
- 1. On the Paper Settings Panel \rightarrow P.524, select Roll Paper in Paper Source.
- 2. On the Output Settings panel, click the Enlarged/Reduced Printing check box on.
- 3. Select Fit Roll Paper Width.
- **4.** Click the **Borderless Printing** check box on.



5. Click the **Print** button.

Borderless printing begins.

Print on the Center

You can print on the center of the media loaded in the printer.




Note

• This is not displayed when a checkmark is placed in **Borderless Printing**.

iPF8300S Print with No Borders

1. On the Output Settings panel, click the Print Centered check box on.



2. Click the **Print** button.

Printing on the center begins.

Not Print Spaces at the Top/Bottom

You can save paper on not to feed roll paper for the empty spaces when the print data contains spaces at the top or bottom.




Note

• This is not displayed when a checkmark is placed in **Borderless Printing**.

1. On the Paper Settings Panel \longrightarrow P.524, select Roll Paper in Paper Source.

544



Output Size 24.00 x 23.39 in.

2. On the Output Settings panel, click the No Spaces at Top or Bottom check box on.

3. Click the Print button.


Printing on the settings with no spaces at top or bottom begins.

Print Page Rotated 90 Degrees

You can save paper by printing in landscape orientation on roll paper.

- 1. On the Paper Settings Panel \longrightarrow P.524, select Roll Paper in Paper Source.
- 2. On the Output Settings panel, click the Rotate Page check box on.

3. Select Rotate Right 90 Degrees or Rotate Left 90 Degrees.



4. Click the **Print** button.


Printing on rotating 90 degrees begins.

Display with Fitting to the Width of the Paper

In the preview area, you can display to the width of the paper.

1. Select Fit Roll Paper Width from the tool bar.


2. Fitting to the width of the paper, it is displayed.



Display with All

In the preview area, you can display all.

- 1. Select Fit Screen from the tool bar.
- 2. All is displayed.




iPF8300S Display with All

547

Display with Actual Size

In the preview area, you can display the actual size.

- 1. Select Actual Size from the tool bar.
- 2. Actual size is displayed.



Moving a Page


You can move a page to display in the preview area.

1. Select each button in Go to Page on the tool bar.

| Setting | Details |
|---------------|--------------------------|
| | Go to the first page. |
| 4 | Go to the previous page. |
| ▶ | Go to the next page. |
| > 1 | Go to the last page. |

548

2. The target page appears.





Note

• You can also move a page by clicking the page on the thumbnails.

iPF8300S Moving a Page

Free Layout

| The Features of Free Layout | 550 |
|--|-----|
| Operating Environment | 550 |
| Starting Free Layout | 551 |
| Free Layout Main Window | 552 |
| Paper Settings Panel | |
| Easy Settings | |
| Advanced Settings | |
| Color Settings Panel | |
| Color Adjustment | |
| Gray Adjustment | |
| Matching | |
| Driver Matching Mode | |
| ICC Matching Mode | |
| ColorSync | |
| Preferences Dialog Box | 571 |
| Page Setup Dialog Box | |
| Zoom Dialog Box | |
| Format Dialog Box | |
| Laying out a Multiple-File Document on One Page | 575 |
| Laying out a Document Created with Multiple Application Programs on One Page | |
| Selecting an Object | |
| Changing the Object Size | |
| Moving an Object | |
| Rotating an Object | |
| Laying out Objects Automatically | |
| Aligning Objects | |
| Changing the Object Overlapping Order | |
| Pasting a Copied or Cut Object | |

The Features of Free Layout

The main features of Free Layout are as follows.

- Allows you to lay out at will and print a document created with application software.
- You can not only lay out multiple pages on one page but also lay out and print a multiple-file document on one page, or lay out and print a document created with multiple application programs on one page.



Note

• The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Free Layout settings.

Operating Environment

You can use the Free Layout in the following environments.

- Compatible Operating System Mac OS X (10.4.11 to 10.6)
- Software that requires installation

imagePROGRAF Printer Driver

Starting Free Layout


Follow the procedure below to start the Free Layout.

- 1. Start the application software which you use.
- 2. From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



Note

- Normally, select **Print** from the **File** menu.
- 3. Click on Free Layout in the Page Setup panel to attach a checkmark.
- **4.** Click the **Print** button in the **Print** dialog box.






Note

• Your printer is depicted in the lower-left area of this screen.

iPF8300S Starting Free Layout


551

5. Free Layout main window is displayed.



Free Layout Main Window

The Free Layout main window consists of the menu and tool bars, layout area and dialog areas.



• You can use the **View** menu to show or hide the tool.

552

Note

Menu Bar

This allows you to select menus required for operations.

imagePROGRAF Advanced Preview File Edit View Object Window Help


• Tool Bar

This allows you to select tool buttons required for major operations.



Layout Area


This allows you to lay out objects and edit the object size and orientation.



iPF8300S

• Dialog Area


This allows you to set the print conditions and perform a print job.



554

Paper Settings Panel

This panel appears when you select **Paper Settings** in the dialog area.



Media Type

This allows you to select the media type.



Note

• Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.

Easy Settings / Advanced Settings

Two modes are available to provide the optimum print settings for jobs.

The settings available on each mode are as follows.

- Easy Settings →P.557
- Advanced Settings →P.559

Paper Source

You can select the paper source.

The following settings are available for paper source.

| Setting | Details |
|------------|-----------------------------------|
| Cut Sheet | Select to print on the cut sheet. |
| Roll Paper | Select to print on roll paper. |

iPF8300S Paper Settings Panel

This selects the width of the roll media set to the printer.



Note

• Available only if rolls are selected in **Paper Source**.

Copies

You can input the number of print copies in numerical characters.



Note

- The maximum value is 999.
- You can change the numbers by clicking either ▲ button or ▼ button.

• Restore Defaults Button

Click the button to reset to the setting when starting Free Layout.

• Print Button

Click the button to begin printing.

• Update Printer Info. Button


Click the button to acquire printer information.

556

Paper Settings Panel iPF8300S

Easy Settings

You can easily select the best settings for the print job by just selecting an item from the print target list that matches the content of the document.




Print Target

You can easily select the best settings for the print job simply.

If you select each Print Target item the corresponding comment for that item is displayed below the list.

| Setting | Details |
|-----------------------------|---|
| Default Settings | Suitable for printing normal documents that contain a mixture of text, photographs, and graphics. |
| Photo (Color) | Suitable for printing photographic images captured with a digital camera. |
| Photo (Monochrome) | Suitable for optimized printing of monochrome photos. |
| Poster | The best setting for posters.Prints using vivid and high impact colors. |
| Faithful Color Reproduction | Prints by faithfully reproducing the colors of the original image. |
| Photo (Adobe RGB) | Achieves the best color when printing an image created with the Adobe RGB color space feature. |
| CAD (Color Line Drawing) | Prints the fine lines of CAD drawings and other such documents sharp and clear. |
| Perspective, GIS | Suitable for attractive printing of 3D-CAD drawings, perspective drawings, and GIS drawings including maps. |
| Office Document | Suitable for printing handouts as well as general office documents for which print clarity is key. |

iPF8300S Easy Settings





Note

• The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.

| Setting | Details |
|---------------|--|
| Print Quality | Highest quality / High / Standard / Fast |
| Resolution | 600dpi / 300dpi |




Note

- The availability of settings is determined by the media type and print priority selections.
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
- Printing time is shorter and less ink is consumed with **Fast** than with **High**, however, print quality is lower
- For **Highest quality**, the resolution is not displayed.

Easy Settings iPF8300S

Advanced Settings

Presents detailed settings for the print priority, the print quality, and other items so you can select the values for these settings yourself.



• Print Priority

Select a print quality mode that is appropriate for the print job.

| Setting | Details |
|-----------------|---|
| Image | This mode achieves the best results for printing photographic images and illustrations. |
| Line Drawing | This mode is best for printing CAD drawings with fine lines or wall newssheet or other documents that contain large amounts of text. However, you may not achieve the quality you expect with printing photographs or other images with many filled areas. For these types of jobs, select Image . |
| Proof | This is a setting for enhancing the reproducibility of characters, illustrations, and photos with print proofing. However, this takes more time than regular printing. |
| Office Document | Prints common office documents, such as proposals, memos for distribution, etc., so they are easy to read. |



Note

• The number of settings available for selection depends on the media type.

iPF8300S Advanced Settings

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.

| Setting | Details |
|---------------|--|
| Print Quality | Highest quality / High / Standard / Fast |
| Resolution | 600dpi / 300dpi |




Note

- The availability of settings is determined by the media type and print priority selections.
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
- Printing time is shorter and less ink is consumed with **Fast** than with **High**, however, print quality is lower.
- For **Highest quality**, the resolution is not displayed.

Color Settings Panel

This panel appears when you select Color Settings in the dialog area.



560

Color Mode

You can select a color mode to suit the print job.

Color Settings Panel iPF8300S

| Setting | Details |
|---------------------|---|
| Color | Enables color printing. |
| Monochrome (Photo) | Prints monochrome photo image data in a gray scale that is free of color casting (phenomenon of grays that appear tinted). |
| Monochrome | Disables color printing and converts image from continuous color to grayscaled monochrome. |
| No color correction | Prints without performing color matching in the printer driver. Select this when color matching is performed by the application such as Adobe Photoshop or when you want to print color charts using the profile creation tool. |



Note

• The availability of settings depends on the print priority and media type selections.

• Color Adjustment / Gray Adjustment / Matching

You can set the color adjustment and matching.

- Color Adjustment →P.561
- Gray Adjustment →P.564
- Matching →P.565



Note

- You can select Gray Adjustment only after Monochrome (Photo) has been selected in Color Mode.
- Matching is not displayed if No color correction has been selected in Color Mode.

• Restore Defaults Button

Click the button to reset to the setting when starting Free Layout.

• Print Button

Click the button to begin printing.

• Update Printer Info. Button

Click the button to acquire printer information.

Color Adjustment

You can set the color adjustment.


Adjusting Color

Normally colors should be adjusted in the software application, but if you see colors in the printout that do not match colors on the screen, you can perform color adjustments.

1. Select Color or Color (Economy) on Color Mode in the Color Settings panel.

iPF8300S Color Adjustment

2. Select Color Adjustment.



3. Drag each slider to the left or right to adjust.

| Setting | Details |
|------------|--|
| Cyan | Adjusts the strength of colors to compensate the hues. |
| Magenta | Adjusts the strength of colors to compensate the hues. |
| Yellow | Adjusts the strength of colors to compensate the hues. |
| Brightness | Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature. |
| Contrast | Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast. |
| Saturation | Adjusts the hues for vivid color or dark color. |
| Gray Tone | Adjusts gray from cool black (bluish tones) to warm black (reddish tones). |



Note


• You can also click the up or down arrow, or enter the number directly to increase or decrease the value.

Color Adjustment iPF8300S

Adjusting Monochrome

Use the monochrome setting to print monochrome images of color photographs captured with a scanner or digital camera or other color images.

- 1. Select Monochrome on Color Mode in the Color Settings panel.
- 2. Select Color Adjustment.



3. Drag each slider to the left or right to adjust.

| Setting | Details |
|------------|--|
| Brightness | Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature. |
| Contrast | Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast. |



Note

You can also click the up or down arrow, or enter the number directly to increase or decrease the value.


iPF8300S Color Adjustment

You can set the gray adjustment.

Adjusting Monochrome (Photo)

Sets monochrome printing for black-and-white photo image data captured with a scanner or digital camera.

- 1. Select Monochrome (Photo) on Color Mode in the Color Settings panel.
- 2. Select Gray Adjustment.



3. Click the **Color Balance** list and select the color settings.

| Setting | Details |
|--------------------|--|
| Cool Black | Adjusts cool black (blue tones) to gray. |
| Pure Neutral Black | Adjusts to neutral gray. |
| Warm Black | Adjusts warm black (red tones) to gray. |



Note

- To perform the adjustments, drag the X or Y slide bar left and right.
- You can also click the up or down arrow, or enter the number directly to increase or decrease the value by X and Y.

1

564

Gray Adjustment iPF8300S

4. Drag each slider to the left or right to adjust.

| Setting | Details |
|------------|--|
| Brightness | Adjusts the brightness of the entire image. When the results of the printout are brighter than the original images such as the original photo before scanning and graphics created on the display, or when you want to print in different degrees of brightness, use this feature. |
| Contrast | Adjusts the relative brightness between the brightest and darkest portions of the image. *For soft gradation, decrease the contrast. For hard gradation, increase the contrast. |
| Highlight | Adjusts the brightness of the brightest areas. |
| Shadow | Adjusts the brightness of the darkest areas. |



Note

- You can also click the up or down arrow, or enter the number directly to increase or decrease the value.
- The availability of settings depends on the selected the media type.

Matching


You can set the matching.



Important

• If **No color correction** is selected under **Color Mode**, the **Matching** is not displayed.

iPF8300S Matching



Matching Mode

You can select a matching mode to suit the print job.

| Setting | Details |
|------------------------------|---|
| Driver Matching Mode →P.568 | Enables printing of optimal color tones using a driver specific color profile. You should normally select this mode. |
| ICC Matching Mode →P.569 | Enables color matching using ICC profiles. Select this if you want to print by specifying the input profile, printer profile, and matching method in detail. This allows you to use ICC profiles for digital cameras and scanners, ICC profiles created using the profile creation tool, etc. |
| ColorSync →P.570 | Enables color matching by using the ColorSync function of Mac OS. Select this if you want to perform soft proofing using ColorSync before printing. |



Note

- You need to set each correction on the printer driver.
- Using Mac OS X 10.5 or later, **ColorSync** needs to be selected in the **Color Matching** panel of the driver in order to select **ColorSync**.

Matching Method

You can select a matching method to suit the print job.

Color Space

Select the color space.

Matching iPF8300S



Note

• You can select only after **Driver Matching Mode** has been selected in **Matching Mode**.

Input Profile

Select the input profile.



Note

• You can select only after ICC Matching Mode has been selected in Matching Mode.

Printer Profile

Select the printer profile.



Note

- (Using Mac OS X 10.4)You can select only after ICC Matching Mode or ColorSync has been selected in Matching Mode.
- (Using Mac OS X 10.5 or later)You can select only after ICC Matching Mode has been selected in Matching Mode.

Soft Proof

When you place a checkmark here, ColorSync applies to the layout area.



Note

• You can select only after ColorSync has been selected in Matching Mode.

iPF8300S Matching

Driver Matching Mode

 $\textbf{1.} \ \ \textbf{Under Matching Mode}, \textbf{select Driver Matching Mode}.$



2. Click the Matching Method list, and then select a setting.

| Setting | Details |
|--------------|---|
| Auto | Automatically selects the best color matching method for each Image, Graphics, Text. |
| Perceptual | Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software. |
| Saturation | Color-matching optimized for printing posters, etc., vividly. |
| Colorimetric | Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric. |

3. Select Color Space for the print output.


| Setting | Details |
|---------|--|
| sRGB | Uses color space for a standard monitor. This selection is ideal for most software applications. |

Driver Matching Mode iPF8300S

| Setting | Details |
|-----------|---|
| Adobe RGB | Uses wide color space. Use this setting to print images created with Adobe RGB color space. |

ICC Matching Mode

1. Under Matching Mode, select ICC Matching Mode.



2. Click the Matching Method list, and then select a setting.


| Setting | Details |
|---|---|
| Perceptual | Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software. |
| Saturation | Color-matching optimized for printing posters, etc., vividly. |
| Colorimetric | Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric. |
| Colorimetric (No White-Point Correction) | The processing method of color-matching is identical to Colorimetric . Use this when you want to further reproduce the target paper material color of the image data. Generally, this also is called absolute colorimetric. |

iPF8300S ICC Matching Mode

- **3.** Click the **Input Profile** list and select an input profile.
- **4.** Click the **Printer Profile** list and select a printer profile.

ColorSync

1. Check that ColorSync is selected in Matching Mode.



2. Place a checkmark on **Soft Proof** to simulate the output product in Layout Area.

ColorSync iPF8300S

571

Preferences Dialog Box

This dialog box appears when you select **Preferences** from the imagePROGRAF Advanced Preview menu. You can set the preferences for Free Layout.

| | Preferences |
|------------------------|----------------------------|
| Units : | ○ mm ○ in. |
| Gridlines : | 1.97 (in. (0.39 - 7.87) |
| Divisions : | 4 (sections (1–10) |
| Grid Color : | Gray |
| Print Object Frames | |
| Object Frame Style : | Solid 💠 |
| Auto Arrange Spacing : | 0.00 (1) in. (0.00 - 3.94) |
| | Cancel OK |

Units

Set the unit for paper length, margins, and so on.

Gridlines

You can input a grid line width value in numerical characters so that they serve as a guide to laying out objects.



Note

- You can input between 10.0 and 200.0(mm) (between 0.39 and 7.87(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Divisions

You can change the number of divisions of grid lines so that they serve as a guide to laying out objects.



Note

- You can input between 1 and 10.
- You can change the numbers by clicking either ▲ button or ▼ button.

Grid Color

Select the grid line color.

Print Object Frames

You can print the object border.



Note

• If you do not want to print the object border, deselect the **Print Object Frames** check box.

iPF8300S Preferences Dialog Box

You can select the object frame style for printing.

The following settings are available for the object frame style.

| Setting | Details |
|--------------------|---|
| Solid Line | You can print the solid line as the frame style. |
| Dotted Line | You can print the dotted line as the frame style. |
| Dashed Line | You can print the dashed line as the frame style. |

Auto Arrange Spacing


Change the object-to-object spacing to be applied in the operation of laying out objects automatically.



- You can input between 0.0 and 100.0(mm) (between 0.00 and 3.94(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Page Setup Dialog Box

This dialog box appears when you select Page Setup from the File menu. This dialog box provides selections for setting the media size, orientation and other important features.



Paper Orientation

This selects the paper orientation.

The following settings are available for orientation.

| Setting | Details |
|------------|---|
| Vertical | Prints the image and text created with the application software in the orientation as it is. |
| Horizontal | Prints the image and text by rotating sideways 90 degrees from the orientation as specified in the application. |

572

Page Setup Dialog Box

· Roll Paper Length

Set the length of one page to print on roll paper.

When you place a checkmark on **Auto Settings**, the one-page length to be printed on roll paper is automatically set so that the laid-out objects are printed on one page.



Note

- Available only if rolls are selected in **Paper Source**.
- You can input between 203.2 and 18000.0(mm) (between 8.00 and 708.66(inch)).
- You can change the numbers by clicking either ▲ button or ▼ button.

Order

Set the object layout order.

The following settings are available for order.

| Setting | Details |
|----------------------|---|
| Upper Left to Right | The objects are laid out from upper left to right. |
| Upper Left to Bottom | The objects are laid out from upper left to bottom. |



Note

- When you have selected Roll Paper Length > Auto Settings and Paper Orientation > Vertical, you can choose only Upper Left to Right.
- When you have selected Roll Paper Length > Auto Settings and Paper Orientation > Horizontal, you can choose only Upper Left to Bottom.

Paper Size

You can select the size of the print media.




Note

• You cannot display this if Roll Paper is selected in Paper Source.

Zoom Dialog Box

This dialog box appears when you select **Zoom** from the **View** menu. You can enlarge or reduce the screen display.



Scaling

Set the magnification for enlargement or reduction of the screen display.




Note

- You can input between 10 and 400.
- You can change the numbers by clicking ▼ button.

iPF8300S Zoom Dialog Box

Format Dialog Box

This dialog box appears when you select **Format** from the **Object** menu after you select an object. You can rotate, enlarge, or reduce an object.





Note

• When the objects are not selected, you can not select **Format**.

Rotate

When you place a checkmark here, you can select Rotate Right or Rotate Left.

| Setting | Details |
|--------------|---|
| Rotate Right | Rotates the object 90 degrees clockwise. |
| Rotate Left | Rotates the object 90 degrees counterclockwise. |



Note

• When several objects are selected, you cannot select **Rotate**.

Scaling

You can input the value for enlargement or reduction of the obeject in numerical characters.



Note

- You can input between 25 and 400.
- You can change the numbers by clicking either ▲ button or ▼ button.

Object Size

You can confirm the object size.



Note

• When several objects are selected, you cannot display **Object Size**.

Format Dialog Box iPF8300S

Laying out a Multiple-File Document on One Page

You can lay out and print a multiple-file document on one page.

1. From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.



Note

- Normally, select **Print** from the **File** menu.
- 2. Click on Free Layout in the Page Setup panel to attach a checkmark.
- 3. In the **Print** dialog box, select the pages to print and the number of copies, and click the **Print** button. Free Layout starts, laying out the document created with application software in the layout area as an object.
- **4.** Leaving Free Layout running, open other files with the application software and repeat the above steps.

Laying out a Document Created with Multiple Application Programs on One Page

You can lay out and print a document created with multiple application programs on one page.

1. From the application software's **File** menu, select the printer setup menu to open the **Print** dialog box.




Note

- Normally, select **Print** from the **File** menu.
- 2. Click on Free Layout in the Page Setup panel to attach a checkmark.
- 3. In the **Print** dialog box, select the pages to print and the number of copies, and click the **Print** button. Free Layout starts, laying out the document created with application software in the layout area as an object.
- **4.** Leaving Free Layout running, open the files with other application software and repeat the above steps.

Selecting an Object

When an object is selected, a select box (blue border) appears around the object.





Note

- To select an object, click that object.
- To select multiple successive objects, click them while holding down the shift key.
- To select multiple arbitrary objects, click them while holding down the command key.
- To select all objects, select **Select All** from the **Edit** menu.

Changing the Object Size

You can change the object size by means of mouse operation or by specifying a scaling value.



Note


• The vertical-to-horizontal ratio remains unchanged when the object is enlarged or reduced.

Resizing by means of mouse operation

1. Select an object.

Selecting an Object iPF8300S

2. Place the pointer at a corner of the selection box around the object to show the arrow handle, and drag this handle to change the object size.



Resizing by specifying a scaling value

- 1. Select an object.
- 2. Open the Format Dialog Box →P.574.
- 3. Use Scaling to set the magnification for enlargement or reduction. You either enter numbers directly.



Note

- You can input between 25 and 400.
- You can change the numbers by clicking either ▲ button or ▼ button.
- 4. Click the **OK** button.


Moving an Object

You can move the object position.

1. Select an object.

iPF8300S Moving an Object

2. Place the pointer inside the selection box of the object to show the crosshair handle, and drag it to move the object.




Rotating an Object

You can rotate the object.

- 1. Select an object.
- 2. Select Rotate Left or Rotate Right from the toolbar.

 Alternatively, you may click on the Rotate check box in the Format Dialog Box →P.574 then select Rotate Right or Rotate Left, and click the OK button.



578


Note

• When several objects are selected, you cannot select Rotate.

Rotating an Object iPF8300S

Laying out Objects Automatically

Click **Auto Arrange** in the tool bar. This automatically lays out objects. Alternatively, you may select **Auto Arrange Object** from the **Object** menu.





Note

• The object layout order varies depending on the Order setting on the Page Setup Dialog Box P.572.


Aligning Objects

You can align objects systematically.

- 1. Select multiple objects.
- 2. Select the align menu from the **Object** menu.


Align Top

Lays out the objects, justifying them to the top.




Center Vertically

Lays out the objects, justifying them to the vertical center.




Align Bottom

Lays out the objects, justifying them to the bottom.



Align Left

Lays out the objects, justifying them to the left.




580

Aligning Objects iPF8300S


Center Horizontally

Lays out the objects, justifying them to the horizontal center.



Align Right

Lays out the objects, justifying them to the right.




Changing the Object Overlapping Order

You can change the object overlapping order.

- 1. Select an object.
- 2. Select the overlapping order menu from the **Object** menu.


Bring to Front

Moves the object to the frontmost position.




Send to Back

Moves the object to the backmost position.




Bring Forward

Moves the object one position to the front.



Send Backward

Moves the object one position to the back.



Pasting a Copied or Cut Object

- 1. Click Copy or Cut from the toolbar.

 Alternatively, you may select Copy or Cut from the Edit menu.
- 2. Click Paste from the toolbar.
 Alternatively, you may select Paste from the Edit menu.



Note

• The copied or cut object is laid out at the end of the page.

Color imageRUNNER Enlargement Copy

| The Features of Color imageRUNNER Enlargement Copy | 584 |
|---|-----|
| Operating Environment | 584 |
| Starting Color imageRUNNER Enlargement Copy | 585 |
| Color imageRUNNER Enlargement Copy Dialog Box | 586 |
| Hot Folder | 587 |
| Creating a New Hot Folder | |
| Editing a Hot Folder (Setting Print Conditions) | |
| Deleting a Hot Folder | |
| Setting the Print Parameters | 594 |
| Paper Settings Panel | 595 |
| Easy Settings | |
| Advanced Settings | |
| Output Settings Panel | |
| Color Settings Panel | 602 |
| Driver Matching Mode | |
| ICC Matching Mode | |
| ColorSync | |
| Printing Enlargements of Scanned Originals from a Color imageRUNNER | 606 |

The Features of Color imageRUNNER Enlargement Copy

The main features of Color imageRUNNER Enlargement Copy are as follows.

- Allows the document scanned with the Color imageRUNNER to be automatically enlarged and printed.
- You can perform basic printer settings such as printer selection, media type and output profile selection, and matching
 methods, in addition to borderless printing and enlargement/reduction process without growing through the printer
 driver.



Note

• The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Color imageRUNNER Enlargement Copy settings.

Operating Environment


You can use the Color imageRUNNER Enlargement Copy in the following environments.

- Compatible Operating System Mac OS X (10.4.11 to 10.6)
- Software that requires installation imagePROGRAF Printer Driver

Starting Color imageRUNNER Enlargement Copy

Follow the procedure below to start the Color imageRUNNER Enlargement Copy.

1. Open the **Utility** panel of the **Print** dialog box.





Note

• Your printer is depicted in the lower-left area of this screen.

2. Click the Set button in Configure Color imageRUNNER Enlargement Copy. to open the Color imageRUNNER Enlargement Copy dialog box.






Note

• You can also start the utility directly by clicking on the Color imageRUNNER Enlargement Copy.app icon in Applications > Canon Utilities > iR Enlargement Copy.

Color imageRUNNER Enlargement Copy Dialog Box

The explanation below is on the Color imageRUNNER Enlargement Copy dialog box.



586



Note

• For the step to open the Color imageRUNNER Enlargement Copy dialog box, see "Starting Color image-RUNNER Enlargement Copy." →P.585

· Delete files in the folder

From the Hot Folder list, select a hot folder and click the **Delete** button to delete only files in the hot folder.

• Delete the entire folder, as well as items in the list above

From the Hot Folder list, select a hot folder and click the **Delete** button to delete the hot folder.

• Delete Button

Select **Delete files in the folder** or **Delete the entire folder**, **as well as items in the list above** and click this button to delete the hot folder or only files in the hot folder.

• Add Button

Click the button to open the **Destination Selection** dialog box so that you can add a hot folder.

• Edit Button

From the Hot Folder list, select a hot folder and click this button to open the **Add/Edit Hot Folder** dialog box that allows you to edit the hot folder.

Monitor Hot Folder Constantly

If you click on the check box, the icon of Color imageRUNNER Enlargement Copy utility will appear on the Dock when starting OS X thereafter.

Hot Folder

Hot folder refers to a folder used for Color imageRUNNER Enlargement Copy.

- When transferred to the PC's hot folder, the document data scanned with the Color imageRUNNER is printed in enlarged size from the printer according to the print conditions set in the hot folder.
- You can create a new hot folder, edit or delete an existing one, and set print conditions at will.




Note

You can create up to 10 hot folders.

iPF8300S Hot Folder

Creating a New Hot Folder


 ${f 1.}$ Open the Color imageRUNNER Enlargement Copy dialog box.





Note

- For the step to open the Color imageRUNNER Enlargement Copy dialog box, see "Starting Color imageRUNNER Enlargement Copy." →P.585
- 2. Click the Add button in Enlarged Copy Settings to open the Destination Selection dialog box.



3. From the printer list in **Destination**, select the printer of destination.

4. Click the **OK** button to open the **Add/Edit Hot Folder** dialog box.



- 5. In Name, enter the name to display in the Hot Folder list.
- **6.** In **Hot Folder**, enter the Hot Folder name.
- 7. Click the OK button. The created Hot Folder is listed in the Color imageRUNNER Enlargement Copy dialog box.



- 8. Click the Close button to close the Color imageRUNNER Enlargement Copy dialog box.
- 9. From the Apple Menu, open the Sharing dialog box for System Preferences.
- 10. Select the check box labeled File Sharing, and click the Options button.
- 11. Select the check box labeled **Share files and folders using FTP** and **Share files and folders using SMB** to make shared settings.




Note

• You can create up to 10 hot folders.


Editing a Hot Folder (Setting Print Conditions)

 ${f 1.}$ Open the Color imageRUNNER Enlargement Copy dialog box.





- 2. Select the Hot Folder from the Hot Folder list.
- 3. From Enlarged Copy Settings, click Edit button to open the Add/Edit Hot Folder dialog box.


4. Make the necessary settings in the Paper Settings Panel P.595.



5. Make the necessary settings in the Output Settings Panel —P.600 .







- 7. Click the **OK** button to close the **Add/Edit Hot Folder** dialog box.
- **8.** From the **Apple** Menu, open the **Sharing** dialog box for **System Preferences**.
- 9. Select the check box labeled File Sharing, and click the Options button.
- 10. Select the check box labeled Share files and folders using FTP and Share files and folders using SMB to make shared settings.




Note

• If you've made shared settings when you created a new Hot Folder, you do not need to execute steps 8 to 10.


593

Deleting a Hot Folder

 ${f 1.}$ Open the Color imageRUNNER Enlargement Copy dialog box.



- 2. Select the Hot Folder you want to delete from the Hot Folder list.
- 3. Select Delete the entire folder, as well as items in the list above, and then click the Delete button.



4. Read the messag, e and then click the **OK** button.



Note

• Select **Delete files in the folder** to delete only files in the hot folder.


Setting the Print Parameters

You can set the print conditions in the setting panels within the **Add/Edit Hot Folder** dialog box. The settings available on each panel are as follows.

- Paper Settings Panel →P.595
- Output Settings Panel →P.600
- Color Settings Panel →P.602

Deleting a Hot Folder iPF8300S

Paper Settings Panel



Easy Settings / Advanced Settings

Two modes are available to provide the optimum print settings for jobs.

The settings available on each mode are as follows.

- Easy Settings →P.597
- Advanced Settings →P.598

Media Type

This allows you to select the media type.



Note

• Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.

Paper Source

You can select the paper source.

The following settings are available for paper source.

| Setting | Details |
|------------|-----------------------------------|
| Cut Sheet | Select to print on the cut sheet. |
| Roll Paper | Select to print on roll paper. |

Roll Paper Width

This selects the width of the roll media set to the printer.

iPF8300S Paper Settings Panel



Note

• Available only if rolls are selected in **Paper Source**.

Automatic Cutting

You can set the printer to cut roll paper automatically or print a guideline for cutting.

The following settings are available for automatic cutting.

| Setting | Details |
|---------------------|---|
| Printer Default | The value set on the printer operation panel takes priority. |
| None | Each page is not cut after it is printed and printing continues without interruption. |
| Print Cut Guideline | A print cut guideline is printed after each page and printing continues without interruption. |



Note

• Available only if rolls are selected in Paper Source.

Copies

You can input the number of print copies in numerical characters.




Note

- The maximum value is 999.
- You can change the numbers by clicking either ▲ button or ▼ button.

Paper Settings Panel iPF8300S

Easy Settings

You can easily select the best settings for the print job by just selecting an item from the print target list that matches the content of the document.



Print Target

You can easily select the best settings for the print job simply.

If you select each **Print Target** item the corresponding comment for that item is displayed below the list.

| Setting | Details |
|-----------------------------|---|
| Default Settings | Suitable for printing normal documents that contain a mixture of text, photographs, and graphics. |
| Photo (Color) | Suitable for printing photographic images captured with a digital camera. |
| Photo (Monochrome) | Suitable for optimized printing of monochrome photos. |
| Poster | The best setting for posters.Prints using vivid and high impact colors. |
| Faithful Color Reproduction | Prints by faithfully reproducing the colors of the original image. |
| Photo (Adobe RGB) | Achieves the best color when printing an image created with the Adobe RGB color space feature. |
| CAD (Color Line Drawing) | Prints the fine lines of CAD drawings and other such documents sharp and clear. |
| Perspective, GIS | Suitable for attractive printing of 3D-CAD drawings, perspective drawings, and GIS drawings including maps. |
| Office Document | Suitable for printing handouts as well as general office documents for which print clarity is key. |
| Custom Settings | Suitable for printing documents for which Advanced Settings have been specified. |

iPF8300S Easy Settings

Note

• The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.

| Setting | Details |
|---------------|------------------------|
| Print Quality | High / Standard / Fast |
| Resolution | 600dpi / 300dpi |




Note

- The availability of settings is determined by the media type and print priority selections.
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
- Printing time is shorter and less ink is consumed with **Fast** than with **High**, however, print quality is lower.

Advanced Settings

Presents detailed settings for the print priority, the print quality, and other items so you can select the values for these settings yourself.



598

Advanced Settings iPF8300S

Print Priority

Select a print quality mode that is appropriate for the print job.

| Setting | Details |
|-----------------|---|
| Image | This mode achieves the best results for printing photographic images and illustrations. |
| Line Drawing | This mode is best for printing CAD drawings with fine lines or wall newssheet or other documents that contain large amounts of text. However, you may not achieve the quality you expect with printing photographs or other images with many filled areas. For these types of jobs, select Image . |
| Proof | This is a setting for enhancing the reproducibility of characters, illustrations, and photos with print proofing. However, this takes more time than regular printing. |
| Office Document | Prints common office documents, such as proposals, memos for distribution, etc., so they are easy to read. |



Note

• The number of settings available for selection depends on the media type.

Print Quality

Selecting print quality strikes a balance between the quality of the printed image and printing speed.

The level of the print quality and resolution settings are displayed in the following combinations.

| Setting | Details |
|---------------|------------------------|
| Print Quality | High / Standard / Fast |
| Resolution | 600dpi / 300dpi |




Note

- The availability of settings is determined by the media type and print priority selections.
- Printing time is longer and more ink is consumed with **High** than with **Fast**, however, print quality is higher.
- Printing time is shorter and less ink is consumed with **Fast** than with **High**, however, print quality is lower.

iPF8300S Advanced Settings

Output Settings Panel



• Enlarged/Reduced Printing

Select the method for enlarged/reduced printing.

The following settings are available for enlarged/reduced printing.

| Setting | Details |
|----------------------|--|
| Fit Paper Size | Enlarges/reduces the whole page automatically to fit the media size selected for output. Select the media size to print from Paper Size . |
| Fit Roll Paper Width | Enlarges/reduces the whole page automatically to fit the width of the roll paper with the page width. |
| | *Make sure that the width of the roll paper in the printer is set correctly for Roll Paper Width in the Paper Settings panel. *Displayed only if rolls are selected in Paper Source . |
| Scaling | Enlarges/reduces the whole page by the scaling rate as specified. Input the scaling value in numerical characters. You can specify a range between 5 and 600%. |
| | *You can change the numbers by clicking either ▲ button or ▼ button. *Although Scaling can be set to make the image larger than the media size, the part that does not fit in the media cannot be printed. *This is not displayed when a checkmark is placed in Borderless Printing . |

Borderless Printing

You can print the media without margins on all sides when the roll paper with the specific width and the specific media type is used.

Output Settings Panel iPF8300S



Note

• Available only if rolls are selected in **Paper Source**.

Paper Size

You can select the size of the print media.



Note

• This is not displayed when Fit Roll Paper Width is set in Enlarged/Reduced Printing.

Print Centered

Select this feature to print the image in the center of a cut sheet or to print left and right margins evenly from the edges of roll paper.



Note

• This feature is useful when you print the document enlarged or reduced with **Scaling** as well. When an image is scaled, it is always enlarged or reduced in reference to a starting point in the upper left corner of the page. If the image is reduced, the bottom and right margins are enlarged and the top and left margins remain unchanged. At that point, you can set all margins evenly with this feature.

No Spaces at Top or Bottom

You can set the printer to print without any empty area when the print data contains empty area at the top or bottom. Since the printer does not feed paper over the empty area, you can save paper.



Note

• Available only if rolls are selected in **Paper Source**.

Rotate Page

Select the method for rotating page.

The following settings are available for rotating page.

| Setting | Details |
|-------------------------|--|
| Rotate Right 90 Degrees | Rotates the portrait page right 90 degrees and print in landscape orientation. When the rotated page can fit in the width of roll paper, the page is rotated automatically, and when it can not fit in the width of roll paper, the page is not rotated. |
| | *When Fit Roll Paper Width is selected under Enlarged/Reduced Printing , then the image is enlarged or reduced after rotating to fit the width of the roll paper. |
| Rotate Left 90 Degrees | Rotates the portrait page left 90 degrees and print in landscape orientation. When the rotated page can fit in the width of roll paper, the page is rotated automatically, and when it can not fit in the width of roll paper, the page is not rotated. |
| | *When Fit Roll Paper Width is selected under Enlarged/Reduced Printing , then the image is enlarged or reduced after rotating to fit the width of the roll paper. |
| Rotate 180 degrees | Allows you to rotate the image 180 degrees from the vertical to the right. |



Note

• Available only if rolls are selected in **Paper Source**.

Output Method Button

Click the button to open the **Output Method** dialog box.

iPF8300S Output Settings Panel

In this dialog box, you can specify the object output method.



Note

• To print after saving jobs in the temporary storage space, select Save data before printing.

Color Settings Panel



Color Mode

You can select a color mode to suit the print job.

| Setting | Details |
|--------------------|--|
| Color | Enables color printing. |
| Monochrome (Photo) | Prints monochrome photo image data in a gray scale that is free of color casting (phenomenon of grays that appear tinted). |
| Monochrome | Disables color printing and converts image from continuous color to grayscaled monochrome. |



Note

• The availability of settings depends on the print priority and media type selections.

Matching Mode

Under Matching Mode, select the matching mode.

Color Settings Panel iPF8300S


4

602

| Setting | Details |
|------------------------------|---|
| Driver Matching Mode →P.603 | Enables printing of optimal color tones using a driver specific color profile. You should normally select this mode. |
| ICC Matching Mode →P.604 | Enables color matching using ICC profiles. Select this if you want to print by specifying the input profile, printer profile, and matching method in detail. This allows you to use ICC profiles for digital cameras and scanners, ICC profiles created using the profile creation tool, etc. |
| ColorSync →P.605 | Enables color matching by using the ColorSync function of Mac OS. Select this if you want to perform soft proofing using ColorSync before printing. |
| No Correction | No color matching is performed. Select this option when you want to perform color matching in the software application. |

Driver Matching Mode

1. Under Matching Mode, select Driver Matching Mode.



2. Click Matching Method list, and then select a setting.


| Setting | Details |
|------------|---|
| Auto | Automatically selects the best color matching method for each Image, Graphics, Text. |
| Perceptual | Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software. |

iPF8300S Driver Matching Mode

| Setting | Details |
|--------------|---|
| Saturation | Color-matching optimized for printing posters, etc., vividly. |
| Colorimetric | Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric. |

ICC Matching Mode

1. Under Matching Mode, select ICC Matching Mode.



2. Click Matching Method list, and then select a setting.

| Setting | Details |
|--------------|---|
| Perceptual | Color-matching optimized for printing typical photos attractively. Smooth gradation is a feature. This is also an easy-to-use mode when performing color adjustment using application software. |
| Saturation | Color-matching optimized for printing posters, etc., vividly. |
| Colorimetric | Color-matching optimized for printing image data with accurate colors in input color space. This is the easiest-to-use mode when you want to adjust the color and print. However, gradation may be lost for colors of wider range than the color reproduction range of the printer. Generally, this is also called relative colorimetric. |

ICC Matching Mode iPF8300S

| Setting | Details |
|---|--|
| Colorimetric (No White-Point Correction) | The processing method of color-matching is identical to Colorimetric . Use this when you want to further reproduce the target paper material color of the image data. Generally, this also is called absolute colorimetric. |

3. Click the Input Profile list, and then select an input profile.




Note

- To match the color on the printing, select the input profile for Color imageRUNNER Enlargement Copy of the Color imageRUNNER type in use.
- **4.** Click the **Printer Profile** list, and then select a printer profile.

ColorSync

1. Under Matching Mode, select ColorSync.



2. Click the **Printer Profile** list, and then select a printer profile.



Note

• Available when using Mac OS X 10.4.

iPF8300S ColorSync

Printing Enlargements of Scanned Originals from a Color imageRUNNER

Scanned originals from a Color imageRUNNER can be enlarged and printed automatically.

Originals you create by scanning with a Color imageRUNNER are transferred to a "hot folder" and printed automatically after enlargement according to printing conditions you specify for that folder.

This processing sequence is called the Color imageRUNNER Enlargement Copy function.

To use Color imageRUNNER Enlargement Copy, first complete these settings in the following order.

- 1. Register a hot folder on your computer.


 Register a hot folder on your computer for storing scanned originals from the Color imageRUNNER and complete the settings for enlargement copy.
- **2.** Complete the scanning settings on the Color imageRUNNER. Configure the Color imageRUNNER to send scanned originals to the hot folder.

After these settings are complete, you can print enlarged copies of scanned originals from the Color imageRUNNER.

Registering a hot folder on your computer

Folders used for **Color imageRUNNER Enlargement Copy** (iR enlargement copy) are called hot folders. Register a hot folder on your computer for storing scanned originals from the Color imageRUNNER. You can specify printing conditions (such as the image quality and paper size), based on which originals transferred to the hot folder will be printed. Follow these steps to register and modify hot folders.

1. To display the Color imageRUNNER Enlargement Copy dialog box, either double-click the Color imageRUNNER Enlargement Copy.app icon after navigating to Canon Utilities — iR Enlargement Copy in the Applications folder or click Set in the Utility pane





Note

• Your printer is depicted in the lower-left area of this screen.

In Enlarged Copy Settings, click Add or Edit and either create or modify the hot folder.
 For instructions on registering and modifying hot folders, refer to the help file for Color imageRUNNER Enlargement Copy.

Completing the scanning settings on the Color imageRUNNER.

Configure the Color imageRUNNER to send scanned originals to the hot folder. It is easy to send scanned originals to the hot folder if you assign the scanning settings and destination to a **Favorites** button on the Color imageRUNNER. For instructions on assigning scanning and sending settings to the **Favorites** button, refer to the Color imageRUNNER manual.

607

Scanning the original and print an enlargement

Follow the steps below to scan an original on the Color imageRUNNER for enlarged printing on the printer. For detailed instructions, refer to the Color imageRUNNER manual.

- 1. Load the original on the platen glass or document feeder of the Color imageRUNNER.
- 2. Press **Send** to display the screen for transmission.

specified for the folder.

- **3.** Press **Favorites**, and then press the **Favorites** button assigned to the hot folder.
- **4.** Press **Start** on the control panel. If you scan originals on the platen glass, after scanning all originals, press **Done** on the touch-panel display.

 Scanned originals are sent to the hot folder and automatically enlarged and printed following the conditions you

608

Print Plug-In for Photoshop/Digital Photo Professional

| The Features of Print Plug-In | 610 |
|---|-----|
| Operating Environment | |
| Installation Procedures | 611 |
| Uninstall Procedures | 613 |
| Starting from Photoshop | 615 |
| Starting from Digital Photo Professional | 616 |
| Print Plug-In Main Window | 617 |
| Preview Area | 619 |
| Main Sheet | 621 |
| Page Setup Sheet | 624 |
| Color Settings Sheet | |
| Print History Sheet | |
| Support Sheet | 629 |
| Paper Detailed Settings Dialog Box | 630 |
| Set Configuration Dialog Box | |
| ICC Conversion Options dialog box | 633 |
| Roll Paper Options Dialog Box | 634 |
| Size Options Dialog Box | 635 |
| Curves Dialog Box | 636 |
| Print History Details Dialog Box | 637 |
| Utilize Three Types of Previews | 638 |
| Check Image with Print Area Layout | |
| Check the original image with Image | |
| Check Image with Roll Paper Preview | 641 |
| Print with a Desired Picture Quality | 641 |
| Adjust the Colors and Print | 642 |
| Adjust the Colors while Checking the Preview (for Color) | |
| Adjust the Colors while Checking the Preview (for Monochrome) | |
| Adjust the Colors by Color Matching | |
| Print High-Quality Adobe RGB16bit Images | |
| Prints monochrome photographs with high quality | |
| Using Adobe CMM | |
| Perform Black Point Compensation | |
| Perform Printing Press Simulation Print | |
| Enlarge/Reduce and Print | |
| Enlarge/Reduce and Print Matching Output Media Size | |
| Enlarge/Reduce and Print Matching Width of Roll Paper | |
| Specify Scaling, Enlarge/Reduce and Print | |
| Print with No Borders | |
| Utilize Print History | |
| Confirm Print History Details | |
| Apply Print History to an Image | |
| Store Print History to Print Preferences | |
| Delete Print History | |
| Export Print History from Print Preferences | |
| Import Print History to Print Preferences | |
| Delete Print History from Print Preferences | |
| Set Information to Print with Image | |
| ∵ | |

The Features of Print Plug-In

The main features of Print Plug-In are as follows.

- You can automatically detect the color space of Adobe RGB or sRGB-use images, etc., and automatically set optimal profiles. Thus, you can print without the trouble of configuring settings.
- You can directly process image data on Photoshop, and forward the image data to a printer. In this way, you can process 16-bit image data in addition to 8-bit image data.
- By using the preview function for images based on real images, and the preview function for layouts based on image positioning by media size, you can use this software to make color adjustments and confirm print layout.
- You can perform basic printer settings such as printer selection, media type and output profile selection, and matching
 methods, in addition to borderless printing and enlargement/reduction process without growing through the printer
 driver.
- By using the print history management function, you can import past print settings parameters. Additionally, you can save preferences as a file.



Note

- The media type, image size, detailed media settings, and the printer settings can cause the actual print output to differ from the Print Plug-In settings (the arrangement of the image in the layout preview, the print start position, and the media size).
- Loss of gradation in dark areas can be reduced by performing black point compensation.



Note

- Adobe CMM is required in order to use the black point compensation function.
- You can perform printing press simulation printing by specifying the printing press profile.

Operating Environment

The Print Plug-In operating environment is as follows.

- Compatible Operating System Mac OS X (10.4.8 or later)
- Compatible Photoshop Version Photoshop CS5, Photoshop CS4, Photoshop CS3
- Compatible Digital Photo Professional Version Digital Photo Professional Version 3.8x or later
- Software needed for Print Plug-In Installation Photoshop or Digital Photo Professional, imagePROGRAF Printer Driver



Note

- The supported OS version differs for each version of Photoshop. Check with Adobe for details.
- The supported OS version differs for each version of Digital Photo Professional.
- Operation in Mac OS X Classic is not guaranteed.

Installation Procedures

The procedures to install Print Plug-In are as follows.



Note


- Always install the printer driver before installing the Print Plug-In.
- 1. Insert the User Software CD-ROM into the CD-ROM drive to start the installer.
- 2. Click on the iPFxxxx PlugIn InstallerX icon in the Plug-in folder in the User Software CD-ROM.





Note

- The iPFxxxx icon is the name of the printer you are using.
- $\bf 3.$ Input the Administrator name and password and click the $\bf OK$ button.



iPF8300S Installation Procedures


4. After you have read the software User's Licensing Agreement, click the **Continue** button.



5. Click the **Agree** button.



6. Select **Custom Install** to put a checkmark on your Print Plug-In, then click the **Install** button.



Installation Procedures iPF8300S

7. To quit another application, click the **Continue** button.



8. Click the **Quit** button.



The Print Plug-In installation is complete.

Uninstall Procedures

The procedures for uninstalling the Print Plug-In are as follows.

- Uninstall Print Plug-In for Photoshop
 - **1.** Close Photoshop.
 - **2.** In Finder, display the **Print Plugin for iPFxxxx** folder.
 - **3.** Delete the **Print Plugin for iPFxxxx** folder.




Note

- iPFxxxx is the name of your printer.
- Uninstall Print Plug-In for Digital Photo Professional
 - **1.** Perform the installation procedures 1 through 5.

iPF8300S Uninstall Procedures

2. Select Uninstall.



3. Click the **Uninstall** button.



4. To quit another application, click on the **Continue** button.



Uninstall Procedures iPF8300S

5. Click the **Quit** button.



Starting from Photoshop

Follow the procedure below to start the Print Plug-In from Photoshop.

- **1.** Start Photoshop.
- 2. Open the image that you wish to print.
- **3.** If required, select the print range.




Note

• Images for use with Print Plug-In are less than 60,000 pixels in width and height. Reduce the selection range or reduce the image with processing for images more than 60,000 pixels in width and height, and then attempt step 3.

iPF8300S Starting from Photoshop

4. Select Export (or Data Export) from the File menu and then select the output plug-in that matches your printer.

The imagePROGRAF Print Plug-In for Photoshop window (known below as the Print Plug-In window) is displayed.





Note

- When the color space of the input image is CMYK, it is changed to AdobeRGB for processing with Print Plug-In. Also, **Relative Colorimetric** is used for the matching method.
- If the message below is displayed but the Print Plug-In window is not displayed, install the newest imagePROGRAF printer driver and then attempt step 3.
 - To install imagePROGRAF Print Plug-In, the latest version of the imagePROGRAF printer driver must be installed.
- If the following message is displayed, but the Print Plug-In window is not displayed, open only one Photoshop.
 - When Photoshop is running in multiple windows, the plug-in may not start.
- If the message below is displayed but the Print Plug-In window is not displayed, convert the color space of the image to either RGB color, grayscale, or CMYK color and then attempt step 3.

 Set the color space of the image to either RGB color, grayscale, or CMYK color.

Starting from Digital Photo Professional

Follow the procedure below to start the Print Plug-In from Digital Photo Professional.


- 1. Start Digital Photo Professional.
- 2. Open the RGB color image that you want to print.
- **3.** If required, select the print range.



Note


• Images for use with Print Plug-In are less than 6,000 pixels in width and height. Reduce the selection range or reduce the image with processing for images more than 6,000 pixels in width and height, and then attempt step 3.

4. Select **File** from the **Plug-in printing** menu and then select the output plug-in that matches your printer. The imagePROGRAF Print Plug-In for Digital Photo Professional window (hereinafter referred to as the Print Plug-In window) is displayed.



Print Plug-In Main Window


The Print Plug-In main window consists of the sheet selection area, and the preview and button area.



617

· Sheet Selection Area

The tabs used to switch between each sheet on the Print Plug-In window are displayed.




When you select a tab, a sheet is displayed. The settings available on each sheet are as follows.

- Main Sheet →P.621
- Page Setup Sheet →P.624
- Color Settings Sheet →P.627
- Print History Sheet →P.628
- Support Sheet →P.629

Preview Area

You can check the settings you made on the image in this area.




About the settings available on the preview area, see "Preview Area." —P.619

618

• Button Area


This contains the buttons Print, Quit and Help



- **Print**Button Click this button to begin printing.
- **Quit**Button
 Click this button to close the Print Plug-In window and return to application software.
- Button
 Click this button to display the Print Plug-In Help file.

Preview Area

You can check the settings you made on the image in this area.



iPF8300S Preview Area

Preview

Select the preview display method.

For more information about preview, see "Utilize Three Types of Previews." →P.638

| Setting | Details |
|--------------------|--|
| Print Area Layout | Displays the print range and the area out of the print range in the layout matching the Paper Size set. |
| | *You can change the image print position when you drag the image while the cursor is displayed as . |
| Image | The entire image is displayed. *You can select the print range when you drag the image while the cursor is displayed as *When you click the image while the cursor is displayed as, the selected area is deselected. |
| Roll Paper Preview | Display the media size and roll paper information on the top in the layout printing on roll paper. *To select Roll Paper Preview, select Roll Paper in Paper Source. |

• Print Selected Range

Place a checkmark here to only print the selected range.



Note

• When you select **Preview** in the **Image**, then select a portion of the image on the preview display, this becomes valid.

Perform Proof in Preview

Place a checkmark here to simulate the colors of the output product in the preview.



Note

- If Auto (Color) is selected under Output Profile, some media types are enabled.
- If ICC profile is selected under **Output Profile**, this is always enabled.
- The actual color balance of the print product and the simulation product may differ with some environments and conditions. In addition, when you have selected an ICC Profile with **Output Profile** and it is not compatible with the printer or media that you are using, the color balance of the actual print product will differ.

• Image Properties button

When you click the button to open the **Image Properties** dialog box, where **Image Size**, **Resolution**, **Bit** and **Color Space** information of the image imported to Print Plug-In are displayed.


Preview Area iPF8300S

Click the Close button to return to Print Plug-In.



Main Sheet

You can use this sheet to perform basic settings such as selecting a printer, setting the media type, or adjusting image quality.



Printer

The printer types are displayed.

Select button

Click this button to display the **Select Printer** dialog box.

When you click the **OK** button after selecting the printer in the **Select Printer** dialog box, you can change the printer that corresponds with Print Plug-In.

Media Type

This allows you to select the media type.

For more information about **Media Type**, see "Customize Media Settings." \rightarrow P.660



Note

• Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.

iPF8300S Main Sheet

• Advanced Settings button

Click the button to display the **Paper Detailed Settings** dialog box.

For more information about the media detailed settings, see "Paper Detailed Settings Dialog Box." —P.630

• Input Resolution to Plug-in

You can select the resolution to process the image with Print Plug-In.

The following settings are available for resolution.

| Setting | Details |
|----------------------|--|
| Accuracy 300ppi | This processes images at an accurate resolution. This can control print speed and memory capacity. |
| High Accuracy 600ppi | This processes images at a more accurate resolution. This setting results in the best print quality, but this takes more time to print than Accuracy 300ppi while also requiring more memory capacity. *This may not be displayed depending on how you set Media Type |

• Input Bit to Plug-in

You can select the bit number to process with Print Plug-In.

The following settings are available for the input bit number.

| Setting | Details |
|-------------------------|--|
| High Gradation 8bit | This processes images with at 8bit/channel (24 bit). |
| Highest Gradation 16bit | This processes images with at 16bit/channel (48 bit). |
| | *This may not be displayed depending on how you set Media Type and Input Resolution to Plug-in . |

Print Mode

Selecting the printing mode strikes the balance between the quality of the printed image and printing speed. The following settings are available for the print mode.

| Setting | Details |
|------------------------------|--|
| Highest | A setting for printing at the highest resolution when quality is most important. Printing takes longer and consumes more ink than in other modes, but this mode offers superior printing quality. |
| High | Choose this setting to print at high resolution when quality is most important. Printing takes longer and consumes more ink than in Standard or Fast modes, but this mode offers exceptional printing quality. |
| Standard | Choose this setting to print at standard resolution when quality and speed are both important. Printing takes less time than in Highest or High mode. |
| Fast | Choose this setting to print faster. Printing in fast mode can help you work more efficiently when checking layouts. |
| Highest (Max. No. of Passes) | If you are concerned about uneven colors in the print result of Highest quality , selecting this option may improve printing results. However, printing may take longer. |



Note

• The selectable fields may vary according to the Media Type, Input Resolution to Plug-in and Input Bit to Plug-in settings.

Main Sheet iPF8300S

Output Profile

You can select the output profile.

The following settings are available for the output profile.

| Setting | Details |
|------------------------------|--|
| Auto (Color) | Performs the optimum color conversion from the input image data color space information (sRGB, Adobe RGB), media settings etc. You should normally select these settings. |
| Auto (Monochrome Photo) | Performs the best color conversion to monochrome from the input image data color space information (sRGB, Adobe RGB), media settings etc. |
| None (No Color Correction) | You cannot perform color conversion with a plug-in. This is useful for creating an original ICC profile. |
| External ICC Profiles | This selects printer ICC profiles to be output to ICC profiles saved in the OS standard folder. Use the color space of the input data as well as the select ICC profile to perform color conversion. |



Note

• Auto (Monochrome Photo) can only be selected for the corresponding media types.

Proof

This is displayed when an ICC profile is selected as the **Output Profile**.

When this is checked, you can perform printing press simulation prints.

Refer to Perform Printing Press Simulation Print —P.654 for details on printing press simulation prints.

Matching Method

You can select the processing method when performing color conversion.

The following settings are available for the matching method.

| Setting | Details |
|-----------------------|--|
| Perceptual | This converts the image to an image with natural color balance and gradation. This is useful for pictures. |
| Saturation | This converts the image to an image with heightened color saturation. The color balance of pictures and drawings may change. |
| Relative Colorimetric | This converts the image with emphasis on color balance before the conversion or on visual color balance. This is useful for pictures and drawings. |



Note

 When the Output Profile you have set is Auto (Monochrome Photo) or None (No Color Correction), you cannot select a matching method.

• ICC Conversion Options button

This is displayed when an ICC profile is selected as the **Output Profile**.

When this button is clicked, the ICC Conversion Options dialog box is displayed allowing you to configure color conversion related settings.

Refer to ICC Conversion Options dialog box —P.633 for details on ICC Conversion Options.

Copies

You can input the number of print copies in numerical characters.

iPF8300S Main Sheet



Note

- The maximum value is 99.
- You can change the numbers by clicking either ▲ or ▼.

• Set Configuration button

Clicking the button opens the **Set Configuration** dialog box that provides settings for the adjustment of image sharpness and image enlargement method.


For more information about Set Configuration, see "Set Configuration Dialog Box." —P.632

• Defaults button

Click the button to return all of the settings on the Main sheet to their defaults.

Page Setup Sheet

You can use this sheet to set the size of the image to be printed, the media size, and whether to enlarge/reduce the image.



Input Image Size

The size of the image imported to Print Plug-In is displayed.

Borderless Printing

When you place a checkmark here, the **Specify Roll Paper Width** dialog box is displayed and you can print an image without borders.

For more information about **Borderless Printing**, see "Print with No Borders." →P.659



Note

• Available only if rolls are selected in **Paper Source**.

Enlarged/Reduced Printing

When you place a checkmark here, you can print enlarged/reduced images.

Page Setup Sheet iPF8300S

1

624

When printing an enlarged/reduced image, select the method for enlargement/reduction. The image size sent to the printer is displayed matching the selected method in **Output Image Size**.

The following settings are available for enlarged/reduced printing.

| Setting | Details |
|----------------------|---|
| Fit Paper Size | This automatically enlarges/reduces the entire image imported to Print Plug-In to match the export media size when printing. |
| Fit Roll Paper Width | This automatically enlarges/reduces the entire image imported to Print Plug-In to match the width of the roll paper with the width of the image when printing. |
| | *Displayed only if rolls are selected in Paper Source . |
| Scaling | This enlarges/reduces the entire image by the specified scaling value. Input the scaling value in numerical characters. You can specify a range between 5-600%. |
| | *You can change the numbers by clicking either ▲ or ▼. |



Note

• This is not displayed when a checkmark is placed in Borderless Printing.

Output Image Size

The output image size is displayed up to one place after the decimal point in millimeters.



Note

• When Paper Size is smaller than Output Image Size, part of the image may not print.

• Paper Size

You can select the size of the print media.



Note

- This is not displayed when a checkmark is placed in Borderless Printing.
- This is not displayed when Fit Roll Paper Width is set in Enlarged/Reduced Printing.

Orientation

This selects the print orientation.

The following settings are available for orientation.

| Setting | Details |
|-----------|--|
| Portrait | Prints the image on the media as it appears on the screen. |
| Landscape | Prints the image on the media rotated 90 degrees. |

Layout

You can select the print position of an image on the media.

The following settings are available for layout.

Layout

| Setting | Details |
|------------------------------------|---|
| Upper-Left of Output Paper Size | Prints the image with fitting the top left of the active print area for Paper Size . |

iPF8300S Page Setup Sheet

| Setting | Details | |
|------------------------------|---|---|
| Center of Output Paper Size | Prints the center of the image on the center of the selected Paper Size . | |
| Specify Print Start Position | You can print with specifying the top and left printing start positions in From Top Margin and From Left Margin for Paper Size. | |
| | From Top Margin | Input the margin from the top of the media in numbers. |
| | | *You can input between -9999 and 9999 mm. |
| | From Left Margin | Input the margin from the left of the media in numbers. |
| | | *You can input between -9999 and 9999 mm. |



Note

• Select Print Area Layout or Image in Preview when you select Layout.

Roll Paper Layout

| Setting | Details |
|--------------------------|---|
| Upper-Left of Roll Paper | Prints the top left of Media Size on the top left of the selected roll paper. |
| Center of Roll Paper | Prints the center of Media Size on the center of the selected roll paper. |



Note

• Select Roll Paper Preview in Preview when you select Roll Paper Layout.

Paper Source

You can select the media source.

The following settings are available for media source.

| Setting | Details |
|------------|-----------------------------------|
| Roll Paper | Select to print on roll paper. |
| Cut Sheet | Select to print on the cut sheet. |

• Roll Paper Options button

Click this button to open the **Roll Paper Options** dialog box, where you can set roll paper width and perform auto cut settings.

For more information about the roll paper options, see "Roll Paper Options Dialog Box." →P.634

Size Options

Click the Size Options button to open the **Size Options** dialog box and you can select a media name, size and other settings.

For more information about the size options, see "Size Options Dialog Box." —P.635


• **Defaults** button

Click the button to return all of the settings on the **Page Setup** sheet to their defaults.

Page Setup Sheet iPF8300S

Color Settings Sheet

You can use this sheet to adjust image Color, **Brightness**, **Contrast**, **Saturation**, and you can set the color balance of print product more to your liking.



· Cyan / Magenta / Yellow

You can adjust the strength or weakness of a color by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

Gray Tone

You can adjust gray tone from cool black (cool tones) to warm black (red tones) by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

Brightness

You can adjust the brightness of the printed image without losing the brightest and darkest areas by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

Contrast

You can relatively adjust the brightness of the brightest and darkness areas by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

iPF8300S Color Settings Sheet

Saturation

You can adjust the saturation of vivid color balance to dark color balance by either inputting a numerical value or dragging the slide bar.



Note

• You can check the adjustments in the preview display.

• Curves button

Click the button to open the **Curves** dialog box then set the **Channel** and other settings. For more information about **Curves**, see "Curves Dialog Box."


P.636

· Defaults button

Click the button to return all of the settings on the Color Settings sheet to their defaults.

Print History Sheet

You can use this sheet to apply settings history used in printing, and to print information, such as the image file name, with the image.



Print History and Favorites

This displays a list of print preferences.

Select **Restore Defaults** and click the **Apply** button to restore all settings to their initial settings.



628

Note

• You can check the 3 print preferences in the preview display.

· Apply button

When you click the button, the print setting content applies to the current image selected with **Print History and Favorites**.

Print History Sheet iPF8300S

• **Details** button

Click the Details button to open the **Print History Details** dialog box, where you can manage print history. For more information about the print history details, see "Print History Details Dialog Box." —P.637

• Print Information

When you place a checkmark here, you can print the file name and print time and date on the image. The following settings are available for the print position and content.

For more information about **Print Information**, see "Set Information to Print with Image." (¬P.672)

| Setting | | Details |
|----------------------------|---|--|
| Information Print Position | Selects the information print position. | |
| | Top (Header) | Information is printed on the top of the image. |
| | Bottom (Footer) | Information is printed on the bottom of the image. |
| Print History Number | Place a checkmark here | e to print the print history number. |
| File Name | Place a checkmark here | e to print the file name. |
| Printed at | Place a checkmark here | e to print the time and date. |
| Color Adjustment Value | Place a checkmark here | to print the color adjustment value. |
| Printer Name | Place a checkmark here | e to print the printer name. |
| Comment | Place a checkmark here | e to print the comment details. |
| Comment Details | Place a checkmark here | to display the comment details. |

• Edit Comment button

Click the button to display the **Edit Comment** dialog box, where you can edit the comment.

Support Sheet

You can display product support information and the electronic manual.



iPF8300S Support Sheet

Click the button to display websites that contain the latest product information.



Note

• An Internet connection is needed to view the websites.

User Manual button

Click the button to display the printer manuals installed on the computer.



Note


You must have User Manual installed on your computer.

About button

Click the button to open the version information window of the Print Plug-In. Click the **OK** button in the version information window to return to the Print Plug-In window.

Paper Detailed Settings Dialog Box

This dialog box appears when you click the **Advanced Settings** button on the **Main** Sheet. You can set **Drying Time** and **Roll Paper Margin for Safety** by media type.



630

Drying Time

Between Pages

This sets the wait time for the ink to dry between each completely printed sheet and the output of the sheet.

| Setting | Details |
|--|--|
| Printer Default | The settings of the printer operating panel are applied. |
| None | The paper is ejected immediately after printing. |
| 30sec. / 1min. / 3min. / 5min. / 10min. / 30min. / 60min. | The sheet is ejected when the specified time after printing has elapsed. |

Between Scans

This sets the wait time between line scans during printing.

| Setting | Details |
|---------------------------------------|--|
| Printer Default | The settings of the printer operating panel are applied. |
| None | The printing continues to the next line immediately after the last line. |
| 1sec. / 3sec. / 5sec. / 7sec. / 9sec. | The printing continues to the next line after the set time. |
| | *For the media type that has problems, such as ink smears on the page or colors that seem uneven during borderless printing etc., increase the value for this setting. |

Roll Paper Margin for Safety

Near End Margin

This sets the length of the near end margin of the roll paper.

| Setting | Details |
|-----------------|--|
| Printer Default | The settings of the printer operating panel are applied. |
| 5mm | Print at a standard size. *Select for Media Type that has no problem when printing with a standard size margin. |
| 20mm | Select this when rubbing against the printhead occurs such as when using paper that tends to curl. |

Cut Speed

This selects the auto cut speed.

| Setting | Details |
|-----------------|--|
| Printer Default | The settings of the printer operating panel are applied. |
| Fast | Select this setting if cutting with the Standard setting is not clean. |
| Standard | Select this setting when you are not experiencing problems. |
| Slow | This helps prevent adhesive from sticking to the cutter and keeps the cutter sharp if you select it when using adhesive paper. |

Calibration Value

When calibration has been carried out on the printer, use this setting to choose whether or not to use the results.

| Setting | Details |
|-----------------|---|
| Printer Default | The settings of the printer operating panel are applied. |
| Use Value | The calibration results are used for printing. |
| Disregard Value | The calibration results are not used for printing. Select this option to avoid changes to image color tones during printing due to color calibration. |

• Mirror

Specify whether to print a mirror image, as needed. Select this option to print a version of the document or image with the left and right sides inverted.

Unidirectional Printing

Select this checkbox to prevent problems such as misaligned lines and improve the print quality. However, the printing speed becomes slower.

High-Precision Text and Fine Lines

Print increasing ink impact accuracy, particularly for sharper text and fine lines. However, this takes more time than regular printing.



Note

• When **Highest (Max. No. of Passes)** is selected as the print mode, **High-Precision Text and Fine** Lines cannot be selected.

Set Configuration Dialog Box

This dialog box appears when you click the **Set Configuration** button on the **Main** Sheet. You can set the adjustment of image sharpness and image enlargement method.

| Set Configuration | |
|--|--|
| Sharpen: 0 (0-500) | |
| Image Enlargement Method : Nearest Neighbor | |
| Perform printing in the background Close Plug-in After Printing | |
| Output Method | |
| O Print | |
| O Save in mail box | |
| Inbox No. : 1 (1-29) | |
| Name of data to be saved : | |
| Print after reception is complete | |
| Initialize all warning dialog boxes | |
| ② Defaults Cancel OK | |

Sharpen

Performs adjustment of the sharpness (outline) settings.

Image Enlargement Method

You can select the image enlargement method.

The following settings are available for the image enlargement method.

| Setting | Details |
|------------------|---|
| Nearest Neighbor | Performs simple enlargement. |
| Bilinear | Performs line vector enlargement. |
| Bicubic | Adjust pixels with calculation of elements such as a color or brightness of neighboring pixels. |

· Perform printing in the background

When you place a checkmark here, the plug-in performs printing with the Plug-In in the background.

• Close Plug-in After Printing

When you place a checkmark here, the plug-in closes after printing finishes.



Note

• If printing does not finish correctly because it was canceled or an error occurred, the plug-in does not close.

Output Method

You can select the output method.

The following settings are available for the output method.


| Setting | Details |
|-----------------------------------|--|
| Print | Normal printing. The print job data is stored temporarily in the box as the job prints. |
| Save in mail box | Saves the print data in the mail box. If you select Save in mail box, you must specify Name of data to be saved. |
| Print after reception is complete | When you place a checkmark here, you can print after saving jobs in the temporary storage space. This cannot be used when Save in mail box is selected. |

· Initialize all warning dialog boxes

When this is checked, all of the warning dialog boxes that have been set to "Do not show this screen again" become displayed.

ICC Conversion Options dialog box

This is displayed when an ICC profile is selected in the **Output Profile** list in the **Main** sheet and the **ICC Conversion Options** button is clicked. This allows you to configure detailed color matching related settings.



Conversion Engine

Selects the conversion engine to use when converting colors.



Note

• Adobe CMM needs to be installed in order to use **Adobe CMM**. Refer to **Using Adobe CMM** →**P.651** for details on how to install Adobe CMM.

Black Point Compensation

Check this check box to perform black point compensation. Loss of gradation in dark areas can be improved by performing black point compensation.



Note

• This can be used if **Adobe CMM** is selected as the **Conversion Engine**.

Proof Options

Configures settings related to printing press simulation.

The proof options consist of the following settings.

| Setting | Details |
|----------------------|---|
| Simulate Paper Color | Select this when performing paper color simulation. |

Roll Paper Options Dialog Box

This dialog box appears when you click the **Roll Paper Options** button on the **Page Setup** Sheet. You can set the roll paper width and perform the auto cut settings.



Roll Paper Width

This selects the width of the roll media set to the printer.

Automatic Cutting

You can set the printer to cut roll paper automatically or print a guideline for cutting.

The following settings are available for automatic cutting.


| Setting | Details |
|---------------------|---|
| Available | Each page is automatically cut after it is printed. |
| None | Each page is not cut after it is printed and printing continues without interruption. |
| Print Cut Guideline | A print cut guideline is printed after each page and printing continues without interruption. |

No Spaces at Top or Bottom (Conserve Paper)

When you place a checkmark here, the print data is printed without margins.

Size Options Dialog Box

This dialog box appears when you click the **Size Options** button on the **Page Setup** Sheet. You can select a media name, size and other settings.



Paper Size List

Displays all the standard sizes and custom media sizes.

Custom Paper Size Name

You can enter any name up to 63 characters.

• Units

You can select the units of measure to use when you define custom media size. Switching this setting resets the units of measure for the entire Plug-In.

Paper Size

Width

Enter the width of the media size.

Height

Enter the height of the media size.


Add button

Click the button to register the contents of the settings.

iPF8300S Size Options Dialog Box

Curves Dialog Box

This dialog box appears when you click the **Curves** button on the **Color Settings** Sheet. You can set **Channel** and other settings.



Channel

Select from among RGB, Red, Green, or Blue.



Note

• Gray is displayed for monochrome printing and this selection cannot be changed.

Input

Enter an input value.



Note

- The allowed entry range is 0 to 255.
- You can change the numbers by clicking either ▲ button or ▼ button.

Output

Enter an output value.



Note

• The allowed entry range is 0 to 255.

Curves Dialog Box iPF8300S

· Load Curves button


Click the button to load stored data for a tone curve.

· Save Curves button

Click the button to stores the current tone curve settings.

Print History Details Dialog Box

This dialog box appears when you click the **Details** button on the **Print History** Sheet. This controls print history. For more information about **Print History Details**, see "Utilize Print History." \longrightarrow P.661



Print History

Print History appears in list format.

| Display Items | Details |
|----------------------|-------------------------------------|
| Print History Number | Displays the print history number. |
| File Name | Displays image file name. |
| Printed at | Displays time and date of printing. |
| Comment | Displays comment details. |



Note

- Up to 200 print history items can be displayed. All items above 200 are deleted.
- When you cannot print properly because you canceled the printing or an error occurred, appears × to the left of the print history number.

• Delete button

Click the button to delete the selected print history.

• Add button

Click the

button to add the selected print history to preferences.



• Up to 200 print preference items can be added.

Favorites

The print history stored in print preferences displays in list format.



• You can change the order by selecting an item and dragging it to another place.

• Import button

Click the button to import print history saved as a file.

• Export button

Click the button to save print history as a file that is stored in print preferences.

· Delete button

Click the button to delete print history stored in print preferences.

Settings

Displays the print history settings selected from the **Print History** or **Favorites**.

| Setting | Details |
|----------------|--|
| Main | When you select this the Main sheet settings are displayed. |
| Page Setup | When you select this the Page Setup sheet settings are displayed. |
| Color Settings | When you select this the Color Settings sheet settings are displayed. |


Utilize Three Types of Previews

You can use Print Plug-In to check an image in three types of previews. The preview types are as follows.

- Check Image with Print Area Layout →P.639
- Check the original image with Image →P.640
- Check Image with Roll Paper Preview →P.641

Check Image with Print Area Layout

Displays the print range and the area out of the print range in the layout matching the media size set in the print area layout. Select **Print Area Layout** in **Preview**.






Note

- When the cursor on the preview is displayed as on the preview, you can specify the print position by dragging the image.
- When the cursor is displayed as on the preview, the below conditions on the **Page Setup** sheet have all been met.
 - There is no checkmark in **Borderless Printing**.
 - There is no checkmark in Enlarged/Reduced Printing or Scaling has been selected.

Check the original image with Image

In the image preview you can check the entire image that you have input. Select **Image** in **Preview**.






Note

- When the cursor appears as a small magnifying glass while there is an **Image** in the **Preview** area, the **Selected Range** feature is enabled and you an drag the cursor on the image and select an area for printing.
- When you click the image while the cursor is displayed as an on the preview, the selected area is deselected.

Check Image with Roll Paper Preview

Display the media size and roll paper information on the top in the layout printing on roll paper in Roll Paper Preview Select **Roll Paper Preview** in **Preview**.



Note

• To select Roll Paper Preview in Preview, select Roll Paper in Paper Source.

Print with a Desired Picture Quality

You can specify and print at the resolution you desire.

1. Display the Main sheet.





Note

- Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.
- 3. Choose either Accuracy 300ppi or High Accuracy 600ppi for the resolution to process images in Input Resolution to Plug-in.



Note

- When you select **Accuracy 300ppi** images are processed at an accurate resolution. This can control print speed and memory capacity.
- When you select **High Accuracy 600ppi** images are processed at a more accurate resolution. This setting results in the best print quality, but this takes more time to print than **Accuracy 300ppi** while also requiring more memory capacity.
- High Accuracy 600ppi will not display with some Media Type settings.
- 4. Choose either **High Gradation 8bit** or **Highest Gradation 16bit** for the bit number when processing images in **Input Bit to Plug-in**.



Note

- When you select **High Gradation 8bit**, images are processed at 8 bit/channel (24 bit).
- When you select **Highest Gradation 16bit**, images are processed at 16bit/channel (48 bit).
- Highest Gradation 16bit will not display with some Media Type or Input Resolution to Plug-in settings.
- 5. Select the mode to be printed when processing images in **Print Mode**.



Note

 The settings that can be selected differ by Media Type, Input Resolution to Plug-in, and Input Bit to Plug-in selected.

6. Click the **Print** button.

Printing begins.

Adjust the Colors and Print

You can adjust the colors to your liking and print images.

The explanation below is on 5 ways to adjust the colors using Print Plug-In.

- Adjust the Colors while Checking the Preview (for Color) —P.643
- Adjust the Colors while Checking the Preview (for Monochrome) →P.644
- Adjust the Colors by Color Matching →P.648
- Print High-Quality Adobe RGB16bit Images →P.649
- Prints monochrome photographs with high quality →P.651
- Using Adobe CMM →P.651

1

Adjust the Colors while Checking the Preview (for Color)

You can adjust the colors while checking the adjustments in the preview. The following explanation is on the procedures for adjusting example image below.

- · Low for Cyan
- · High for Yellow
- Low for Saturation
- Warm Black for Gray Tone
- Enhance brightness for the curves

The above image adjustments are reflected in the before and after images below.



1. Display the Color Settings sheet.




2. Drag the slide bar in the direction of **Low** in **Cyan**.

- **3.** Drag the slide bar in the direction of **High** in **Yellow**.
- **4.** Drag the slide bar in the direction of **Low** in **Saturation**.
- 5. Drag the slide bar in the direction of Warm Black in Gray Tone.



Note

- You can change the numbers by inputting in numerical characters.
- You can change the numbers by clicking either ▲ button or ▼ button.
- 6. Click the Curves button then click near the center of the curve.
- 7. Enter 120 in **Input** and 135 in **Output** then click the **OK** button.



8. Click the **Print** button.

The adjustments are reflected in the image and printing begins.

Adjust the Colors while Checking the Preview (for Monochrome)

You can adjust the colors while checking the adjustments in the preview. The following explanation is about the procedures for adjusting example image below.


• Low for Contrast

- Light for Highlight
- · Light for Shadow
- Enhance brightness for the curves


The unapplied and the applied images of the above image adjustments are as below.



- 1. Open the Main sheet.
- 2. Select Auto (Monochrome Photo) in Output Profile.



3. Open the **Color Settings** sheet.




- **4.** In **Contrast**, drag the slide bar toward **Low**.
- **5.** In **Highlight**, drag the slide bar toward **Light**.
- **6.** In **Shadow**, drag the slide bar toward **Light**.



Note

- You can change the numbers by inputting in numerical characters.
- You can change the numbers by clicking either ▲ button or ▼ button.
- 7. Click the Curves button then click near the center of the curve.

8. Enter 120 in **Input** and 135 in **Output** then click the **OK** button.




9. Click the **Print** button.

This applies the image adjustments and starts the print job.

Adjust the Colors by Color Matching

When you print a color image imported from a scanner or a digital camera, the image may appear different from the image on the screen. That is due to the differences in color on the screen and in the printer. In Print Plug-In, you can get the color balance of the print product closer to the color balance displayed on the screen through performing ICC (International Color Consortium) color profile settings, matching method settings, and settings for the internal profile, which performs optimum color conversion in response to media and resolution settings.

1. Display the Main sheet.



2. Select the profile in Output Profile.



Note


- When you place a checkmark in **Perform Proof in Preview**, you can check the color matching in the preview. This may not be displayed depending on how you set **Media Type**.
- The details of **Output Profile** you have set is saved even when you close the Print Plug-In, but when the specified profile cannot be located it is set to **Auto (Color)**.
- If an ICC profile is selected as the **Output Profile**, Adobe CMM can be selected as the color conversion engine. Refer to Using Adobe CMM P.651 for details.
- 3. Select the profile matching method in **Matching Method**.
- **4.** Click the **Print** button.

Printing begins with the output profile and matching method that you have set.


Print High-Quality Adobe RGB16bit Images

This prints a high-quality Adobe RGB16bit image taken with a high-end digital camera. Print Plug-In allows you to print high color gamut and high tone images, when the Adobe RGB16bit image data has been retouched in Photoshop, without compromising the level of tone in the image.


1. Select the Adobe RGB16bit image data in Photoshop and start Print Plug-In. (See "Starting from Photoshop.")



- 2. Click button.
- 3. Check that Adobe RGB is displayed in Color Space, and 16bit/channel is displayed in Bit in the Image Properties dialog box, and click the Close button.



4. Display the **Main** sheet.



- 5. Select High Accuracy 600ppi in Input Resolution to Plug-in.
- 6. Select Highest Gradation 16bit in Input Bit to Plug-in.
- 7. Select the highest quality possible in **Print Mode**.
- **8.** If required, adjust the colors using color matching.




9. Click the Print button.

Printing of the Adobe RGB16bit image begins.

Prints monochrome photographs with high quality

Prints images captured with a scanner or digital camera in monochrome with high quality. Provides stable monochrome photo images without color casts and minimizes the influences of the difference of the light source.

1. Display the Main sheet.



2. Select Auto (Monochrome Photo) in Output Profile.



Note

• Auto (Monochrome Photo) can be selected only after a compatible Media Type has been selected.

3. Click the **Print** button.

Performs conversion to the most suitable monochrome and printing begins.

Using Adobe CMM

Adobe CMM is a color conversion engine made by Adobe. Using Adobe CMM makes it possible to obtain uniform color conversion results and to use the black point compensation function.



Important

• Use version 1.1 or higher of Adobe CMM.

· How to Obtain Adobe CMM

Adobe CMM can be obtained using the following procedure.

- **1.** Open the Adobe website (http://www.adobe.com).
- 2. Enter "Adobe CMM" in the search input box on the screen.

- **3.** Search for the "Adobe Color Management Module (CMM)" item and select the Macintosh version.
- **4.** Download the file by following the on-screen directions.
- 5. Start the installer in the downloaded file to perform the installation.

• Adobe CMM System Requirements

The system requirements for Adobe CMM are as follows.

- Supported OS Mac OS X 10.4.8 or later
- Supported CPU
 PowerPC G4 or G5
 Intel Core Duo, Intel Core 2 Duo, Intel Xeon processor



Note

• Check with Adobe for details.

• How to Use Adobe CMM

The procedure for using Adobe CMM is as follows.


1. Display the **Main** sheet.



- 2. Select one of the ICC profiles as the **Output Profile**.
 - **3.** Click the **ICC Conversion Options** button.

Using Adobe CMM iPF8300S

4. In the ICC Conversion Options dialog box, select Adobe CMM from Conversion Engine.



5. Click the **OK** button to close the **ICC Conversion Options** dialog box.

Perform Black Point Compensation

Black point compensation that is equivalent to Photoshop can be performed using the following procedure. Use this to avoid saturation in the black areas of images.



Important

- In order to make the black point compensation settings effective, close down and restart Photoshop or Digital Photo Professional.
- Adobe CMM needs to be installed in order to use black point compensation. Refer to Using Adobe CMM —P.651 for details on how to install Adobe CMM.
- 1. Display the Main sheet.



- 2. Select one of the ICC profiles as the **Output Profile**.
- $\bf 3.$ Click the ICC Conversion Options button to open the ICC Conversion Options dialog box.

- 4. Select Adobe CMM as the Conversion Engine.
- 5. Check the Black Point Compensation check box.



6. Click the **OK** button to close the **ICC Conversion Options** dialog box.

Perform Printing Press Simulation Print


You can perform printing press simulation prints by specifying ICC profiles such as Japan Color or SWOP, and specifying an ICC profile for the printing press.

1. Display the Main sheet.



- 2. Select one of the ICC profiles as the Output Profile.
 - 3. Check the **Proof** check box and select the profile for the printing press you want to target from the list on the right.

4. Click the ICC Conversion Options button to open the ICC Conversion Options dialog box.



5. Configure the **Proof Options** as needed.



- Note
- The proof option is **Simulate Paper Color**.
- **6.** Click the **OK** button to close the **ICC Conversion Options** dialog box.
- 7. Click the **Print** button. Printing begins.

Enlarge/Reduce and Print

You can enlarge or reduce an image in Print Plug-In.

Three methods to enlarge/reduce and print are as follows.

- Enlarge/Reduce and Print Matching Output Media Size →P.655
- Enlarge/Reduce and Print Matching Width of Roll Paper —P.657
- Specify Scaling, Enlarge/Reduce and Print →P.658

Enlarge/Reduce and Print Matching Output Media Size

By specifying the media type loaded in the printer, the image can be enlarged or reduced to fit the size of the image area of the media. This feature is useful when you need to print on the full width of Media that you have selected.




Note

- When you need to print on the full width of roll media, see "Enlarge/Reduce and Print Matching Width of Roll Paper."

 P.657
- When you do the procedure below to print on roll media, the print job will match the size of the output with the media selected with the **Paper Size** setting.

iPF8300S Enlarge/Reduce and Print

1. Display the Page Setup sheet.



2. Select the size of the media that you want to print in Paper Size.



Note

- This is not displayed when a checkmark is placed in Borderless Printing.
- This is not displayed when Fit Roll Paper Widthis set in Enlarged/Reduced Printing.
- 3. Select either **Portrait** or **Landscape** as the media orientation for the image in **Orientation**.



Note

- When you select **Portrait**, the image on the media prints as it appears on the screen.
- When you select Landscape, the image on the media prints rotated 90 degrees.
- 4. Click the Enlarged/Reduced Printing check box on.



Note

- This is not displayed when a checkmark is placed in **Borderless Printing**.
- 5. Select Fit Paper Size.
- **6.** Click the **Print** button.

The image prints filling the entire output media surface.


Enlarge/Reduce and Print Matching Width of Roll Paper

You can enlarge/reduce and print an image matching the width of the roll paper set in the printer. This is useful when you wish to print an image that covers the entire width of the roll paper.



Note

- Printing will not occur properly when a print roll is not set to the printer.
- 1. Display the Page Setup sheet.



- 2. Select Roll Paper in Paper Source.
- 3. Click the Roll Paper Options button.
- **4.** Set the roll paper options and click the **OK** button.



Note

- For more information about the **Roll Paper Options** dialog box, see "Roll Paper Options Dialog Box." →P.634
- Click the **Defaults** button to return all of the roll paper option settings to their defaults.
- 5. Select either **Portrait** or **Landscape** as the media orientation for the image in **Orientation**.



Note

- When you select **Portrait**, the image on the media prints as it appears on the screen.
- When you select **Landscape**, the image on the media prints rotated 90 degrees.
- **6.** Click the **Enlarged/Reduced Printing** check box on.



Note

• This is not displayed when a checkmark is placed in **Borderless Printing**.


- 7. Select Fit Roll Paper Width.
- **8.** Click the **Print** button.

The image prints covering the entire width of the roll paper.

Specify Scaling, Enlarge/Reduce and Print

You can specify scaling to enlarge/reduce an image and print. This is useful when you wish to print an image at a specific size.

1. Display the Page Setup sheet.



2. Select the size of the media that you want to print in Paper Size.



Note

- This is not displayed when a checkmark is placed in **Borderless Printing**.
- Fit Roll Paper Widthis set in Enlarged/Reduced Printing.
- 3. Select either **Portrait** or **Landscape** as the media orientation for the image in **Orientation**.



Note

- When you select **Portrait**, the image on the media prints as it appears on the screen.
- When you select **Landscape**, the image on the media prints rotated 90 degrees.
- 4. Click the Enlarged/Reduced Printing check box on.



Note

• This is not displayed when a checkmark is placed in **Borderless Printing**.

5. Select Scaling and input the scaling factor or drag the four corners of the image in the Preview display.



Note

- You can specify scaling rate in intervals of 0.01%.
- You can specify a range between 5.00-600.00%.
- The size of the width and height proportionally grow when the image is enlarged/reduced.
- 6. Either drag the image on the **Print Area Layout** preview, or set the print position **Layout**.
- 7. Click the **Print** button.

Printing begins at the set scaling rate.


Print with No Borders

You can use the borderless printing function to print without margins surrounding the image.



Note

- With some media borderless printing can be performed only between two edges.
- To use the borderless printing function, the specified media must be set to the printer.
- 1. Display the Page Setup sheet.




- 2. Select Roll Paper in Paper Source.
- **3.** Click the **Borderless Printing** check box on.



Note

• Select the width for roll paper set in the printer in Roll Paper Width in the Specify Roll Paper Width dialog box, and click OK.

iPF8300S Print with No Borders




4. Click the **Print** button.

Borderless printing begins.

Customize Media Settings

You can customize media settings.

1. Display the Main sheet.



2. Select the media type that you wish to customize in Media Type.



Note

- Always select media type that is actually set in the printer. When the media you chose is different from the media set in the printer, you may not receive the desired print results.
- 3. Click the Advanced Settings button.
- **4.** Perform the settings in the Paper Detailed Settings Dialog Box →P.630 and click the **OK** button.

•

Utilize Print History

When you perform various settings and print in Print Plug-In, those settings are saved as print history. Also, you can export and import as files. You can store often-used print history under a specified name in print preferences.



Note

• You can save up to 200 print history items. All items over 200 are deleted in chronological order.


You can do the following things using print history.

- Confirm Print History Details →P.661
- Apply Print History to an Image →P.662
- Store Print History to Print Preferences →P.663
- Delete Print History →P.665
- Export Print History from Print Preferences →P.667
- Import Print History to Print Preferences →P.668
- Delete Print History from Print Preferences →P.670
- Set Information to Print with Image →P.672

Confirm Print History Details

You can confirm the print history details.

1. Display Print History sheet.




2. Click the **Details** button.



Note

Select the print history you wish to check the details of, from either **Print History** or **Favorites** in the **Print History Details** dialog box.

iPF8300S Utilize Print History



3. Check the print history details in **Settings**, and click the **OK** button.




Note

• You can display the print history details by switching the sheets.

Apply Print History to an Image

You can use previous print history, and apply it to an image.

1. Display the **Print History** sheet.



- 2. If required, check the print history details. (See "Confirm Print History Details.") P.661
- 3. Select the print history you wish to apply from **Print History and Favorites**, and click the **Apply** button.


Store Print History to Print Preferences

You can store often-used print history to print preferences. Not only can you store the print history stored under a different name in print preferences, you can also find it with ease.



Note


- You can store up to 200 print history items to print preferences.
- 1. Display the **Print History** sheet.




- 2. Click the **Details** button.
- 3. Select the print history you wish to store in print preferences from **Print History** in the **Print History Details** dialog box, and check the print history details in **Settings**.




4. Select the print history you wish to store in print preferences from **Print History** and click the button



5. In the Add Favorites dialog box input the name of the print history in Name, input a comment in Comment, and click the OK button.



6. Click the **OK** button to close the **Print History Details** dialog box.



Delete Print History


You can delete print history.



Important

• Be aware that you cannot undo deletions of print history.


1. Display the **Print History** sheet.



2. Click the **Details** button.

iPF8300S Delete Print History

3. Select the print history you wish to delete from **Print History** in the **Print History Details** dialog box, and click the **Delete** button.



4. Click the OK button.



5. Click the **OK**button to close the **Print History Details** dialog box.




666

Delete Print History iPF8300S


Export Print History from Print Preferences

You can export print history stored in print preferences as a file.


1. Display the **Print History** sheet.



- 2. Click the **Details** button.
- 3. Select the print history you wish to export from Favorites in the Print History Details dialog box, and click the Export button.



4. Input the name of the print history in Save As in the Save dialog box, and click the Save button.




The print history is exported under the specified file name.

5. Click the **OK** button to close the **Print History Details** dialog box.

Import Print History to Print Preferences

You can import print history in file format and store it to print preferences.

1. Display the **Print History** sheet.




2. Click the **Details** button.

3. Click the Import button in the Print History Details dialog box.



4. Select the print history you wish to import in the **Open** dialog box, and click the **Open** button.




The print history is imported.



Note

- The print history file name suffix is *.pjb/*.pjb2.
- You cannot import a print history file exported from a different OS in Print Plug-In.
- You cannot import a print history file exported from a different printer in Print Plug-In.


5. Click the **OK** button to close the **Print History Details** dialog box.



Delete Print History from Print Preferences


You can delete print history store to print preferences. You cannot store more than 200 print history items in print preferences.

1. Display the **Print History** sheet.



2. Click the **Details** button.

3. Select the print history you wish to delete from Favorites in the Print History Details dialog box, and click the Delete button.



4. Click the **OK** button.



5. Click the **OK** button to close the **Print History Details** dialog box.




Set Information to Print with Image

You can print information with an image that is related, such as the file name and the time and date.



Note

- When you use the borderless printing function to print, the information will not be printed. (See "Print with No Borders.") →P.659
- When the printed information is too long as does not fit on the media, a break will appear in the printed information
- The information may print on the image data with some media sizes, enlargement rates and print position values.
- When **Keep Media Size** is set to **On** on the printer, a portion of bottom of the print data is not printed.
- 1. Display the **Print History** sheet.




- 2. Click the Print Information check box on.
- 3. Select the position where you wish to print the information in Information Print Position.
- **4.** Click the information check box you wish to print on.
- 5. When you wish to edit the comment, click the **Edit Comment** button.




Note

• When you do not wish to edit the comment, move to step 7.

6. Input the comment in the **Edit Comment** dialog box, and click **OK** button.



7. Click the **Print** button.




Comments are printed with images.

Printmonitor

| The Features of imagePROGRAF Printmonitor | 674 |
|--|-----|
| Job Management Using imagePROGRAF Printmonitor | 675 |

The Features of imagePROGRAF Printmonitor

imagePROGRAF Printmonitor is a utility for checking the printer status and managing print jobs.



- Printer status can be checked in real time on a computer monitor.
- You can check the status of print jobs, cancel jobs, and manage them as needed.
- If a printer error occurs, you can investigate the corrective action immediately.
- You can also set up automatic email notification of any printer problems or errors to email addresses you designate in advance.
- You can check the status of the hard disk and the documents saved on the hard disk.




Note

- If the status of the desired printer is not shown in imagePROGRAF Printmonitor, select the printer again as follows.
- 1. Make sure the printer is on and connected to the network or to a local port.
- **2.** In the **Printer** menu, select the name of the desired printer. After the printer is detected, the printer status is shown.
- **3.** If information about the printer is not shown in step 2, choose **Search Printer** in the **Printer** menu. Printer names listed in the **Printer** menu are updated with the printers that are now detected.
- **4.** In the **Printer** menu, select the name of the desired printer. After the printer is detected, the printer status is shown.

Job Management Using imagePROGRAF Printmonitor

You can use the **Driver** Panel in imagePROGRAF Printmonitor for operations such as pausing and canceling print jobs.



Preempting Other Jobs

If you select a print job and click the button, the selected job is printed ahead of the job that currently precedes it in the print queue.

Pausing/Resuming Print Jobs

Selecting a print job and clicking the button pauses printing of the selected job.

To resume printing of a paused print job, select the print job and click the button.



Note

• Once all the print data for a print job has been sent to the printer, the job can no longer be paused/resumed.

· Canceling Print Jobs

Selecting a print job and clicking the button cancels printing of the selected job.



Note

• You cannot cancel other users' print jobs.

• Printing Held Jobs

Printing of the job with a **Status** of **Holding** is paused because the paper specified by the driver does not match the paper currently loaded in the printer.

Use the procedure below to print the held job.

- 1. Select the held job and click the **Replace Paper** button.
- 2. Replace the paper in the printer with the correct paper.



Note

• To continue printing without changing the paper in the printer, select the held job and click **Continue to print** button.

Media Configuration Tool

| The Features of Media Configuration Tool | 677 |
|---|-----|
| Operating Environment | 678 |
| Procedures for Installing | 678 |
| Procedures for Uninstalling | |
| Starting the Media Configuration Tool | |
| Media Configuration Tool main window | 685 |
| Editing Media Type Information | 686 |
| Adding Media Types | 687 |
| Changing Media Names | |
| Deleting Media Types You Have Added | 692 |
| Switching Media Types Display Show/Hide | 694 |
| Changing the Display Order of Media Types | |
| Updating Media Types | |
| Using Paper Other Than Genuine Paper/Feed Confirmed Paper | 700 |
| Compatible Paper | |
| Add Custom Paper | |
| Delete Custom Paper | |
| Edit Custom Paper | |
| Export Custom Media Information | |
| Import Custom Media Information | |
| Warnings | |

The Features of Media Configuration Tool

The Media Configuration Tool offers the following features.

- Enables information about additional media (types of paper) supported by the printer to be added to the printer control panel and to the printer driver, through the use of relevant media information files.
- You can rearrange lists of the types of paper on the printer control panel and in printer driver dialog boxes and rename them, in addition to other functions.
- You can add custom paper (paper that is not Canon genuine paper or Canon feed confirmed paper) to the printer control panel and printer driver.



Important

- Normally, the Media Configuration Tool is installed and the media information is configured when you install the printer driver from the User Software CD-ROM. Use this software if you want to add new media information or edit existing media information.
- Administration of paper information using the Media Configuration Tool should be performed by the printer administrator.
- Canon offers absolutely no guarantees regarding the print quality or paper feed properties of customer paper (paper that is not Canon genuine paper or Canon output confirmed paper).
- The paper feed properties cannot be guaranteed if **Add Custom Paper** is used on Canon genuine paper in the Media Configuration Tool.
- The print quality and paper feed properties cannot be guaranteed if **Add Custom Paper** is used on Canon feed confirmed paper in the Media Configuration Tool. Furthermore, Canon does not guarantee the print quality of Canon feed confirmed paper.



Note

• Canon genuine paper and Canon feed confirmed paper are detailed in the Paper Reference Guide. Any other paper is called custom paper.

Operating Environment

You can use Media Configuration Tool in the following environments.

- Compatible Operating System Mac OS X (10.4.11 to 10.6)
- Software that requires installation imagePROGRAF Printer Driver

Procedures for Installing

Start the installer in the new version of Media Configuration Tool, and follow procedures below to install the Media Configuration Tool.



Important

- If the printer driver is installed from the User Software CD-ROM, the Media Configuration Tool is also installed and the media information is also configured. Therefore, the following procedure does not normally need to be performed. To install the Media Configuration Tool without using the User Software CD-ROM, such as when you have downloaded a new version of the Media Configuration Tool from the Canon website, use the following procedure.
- 1. Double click the MCT Installer iPFxxxx for X icon to start the Media Configuration Tool installer.




iPFxxxx MCT Installer X




Note


- The **iPFxxxx** in the icon will be the printer name in use.
- 2. Input the administrator name and password, and click the **OK** button.



3. The next screen presents selections for the country or area where the printer is used. Select a country or territory then click the **OK** button.



4. The **License** is displayed.
After you have read Canon Software License Agreement, click the **Continue** button.




5. Click the **Agree** button.



iPF8300S Procedures for Installing

6. Select Easy Install then click the Install button.



7. Click the **Continue** button to quit another application.



8. When the following message is displayed, click the **Quit** button.



680

Procedures for Installing iPF8300S

The installation of Media Configuration Tool is complete.



Note

- When the installation is completed properly, the **Media Configuration Tool** folder is saved in the following folder.
 - Applications > Canon Utilities > iPFxxxx Media Configuration Tool
- The iPFxxxx in the folder above will be the printer name in use.

Procedures for Uninstalling

1. Double click the MCT Installer iPFxxxx for X icon to start the Media Configuration Tool installer.




iPFxxxx MCT Installer X




Note


- The **iPFxxxx** in the icon will be the printer name in use.
- 2. Input the administrator name and password, and click the **OK** button.



3. The next screen presents selections for the country or area where the printer is used. Select a country or territory then click the **OK** button.




4. The **License** is displayed.
After you have read Canon Software License Agreement, click the **Continue** button.




5. Click the **Agree** button.



6. Select Uninstall.



7. Click the Uninstall button.



8. Press the **Continue** button when another application is running.



9. When the following message is displayed, click the **Quit** button.




Media Configuration Tool has been uninstalled.

Starting the Media Configuration Tool

Follow the procedure below to start the Media Configuration Tool.

From the **Applications** menu > **Canon Utilities** > **iPFxxxx Media Configuration Tool** > **MCTxxxx.app**. Media Configuration Tool main window is displayed.






Note

• If a compatible printer driver is not installed, the Media Configuration Tool will not start. If you attempt to start the Media Configuration Tool when a printer driver is not installed, the warning message below is displayed.



Media Configuration Tool main window

The explanation below is on the Media Configuration Tool main window.





Note

• For the step to open the Media Configuration Tool main window, see "Starting the Media Configuration Tool." →P.684

• Add Genuine Paper button

When this button is clicked, the **Edit Media Types** dialog box is displayed, which allows you to add media information files released by Canon to the printer control panel and printer driver. You can also change names, toggle between displaying and hiding, and delete added media types.

You can also change the display order of Canon genuine paper and custom paper.

Refer to Editing Media Type Information —P.686 for details on Add Genuine Paper.

• Add Custom Paper button

When this button is clicked, the **Add Custom Paper** dialog box is displayed, which allows you to added custom paper (paper that is not Canon genuine paper or Canon feed confirmed paper) to the printer control panel and printer driver.

Refer to Using Paper Other Than Genuine Paper/Feed Confirmed Paper —P.700 for details on Add Custom Paper.

Link to Support Information button


Opens **imagePROGRAF Support Information**. You can check information such as the latest information for the product and software version upgrade information.

Link to User Manual Button

Click this button to display the User's Guide. This function requires that the User's Guide be installed on your computer

Editing Media Type Information

Click the **Add Genuine Paper** button in the Media Configuration Tool main window to display the **Edit Media Types** dialog box.



This dialog box presents functions for the following tasks.

- Adding Media Types →P.687
- Changing Media Names →P.690
- Deleting Media Types You Have Added →P.692
- Switching Media Types Display Show/Hide →P.694
- Changing the Display Order of Media Types →P.696



686

Important

- When you update the media type information, perform the same update on all of the PCs that are using that printer.
- Adding, deleting, toggling display/non-display, and changing the paper name of a media type can only be performed for Canon genuine paper and feed confirmed paper. Refer to "Using Paper Other Than Genuine Paper/Feed Confirmed Paper P.700" for details on adding, editing, and deleting custom paper. Custom paper displays Custom as the Status in the Media Type list.
- To add media types, download the media information file (.amf file) in advance from the Canon website.



Note

• It may not be possible to deleting, showing/hiding, and changing the display order under some conditions.


Adding Media Types

Media information files (.amf files) released by Canon are registered in the printer control panel and printer driver.



Important

- Do not perform printing on the target printer while adding the media types.
- Reinstalling Media Configuration Tool after registering a media information file may delete the registered media information file. In this case, first download and install latest Media Configuration Tool, then download and register the required media information file.
- ${f 1.}$ Open the **Edit Media Types** dialog box, and then click the **Add** button.




iPF8300S Adding Media Types

2. The Add Media Type dialog box displays. Click the Browse button.




3. Select the folder that contains the media information files (.amf files), and then click the **Open** button.



688


Adding Media Types iPF8300S

4. The names of media information files in the folder you selected in the Open dialog box are displayed under Media Information File in the Add Media Type dialog box. Select the check boxes of paper to add and click the OK button.



Important

- If **Master Media Information File** is displayed as the **Type** of the **Media Information File**, the media type display order and media type display/non-display settings are initialized. Reconfigure these after added the master media information file.
- **5.** Click **OK** when the confirmation message is displayed.
- **6.** In the **Edit Media Types** dialog box, click the **Update** button.



Adding Media Types

The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." —P.698




Importan^{*}

• Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.


Changing Media Names

1. Open the Edit Media Types dialog box.



Changing Media Names iPF8300S

2. In the **Media Type** list, select the name to change. Click the **Rename** button.



3. The Rename Media dialog box is displayed.
Edit the names in Name in Printer Driver and Name on Control Panel and click the OK button.




Note

• To restore the original names, click the **Restore** button.

iPF8300S Changing Media Names

4. In the **Edit Media Types** dialog box, click the **Update** button.



The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." —P.698




Important


• Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.

Deleting Media Types You Have Added

1. Open the **Edit Media Types** dialog box.




2. In the Media Type list, select the name of the media to delete. Click the Delete button.





- Note
- Only paper for which **Status** in the **Media Type** is **Add** can be deleted.
- 3. In the Edit Media Types dialog box, click the Update button.



The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." —P.698




Important

• Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.


Switching Media Types Display Show/Hide

1. Open the **Edit Media Types** dialog box.



2. In the Media Type list, select the name of the media to switch off or on for display. Click the Show/Hide button.


The selected paper is alternately shown or hidden.





Note

- The names of media switched for non-display appear grayed out in the **Media Type** list.
- Each time you click the **Show/Hide** button, the display mode cycles from showing both the printer driver and printer panel, to hiding both the printer driver and printer panel, and then to showing only the printer panel.
- 3. In the Edit Media Types dialog box, click the Update button.



The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." —P.698




Important

• Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.


Changing the Display Order of Media Types

1. Open the Edit Media Types dialog box.




2. Select the paper in the **Media Type** list for which to change the display order, and then click the buttons to move the item (or item).

The selected item moves one line up or down for every button click.



3. In the Edit Media Types dialog box, click the Update button.



The **Update Media Types** wizard is started at this point. For details on the procedure to update paper information using the **Update Media Types** wizard, see "Updating Media Types." —P.698



Important

• Be sure to click the Update button. If you do not, your changes will not be applied to the printer and printer driver.

Updating Media Types

Clicking the **Update** button on the **Edit Media Types** dialog box opens the **Update Media Types** wizard. You can use this wizard to apply new information about print media in the printer and in the printer driver.

The procedures for updating the media information with the **Update Media Types** wizard are as follows.




Important

- When you update the media type information, perform the same update on all of the PCs that are using that printer.
- 1. Confirm the printer, where media type information is to be updated, to be displayed in **Printer** in the **Update Media Types Select Printer** dialog box, and then click the **Next** button.




2. Communication with the printer starts and the following dialog box is displayed.





Important

- Do not attempt to print or turn the printer off while the program is communicating with the printer.
- When the program cannot communicate with the printer, the following warning message is displayed.



3. When the program has finished communicating with the printer, the screen moves to display **Update Media Types** - **Confirm Update**. Confirm the information received from the printer.

To update click the **Execute** button.





Important

- When setting a data to the printer that differs from the data to be updated, the selected media information file is updated. When you would like to remain the data that is set to the printer, click the **Cancel** button.
- **4.** Communication with the printer starts and the following dialog box is displayed.

Communicating

Communicating with the printer.

Do not perform any operations until complete.

iPF8300S Updating Media Types

Important

- Do not attempt to print or turn the printer off while the program is communicating with the printer.
- When the program cannot communicate with the printer, the following warning message is displayed.





Note

If the authentication screen is displayed, input the administrator name and passowrd and click the OK button.

5. Click the **OK** button.





Note

• To apply the same updates to other printers of the same model, click the **Add Genuine Paper** button in the main window to open the **Edit Media Types** dialog box and then click the **Update** button. Select the printer that you want to update in Step 1, and update the media information by following the **Update Media Types** wizard.

Using Paper Other Than Genuine Paper/Feed Confirmed Paper

When the **Add Custom Paper** button is clicked in the Media Configuration Tool main window, the **Add Custom Paper** dialog box is displayed.


Adding custom paper to the printer control panel and printer driver is performed from this screen.



Note

• Custom paper is paper other than Canon genuine paper and feed confirmed paper (paper that is detailed in the Paper Reference Guide).

1



The following operations can be performed from this screen.

- Add Custom Paper →P.702
- Edit Custom Paper →P.713
- Delete Custom Paper →P.711
- Export Custom Media Information →P.713
- Import Custom Media Information →P.715



Important

- When adding, editing, or deleting custom paper, make the same changes on all of the other PCs that use the target printer. The changes can be made easily by creating a Custom Media Information File (.am1 file) using the custom paper export function and importing the file on the other PCs.
- When using custom paper in another printer, always add the custom paper to that printer before use.
- Canon genuine paper and feed confirmed paper cannot be changed from this dialog box. Refer to "Editing Media Type Information P.686".
- Changing the display order of media types displayed in the printer control panel and printer driver is performed from the Edit Media Types dialog box regardless of whether it is Canon genuine paper or custom paper. Refer to "Editing Media Type Information —P.686".

Compatible Paper

Paper specifications

Refer to "Specifications" and "Paper" for specifications such as thickness and size of paper that can be added as custom paper (See "Specifications.") —P.1123

Notes on the operating environment

In low humidity environments (below 40%), your printer may develop the following problems.

• Paper becomes curled or wrinkled.

iPF8300S Compatible Paper

- Paper and the printhead are more likely to touch each other, resulting in a scratched print surface or damaged printhead.
- The cut printed matter sticks to the printer and will not fall down (film media).
- Paper sticks to the printer, making its transfer impossible and preventing its normal ejection (film media).
- Uneven printing (film media)

In high humidity environments (over 60%), your printer may develop the following problems.

- Printed matter will not dry.
- · Wavy paper surface
- Cut edges are ragged (fabric media).
- Margins remain due to borderless printing.



Important

• Canon offers absolutely no guarantees regarding the print quality or paper feed properties of customer paper (paper that is not Canon genuine paper or Canon feed confirmed paper).

Add Custom Paper

In order to add new custom paper to the printer control panel and printer driver, first select the media type to use as the basis from among the Canon genuine paper and feed confirmed paper. Add this as custom paper after making various changes to the standard paper as necessary.



Important

- Do not execute printing on the target printer while adding custom paper.
- When adding custom paper, check the specifications of paper that can be added using "Compatible Paper P.701".
- Custom paper added using the add custom paper function can only be used by the printer driver. It cannot be used by other software.
- ${f 1}$. Open the ${f Add}$ Custom Paper dialog box and click the ${f Add}$ button.



702

Add Custom Paper iPF8300S

2. Check that the printer on which you are updating the media information is displayed in **Printer** in the **Update Media Types - Select Printer** dialog box and click the **Next** button.



3. The Step 1: Select the standard paper dialog box is displayed. In Paper Category, select the category of media type to use as the basis of the custom paper you are adding.



Important

• Select the category that you think is the closest to the custom paper you are adding.

| iPFXXXX Step 1: Step 1] Select the media type to use as the base for t | Select the standard paper the custom paper to add. | |
|--|---|---|
| Media Type: Paper Category Plain Paper Coated Paper Photo / Art / Proofing Paper (Matte) Photo / Art / Proofing Paper (Glossy) Newsprint for Proofing Sign Paper Fabric Banner CAD Paper POP Board / Cardboard Other All | Media Type Name Plain Paper Plain Paper HQ Plain Paper HG PremPlainPpr 80 Plain Paper – General | Black ink Photo Photo Photo Photo Matte |
| If you do not know the media type, click the | e Assist button on the right. | Assist Next > |

iPF8300S Add Custom Paper



Note

- If you do not know which media type to use as the basis of the custom paper, click the **Assist** button to open the **Media Type Selection Assistance** dialog box, and then set either the **Weight (grammage)** or the **Thickness**. The Media Configuration Tool automatically selects the appropriate paper from the selected paper category. Alternatively, select the media type called **General** from among the displayed **Media Type Name**.
- Depending on the selected category, there might not be a media type called **General**.
- Depending on the selected category, the **Assist** button may be disabled.
- 5. The Step 2: Set the custom paper name dialog box is displayed.

 Enter an arbitrary name to display in the printer control panel and printer driver, and then click the Next button.





Note

• Paper Name (English) is used in keeping track of the amount of roll paper left, in status print, etc.

6. Load the custom paper in the printer and then click the **OK** button.






Important

• Do not load paper that is curled or that has already been printed on.

704


Add Custom Paper iPF8300S

7. The Step 3: Paper Source Settings dialog box is displayed. Select the paper source where the custom paper is loaded and then click the OK button.



8. The Step 4: Paper feed adjustment dialog box is displayed. Click the Execute button to execute paper feed adjustment.

The adjustment pattern is printed, and the paper feed is automatically adjusted based on the printing result. Once the paper feed adjustment is complete, click the **Next** button.





Important


- Check that there is no paper left on the ejection guide.
- If **Paper Feed Adjustment** is not executed, horizontal stripes with different color tones may appear in the printed material. Paper feed adjustment does not need to be executed more than once. Execute paper feed adjustment only once each time you add a custom paper.
- **9.** The **Roll Paper Settings** dialog box is displayed.



Note

• If a paper source other than **Roll Paper** is selected in the **Step 3: Paper Source Settings** dialog box, this screen is not displayed.

iPF8300S Add Custom Paper



Configure the following settings as necessary, and then click the **Next** button.

| Setting | Details |
|-----------------------------------|--|
| Automatic Cutting Settings | Configures the method for cutting roll paper when it is ejected after printing. |
| | Automatic Cut :Roll paper is automatically cut by the cutter unit. |
| | • Eject Cut: When the Cut key is pressed on the printer control panel, the roll paper is cut by the cutter unit. Select this if you do not want the printed material to drop immediately after printing, such as to wait for the ink to dry. |
| | • User Cut :Cutting is not performed by the cutter unit. Cut the roll paper using scissors after each sheet. Select this for paper that cannot be cut by the cutter unit. |
| Drying Time | Specify the time that the printer waits for ink to dry, as needed. |
| | Off :Ejects immediately after printing finishes. |
| | • 30 sec./1 min./3 min./5 min./10 min./30 min./60 min. :Ejects after the specified time has elapsed after printing finishes. |
| Borderless Printing | Configures whether or not to permit borderless printing. |
| | Permit : Borderless printing is permitted. |
| | Deny : Borderless printing is denied. |

Add Custom Paper iPF8300S




Important

- Depending on the paper, there are types that cannot be cut by the cutter unit, and types that speed deterioration of the blade and cause damage to the cutter. For thick paper, hard paper, etc. do not use the cutter unit, and instead cut the roll paper using scissors, etc. after printing. In this case, select **User Cut** as the **Automatic Cutting Settings**.
- If borderless printing is performed on paper where the ink drying is poor, the cutter unit may leave scratches where it touches the printed surface, or may not cut correctly. In this kind of situation, configure the amount of time to wait for the ink to dry after printing using **Drying Time**. Alternatively, if the paper cannot be cut well by the cutter, set the **Automatic Cutting Settings** to **User Cut** and cut the roll paper using scissors, etc.
- Paper where borderless printing can be performed is limited by the media type and roll paper width. Refer to "Compatible Paper >P.701".
- For custom paper where there is a need to set the **Automatic Cutting Settings** to **User Cut**, set the **Borderless Printing** to **Deny**.

10. The Step 5: Configure the amount of ink used dialog box is displayed.

The upper limit on the amount of ink used to print to the custom paper is set on this screen by selecting from among several levels.

First, click the **Test Print** button to perform a test print of each level.





Important

• If **Newsprint for Proofing** was selected as the standard paper for the custom paper, you cannot perform the test print or configure the maximum ink usage.

iPF8300S Add Custom Paper

11. The **Test Print Settings** dialog box is displayed.

Select the print priority and print quality of the test print using **Print Priority** and **Print Quality**. Set the level to test print using **Maximum ink usage** and the image to use using **Image used in test print**, and then click the **Start Print** button.

| Test Print Settings | | |
|---|--|--|
| priority, and print qual Note: For the print prior | (multiple can be selected), image to use, print lity in the test print. ority and print quality, select setting values that nen actually printing on this custom paper. | |
| Print Priority: | Office Document 💠 | |
| Print Quality: | Standard(600dpi) | |
| Maximum ink usage ✓ Canon Standard ✓ Low ✓ Medium-low ✓ Medium ✓ Medium-high ✓ High | Paper | |
| Image used in test print | | |
| • Standard Image User Image | Browse | |
| | Cancel Start Print | |

12. Determine and set the ink level that is thought to give the best visual test print results with no bleeding or scraping of ink

| Maximum ink usage Selection | |
|---|--|
| Select the level where the printing result was the best. Note: If there are scratches in the printing results, change the vacuum strength or head height settings on the next | |
| Level | |
| Canon Standard Paper | |
| OLow | |
| ○ Medium-low | |
| ○ Medium | |
| ○ Medium-high | |
| ○ High | |
| | |
| Cancel OK | |

Add Custom Paper iPF8300S




Note

- Select the optimal ink level by referring to the help.
- If you cannot obtain sufficiently high quality printing no matter which maximum ink usage level you select, use the **Step 1: Select the standard paper** dialog box to change the paper that is the basis of the custom paper to another paper.



Important

- Because this settings imposes an upper limit on the amount of ink used during printing, the printing result might not change even if the level is changed depending on the image.
- The color tone cannot be configured using the Media Configuration Tool. Although the color tone
 may change when the maximum ink usage is changed, at this point you should select the optimal level by only focusing on bleeding and scraping of ink. If the color tone needs to be adjusted, provide an
 ICC color profile that matches the paper you are using, and select that ICC color profile in your software.
- Depending on the maximum ink usage setting, some of the print qualities in the printer driver may become unselectable.
- 13. Configure **Head Height** and **Vacuum Strength** as required and click the **Next** button. Usually, these do not need to be set.






Important

- If you set the **Head Height** lower than the automatically set height in parentheses (), check that the printhead does not rub against the paper. (If the printhead rubs against the paper, there will be scratches in the printing results.) If the printhead rubs against the paper, this can cause damage to the printhead.
- If you change the **Vacuum Strength**, check that the printhead is not rubbing against the paper. (If the printhead rubs against the paper, there will be scratches in the printing results.) If the printhead rubs against the paper, this can cause damage to the printhead.
- For details on the **Head Height** and **Vacuum Strength**, refer to the help.

iPF8300S Add Custom Paper

14. The Step 6: Confirm the settings dialog box is displayed.

Configure the settings of the custom paper, and then click the Next button.



15. The Confirm Update dialog box is displayed.

Confirm the updates and then click the Execute button.



710



Note

If the authentication screen is displayed, input the administrator name and passowrd and click the OK button.

Add Custom Paper iPF8300S

The custom paper is added to the control panel of the printer and to the printer driver of the PC you are using.



Important

• If you have added custom paper with the **POP Board** / **Cardboard** category as the Standard Paper, remove the loaded custom paper from the printer.




Note

• When the custom paper is correctly added to the printer driver, the name of the added custom paper is displayed in the **Edit Media Types** dialog box that is opened by **Add Genuine Paper** in the Media Configuration Tool window.

Delete Custom Paper

You can delete custom paper that you have already added from printer control panel and from the printer driver of the PC you are using.

- ${f 1.}$ Open the **Add Custom Paper** dialog box.
- 2. Select the paper you want to delete from the Added Custom Paper list and then click the Delete button.




iPF8300S Delete Custom Paper

3. Select the custom paper you want to delete, and then click the **Next** button.



4. The **Confirm Update** dialog box is displayed. Confirm the updates and then click the **Execute** button.



712



• If the authentication screen is displayed, input the administrator name and passowrd and click the **OK** button.


The custom paper is deleted from the control panel of the printer and from the printer driver of the PC you are using.

Delete Custom Paper iPF8300S

Edit Custom Paper

You can change the settings of custom paper you have already added.

- 1. Open the Add Custom Paper dialog box.
- 2. Select the paper you want to edit from the Added Custom Paper list and then click the Edit button.



3. The **Update Media Types - Select Printer** dialog box is displayed. Follow the on-screen directions and change the settings as required.



Note

Refer to Steps 5 to 15 of the "Add Custom Paper →P.702" for details on how to configure each setting.

Export Custom Media Information

You can export to file and save media information about custom paper that you have added.

The saved Custom Media Information File can be used by importing it into another printer or P

The saved Custom Media Information File can be used by importing it into another printer or PC. Refer to "Import Custom Media Information".

—P.715 " for details on "importing custom media information".


 ${f 1}_{f \cdot}$ Open the **Add Custom Paper** dialog box.

iPF8300S Edit Custom Paper

2. Select the paper you want to export to media information file from the Added Custom Paper list and then click the Export button.



3. Specify the location to save the Custom Media Information File.




714

A Custom Media Information File (.am1 file) is saved.

Import Custom Media Information

You can import a Custom Media Information File that has been saved in a folder, and add the file to the printer control panel and to the printer driver of the PC you are using.

- 1. Open the Add Custom Paper dialog box.
- 2. Click the Import button.



3. Select the printer to add the custom paper to.






Note

- Double-click Custom Media Information File to start the Media Configuration Tool and display this screen.
- **4.** Select the Custom Media Information File (.am1 file) to import.



5. The Confirm Update dialog box opens. Click the Execute button.





Note

• If the authentication screen is displayed, input the administrator name and passowrd and click the **OK** button.

The custom paper is added to the control panel of the printer and to the printer driver of the PC you are using.



Note

• When the custom paper is correctly added to the printer driver, the name of the added custom paper is displayed in the **Edit Media Types** dialog box that is opened by **Add Genuine Paper** in the Media Configuration Tool window.

Warnings

Take note of the following warnings when added custom paper other than Canon genuine paper and feed confirmed paper to the printer driver and the printer itself.

About the Cutter

• Depending on the paper, there are types that cannot be cut by the cutter unit, and types that speed deterioration of the blade and cause damage to the cutter. For thick paper, hard paper, etc. do not use the cutter unit, and instead cut the roll paper using scissors, etc. after printing. In this case, select **User Cut** as the **Automatic Cutting Settings** in the **Roll Paper Settings** dialog box.



Note

- If the cutter is damaged, contact your Canon dealer for assistance.
- Refer to "Specifying the Cutting Method for Rolls" for details on the methods for cutting roll paper. (See "Specifying the Cutting Method for Rolls.") —P.802

About the Printhead

- If the printhead rubs against the paper during printing, this may cause damage to the printhead. If the printhead is rubbing against the paper, configure the **Vacuum Strength** in the **Step 5: Configure the amount of ink used** dialog box as follows.
 - For paper-based media such as Heavyweight Coated Paper: Set to Strong or Strongest
 - For film-based media such as CAD Tracing Paper: Set to Standard, Strong, or Strongest
 - For thin paper of thickness 0.1mm or less: Set to Weakest



Note

- If the printhead still rubs even after changing the Vacuum Strength, set the Head Height to be higher in the Step 5: Configure the amount of ink used dialog box.
- Refer to "Paper rubs against the Printhead" for details on how to handle the printhead rubbing against the paper. (See "Paper rubs against the printhead.") —P.1072

About Borderless Printing

• When performing borderless printing on paper where the ink does not dry well, the cutter unit may leave scratches where it touches the printed surface, or may not cut correctly. In this kind of situation, configure the amount of time to wait for the ink to dry after printing using **Drying Time** in the **Roll Paper Settings** dialog box.

Alternatively, if the paper cannot be cut well by the cutter, set the **Automatic Cutting Settings** to **User Cut** in the **Roll Paper Settings** dialog box, and cut the roll paper using scissors, etc.

About the Print Quality

If the edges of images are blurry, set the Vacuum Strength to be weaker in the Step 5: Configure the amount of ink
used dialog box.

iPF8300S Warnings

- If lines are warped or scratched, set the **Head Height** to be lower in the **Step 5: Configure the amount of ink used** dialog box.
- If the amount of ink used is too much, wrinkles may appear and the ink may bleed in the printed material. Furthermore, if the amount of ink used is too little, color production may be poor and lines may become scratched. In this kind of situation, change the amount of ink used in the Step 5: Configure the amount of ink used dialog box.
- If horizontal bands with different color tone appear in the printed material, execute **Paper Feed Adjustment** in the **Step 4: Paper feed adjustment** dialog box. If you have already executed **Paper Feed Adjustment**, execute **Adj. Fine Feed** from the printer control panel and fine tune the amount of paper feed.



Note

- Refer to "Fine tuning the amount of paper feed (paper feed fine adjustment)" for details on **Adj. Fine**Feed. (See "Fine-Tuning the Paper Feed Amount (Adj. Fine Feed).") —P.861
- If horizontal bands appear even after executing **Adj. Fine Feed**, refer to "Banding in different colors occurs" in "Troubleshooting". (See "Banding in different colors occurs.") —P.1075
- If you cannot obtain sufficiently high print quality, change the maximum ink usage, or change the media type used as the basis for the custom paper in the **Step 1: Select the standard paper** dialog box.
- If there is no luster in printed material, set the paper used as the basis for the custom paper to a paper that uses photo ink as the Black ink.
 - The types of Black ink used are displayed on the right side of each media type in the **Step 1: Select the standard paper** dialog box.



Note

• Refer to "Problems with the printing quality" for details on problems with printing quality. (Refer to "Problems with the printing quality —P.1071")


About the Color Tone

- The color tone cannot be configured using the Media Configuration Tool. If the color tone needs to be adjusted, provide an ICC color profile that matches the paper you are using, and select that ICC color profile in your software.
- Custom paper cannot be used with the ambient light adjustment function or Monitor Matching in Color-Matching Method.

Warnings iPF8300S

Print Job Operations

| Basic Print Job Operations | 720 |
|-------------------------------|-----|
| | |
| Advanced Print Job Operations | 747 |




Basic Print Job Operations

| Using the Printer Hard Disk | 720 |
|---|-----|
| Saving Print Jobs on the Printer Hard Disk | |
| Managing Pending Jobs (Printing or Deleting Jobs on Hold) | |
| Printing Saved Jobs | 730 |
| Deleting Saved Jobs | 737 |
| Moving Saved Jobs | 741 |

Using the Printer Hard Disk

The printer can save print jobs on the built-in hard disk.

Using print jobs stored on the printer enables you to print the jobs again as needed without using a computer.



Save print jobs

Saving print jobs offers the following benefits.

- Save the time spent using a computer
 When you send a print job to the printer, you can save it on the printer after printing or simply save it on the printer
 without printing it yet. Saved print jobs can be printed in the required quantity later without the need to use a computer
 again.
- Simplify reprinting, if any errors occur
 If errors occur in the middle of printing (as when paper runs out), you can resume printing after clearing the error without resending the print job from a computer.
- Streamline printing work
 Without using a computer, you can select print jobs and print in the desired quantity. You can also select multiple print jobs to print during the same period. This enables unattended operation at night, for example.

Output Method

To save print jobs on the printer's hard disk, choose **Output Method** (in Windows) or **Send job to** (in Mac OS X).

- Print
 - Save print jobs on the printer's hard disk after printing.
- Save in mail box


Save print jobs on the printer's hard disk.

• Print after reception is complete

This option is available in combination with **Print**. Print jobs are saved on the printer's hard disk before printing.

Storage destination

The storage area on the printer's hard disk is divided into a temporary storage area and a permanent storage area. The temporary storage area stores print jobs in the job queue or shared mailbox. The permanent storage area stores jobs in personal boxes.



• Job queue

The job queue refers to print jobs that are being processed by the printer (saved, received, prepared for processing, printed, deleted, or held). Up to 64 jobs can be stored in the temporary storage area.

When the job queue is full, additional jobs sent from a computer are treated as "standby" jobs, to be processed when possible.

However, if all queued jobs are simply being held, the oldest job is deleted and the print job sent from the computer is processed.

Shared mailbox

Jobs for which you have specified **Print** in **Output Method** (in Windows) or **Send job to** (in Mac OS X) are saved in the shared mailbox and classified as saved jobs.

There is one shared mailbox, numbered **00.** A password cannot be set for the shared mailbox.

Up to 100 print jobs can be saved here, but they will be deleted one after another starting with the oldest job in the following situations.

- If there are more than 100 jobs queued and saved in the shared mailbox combined
- If no more temporary storage space is available when jobs for which you have selected **Print** in **Output Method** (in Windows) or **Send job to** (in Mac OS X) are received
- If there is not enough space in the temporary or permanent storage area when jobs for which you have selected **Save in mail box** in **Output Method** (in Windows) or **Send job to** (in Mac OS X) are received

· Personal boxes


Jobs are classified as saved jobs and saved in personal boxes in the following situations.

- When a saved job stored in the shared mailbox is moved to a personal box
- When you have selected **Save in mail box** as the option in **Output Method** (in Windows) or **Send job to** (in Mac OS X)

There are 29 personal boxes, numbered **01** to **29.** You can specify a name and password for each personal box. Up to 100 print jobs can be saved in all personal boxes combined.

Saving Print Jobs on the Printer Hard Disk

To save print jobs on the printer's hard disk, configure the printer driver.





Note


- Printing from the following software also enables you to save print jobs on the printer's hard disk. Windows
 - Print Plug-In for Photoshop/Digital Photo Professional —P.307
 - Free Layout →P.261
 - Color imageRUNNER Enlargement Copy →P.292
 - Preview →P.248 Mac OS
 - Print Plug-In for Photoshop/Digital Photo Professional —P.609
 - Free Layout →P.550
 - Color imageRUNNER Enlargement Copy →P.584
 - Preview —P.519


 The document title will be "imagePROGRAF" when you print from imagePROGRAF Preview.

Configuring the Printer Driver in Windows

1. Access the Page Setup sheet.







- 3. Make your selection in Output Method.
 - Print

Save print jobs on the printer's hard disk after printing.

• Save in mail box

Save print jobs on the printer's hard disk.

If you choose Save in mail box, also specify the destination personal box in the Mail box list.

• Print after reception is complete

This option is available in combination with **Print**. Print jobs are saved on the printer's hard disk before printing.




Note

- Click **Acquire Mail Box Name** to display personal box names in the **Mail box** list, as acquired from the printer.
- **4.** In Name of data to be saved, specify how to name saved print jobs.
 - To use the file name, choose Use file name.
 - Otherwise choose Enter name and enter a name in Name.
- 5. Click **OK** to close the **Output Method** dialog box.


Configuring the printer driver in Mac OS

1. Access the **Additional Settings** pane.



- 2. Make your selection in Send job to.
 - **Print**Save print jobs on the printer's hard disk after printing.
 - Save in mail box
 Save print jobs on the printer's hard disk.

The **Destination** dialog box is displayed if you select **Save in mail box**. Here, specify the name and personal box number for saved print jobs.



- **1.** In **Document title**, enter a name to identify saved print jobs.
- 2. Select the personal box number in the Mail box list.
- **3.** Click **OK** to close the **Destination** dialog box.
- Print after reception is complete

This option is available in combination with **Print**. Print jobs are saved on the printer's hard disk before printing.


Managing the Job Queue (Deleting or Preempting Other Jobs)

Print jobs being processed by the printer are collectively called the job queue. You can delete or preempt jobs in the job queue as needed.


These operations are available from the Control Panel or in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.

• Delete

Note that only jobs that are not currently being deleted can be deleted from the job queue.



Preempting other jobs
 You can preempt other jobs by printing jobs that are currently being received or prepared for processing first.




Note

• For information on managing jobs being held, see "Managing Pending Jobs (Printing or Deleting Jobs on Hold)." →P.728

Using the Control Panel

1. On the **Tab Selection screen** of the Control Panel, press **◄** or **▶** to select the Job tab (....).






Note

- If the Tab Selection screen is not displayed, press the Menu button.
- 2. Press the **OK** button.
 The **Job Menu** is displayed.
- **3.** Manage the job queue as needed.
 - Deleting jobs
 - **1.** Press \triangle or ∇ to select **Print Job**, and then press the **OK** button.
 - 2. Press ▲ or ▼ to select the print job to delete, and then press the OK button.
 - **3.** Press \triangle or ∇ to select **Delete**, and then press the **OK** button.
 - Preempting other jobs
 - **1.** Press \triangle or ∇ to select **Print Job**, and then press the **OK** button.
 - 2. Press ▲ or ▼ to select the job to print first, and then press the OK button.
 - **3.** Press **△** or **▼** to select **Preempt Jobs**, and then press the **OK** button.

Using RemoteUI


Manage jobs as needed on the Print Job page. For details, refer to the RemoteUI help.



5


Using imagePROGRAF Status Monitor (Windows)

Manage jobs as needed on the Job sheet. For details, refer to the imagePROGRAF Status Monitor help file.



Using imagePROGRAF Printmonitor (Mac OS)

Manage jobs as needed on the **Driver** sheet. For details, refer to the imagePROGRAF Printmonitor help file.



Managing Pending Jobs (Printing or Deleting Jobs on Hold)

If the type or size of paper loaded does not match the settings in the print job received when you have set **Detect Mismatch** to **Hold Job** in the Control Panel menu, the print job is held on the printer as a pending job in the job queue. Manage held jobs such as these as follows.


These operations are available from the Control Panel or in RemoteUI, imagePROGRAF Status Monitor, and imagePROG-RAF Printmonitor.



- · As long as you do not manage held jobs from the Control Panel, imagePROGRAF Status Monitor, or image-PROGRAF Printmonitor, they will remain in the job queue. In this case, the printer processes the next job in the queue without pausing.
- To print held jobs, replace the loaded paper with the paper specified in the print job. (See "Loading Rolls in the Printer.") →P.786 (See "Loading Sheets in the Printer.") →P.813

Using the Control Panel

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (....). "There are held jobs." is displayed if jobs are being held.





- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- **2.** Press the **OK** button. The **Job Menu** menu is displayed.
- 3. Press ▲ or ▼ to select **Print Job**, and then press the **OK** button.
- **4.** Press **△** or **▼** to select the print job to manage, and then press the **OK** button. Held jobs are labeled with an icon.



- 5. Press ▲ or ▼ to select **Print Anyway** or **Delete**, and then press the **OK** button.
 - If you choose Print Anyway Press ▲ or ▼ to select Yes or No, and then press the OK button.
 - If you choose Delete


Using RemoteUI

Manage jobs as needed on the **Print Job** page. For details, refer to the RemoteUI help file.




Using imagePROGRAF Status Monitor

Manage jobs as needed on the **Job** sheet. For details, see "Job Management Using imagePROGRAF Status Monitor." \$\to\$P.427\$



Using imagePROGRAF Printmonitor


Manage jobs as needed on the **Driver** sheet. For details, see "Job Management Using imagePROGRAF Printmonitor." →P.675



Printing Saved Jobs

Print saved print jobs stored on the printer's hard disk as follows.

These operations are available from the Control Panel or in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.



Using the Control Panel

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (....).



Printing Saved Jobs



Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Job Menu** menu is displayed.
- **3.** Press ▲ or ▼ to select **Stored Job**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select the box number (in the range 00–29), and then press the **OK** button.



Note

- Enter a password if one has been set, and then press the **OK** button.
- 5. Press ▲ or ▼ to select **Job List**, and then press the **OK** button.
- **6.** Press ▲ or ▼ to select the saved job, and then press the **OK** button.
- 7. Press \triangle or ∇ to select **Print**, and then press the **OK** button.
- **8.** Specify the number of copies and press the **OK** button.

Using RemoteUI


1. On the **Stored Job** page, choose the box.



iPF8300S Printing Saved Jobs



2. Select the print job and click **Resume**.



3. On the Print Saved Document page, enter the quantity to print in Copies and click OK.




For details, refer to the RemoteUI help.

Printing Saved Jobs iPF8300S

Using imagePROGRAF Status Monitor


1. On the Hard Disk sheet, select a box and click Open.






iPF8300S Printing Saved Jobs

2. In the **Documents** dialog box, select the print job and click **Print**.



3. In the **Print** dialog box, enter the quantity to print in **Copies** and click **OK**.





734

Note

• The printing time initially indicates how long it took to finish printing one copy during the previous print job.


If you change the value in **Copies**, the printing time indicates the time it took to print one copy during the previous print job multiplied by the number of copies.


For details, refer to the imagePROGRAF Status Monitor help file.

Printing Saved Jobs iPF8300S

Using imagePROGRAF Printmonitor


1. On the Hard Disk pane, click ▶ by Inbox No./Name.






iPF8300S Printing Saved Jobs

2. Select the saved job and click Resume Printing.



3. In the Resume Printing dialog box, enter the quantity to print and click OK.



For details, refer to the imagePROGRAF Printmonitor help file.

Printing Saved Jobs iPF8300S

Deleting Saved Jobs

Delete saved print jobs stored on the printer's hard disk as follows.

This operation is available from the Control Panel, in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.

Using the Control Panel

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (......).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Job Menu** is displayed.
- 3. Press ▲ or ▼ to select **Stored Job**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select the box number (in the range 00–29), and then press the **OK** button.



Note

- Enter a password if one has been set, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Job List, and then press the OK button.
- **6.** Press **△** or **▼** to select the saved job, and then press the **OK** button.
- 7. Press ▲ or ▼ to select **Delete**, and then press the **OK** button.
- 8. Press ▲ or ▼ to select "Yes", and then press the OK button.

iPF8300S Deleting Saved Jobs


Using RemoteUI

1. On the Stored Job page, choose the mail box.





2. Select the print job and click **Delete**.



iPF8300S

For details, refer to the RemoteUI help file.


5

738

Deleting Saved Jobs

Using imagePROGRAF Status Monitor


1. On the Hard Disk sheet, select a box and click Open.





iPF8300S Deleting Saved Jobs


2. In the **Documents** dialog box, select the print job and click **Delete**.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor


1. In the Hard Disk pane, click next to Inbox No./Name.




740

Deleting Saved Jobs iPF8300S





2. Select the print job and click the **Delete** button.



For details, refer to the imagePROGRAF Printmonitor help file.

Moving Saved Jobs

Print jobs stored on the printer's hard disk (saved jobs) can be moved from the current box to another box as follows. However, jobs saved in personal boxes cannot be moved to the shared mailbox.

This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.



iPF8300S Moving Saved Jobs



Important

• Jobs stored in the shared mailbox may be automatically deleted under some conditions. To prevent jobs from being deleted, move them from the shared mailbox to personal boxes. (See "Using the Printer Hard Disk.")

• P.720

Using RemoteUI

 ${f 1}_{f \cdot}$ On the **Stored Job** page, choose the box.






Note

• Enter a password if one has been set.



2. Select the print job and click **Move Document**.



742

Moving Saved Jobs iPF8300S


3. On the **Move Document** page, select the name or number of the destination personal box in the **Destination mail** box list and click **OK**.




For details, refer to the RemoteUI help file.

Using imagePROGRAF Status Monitor (Windows)


1. On the Hard Disk sheet, select a box and click Open.




iPF8300S Moving Saved Jobs



2. In the **Documents** dialog box, select the print job and click **Move**.



3. In the Move dialog box, select the destination personal box and click $oxt{OK}$.




744


Moving Saved Jobs iPF8300S

For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Macintosh)


1. In the Hard Disk pane, click ▶ next to Inbox No./Name.






iPF8300S Moving Saved Jobs

2. Select the print job and click Move.



 ${f 3.}$ In the ${f Move\ Document}$ dialog box, select the destination personal box and click ${f OK}.$



For details, refer to the imagePROGRAF Printmonitor help file.

746


Moving Saved Jobs iPF8300S

Advanced Print Job Operations

| Saving Print Jobs Sent from Sources Other than the Printer Driver | 747 |
|---|----------------------------------|
| Printing Without Saving Jobs in the Common Box | . 749 |
| Setting Passwords for Personal Boxes | 749 |
| Naming Personal Boxes | |
| Displaying a List of Saved Jobs | . 758 |
| Printing a List of Saved Jobs | |
| Displaying Details of Saved Jobs | 763 |
| | |
| Displaying a List of Saved Jobs | . 753 . 758 . 762 . 763 |

Saving Print Jobs Sent from Sources Other than the Printer Driver

To save print jobs sent from software or systems other than the printer driver or applications provided with the printer, complete the **Output Method** and **Print After Recv** settings in the Control Panel menu.






Note

• Contact the software or system developer for information about support for this printer function.

Specifying Output Method

In **Output Method**, specify how to manage jobs, regarding printing and saving them.

- Print
 - Save print jobs automatically at the same time they are printed. (This is the default format.)
- Print (Auto Del)
 - Save print jobs temporarily at the same time they are printed and delete them after printing.
- Save: Box 01 (Here, the number represents a box number) Save print jobs on the printer.
- 1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (————————).





Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

- 2. Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- 3. Press ▲ or ▼ to select System Setup, and then press the OK button.
- **4.** Press ▲ or ▼ to select **Output Method**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Print, Print (Auto Del), or Save: Box 01. Follow these steps only when you select Save: Box 01.
- **6.** Press **△** or **▼** to select the box, and then press the **OK** button.

Specify Print After Recv

To save print jobs on the hard disk before printing, specify **Print After Recv**.

Printing will start when **Print After Recv** is set to **On**, even if you have selected **Save: Box 01** in **Output Method**.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (—————).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **System Setup**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select **Print After Recv**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select On or Off, and then press the OK button.

Printing Without Saving Jobs in the Common Box

Jobs sent from a computer for which you have selected **Print** in **Output Method** (in Windows) or **Send job to** (in Mac OS X) in the printer driver are saved in the shared mailbox. (See "Using the Printer Hard Disk.") P.720

When **Common Box Set.** is **Print** (**Auto Del**) in the Control Panel menu, print jobs for which you have selected **Print** in the **Output Method** dialog box of the printer driver are deleted from the shared mailbox after printing. Use this function when printing highly confidential documents.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (——————).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- 3. Press ▲ or ▼ to select System Setup, and then press the OK button.
- **4.** Press ▲ or ▼ to select **Common Box Set.**, and then press the **OK** button.




Note

- If a password has been set on the printer, the Logon screen is displayed.
 To change the setting, select Administrator and press the OK button. Enter the password when Admin.Pswd is displayed and press the OK button before going to the next procedure.
 If you select User and press the OK button, you can check settings values but cannot change them.
- 5. Press ▲ or ▼ to select Print (Auto Del), and then press the OK button.

Setting Passwords for Personal Boxes

For greater security, you can specify a password for personal boxes. After you set a password, it will be required to modify the personal box settings, as well as to display, print, delete, move, and modify jobs saved in the personal box. This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.






Note

- By default, no passwords are set for personal boxes.
- A password cannot be set for the shared mailbox.
- Enter a four-digit number as the password, in the range 0001–9999.
- Even if you have set passwords, they are not required to access personal boxes in Administrator Mode in RemoteUI.

Using RemoteUI

- 1. On the **Stored Job** page, choose the personal box.
- 2. Click Edit.




- 3. In the Set/Register User's Inbox dialog box, specify the password and click OK.
 - Set Password Select the check box.
 - **Password**Enter the password. (This field is limited to four digits in the range 0001–9999.)
 - Confirmation Number
 Re-enter the password to confirm it.




For details, refer to the RemoteUI help.

Using imagePROGRAF Status Monitor (Windows)

1. On the Hard Disk sheet, select the personal box and click Open.



2. In the **Documents** dialog box, click **Settings**.




- ${\bf 3.}\,$ In the Settings dialog box, specify the password and click ${\bf OK}.$
 - Set password Select the check box.
 - **Password**Enter the password. (This field is limited to four digits in the range 0001–9999.)
 - **Re-enter to confirm**Re-enter the password to confirm it.

For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Macintosh)

1. On the Hard Disk pane, click ▶ by Inbox No./Name. Select a saved job in the list and click Set.



- 2. In the **Settings** dialog box, specify the password and click $oxt{OK}$.
 - Set password Select the check box.
 - **Password**Enter the password. (This field is limited to four digits in the range 0001–9999.)
 - Verify
 Re-enter the password to confirm it.

5



For details, refer to the imagePROGRAF Printmonitor help file.


Naming Personal Boxes

For easier identification, you can assign names to personal boxes.

This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.


Using RemoteUI

1. On the **Stored Job** page, choose the personal box.




iPF8300S Naming Personal Boxes






2. Click Edit.



3. In the Set/Register User's Inbox dialog box, enter the name in Inbox Name and click OK.




For details, refer to the RemoteUI help file.

Naming Personal Boxes iPF8300S

Using imagePROGRAF Status Monitor (Windows)

1. On the Hard Disk sheet, select the personal box and click Open.






iPF8300S Naming Personal Boxes

2. In the **Documents** dialog box, click **Settings**.




3. In the Settings dialog box, enter the name and click OK.




For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Macintosh)

1. In the Hard Disk pane, click next to Inbox No./Name. Select a saved job in the list and click Set.





iPF8300S Naming Personal Boxes

For details, refer to the imagePROGRAF Printmonitor help file.

Displaying a List of Saved Jobs

Print jobs stored on the printer's hard disk (saved jobs) can be listed by box as follows.

These operations are available from the Control Panel or in RemoteUI, imagePROGRAF Status Monitor, and imagePROG-RAF Printmonitor.

Using the Control Panel

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (......).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The Job Menu is displayed.
- **3.** Press \blacktriangle or \blacktriangledown to select **Stored Job**, and then press the **OK** button.

4. Press ▲ or ▼ to select the box number (in the range 00–29), and then press the **OK** button.




Note

- Enter a password if one has been set, and then press the **OK** button.
- 5. Press ▲ or ▼ to select **Job List**, and then press the **OK** button.

Using RemoteUI

On the Stored Job page, choose the box.






Note

• Enter a password if one has been set.




Jobs saved in the box are listed.




For details, refer to the RemoteUI help.


Using imagePROGRAF Status Monitor (Windows)

On the Hard Disk sheet, select a box and click Open.






Jobs saved in that box are displayed in the **Documents** dialog box.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Macintosh)

On the **Hard Disk** pane, click by **Inbox No./Name**.





Note

• Enter a password if one has been set. The password is a four-digit number.




For details, refer to the imagePROGRAF Printmonitor help file.

5 Printing a List of Saved Jobs

The list of print jobs stored on the printer's hard disk (saved jobs) can be printed by box as follows.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (.....).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Job Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Stored Job**, and then press the **OK** button.
- **4.** Press \blacktriangle or \blacktriangledown to select the box number (in the range 00–29), and then press the **OK** button.



Note

• Enter a password if one has been set, and then press the **OK** button.


5. Press ▲ or ▼ to select **Print Job List**, and then press the **OK** button.

Displaying Details of Saved Jobs

Details of print jobs stored on the printer's hard disk (saved jobs) can be displayed as follows. This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.


Using RemoteUI

1. On the **Stored Job** page, choose the box.





2. Select the print job and click **Details**.




The **Details of the saved document** page is displayed.




For details, refer to the RemoteUI help file.


Using imagePROGRAF Status Monitor (Windows)

1. On the Hard Disk sheet, select a box and click Open.






2. In the **Documents** dialog box, select the print job and click **Properties**.




The **Properties** dialog box is displayed.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor (Macintosh)

1. In the Hard Disk pane, click next to Inbox No./Name.





For details, refer to the imagePROGRAF Printmonitor help file.

Renaming Saved Jobs

Print jobs stored on the printer's hard disk (saved jobs) can be renamed as follows.

This operation is available in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.


Using RemoteUI

 ${f 1}_{f \cdot}$ On the **Stored Job** page, choose the box.






2. Select the print job and click **Details**.




iPF8300S Renaming Saved Jobs

3. On the Details of the saved document page, click Change Document.



4. In the **Rename Saved Document** dialog box, enter the name and click **OK**.




For details, refer to the RemoteUI help file.

768

Renaming Saved Jobs iPF8300S

Using imagePROGRAF Status Monitor (Windows)


1. On the Hard Disk sheet, select a box and click Open.






iPF8300S Renaming Saved Jobs

2. In the **Documents** dialog box, select the print job and click **Properties**.



3. In the **Properties** dialog box, enter the new name and click **OK**.




For details, refer to the imagePROGRAF Status Monitor help file.


770

Renaming Saved Jobs iPF8300S

Using imagePROGRAF Printmonitor (Macintosh)


1. In the Hard Disk pane, click ▶ next to Inbox No./Name.





iPF8300S Renaming Saved Jobs

2. Select the print job and click Set.



 ${\bf 3.}\,$ In the Settings dialog box, enter the new name and click ${\bf OK}.$


| S | Settings |
|------------------|------------------|
| Mail box | |
| Rename inbox | |
| Inbox no. : | 1 |
| Inbox name : | Box 1 |
| Set password | |
| Password : | (4-digit number) |
| Verify : | |
| Rename document | |
| Document title : | sample2 |
| | Cancel |

For details, refer to the imagePROGRAF Printmonitor help file.

Renaming Saved Jobs iPF8300S

Handling Paper

| Paper | 774 |
|--------------------|-----|
| Handling rolls | 782 |
| Handling sheets | 813 |
| Output Stacker | 822 |
| Media take-up unit | 831 |



Paper

| Types of Paper | . 774 |
|--------------------------------------|-------|
| Paper Sizes | |
| Displaying the Paper Reference Guide | |
| Updating paper information | |
| Adding Custom Paper | |

Types of Paper

The following types of paper are supported by the printer. For details on the paper supported by the printer, refer to the Paper Reference Guide. (See Paper Reference Guide .)

- · Plain Paper
- · Coated Paper
- · Photo Paper
- · Glossy Paper
- · Proofing Paper
- CAD-dedicated Paper Etc.

The following content is described in the Paper Reference Guide.

- · Types of paper
- · Paper handling
- Paper product specifications
- Use precautions
- Setting of printer driver, control panel etc.

Paper Reference Guide display method

You can display the Paper Reference Guide from [imagePROGRAF Support Information]. (See "Displaying the Paper Reference Guide .") —P.777

Method of Updating Supported Paper

Paper supported by the printer may be newly released on the imagePROGRAF website.

To use newly released paper, register the latest paper information on the printer with the Media Configuration Tool. (See "Updating paper information.") P.779



Important

• To install the Paper Reference Guide and register paper types applicable to your region on your printer even when not using the printer driver, install the Media Configuration Tool.

For information about the Media Configuration Tool, see Media Configuration Tool

P.448 or Media Configuration Tool

P.677.



Note

• To use paper not described in the Paper Reference Guide, configure the custom paper setting. (See "Adding Custom Paper.") →P.780

6

774

Types of Paper iPF8300S

Paper Sizes

Rolls

Rolls that meet the following conditions are supported.

• Outer diameter: Up to 150 mm (6 in)

• Inner diameter of paper core: 2 or 3 inches

• Printing side out

| Roll Width | Roll Paper Width Setting in Printer Driver | Borderless Printing (*1 →P.775) |
|--------------------------|--|----------------------------------|
| 1117.6 mm (44.00 in) | 44-in. Roll (1117.6mm) | Yes |
| 1066.8 mm (42.00 in) | 42-in. Roll (1066.8mm) | Yes |
| 1030.0 mm (40.55 in) | JIS B0/B1 Roll (1030.0mm) | Yes |
| 914.4 mm (36.00 in) | 36-in. Roll (914.4mm) | Yes |
| 841.0 mm (33.11 in) | ISO A0/A1 Roll (841.0mm) | Yes |
| 762.0 mm (30.00 in) | 30-in. Roll (762.0mm) | No |
| 728.0 mm (28.66 in) | JIS B1/B2 Roll (728.0mm) | No |
| 609.6 mm (24.00 in) | 24-in. Roll (609.6mm) | Yes |
| 594.0 mm (23.39 in) | ISO A1/A2 Roll (594.0mm) | Yes |
| 515.0 mm (20.28 in) | JIS B2/B3 Roll (515.0mm) | Yes |
| 431.8 mm (17.00 in) | 17-in. Roll (431.8mm) | Yes |
| 420.0 mm (16.54 in) | ISO A2/A3 Roll (420.0mm) | No |
| 406.4 mm (16.00 in) | 16-in. Roll (406.4mm) | No |
| 355.6 mm (14.00 in) | 14-in. Roll (355.6mm) | Yes |
| 297.0 mm (11.69 in) | ISO A3/A4 Roll (297.0mm) | No |
| 254.0 mm (10.00 in) | 10-in. Roll (254.0mm) | Yes |
| Custom Paper Size | 254.0 mm (10.00 in) to 1,118.0 mm (44.02 in) | |

^{*1:} For information on types of paper compatible with borderless printing, refer to the Paper Reference Guide. (See "Types of Paper.") —P.774

Sheets

Sheets of the following sizes are supported.

| Paper Sizes | Dimensions |
|-------------|--------------------------------------|
| ISO A0 | 841.0 × 1189.0 mm (33.11 × 46.81 in) |
| ISO A1 | 594.0 × 841.0 mm (23.39 × 33.11 in) |
| ISO A2 | 420.0 × 594.0 mm (16.54 × 23.39 in) |
| ISO A2+ | 431.8 × 609.6 mm (17.00 × 24.00 in) |
| ISO A3 | 297.0 × 420.0 mm (11.69 × 16.54 in) |
| ISO A3+ | 329.0 × 483.0 mm (12.95 × 19.02 in) |
| ISO A4 | 210.0 × 297.0 mm (8.27 × 11.69 in) |

iPF8300S Paper Sizes

| 776 | |
|-------|--|
| , , , | |

| Paper Sizes | Dimensions |
|------------------|---------------------------------------|
| ISO B0 | 1000.0 × 1414.0 mm (39.37 × 55.67 in) |
| ISO B1 | 707.0 × 1000.0 mm (27.83 × 39.37 in) |
| ISO B2 | 500.0 × 707.0 mm (19.69 × 27.83 in) |
| ISO B3 | 353.0 × 500.0 mm (13.90 × 19.69 in) |
| ISO B4 | 250.0 × 353.0 mm (9.84 × 13.90 in) |
| JIS B0 | 1030.0 × 1456.0 mm (40.55 × 57.32 in) |
| JIS B1 | 728.0 × 1030.0 mm (28.66 × 40.55 in) |
| JIS B2 | 515.0 × 728.0 mm (20.28 × 28.66 in) |
| JIS B3 | 364.0 × 515.0 mm (14.33 × 20.28 in) |
| JIS B4 | 257.0 × 364.0 mm (10.12 × 14.33 in) |
| 34"x44"(ANSI E) | 863.6 × 1117.6 mm (34.00 × 44.00 in) |
| 28"x40"(ANSI F) | 711.2 × 1016.0 mm (28.00 × 40.00 in) |
| 22"x34"(ANSI D) | 558.8 × 863.6 mm (22.00 × 34.00 in) |
| 17"x22"(ANSI C) | 431.8 × 558.8 mm (17.00 × 22.00 in) |
| 11"x17"(Ledger) | 279.4 × 431.8 mm (11.00 × 17.00 in) |
| 13"x19"(Super B) | 330.2 × 482.6 mm (13.00 × 19.00 in) |
| Letter(8.5"x11") | 215.9 × 279.4 mm (8.50 × 11.00 in) |
| Legal(8.5"x14") | 215.9 × 355.6 mm (8.50 × 14.00 in) |
| 36"x48"(ARCH E) | 914.4 × 1219.2 mm (36.00 × 48.00 in) |
| 30"x42"(ARCH E1) | 762.0 × 1066.8 mm (30.00 × 42.00 in) |
| 26"x38"(ARCH E2) | 660.4 × 965.2 mm (26.00 × 38.00 in) |
| 27"x39"(ARCH E3) | 685.8 × 990.6 mm (27.00 × 39.00 in) |
| 24"x36"(ARCH D) | 609.6 × 914.4 mm (24.00 × 36.00 in) |
| 18"x24"(ARCH C) | 457.2 × 609.6 mm (18.00 × 24.00 in) |
| 12"x18"(ARCH B) | 304.8 × 457.2 mm (12.00 × 18.00 in) |
| 9"x12"(ARCH A) | 228.6 × 304.8 mm (9.00 × 12.00 in) |
| DIN CO | 917.0 × 1296.0 mm (36.10 × 51.02 in) |
| DIN C1 | 648.0 × 917.0 mm (25.51 × 36.10 in) |
| DIN C2 | 458.0 × 648.0 mm (18.03 × 25.51 in) |
| DIN C3 | 324.0 × 458.0 mm (12.76 × 18.03 in) |
| DIN C4 | 229.0 × 324.0 mm (9.02 × 12.76 in) |
| 20"x24" | 508.0 × 609.6 mm (20.00 × 24.00 in) |
| 18"x22" | 457.2 × 558.8 mm (18.00 × 22.00 in) |
| 14"x17" | 355.6 × 431.8 mm (14.00 × 17.00 in) |
| 12"x16" | 304.8 × 406.4 mm (12.00 × 16.00 in) |
| 10"x12" | 254.0 × 304.8 mm (10.00 × 12.00 in) |
| 10"x15" | 254.0 × 381.0 mm (10.00 × 15.00 in) |
| 8"x10" | 203.2 × 254.0 mm (8.00 × 10.00 in) |

Paper Sizes iPF8300S

| Paper Sizes | Dimensions | |
|-------------------|--|--|
| US Photo 16"x20" | 406.4 × 508.0 mm (16.00 × 20.00 in) | |
| Poster 20"x30" | 508.0 × 762.0 mm (20.00 × 30.00 in) | |
| Poster 30"x40" | 762.0 × 1016.0 mm (30.00 × 40.00 in) | |
| Poster 42"x60" | 1066.8 × 1524.0 mm (42.00 × 60.00 in) | |
| Poster 44"x62" | 1117.6 × 1574.8 mm (44.00 × 62.00 in) | |
| 13"x22" | 329.0 × 558.0 mm (12.95 × 21.97 in) | |
| Poster 300x900mm | 300.0 × 900.0 mm (11.81 × 35.43 in) | |
| Custom Paper Size | 203.2 × 203.2 mm (8.00 × 8.00 in) to 1118.0 × 1600.0 mm (44.02 × 62.99 in) | |



Note

• For details on non-standard paper sizes, see "Printing on Non-Standard Paper Sizes." —P.131

• Borderless printing is not supported on sheets.

Displaying the Paper Reference Guide


The Paper Reference Guide can be accessed from **imagePROGRAF Support Information**. Follow these instructions, as appropriate for your operating system.

- Windows
 - 1. Double-click the iPFxxxx Support desktop icon. (iPFxxxx indicates the printer model.)



The imagePROGRAF Support Information window is displayed.

2. Click the Paper Reference Guide button.



The Paper Reference Guide is displayed.



- Mac OS X
 - 1. Click the iPF Support icon in the Dock.




The imagePROGRAF Support Information window is displayed.

2. Click the Paper Reference Guide button.



The Paper Reference Guide is displayed.



Updating paper information

As for paper information of the Paper Reference Guide, printer Control Panel, and printer driver, you can update it to the latest information by downloading and installing the latest version of **Media Information File** (Media Information File) from the imagePROGRAF website.

Download the latest **Media Information File** (Media Information File) after accessing the imagePROGRAF-dedicated site from **imagePROGRAF Support Information**. If you cannot download it, contact your Canon dealer. For details on **Media Information File** (Media Information File), refer as follows.

- Media Configuration Tool →P.448 (Windows)
- Media Configuration Tool →P.677 (Macintosh)



Important


 When your version of Media Configuration Tool is older than the version released on the imagePROG-RAF website, download and install the latest version of Media Configuration Tool before installing Media Information File. If you do not install the latest version of Media Configuration Tool before installing Media Information File, the latest paper information cannot be updated.

- Windows
 - 1. Double-click the iPFxxxx Support desktop icon. (iPFxxxx indicates the printer model.)



The imagePROGRAF Support Information window is displayed.

2. Click Visit the imagePROGRAF webpage.




The default browser on your computer is started and the imagePROGRAF webpage is displayed.

- Mac OS X
 - **1.** Click the **iPF Support** icon in the **Dock**.



The imagePROGRAF Support Information window is displayed.

2. Click Visit the imagePROGRAF webpage.



The default browser on your computer is started and the imagePROGRAF webpage is displayed.

780

Adding Custom Paper

Using Media Configuration Tool, you can add custom paper (paper not listed in the Paper Reference Guide) to the printer driver and control panel of the printer.

For details on Media Configuration Tool, refer as follows.

- Media Configuration Tool →P.448 (Windows)
- Media Configuration Tool →P.677 (Macintosh)

Adding Custom Paper iPF8300S



• If a malfunction occurs in the printer resulting from the use of custom paper (paper not listed in the Paper Reference Guide), it is not guaranteed even within the warranty period.

iPF8300S Adding Custom Paper

Handling rolls

| Attaching the Roll Holder to Rolls | 782 |
|--|-----|
| Loading Rolls in the Printer | 786 |
| Changing the Type of Paper | 791 |
| Specifying the Paper Length | 793 |
| Removing the Roll from the Printer | 794 |
| Removing the Roll Holder from Rolls | 797 |
| Feeding Roll Paper Manually | 798 |
| Keeping Track of the Amount of Roll Paper Left | 799 |
| Specifying the Ink Drying Time for Rolls | 800 |
| Specifying the Cutting Method for Rolls | 802 |
| Cutting the Leading Edge of Roll Paper Automatically | |
| Reducing Dust from Cutting Rolls | 812 |

Attaching the Roll Holder to Rolls

When printing on rolls, attach the Roll Holder to the roll.

Rolls have a two- or three-inch paper core. Use the correct attachment for the paper core. The printer comes equipped with the 2-Inch Paper Core Attachment installed.

| Using Rolls with a 2-inch Paper Core | | Using Rolls with a 3-inch Paper Core | |
|--------------------------------------|------------------------------|--------------------------------------|---------------------------------|
| Roll Holder Side | Holder Stopper Side | Roll Holder Side | Holder Stopper Side |
| No Attachment Needed | 2-Inch Paper Core Attachment | 3-Inch Paper Core Attachment #1 | 3-Inch Paper Core Attachment #2 |




Caution

• Set the roll on a table or other flat surface so that it does not roll or fall. Rolls are heavy, and dropping a roll may cause injury.



Important


- When handling the roll, be careful not to soil the printing surface. This may affect the printing quality. We recommend wearing clean cloth gloves when handling rolls to protect the printing surface.
- Use scissors or a cutting tool to cut the edge of the roll paper if it is uneven, dirty, or has tape residue. Otherwise, it may cause feeding problems and affect the printing quality. Be careful not to cut through any barcodes printed on the roll.
- Align the edges of the paper on both ends of the roll. Misalignment may cause feeding problems.





Note

- For details on supported sizes and types of rolls, see **Paper Sizes** or the Paper Reference Guide. (See "Paper Sizes.") —P.775 (See "Types of Paper.") —P.774
- To view instructions as you attach the Roll Holder, press the **Navigate** button. (See "How to View Instructions With Navigate.") —P.919
- 1. Lift the Holder Stopper lever (a) from the shaft side to unlock it. Holding the Holder Stopper at the position indicated (b), remove it from the Roll Holder.




• Using rolls with a 2-inch paper core

| Holder Stopper Side | Roll Holder Side |
|---|--------------------------|
| Align the tips (a) of the 2-Inch Paper Core Attachment with the holes (b) of the Holder Stopper and insert it firmly. | No attachment is needed. |
| a | |


Using rolls with a 3-inch paper core

| Holder Stopper Side | Roll Holder Side |
|--|---|
| Align the tips (a) of 3-Inch Paper Core Attachment #2 with the holes (b) of the Holder Stopper and insert it | Align the tips (a) of 3-Inch Paper Core Attachment #1 with the holes (b) of the Roll Holder and insert it firmly. |
| firmly. | b b |
| | a |
| | |

3. With the edge of the roll paper facing forward as shown, insert the Roll Holder from the right of the roll. Insert it firmly until the roll touches the flange (a) of the Roll Holder, leaving no gap.



4. Insert the Holder Stopper from the left in the Roll Holder as shown. Holding it at the position shown (b), push it firmly in until the flange (a) of the Holder Stopper touches the roll. Lock the Holder Stopper lever (c) by pushing it down toward the shaft side.



Loading Rolls in the Printer

Follow these steps to load rolls in the printer.



Important

- Always load rolls when the printer is on. If the printer is off when you load a roll, the paper may not be advanced correctly when you turn the printer on.
- Before loading a roll, confirm whether the inside of the Top Cover or the Ejection Guide is soiled. If soiled, we recommend cleaning in advance. (See "Cleaning Inside the Top Cover.") —P.1040
- 1. Press the Load button.




2. Press ▲ or ▼ to select Load Roll Paper, and then press the OK button.




Note

• If any paper has been advanced that will not be used, a message is shown requesting you to remove it. Press ▲ or ▼ to select "Yes", and then press the OK button. Remove the paper and go to the next step.

3. Open the Top Cover and lift the Ejection Guide.



4. Holding the Roll Holder so that the side with the white gear faces the side of the Roll Holder Slot with a white gear, load the Roll Holder shaft (a) into the grooves (b) on both ends of the Roll Holder Slot, fully into the slot.






Caution

- Be careful not to drop the roll and hurt yourself when loading it.
- Be careful not to pinch your fingers between the Roll Holder shaft (a) and the guide grooves (b) when loading rolls.

5. Pull out the roll evenly on both ends and insert it in the Paper Feed Slot (a). Advance the roll until it touches the Paper Retainer (b).




Once the roll reaches the Paper Retainer, it is automatically advanced over the Platen.




Important

- When handling the roll, be careful not to soil the printing surface. Otherwise, it may affect printing quality. We recommend wearing clean cloth gloves when handling rolls to protect the printing surface.
- If the paper is wrinkled or warped, straighten it out before loading it.
- For paper that tends to curl, lift the Release Lever and manually pull the roll paper over the Platen.
- Load paper straight so it is not fed askew.




789


6. Lower the Ejection Guide.



7. Holding the edge of the roll paper, lift the Release Lever.



8. Hold the edge of the roll paper as you gently pull it evenly with both hands to the position of the Ejection Guide (a). Align the right side of the roll paper with the Paper Alignment Line (b), keeping this side parallel to the line, and then lower the Release Lever.





Important


- Do not omit steps 7 and 8. If paper cannot be advanced straight or if it wrinkles, it may jam or rub against the Printhead.
- Do not force the roll paper into alignment with the paper alignment line (b). This may prevent the paper from being advanced straight.



Note

• You can adjust the strength of suction holding paper against the Platen when the Release Lever is released. If it is difficult to load paper, press the ▲ or ▼ button on the Control Panel to adjust the strength. Set suction stronger by pressing the ▲ button or weaker with the ▼ button. Three settings are available.

9. Close the Top Cover.



10. Once paper feeding starts, you will need to do the following, based on the ManageRemainRoll setting and the barcode printed on rolls. (See "Keeping Track of the Amount of Roll Paper Left.") —P.799

| ManageR- emainRoll | Barcodes | Printer Operation After the Paper is Fed |
|---|------------------|--|
| Off | Printed | A menu for selection of the type of paper is shown on the Display Screen. |
| | Not prin- ted | Press ▲ or ▼ to select the type of paper, and then press the OK button. |
| On Printed The type and amount of paper left is automatically detected based on the b on the roll. There is no need to specify the type and length of the paper. | | |
| | Not prin- ted | A menu for selection of the type and length of paper is shown on the Display Screen. Press ▲ or ▼ to select the type and length of paper loaded, and then press the OK button. |



Important

• Cut the edge of the roll using the **Paper Cutting** function if the edge is creased or soiled. (See "Specifying the Cutting Method for Rolls.") \rightarrow P.802



Note

- For details on types of paper to select, see the Paper Reference Guide. (See "Types of Paper.")

 —P.774
- Adjusting the printhead alignment with the type of paper to be used in printing may enhance printing quality. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).")

 P.850
- When paper leading edge detection is set to **Off** for Manual, printing will start at the position at which the roll was set in procedure 8. Thus, the margin of the paper leading edge will enlarge. (See "Specifying the Cutting Method for Rolls.") —P.802

Changing the Type of Paper

Follow these steps to change the type of paper specified on the printer after you have loaded paper.

If you will continue using this type of paper later, selecting **Keep Paper Type** > **On** will save the time and effort of configuring the media type setting when you load the paper again. The current media type settings before you select **On** will be automatically selected at that time. (See "Using the Same Type of Paper Regularly.") —**P.793**

Important

- For best printing results, the printer fine-tunes the print head height and the feed amount for each type of paper. Be sure to select the type of paper to use correctly before printing.
- Because the printer fine-tunes the feed amount for each type of paper, the margins and the size of printed images may vary depending on the type of paper used. If margins and the size of images are not as you expected, adjust the paper feed amount.

(See "Adjusting the Feed Amount.") →P.856

Changing the Type of Paper



Note

ullet When you load a roll, a menu for selection of the type of paper is shown on the Display Screen. Select the type of paper, and then press the OK button.

If no barcode has been printed on the roll and you have set **ManageRemainRoll** to **On**, specify the roll length after the type of paper. (See "Specifying the Paper Length.") →P.793

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□□).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- **2.** Press the **OK** button. The **Paper Menu** is displayed.
- **3.** Press ▲ or ▼ to select Chg. Paper Type, and then press the OK button.
- **4.** Press ▲ or ▼ to select the type of paper loaded (**Roll Paper** or **Cut Sheet**), and then press the **OK** button.
- 5. Press ▲ or ▼ to select the type of paper loaded in the printer, and then press the **OK** button.



Important

• Be sure to select the correct paper type. If this setting does not match the loaded paper, it may cause feed errors and affect printing quality.



Note

- For details on types of paper, see the Paper Reference Guide. (See "Types of Paper.") P.774 By default, Plain Paper is selected.
- If you move the Release Lever, the setting automatically reverts to the previously selected paper.

6

793

Using the Same Type of Paper Regularly

Configure this setting so that current media type settings will be automatically selected when you load the same type of paper later.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





Note

- If the Tab Selection screen is not displayed, press the Menu button.
- 2. Press the **OK** button.
 The **Paper Menu** is displayed.
- 3. Press ▲ or ▼ to select **Keep Paper Type**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select **On**, and then press the **OK** button.



Note

- The specified media type setting is updated in the following situations.
 - When using sheets, if you send a print job before loading a sheet, the media type setting is updated to match the type of paper specified by the print job.
 - When you have selected **ManageRemainRoll** > **On** on the Control Panel and a barcode is printed on the roll, the media type setting is updated to match the type of paper specified by the barcode.
- To change the media type setting, see "Changing the Type of Paper." →P.792

Specifying the Paper Length

When changing the length of paper after the paper has been advanced, specify the length as follows.



Note

- Specify the paper length when you have set ManageRemainRoll to On. (See "Keeping Track of the Amount of Roll Paper Left.") —P.799
- 1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□□).



iPF8300S



Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Paper Menu** is displayed.
- 3. Press ▲ or ▼ to select Chg. Paper Size, and then press the OK button.
- **4.** Press ▲ or ▼ to select **Roll Length**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select the length of paper loaded in the printer, and then press the OK button. Specify the roll length as follows.
 - **1.** Press the ◀ or ▶ button to move to the next field for input.
 - **2.** Press the \triangle or ∇ button to enter the value.
 - **3.** Repeat steps 1 and 2 to finish entering the value, and then press the **OK** button.

Removing the Roll from the Printer

Remove rolls from the printer as follows.



Note

• If you need to cut the roll, see "Specifying the Cutting Method for Rolls." →P.802

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Paper Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Eject Paper**, and then press the **OK** button.


4. Press ▲ or ▼ to select "Yes", and then press the **OK** button. The roll is now rewound and ejected.




Important

• If you have selected **ManageRemainRoll** > **On** in the Control Panel menu, a barcode is printed on the leading edge of the roll.


Do not remove the roll before the barcode is printed. You will be unable to keep track of the amount of roll paper left. (See "Keeping Track of the Amount of Roll Paper Left.") →P.799




5. Open the Top Cover and lift the Ejection Guide.



 $\mathbf{6}$. Using both hands, rotate the Roll Holder in the direction of the arrow to rewind the roll.




7. Holding the Roll Holder flange (a), remove the holder from the Roll Holder Slot.



Note

• For instructions on removing the Roll Holder from rolls, see "Removing the Roll Holder from Rolls." P.797

8. Lower the Ejection Guide and close the Top Cover.




Note

- To load new paper in the printer at this point, see "Loading Rolls in the Printer." -P.786
- Clean inside the top cover before loading paper. (See "Cleaning Inside the Top Cover.") →P.1040


6

Removing the Roll Holder from Rolls


1. Lift the Holder Stopper lever (a) from the shaft side to unlock it. Holding the Holder Stopper at the position indicated (b), remove it from the Roll Holder.




2. Remove the Roll Holder from the roll.




- 3. When removing attachments, push the tips (a) in as you remove the attachment.
 - 3-Inch Paper Core Attachment #1 (Roll Holder side)



• 3-Inch Paper Core Attachment #2 (Holder Stopper side)



• 2-Inch Paper Core Attachment





Important

• Store the roll in the original bag or box, away from high temperature, humidity, and direct sunlight. If paper is not stored properly, the printing surface may become scratched, which may affect the printing quality when you use it again.

Feeding Roll Paper Manually

After a roll has been advanced, you can press the **Feed** button to feed or retract the roll with the ▲ and ▼ buttons.



- 1. Press the **Feed** button.
- 2. Press the ▲ or ▼ button to advance or retract the roll. Press ▲ to retract the roll manually.
 - Press ▼ to advance the roll manually.



Note

• If you hold down ▲ or ▼ for less than a second, the roll will move about 1 mm (0.04 in). If you hold down ▲ or ▼ for more than a second, the roll will move until you release the button. Release the button when the Display Screen indicates "End of paper feed. Cannot feed paper more."

Keeping Track of the Amount of Roll Paper Left

Setting ManageRemainRoll to On in the Paper Menu of the Control Panel will print a barcode with text on the roll when the roll is removed that identifies the type of paper and amount left. When ManageRemainRoll is On and you load rolls with printed barcodes, the type of paper and amount left are automatically detected after rolls are loaded. The barcode will be cut off after it has been read.






Important

• If the barcode on the roll is not detected, enter the type and length of paper on the Control Panel.

Follow these steps to set ManageRemainRoll to On as follows.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Paper Menu** is displayed.
- 3. Press ▲ or ▼ to select ManageRemainRoll, and then press the OK button.
- **4.** Press ▲ or ▼ to select **On**, and then press the **OK** button.

Specifying the Ink Drying Time for Rolls

When you are using paper that takes longer for ink to adhere, ink may be transferred onto the paper surface during ejection, soiling it. In that case, you may be able to improve the condition by setting the time to wait for the ink to dry after printing.




Note

 If the Cutter touches the print surface on which the ink is not dry, the paper surface may become scratched or soiled, or the paper surface may rub against the output stacker when the paper falls and the surface may become soiled.

To wait for the ink to dry without allowing printed documents to fall after printing, set Cutting Mode on the menu of the printer to Eject. (See "Specifying the Cutting Method for Rolls.") —P.802

Windows


- Display the printer driver dialog box.
 (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows).") →P.213
- 2. Select the Main sheet and click C Advanced Settings in A Media Type.






3. In the Paper Detailed Settings dialog box displayed next, select the desired settings values in Between Pages and C Between Scans in A Drying Time, and then click OK.

(See "Paper Detailed Settings Dialog Box (Windows).") -P.220



Mac OS X

- **1.** Choose **Print** in the application menu.
- 2. Select the Main pane and click C Settings in A Media Type.



3. In the Paper Detailed Settings dialog box displayed next, select the desired settings values in C Between Pages and D Between Scans in B Drying Time, and then click OK.

(See "Paper Detailed Settings Dialog Box (Mac OS X).") -P.500



Specifying the Cutting Method for Rolls

How rolls are cut after ejection varies depending on printer settings.

| Cutting Method | | Printer Setting | | Driver Setting | |
|-----------------------|---|---|----------------|--|-------------------------------|
| Automatic | The roll is automatically cut by the Cutter Unit following printer driver settings. | Media Menu > | Automat- ic | Auto Cut (See | Yes |
| Eject →P.803 | Select this to move the cutter by key operation and cut paper. Although there are cases with Automatic in which the paper falls and the paper surface is scratched when the paper rubs the Output Stacker, you can avoid damaging the paper with this method since you can cut by holding the paper with your hand so that the paper does not fall when cutting, Also, since you can cut while visually confirming the drying of the ink, you can avoid ejecting paper before the ink has dried. To cut the roll with the Cutter Unit, press the Cut button. | Paper Details > (Various Types of Paper) > Cutting Mode | Eject | "Cutting Roll Pa- per After Printing.") →P.196 | Yes |
| Man- ual →P.805 | Select this for paper that cannot be cut with the Cutter Unit and for paper of which the leading edge curls strongly and rubs the printhead. | | Manual | | No Yes Print Cut Guideline |

| Cutting Method | | Printer Setting | | Driver Setting | |
|---------------------------------|--|--|--------|--|-------------------------------|
| Man- ual →P.805 | Use scissors to cut each document from the roll after printing. For continuous printing (if you will cut each page later), select Auto Cut > Yes or select Print Cut Guideline . | Media Menu > Paper Details > (Various Types of Paper) > Cutting Mode | Manual | Auto Cut (See "Cutting Roll Paper After Printing.") →P.196 | No Yes Print Cut Guideline |
| Paper Cut- ting →P.809 | Choose this option if you want to cut pages by pressing Cutter Unit buttons for manual cutting after printing when Auto Cut > No is selected or Print Cut Guideline is selected in the printer driver. Otherwise choose this option if you want to cut the roll edge after loading a roll. | Cut but- ton press- ed | Yes | | No Print Cut Guideline |




Note

- Automatic and Eject are valid only when you have selected **Auto Cut** > **Yes** in the printer driver.
- With Eject, printing does not resume after a series of jobs have been printed continuously until the roll is cut.
- **Eject** is the preset selection in **Cutting Mode** for some types of paper. For this paper, we recommend keeping the preset cutting mode.
- If documents printed using Automatic, Eject, or manual cutting are short, rolls are advanced a specific amount before cutting to prevent problems with cutting and paper ejection. This may create a wider bottom margin, in some cases.

Cut rolls manually in the following cases:


Eject (when the paper surface is being scratched / to wait for ink to dry)





Important

- When cutting wide printed documents after ejection, have two people support the documents. If the paper drops, printed documents may be damaged.
- Do not lift the paper when holding printed documents before cutting. If the paper rises, it may affect the printing quality or cause rough cut edges.






Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Paper Menu** is displayed.
- 3. Press ▲ or ▼ to select Paper Details, and then press the OK button.
- **4.** Press ▲ or ▼ to select the type of paper, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Cutting Mode, and then press the OK button.
- **6.** Press ▲ or ▼ to select **Eject**, and then press the **OK** button.
- 7. Print the job.

 When printing is finished, the printer will stop without cutting.
- **8.** Holding the printed document to prevent it from dropping, press the **Cut** button to cut the roll.



Manual (when using media that cannot be cut with the Cutter Unit)



1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





Note


- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Paper Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Paper Details**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select the type of paper, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Cutting Mode, and then press the OK button.
- **6.** Press ▲ or ▼ to select **Manual**, and then press the **OK** button.
- 7. When Perform the detection of paper leading edge? is displayed, select Perform(recommend).
- **8.** Print the job. The printer stops advancing the paper after printing.

9. Press the **Feed** button.



Roll paper is fed to the specified cut position and then automatically stopped.

 $10 { ilde \cdot}$ Cut the roll paper manually with scissors or the like.




11. Press the OK button.



After the roll is rewound, it stops automatically.

6

Manual (for paper of which the leading edge rubs the printhead)



1. On the **Tab Selection screen** of the Control Panel, press \triangleleft or \triangleright to select the Paper tab (\square).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Paper Menu** is displayed.
- **3.** Press \blacktriangle or \blacktriangledown to select **Paper Details**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select the type of paper, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Cutting Mode, and then press the OK button.
- **6.** Press ▲ or ▼ to select **Manual**, and then press the **OK** button.
- 7. When Perform the detection of paper leading edge? is displayed, select Do not perform.




Note

- If you set the detection of paper leading edge to **Do not perform**, a margin of about 10 cm is created at the paper leading edge when printing starts.
- When the detection of paper leading edge is set to **Do not perform**, printing will start at the position at which the roll was set for the first printing after replacing a roll. Thus, the margin of the paper leading edge will enlarge.

(See "Loading Rolls in the Printer.") →P.786

9. Press \blacktriangle or \blacktriangledown to align the paper leading edge with the (a) position.



10. Print the job.

The printer stops advancing the paper after printing.



Note

• The printer can continue to receive print jobs from computers. If a print job is received and printed here, it can be printed without the margin of about 10 cm being created at the paper leading edge.

11. Press the Feed button.




Roll paper is fed to the specified cut position and then automatically stopped.

_

809

12. Cut the roll paper manually with scissors or the like.



Important


• Cut at the dotted line printed on the paper. If you cut on the printer side of the dotted line, the paper leading edge may rub against the printhead and may deviate from the paper retainer.

13. Press the o_K button.



After the roll is rewound, it stops automatically.

Paper cutting (to have the roll cut at your specified position)



Feed paper the cutting position by pressing ▲ or ▼

Paper Cutting

1. Press the Feed button.

2. Press the ▼ button to advance the roll to the position for cutting.



3. Press the **Cut** button.



4. Press ▲ or ▼ to select **Yes**, and then press the **OK** button. After the roll paper is cut, it is rewound automatically.


Cutting the Leading Edge of Roll Paper Automatically

If the leading edge of a roll is crooked or warped, it may cause an error message or printing problems. In this case, set **Trim Edge First** to **Automatic** or **On** on the Control Panel to have the printer cut the leading edge to make the edge straight after you load a roll.

Trim Edge First offers the following options.

Automatic

If the left and right side of the leading edge of the roll ((a) and (b)) are uneven by 40 mm (1.6 in) or more when you load the roll, the edge is cut an amount relative to the slant to ensure a straight edge, and scraps are removed. The edge is not cut if the unevenness is less than 40 mm. However, paper may sometimes be cut, depending on the state of the leading edge.



• Off


The edge is not cut and scraps are not removed.

6

811

• On

The leading edge is cut off when you load a roll, and scraps are removed. The amount of paper cut from the leading edge varies depending on the type of paper. For more information, see the Paper Reference Guide. (See "Types of Paper.") —P.774





Important

• If the width of the paper differs, setting **Skew Check Lv.** to **Loose** relaxes the accuracy of the paper skew detection feature, and setting it to **Off** ignores the skew detection feature. However, when **Off** is selected and the paper is loaded skewed, a paper jam may result or the Platen may become soiled.




Note

• By default, the setting varies depending on the type of paper. For more information, see the Paper Reference Guide. (See "Types of Paper.") —P.774

Follow these steps to change the Trim Edge First setting.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).






Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Paper Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Paper Details**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select the type of paper, and then press the **OK** button.
- 5. Press ▲ or ▼ to select **Trim Edge First**, and then press the **OK** button.
- **6.** Press **△** or **▼** to select the desired setting option, and then press the **OK** button. This setting takes effect the next time you load a roll.

Reducing Dust from Cutting Rolls

For media such as Backlit Film that are more likely to generate debris when cut, select **CutDustReduct.** > **On** in the **Paper Menu** of the Control Panel. This option reduces debris from cutting by printing black lines at the leading and trailing edges of documents. It may help prevent Printhead damage. You can specify for **CutDustReduct.** to be activated for particular types of paper.






Important

- Do not set **CutDustReduct.** to **On** for paper that wrinkles easily, such as Plain Paper or lightweight paper. This may impair cutting and cause paper jams.
- Borderless printing is not available when **CutDustReduct.** is set to **On**. To use borderless printing, select **CutDustReduct.** > **Off**.

Set CutDustReduct. to On as follows.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- **2.** Press the **OK** button. The **Paper Menu** is displayed.
- 3. Press ▲ or ▼ to select Paper Details, and then press the OK button.
- **4.** Press ▲ or ▼ to select the type of paper loaded in the printer, and then press the **OK** button.
- 5. Press ▲ or ▼ to select CutDustReduct., and then press the OK button.
- **6.** Press ▲ or \blacktriangledown to select **On**, and then press the **OK** button.

813

Handling sheets

| Loading Sheets in the Printer | 813 |
|--|-----|
| Printing From a Desired Starting Point | 817 |
| Removing Sheets | 820 |

Loading Sheets in the Printer

Follow these steps to load sheets in the printer.




Important

- Paper that is wrinkled or warped may jam. If necessary, straighten the paper and reload it.
- Load the paper straight. Loading paper askew will cause an error.



Note

- Loading sheets when a roll is already loaded in the printer may cause jams. We recommend removing rolls before loading sheets. (See "Removing the Roll from the Printer.") —P.794
- To prevent the roll from unwinding if you leave it loaded, wrap a sheet of paper around the roll and tape it.



- Before loading sheets, make sure the printer is clean inside the Top Cover and around the Ejection Guide. If these areas are dirty, we recommend cleaning them in advance. (See "Cleaning Inside the Top Cover.")

 P.1040
- Store unused paper in the original package, away from high temperature, humidity, and direct sunlight.
- 1. Select sheets as the paper source.
 - · If a print job was received

Sheets are automatically selected, and the media type and size specified by the print job are shown on the Display Screen.

Press ▲ or ▼ to select **Load Paper**, and then press the **OK** button.

• If no print job was received

1. Press the **Load** button.




2. Press ▲ or ▼ to select **Load Cut Sheet**, and then press the **OK** button.



Note

• If any paper has been advanced that will not be used, a message is shown requesting you to remove it. Press ▲ or ▼ to select "Yes", and then press the OK button. Remove the paper and go to the next step.


2. Lift the Release Lever and open the Top Cover.





Important

• Do not touch the Linear Scale (a), Carriage Shaft (b), or Fixed Blade (c). This may stain your hands and damage the printer.



- **3.** With a sheet lengthwise and printing-side up, insert it between the Platen (a) and the Paper Retainer (b). Align the edges of the sheet as follows.
 - 1. Align the sheet with the Paper Alignment Line (c) at right.
 - 2. Align the inserted edge of the sheet with the leading edge of the Paper Alignment Line (d), as shown.

When inserted, sheets are automatically held by suction against the Platen.



Important


- Load a sheet so that it is parallel to the Paper Alignment Line at right (c). Loading paper askew will cause an error.
- Warped paper may rub against the Printhead. Straighten paper if it is warped before loading it.



Note

- You can adjust the strength of suction holding paper against the Platen when the Release Lever is up. If it is difficult to load paper, press the ▲ or ▼ button on the Control Panel to adjust the strength. Set suction stronger by pressing the ▲ button or weaker with the ▼ button. Three settings are available. However, even if you increase the suction, it may not be sufficient to hold some types of paper against the Platen well. In this case, use your hand to load the paper.
- Sheets are held in place by suction through holes on the Platen. Although the suction may produce a noise when paper is loaded in some positions, it does not indicate a problem. If the noise is distracting, try moving the paper over slightly to the left or right (up to 1 mm [0.039 in]) while keeping it parallel to the Paper Alignment Line.
- The suction remains on for about 30 seconds during loading. If you cannot finish loading a sheet during this time, pull the sheet away and reinsert it to start the suction again.

4. Lower the Release Lever and close the Top Cover.



If a print job was received

Pressing the **OK** button will advance the paper, and then printing will begin.

· If no print job was received

A menu for selection of the type of paper is shown on the Display Screen.

Press ▲ or ▼ to select the type of paper, and then press the **OK** button.

The printer now starts feeding the paper.



Note

- When using the Output Stacker, if you will print on large, stiff sheets, we recommend adjusting the Output Stacker into the lowest position to prevent printed sheets from being bent. (See "Using the Output Stacker.") —P.823

Printing From a Desired Starting Point

Print on sheets from a desired starting point as follows.

Set Width Detection to Off

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Paper Menu** is displayed.
- 3. Press ▲ or ▼ to select Paper Details, and then press the OK button.
- **4.** Press ▲ or ▼ to select the type of paper, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Width Detection, and then press the OK button.
- **6.** Press **△** or **▼** to select **Off**, and then press the **OK** button.

Load paper in the desired position to start printing from

Follow these instructions to load paper at the desired starting position for printing when Width Detection is Off.

1. If you did not send a print job in advance, a menu for selection of the type of paper is displayed. Press ▲ or ▼ to select the type of paper, and then press the **OK** button.




Note

• If a print job was received before paper was advanced, the media type and size specified by the job are shown on the Display Screen.


Thus, this screen is not displayed. Go to step 2.

- 2. "Width Detection OFF. OK to continue?" is now shown on the Display Screen. Press ▲ or ▼ to select "Leave OFF", and then press the OK button.
- 3. After a menu for selection of the paper size is displayed, press ▲ or ▼ to select the paper size, and then press the OK button.
- **4.** Open the Top Cover and check the position where paper is loaded.




U


To start printing from the current position, close the Top Cover. To reposition the paper, lift the Release Lever.



5. Keeping the right edge of the paper aligned with the extended line of the paper alignment line (a) on the right side of the printer and the position from which to start printing aligned with the groove (b) at the far end of the platen, load the paper.




6. Lower the Release Lever and close the Top Cover.



Removing Sheets

Remove sheets from the printer as follows.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□).






Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Paper Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Eject Paper**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select "Yes", and then press the OK button. The paper is ejected from the front of the printer.


C

820

Removing Sheets iPF8300S



 $\mathbf{6}_{ullet}$ Lower the Release Lever and close the Top Cover.




821

iPF8300S Removing Sheets

| Output Stacker | 822 |
|----------------------------|-------|
| Jsing the Output Stacker | . 823 |
| Storing the Output Stacker | |

Output Stacker



822

a. Output Stacker

A cloth tray that catches ejected documents.

b. White tag

A point of reference for attaching the Output Stacker in the right direction.

Output Stacker iPF8300S

823

c. Basket Arm R and Basket Arm L

Holds the Basket Rod (tag side) attached to the Output Stacker. When the Output Stacker is not used, push it down and store it next to the Stand Leg.

d. Basket Rod (tag side) and Basket Rod (cord side)

Holds the cloth Output Stacker securely in specific positions.

e. Basket Rod

Keeps Basket Arm R and Basket Arm L at the same angle.


f. Rod Holder

Holds the middle of the Basket Rod (cord side).

(See "Using the Output Stacker.") →P.823

Using the Output Stacker

The Output Stacker can be held at four positions, as shown.



• When storing printed documents on the Output Stacker Use position (1).

· When the Output Stacker is not used

Use position (2).

• When the Media Take-up Unit is used, or when the Output Stacker is stored for long periods

Lower it to position (3) for storage. (See "Storing the Output Stacker.") —P.829

When using the Output Stacker again after storage, reattach the Basket Rod on the front of the Output Stacker to the tips of the left and right basket arms and pull it out completely.

• When printing on large, stiff sheets

Use position (3).


Set it to position (4) when printing banners or when printing on delicate paper. (See "Using the output stacker for ejection in front.") —P.825




Important

- When storing printed documents on the Output Stacker, always use it in position (1). If you do not, printed documents may not be dropped into the Output Stacker, and the printed surface may become soiled.
- The Output Stacker can hold one sheet. When printing multiple pages, remove each sheet after it is printed.
- Before using the Output Stacker, remove the Rewind Spool. If you do not, it may prevent printed documents from being held correctly, and they may be scratched.
- The Output Stacker can hold printed documents from rolls that are 62 inches (1,575 mm) long. When printing longer documents, adjust the stacker for ejection in front, or use the optional Media Take-up Unit.

The Output Stacker locks into position if you lift it to position (1) or (2). To lower the Output Stacker, lift the front Basket Rod lightly to release the lock, and then lower the stacker.






Using the output stacker for ejection in front

You can also set the stacker to the following position when printing banners or when printing on delicate paper.




Important

- When using the stacker for ejection in front, always select **Cutting Mode** > **Eject**. Selecting **Automatic** may damage printed documents. (See "Specifying the Cutting Method for Rolls.") —P.802
- During ejection in the front of the printer, be especially careful when using delicate paper or paper that curls easily.
- Depending on the type of paper, the edge may curl or bend during ejection. In this case, straighten out the paper. If the paper is curled or bent, it may damage printed documents.
- Some types of paper may get caught between the Ejection Guide and Output Stacker during ejection. In this case, free the paper from where it is caught. If the paper is caught, it may damage printed documents.
- 1. Lift the Basket Rod gently to release the lock, lower the stacker toward the front, and push it back.




2. Remove the Output Stacker from the printer.


Remove the front Basket Rod from the left and right basket arms, and remove the back Basket Rod and black cord




3. Stow the left and right basket arms. Next, with the Rod Holder still attached, remove the Rod Holder Adapter and put it in front of the printer.




4. Pull out the left and right Basket Hooks from the Ejection Guide.



5. Attach the Basket Rod to the Basket Hooks so that the white tag of the Basket Cloth is on the left.




 $\mathbf{6}_{ullet}$ Form the Basket Cloth into a sloping shape to make it taut, and attach the middle Basket Rod to the Rod Holder.




Storing the Output Stacker

Stow the Output Stacker if you will use the Media Take-up Unit or if you will not use the Output Stacker for an extended period.

1. When the Output Stacker is in the position used when storing printed documents (a), lift the front Basket Rod gently to release the lock, lower the stacker toward the front (b), and push it all the way back.




2. Remove the front Basket Rod from the left and right basket arms. Roll up the Basket Cloth and put it at the back of the Bottom Stand Stay.






Important

• When using the Media Take-up Unit, position the Basket Cloth and Basket Rod so they do not interfere with the Media Take-up Sensor (wave portion). This may impair operation.



3. Push in the left and right basket arms toward the back all the way, until they stop.




Media take-up unit

| Media Take-up Unit (Optional) | 831 |
|---|-------|
| Using the Media Take-up Unit (Optional) | . 831 |
| Enabling Roll Take-Up | |
| Disabling Roll Take-Up | 833 |
| Loading the Rewind Spool on the Media Take-up Unit | 834 |
| Removing Printed Documents from the Media Take-up Unit (Optional) | . 842 |

Media Take-up Unit (Optional)

Use the optional Media Take-up Unit to have documents that are printed on rolls rewound automatically after printing. This is convenient for large-format printing, or when printing large-volume jobs continuously.





Note

- For instructions on installing the Media Take-up Unit, refer to the Media Take-up Unit Setup Guide.
- For information on the types of paper compatible with the Media Take-up Unit, refer to the Paper Reference Guide. (See "Types of Paper.") →P.774
- For Media Take-up Unit instructions, see "Using the Media Take-up Unit (Optional)."

 →P.831

Using the Media Take-up Unit (Optional)

- 1. Turn the printer on. (See "Turning the Printer On and Off.") \rightarrow P.3
- 2. Enable roll take-up. (See "Enabling Roll Take-Up.") P.832
- 3. Load the rewind spool on the media take-up unit. (See "Loading the Rewind Spool on the Media Take-up Unit.")

 P.834
- **4.** Turn on the Media Take-up Unit.

- **5.** Print on the roll.
- **6.** Turn off the Media Take-up Unit.
- 7. Remove the printed document from the media take-up unit. (See "Removing Printed Documents from the Media Take-up Unit (Optional).") (>P.842)
- 8. Disable roll take-up. (See "Disabling Roll Take-Up.") →P.833




Important

- The Media Take-up Unit cannot be used with sheets.
- If you have attached the Output Stacker, always stow it before using the Media Take-up Unit. (See "Storing the Output Stacker.") —P.829
- Position the Basket Cloth and Basket Rod so they do not interfere with the Media Take-up Sensor. This may impair operation. (See "Storing the Output Stacker.") —P.829
- Rolls are not cut automatically when the Media Take-up Unit is used, regardless of the **Cutting Mode** setting in the printer menu or the **Automatic Cutting** setting in the printer driver. However, you can cut paper by pressing the **Cut** button.
- Color tones after printing may change during the ink drying period for some types of paper. Allow ample drying time before the final check of colors, and do not remove printed documents from the Media Take-up Unit too soon.
- In humid environments, documents printed using plenty of ink on relatively insubstantial media such as light-weight Coated Paper may not be retracted evenly by the unit. In this case, take steps to control humidity in the operating environment, or adjust the **Roll DryingTime** setting so that printed documents are retracted after the ink has fully dried.
- In humid environments, documents printed on Fabric Banner or Synthetic Paper may not be retracted evenly by the unit. In this case, take steps to control humidity in the operating environment, or adjust the **Roll DryingTime** setting so that printed documents are retracted after the ink has fully dried.

Enabling Roll Take-Up

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (————————).







- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Take-up Reel**, and then press the **OK** button.

Enabling Roll Take-Up

- **4.** Press ▲ or ▼ to select Use Take-up Reel, and then press the OK button.
- 5. Press ▲ or ▼ to select Enable, and then press the OK button.

Disabling Roll Take-Up

- 1. Press the Cut button.
- 2. Press ▲ or ▼ to select Yes, and then press the OK button. The mode now switches from take-up mode to regular mode.



Note

- The printer will also switch from take-up mode to regular mode if you lift the Release Lever and cut the roll with scissors instead of pressing the **Cut** button.
- 3. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- **4.** Press the **OK** button. The **Set./Adj. Menu** is displayed.
- 5. Press ▲ or ▼ to select Take-up Reel, and then press the OK button.
- **6.** Press ▲ or ▼ to select Use Take-up Reel, and then press the OK button.
- 7. Press ▲ or ▼ to select **Disable**, and then press the **OK** button.

6


Loading the Rewind Spool on the Media Take-up Unit

1. When using the Output Stacker, stow the Output Stacker before this procedure. (See "Storing the Output Stacker.") —P.829




Important


• Position the Basket Cloth and Basket Rod so they do not interfere with the Media Take-up Sensor (wave portion). This may impair operation.




2. Unlock the flange on the left side of the Rewind Spool by lifting the lever (a) from the shaft side. Remove the flange



3. When rewinding rolls with 3-inch paper cores, insert the 3-inch Adapter on the flanges at both ends.








Important

- Definitely load the same size of paper core in the Rewind Spool as that of the roll to be rewound. Using a paper core of a different size may cause rewinding problems.
- 5. Push the flanges in firmly until the paper core is secured in place and push down the lever (a) toward the shaft.






Important

• After the flange is pressed strongly, confirm that the paper core does not move. If you can hold and move the paper core leftward and rightward and there is clearance between the flange and paper core, repeat procedures 2 to 4. If there is clearance, a rewinding problem may result.

6. Load the Rewind Spool on the Media Take-up Unit so that the gear of the Rewind Spool (a) meshes with the gear of the Right Media Take-up Unit (b).






Important

• If the gear of the Rewind Spool (a) does not mesh with the gear of the Right Media Take-up Unit (b), the Media Take-up Unit cannot be turned on.

7. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (-----).






Note


• If the Tab Selection screen is not displayed, press the Menu button.

- **8.** Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **9.** Press ▲ or ▼ to select **Take-up Reel**, and then press the **OK** button.
- **10.** Press ▲ or ▼ to select **Auto Feed**, and then press the **OK** button. The roll is now advanced to the Media Take-up Unit.

11. Hold the roll paper by the middle of the leading edge and align the right edge with the right edge of the paper core of the Rewind Spool. With the left and right edges of the roll paper evenly taut, tape the middle to the paper core to fasten it.



12. Making sure the roll paper is not slack, tape the left and right side of the leading edge to the paper core.







Note

• When rewinding heavyweight paper, use strong adhesive tape to fasten it. Otherwise, a rewinding problem may result.

13. Press the ▼ button to make the roll a little slack.




14. On the Right Media Take-up Unit, pull the Rewind Mode Switch forward to turn it on. Press the ▼ button to rewind the roll so that it is nearly taut.




Important

- Rewind the paper so that the paper core makes at least two revolutions. If the paper is not rewound two full revolutions, repeat steps 13 and 14.
- Do not manually force the Rewind Spool or paper core to rotate them. This may damage them. To rewind or unwind rolls, press ▲ or ▼ on the Media Take-up Unit.

15. You can unwind rolls by holding down ▼ on the control panel.



16. Refer to the following table and securely insert the Weight Flange and Weight Joint suitable for the type and width of roll into the Weight Roll.



The following list identifies Weight Roll and Weight Flange you can use. A Color Label is applied to each Weight Roll.

Weight Roll

| vvoignt rton | |
|--------------------------------|--------------------|
| Roll Width | Weight Roll to Use |
| B2 Width: 515.0 mm (20.3 in) | D |
| B1 Width: 728.0 mm (28.7 in) | A+E |
| B0 Width: 1,030.0 mm (40.6 in) | A+G |
| A1 Width: 594.0 mm (23.4 in) | E |
| A0 Width: 841.0 mm (33.1 in) | В+Е |
| 431.8 mm (17 in) | C |
| 609.6 mm (24 in) | E |
| 762.0 mm (30 in) | B+D |
| 914.4 mm (36 in) | G |
| 1,066.8 mm (42 in) | C+E |
| 1,117.6 mm (44 in) | D+E |

6

Weight Flange

| Roll Type | Weight Flange to Use |
|--|-------------------------|
| Glossy Photo Paper, Semi-Glossy Photo Paper, Heavyweight Glossy Photo Paper, Heavyweight SemiGlossy Photo Paper, Fine Art Photo Paper, Fine Art Heavyweight Photo Paper, Fine Art Textured Paper, Canvas Matte, Fine Art Block Print, Fine Art Watercolor, Proofing Paper, Coated Paper, Heavyweight Coated Paper, Extra Heavyweight Coated Paper, Colored Coated Paper, Synthetic Paper, Adhesive Synthetic Paper, Backprint Film, Backlit Film, Flame-Resistant Cloth, Fabric Banner, Thin Fabric Banner | Weight Flange 1 (*1) |
| Premium Matte Paper | Weight Flange 2 |

*1: If you cannot retract stiff paper well using Weight Flange 1 or if the diameter of the retracted paper is wider than the Rewind Spool, use Weight Flange 2. When using Weight Flange 2, adjust the paper feed amount by executing Auto(GenuinePpr) or Auto(OtherPaper). (See "Automatic Banding Adjustment (Adj. Quality).")

P.857



Important


- Do not use combinations other than those identified here.
- Insert the Weight Flange and Weight Joint firmly on the Weight Roll.
- Use identical Weight Flange on the left and right ends. Insert matching Weight Flanges (1 or 2) on both ends of the Weight Roll.



Note

• Keep unused weight rolls, weight joints, and weight flanges handy by putting them in the box and putting the box under the Stand.

17. Set the Weight Roll gently on top of the slack in the roll paper.



The media take-up unit is now ready for use. Printed rolls can now be rewound automatically.



Important

- Always set the Weight Roll on the paper. Failure to do this may cause rewinding problems.
- When setting the Weight Roll on the paper, avoid touching the paper core and causing the wound roll to become misaligned on the left and right end. If it is misaligned on the left and right ends, a rewinding problem may result.

Note

• When the media take-up unit is in use, an icon indicating the take-up mode is shown on the Display Screen.




Removing Printed Documents from the Media Take-up Unit (Optional)

1. Press the **Feed** button.




2. Hold down the ▼ button to advance the roll a little.

To protect the paper that has been rewound, advance it an amount longer than the outer circumference.



3. Remove the Weight Roll from the roll paper.



4. Press the **Cut** button.




5. Press ▲ or ▼ to select Yes. As you hold the trailing edge of the printed document, press the OK button. The roll is now cut.



Important

• Always hold the trailing edge of printed documents when cutting rolls. If you do not hold the documents, they may fall on the floor and the printed surface may become soiled.

6. Hold the trailing edge of the printed document and press the ▼ button on the Media Take-up Unit to rewind the printed document.




Apply adhesive tape to the rewound paper to hold it in place, if necessary.



Important


• Be careful not to scratch the printed surface.

7. Turn off the Media Take-up Unit by pushing in the Rewind Mode Switch.



6


8. Remove the Rewind Spool from the Media Take-up Unit.






Important

- Always turn off the Media Take-up Unit before removing the Rewind Spool. The Media Take-up Unit may be damaged if you do not turn it off first.
- Remove the Rewind Spool, pulling off both ends from the Media Take-up Unit at once. If you do not pull off both ends at once, the Media Take-up Unit may become damaged.
- 9. Unlock the flange on the left side of the Rewind Spool by lifting the lever (a) from the shaft side. Remove the flange.



10. Remove the entire paper core with the rewound printed documents from the Rewind Spool.






Note

• You can leave the Rewind Spool on the Media Take-up Unit even when it is not used for rewinding rolls

6

Adjustments for Better Print Quality

| Adjustment for high-precision printing | 848 |
|--|-----|
| Adjusting the Printhead | 850 |
| Adjusting the feed amount | 856 |
| Color adjustment | 865 |



Adjustment for high-precision printing

Enhancing Printing Quality

With some types of paper and under some conditions, adjusting the printer as follows with the paper to be used can enhance printing quality when printing fine lines/text or photos.

Two adjustment options are available: standard adjustment (with the Printhead height set to **Automatic**) and supplemental adjustment (used if standard adjustment is not effective).



Important

• Ideal temperature and humidity during adjustment and for printing in general when the Printhead height is set to **Automatic** are 20–30°C and 30–60%. Under other environmental conditions, adjustment may not enhance printing quality.



Note

• Paper used for adjustment must conform to the following specifications.

Type: Glossy or semi-glossy photo paper, or proofing paper (in either case, roll paper only)

Thickness/weight: 300 μm or less, or 300 g/m² or less

Width: 25.4 cm (10 in.) or more

Standard Adjustment

Perform standard adjustment with the Printhead height set to Automatic.

- **1.** Load paper in the printer.
 - Attaching the Roll Holder to Rolls →P.782
 - Loading Rolls in the Printer →P.786
- 2. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (().



Note

- Auto(Expansion) may be unavailable in some cases, even if it is displayed in the menu. If so, execute Auto(Advanced) once.
- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 3. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **4.** Press ▲ or ▼ to select **Adjust Printer**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select **Head Posi. Adj.**, and then press the **OK** button.
- **6.** Press ▲ or ▼ to select **Auto(Expansion)**, and then press the **OK** button.

A test pattern is printed for adjustment. This process will take about 11 minutes.



Note

• If standard adjustment does not enhance printing quality, next try supplemental adjustment, which may be helpful.

Supplemental Adjustment

Perform supplemental adjustment with the Printhead height set to Super Low.



Important

- Printing with **Head Height** set to **Super Low** may enhance printing quality, but it may also cause paper to rub against or become caught on the Printhead, which may cause paper jams or soiling on printed documents.
- 1. Set **Head Height** to **Super Low**. (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).")

 •• P.854



Note

- If **Super Low** is not available, select **Lowest**.
- 2. In Head Posi. Adj., select Auto(Expansion).



Note

• If paper rubs against the Printhead or becomes jammed during Printhead height adjustment, try selecting a higher level in **Head Height** and performing **Auto(Expansion)** again.

Adjusting the Printhead

| Adjusting the Printhead | 850 |
|---|-----|
| Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.) | |
| Manual Adjustment to Straighten Lines and Colors (Head Posi. Adj.) | |
| Troubleshooting Paper Abrasion and Blurry Images (Head Height) | 854 |

Adjusting the Printhead

If printed documents are affected by the following problems, try adjusting the printhead.

- Printed vertical lines are warped or colors are out of alignment
 Execute Head Posi. Adj. to adjust the printhead position.
 Normally, execute Auto(Standard), Auto(Advanced), or Auto(Expansion). However, when using special paper or if printing is not improved after executing Auto(Advanced), try Manual.
 (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") P.850
 (See "Manual Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") P.852
- Paper rubs against the printhead, or image edges are blurred
 Executing Head Height to adjust the printhead height may improve printing results.


 (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") →P.854

Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.)

If vertical lines in printed documents are warped or colors are out of alignment, execute **Head Posi. Adj.**. The printer will print and read a test pattern, and the Printhead position will be adjusted automatically.

There are three modes for automatic Printhead adjustment: Auto(Standard), Auto(Advanced) and Auto(Expansion).

- Auto(Standard)
 Fixes slight distortion and color misalignment.
- Auto(Advanced)
 Try adjustment in this mode if Auto(Standard) does not improve printing.
- Auto(Expansion)
 Try adjustment in this mode if vertical lines are warped or colors are out of alignment when the printer driver option Print Priority is set to Proof.







Important

• This function is not available with CAD Tracing Paper, CAD Translucent Matte Film, or CAD Clear Film. If adjustment is not possible as expected using highly transparent film or similar media, try another type of paper, or try **Manual** adjustment.

(See "Manual Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") P.852



Note

- Because the results of adjustment vary depending on the type of paper used for adjustment, use the same type of paper as you will use for printing. Even if you will print on a different type of paper, we recommend using **Auto(Advanced)** for adjustment.
- If **Auto(Advanced)** does not improve printing, try adjustment in **Manual** mode. (See "Manual Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") ¬P.852
- Advanced adjustment can enable superior printing quality when printing fine lines or text at high precision on glossy or semi-glossy photo or proofing paper.
 (See "Enhancing Printing Quality.") —P.848

Items to Prepare

| When Using Rolls | An unused roll at least 10 inches wide | |
|-------------------|---|--|
| When Using Sheets | Auto(Standard): Three sheets of unused paper, A4/Letter size (or one sheet when using A2) Auto(Advanced): 11 sheets of unused paper, A4/Letter size (or three sheets when using A2) Auto(Expansion): Seven sheets of unused paper, A4/Letter size (or two sheets when using A2) | |


Perform adjustment as follows.

- **1.** Load paper.
 - Attaching the Roll Holder to Rolls →P.782
 - Loading Rolls in the Printer →P.786
 - Loading Sheets in the Printer →P.813



Important

- Always make sure the loaded paper matches the type of paper specified on the printer. Adjustment cannot be completed correctly unless the loaded paper matches the settings.
- 2. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐).





lote

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

- **3.** Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **4.** Press ▲ or ▼ to select **Adjust Printer**, and then press the **OK** button.

- 5. Press ▲ or ▼ to select **Head Posi. Adj.**, and then press the **OK** button.
- 6. Press ▲ or ▼ to select Auto(Standard), Auto(Advanced), or Auto(Expansion), and then press the OK button. A test pattern is printed for adjustment.

Adjustment is now finished if you have printed on a roll.



Note

- **Auto(Expansion)** may be unavailable in some cases, even if it is displayed in the menu. If so, execute **Auto(Advanced)** once.
- 7. If you are printing on sheets, a confirmation message is displayed requesting you to continue printing. Press the **OK** button and follow the instructions displayed.

Manual Adjustment to Straighten Lines and Colors (Head Posi. Adj.)


If printed vertical lines are warped or colors are out of alignment, execute **Head Posi. Adj.** to adjust the Printhead alignment.

Normally, execute Auto(Standard), Auto(Advanced), or Auto(Expansion).

(See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") →P.850

However, when printing on special paper, or if printing is not improved after Auto(Advanced), try Manual.

Manual adjustment requires you to examine the printed test pattern and enter an adjustment value.







Note

• We recommend using the type of paper you use most often for adjustment.

Items to Prepare

| When Using Rolls | An unused roll at least 10 inches wide | |
|-------------------|---|---|
| When Using Sheets | Three sheets of unused paper, A4/Letter size (or one sheet when using A2) | 1 |

Perform adjustment as follows.

- 1. Load paper.
 - Attaching the Roll Holder to Rolls →P.782
 - Loading Rolls in the Printer →P.786
 - Loading Sheets in the Printer →P.813




Important

• Always make sure the loaded paper matches the type of paper specified on the printer. Adjustment cannot be completed correctly unless the loaded paper matches the settings.

7

2. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐).






Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 3. Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- **4.** Press ▲ or ▼ to select **Adjust Printer**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select **Head Posi. Adj.**, and then press the **OK** button.
- **6.** Press ▲ or ▼ to select **Manual**, and then press the **OK** button. A test pattern is printed for adjustment.



Note

- Manual may be unavailable in some cases, even if it is displayed in the menu. If so, execute Auto(Advanced) once.
- 7. Press \triangle or ∇ to select **D**, and then press the **OK** button.
- **8.** Press \triangle or ∇ to select **D-1**, and then press the **OK** button.
- **9.** Examine adjustment test pattern **D-1** and determine the number with straight lines.





Note

• If two patterns seem equally good and you cannot decide which one is better, choose an intermediate value.

For example, choose 11 if you cannot decide whether pattern 10 or 12 is better.

- 10. Press ▲ or ▼ to select the pattern number you have decided, and then press the OK button.
- 11. Repeat steps 8–10 to specify the adjustment value for D-1 to D-8, D-10 to D-20, D-22 to D-32, and D-34 to D-36.
- **12.** Press the **Back** button.
- **13.** Press ▲ or ▼ to select **Register Setting**, and then press the **OK** button.
- **14.** Press ▲ or ▼ to select **Yes**, and then press the **OK** button. The adjustment value is now registered, and adjustment is complete.

Troubleshooting Paper Abrasion and Blurry Images (Head Height)

The Printhead height setting affects printing quality.

Specifying a low Printhead height makes images clearer and enhances printing quality but may cause paper to rub against the Printhead.

On the other hand, specifying a high Printhead height will prevent paper from rubbing against the Printhead but may reduce the printing quality.



Important

• Paper rubbing against or becoming caught on the Printhead may jam or result in printed documents that are soiled.



Note

• Raise or lower the printhead, depending on the nature of the problem.

(See "Paper rubs against the printhead.") →P.1072

(See "The edges of the paper are dirty.") →P.1073

(See "Image edges are blurred or white banding occurs.") →P.1077

1. On the **Tab Selection screen** of the Control Panel, press \blacktriangleleft or \blacktriangleright to select the Paper tab (\Box).





Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

- 2. Press the **OK** button. The **Paper Menu** is displayed.
- 3. Press ▲ or ▼ to select Paper Details, and then press the OK button.

4. Press ▲ or ▼ to select the type of paper, and then press the **OK** button.



Note

• When **Head Height** is set to **Automatic**, the setting value selected for the previous print job is displayed (to the right of **Automatic**) once you select the type of paper currently supplied. However, the value is cleared when the printer is turned off or the paper is replaced.



- 5. Press ▲ or ▼ to select **Head Height**, and then press the **OK** button.
- **6.** Press ▲ or ▼ to select the desired setting value, and then press the **OK** button.



Note

- Using **Automatic** will ensure that the printer adjusts the Printhead height to the optimal level before printing, accounting for the ambient temperature and humidity. When a setting other than **Automatic** is used, that value will always be applied.
- Depending on the type of paper, some setting values may not be available.

856

Adjusting the feed amount

| Adjusting the Feed Amount | 856 |
|---|-----|
| Selecting a Feed Amount Adjustment Method (Feed Priority) | |
| Automatic Banding Adjustment (Adj. Quality) | 857 |
| Manual Banding Adjustment (Adj. Quality) | |
| Fine-Tuning the Paper Feed Amount (Adj. Fine Feed) | |
| Adjusting Line Length (Adjust Length) | |
| Adjusting the Vacuum Strength (VacuumStrngth) | 863 |

Adjusting the Feed Amount

If printed documents are affected by the following problems, try adjusting the feed amount.

- Banding in different colors
- Line length is not accurate in the direction paper is fed

To adjust the feed amount, do the following, in this order.

- Depending on the issue, adjust Adj. Priority to suit the particular type of paper. (See "Selecting a Feed Amount Adjustment Method (Feed Priority).") →P.856
- 2. Execute Adj. Quality or Adjust Length, depending on the selection in Adj. Priority. (See "Automatic Banding Adjustment (Adj. Quality).") →P.857 (See "Manual Banding Adjustment (Adj. Quality).") →P.859 (See "Adjusting Line Length (Adjust Length).") →P.861
- 3. After executing Adj. Quality, execute Adj. Fine Feed for further adjustment as needed. (See "Fine-Tuning the Paper Feed Amount (Adj. Fine Feed).") P.861

Selecting a Feed Amount Adjustment Method (Feed Priority)

Methods of adjusting the amount paper is fed are set in **Adj. Priority**. Adjust **Adj. Priority** to suit your particular printing application.

- Print Quality: Adjusts the feed amount to reduce banding across the sheet in printed documents.
 Adj. Quality settings are applied. When Adj. Fine Feed is executed, the Adj. Fine Feed settings are applied in addition to the Adj. Quality settings.
- **Print Length**: Adjusts the feed amount for better accuracy of lines in printed documents. The settings of **A:High** or **B:Standard/Draft** in **Adjust Length** are applied.
- Automatic: Print Quality or Print Length is selected, depending on Print Priority as selected in the printer driver at the time of printing.

Image or Office Document: Print Quality is selected. Line Drawing/Text: Print Length is selected.



Note

- Either A:High or B:Standard/Draft in the Adjust Length menu is applied, depending on printer driver settings at the time of printing.
- If you have selected Easy Settings in the printer driver, follow these steps to confirm the Print Priority setting.
 - Windows: Click View Settings on the Main tab to display the View Settings dialog box.
 - Mac OS X: Click View set. on the Main pane to display the View settings dialog box.

Follow these steps to configure the settings.

- **1.** Load the paper.
 - Attaching the Roll Holder to Rolls →P.782
 - Loading Rolls in the Printer →P.786
 - Loading Sheets in the Printer →P.813
- 2. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab ().





Vote

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- **3.** Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **4.** Press ▲ or ▼ to select **Adjust Printer**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Feed Priority, and then press the OK button.
- **6.** Press ▲ or ▼ to select **Adj. Priority**, and then press the **OK** button.
- 7. Press ▲ or ▼ to select Automatic, Print Quality, or Print Length, and then press the OK button.

Automatic Banding Adjustment (Adj. Quality)

If printed images are affected by banding in different colors across the sheet, execute **Adj. Quality** for automatic adjustment of the paper feed amount.

There are two modes of automatic adjustment to correct banding: **Auto(GenuinePpr)** and **Auto(OtherPaper)**. In either mode, the printer prints and reads a test pattern for automatic adjustment of the feed amount.

• Auto(GenuinePpr)

Use this mode with paper identified in the Paper Reference Guide. (See "Types of Paper.") —P.774

• Auto(OtherPaper)

Use this mode with paper not in the Paper Reference Guide, or if **Auto(GenuinePpr)** does not eliminate banding. (See "Types of Paper.") —P.774



Important

• Adjustment is not possible with **Auto(GenuinePpr)** and **Auto(OtherPaper)** when using highly transparent media.

In this case, use **Manual** adjustment.

(See "Manual Banding Adjustment (Adj. Quality).") →P.859



Note

- Use paper of the same type and size for adjustment as you will use for printing.
- Always check the **Adj. Priority** values before using **Auto(GenuinePpr)** or **Auto(OtherPaper)**. (See "Selecting a Feed Amount Adjustment Method (Feed Priority).") —P.856
- If additional fine-tuning is necessary after Auto(GenuinePpr) and Auto(OtherPaper), execute Adj. Fine Feed.

(See "Fine-Tuning the Paper Feed Amount (Adj. Fine Feed).") →P.861

- Use **Adjust Length** to ensure that lines in CAD drawings are printed at exactly the right length. (See "Adjusting Line Length (Adjust Length).") —P.861
- This may take some time, depending on the type of paper.

Items to Prepare

| When Using Rolls | An unused roll at least 10 inches wide | |
|-------------------|---|--|
| When Using Sheets | Auto(GenuinePpr): One sheet of unused paper, A4/Letter size Auto(OtherPaper): Two sheets of unused paper, A4/Letter size (or one sheet when using A2) | |

Perform adjustment as follows.

1. Load the paper.


- Attaching the Roll Holder to Rolls →P.782
- Loading Rolls in the Printer →P.786
- Loading Sheets in the Printer →P.813



Important

• Always make sure the loaded paper matches the type of paper specified in the settings. Adjustment cannot be completed correctly unless the loaded paper matches the settings.

2. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐☐☐).





Note

• If the Tab Selection screen is not displayed, press the Menu button.

- Press the OK button.
 The Set./Adj. Menu is displayed.
- **4.** Press ▲ or ▼ to select **Adjust Printer**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Feed Priority, and then press the OK button.
- **6.** Press ▲ or ▼ to select **Adj. Quality**, and then press the **OK** button.
- 7. Press ▲ or ▼ to select Auto(GenuinePpr) or Auto(OtherPaper), and then press the OK button. A test pattern is printed for adjustment.
 Adjustment is now finished if you have printed on a roll or a sheet of A2 size or larger.
- **8.** If you are printing on sheets smaller than A2 size for **Auto(OtherPaper)**, a confirmation message is shown on the Display Screen requesting you to continue printing.

 Press the **OK** button and follow the instructions on the Display Screen.

Manual Banding Adjustment (Adj. Quality)

If printed images are affected by banding in different colors, execute **Adj. Quality** for adjustment of the paper feed amount. Use **Manual** adjustment with highly transparent media or other paper for which **Auto(GenuinePpr)** or **Auto(OtherPaper)** cannot be used.

(See "Automatic Banding Adjustment (Adj. Quality).") →P.857

Manual adjustment requires you to enter an adjustment value after a test pattern is printed.



Note

- Use paper of the same type and size for adjustment as you will use for printing.
- Always check the Adj. Priority values before using Manual adjustment.
 (See "Selecting a Feed Amount Adjustment Method (Feed Priority).") P.856
- If additional fine-tuning is necessary after **Manual** adjustment, use **Adj. Fine Feed** (See "Fine-Tuning the Paper Feed Amount (Adj. Fine Feed).") —P.861
- Use **Adjust Length** to ensure that lines in CAD drawings are printed at exactly the right length. (See "Adjusting Line Length (Adjust Length).") —P.861

Paper to Prepare

| When Using Rolls | |
|-------------------|---|
| When Using Sheets | Two sheets of unused paper of at least A4/Letter size |

Perform adjustment as follows.

- **1.** Load the paper.
 - Attaching the Roll Holder to Rolls →P.782
 - Loading Rolls in the Printer →P.786
 - Loading Sheets in the Printer →P.813



Important

• Always make sure the loaded paper matches the type of paper specified. Adjustment cannot be completed correctly unless the loaded paper matches the settings.





Note


- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- **3.** Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **4.** Press ▲ or ▼ to select **Adjust Printer**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Feed Priority, and then press the OK button.
- **6.** Press ▲ or ▼ to select **Adj. Quality**, and then press the **OK** button.
- 7. Press ▲ or ▼ to select Manual, and then press the OK button. Test pattern A is printed for manual adjustment.



Note

• When printing on sheets, follow the instructions on the Display Screen and remove the sheet.

8. Examine test pattern A for adjustment. Determine the pattern in which banding is least noticeable.





Note

• If banding seems least noticeable in two patterns but you cannot decide which one is better, choose an intermediate value.

For example, choose 11 if you cannot decide whether pattern 10 or 12 is better.

9. Press ▲ or ▼ to select the pattern number you have decided, and then press the OK button. Test pattern B is printed for adjustment.



Note

• If you printed test pattern A on a sheet, follow the instructions on the Display Screen and use another sheet of the same type of paper.

Additionally, after test pattern B is printed, follow the instructions on the Display Screen and remove the sheet.

- 10. Examine test pattern B for adjustment. Determine the pattern in which banding is least noticeable.
- 11. Press ▲ or ▼ to select the pattern number you have decided, and then press the **OK** button. The adjustment value is now registered, and adjustment is complete.

Fine-Tuning the Paper Feed Amount (Adj. Fine Feed)

If the contrast is uneven or banding in different colors appears at 50 mm (2.0 in) intervals in printed documents, try executing **Adj. Fine Feed** during printing to fine-tune the feed amount.



Note

• Always execute Adj. Quality before Adj. Fine Feed.


Once you execute **Adj. Quality**, the **Adj. Fine Feed** value will revert to 0.

(See "Automatic Banding Adjustment (Adj. Quality).") -P.857

(See "Manual Banding Adjustment (Adj. Quality).") →P.859

Perform adjustment as follows.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐☐☐).





Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Adj. Fine Feed**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select a setting value in the range -5 to +5, and then press the **OK** button. The setting is now applied.

Adjusting Line Length (Adjust Length)

To ensure that lines in CAD drawings are printed at exactly the right length, use **Adjust Length** to adjust the amount that paper is advanced.

There are two options in Adjust Length: AdjustmentPrint and Change Settings.

• AdjustmentPrint

After a test pattern is printed, you will measure the discrepancy based on the results of printing.

Change Settings

No test pattern is printed. Instead, you will measure a document already printed to determine the discrepancy.

Choose the mode that suits your particular printing application.

· A:High

This setting is applied when **Highest quality** or **High** is selected in **Print Quality** in the printer driver.

Additionally, two modes are available in both AdjustmentPrint and Change Settings: A: High or B:Standard/Draft.

• B:Standard/Draft

This setting is applied when Standard or Fast is selected in Print Quality in the printer driver.



Note

- Always check the **Adj. Priority** values before using **Adjust Length**. (See "Selecting a Feed Amount Adjustment Method (Feed Priority).") P.856
- Use paper of the same type and size for adjustment as you will use for printing.

Paper to Prepare

| When Using Rolls | An unused roll at least 10 inches wide | | |
|-------------------|--|--|--|
| | High-precision ruler | | |
| When Using Sheets | • One sheet of unused paper of at least A4/Letter size | | |
| | High-precision ruler | | |

Perform adjustment as follows.

- **1.** Load the paper.
 - Attaching the Roll Holder to Rolls →P.782
 - Loading Rolls in the Printer →P.786
 - Loading Sheets in the Printer →P.813



Important

- Always make sure the loaded paper matches the type of paper specified. Adjustment cannot be completed correctly unless the loaded paper matches the settings.
- 2. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (-i--).






Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

- 3. Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- **4.** Press ▲ or ▼ to select **Adjust Printer**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Feed Priority, and then press the OK button.

- **6.** Press ▲ or ▼ to select **Adjust Length**, and then press the **OK** button.
- 7. Press ▲ or ▼ to select AdjustmentPrint or Change Settings, and then press the OK button.

 When you select AdjustmentPrint, a test pattern is printed for you to measure the scale and calculate the discrepancy. The scale bar shows Millimeter in 50 mm units and Inch in 1 inch units.





Note

- A test pattern is printed in black when you choose **A:High** or in magenta if you choose **B:Standard/ Draft**.
- To cancel printing the test pattern for adjustment, hold down the **Stop** button. When "**Stop printing?**" is displayed, press ▲ or ▼ to select "**Yes**", and then press the **OK** button.
- 8. Press ▲ or ▼ to enter the amount of discrepancy, and then press the **OK** button. If the scale is shorter than the actual size, use a positive setting value. If it is longer, use a negative value. The feed amount can be adjusted in 0.02% increments.

Adjusting the Vacuum Strength (VacuumStrngth)

When printing on heavyweight paper or paper that curls or wrinkles easily, if the Printhead rubs against paper, adjusting the level of suction against paper on the Platen may improve results.



Important

- Paper rubbing against or becoming caught on the Printhead may jam or result in printed documents that are soiled
- 1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Paper tab (□□).





Note


- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Paper Menu** is displayed.
- 3. Press ▲ or ▼ to select Paper Details, and then press the OK button.

4. Press ▲ or ▼ to select the type of paper, and then press the **OK** button.



Note

• When **VacuumStrngth** is set to **Automatic**, the setting value selected for the previous print job is displayed (to the right of **Automatic**) once you select the type of paper currently supplied. However, the value is cleared when the printer is turned off or the paper is replaced.



- 5. Press ▲ or ▼ to select VacuumStrngth, and then press the OK button.
- **6.** Press ▲ or ▼ to select the desired setting value, and then press the **OK** button.

Color adjustment

| Using Color Calibration for Color Adjustment | 865 |
|---|-----|
| Paper that can be used in Color Calibration | |
| Printing in Ideal Colors for Light in the Viewing Environment | 871 |
| Selecting Color Tones on Charts Before Printing (Windows) | 872 |
| Selecting Color Tones on Charts Before Printing (Mac OS X) | 876 |
| Printing in Colors Matching the Measured Ambient Light (Windows) | |
| Printing in Colors Matching the Measured Ambient Light (Mac OS X) | 884 |
| Printing Images to Match Monitor Colors | 888 |
| Printing Images to Match Monitor Colors (Windows) | 889 |
| Printing Images to Match Monitor Colors (Mac OS X) | 892 |

Using Color Calibration for Color Adjustment

What is Color Calibration?

Color calibration improves color consistency by compensating for slight differences in how color appears when printing due to individual variations or aging among the printers.

Executing color calibration will print a test pattern, which will be read automatically by a sensor built in the printer.

By this operation, an adjustment value reflecting the print result of the test pattern is set automatically.



Important

- For better color consistency, execute color calibration under the same conditions of temperature and humidity each time.
 - If you execute color calibration under various conditions of temperature and humidity, correct adjustment may not be possible.
- If you execute color calibration with paper classified for common calibration, continue to use the same type of paper for better color consistency.
 - If you execute color calibration with multiple paper types, correct adjustment may not be possible.
- Before color calibration, ensure the printer is not exposed to direct sunlight or other strong sources of light. If the printer is exposed to strong sources of light, correct adjustment may not be possible.

Recommend Timing for Color Calibration

We recommend color calibration in the following situations.

- After initial printer installation
- · After Printhead replacement
- If colors seem different from before, despite using the same printing environment, under the same conditions
- To ensure uniform colors when printing on multiple printers (however, be sure to use the same version of firmware and printer driver, under the same settings)
- When the Execution Guide is displayed (Specifying Execution Guide →P.868)



Note

• You can confirm information of color calibration such as the execution date and executed paper type by the following method.

| | Confirm it on the Control Panel of the printer. | From Set./Adj. Menu, select Adjust Printer > Calibration > Calibration Log. (See "Menu Settings.") →P.938 |
|--|---|---|
| | Print information about the printer. | From Set./Adj. Menu , select Test Print > Status Print . (See "Status Print.") → P.951 |
| | Confirm with imagePROGRAF Status Monitor. (Windows) | On the Information sheet of imagePROGRAF Status Monitor, click the View Calibration Log button. (See "The Features of imagePROGRAF Status Monitor.") —P.426 |
| | Confirm this in the Printer Information dialog box of the printer driver. (Mac OS X) | In the Printer Information dialog box, click the Information tab, and click the View Calibration Log button. (See "Main Pane (Mac OS X).") →P.495 |


Adjustment Types of Color Calibration

Two types of color calibration are available: common calibration and unique calibration.

The adjustment type in which calibration is to be classified is decided in advance according to the paper type for which calibration is to be executed. To confirm the adjustment type in which calibration is to be classified, refer to Paper that can be used in Color Calibration —P.869 .

• Common calibration


If you execute color calibration with paper classified for common calibration, the color calibration adjustment value is set for all print qualities of all paper types (including paper types for which color calibration cannot be executed). If executing color calibration per paper type is unnecessary, you can operate calibration easily in a short time. For better color consistency, continue to use the same type of paper in color calibration.



• Unique calibration

If you execute color calibration with paper types classified for unique calibration, the color calibration adjustment value is set for only the executed paper. The set adjustment value is not applied to paper types other than that for which color calibration was executed.


If unique calibration is not executed, the adjustment value of common calibration is applied when printing.



Executing Color Calibration

Perform adjustment as follows.

- 1. You can confirm whether the paper to be loaded can be used in color calibration.
 - Paper that can be used in Color Calibration →P.869
- **2.** Load the paper.
 - Attaching the Roll Holder to Rolls →P.782
 - Loading Rolls in the Printer →P.786
 - Loading Sheets in the Printer →P.813
- 3. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select (Settings/Adj. tab).





Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

- 4. Press the **OK** button. **Set./Adj. Menu** is displayed.
- 5. Press ▲ or ▼ to select **Adjust Printer**, and then press the **OK** button.
- **6.** Press **△** or **▼** to select **Calibration**, and then press the **OK** button.


7. Press ▲ or ▼ to select **Auto Adjust**, and then press the **OK** button.

After the environment measurements and paper are confirmed, and color calibration is executed, the adjustment value is set automatically.



Note

• A confirmation message may be displayed depending on the paper type.



Although you attempted to execute common calibration, since the paper type differs from that executed the previous time, replace it with the same paper type for which calibration was executed the previous time.

Press ▲ or ▼ to select **Stop**, and then press the **OK** button.

Calibration adjusted value applies only to this paper type.
[Paper Type] xxxxxxxxxx
Continue
Stop

This is displayed in the case of unique calibration.

To continue color calibration, press \blacktriangle or \blacktriangledown to select Continue, and then press the OK button.

• The application of the adjustment value when printing can be set in the printer driver or on the menu of the Control Panel.

However, when the setting value of the printer driver and the setting value of the Control Panel differ, the setting of the printer driver is prioritized.

| Configure on the printer driver menu. (Windows) | Configure Calibration Value. (See "Paper Detailed Settings Dialog Box (Windows).") →P.220 |
|--|---|
| Configure on the printer driver menu. (Mac OS X) | Configure Calibration Value. (See "Paper Detailed Settings Dialog Box (Mac OS X).") →P.500 |
| Configure on the menu of the Control Panel. | From Set./Adj. Menu, select Adjust Printer > Calibration > Use Adj. Value. (See "Menu Settings.") -P.938 |

• After executing color calibration, you can also adjust colors as desired in the printer driver. (See "Adjusting the Color in the Printer Driver.") —P.55

Specifying Execution Guide

Execution Guide is a function in which a guide is displayed on the Control Panel, imagePROGRAF Status Monitor (Windows), imagePROGRAF Printmonitor (Macintosh), or RemoteUI when you execute color calibration. If you enable this function, an Execution Guide is displayed in the following cases.

- When a new Printhead has been installed
- When a certain amount of printing has been executed after color calibration is executed
- When the data of color calibration has been initialized

To enable the function, set "**Set Exec. Guide**" to **On** on the menu of the Control Panel. (See "Menu Settings.") →P.938

Paper that can be used in Color Calibration

Recommended Environment for Use of Paper

Since the recommended use environment varies according to the paper type, use within the recommended environment range suiting the paper type.

For details, refer to the Paper Reference Guide.

Paper Type and Adjustment Type

In color calibration, you can use any of the following paper types.

Also, the adjustment type of color calibration is decided according to the paper type. (See "Using Color Calibration for Color Adjustment.") —P.865

For details, refer to the Paper Reference Guide.

| | Country or Region of Use selected when the print- er driver was installed | | | |
|------------------|--|---------------|--------------------------------|--------------------|
| Paper Type | Japan, Asia, Oceania | EU | North or South Ameri- ca | Adjustment Type |
| HW Coated | Available | Available | Available | Common calibration |
| GlossyPhotoHG170 | Available | Available | Available | Common calibration |
| SemGlsPhotoHG170 | Available | Available | Available | Common calibration |
| GlossyPhotoHG255 | Available | Available | Available | Common calibration |
| SemGlsPhotoHG255 | Available | Available | Available | Common calibration |
| Premium Gl2 280 | Available | Available | Available | Common calibration |
| Prem.SemiGl2 280 | Available | Available | Available | Common calibration |
| Poster Semi-Gl | Available | Available | Available | Common calibration |
| SatinPhoto 190 | Available | Available | Available | Common calibration |
| Proofing Paper | Available | Not available | Available | Common calibration |
| Proofing Paper3 | Available | Not available | Available | Unique calibration |
| FineArt Photo | Available | Available | Available | Common calibration |
| FneArt HW Photo | Available | Available | Available | Common calibration |
| GlossyPhoto 190 | Not available | Available | Available | Common calibration |
| GlossyPhoto 240 | Not available | Available | Available | Common calibration |
| SatinPhoto 240 | Not available | Available | Available | Common calibration |
| RC Photo Luster | Not available | Not available | Available | Unique calibration |
| Comm Proofing | Not available | Available | Available | Common calibration |
| SemiGlProof 195 | Not available | Available | Not available | Unique calibration |
| PhotoProPlat adj | Available | Available | Available | Common calibration |



Note

• For details on the paper that can be used when **PhotoProPlat adj** is selected as the paper type, refer to the Paper Reference Guide.

Paper Sizes that can be Used in Color Calibration

Paper sizes that can be used in color calibration differ for sheets and rolls.

For details, refer to the Paper Reference Guide.

| When Using Rolls | An unused roll at least 10 inches wide (however, a roll at least 16 inches wide depending on the paper type) |
|-------------------|---|
| When Using Sheets | One sheet of unused paper of at least A4/Letter size (however, one sheet of unused paper of at least A2 size depending on the paper type) |

Registration and Confirmation of Paper Information

· To Register Paper Information on the Printer

When using newly released paper, paper information must be registered on the printer and the printer driver. Download the new version of **Media Information File** from the Canon website and install it.

(See "Types of Paper.") →P.774

To Confirm the Paper Information Registered on the Printer

When confirming the paper information registered on the printer, select **Paper Details** on the Control Panel menu, and print the detailed information of the paper.

In the **Calibration** column, **OK(Common)** is displayed for the paper for which common calibration is executed, **OK(Unique)** is displayed for the paper for which unique calibration is executed, and **N/A** is displayed for the paper for which color calibration cannot be executed.



Important

• If, when reinstalling the printer driver, you change the region selection of the Media Configuration Tool, the region-specific paper information originally registered on the printer before installation will be deleted. Using paper with deleted information when executing color calibration will prevent the resulting calibration adjustment value from being applied to all other types of the paper.

To apply the color calibration, prepare paper compatible with color calibration in the newly selected region and perform color calibration again.

(See Media Configuration Tool →P.448 .) (See Media Configuration Tool →P.677 .)

• To restore the default settings, set **Reset PaprSetngs** to **Yes** in **System Setup** in the Control Panel menu. Because paper information added or modified by the Media Configuration Tool is deleted, if you have calibrated the printer using paper with information added by the Media Configuration Tool, color calibration executed this way can no longer be applied to any type of paper.

If you wish to apply calibration results, prepare calibration-compatible paper that was in the original settings and perform calibration again.

(See Media Configuration Tool →P.448 .) (See Media Configuration Tool →P.677 .)

Printing in Ideal Colors for Light in the Viewing Environment

You can print in the colors that look best when viewed under the light where the printed image will be displayed. There are two ways to adjust the color tone for the ambient light, as follows.

• By selecting color tones on **Chart** before printing

On the printed **Chart**, note the number of the set of colors with the desired color tone and enter this number in the printer driver before printing.



Important

- This function is only supported in Windows and Mac OS X 10.4 or later.
- The colors in this function may differ slightly depending on the system software used (Windows 32/64 bit or Macintosh).

For instructions on selecting color tones on **Chart** before printing, refer to the following topic:

- Selecting Color Tones on Charts Before Printing (Windows) —P.872
- Selecting Color Tones on Charts Before Printing (Mac OS X) →P.876
- Printing in Colors Matching the Measured Ambient Light

Measure the light level in the viewing environment and enter the results in the printer driver before printing.



Important

- This function requires the il spectrophotometer. The Light Source Measure Tool must also be installed.
- You can install the Light Source Measure Tool from the User Software CD-ROM.
- For a list of supported i1 devices, refer to the manual provided with the Light Source Measure Tool.
- This function is only supported in Windows and Mac OS X 10.4 or later.
- The colors in this function may differ slightly depending on the system software used (Windows 32/64 bit or Macintosh).

For instructions on measuring light levels before printing, refer to the following topic:

Printing in Colors Matching the Measured Ambient Light (Windows) →P.881

Printing in Colors Matching the Measured Ambient Light (Mac OS X) →P.884

Selecting Color Tones on Charts Before Printing (Windows)

Print **Chart**, note the number of the chart with your desired color tone, and enter this number in the printer driver before printing.




Important

• This function requires that the **Light Source Check Tool** be installed.



Note

- You can install the Light Source Check Tool from the User Software CD-ROM.
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) (-P.211)")
- **3.** Make sure the **Main** sheet is displayed.




872


4. In the A Media Type list, select the type of paper that is loaded (for example, Glossy Photo Paper HG 170).




Important

• You can execute **Ambient Light Adjust** only when **F Print Quality** is set to **High**.






6. In F Print Quality, click High.



- 7. Click Color in the G Color Mode list.
- **8.** Click **H** Color Settings to display the Color Settings dialog box.

9. Click the **Matching** tab to display the **Matching** sheet.




10. Make sure Driver Matching Mode is selected in A Matching Mode.



Note


- To specify monitor matching, select **Monitor Matching** in **B Matching Method**. In this case, select the same color space as when the file was opened in **C Color Space** and the monitor color temperature in **D Monitor White Point**.
- 11. Select E Use ambient light adjustment.
- 12. Click F Ambient Light Adjust to display the Ambient Light Adjust dialog box.




13. Confirm that By selecting a chart number is selected in A Setting Method. If it is not selected already, select it.

14. Click B Print Chart.

Light Source Check Tool now starts up.



15. Check the settings and click D Print. The Chart is printed.




16. In the viewing environment, determine the number of the set of images on the Chart in which all four vertical images have the best overall color tone.



Note

- Choose the number of the set of images in which the people, the blue of the sky, and the red of the strawberries look the most natural overall.
- 17. In the Ambient Light Adjust dialog box, select the number of your preferred chart in C Chart Number.



- 18. If Matching Method is set to Monitor Matching on the Matching sheet, enter the Color Temperature and Elluminance as measured during monitor calibration.
- 19. Click OK.
- **20.** Confirm the print settings and print as desired.


Selecting Color Tones on Charts Before Printing (Mac OS X)

Print **Chart**, note the number of the chart with your desired color tone, and enter this number in the printer driver before printing.


- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Mac OS X).") —P.494

/

3. Make sure the **Main** panel is displayed.




- 4. In the A Media Type list, select the type of paper that is loaded (for example, Glossy Photo Paper HG 170).
 - You can execute Ambient Light Adjust only when F Print Quality is set to High.
- **5.** Click **D** Advanced Settings to switch the print mode.



6. In F Print Quality, click High.



- You can execute Ambient Light Adjust only when F Print Quality is set to High.
- 7. Click Color in the H Color Mode list.
- **8.** Click | Set to display the Color Settings dialog box.
- **9.** Click the **Matching** tab to display the **Matching** panel.





10. Make sure Driver Matching Mode is selected in A Matching Mode.




Note

- To specify monitor matching, select **Monitor Matching** in **B Matching Method**. In this case, select the same color space as when the file was opened in **C Color Space** and the monitor color temperature in **D Monitor White Point**.
- 11. Select E Use ambient light adjustment.






- 13. Confirm that By selecting a chart number is selected in A Setting Method. If it is not selected already, select it.
- 14. Click B Print Chart.
 Light Source Check Tool now starts up.



15. Check the settings and click D Print. The Chart is printed.




16. In the viewing environment, determine the number of the set of images on the Chart in which all four vertical images have the best overall color tone.



Note

- Choose the number of the set of images in which the people, the blue of the sky, and the red of the strawberries look the most natural overall.
- 17. In the Ambient Light Adjust dialog box, select the number of your preferred chart in C Chart Number.



18. If Matching Method is set to Monitor Matching on the Matching panel, enter the Color Temperature and Elluminance as measured during monitor calibration.

7

19. Click OK.

20. Confirm the print settings and print as desired.

Printing in Colors Matching the Measured Ambient Light (Windows)

Measure the light level in the viewing environment and enter the results in the printer driver before printing.



Important

• This function requires the i1 spectrophotometer. The Light Source Measure Tool must also be installed.




Note

- You can install the Light Source Measure Tool from the User Software CD-ROM.
- For a list of supported i1 devices, refer to the manual provided with the Light Source Measure Tool.
- 1. Using the il spectrophotometer and the Light Source Measure Tool, determine the Lighting Source Type, Color Temperature, and Illuminance in the viewing environment.




Note


- For detailed instructions on the il and Light Source Measure Tool, refer to the provided instructions.
- **2.** Choose **Print** in the application menu.
- 3. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")
- **4.** Make sure the **Main** sheet is displayed.



5. In the A Media Type list, select the type of paper that is loaded (for example, Glossy Photo Paper HG 170).



6. Click **D** Advanced Settings to switch the print mode.




7. In F Print Quality, click High.



- **8.** Click Color in the G Color Mode list.
- **9.** Click **H** Color Settings to display the Color Settings dialog box.

10. Click the Matching tab to display the Matching sheet.




11. Make sure **Driver Matching Mode** is selected in **A Matching Mode**.



Note

- To specify monitor matching, select **Monitor Matching** in **B Matching Method**. In this case, select the same color space as when the file was opened in **C Color Space** and the monitor color temperature in **D Monitor White Point**.
- 12. Select E Use ambient light adjustment.
- 13. Click F Ambient Light Adjust to display the Ambient Light Adjust dialog box.



14. Select By entering values directly in A Setting Method.

7

15. Select the **B** Lighting Source Type and **D** Color Temperature determined in step 1.

If you have selected Monitor Matching in Matching Method on the Matching sheet, also select **E** Illuminance.



Note

- If you will print repeatedly using the settings values you set this one time, we recommend completing the settings by accessing the printer driver dialog box from the operating system menu.(See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) (See "Accessing the Printer Driver Drive
- 16. Click OK.
- 17. Confirm the print settings and print as desired.

Printing in Colors Matching the Measured Ambient Light (Mac OS X)

Measure the light level in the viewing environment and enter the results in the printer driver before printing.



Important


- This function requires the i1 spectrophotometer. The Light Source Measure Tool must also be installed.
- You can install the Light Source Measure Tool from the User Software CD-ROM.
- For a list of supported i1 devices, refer to the manual provided with the Light Source Measure Tool.
- 1. Using the il spectrophotometer and the Light Source Measure Tool, determine the Lighting Source Type, Color Temperature, and Illuminance in the viewing environment.




Note

- For detailed instructions on the i1 and Light Source Measure Tool, refer to the provided instructions.
- **2.** Choose **Print** in the application menu.
- 3. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Mac OS X).") -P.494

4. Make sure the **Main** panel is displayed.




- 5. In the A Media Type list, select the type of paper that is loaded (for example, Glossy Photo Paper HG 170).
 - You can execute Ambient Light Adjust only when F Print Quality is set to High.
- **6.** Click **D** Advanced Settings to switch the print mode.



7. In F Print Quality, click High.



- **8.** Click Color in the H Color Mode list.
- **9.** Click | Set to display the Color Settings dialog box.
- 10. Click the Matching tab to display the Matching panel.





11. Make sure Driver Matching Mode is selected in A Matching Mode.



Note

- To specify monitor matching, select **Monitor Matching** in **B Matching Method**. In this case, select the same color space as when the file was opened in **C Color Space** and the monitor color temperature in **D Monitor White Point**.
- 12. Select E Use ambient light adjustment.






- 14. Select By entering values directly in A Setting Method.
- 15. Select the **B** Lighting Source Type and **D** Color Temperature determined in step 1.

 If you have selected Monitor Matching in Matching Method on the Matching panel, also select **E** Illuminance.
- **16.** Click **OK**.
- 17. Confirm the print settings and print as desired.

Adjusting the colors printed so that they more closely match the colors displayed on the monitor is called "monitor matching." Using this mode requires adjustment or configuration of the settings of your monitor, the source application, the file for printing, and the printer driver.



Printed Colors Match Monitor Colors

888

Important

• Monitor matching may not be applied, or these settings may not be configurable or adjustable, depending on your monitor and the source application.



Note

- Printing in exactly the same colors as displayed on the monitor may not be possible due to differences in the monitor and printer color gamuts.
- Calibrating your monitor requires a measuring device.
- Because colors appear different under sunlight at different times of day, we recommend following this procedure in a room not exposed to sunlight.

Monitor Matching

The sequence in monitor matching is as follows.

1. Calibrate the printer.

Calibration improves color consistency by compensating for slight differences in how color appears due to individual variation among printheads or conditions in various printing environments.

(See "Using Color Calibration for Color Adjustment.") →P.865

2. Calibrate the monitor.

Normally, you can use a colorimeter such as the i1-Display.

Set the white point to 6500 K or 5000 K, the gamma to 2.2, and the brightness to 120 cd, and activate light source measurement.

The exact procedure varies depending on your monitor and measurement device.

3. Open the file to print and configure settings in the source application.

Display the file in the sRGB or Adobe RGB color space.

Configure settings to prevent color conversion by the application.

In Photoshop CS3, for example, select **Color Management** in the **Print** dialog box, and then select **No Color Management** in **Color Handling**.

4. Configure and adjust printer driver settings.

Select **Monitor Matching** in **Matching Method**. Specify the **Monitor White Point** set during monitor calibration and the **Color Temperature** and **Illuminance** measured in the ambient light.

In Color Space, select the color space used when displaying the file in the source application.

If you own an i1-Pro, using Light Source Measure Tool enables more precision measurement of the ambient light.



Note

• If you will print repeatedly using the settings values you set this one time, we recommend completing the settings by accessing the printer driver dialog box from the operating system menu. (See "Accessing the Printer Driver Dialog Box from the Operating System Menu (Windows) —P.213 ")

For instructions on configuring printer driver settings for monitor matching, refer to the following topic, as appropriate for your computer and operating system.

- Printing Images to Match Monitor Colors (Windows) —P.889
- Printing Images to Match Monitor Colors (Mac OS X) →P.892

Printing Images to Match Monitor Colors (Windows)


By calibrating your monitor and configuring settings in the source application in advance, you can complete settings to print in colors that are as close as possible to the colors displayed on the monitor.




Important

- Before using this feature, you must calibrate the monitor and configure settings in the source application. (See "Printing Images to Match Monitor Colors P.888")
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Windows) —P.211 ")

3. Make sure the **Main** sheet is displayed.




- 4. In the A Media Type list, select the type of paper that is loaded (for example, Glossy Photo Paper HG 170).
 - You can execute Ambient Light Adjust only when F Print Quality is set to High.
- **5.** Click **D Advanced Settings** to switch the print mode.



6. In F Print Quality, click High.



- You can execute **Ambient Light Adjust** only when **F Print Quality** is set to **High**.
- 7. Click Color in the G Color Mode list.
- **8.** Click H Color Settings to display the Color Settings dialog box.
- **9.** Click the **Matching** tab to display the **Matching** sheet.



- 10. Make sure Driver Matching Mode is selected in A Matching Mode.
- 11. In **B** Matching Method, select Monitor Matching.
- 12. In C Color Space, select the color space used when displaying the file in the source application.
- 13. In D Monitor White Point, select the white point set on the monitor.



lote

• For greater precision in monitor matching, we recommend configuring the settings for ambient light matching. (See "Printing in Ideal Colors for Light in the Viewing Environment —P.871")

- 14. Click OK.
- 15. Confirm the print settings and print as desired.


Printing Images to Match Monitor Colors (Mac OS X)

By calibrating your monitor and configuring settings in the source application in advance, you can complete settings to print in colors that are as close as possible to the colors displayed on the monitor.



Important

- Before using this feature, you must calibrate the monitor and configure settings in the source application. (See "Printing Images to Match Monitor Colors.") P.888
- **1.** Choose **Print** in the application menu.
- 2. Select the printer in the dialog box, and then display the printer driver dialog box. (See "Accessing the Printer Driver Dialog Box from Applications (Mac OS X).") —P.494
- **3.** Make sure the **Main** panel is displayed.




4. In the A Media Type list, select the type of paper that is loaded (for example, Glossy Photo Paper HG 170).




Important

• You can execute Ambient Light Adjust only when F Print Quality is set to High.






6. In F Print Quality, click High.



- 7. Click Color in the H Color Mode list.
- **8.** Click | Set to display the Color Settings dialog box.

9. Click the **Matching** tab to display the **Matching** panel.



- 10. Make sure Driver Matching Mode is selected in A Matching Mode.
- 11. In B Matching Method, select Monitor Matching.
- 12. In Color Space, select the color space used when displaying the file in the source application.
- 13. In D Monitor White Point, select the white point set on the monitor.




Note

• For greater precision in monitor matching, we recommend configuring the settings for ambient light matching. (See "Printing in Ideal Colors for Light in the Viewing Environment.") —P.871

- 14. Click OK.
- 15. Confirm the print settings and print as desired.

Printer Parts


| Printer parts | 896 |
|----------------------|-----|
| Hard Disk | 006 |
| Halu Disk | 906 |
| Optional accessories | 911 |



Printer parts

| Front | |
|-------------------------------|-----|
| Back | 898 |
| Fop Cover (Inside) | 899 |
| Carriage | 900 |
| nk Tank Cover (Inside) | 901 |
| Stand | 903 |
| Media Take-up Unit (Optional) | 904 |

Front



a. Top Cover

Open this cover to install the Printhead, load paper, and remove any jammed paper from inside the printer as needed. (See "Top Cover (Inside).") P.899

iPF8300S

b. Cutter Groove

Paper is cut (using the cutter or manually with scissors) over this groove.

c. Ejection Guide

Guides printed documents as they are ejected. Raise the guide when loading a roll.

d. Roll Holder Slot

Front

Slide the Roll Holder into this slot.

e. Roll Holder

Load the roll on this holder.

f. Ejection Support

Prevents printed documents from winding around the Roll Holder or being drawn into the Paper Feed Slot.

g. Output Stacker

A cloth tray that catches ejected documents. (See "Output Stacker .") P.822

h. Paper Feed Slot

When loading a roll, insert the edge of the roll paper here.

i. Holder Stopper

Secure rolls on the Roll Holder with this part.

j. Ink Tank Cover

Open this cover to replace an Ink Tank. (See "Ink Tank Cover (Inside).") —P.901

k. Control Panel

Use this panel to operate the printer and check the printer status. (See "Control Panel.") —P.914

I. Release Lever

Releases the Paper Retainer. Lift this lever toward the front of the printer when loading paper.

m. Maintenance Cartridge

Absorbs ink used for maintenance purposes such as head cleaning. (Replace the cartridge when it is full.)

n. Carrying Handles

When carrying the printer, have four people hold it by these handles under both sides.

o. Maintenance Cartridge Cover

Open this cover to replace the Maintenance Cartridge.

p. Stand

A stand that holds the printer. Equipped with casters to facilitate moving it. (See "Stand .") →P.903

iPF8300S Front



When carrying the printer, have four people hold it by these handles under both sides.

iPF8300S

b. Media Take-up Unit Power Inlet

Connect the power cord of the optional Media Take-up Unit here.

c. Ethernet Port

Connect an Ethernet cable to this port.

d. USB Port

Connect a USB cable to this port. It supports Hi-Speed USB.

Back


e. Manual Pocket

Store printer manuals in this pocket.

f. Power Supply Connector

Connect the power cord to this connector.

Top Cover (Inside)



a. Top Cover Roller

Prevents paper from rising when ejected.

iPF8300S Top Cover (Inside)

b. Paper Alignment Line

Align paper with this line when loading it.

c. Carriage

Moves the Printhead. The carriage serves a key role in printing. (See "Carriage.") →P.900

d. Carriage Shaft

The Carriage slides along this shaft.

e. Paper Retainer

Important in supplying the paper. This retainer holds paper as it is fed.

f. Platen

The Printhead moves across the platen to print. Vacuum holes on the platen hold paper in place.

g. Borderless Printing Ink Grooves

For catching ink outside the edges of paper during borderless printing.

h. Cleaning Brush

When cleaning inside the printer under the Top Cover, use this brush to sweep away paper dust on the Platen. Also use the brush to move the blue Switch on the Platen.

i. Fixed Blade

The Cutter Unit passes over this rail to cut paper.


j. Linear Scale

The linear scale serves a key role in detecting the Carriage position. Be careful not to touch this part when cleaning inside the Top Cover or clearing paper jams.

k. Switch

Set the switch to the side opposite • if the edges of printed images are blurred. Set the switch to the • side before borderless printing. (See "Setting the Blue Switch on the Platen.") →P.1078

Carriage



a. Carriage Cover

Protects the Carriage.

b. Printhead Fixer Cover

Holds the Printhead in place.

Carriage iPF8300S

c. Printhead L

The printhead is equipped with ink nozzles. The carriage serves a key role in printing.

d. Printhead R

The printhead is equipped with ink nozzles. The carriage serves a key role in printing.

e. Printhead Fixer Lever

Locks the Printhead Fixer Cover.

f. Cutter Unit

A round-bladed cutter for automatic paper cutting. Retracted when not in use.


g. Shaft Cleaner

Prevents the Carriage Shaft from becoming dirty.

h. Cutter Unit Detachment Lever

Used when replacing the Cutter Unit.

Ink Tank Cover (Inside)



Note: The figure shows the printer as loaded with 700 ml (23.7 fl oz) Ink Tank.


a. Ink tanks

Cartridges of ink in various colors.

b. Ink Tank Lock Lever

A lever that locks the Ink Tank in place and protects it. Lift and lower the lever when replacing an Ink Tank. To open it, lift the stopper of the lever until it stops, and then push it down toward the front. To close it, push it down until it clicks into place.

iPF8300S Ink Tank Cover (Inside)



a. Ink Color Label

Load an Ink Tank that matches the color and name on this label.

b. Ink Lamp (Red)

Indicates the state of the Ink Tank as follows when the Ink Tank Cover is opened.

• On

The Ink Tank is installed correctly.

• Off

No Ink Tank is installed, or the ink level detection function is disabled.


Flashing Slowly

Not much ink is left.

Flashing Rapidly

Ink tank is empty.

Stand



a. Stand L

The left leg of the Stand.

b. Stand R

The right leg of the Stand.

c. Top Stand Stay

Supports Stand L and Stand R. Attach the optional Media Take-up Unit to this part.

d. Bottom Stand Stay

Supports Stand L and Stand R.

e. Leg Covers

Covers for Stand L and Stand R.


f. Stopper

Locks the Stand casters.

Always release the Stopper before moving the printer. Moving the printer while the Stopper is locked may scratch the casters or the floor.

iPF8300S Stand

· Main Unit



a. Left Media Take-up Unit

Load the Rewind Spool here.

b. Right Media Take-up Unit

Load the Rewind Spool here. Includes the Media Take-up Unit **Power** button, ▲ and ▼ buttons to advance or rewind paper, and a power cord.

c. Rewind Spool

Winds documents printed on rolls.


d. 3-inch Adapter

When rewinding rolls with 3-inch paper cores, attach the adapter to the Rewind Spool.

e. Media Take-up Sensor

A sensor for automatically rewinding rolls.

Weight



8

Weights required when rewinding rolls. Use one weight roll or combine two (with a Weight Joint), depending on the roll width.

b. Weight Joint

Fastens two weight rolls.

c. Weight Flange (2 sets)

Attached to the ends of Weight Roll to adjust the weight. Use Weight Flange 1 or Weight Flange 2, depending on the type of paper. (See "Loading the Rewind Spool on the Media Take-up Unit.") —P.834

Hard Disk

| Printer Hard Disk Operations | 906 |
|---|-----|
| Checking the Free Hard Disk Space | 907 |
| Erasing Data on the Printer's Hard Disk | |

Printer Hard Disk Operations

Printer hard disk operations are available through the Control Panel and in the printer driver, imagePROGRAF Print Plug-In, RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.

The hard disk operations available through each interface are as follows.

| 0 | peration | Printer Driv- er or image- PROGRAF Print Plug-In | image- PROGRAF Status Moni- tor or image- PROGRAF Printmonitor | Remo- teUI | Control Panel |
|------------------------|---|---|---|---------------|------------------|
| Saving print jobs | Print | Yes | No | No | No |
| | Save in mail box | Yes | No | No | No |
| | Save data before printing(*1) | Yes | No | No | No |
| | Print without saving jobs in the shared mailbox | No | No | No | Yes |
| | Save print jobs sent from sources other than the printer driver | No | No | No | Yes |
| Operations with saved | Print saved jobs | No | Yes | Yes | Yes |
| jobs | Delete saved jobs | No | Yes | Yes | Yes |
| Job queue management | Display job queue | No | Yes | Yes | Yes |
| | Delete | No | Yes | Yes | Yes |
| | Priority | No | Yes | Yes | Yes |
| Mail box management | Move saved jobs | No | Yes | Yes | No |
| | Modify saved jobs | No | Yes | Yes | No |
| | Modify mail boxes | No | Yes | Yes | No |
| | Print a list of saved jobs | No | No | No | Yes |
| | Display a list of saved jobs | No | Yes | Yes | Yes |
| Other operations | Display free hard disk space | No | Yes | Yes | Yes |
| | Initialize hard disk | No | No | No | Yes |
| | Error recovery | No | No | No | Yes |
| Display error messages | | No | Yes | Yes | Yes |

^{*1:} This option is available in combination with **Print**. Print jobs are saved and then printed.

8


Checking the Free Hard Disk Space

Check the space available on the printer's hard disk as follows.

This operation is available from the Control Panel, in RemoteUI, imagePROGRAF Status Monitor, and imagePROGRAF Printmonitor.

Using the Control Panel

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Job tab (......).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Job Menu** is displayed.
- **3.** Press ▲ or ▼ to select **HDD Information**, and then press the **OK** button.


Using RemoteUI

To view the box list, select **Stored Job** in Job Management. On the **Stored Job** page, the free hard disk space is shown in the upper-right corner when boxes are listed.



For details, refer to the RemoteUI help file.


The Hard Disk sheet shows the free hard disk space.



For details, refer to the imagePROGRAF Status Monitor help file.

Using imagePROGRAF Printmonitor

The **Hard Disk** pane shows the free hard disk space.



8

For details, refer to the imagePROGRAF Printmonitor help file.

Erasing Data on the Printer's Hard Disk

When erasing all data on the hard disk, choose from the following three options. This operation is only available from the Control Panel.

| Erasure Method | Details |
|---------------------|--|
| High Speed | Erases file management data for print job data stored on the printer's hard disk. Choose this method for relatively fast erasure. Because only the file management data is erased, the print job data itself is not erased. Note that it may be possible to read this data using commercial data recovery software. |
| Secure High Spd. | Overwrites the entire hard disk with random data. No verification is performed to check if the data was correctly written. Choose this method to erase highly confidential data. Note that it may be possible to read the overwritten data using specialized data recovery tools. |
| Secure | Overwrites the entire hard disk with 00, FF, and random data (one time each). Verification is performed to check if the data was correctly written. Choose this method to erase especially confidential data. It is virtually impossible to recover the overwritten data. Conforms to the DoD5220.22-M standard of the U.S. Department of Defense. |



Important

- For a more secure method of preventing data recovery, we recommend physically or magnetically destroying the hard disk. In this case, the hard disk can no longer be used.
- Erase HDD Data is not available if there is a job queue.

 Additionally, print jobs are not processed during execution of Erase HDD Data.
- 1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **System Setup**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select Erase HDD Data, and then press the OK button.

5. Press ▲ or ▼ to select **High Speed**, **Secure High Spd.**, or **Secure**, and then press the **OK** button to display the confirmation screen.



Note

- If a password has been set on the printer, the **Admin.Pswd** screen is displayed. In this case, enter the password and press the **OK** button to go to the next step.
- As for the time required for deletion, confirm it on the Control Panel. However, when **High Speed** is selected, this finishes in several seconds.
- **6.** Press the **OK** button to start erasure.

 After the printer hard disk is erased, the printer automatically restarts.


Optional accessories

| Roll Holder Set | 911 |
|--------------------|-----|
| Media Take-up Unit | 911 |


Roll Holder Set

Load a roll on the roll holder and then load the holder in the printer. The Roll Holder in the Roll Holder Set RH2-44 is for use with both 2-inch and 3-inch paper cores. Use the correct attachment for the particular paper core. (See "Attaching the Roll Holder to Rolls.") —P.782

- Roll Holder Set RH2-44
 - Roll Holder (for 2- and 3-inch paper cores)




• Attachments



Media Take-up Unit

Automatically winds documents printed on rolls.

iPF8300S Roll Holder Set





Note

- For instructions on installing the Media Take-up Unit, refer to the Media Take-up Unit Setup Guide.
- For information on the types of paper compatible with the Media Take-up Unit, refer to the Paper Reference Guide.
- For Media Take-up Unit instructions, see "Using the Media Take-up Unit (Optional)." —P.831


8

912

Media Take-up Unit iPF8300S


Control Panel

| Operations and Display Screen | 914 |
|-------------------------------|-----|
| Printer Menu | 924 |



| Control Panel | . 914 |
|---|-------|
| Control Panel Display | . 916 |
| How to View Instructions With Navigate | |
| Checking Instructions During Printer Operations | |
| | |

Control Panel



a. Display Screen

Shows printer menus, as well as the printer status and messages.

b. Data Lamp (green)

Flashing

During printing, the Data lamp flashes when the printer is receiving or processing print jobs. Otherwise, this lamp flashes when the print job is paused or the printer is updating the firmware.

Off

There are no active print jobs when the Data lamp is off.

c. Message Lamp (orange)

• On

A warning message is displayed.

Flashing

An error message is displayed.

• Off

The printer is off or is operating normally.

d. Menu button

Displays the **Tab Selection screen**. (See "Menu Settings.") —P.938

e. Arrow buttons

Control Panel

• **◀** button

Press this button on the **Tab Selection screen** to move to another tab.

9

In menu items requiring numerical input, press this button to move to another digit.

▲ button

Press this button when viewing menus to display the next menu item or setting value.

• button

Press this button on the **Tab Selection screen** to move to another tab.

In menu items requiring numerical input, press this button to move to another digit.

▼ button

Press this button when viewing menus to display the next menu item or setting value.

f. OK button

Press this button on the **Tab Selection screen** to display the menu of the tab shown.

Pressing this button in menu items of each tab for which 🛨 is displayed at left will move to the lower level of the menu item, enabling you to execute menu commands or set menu values.

Also press this button if the Display Screen indicates to press the **OK** button.

g. Stop button

Cancels print jobs in progress and ends the ink drying period.

h. Power button (green)

Turns the printer on and off. (See "Turning the Printer On and Off.") —P.3

The **Power** button is lit when the printer is on or in Sleep mode.

i. Navigate button

Enables you to check instructions for loading and removing paper or replacing ink tanks or printheads, as well as other operations. (See "How to View Instructions With Navigate.") —P.919

j. Back button

Displays the screen before the current screen.

k. Cut button

Pressing this button when rolls are loaded cuts the paper, if you have specified **Automatic** or **Eject** in **Cutting Mode** in the Control Panel menu. (See "Specifying the Cutting Method for Rolls.") \longrightarrow P.802

Feed button

Pressing this button when rolls are loaded enables you to reposition the paper. (See "Feeding Roll Paper Manually.")

P.798

m. Load button

Press this button when loading or replacing paper.

(See "Loading Rolls in the Printer.") →P.786

(See "Loading Sheets in the Printer.") →P.813

n. Roll Media lamp (green)

Lit when rolls are selected as the paper source.

o. Cut Sheet lamp (green)

Lit when sheets are selected as the paper source.



Note

• To recover from Sleep mode, any button can be pressed on the Control Panel.

iPF8300S Control Panel


Control Panel Display

After the printer starts up, the **Tab Selection screen** is displayed.

Each of the four tabs presents status, menus, and error information related to the particular tab.

Types of tabs

The **Tab Selection screen** presents four tabs. Each tab is represented by an icon in the top row. Press the ◀ or ▶ button to access other tabs.



A tab indicating status and showing menus related to paper. Pressing the **OK** button when this tab is highlighted will display the **Paper Menu**.

· Top line displayed

The paper icon is highlighted.

Middle line displayed

Indicates the printer status and shows menu names.

· Bottom line displayed

The first and second lines display the paper type and size.



A tab indicating status and showing menus related to ink. Pressing the **OK** button when this tab is highlighted will display the **Ink Menu**.

Top line displayed

The ink icon is highlighted.

· Middle line displayed

Indicates the printer status and shows menu names.

Bottom line displayed

Here, the remaining ink level is indicated. (See "Checking Ink Tank Levels.")

P.1008



A tab indicating status and showing menus related to print jobs. Pressing the **OK** button when this tab is highlighted will display the **Job Menu** menu.

Top line displayed

The job icon is highlighted.

Middle line displayed

Indicates the printer status and shows menu names.

Settings/Adj. tab



A tab indicating status and showing menus related to settings and adjustment. Pressing the **OK** button when this tab is highlighted will display the **Set./Adj. Menu**.

Top line displayed

The settings/adjustment icon is highlighted.

Middle line displayed

Indicates the printer status and shows menu names.

Bottom line displayed

The remaining Maintenance Cartridge capacity is shown on the first line and **Tot.Print Area** on the second. The display unit for **Tot.Print Area** can be specified in the **Length Unit** menu. (See "Menu Settings.") —P.938


Control Panel Display iPF8300S

Printer status and modes

Printer status is classified according to the following five modes.



The printer is ready to receive jobs sent from the computer. Jobs sent from the computer are printed immediately.





Printing is paused on the printer. Any jobs sent from the computer are held without being printed.





Printing is in progress on the printer. Jobs sent from the computer are printed after the current job. The time left until printing is finished is indicated in the upper-right corner of the screen. (Values exceeding 10 hours are not shown.)

Sleep


Blank display

The printer is in power-saving mode. The printer automatically enters Sleep mode to conserve power when idle for a specific period (by default, five minutes), that is, if no print jobs are received or buttons are pressed while all covers are closed.

You can specify the period before the printer enters **Sleep** mode in the **Sleep Timer** menu. (See "Menu Settings.") —P.938

After entering **Sleep** mode from **Standby** mode, the printer automatically recovers if print jobs are received, and the jobs are printed.

Error



The printer requires your attention. Any jobs sent from the computer cannot be processed. The tab related to the error is displayed.

For information about the display in the case of multiple errors, see "Error display."

→P.919


iPF8300S Control Panel Display

917

Mode transition

• Mode display

The printer mode is indicated as follows.




*1: The printer automatically enters **Sleep** mode when idle for a specific period (by default, five minutes), that is, if no print jobs are received or buttons are pressed while all covers are closed. However, it does not enter **Sleep** mode while error messages are displayed or when a roll can be manually advanced by pressing the **Feed** button.

Control Panel Display iPF8300S

- *2: When the printer is in **Sleep** mode, you can press any button except the **Power** button to recover from **Sleep** mode. **Sleep** mode is also terminated if a print job is received or a command is issued from RemoteUI.
- Error display

Mode transition during error display is as follows.

If multiple errors occur, tabs related to errors other than the error currently shown flash. Press the ◀ or ▶ button to access other tabs and check those errors. If multiple errors occur that are related to the Job tab and Settings/Adj. tab, each error message is displayed for 4 seconds on each tab before another message is shown.




How to View Instructions With Navigate

You can refer to instructions for loading paper, replacing ink tanks, and performing other operations on the printer control panel.

- 1. Press the Navigate button.
- **2.** Press \triangle or ∇ to select the desired navigation menu.
- **3.** Press ▲ or ▼ to select **View Op. Guide**, and then press the **OK** button. Instructions are now displayed.

919

· Example: Loading sheets



9

920

Checking Instructions During Printer Operations


You can refer to instructions on the printer control panel when loading paper, replacing ink tanks, or performing other operations.

How to view instructions

Once you complete an action described in the instructions, the printer detects the action and switches to the next instruction screen.

In the case of actions the printer cannot detect, instruction screens are switched every four seconds, and the sequence of operations is shown repeatedly.

• Example: Ink tank replacement



Q

922



Note

• During a continuous display of instructions, you can press the ◀ button to pause the instructions on the current screen.

Press the ◀ or ▶ button to display the previous or next screens. If you do not press the ◀ or ▶ button within 30 seconds, continuous display is resumed.

Press the **OK** button to display the instruction screen for the next step.

Printer Menu

| Printer Menu Operations | 924 |
|------------------------------------|-----|
| Menu Operations | 925 |
| Menu Structure | |
| Menu Settings | 938 |
| Menu Settings (During Printing) | |
| Status Print | 951 |
| Printing Interface Setting Reports | 954 |

Printer Menu Operations

The printer menu is classified into menu items available when no print job is in progress and menu items only available during printing.

- Menu operations when no print job is in progress →P.924
- Menu operations during printing →P.924

Menu operations when no print job is in progress

To view available menus organized on tabs, select a tab on the **Tab Selection screen** and press the **OK** button.



Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

The following operations are available from the menu.

• Paper Menu

Paper menu settings

• Ink Menu

Ink menu operations

• Job Menu

Menu operations to manage print jobs

· Set./Adj. Menu

Menu operations for printer adjustment and maintenance

For a description of specific menu items available, see "Menu Settings." —P.938
For instructions on selecting menu items, see "Menu Operations." —P.925



Note

• By default, menu settings apply to all print jobs. However, for settings that are also available in the printer driver, the values specified in the printer driver take priority.

Menu operations during printing

To display menus during printing, select a tab on the **Tab Selection screen** on the Control Panel, and then press the **OK** button. Other menus are available after printing is finished.



Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

0

924

Printer Menu Operations

The following operations are available from the menu during printing.

• Ink Menu

Ink menu operations

• Job Menu

Menu operations to manage print jobs

· Set./Adj. Menu


Fine-tuning paper feeding
Display of printer-related information

For a description of specific menu items available during printing, see "Menu Settings (During Printing)."
P.949
For instructions on selecting menu items during printing, see "Menu Operations."
P.925

Menu Operations

To view available menus organized on tabs, select a tab on the **Tab Selection screen** and press the **OK** button. For details, see "Menu Settings." \rightarrow P.938

• Menus (when the Ink tab is selected and the **OK** button is pressed)





Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

Simply press buttons on the Control Panel to access menus on various tabs from the **Tab Selection screen** and set or execute **Menu** items.

The following sections describe menu operations.

- Accessing menus →P.925
- Specifying menu items →P.927
- Specifying numerical values →P.927
- Executing menu commands →P.928


Accessing menus

Printer menus are grouped by function.

iPF8300S Menu Operations

925

Menus are displayed with the upper line selected. You can use the buttons on the Control Panel to access each menu.



• Press **Back** to access a higher menu in the menu list, and press **OK** to access a lower one. If not all menu items are displayed, hold down ▲ or ▼ to scroll through higher and lower menu items. Items you select are highlighted.



The scroll bar at right indicates the current position in the overall menu.

• Lower menus are available if 🖭 is displayed at left next to the second and subsequent rows. To access the lower menus, select the menu and press the **OK** button.




926

Menu Operations iPF8300S

Specifying menu items

Menu items can be set as follows.

1. Press ▲ or ▼ to select the desired setting, and then press the **OK** button.



After two seconds, the display reverts to the upper level menu.




Note

• If a confirmation message is displayed regarding the setting you entered, press the **OK** button. The setting is applied, and the printer is now in **Standby**.

Specifying numerical values

Follow these steps to enter numbers. In this example, network settings items are entered.

1. Press the **◄** or **▶** button to move to the next field for input.



2. Press the \triangle or ∇ button to enter the value.



Note

Hold down ▲ or ▼ to increase or decrease the value continuously.

 $\bf 3.$ Repeat steps 1 and 2 to complete the settings, and then press the $\bf OK$ button.



Note

• If a confirmation message is displayed regarding the setting you entered, press the **OK** button. The setting is applied, and the printer is now in **Standby**.

iPF8300S Menu Operations

Executing menu commands

Menu commands can be executed as follows.

1. Press ▲ or ▼ to select the action to execute, and then press the OK button. The menu command is now executed.

Menu Structure

The menu structure is organized by tabs, as follows. Values at right indicated by an asterisk are the defaults.

- Paper Menu →P.928
- Ink Menu →P.930
- Job Menu →P.930
- Set./Adj. Menu →P.931

For instructions on menu operations, see "Menu Operations." —P.925 For details on menu items, see "Menu Settings."
-P.938

Paper Menu

| First Level | Second Level | Third Level | Fourth Level | Fifth Level | | |
|------------------|----------------------------------|--|-------------------------|-------------|--|--|
| Load Paper | Roll Paper | | | | | |
| | Cut Sheet | | | | | |
| Eject Paper | | | | | | |
| Chg. Paper Type | Roll Paper | (The paper type is disp | layed here.) (*1 →P.930 |) | | |
| (*1 →P.930) | Cut Sheet | (The paper type is displayed here.) (*1 →P.930) | | | | |
| Chg. Paper Size | Sheet Size | (The size of paper is displayed here.) (*2 →P.930) | | | | |
| | | CustomPaperSize (Set the length and width) | | | | |
| | Roll Length (*3 →P.930) | (Set the length) (Set the width) | | | | |
| | Roll Width (*4 →P.930) | | | | | |
| ManageRemainRoll | Off* | | | | | |
| | On | | | | | |
| Paper Details | (The paper type is | Head Height | Automatic * | | | |
| | displayed here.) (*1 →P.930) | | Highest | | | |
| | () | | High | | | |
| | | | Standard | | | |
| | | | Low | | | |
| | | | Lowest | | | |
| | | | Super Low | | | |
| | | Skew Check Lv. | Standard * | | | |
| | | | Loose | | | |

928

Menu Structure iPF8300S

| First Level | Second Level | Third Level | Fourth Level | Fifth Level | |
|---------------|------------------------------|---------------------|--------------|--|--|
| Paper Details | | Skew Check Lv. | Off | | |
| | displayed here.) (*1 →P.930) | Cutting Mode | Automatic | | |
| | (' () | (*6 →P.930) | Eject | | |
| | | | Manual | (The screen for set- ting paper leading edge detection is dis played) | |
| | | Cut Speed | Fast | | |
| | | | Standard | | |
| | | | Slow | | |
| | | Trim Edge First | Automatic | | |
| | | | Off | | |
| | | | On | | |
| | | CutDustReduct. | Off | | |
| | | | On | | |
| | | VacuumStrngth | Automatic * | | |
| | | | Strongest | | |
| | | | Strong | | |
| | | | Standard | | |
| | | | Weak | | |
| | | | Weakest | | |
| | | Scan Wait Time | Dry time | Off* | |
| | | | | 1 sec. | |
| | | | | 3 sec. | |
| | | | | 5 sec. | |
| | | | | 7 sec. | |
| | | | | 9 sec. | |
| | | | Area | Entire area * | |
| | | | (*5 →P.930) | Leading edge | |
| | | Roll DryingTime | Off | | |
| | | | 30 sec. | | |
| | | | 1 min. | | |
| | | | 3 min. | | |
| | | | 5 min. | | |
| | | | 10 min. | | |
| | | | 30 min. | | |
| | | | 60 min. | | |
| | | NearEnd RollMrgn | 5mm | | |
| | | | 20mm | | |

iPF8300S Menu Structure

| ı | l | l | ı | |
|---|---|---|---|--|
| | 7 | , | | |
| 1 | | | | |

| First Level | Second Level | Third Level | Fourth Level | Fifth Level | | |
|-----------------|----------------------------------|------------------|--------------|-------------|--|--|
| Paper Details | (The paper type is | NearEnd Sht Mrgn | 5mm | | | |
| | displayed here.) (*1 →P.930) | | 20mm | | | |
| | | Bordless Margin | Automatic | | | |
| | | | Fixed | | | |
| | | Width Detection | Off | | | |
| | | | On * | | | |
| | | Return Defaults | | | | |
| Paper Details | | | | | | |
| Keep Paper Type | Off * | | | | | |
| | On | | | | | |

- *1: For information on the types of paper the printer supports, refer to the Paper Reference Guide. (See Paper Reference Guide .) Types of paper in the printer driver and related software (as well as on the Control Panel) are updated when you install the printer driver from the User Software CD-ROM or if you update paper information with the Media Configuration Tool. (See "Updating paper information.") —P.779
- *2: For information on the sizes of paper the printer supports, see "Paper Sizes." —P.775
- *3: Available only if **ManageRemainRoll** is **On**.
- *4: Available only if Width Detection is Off.
- *5: **Leading edge** is not available as a setting option in the **Paper Detailed Settings** dialog box of the printer driver.
- *6: see "Specifying the Cutting Method for Rolls." →P.802

Ink Menu

First Level
Rep. Ink Tank
Head Cleaning A

Job Menu

| First Level | Second Level | Third Level | Fourth Level | Fifth Level | | | |
|-------------|--|-----------------------|---------------------------------|-------------|--|----|--|
| Print Job | Job List | (Choose a print job.) | Delete | | | | |
| | | | Preempt Jobs (*1 | 2.931) | | | |
| Stored Job | Mailbox List | (Enter a password if | Job List | Print | | | |
| | | one has been set.) | | Delete | | | |
| | | | Print Job List | | | | |
| Job Log | (Choose from infor- | - Document Name | | | | | |
| | mation about the latest three print jobs.) | User Name | | | | | |
| | est unce print joos.) | Page Count | | | | | |
| | | Job Status | OK CANCELED yyyy/mm/dd hh:mm:ss | | | ОК | |
| | | | | | | | |
| | | Print Start Time | | | | | |

Menu Structure iPF8300S

| First Level | Second Level | Third Level | Fourth Level | Fifth Level | |
|-----------------|--|------------------|------------------------------------|-------------|--|
| Job Log | (Choose from infor- | Print End Time | yyyy/mm/dd hh:mm:s | ss | |
| | mation about the latest three print jobs.) | Print Time | xxxsec. | | |
| | 1 3 / | Output Img. Size | (The image size is disp | layed) | |
| | | Media Type | | | |
| | | Paper Consumed | | | |
| | | Paper Length | | | |
| | | Paper Width | | | |
| | | Interface | USB | | |
| | | | Network | | |
| | | | HDD | | |
| | | Ink Consumed | (The ink color is displayed here.) | xxx.xxx ml | |
| | | Print settings | | | |
| | | Head Height | | | |
| | | Temp./Humidity | | | |
| | | Adjustment req. | | | |
| Print Job Log | · | | | | |
| Pause Print | Off * | | | | |
| | On | | | | |
| HDD Information | Total capacity | | | | |
| | Box free space | | | | |

^{*1:} If a pending job is selected, **Print Anyway** is displayed.

Set./Adj. Menu

| First Level | Second Level | Third Level | Fourth Lev- el | Fifth Level | Sixth Level | Seventh Level | | |
|-------------|---------------------|----------------------|------------------------------|-------------|-------------|---------------|--|--|
| Test Print | Nozzle Check | | | | | | | |
| | Status Print | Status Print | | | | | | |
| | Interface Prin | nt | | | | | | |
| | Paper Details | | | | | | | |
| | Print Job Log | ţ | | | | | | |
| | Menu Map | | | | | | | |
| Adjust | Head Posi. | Posi. Auto(Standard) | | | | | | |
| Printer | Adj. Auto | Auto(Advanced) | | | | | | |
| | | Auto(Expansi | Auto(Expansion) (*1 →P.938) | | | | | |
| | Manual (*1 →P.938) | | | | | | | |
| | Feed Priori- | Adj. Priori- | Priori- Automatic * | | | | | |
| | ty | ty | Print Quality | | | | | |

iPF8300S Menu Structure

| First Level | Second Level | Third Level | Fourth Lev- el | Fifth Level | Sixth Level | Seventh Level | |
|-------------------|--------------------|--------------------|-------------------|---------------|-------------|---------------|--|
| Adjust Printer | Feed Priori- ty | Adj. Priori- ty | Print Length | Print Length | | | |
| | | Adj. Quali- | Auto(Genuine | ePpr) | | | |
| | | (*2 | Auto(OtherPa | aper) | | | |
| | | →P.938)) | Manual | | | | |
| | | Adjust | Adjust- | A:High | | | |
| | | Length (*3 | mentPrint | B:Standard/Di | raft | | |
| | | →P.938)) | Change Set- | A:High | | | |
| | | / | tings | B:Standard/Di | raft | | |
| | Calibration | Auto Adjust | I | I. | | | |
| | | Calibration | Date | | | | |
| | | Log | Paper Type | | | | |
| | | | Adjustment T | Гуре | | | |
| | | Use Adj. Value | Disabled | | | | |
| | | | Enabled * | | | | |
| | | "Set Exec. | Off* | | | | |
| | | Guide" | On | | | | |
| | | Return Defau | ılts | | | | |
| Mainte- | Head | Head Cleaning A | | | | | |
| nance | Cleaning | Head Cleaning B | | | | | |
| | Nozzle Check | | | | | | |
| | Replace | Printhead L | | | | | |
| | P.head | Printhead R | | | | | |
| | | L & R Printh | eads | | | | |
| | Repl. maint cart | | | | | | |
| | Head Info | Printhead L | ProductName | e: | | | |
| | | | s/n: | | | | |
| | | | Days elapsed: | | | | |
| | | | Count [Mdot]: | | | | |
| | | Printhead | ProductName: | | | | |
| | | R | s/n: | | | | |
| | | | Days elapsed: | | | | |
| | | | Count [Mdot] |] : | | | |
| | Repl. S. Clear | ner | | | | | |
| | Change Cutte | er | | | | | |
| Interface | EOP Timer | r 10 sec. | | | | | |
| Setup | (*8 →P.938) | 30 sec. | | | | | |

Menu Structure iPF8300S

| 933 |
|-----|

| First Level | Second Level | Third Level | Fourth Lev- el | Fifth Level | Sixth Level | Seventh Level | | |
|--------------------|-----------------|----------------|-------------------|--------------------|-------------------|---------------|--|--|
| Interface Setup | EOP Timer (*8 | 1 min. | | | | | | |
| Scrup | →P.938) | 2 min. | | | | | | |
| | | 5 min. | | | | | | |
| | | 10 min. * | | | | | | |
| | | 30 min. | | | | | | |
| | | 60 min. | | | | | | |
| | TCP/IP | IPv4 | IPv4 Mode | Automatic | | | | |
| | (*8 →P.938) | | | Manual * | | | | |
| |) | | Protocol | DHCP | On | | | |
| | | | (*4 →P.938)) | | Off * | | | |
| | | | 71 .330 | ВООТР | On | | | |
| | | | | | Off * | | | |
| | | | | RARP | On | | | |
| | | | | | Off * | | | |
| | | | IPv4 Set- | IP Address | XXX.XXX.XXX.XX | XX | | |
| | | tings | | Subnet Mask | XXX.XXX.XXX.XX | XX | | |
| | | (*9 →P.938) | Default G/W | XXX.XXX.XXX | | | | |
| | | | DNS Set- | DNS Dync On | | | | |
| | | tings | | Off * | | | | |
| | | | (*9 →P.938)) | Pri. DNS SrvA | ddr | | | |
| | | | , | Sec. DNS SrvA | ddr | | | |
| | | | | DNS Host Nan | ne | | | |
| | | | | DNS Domain N | Name | | | |
| | | IPv6 | IPv6 Sup- | On | | | | |
| | | | port | Off * | | | | |
| | | | IPv6 Stles- | On * | | | | |
| | | | sAddrs | Off | | | | |
| | | | (*10 →P.938) | | | | | |
| | | | DHCPv6 | On | | | | |
| | | | (*10 | Off * | | | | |
| | | | →P.938) | | l | | | |
| | | | DNS Set- tings | DNS Dync update | Statefull Addr | On | | |
| | | | (*9 | upuate | | Off * | | |
| | | | →P.938) | →P.938)) (*10 | Stateless Addr | On | | |
| | | | (*10 →P.938)) | | Auur | Off * | | |
| | | | | Pri. DNS SrvA | ddr | | | |
| | | | | Sec. DNS SrvA | ddr | | | |
| | | | | DNS Host Name | | | | |

iPF8300S Menu Structure

| First Level | Second Level | Third Level | Fourth Lev- el | Fifth Level | Sixth Level | Seventh Level |
|--------------------|---------------------------------------|------------------|--|--------------|-------------|---------------|
| Interface Setup | TCP/IP (*8 →P.938) | IPv6 | DNS Set- tings (*9 →P.938) (*10 →P.938) | DNS Domain N | ame | |
| | NetWare (*8 | NetWare | On | | | |
| | →P.938)) | | Off * | | | |
| | | Frame Type | Auto Detect | | | |
| | | (*5 | Ethernet 2 | | | |
| | | →P.938)) | Ethernet 802. | | | |
| | | | Ethernet SNA | | | |
| | | Print Serv- | BinderyPServ | | | |
| | | ice | RPrinter | | | |
| | | (*5 →P.938) | NDSPServer * | | | |
| | | , | NPrinter | | | |
| | AppleTalk | On | | | | |
| | (*8 →P.938) Ethernet Driver (*8 | Off * | | | | |
| | | Auto Detect | On * | | | |
| | | | Off | | | |
| | →P.938)) | Comm.Mod | Half Duplex * | : | | |
| | e (*6 →P.938) | Full Duplex | | | | |
| | | Ethernet | 10 Base-T * | | | |
| | | Type (*6 | 100 Base-TX | | | |
| | | →P.938)) | 1000 Base-T | | | |
| | | Spanning | Not Use * | | | |
| | | Tree | Use | | | |
| | | MAC Ad- dress | xxxxxxxxxxx | C . | | |
| | Interface Prin | nt (*8 →P.938) |) | | | |
| | | lts (*8 →P.938 |) | | | |
| System Set- up | Sleep Timer (*11 | 5 min. * | | | | |
| up | →P.938)) | 10 min. | | | | |
| | | 15 min. | | | | |
| | | 20 min. | | | | |
| | | 30 min. | | | | |
| | | 40 min. | | | | |

Menu Structure iPF8300S

| First Level | Second Level | Third Level | Fourth Lev- el | Fifth Level | Sixth Level | Seventh Level |
|-------------------|------------------|------------------------------|-------------------|-------------|-------------|---------------|
| System Set- up | Sleep Timer | 50 min. | | | | |
| | (*11 →P.938) | 60 min. | | | | |
| | | 240 min. | | | | |
| | Buzzer | Off | | | | |
| | | On * | | | | |
| | Contrast Adj. | -4,-3,-2,-1,0*,+1,+2,+3,+4 | | | | |
| | Date & Time | Date yyyy/mm/dd (*7 →P.938) | | | | |
| | (*8 →P.938) | | Time hh:mm | | | |
| | Date For- | yyyy/mm/dd | * | | | |
| | mat (*8 | dd/mm/yyyy | | | | |
| | (*8 →P.938) | mm/dd/yyyy | | | | |
| | Language | English | | | | |
| | | 日本語 | | | | |
| | | Français | | | | |
| | | Italiano | | | | |
| | | Deutsch | | | | |
| | | Español | | | | |
| | | Русский | | | | |
| | | 中文 (簡体字 | Z) | | | |
| | | 한국어 | | | | |
| | Time Zone (*8 | 0:London (G | | | | |
| | →P.938) | +1:Paris,Ron | | | | |
| | | +2:Athens,Ca | niro | | | |
| | | +3:Moscow | | | | |
| | | +4:Eerevan,E | | | | |
| | | +5:Islamabad | | | | |
| | | +6:Dacca +7:Bangkok | | | | |
| | | +8:Hong Kon | ισ | | | |
| | | +9:Tokyo,Sec | | | | |
| | | +10:Canberr | | | | |
| | | +11NewCaled | | | | |
| | | +12:Wellington | | | | |

iPF8300S Menu Structure

| 936 | |
|-----|--|
| 750 | |

| First Level | Second Level | Third Level | Fourth Lev- el | Fifth Level | Sixth Level | Seventh Level | |
|-------------------|------------------------|--|--------------------------|-------------|-------------|---------------|--|
| System Set- up | Time Zone (*8 | -12:Eniwetok | | | | | |
| up | →P.938)) | -11:Midway is. | | | | | |
| | | -10Hawaii(AHST) | | | | | |
| | | -9:Alaska(AKST) | | | | | |
| | | -8:Oregon (Ps | ST) | | | | |
| | | -7:Arizona(M | ST) | | | | |
| -6:Texas (CST) | | | | | | | |
| | | -5:NewYork(EST) | | | | | |
| | | -4:Santiago | | | | | |
| -3:Buenos Aires | | | | | | | |
| | | -2: | | | | | |
| | | -1:Cape Verd | e | | | | |
| | Length Unit | meter * | | | | | |
| | | feet/inch | | | | | |
| | Detect Mis- | Pause | | | | | |
| | match | Warning | | | | | |
| | | None * | | | | | |
| | | Hold Job | | | | | |
| | Paper Size Basis | Sht Selection 1 ISO A3+ * 13"x19"(Super B) | | | | | |
| | | Sht Selection 2 | ISO B1 * 28"x40" (ANS | SI F) | | | |
| | Keep Paper Size | Off * | | | | | |
| | | On | | | | | |
| | Rep.P.head Print | Off | | | | | |
| | | On * | | | | | |
| | Nozzle | Frequency | Standard * | | | | |
| | Check | | 1 page | | | | |
| | | Warning | Off * | | | | |
| | | | On | | | | |
| | CarriageS- | Automatic * | | | | | |
| | canWdth | Fixed | | | | | |
| | Use Remo- | On * | | | | | |
| | teUI (*8 →P.938) | Off | | | | | |
| | Reset PaprSe | tngs (*8 →P.93 | B) | | | | |
| | Erase HDD | High Speed (* | 8 (→P.938) | | | | |
| | Data | Secure High Spd. (*8 →P.938) | | | | | |

Menu Structure iPF8300S

| 937 | | 937 |
|-----|--|-----|
|-----|--|-----|

| First Level | Second Level | Third Level | Fourth Lev- el | Fifth Level | Sixth Level | Seventh Level | | | |
|----------------------------------|--------------------------------------|--|---------------------|-------------|-------------|---------------|--|--|--|
| System Set- up | Erase HDD Data | Secure (*8 | Secure (*8 →P.938) | | | | | | |
| | Output | Print * | | | | | | | |
| | Method | Print (Auto Del) | | | | | | | |
| | | Save: Box XX | | | | | | | |
| | Print After | Off * | | | | | | | |
| | Recv | On | | | | | | | |
| | Common | Print * | | | | | | | |
| | Box Set. (*4 →P.938) | Print (Auto Del) | | | | | | | |
| | Show Job | Off | | | | | | | |
| | Log (*8 →P.938) | On * | | | | | | | |
| Take-up | Use Take- | Disable * | | | | | | | |
| Reel (*12 | up Reel | Enable | | | | | | | |
| →P.938) | Auto Feed (*13 →P.938) | | | | | | | | |
| | Skip Take- Off * | | | | | | | | |
| | Up Err (*14 →P.938) | On | | | | | | | |
| Prep.Move- | Level 1 | | | | | | | | |
| Printer | Level 2 | | | | | | | | |
| | Level 3 | | | | | | | | |
| Admin. Menu (*8 →P.938) | Change Password (*9 →P.938) | (The screen for setting the password is displayed) | | | | | | | |
| | Init.Admin.Pswd (*9 →P.938) | | | | | | | | |
| Printer Info | Paper Info | | | | | | | | |
| | Ink Info | | | | | | | | |
| | Head Info | ProductName: | | | | | | | |
| | | s/n: | | | | | | | |
| | | | Days elapsed: | | | | | | |
| | | | Count [Mdot]: | | | | | | |
| | | Printhead L | ProductName | : | | | | | |
| | | | s/n: | | | | | | |
| | | | Days elapsed: | | | | | | |
| | | | Count [Mdot] | : | | | | | |
| | | Printhead R | ProductName | : | | | | | |

iPF8300S Menu Structure

| $\boldsymbol{\Lambda}$ | |
|------------------------|--|
| u | |
| 7 | |
| | |

| First Level | Second Level | Third Level | Fourth Lev- el | Fifth Level | Sixth Level | Seventh Level | |
|--------------|-----------------|-------------|-------------------|-------------|-------------|---------------|--|
| Printer Info | Head Info | Printhead | s/n: | | | | |
| | K | R | Days elapsed: | | | | |
| | | | Count [Mdot] | : | | | |
| | System Info | | | | | | |
| | Error Log | | | | | | |
| | Other Counter | | | | | | |

^{*1:} Available after you have used Auto(Advanced) in Head Posi. Adj. once.

- *2: Available if Adj. Priority is Automatic or Print Quality.
- *3: Available if Adj. Priority is Automatic or Print Length.
- *4: Not displayed if **IPv4 Mode** is **Manual**.
- *5: Not displayed if NetWare is Off.
- *6: Not displayed if **Auto Detect** is **On**.
- *7: Follows the setting in **Date Format**.
- *8: Viewing and configuration is possible for administrators, and only viewing for other users.
- *9: Viewing and configuration is possible for administrators only.
- *10: Not displayed if **IPv6 Support** is **Off**.
- *11: Default setting for the time to enter the power save mode/Sleep mode is recommended.
- *12: Displayed only when the Media Take-up Unit is attached.
- *13: Available if: (a) Use Take-up Reel is Enable, (b) roll paper is loaded, and (c) you have not executed Auto Feed for the loaded roll.
- *14: Available when **Use Take-up Reel** is **Enable**.

Menu Settings

Menu items are as follows.

For instructions on selecting menu items, see "Menu Operations." —P.925 For details on menu levels and values, see "Menu Structure." —P.928

Paper Menu

| Setting Item | Description, Instructions |
|---|---|
| Load Paper | Select either sheets or rolls and load the paper. |
| Eject Paper | Choose this item before removing loaded paper. |
| Chg. Paper Type (*1 → P.940) | Change the type of paper loaded. (See "Changing the Type of Paper.") →P.791 |
| Chg. Paper Size | Change the size of paper loaded. (See "Specifying the Paper Length.") →P.793 (See "Paper Sizes.") →P.775 |
| ManageRemainRoll | Choose On to print a barcode at the end of a roll before you remove it. The printed barcode can be used in managing the amount of roll paper left. Choose Off if you prefer not to print the barcode. (See "Keeping Track of the Amount of Roll Paper Left.") P.799 |

Menu Settings iPF8300S

| 939 |
|-----|

| | Setting Item | | Description, Instructions | |
|---------------|---------------------------------|----------------------|--|-------------------|
| Paper Details | (The type of paper is displayed | Head Height | Adjust the Printhead height. (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") P.854 | |
| | here.) (*1 →P.940) | Skew Check Lv. | If you print on Japanese paper (washi) or other handmade paper that has an irregular width, choose Loose for a higher skew detection threshold, or choose Off to disable skew detection. However, if paper is loaded askew when detection is Off , note that paper jams or Platen soiling may occur. | |
| | | Cutting Mode | Specify whether or not to cut with the standard round-bladed cutter. If you choose Automatic , the roll will be cut automatically using the Cutter Unit, depending on the printer driver settings. Select Eject to prevent printed documents from falling immediately after printing such as when you wait for the ink to dry, etc. Manual prints lines at the cut position instead of cutting after printing. If you select Manual , the setting screen for detection of the paper leading edge is displayed. (See "Specifying the Cutting Method for Rolls.") P.802 | |
| | | Cut Speed | Choose the cutting speed. The preset selection represents the optimal cutting speed for the type of paper. We recommend keeping the preset cutting speed. If you use adhesive paper, choosing Slow helps prevent adhesive from sticking to the cutter and keeps the cutter sharp. | |
| | | Trim Edge First | If a roll is loaded, the end of the paper will be cut. | |
| | | CutDustRe- duct. | If you choose On , a line will be printed at the cut position when paper cutting is selected. This option reduces the amount of debris given off after cutting. It also helps prevent adhesive from sticking to the cutter and keeps the cutter sharp if you use adhesive paper. (See "Reducing Dust from Cutting Rolls.") —P.812 | |
| | | Vac- uumStrngth | Specify the level of suction that holds paper against the Platen. (See "Adjusting the Vacuum Strength (VacuumStrngth).") P.863 | |
| | | | | Scan Wait Time |
| | | Roll Drying- Time | Specify the time to wait for the ink to dry for each sheet. | |
| | | NearEnd RollMrgn | Specify the minimum margin at the leading edge of roll paper to ensure better printing quality at the leading edge. Note that if you choose 5mm , it may lower the printing quality at the leading edge and affect feeding accuracy. The printed surface may be scratched, and ink may adhere to the leading edge. It may also cause the Platen to become soiled. | |

iPF8300S Menu Settings

| | Setting Item | | Description, Instructions |
|-----------------|--|----------------------|---|
| Paper Details | Paper Details (The type of paper is displayed here.) (*1 →P.940) | NearEnd Sht Mrgn | Specify a margin at the leading edge of sheets to ensure better printing quality at the leading edge. Note that if you choose 5mm , it may lower the printing quality at the leading edge and affect feeding accuracy. The printed surface may be scratched, and ink may adhere to the leading edge. |
| | | Bordless Margin | Adjust the margin during borderless printing. Choose Automatic to have the printer automatically detect the paper width and configure the margin settings for borderless printing. If margins are mistakenly created when Automatic is selected, choose Fixed . In this case, the paper width is not detected automatically, and the document is printed without borders, using the margin settings required by the printer. |
| | | Width Detection | Specify this option to print inside boundaries or in other cases when specifying a particular starting position for printing. Paper width and skew are not detected if you select Off . If paper is loaded askew, paper jams or Platen soiling may occur. |
| | | Return De- faults | Choose OK to restore Paper Details to the default values. |
| Paper Details | | | Print the paper settings as specified in Paper Details . |
| Keep Paper Type | | | Select On when printing on a particular type of paper regularly. (See "Changing the Type of Paper.") →P.791 |

^{*1:} For information on the types of paper the printer supports, refer to the Paper Reference Guide. (See Paper Reference Guide .) Types of paper in the printer driver and related software (as well as on the Control Panel) are updated when you install the printer driver from the User Software CD-ROM or if you update paper information with the Media Configuration Tool. (See "Updating paper information.") —P.779

Ink Menu

| Setting Item | Description, Instructions |
|-----------------|--|
| Rep. Ink Tank | Replace the Ink Tank at this point. Follow the instructions displayed to complete the required procedure. (See "Replacing Ink Tanks.") P.997 |
| Head Cleaning A | Printhead cleaning options. (See "Cleaning the Printhead.") →P.1012 Execute Head Cleaning A if printing is faint, oddly colored, or contains foreign substances. |

940 Job Menu

| | | Setting Item | | Description, Instructions |
|--------------|----------|----------------------------|--------------|--|
| Print Job | Job List | (Choose a print job) | Delete | Delete the current job or queued jobs. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") P.725 |
| | | | Preempt Jobs | Print the job first after the current print job is finished. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") →P.725 |

Menu Settings iPF8300S

| Setting Item | | | | | Description, Instructions |
|---------------|----------------------|----------------------------|------------------------------|----------------------|--|
| Stored | | | Job List Print | Print the saved job. | |
| Job List | List | pass- word if | | Delete | Delete the saved job. |
| | | one has been set.) | Print Job List | | Print a list of saved print jobs. |
| Job Log | (Choose | Document | Name | | Indicates the document name of the selected print job. |
| | from in- forma- | User Nam | e | | Indicates the name of the user who sent the print job. |
| | tion | Page Cour | nt | | Indicates the number of pages in the job. |
| | about the last three | Job Status | S | | Indicates the printing results. |
| | print | Print Star | t Time | | Indicates when the print job was started. |
| | jobs.) | Print End | Time | | Indicates when the print job was finished. |
| | | Print Tim | e | | Indicates the time required to print the job. |
| | | Output Img. Size | | | Indicates the image size in the print job. |
| | | Media Ty | pe | | Indicates the type of paper in the print job. |
| | | Paper Cor | ısumed | | Indicates the total amount of paper consumed. |
| | | Paper Len | gth | | Indicates the length of paper. |
| | | Paper Wio | dth | | Indicates the width of paper. |
| | | Interface | | | Indicates the interface used for the print job. |
| | | Ink Consu | Ink Consumed Print settings | | Indicates a rough estimate of how much ink was consumed per job.(*1 →P.941) |
| | | Print setti | | | A counter for maintenance purposes. Indicates job print settings. |
| | | Head Height Temp./Humidity | | | A counter for maintenance purposes. Indicates the head height when jobs wereprinted. |
| | | | | | A counter for maintenance purposes. Indicates the temperature and humiditywhen jobs were printed. |
| | | Adjustme | justment req. | | A counter for maintenance purposes. Indicates adjustment conditions applied to jobs. |
| Print Job Log | | | | | Print a record of print jobs, including the paper type and size, amount of ink consumed, and so on. Ink consumption indicates a rough estimate of the amount of ink consumed per print job.(*1 ¬P.941) |
| Pause Print | | | | | Choose On to stop printing. |
| HDD Info | rmation | | | | Indicates the total hard disk capacity and the mail box free space. |

^{*1:} A rough estimate of the amount of ink consumed per print job is displayed. Actual ink consumption may be different. The average margin of error for estimates calculated according to Canon measurement conditions for ink costs is ±15%. Canon does not guarantee the accuracy of these estimates. Estimates may vary depending on conditions of use. Calculation of these estimates does not include ink consumed when cleaning printheads by forceful ejection of ink.

iPF8300S Menu Settings

Set./Adj. Menu

| | | Settin | g Item | Description, Instructions |
|-------------------|--------------------|----------------------|------------------|---|
| Test | Nozzle Check | | | Print a test pattern to check the nozzles. |
| Print | Status P | rint | | Print information about the setting values and condition of the printer. |
| | Interface | e Print | | Print interface settings information. |
| | Paper D | etails | | Print the paper settings as specified in Paper Details. |
| | Print Jol | b Log | | Print a record of print jobs, including the paper type and size, amount of ink consumed, and so on. Ink consumption indicates a rough estimate of the amount of ink consumed per print job.(*1 -P.949) |
| | Menu M | ар | | Print the menu structure. |
| Adjust Printer | ust Head Auto(Stan | | ndard) | The printer prints and reads a test pattern for automatic adjustment of Printhead alignment relative to the printing direction. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") P.850 |
| | | Auto(Advanced) | | The printer prints and reads a test pattern for automatic adjustment of Printhead alignment relative to the printing direction and spacing between nozzles and colors. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") ¬P.850 |
| | | Auto(Exp | pansion) | The printer prints and reads a test pattern for automatic adjustment of Printhead alignment relative to the printing direction and spacing between nozzles and colors. Adjustment is performed at a higher level of precision than Auto(Advanced) . (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") P.850 |
| | | Manual | | Print a test pattern for adjustment of Printhead alignment relative to the printing direction. Enter the adjustment value manually based on the resulting pattern. (See "Manual Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") P.852 |
| | Feed | Adj. | Automatic | Specify exact paper feeding, if desired. Normally, se- |
| | Priori- ty | Priori- ty | Print Quality | lect Automatic . Choose Print Quality for attractive printing. Choosing Print Quality also makes banding |
| | | | Print Length | less noticeable. Choose Print Length if you prefer to feed the paper an exact amount. However, note that slight banding may occur in the direction of carriage scanning when Print Length is selected. |
| | | Adj. Quali- ty | Auto(GenuinePpr) | Specify this mode with paper identified in the Paper Reference Guide. (See Paper Reference Guide.) The printer prints and reads a test pattern for automatic adjustment of the feed amount. (See "Automatic Banding Adjustment (Adj. Quality).") P.857 |
| | | | Auto(OtherPaper) | Specify this mode with paper not in the Paper Reference Guide.(See Paper Reference Guide.) |

Menu Settings iPF8300S

| 943 |
|-----|
|-----|

| Setting Item | | | | | Description, Instructions |
|-------------------|-----------------------|-----------------|-------------------------|------------------|--|
| Adjust Printer | Feed Priori- ty | , | | herPaper) | The printer prints and reads a test pattern for automatic adjustment of the feed amount. Note that this function takes more time and consumes more ink than Auto(GenuinePpr) . (See "Automatic Banding Adjustment (Adj. Quality).") —P.857 |
| | | | Manual | | Use this mode with highly transparent media or other paper for which Auto(GenuinePpr) or Auto(Other-Paper) cannot be used. Print a test pattern for adjustment of the feed amount based on the type of paper. (See "Manual Banding Adjustment (Adj. Quality).") —P.859 |
| | | Adjust | Ad- | A:High | Print a test pattern for particular types of paper to |
| | | Length | just- ment- Print | B:Standard/Draft | compensate for paper stretching or shrinkage, after which you enter the amount of adjustment. (See "Adjusting Line Length (Adjust Length).") -P.861 |
| | | | Chang | A:High | Displayed when you have selected Feed Priority > |
| | | e Set- tings | | B:Standard/Draft | Adj. Priority > Print Length. Adjustment relative to the amount of stretching or shrinkage of the current paper. Enter either the adjustment results from Adjustment-Print or the discrepancy that you measured (as a percentage). For paper that tends to stretch, increase the feed amount by choosing a higher adjustment value. For paper that tends to shrink, decrease the feed amount by choosing a lower adjustment value. |
| | Cali- bration | Auto Adjust | | | Choose Yes for automatic adjustment of the adjustment value after a test pattern for color calibration is printed. |
| | | Calibrat | ion Log | | The Date, Paper Type, and Adjustment Type for which color calibration was executed are displayed on the Display Screen where you can confirm them. Common calibration and unique calibration are the Adjustment Type of color calibration. When paper is set in the printer, the history of effective color calibration for the set paper is displayed. When paper is not set in the printer, the latest history among common calibration or unique calibration is displayed. Also, a hyphen (-) is displayed when there are no execution results. (See "Using Color Calibration for Color Adjustment.") →P.865 (See "Paper that can be used in Color Calibration.") →P.869 |
| | | Use Adj. | Value | | Choose Disabled > OK if you prefer not to apply the color calibration adjustment value in print jobs. However, printer driver settings are given priority. Choose Enabled > OK to apply the color calibration adjustment value in print jobs. However, printer driver settings are given priority. |

iPF8300S Menu Settings

| | | Settir | ng Item | | Description, Instructions |
|-----------------------|-------------------------------|-----------------|-----------------------|-------------|--|
| Adjust Printer | Calibration "Set Exec. Guide" | | | | If you select On , a message is displayed on the control panel at the timing recommended for executing color calibration. |
| | | Return Defaults | | | Clear the color calibration adjustment value and the execution log. |
| Main- te- nance | Head Clo | eaning | | | Clean the Printhead. (See "Cleaning the Printhead.") →P.1012 Choose Head Cleaning A if printing is faint, oddly colored, or contains foreign substances. Choose Head Cleaning B if no ink is printed at all, or if printing is not improved by Head Cleaning A. |
| | Nozzle C | heck | | | Print a test pattern to check the nozzles. |
| | Replace | P.head | | | Execute when replacing the Printhead. Follow the instructions displayed to complete the required procedure. (See "Replacing the Printhead.") →P.1013 Not displayed during a warning message that the remaining Maintenance Cartridge capacity is low. |
| | Repl. ma | int cart | | | Execute when replacing the Maintenance Cartridge. Follow the instructions displayed to complete the required procedure. (See "Replacing the Maintenance Cartridge.") —P.1028 |
| | Head Info | Printhea | | | Indicates information about the printhead. |
| | | Printhea | ad R | | |
| | Repl. S. (| Cleaner | | | Replace the Shaft Cleaner. Follow the instructions displayed to complete the required procedure. (See "Replacing the Maintenance Cartridge.") |
| | Change (| Cutter | | | Replace the Cutter Unit. Follow the instructions displayed to complete the required procedure. (See "Replacing the Cutter Unit.") —P.1024 Once you replace the Cutter Unit, you can also reset the cut counter. |
| Inter- face | EOP Tin | ner | | | Specify the timeout period before cancellation of print jobs that cannot be received by the printer. |
| Setup | TCP/ IP | IPv4 | IPv4 Mode | | Choose whether the printer IP address is configured automatically or a static IP address is entered manually. |
| | | | Proto- | DHCP | Specify the protocol used to configure the IP address |
| | | col | col | ВООТР | automatically. |
| | | | | RARP | |
| | | | IPv4 Set- tings | IP Address | Specify the printer network information when using a |
| | | | | Subnet Mask | static IP address. Enter the IP address assigned to the printer, as well as |
| | | | | Default G/W | the network subnet mask and default gateway. The value that was automatically configured is displayed if you have set IPv4 Mode to Automatic . |

Menu Settings iPF8300S

| 945 |
|-----|

| | Setting Item | | | | | Description, Instructions |
|----------------|-------------------------|---------------|----------------------|-----------------------|------------------------|---|
| Inter- face | TCP/ IP | IPv4 | DNS Set- | DNS Dyi | nc update | Specify whether DNS server registration is updated automatically. |
| Setup | | | tings | Pri. DNS SrvAddr | | Specify the DNS server address. |
| | | | | Sec. DNS SrvAddr | | |
| | | | | DNS Hos | st Name | Specify the DNS host name. |
| | | | | DNS Doi Name | main | Specify the DNS domain name. |
| | | IPv6 | IPv6 Sup | port | | Specify whether to connect via IPv6. |
| | | | IPv6 Stle | essAddrs | | Specify whether a IPv6 stateless address is used. |
| | | | DHCPv6 | í | | Specify whether DHCPv6 settings are used. |
| | | | DNS Set- tings | DNS Dync update | State- full Addr | Specify whether DNS server registration is updated automatically. |
| | | | | | State- less Addr | |
| | | | | Pri. DNS SrvAddr | | Specify the DNS server address. |
| | | | | Sec. DNS SrvAddr | | |
| | | | | DNS Host Name | | Specify the DNS host name. |
| | | | | DNS Domain Name | | Specify the DNS domain name. |
| | Net- Ware | NetWare | | | | Specify the NetWare protocol. To apply your changes choose Register Setting . |
| | | Frame T | уре | | | Specify the frame type to use. |
| | | Print Service | | | | Choose the print service. |
| | AppleTa | ılk | | | | Specify whether to use the AppleTalk protocol. To apply your changes, choose Register Setting . |
| | Ether- net Driver | Auto Det | tect | | | Specify the communication method. To apply your changes, choose Register Setting . Choose On for automatic configuration of the LAN communication protocol. Choose Off to use settings values of Comm.Mode and Ethernet Type . |
| | | Comm.M | 1ode | | | Choose the LAN communication method. |
| | | Ethernet Type | | | | Choose the LAN transfer rate. |
| | | Spanning Tree | | | | Choose whether spanning-tree packets are supported over the LAN. |
| | | MAC Address | | | | Indicates the MAC address. |
| | Interface | e Print | | | | Print interface settings information. |
| | Return I | Defaults | | | | Choose OK to restore Interface Setup settings to the default values. |

iPF8300S Menu Settings

| | | Setting Item | Description, Instructions |
|-----------------|------------------------|-----------------|--|
| System Setup | Sleep Tir | ner | Specify the period before the printer enters sleep mode. |
| | Buzzer | | Choose On for the buzzer to sound once for warning and three times for errors. |
| | Contrast | Adj. | Adjust the Display Screen contrast level. |
| | Date & | Date | Set the current date. |
| | Time | Time | Set the current time. Available only if the Date setti is specified. |
| | Date For | mat | Specify the date format. |
| | Languag | e | Specify the language used on the Display Screen. |
| | Time Zo | ne | Specify the time zone. Time zone options indicate a main city in this time zone and the difference from Greenwich Mean Time. |
| | Length U | Jnit | Choose the display unit for length. Change the unit displayed for the remaining amount of roll paper, Tot.Print Area , and so on. |
| | Detect M | lismatch | Specify printing behavior if the type and size of pap specified in the printer menu does not match the typ and size in the printer driver. Choose Pause to have printing paused under these counstances. Choose Warning to continue printing atter notification. Choose None to continue printing without notification. Choose Hold Job to store jobs with mismatched types and sizes of paper on the printer hard disk, in a print queue awaiting processing. (See "Using the Printer Hard Disk.") P.720 |
| | Paper Size Basis | Sht Selection 1 | If sheet size detection is activated, choose whether ISO A3+ or 13"x19"(Super B) is applied when a sheet of an intermediate size is detected. |
| | | Sht Selection 2 | If sheet size detection is activated, choose whether ISO B1 or 28"x40" (ANSI F) is applied when a she of an intermediate size is detected. |
| | Keep Pa | per Size | Choose On to use the paper size setting as the basis for printing instead of other settings. The margin set ting of the printer menu will be used instead of the margin setting of the printer driver if the latter is smaller, which may prevent text or images in the margin from being printed. |
| | | | Choose Off to give priority to margin settings. The larger value is used if the margin specified in the printer driver does not match the margin in the print menu. |

Menu Settings iPF8300S

Description, Instructions

947

| Rep.P.he | ad Print | Choose On to have the printer automatically execute the Advanced Adj. operations after you replace the Printhead. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") →P.850 |
|----------------------|------------------|--|
| Nozzle C | heck | In Frequency , specify the timing for automatic checks of nozzle clogging. Choose Standard to have the printer adjust the timing for checks based on the frequency of nozzle use. Choose 1 page to check once per page. Select Warning > On to display warnings if the nozzles clog during printing. |
| Carriage | ScanWdth | Specify the scan width of the carriage during printing. Select Automatic for movement equivalent to the width of paper loaded. Selecting Fixed will reduce any soiling on the back of the paper, although printing may take a little longer. |
| Use Rem | oteUI | Choosing Off prohibits access from RemoteUI. Settings can only be configured from the control panel. |
| Reset Pa | prSetngs | Restores settings that you have changed with Media Configuration Tool to the default values. |
| Erase HDD Data | High Speed | Erases file management data for print job data stored on the printer's hard disk. (See "Erasing Data on the Printer's Hard Disk.") —P.909 |
| | Secure High Spd. | Overwrites the entire hard disk with random data. (See "Erasing Data on the Printer's Hard Disk.") —P.909 |
| | Secure | Overwrites the entire hard disk with 00, FF, and random data (one time each). Verification is performed to check if the data was correctly written. (See "Erasing Data on the Printer's Hard Disk.") P.909 |
| Output Meth- | Print | Select the printing method for jobs received from soft- |
| od | Print (Auto Del) | ware other than the printer driver. When using the printer driver, configure settings on the printer. |
| Save: Box XX | | To print as usual, select Print . Selecting Print (Auto Del) will print the job and then delete the data from the printer's hard disk. Selecting Save: Box 01 will only save the print job in the box, without printing it. |
| Print Aft | ter Recv | A setting for jobs received from software other than the printer driver. When using the printer driver, configure settings on the printer. Select On to print the job after it has been saved. |

Setting Item

Keep Paper Size

System

Setup

iPF8300S Menu Settings

| | Setting Item | Description, Instructions |
|-----------------|------------------|---|
| System Setup | Common Box Set. | Select Print (Auto Del) to print without saving jobs in the box shared among multiple users. |
| | Show Job Log | Selecting Off prevents display of the log in Job Menu > Job Log . Additionally, the log is not printed if you choose Job Menu > Print Job Log . Note that because job logs are not collected, the Status Monitor accounting functions will not work correctly. |
| Take- up | Use Take-up Reel | Selecting Enable allows use of the Media Take-up Unit. |
| Reel | Auto Feed | Available only if Use Take-up Reel is already set to Enable . Rolls are automatically advanced to the position for attachment to the Rewind Spool. |
| | Skip Take-Up Err | Available only if Use Take-up Reel is already set to Enable . Choose On to continue with printing even if an error occurs with the Media Take-up Unit. Choose Off to pause printing if a take-up error occurs. |
| Prep.Mo | vePrinter | When transferring the printer to another location, choose the level of transfer and follow the instructions on the screen. (See "Preparing to Transfer the Printer.") →P.1044 Not displayed during a warning message that the remaining Maintenance Cartridge capacity is low. |
| Admin. Menu | Change Password | By setting a password, you can restrict menu display and configuration as follows. Enter a number in the range 0–9999999. |
| | | Viewing and configuration by administrators only |
| | | IPv4 Settings |
| | | Change Password Init.Admin.Pswd |
| | | Viewing and configuration by administrators, and only viewing by other users |
| | | Interface Setup settings (except IPv4 Settings) |
| | | Date & Time |
| | | Date Format Time Zone |
| | | Use RemoteUI |
| | | Reset PaprSetngs |
| | | Common Box Set. |
| | Init.Admin.Pswd | Choose OK to restore the Admin. Menu password to the default values. |
| Printer Info | Paper Info | Indicates the current paper size, type, and related printer settings. |
| | Ink Info | Indicates ink levels and maintenance cartridge capacity. |

Menu Settings iPF8300S

| | | Setting Item | Description, Instructions |
|-----------|-------------------------|--------------|---|
| Printer | Head | Printhead L | Indicates information about the printhead. |
| Info Info | | Printhead R | |
| | System Info | | Indicates the firmware version, serial number, and interface information. |
| | Error Log Other Counter | | Indicates the most recent error messages (up to five). |
| | | | Indicates the total printing volume of the printer. |

^{*1:} A rough estimate of how much ink was consumed per job is displayed. Actual ink consumption may be different. The average margin of error for estimates calculated according to Canon measurement conditions for ink costs is ±15%. Canon does not guarantee the accuracy of these estimates. Estimates may vary depending on conditions of use. Calculation of these estimates does not include ink consumed when cleaning printheads by forceful ejection of ink.

Menu Settings (During Printing)

Menu items are described in the following tables.

For instructions on selecting menu items, see "Menu Operations." -P.925

For details on menu levels and values, see "Menu Structure." →P.928

Ink Menu

| Setting Item | Description, Instructions |
|-----------------|--|
| Rep. Ink Tank | Replace the Ink Tank at this point. Follow the instructions displayed to complete the required procedure. (See "Replacing Ink Tanks.") —P.997 |
| Head Cleaning A | Clean the Printhead. (See "Cleaning the Printhead.") P.1012 Execute Head Cleaning A if printing is faint, oddly colored, or contains foreign substances. |

Job Menu

| | | Description, Instructions | | | |
|------------|----------------------------|---------------------------|--------------|-----------------------|---|
| Print Job | Job List | (Choose a print job) | Delete | | Delete the current job or queued jobs. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") —P.725 |
| | | | Preempt Jobs | | Print the job first after the current print job is finished. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") —P.725 |
| | | | Print Anyway | | Displayed when a job being held is selected. (See "Managing Pending Jobs (Printing or Deleting Jobs on Hold).") >P.728 |
| Stored Job | Mailbox List | (Enter a pass- | Job List | Print | Print the saved job. |
| | word if one has been set.) | | Delete | Delete the saved job. | |

| | | Setting Item | | Description, Instructions |
|-----------------|--|---|---|--|
| Stored Job | Mailbox List | (Enter a password if one has been set.) | Print Job List | Print a list of saved print jobs. |
| Job Log | (Choose from information about the last three print jobs.) | Document Nan | ne | Indicates the document name of the selected print job. |
| | | User Name | | Indicates the name of the user who sent the print job. |
| | Joes.) | Page Count | | Indicates the number of pages in the job. |
| | | Job Status | | Indicates the printing results. |
| | | Print Start Tin | ne | Indicates when the print job was started. |
| | | Print End Time | e | Indicates when the print job was finished. |
| | | Print Time | | Indicates the time required to print the job. |
| | | Print Size | | Indicates the paper size in the print job. |
| | | Media Type | | Indicates the type of paper in the print job. |
| | | Interface | | Indicates the interface used for the print job. |
| | | Ink Consumed | | Indicates a rough estimate of how much ink was consumed per job.(*1 →P.950) |
| Print Job Log | | | | Print a record of print jobs, including the paper type and size, amount of ink consumed, and so on. Ink consumption indicates a rough estimate of the amount of ink consumed per print job. (*1 →P.950) |
| Pause Print | | | | If you set this option to On , printing is stopped at that point and the printer enters a state in which printing is paused. |
| HDD Information | | | Indicates the total hard disk capacity and the mail box free space. | |

^{*1:} A rough estimate of how much ink was consumed per job is displayed. Actual ink consumption may be different. The average margin of error for estimates calculated according to Canon measurement conditions for ink costs is ±15%. Canon does not guarantee the accuracy of these estimates. Estimates may vary depending on conditions of use. Calculation of these estimates does not include ink consumed when cleaning printheads by forceful ejection of ink.

Set./Adj. Menu

| Settir | g Item | Description, Instructions | |
|-------------------------|---------------|---|--|
| Adj. Fine Feed | | Displayed when you have selected Feed Priority > Adj. Priority > Automatic or Print Quality . Fine-tune the feed amount manually. | |
| Printer Info Paper Info | | Indicates the current paper size, type, and related printer settings. | |
| | Ink Info | Indicates ink levels and maintenance cartridge capacity. | |
| | Head Info | Indicates the model name, serial number, number of days used, and dot count of the current printhead | |
| | System Info | Indicates the firmware version, serial number, and interface information. | |
| | Error Log | Indicates the most recent error messages (up to five). | |
| | Other Counter | Indicates the total printing volume of the printer. | |

Status Print

You can print a **Status Print** report indicating the current status of the printer.


With **Status Print**, information is printed regarding the printer firmware version, various settings, and the status of consumables.

Printing Status Print reports

1. Load paper.

When using sheets, load paper of A4/Letter size. You will need at least four sheets. The required sheet quantity varies depending on the execution log quantity of unique calibration.

2. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select Settings/Adj. tab (☐).





Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

3. Press the **OK** button. The **Set./Adj. Menu** is displayed.

- **4.** Press ▲ or ▼ to select **Test Print**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select **Status Print**, and then press the **OK** button.

iPF8300S Status Print

Checking the information in **Status Print** reports

The following information is included in **Status Print** reports.

| Canon imagePROGRAF iPFxxxx Status Print | Printer model |
|---|---|
| Firm | Firmware version |
| Boot | Boot ROM version |
| MIT(DBF) | MIT database format version |
| MIT(DB) | MIT database version |
| S/N | Printer serial number |
| Date | Indicates when the status print report was printed. |

| Paper Menu | | | Information on the loaded paper. |
|------------|------------------|-----------|----------------------------------|
| | Paper Type | | |
| | Roll Media | | |
| | | Cut Sheet | |
| | ManageRemainRoll | | |
| | Keep Paper Type | | |

| Job Menu | | | Job-related information. |
|----------|-----------------|----------------|--|
| Job Log | | | A counter for maintenance purposes. Various information about previous jobs. |
| | HDD Information | | Indicates the total hard disk capacity and the mail box free |
| | | Total capacity | space. |
| | | Box free space | |

| Set./Adj. Menu | | | | Settings and adjustment information. |
|----------------|--------------|------------------|-----------------|--|
| | System Setup | | | Printer system settings, as well as settings re- |
| | | Sleep Time | er | garding warnings and errors. |
| | | Buzzer | | |
| | | Contrast A | dj. | |
| | | Date Form | at | |
| | | Language | | |
| | | Time Zone | | |
| | | Length Unit | | |
| | | Detect Mis | match | |
| | | Paper Size Basis | | Paper-related settings. |
| | | | Sht Selection 1 | |
| | | | Sht Selection 2 | |
| | | Keep Paper Size | | |

Status Print iPF8300S

| | Rep.P.head I | Print | | Settings after a test pattern was printed following head replacement. | |
|-----------|---------------|-----------------------------|-----------------|---|--|
| | Show Job Lo | og | | Show Job Log settings. | |
| | Nozzle Chec | ck | | Nozzle-check settings. | |
| | | Frequency | | | |
| | | Warning | | | |
| | CarriageScar | nWdth | | Carriage scan width setting. | |
| | Use Remote | UI | | Settings used by RemoteUI. | |
| | Output Meth | nod | | Print job settings. | |
| | Print After R | Recv | | | |
| | Common Bo | ox Set. | | | |
| Adjust l | Printer | | | Adjustment settings. | |
| | Head Posi. A | Adj. | | A counter for maintenance purposes. | |
| | | Adjust Log | | Head position adjustment values for previous jobs. | |
| | Calibration | | | Color calibration settings. | |
| | | Calibration Log bration) | g (Common Cali- | A record of when common calibration was performed. | |
| | | Da | | Indicates the date when calibration was performed and the type of paper used. | |
| | | | per Type | 11 11 | |
| | | Use Adj. Value | | A setting value indicating whether color calibration adjustment values are to be applied to printing. | |
| | | Set Exec. Guide | | A setting value indicating whether to display a message recommending the execution of colo calibration. | |
| Гake-up | Reel | | | Settings regarding the Media Take-up Unit. | |
| | Use Take-up | Reel | | | |
| | Skip Take-U | Jp Err | | 1 | |
| Printer 1 | Info | | | Ink information, RAM usage, and a record of errors. | |
| | Ink Info | | | Ink-related information. | |
| | | MC | | Maintenance Cartridge capacity (%) | |
| | | PC, C, BK, MB | K, Y, M, PM, GY | Ink levels. The remaining ink is displayed in a five-level scale. | |
| | System Info | | | Indicates the total amount of RAM. | |
| | | RAM | | | |
| | Error Log | | | The past five error codes. | |

| HEAD LOT NUMBER | Printhead lot number. |
|-----------------|-----------------------|
| LOT L: R: | |

iPF8300S Status Print

| PARTS ST | PARTS STATUS COUNTER | | Utilization status of replacement parts that require servicing. |
|----------|-----------------------|---------------|---|
| | | | |
| COUNTE | R | | Utilization status of the cutter, media, and other items (indi- |
| | CUTTER MEDIA | | cating how much they have been used). |
| | | | |
| | LIFE TTL | | |
| | | LIFE ROLL | |
| | | LIFE CUTSHEET | |
| | MEDIA 1-7,OTHER | | |
| | NAME | | |
| | | TTL | |
| | | ROLL | |
| | | CUTSHEET | |
| | AFTER IN | ISTALLATION | |

| DUTY | | Counters for maintenance purposes. Needed when service |
|------|-------------------|--|
| | UNIT:m2 | is requested. |
| | UNIT:sq.f | |
| | UNIT:A4 Sheet | |
| | UNIT:Letter Sheet | |

| Set./Adj. Menu | | | | Settings and adjustment information. | |
|----------------|--|-------------|--------------------------------------|--------------------------------------|--|
| Adjust Printer | | | | | Adjustment settings. |
| | | Calibration | | | Color calibration settings. |
| | | | Calibration Log (Unique Calibration) | | A record of when unique calibration was performed. |
| | | | | No. | Log number. |
| | | | | Paper Type | Indicates the date when calibration was per- |
| | | | | Date | formed and the type of paper used. |

Printing Interface Setting Reports


You can print an **Interface Print** report indicating the current interface settings values of the printer. **Interface Print** reports indicate settings values for TCP/IP, NetWare, and other settings.

Printing Interface Print reports

1. Load the paper.

If using sheets, load paper A4/Letter-sized, you will need at least three sheets.

2. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐).





- Note
- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- **3.** Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **4.** Press ▲ or ▼ to select **Test Print**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Interface Print, and then press the OK button.

Confirming Interface Print information

The following information is included in the **Interface Print** report.

| Canon imagePROGRAF iPFxxxx Interface Print | Printer model |
|--|---|
| | |
| Firm | Firmware Version |
| Boot | Boot ROM Version |
| MIT(DBF) | MIT Database Format Version |
| MIT(DB) | MIT Database Version |
| S/N | Printer serial number |
| Date | The date when the interface setup print report was printed. |

| EOP Timer | | Specify the timeout period before cancellation of print jobs that cannot be received by the printer. |
|-----------|---------------------------|--|
| TCP/IPv4 | Frame Type | IPv4 settings values. |
| | Use DHCP | |
| | Use BOOTP | |
| | Use RARP | |
| | Enable DNS Dynamic Update | |
| | Use Zeroconf Function | |
| | IP Address | |
| | Subnet Mask | |
| | Gateway Address | |

| TCP/IPv4 | LPD Printing | IPv4 settings values. |
|----------|------------------------------|-----------------------|
| | IPP Printing | |
| | IPP Printer URI | |
| | RAW Printing | |
| | Raw Mode Bi-direction | |
| | FTP Printing | |
| | Use Discovery | |
| | Scope | |
| | Primary DNS Server Address | |
| | Secondary DNS Server Address | |
| | DNS Host Name | |
| | DNS Domain Name | |
| | MulticastDNS ServiceName | |
| | SNMPv1 | |
| | SNMPv3 | |

| TCP/IPv6 | Use IPv6 | Use IPv6 | | |
|----------|--------------------------|------------------------------|--|--|
| | Use DHCPv6 | Stateful Address | | |
| | | Prefix Length | | |
| | | Primary DNS Server Address | | |
| | | Secondary DNS Server Address | | |
| | Use a stateless address | Stateless Address 1 | | |
| | | Prefix Length 1 | | |
| | | Stateless Address 2 | | |
| | | Prefix Length 2 | | |
| | | Stateless Address 3 | | |
| | | Prefix Length 3 | | |
| | | Stateless Address 4 | | |
| | | Prefix Length 4 | | |
| | | Stateless Address 5 | | |
| | | Prefix Length 5 | | |
| | | Stateless Address 6 | | |
| | | Prefix Length 6 | | |
| | Use a link-local Address | Link-Local Address | | |
| | | Prefix Length | | |
| | Use a manual address | IP Address | | |
| | | Prefix Length | | |
| | | Default Router Address | | |
| | | Prefix Length | | |


| TCP/IPv6 | Use a manual address | Primary DNS Server Address | IPv6 settings values. |
|----------|--|------------------------------|-----------------------|
| | | Secondary DNS Server Address | |
| | Use the same host name and domain name as IPv4 | DNS Host Name | |
| | | DNS Domain Name | |
| | Perform dynamic updating of stateful addresses | | |
| | Dynamically update the stateless address | | |
| | Dynamically update the manual add | ress | |

| NetWare | Frame Type | NetWare settings values. | | |
|-------------------|------------------------------|-----------------------------|-------------------|--|
| | IPX External Network Numb | IPX External Network Number | | |
| | Node Number | | | |
| | Print Application | | | |
| | Bindery PServer | File Server Name | | |
| | | Print Server Name | | |
| | | Print Server Password | | |
| | | Polling Interval | | |
| | RPrinter | Print Server Name | | |
| | | Printer Number | | |
| | NDS PServer | Tree Name | | |
| | | Context Name | | |
| | | Print Server Name | | |
| | | Print Server Password | | |
| | | Polling Interval | | |
| | NPrinter | Print Server Name | | |
| | | Printer Number | | |
| AppleTalk | Phase Type | AppleTalk settings values. | | |
| | Name | | | |
| | Network Number | | | |
| | Zone | | | |
| Network Interface | Physical Interface | | Network interface | |
| | Transmission Rate | settings values. | | |
| | MAC Address | | | |
| | Auto Detect | | | |
| | Communication | | | |
| | Ethernet Type | | | |
| | Spanning Tree | | | |
| | Use the Jumbo Frame Function | | | |

Network Setting

| Networl | k Environment | 959 |
|-----------|---------------|-----|
| Using F | RemoteUI | 962 |
| Initial S | Settings | 965 |
| NetWar | re Settings | 974 |
| Mac OS | S X Settings | 984 |
| Other S | Settings | 991 |

10



959

Network Environment

Network Environment 959

Network Environment

System requirements

The system requirements, which vary depending on your network, are as follows.

- Printing over a TCP/IP network (when using IPv4)
 - Compatible operating systems
 - Windows XP (Home Edition or Professional)
 - Windows Server 2003 (Standard Edition)
 - Windows Vista (Home Basic/Business/Ultimate)
 - Windows Server 2008 (Standard Edition or Enterprise Edition)
 - Windows 7
 - Windows XP Professional x64 Edition
 - Windows Server 2003 x64 Edition
 - Windows Vista x64
 - Windows Server 2008 x64
 - Windows 7 x64
 - Mac OS X 10.2.8 or later
 - Unix (Solaris 9)
 - Unix (Red Hat 9)
 - Compatible computer
 - A computer that runs one of the above operating systems
- Printing over a TCP/IP network (when using IPv6)
 - Compatible operating systems
 - Windows Vista (Home Basic/Business/Ultimate)
 - Windows Server 2008 (Standard Edition or Enterprise Edition)
 - Windows 7
 - Windows Vista x64
 - Windows Server 2008 x64
 - Windows 7 x64
 - Mac OS X 10.3.9 or later



Note

- When using IPv6, you must specify IPv6 on the Control Panel or in RemoteUI. For instructions, see "Configuring TCP/IPv6 Network Settings." —P.968 or see "Configuring the Printer's TCP/IP Network Settings With RemoteUI." —P.970
- The imagePROGRAF printer driver is supported in Mac OS X 10.4.11 or later.
- The imagePROGRAF printer driver is not compatible with Unix.

iPF8300S Network Environment

Printing over an AppleTalk network

- · Compatible operating systems
 - Mac OS X 10.2.8-10.4
- Compatible computer
 - A computer that runs one of the above operating systems



Note

- The printer cannot be used over a LocalTalk network.
- Compatible with EtherTalk Phase 2.
- The imagePROGRAF printer driver is not compatible with AppleTalk.

Printing over a NetWare network

- Compatible servers
 - Novell NetWare 4.2/5.1/6.0
- Compatible clients
 - Windows XP (Professional)
- Compatible computer
 - A computer that runs one of the above operating systems



Note


• In NetWare 6.0, iPrint is not supported.

Network Environment

After confirming what type of network environment you will connect the printer to, set up the printer and computers as needed.

· Example of a Windows network

In Windows networks, print over TCP/IP.



960

10




Note

• NetBIOS is not supported.

Network Environment iPF8300S

• Example of a Macintosh network

In Macintosh networks, print over AppleTalk (EtherTalk) or TCP/IP, using Bonjour (Zeroconf) functions.






Note

• The imagePROGRAF printer driver is not compatible with AppleTalk.

• Example of a NetWare network





Note

• Even if there is a NetWare server in your network environment, you can use it in conjunction with TCP/ IP or AppleTalk. In this case, complete the settings for each protocol you will use.

iPF8300S Network Environment

Using RemoteUI

Using RemoteUI962

Using RemoteUl

RemoteUI is software with which you can access the printer via the network from your Web browser to confirm the printer status, operate jobs, and configure the settings. Since the software (Web server) for using RemoteUI is built in the printer, preparing software other than a Web browser is unnecessary. You can use RemoteUI if an imagePROGRAF printer on a network is connected to your computer. If you start your Web browser and specify the IP address of the printer, the RemoteUI screen is displayed, and you can use RemoteUI.



Important

What You Can Do With RemoteUI

With RemoteUI, you can access the printer via a network, configure network settings, and display the current status of the printer, various types of information, the processing status of jobs, etc.

Starting RemoteUI

Start RemoteUI by the following operations.


- 1. Start your Web browser.
- 2. Enter the following URL in Address or Location. http://printer IP address or name/ Example: http://xxx.xxx.xxx.xxx/

10

962

Using RemoteUI iPF8300S

3. The RemoteUI screen is displayed.





Note

• The screen slightly differs depending on the model of printer.

Configuring the Network With RemoteUI

For details on configuring printer settings for networks, refer to the following topics.

- Configuring the Printer's TCP/IP Network Settings With RemoteUI —P.970
- Configuring the Printer's AppleTalk Network Settings →P.989
- Configuring the Printer's NetWare Network Settings With RemoteUI →P.981
- Specifying Printer-Related Information →P.991

963

iPF8300S Using RemoteUI



Important

- For the Web browser, use Netscape Navigator 6.0 or later, Internet Explorer 5.01 or later, or Firefox 1.5 or later. For Mac OS X, Safari 1.32 or later or 2.03 or later also is supported.
- This cannot be used connected via a proxy server. In environments where a proxy server is used, add the printer's IP address to **Exceptions** (addresses accessed without a proxy server) in the web browser proxy server settings. (Settings may vary depending on the network environment.)
- Enable JavaScript and cookies in the web browser.
- If you access RemoteUI with the printer name instead of its IP address, make sure the DNS settings are correctly configured.
- Depending on the network environment, you may not be able to start RemoteUI.
- Confirm whether System Setup > Use RemoteUI is set to On on the Control Panel of the printer.



Note

- RemoteUI also offers many other features. You can display the ink levels, check error messages and other status information, and cancel print jobs.
- By factory default, the English screen is displayed. To change the display language, select the desired language under **Language** before logging on in administrator mode.
- If you login in Administrator Mode, you can configure to use the Jumbo Frame function in the **Network** page. However, this function might not be able to be used depending on the network environment.

10

964

Using RemoteUI iPF8300S

Initial Settings

| Configuring the IP Address on the Printer | 965 |
|---|-----|
| Configuring the IP Address Using the Printer Control Panel | 966 |
| Configuring TCP/IPv6 Network Settings | 968 |
| Configuring the Printer Driver Destination (Windows) | |
| Configuring the Printer's TCP/IP Network Settings With RemoteUI | 970 |

Configuring the IP Address on the Printer

You must configure the printer's IP address before using the printer in a TCP/IP network.

The printer's IP address is configured automatically when you install the printer driver following the instructions in the Setup Guide.

Configure the IP address by using imagePROGRAF Device Setup Utility, the printer Control Panel, or ARP or PING commands, if the IP address is changed, or if you change the printer connection mode to a network connection. For details on configuring the IP address, refer to the following topics.

- Configuring the IP Address Using imagePROGRAF Device Setup Utility →P.443 (Windows)
- Configuring the IP Address Using the Printer Control Panel →P.966
- Configuring the IP Address Using ARP and PING Commands →P.967



Important

- If you use a DHCP server for automatic assignment of the printer's IP address, printing may no longer be possible after the printer is turned off and on. This is because an IP address different from before has been assigned. Thus, when using DHCP server functions, consult your network administrator and configure the settings in one of the following ways.
 - Configure the setting for dynamic DNS updating
 In the printer menu, either set DNS Dync update to On, or activate the setting Enable DNS Dynamic Update in RemoteUI.

(See "Menu Settings.") →P.938 (See "Configuring the Printer's TCP/IP Network Settings With RemoteUI .") →P.970

• Configure the setting for assignment of the same IP address each time the printer starts up



Note

• We recommend configuring the printer's IP address even if you will use the printer in networks other than TCP/IP networks. Configuring the printer's IP address enables you to use RemoteUI to configure the network settings and manage the printer with a web browser.

For details on RemoteUI, see "Using RemoteUI ." →P.962

Configuring the IP Address Using the Printer Control Panel

This topic describes how to configure the printer's IP address on the Control Panel.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (—————).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Interface Setup**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select TCP/IP, and then press the **OK** button.
- 5. Press ▲ or ▼ to select IPv4, and then press the OK button.
- **6.** Press ▲ or ▼ to select **IPv4 Settings**, and then press the **OK** button.
- 7. Press ▲ or ▼ to select **IP Address**, and then press the **OK** button.
- **8.** After you press \blacktriangleleft or \blacktriangleright to select the input field, numerical input is possible.
- **9.** Press the \triangle or ∇ button to enter the value.



Note

- Hold down ▲ to increase the value continuously. However, 0 follows 2 for digits of 100 and 0 follows 9 for digits of 10 and 1.
- Hold down ▼ to decrease the value continuously. However, 2 follows 0 for digits of 100 and 9 follows 0 for digits of 10 and 1.
- Hold down ▲ or ▼ to increase or decrease the value continuously.
- Make sure the IP address you enter for the printer is not the same as any computer IP address in your network.
- 10. Repeat steps 8 and 9 to complete the settings, and then press the **OK** button.

10

11. Press the Menu button.

If you have changed the settings, a confirmation message is displayed. Press \blacktriangle or \blacktriangledown to select **Yes**, and then press the **OK** button.





Important

- Be sure to complete step 11. This will activate the values you have entered.
- If an error message is displayed, check the settings and correct any invalid values.



Note

- You can also specify the subnet mask and default gateway on the Control Panel.
- The DNS can also be configured from the printer Control Panel.


Configuring the IP Address Using ARP and PING Commands

This topic describes how to configure the IP address using ARP and PING commands.

To use the ARP and PING commands, you will need to know the printer's MAC address. You can confirm the MAC address on the Control Panel.

1. Check the printer's MAC address.
You can confirm the MAC address on the Control Panel as follows:

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐☐☐).



- **2.** Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Interface Setup**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select **Ethernet Driver**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select MAC Address, and then press the OK button.



Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- You can investigate the MAC address by printing an interface setting report. (See "Printing Interface Setting Reports.") →P.954

- 2. In Windows, open a command prompt, or in Mac OS X, start Terminal.
- Execute the following command to add entries to the ARP table for managing IP addresses and corresponding MAC addresses.

arp -s [IP address] [the printer's MAC address you have verified] Example: arp -s xxx.xxx.xxx.xxx xx-xx-xx-xx-xx



Note

 In Mac OS X when using Terminal, enter the arp command in the format arp -s xxx.xxx.xxx.xxx xx-xx-xx-xx.
 For details, refer to the help file for the command line.

4. Execute the following command to send the IP address to the printer and configure it. ping [IP address as specified in the ARP command] -1 479 Example: ping xxx.xxx.xxx -1 479



Note

- In -I, the I is the letter I.
- In Mac OS X when using Terminal, enter the ping command in the format ping -s 479 xxx.xxx.xxx.

 For details, refer to the help file for the command line.



Note


• The subnet mask and default gateway are set to 0.0.0.0. Use RemoteUI to change the subnet mask and default gateway to match your network settings.

For details on RemoteUI, see "Using RemoteUI ." →P.962

Configuring TCP/IPv6 Network Settings

When printing in a TCP/IPv6 network, you must configure the TCP/IPv6 settings on the Control Panel. Follow the steps below to configure the TCP/IPv6 network settings.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐☐☐).



968



Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Interface Setup**, and then press the **OK** button.

- **4.** Press \blacktriangle or \blacktriangledown to select TCP/IP, and then press the **OK** button.
- 5. Press ▲ or ▼ to select IPv6, and then press the OK button.
- **6.** Press ▲ or ▼ to select **IPv6 Support**, and then press the **OK** button.
- **7.** Press \triangle or ∇ to select **On**, and then press the **OK** button.



Important

• Once you set IPv6 Support to On, the IPv6 StlessAddrs setting takes effect.



Note

- You can also configure IPv6 StlessAddrs and DHCPv6 from the printer Control Panel.
- The DNS can also be configured from the printer Control Panel.

Configuring the Printer Driver Destination (Windows)

This topic describes how to specify the printer driver destination if the printer's IP address is changed, or if you will use the printer over a network connection instead of via USB connection.

The procedure described below is the configuration based on the LPR or Raw protocol using the standard TCP/IP port in Windows (**Standard TCP/IP Port**).



Important

- If you will use the printer in a TCP/IP network, make sure the printer's IP address is configured correctly.
 - Configuring the IP Address on the Printer →P.965
- ${f 1.}$ Open the **Printers and Faxes** (or **Printers**, **Devices and Printers**) window.
- 2. Right-click the icon of this printer and choose **Properties** (For Windows 7 and Windows Vista, **Printer Properties**) to open the printer properties window.
- **3.** Click the **Port** tab to display the **Port** sheet.
- **4.** Click **Add Port** to display the **Printer Ports** dialog box.
- 5. In the Available Port list, select Standard TCP/IP Port.
- 6. Click New Port. After the wizard starts, a window is displayed for the Welcome to the Add Standard TCP/IP Printer Port Wizard.
- 7. Click Next.
- 8. In **Printer Name or IP Address**, enter the printer's IP address. If the DNS is configured, you can also enter the DNS Domain Name.

10

- **9.** Follow the instructions on the screen to add a printer port.
- **10.** Click **Close** to close the **Printer Ports** dialog box.
- 11. Make sure the printer port you added is displayed under **Ports**, and that the port is selected.
- **12.** Click **Close** to close the printer properties window.

Configuring the Printer Driver Destination (Mac OS X)

Specify the printer driver destination as follows if the printer's IP address is changed, or if you will use the printer over a network connection instead of via USB connection.

- If you switch to printing in a TCP/IP network, or if the printer's IP address is changed, see "Configuring the Destination in TCP/IP Networks." —P.984
- If you switch to printing in a Bonjour network, see "Configuring the Destination for Bonjour Network ." —P.986

Configuring the Printer's TCP/IP Network Settings With RemoteUI

Follow the steps below to configure the TCP/IP network settings.

When using an IPv4 IP address

1. Start the web browser and enter the following URL in the Location (or Address) box to display the RemoteUI page.

http://**printer IP address or name**/ Example: http://xxx.xxx.xxx/

- 2. Select Administrator Mode and click Logon.
- **3.** If a password has been set on the printer, enter the password.
- **4.** Click **Network** in the **Device Manager** menu at left to display the **Network** page.
- 5. Click Edit in the upper-right corner of the TCP/IPv4 group to display the Edit TCP/IP Protocol Settings page.
- **6.** Refer to the TCP/IP Settings Items table to complete the settings.

TCP/IP Settings Items

| Item | Details | Default Setting |
|--------------------------------|---|-----------------|
| Use DHCP | Activate this setting to use DHCP for configuring the IP address. | Off |
| Use BOOTP | Activate this setting to use BOOTP for configuring the IP address. | Off |
| Use RARP | Activate this setting to use RARP for configuring the IP address. | Off |
| Enable DNS Dy- namic Update | Activate this setting to perform DNS server registration automatically. | Off |

| Item | Details | Default Setting |
|---------------------------------|--|---------------------------|
| Use Zeroconf Function | Activate this setting to use Bonjour. | On |
| IP Address | Specify the printer's IP address. | 0.0.0.0 |
| Subnet Mask | Specify the printer's subnet mask. | 0.0.0.0 |
| Gateway Address | Specify the printer's default gateway. | 0.0.0.0 |
| LPD Printing | Activate this setting to use LDP Printing. | On |
| IPP Printing | Activate this setting to use IPP Printing. | On |
| IPP Printer URI | Specify the URI of the printer used for IPP printing using up to 252 characters. | printer |
| RAW Printing | Activate this setting to use Raw Printing. | On |
| RAW Mode Bi-di- rection | Activate this setting to use Raw mode bidirectional communication. | Off |
| FTP Printing | Activate this setting to use FTP Printing. | On |
| Use Discovery | Activate this setting to use SLP Discovery function. | On |
| Scope | Enter the SLP search range. | default |
| SMTP Server Address | Specify the SMTP server's IP address. You can also specify the SMTP server domain name, if desired. | 0.0.0.0 |
| Primary DNS Serv- er Address | Specify the IP address of the primary DNS server. | 0.0.0.0 |
| Secondary DNS Server Address | Specify the IP address of the secondary DNS server. | 0.0.0.0 |
| DNS Host Name | Specify the printer host name, up to 63 characters (1–63 characters). Use single-byte letters, numbers, and - (hyphens). Do not use numbers or - for the first character or - for the last character. | NB-18GBipxxxxxx |
| DNS Domain Name | Specify the printer domain name, up to 63 characters. Use single-byte letters, numbers, - (hyphens), and . (periods). Do not use numbers, -, or . for the first character, or - or . for the last character. | blank |
| Multicast DNS Service Name | Specify the printer's Multicast DNS service name. (1–63 characters) This name will be displayed when Bonjour functions are used. | Canon iPFxxxx (xxxxxx) |

7. Click **OK** to display the **Network** page.



Note

- If you specify to configure the IP address using DHCP, BOOTP, or RARP, there must be a server that supports such protocol running in the network.
- If you specify to configure the IP address using DHCP, BOOTP, or RARP, the IP address obtained by this method is used first. If you cannot obtain the IP address, the address specified in **IP Address** is used.
- It takes up to two minutes to determine whether DHCP, BOOTP, or RARP are available. We recommend clearing check boxes of options you will not use.
- If you are using a DNS server, select **Enable DNS Dynamic Update** and enter the IP Address for DNS servers and DNS domain name in **Primary DNS Server Address**, **Secondary DNS Server Address** and **DNS Domain Name**, respectively.

When using an IPv6 IP address

1. Start the web browser and enter the following URL in the Location (or Address) box to display the RemoteUI page.

http://**printer IP address or name**/ Example: http://xxx.xxx.xxx/

- 2. Select Administrator Mode and click Logon.
- **3.** If a password has been set on the printer, enter the password.
- **4.** Click **Network** in the **Device Manager** menu at left to display the **Network** page.
- 5. Click Edit in the upper-right corner of the TCP/IPv6 group to display the Edit TCP/IPv6 Protocol Settings page.
- **6.** Refer to the TCP/IPv6 Settings Items table to complete the settings.

TCP/IPv6 Settings Items

| | Item | Details | Default Setting |
|--|------------------------|--|------------------|
| Use IPv6 | | Activate to enable IPv6. | Off |
| Use DHCPv | 6 | Activate when using a DHCPv6 server to acquire the IP address. | Off |
| Use a statele | ess address | Activate when using an IPv6-compatible router to acquire the IP address. | On |
| Use a manua | al address | Activate when configuring the IP address manually. | Off |
| | IP Address | Enter the printer's IP address. | :: |
| | Prefix Length | Enter the IP address prefix length. | 0 |
| | Default Router Address | Enter the default router address. | :: |
| | Prefix Length | Enter the prefix length of the default router address. | 0 |
| Primary DN | IS Server Address | Specify the IP address of the primary DNS server. | :: |
| Secondary I | ONS Server Address | Specify the IP address of the secondary DNS server. | :: |
| Use the same host name and domain name as IPv4 | | Activate when using the same DNS host and domain names as for IPv4. | Off |
| | DNS Host Name | Specify the printer host name, up to 63 characters (1–63 characters). Use single-byte letters, numbers, and - (hyphens). Do not use numbers or - for the first character or - for the last character. | NB-18GBip6xxxxxx |
| | DNS Domain Name | Specify the printer domain name, up to 63 characters. Use single-byte letters, numbers, - (hyphens), and . (periods). Do not use numbers, -, or . for the first character, or - or . for the last character. | blank |
| Perform dynamic updating of stateful addresses | | Activate this setting to automatically register the stateful address with the DNS server. | Off |
| Dynamically address | y update the stateless | Activate this setting to automatically register the stateless address with the DNS server. | Off |

| Item | Details | Default Setting |
|---------------------------------------|---|-----------------|
| Dynamically update the manual address | Activate this setting to automatically register the manual address with the DNS server. | Off |

7. Click ok to display the Network page.



Note

• If you are using a DNS server, select **Enable DNS Dynamic Update** and enter the IP Address for DNS servers and DNS domain name in **Primary DNS Server Address**, **Secondary DNS Server Address** and **DNS Domain Name**, respectively.

NetWare Settings

| Configuring NetWare Network Settings | 974 |
|--|-----|
| Specifying the Printer's Frame Type | |
| Specifying NetWare Print Services | |
| Configuring the Printer's NetWare Network Settings With RemoteUI | |

Configuring NetWare Network Settings

Follow these steps to configure the network environment when using the printer in a NetWare network.



Important

- To configure network settings, you must be logged in with administrative rights such as **Administrator**. We recommend that your network administrator configure the network settings.
- 1. Configure the Ethernet frame type to be used in communication by the printer with the computer. For details on configuring settings, see "Specifying the Printer's Frame Type." —P.975
- 2. Configure the NetWare print service such as the print server and queue.

 For details on configuring settings, see "Specifying NetWare Print Services." →P.979
- 3. Configure the NetWare protocol details other than the frame type.

 For details on configuring settings, see "Configuring the Printer's NetWare Network Settings With RemoteUI."

 P 981

After completing the settings of this procedure, configure the settings on each computer for printing in a NetWare network.

- **4.** Connect to the NetWare network.

 Install the NetWare client software on all computers that are to perform printing, and log in to the NetWare server or tree. For details on connecting, refer to the documentation for NetWare or your operating system.
- 5. Install the printer driver.

 According to the instructions of your network administrator, install the printer driver on all computers that are to perform printing. When installing, select **Network Printer** as the printer connection destination, and select the queue created when configuring the NetWare print service.
- **6.** Configure the printer port by the following procedure. If you configured the printer connection destination while installing the printer driver, this procedure is unnecessary.
 - 1. Open the Printers and Faxes (or Printers, Devices and Printers) window.
 - **2.** Right-click the icon of this printer and choose **Properties** (For Windows 7 and Windows Vista, **Printer Properties**) to open the printer properties window.
 - **3.** Click the **Port** (or **Advanced**) tab to display the **Port** (or **Advanced**) sheet.
 - **4.** Configure the print destination port to the print queue created when configuring the NetWare print service.

Specifying the Printer's Frame Type

To enable communication between the printer and computers on your network, specify the Ethernet frame type in your Net-Ware environment.

Follow the steps below to specify the frame type by using imagePROGRAF Device Setup Utility or the printer Control Panel.



Important

• Before specifying the frame type, make sure the printer is on and connected to the network.



Note

- You can specify the frame type by using RemoteUI if the printer's IP address is configured.
- For instructions on installing imagePROGRAF Device Setup Utility, see "Installing imagePROGRAF Device Setup Utility." →P.443 .


Specifying the frame type using imagePROGRAF Device Setup Utility

1. Start imagePROGRAF Device Setup Utility.




- 2. In the list of printers, select the printer to configure.
- **3.** Choose **Protocol Settings** from the **Printer** menu.

4. Click the **NetWare** tab and select the frame type in the **NetWare Frame Type** list.



Specifying the Printer's Frame Type

5. Select the IPv4 tab. In IP Address, enter the IP address assigned to the printer, and then enter the subnet mask in Subnet Mask and the default gateway in Gateway Address.





Important

- You must specify the IP address here to be able to configure NetWare protocol settings using RemoteUI.
- 6. Click Set.
- 7. Click ok after the Confirmation message is displayed.
- **8.** Exit imagePROGRAF Device Setup Utility.

Specifying the frame type using the printer Control Panel

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (———————).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Interface Setup**, and then press the **OK** button.
- **4.** Press **△** or **▼** to select **NetWare**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select **NetWare**, and then press the **OK** button.
- **6.** Press ▲ or ▼ to select **On**, and then press the **OK** button. The display reverts to the **NetWare** menu.
- 7. Press ▲ or ▼ to select Frame Type, and then press the OK button.
- 8. Press ▲ or ▼ to select the frame type to use, and then press the **OK** button. The display reverts to the **NetWare** menu.
- **9.** Press ▲ or ▼ to select **Print Service**, and then press the **OK** button.
- 10. Press ▲ or ▼ to select the desired print service, and then press the OK button. The display reverts to the NetWare menu.
- 11. Press the Menu button.

 If you have changed any settings, a confirmation message is displayed. In this case, press the OK button.





Important

• Be sure to complete step 11. This will activate the values you have entered.



Note

- If an error message is displayed, check the settings and correct any invalid values.
- To cancel this process, press the **Back** button.

Specifying NetWare Print Services

Before printing in a NetWare network, you must configure print services such as print servers, print queues, and so on. You can configure the print service settings from a computer using any of the following Novell software provided with NetWare.

- NWADMIN
- PCONSOLE



Important

- If you use NWADMIN to configure the print service settings, Novell Client (the Novell NetWare client software) must be installed as the client software application.
- NetWare networking is unsupported in Windows Vista, Windows Server 2008 and Windows 7.

This topic gives instructions for configuring NetWare print services. The order of this procedure may vary depending on the environment

Choosing the type of print services

Before completing print service settings, choose the type of print service. Refer to the following descriptions as needed.



Note

• In NetWare 5.1 or 6.0, NDPS may also be used as the print service. If you use NDPS, use the Novell printer gateway included with NetWare. For details on configuring NDPS, refer to the NetWare documentation.

- NDS (Novell Directory Service) and bindery NDS and bindery are both supported. Use the mode that is compatible with your network environment.
- Queue server mode and remote printer mode Queue server mode and remote printer mode are both supported.
 - · Queue server mode
 - When using queue server mode, all print server functions are supported, so there is no need for other print server software or hardware. In NDS queue server mode (NDS PServer), the NDS print server is used for printing. In bindery queue server mode (Bindery PServer), the bindery print server is used for printing. Note that if you use queue server mode, a NetWare user license is required for each network interface.
 - Remote printer mode
 In remote printer mode, the printer is controlled by the NetWare print server. Thus, a NetWare print server is required. In NDS remote printer mode (NPrinter), the NDS print server is used for printing, and in bindery remote printer mode (RPrinter), the bindery print server is used for printing.

Using NWADMIN or PCONSOLE to set up the print server

Use NWADMIN to set up the print server if NDS queue server mode or remote printer mode is used.

1. Log into NetWare as Administrator or with equivalent rights, and then start NWADMIN.

- 2. Run Quick Setup.
 - 1. Choose Print Services Quick Setup in the Tools menu.
 - **2.** Enter a desired name in **Print Server Name**. To use an existing print server, click the button at right and choose the name from the list.
 - **3.** Enter a desired printer name in Name.
 - **4.** To use the printer in queue server mode, choose **Other/Unknown** in **Type**. To use the printer in remote printer mode, choose **Parallel** in **Type**, click **Communications**, and set **Ports** to **LPT1** and **Connection Type** to **Manual Load**.
 - **5.** Enter a desired queue name in Name.
 - **6.** In **Volume**, enter the volume object (that is, the object representing the physical volume on the network) where the print queue will be created. Click the button at right to choose from a list.
 - 7. Complete other settings as needed and click **OK**.



Note

- The print server name will be required when configuring the printer's protocol settings. Write down the print server name for future reference.
- When running Quick Setup, the printer is assigned printer number 0. When using the printer in queue server mode, do not change the printer number from 0.
- **3.** Set a password.
 - 1. Right-click the print server created in step 2 and choose **Details**.
 - 2. Click Change Password to open the password input dialog box. Enter the password.
 - **3.** Click **OK** to close the password input dialog box.
 - **4.** Click **OK** or **Cancel** to close the details dialog box.
- **4.** To use the printer in remote printer mode, start the print server.

 To use the NetWare file server as the print server, enter **LOAD PSERVER.NLM** at the file server and press the Enter key.



Note

• This procedure is not required when using queue server mode.

Use PCONSOLE to set up the print server if bindery queue server mode or remote printer mode is used.

- 1. Log into NetWare as Admin and start PCONSOLE.
- **2.** Switch to bindery mode.
- **3.** If the print server has not been created, create it.
 - 1. In Available Options, select Quick Setup, and press the Enter key.
 - **2.** Enter the name of the new print server, the new printer, and the queue.



Note

- The print server name will be required when configuring the printer's protocol settings. Write down the print server name for future reference.
- **4.** Specify the printer type.
 - 1. To use the printer in queue server mode, choose Other/Unknown in Type. To use remote printer mode, set Printer Type to Parallel and Position to Manual Load.
 - **2.** Press the Esc key.
 - **3.** After the confirmation message is displayed, choose **Yes** and press the Enter key.
- **5.** Set a password.
 - 1. In Available Options, select Print Servers and press the Enter key.
 - 2. Select the print server created in step 2 and press the Enter key.
 - **3.** Select **Password**, and press the Enter key to display the password input dialog box.
 - **4.** Enter the password and press the Enter key.
- **6.** Press the Esc key several times to display the dialog box for confirming that PCONSOLE is finished.
- 7. Click **Yes** to exit PCONSOLE.

Configuring the Printer's NetWare Network Settings With RemoteUI

Follow the steps below to configure NetWare protocol settings other than the frame type by using RemoteUI.



Note

- For details on RemoteUI, see "Using RemoteUI." →P.962
- 1. Start the web browser and enter the following URL in the Location (or Address) box to display the RemoteUI page.

http://printer IP address or name/

Example: http://xxx.xxx.xxx/

- 2. Select Administrator Mode and click Logon.
- **3.** If a password has been set on the printer, enter the password.
- 4. Click **Network** in the **Device Manager** menu at left to display the **Network** page.
- 5. Click Edit in the upper-right corner of the NetWare group to display the Edit NetWare Protocol Settings page.

6. Refer to the NetWare Settings Items table to complete the settings.

NetWare Settings Items

| Item | | Details | Default Setting |
|-------------------|--------------------------|---|------------------------|
| Frame Type | | Specify the type of frame to use in NetWare. | Disabled |
| NCP Burst Mode | | Activate this setting to use NCP Burst Mode. This mode supports fast data transfer when printing in queue server mode. Normally, leave the setting On. | On |
| Print Application | | Choose the print service. The print service selected here is enabled. Multiple print services cannot be enabled simultaneously. | NDS PServer |
| | | Bindery PServer | |
| | | • RPrinter | |
| | | • NDS PServer | |
| | | • NPrinter | |
| Packet Signature | | Select If Requested by Server to use packet signature. | If Requested by Server |
| Bindery PServer | File Server Name | Specify the name of a file server that has a NetWare print server. (0–47 characters) | _ |
| | Print Server Name | Specify the name of a NetWare print server. (0–47 characters) | _ |
| | Print Server Password | Set a password for the print server. (0–20 characters) | _ |
| | Polling Interval | Specify the interval to confirm jobs. (1–15 seconds) | 5 |
| RPrinter | Print Server Name | Specify the name of a NetWare print server. (0–47 characters) | _ |
| | Printer Number | Specify the number of the printer connected to the NetWare print server. (0-15) | 0 |
| NDS PServer | Tree Name | Specify the name of an NDS tree that has a NetWare print server. (0–32 characters) | _ |
| | Context Name | Specify the name of a context that has a NetWare print server. (0–255 characters) | _ |
| | Print Server Name | Specify the name of a NetWare print server. (0–64 characters) | _ |
| | Print Server Password | Set a password for the print server. (0–20 characters) | |
| | Polling Interval | Specify the interval to confirm jobs. (1–255 seconds) | 5 |
| NPrinter | Print Server Name | Specify the name of a NetWare print server. (0–47 characters) | |
| | Printer Number | Specify the number of the printer connected to the NetWare print server. (0-254) | 0 |

- 7. Complete the following settings based on the selected service.
 - If you have selected Bindery PServer: Queue Server Mode (Using a Bindery Print Server)
 - **1.** In **File Server Name**, enter the file server name.
 - 2. In Print Server Name, enter the name of the print server created in "Specifying NetWare Print Services —P.979"."
 - **3.** In **Print Server Password**, enter the password of the print server created in "Specifying NetWare Print Services →P.979 ."
 - **4.** In **Polling Interval**, specify the interval at which the printer checks the NetWare print queue.
 - If you have selected RPrinter: Remote Printer Mode (Using a Bindery Print Server)
 - 1. In Print Server Name, enter the advertising name of the print server created in "Specifying NetWare Print Services P.979 ."
 - 2. In Printer Number, enter the same printer number specified in "Specifying NetWare Print Services →P.979 ."
 - If you have selected NDS PServer: Queue Server Mode (Using an NDS Print Server)
 - 1. In Tree Name and Context Name, enter the tree and context name of the print server.
 - 2. In Print Server Name, enter the name of the print server created in "Specifying NetWare Print Services —P.979"."
 - **3.** In **Print Server Password**, enter the password of the print server created in "Specifying NetWare Print Services →P.979 ."
 - **4.** In **Polling Interval**, specify the interval at which the printer checks the NetWare print queue.
 - If you have selected NPrinter: Remote Printer Mode (Using a NDS Print Server)
 - 1. In Print Server Name, enter the advertising name of the print server created in "Specifying NetWare Print Services —P.979 ." Usually, the advertising name is the same as the name of the print server.
 - 2. In Printer Number, enter the same printer number specified in "Specifying NetWare Print Services P.979"."
- **8.** Click **OK** to display the **Network** page.

Mac OS X Settings

| Configuring the Destination in TCP/IP Networks | 984 |
|--|-----|
| Configuring the Destination for Bonjour Network | |
| Configuring the Destination for AppleTalk Networks | 988 |
| Configuring the Printer's AppleTalk Network Settings | 989 |

Configuring the Destination in TCP/IP Networks

Follow these steps to configure the destination when using the printer in a TCP/IP network.




Important


• If you use the printer in a TCP/IP network, make sure the printer's IP address is configured correctly. (See "Configuring the IP Address Using the Printer Control Panel.") —P.966

Configuring the Destination (Mac OS X)


- 1. Navigate to Applications > Canon Utilities > imagePROGRAF PrinterSetup and double-click imagePROGRAF PrinterSetup.app.
- 2. Click Next.




3. Click Registering IP Address.




4. Select the model and type and then enter the IP address before clicking the **Next** button.



5. Complete Printer Name and Location as desired and click Register.



6. Click Finish.




Configuring the Destination for Bonjour Network

Follow the steps below to configure the destination if you are using the printer in a network that uses the Bonjour function.




Important

- Bonjour and IP Print (Auto) do not support printing to a printer on other network groups that require a router for connection. Make sure the computer and printer are on the same network. For information about network settings, ask your network administrator.
- By default, Bonjour is activated on the printer. You can activate or deactivate the Bonjour function or change the printer name by using RemoteUI. For instructions on changing it, see "Using RemoteUI." —P.962
- 1. Navigate to Applications > Canon Utilities > imagePROGRAF PrinterSetup and double-click imagePROGRAF PrinterSetup.app.
- 2. Click Next.




10


3. Select the printer to register and click Next.



4. Complete **Printer Name** and **Location** as desired and click **Register**.



5. Click Finish.



Configuring the Destination for AppleTalk Networks

To print over an AppleTalk network, activate the AppleTalk protocol and configure the destination as follows.

Activating AppleTalk on the printer



Important

- By default, the AppleTalk protocol is disabled on the printer.
- 1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (———————).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Interface Setup**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select AppleTalk, and then press the OK button.
- 5. Press ▲ or ▼ to select On, and then press the OK button.
- **6.** Press the **Menu** button. If you have changed any settings, a confirmation message is displayed. In this case, press the **OK** button.



988

10



Important

• Be sure to complete step 6. This will activate the values you have entered.



Note

• By using RemoteUI, you can also specify the object name used for AppleTalk, as well as the printer zone name.

For details on RemoteUI, see "Using RemoteUI ." →P.962

Configuring the Destination (Mac OS X)




Important

• AppleTalk is supported in Mac OS X 10.2.8–10.4.



Note

- The following procedures are based on Mac OS X 10.4. The method of configuring the destination varies depending on the version of Mac OS X.
- The imagePROGRAF printer driver is not compatible with AppleTalk.
- 1. In System Preferences, click Network to display the Network window.
- 2. In Show, choose Built-in Ethernet. Next, click AppleTalk, select Make AppleTalk Active, and click Apply now.



3. Close the **Network** window and save the settings.

Configuring the Printer's AppleTalk Network Settings

Follow the steps below to configure the AppleTalk network settings.

1. Start the web browser and enter the following URL in the Location (or Address) box to display the RemoteUI page.

http://printer IP address or name/ Example: http://xxx.xxx.xxx/

2. Select Administrator Mode and click Logon.

- **3.** If a password has been set on the printer, enter the password.
- 4. Click Network in the Device Manager menu at left to display the Network page.
- 5. Click Edit in the upper-right corner of the AppleTalk group to display the Edit AppleTalk Protocol Settings page.
- **6.** Refer to the AppleTalk Settings Items table to complete the settings.

AppleTalk Settings Items

| Item | Details | Default Setting |
|------------------|--|------------------------------|
| Phase Type | Specify whether to use AppleTalk. If you will use AppleTalk, choose Phase 2 . If you will not use AppleTalk, choose Disabled . | Disabled |
| Name (*1) | Specify the object name used by AppleTalk (in up to 31 single-byte or 15 double-byte characters). However, do not use the following single-byte characters: @, *, :, and =. | Canon NB-18GB (xxxxxx) |
| Zone (*2) | Specify the printer zone name, up to 31 single-byte characters. However, do not use the following single-byte characters: Also avoid using * (which represents the default zone) in the middle of a string. | * |

- *1: The object name you have specified in **Name** is displayed in **Printer Setup Utility** (or **Print Center**) in Mac OS X 10.2.8–10.4. If you use multiple printers in the same zone, assign a unique name to each printer. By default, the network interface name is **Canon NB-18GB** (xxxxxx). (Here, xxxxxx is the last six digits of the printer's MAC address.)
- *2: If zones have been created on the network, enter the name of the printer's zone. If there are no zones, leave the asterisk * entry (for the default zone) as it is. If you enter a network zone name that does not match created zones, the printer will not be detected by Macintosh computers. Consult your network administrator for information on zone names.
- 7. Click **OK** to display the **Network** page.

991

Other Settings

| Specifying Printer-Related Information | . 991 |
|--|-------|
| Configuring the Communication Mode Manually | |
| Email Notification When Printing is Finished or Errors Occur | |
| nitializing the Network Settings | |

Specifying Printer-Related Information

Follow the steps below to specify device information and security settings.

1. Start the web browser and enter the following URL in the Location (or Address) box to display the RemoteUI page.

http://printer IP address or name/ Example: http://xxx.xxx.xxx/

- 2. Select Administrator Mode and click Logon.
- **3.** If a password has been set on the printer, enter the password.
- **4.** Click **Information** in the **Device Manager** menu at left to display the **Information** page.
- 5. To display the relevant settings page, click Edit in the upper-right corner of Device Information or Security, depending on what information you want to specify.
 To change the administrator password, click the Change Password button in the Security group.
- **6.** Refer to the table of settings for device information and security as you complete these settings. Security setting items are displayed when you click the **Change Password** button in the **Security** group.

Device Information Settings

| Item | Details | Default Setting |
|------------------|---|-----------------|
| Device Name | Enter a device name. (0–32 characters) | blank |
| Location | Enter the location where the device is installed. (0–32 characters) | blank |
| Administrator | Enter the administrator's name. (0–32 characters) | blank |
| Phone | Enter the administrator's contact information. (0–32 characters) | blank |
| Comments(E-mail) | Enter any comments regarding the administrator. (0–32 characters) | blank |

Security Settings


| Coounty Cottingo | | |
|------------------|---|-----------------|
| Item | Details | Default Setting |
| New Password | Enter the new password. (0-9999999) | blank |
| Confirm | Enter the new password again to confirm it. (0-9999999) | blank |

- *1: On the **Security** settings screen, besides entering a password, you can specify other security-related information, such as IP address-based SNMP or TCP usage restrictions, MAC address-based access restrictions, or IPP and FTP authentication settings.
- 7. Click **OK** to activate the settings.

Configuring the Communication Mode Manually

This topic gives instructions for configuring the communication mode manually.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐).





10

992

Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Interface Setup**, and then press the **OK** button.
- **4.** Press **△** or **▼** to select **Ethernet Driver**, and then press the **OK** button.
- **5.** Press ▲ or ▼ to select **Auto Detect**, and then press the **OK** button.
- **6.** Press ▲ or ▼ to select **Off**, and then press the **OK** button. The display reverts to the **Ethernet Driver** menu.
- 7. Press ▲ or ▼ to select Comm.Mode, and then press the OK button.
- 8. Press ▲ or ▼ to select the communication mode, and then press the **OK** button. The display reverts to the **Ethernet Driver** menu.
- **9.** Press **△** or **▼** to select **Ethernet Type**, and then press the **OK** button.
- **10.** Press ▲ or ▼ to select the Ethernet type, and then press the **OK** button. The display reverts to the **Ethernet Driver** menu.
- 11. Press \triangle or ∇ to select **Spanning Tree**, and then press the **OK** button.
- **12.** Press ▲ or ▼ to enable or disable spanning tree support, and then press the **OK** button. The display reverts to the **Ethernet Driver** menu.

10

13. Press the Menu button.

After the confirmation message is displayed, press the **OK** button.

The new settings will take effect after the printer restarts.






Note

• Communication can also be configured on the Network page in RemoteUI.

Email Notification When Printing is Finished or Errors Occur

The printer can notify you of the printer status by email. Even when you are away from the printer, you can know when printing is finished or if errors occur. Receive notification via email on your mobile phone or at your computer.



Use the imagePROGRAF Status Monitor (Windows) function to set up email recipients and message timing. Besides being informed of finished print jobs or errors, you can also complete settings for email notification when service is needed or it's time to replace consumables. For detailed instructions,see "Specifying Printer-Related Information."
P.991



Note

- For details on email notification using imagePROGRAF Status Monitor (in Windows), refer to the image-PROGRAF Status Monitor help.
- Mail server authentication is only supported with imagePROGRAF Status Monitor.

Initializing the Network Settings

Use RemoteUI to restore the network settings to the default values as follows.



Important

- Initializing the network settings will also restore the default value of the printer's IP address. As a result, the RemoteUI page cannot be displayed in the web browser after this procedure.
- For instructions on reconfiguring the IP address, see "Configuring the IP Address on the Printer." —P.965
- For details on RemoteUI, see "Using RemoteUI ." →P.962
- 1. Start the web browser and enter the following URL in the Location (or Address) box to display the RemoteUI page.

http://printer IP address or name/ Example: http://xxx.xxx.xxx/

- 2. Select Administrator Mode and click Logon.
- **3.** If a password has been set on the printer, enter the password.
- **4.** Click **Network** in the **Device Manager** menu at left to display the **Network** page.
- 5. Click **Reset to Default settings** in the lower-right corner of the **Network Interface** group.
- **6.** After confirming the message, click **OK** to restore the network settings to the default values.




Note

• You can also use imagePROGRAF Device Setup Utility or the Control Panel to restore the default network settings.

10

Maintenance and Consumables

| Ink Tanks | 996 |
|-----------------------|------|
| Printheads | 1011 |
| Cutter Unit | 1024 |
| Maintenance Cartridge | 1028 |
| Cleaning the Printer | 1039 |
| Other Maintenance | 1044 |
| Consumables | 1053 |



Ink Tanks

| Ink Tanks | 996 |
|---------------------------|-----|
| Replacing Ink Tanks | 997 |
| Checking Ink Tank Levels | |
| When to Replace Ink Tanks | |

Ink Tanks

When purchasing ink tanks, make sure the following Ink Tank serial numbers are printed on the label.

- 330 ml (11.2 fl oz)
 - MBK Ink Tank PFI-304MBK
 - BK Ink Tank PFI-304BK
 - C Ink Tank PFI-304C
 - M Ink Tank PFI-304M
 - Y Ink Tank PFI-304Y
 - PC Ink Tank PFI-304PC
 - PM Ink Tank PFI-304PM
 - GY Ink Tank PFI-304GY



• 700 ml (23.7 fl oz)

- MBK Ink Tank PFI-704MBK
- BK Ink Tank PFI-704BK
- C Ink Tank PFI-704C
- M Ink Tank PFI-704M
- Y Ink Tank PFI-704Y
- PC Ink Tank PFI-704PC
- PM Ink Tank PFI-704PM
- GY Ink Tank PFI-704GY

996

11



Ink Tanks

Note

• For instructions on Ink Tank replacement, see "Replacing Ink Tanks." —P.997

Replacing Ink Tanks

Compatible ink tanks

Replacement ink tanks in 330 ml (11.2 fl oz) and 700 ml (23.7 fl oz) capacities are supported. For information on supported ink tanks, see "lnk Tanks." —P.996

Precautions when handling ink tanks

Take the following precautions when handling ink tanks.



Caution

- For safety, keep ink tanks out of the reach of children.
- If ink is accidentally ingested, contact a physician immediately.



Important

- There may be ink around the ink supply section of ink tanks you removed. Handle ink tanks carefully during replacement. The ink may stain clothing.
- Do not install used ink tanks in another model of printer.

 This will prevent correct ink level detection, which may damage the printer or cause other problems.
- We recommend using up an Ink Tank in the course of printing within six months after breaking the seal. Printing quality may be affected if you use older ink tanks.
- Do not leave the printer without ink tanks installed for extended periods (a month or more). Residual ink may become clogged inside the printer and affect printing quality.

How to replace an Ink Tank

- **1.** Confirm the message. →P.997
- 2. Access the menu for lnk Tank replacement. —P.998 (Otherwise, open the Ink Tank Cover.)
- **3.** Remove the Ink Tank.
 - 330 ml ink tanks →P.999
 - 700 ml ink tanks →P.1000
- **4.** Load the new Ink Tank.
 - 330 ml ink tanks →P.1002
 - 700 ml ink tanks →P.1005


Confirm the message

When the ink level becomes low, a message is displayed on the Display Screen.


11

997

iPF8300S



If a message requests you to replace an Ink Tank, press the **OK** button. In this case, you can skip the step **Access the menu for ink tank replacement.** Follow the instructions in **Remove the ink tanks.**





Important

• Do not remove an Ink Tank during initialization immediately after turning on the printer, or during printhead cleaning. Ink may leak out.




Note

• Ink Tank replacement is possible even during printing, when print jobs are being canceled, or when paper is being advanced.

Access the menu for Ink Tank replacement

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Ink tab (்).





Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

2. Press the **OK** button. The **Ink Menu** is displayed.

3. Press ▲ or ▼ to select Rep. Ink Tank, and then press the OK button.

A message on the Display Screen requests you to open the Ink Tank Cover. Remove the Ink Tank at this point.

998


11

Replacing Ink Tanks iPF8300S

999

Remove the Ink Tank (330 ml)


1. Open the Ink Tank Cover of the tank for replacement and check the Ink Lamp. The Ink Lamp flashes quickly if there is no ink left.





Important

- Avoid hitting the printer when replacing an Ink Tank. Handle the printer gently when replacing tanks. Jolting the printer during printing may deteriorate print quality.
- 2. Lift the stopper (a) of the Ink Tank Lock Lever for the color to replace. Lift the Ink Tank Lock Lever until it stops, and then push it down to the front.






Note

- Push the Ink Tank Lock Lever down until it locks.
- Make sure the Ink Tank Lock Lever does not return to the original position.

iPF8300S Replacing Ink Tanks


3. Hold the Ink Tank by the grips (a) and remove it. Press the **OK** button.





Important

• If there is still ink in the Ink Tank you removed, store it with the ink holes (a) facing up. Otherwise, ink may leak and cause stains. Put the removed Ink Tank in a plastic bag and seal it.






Note

• Dispose of used ink tanks according to local regulations.

Remove the Ink Tank (700 ml)

1. Open the Ink Tank Cover of the tank for replacement and check the Ink Lamp. The Ink Lamp flashes quickly if there is no ink left.



1000

11


Replacing Ink Tanks iPF8300S

11




Important

- Avoid hitting the printer when replacing an Ink Tank. Handle the printer gently when replacing tanks. Jolting the printer during printing may deteriorate print quality.
- 2. Lift the stopper (a) of the Ink Tank Lock Lever for the color to replace. Lift the Ink Tank Lock Lever until it stops, and then push it down to the front.





- Push the Ink Tank Lock Lever down until it locks.
- Make sure the Ink Tank Lock Lever does not return to the original position.
- ${\bf 3.}$ Hold the Ink Tank by the handle (a) and remove it. Press the ${\bf OK}$ button.




iPF8300S Replacing Ink Tanks



Important

• If there is still ink in the Ink Tank you removed, store it in the box with the ink holes (a) facing up. Otherwise, ink may leak and cause stains.






Note

• Dispose of used ink tanks according to local regulations.

Load the Ink Tank (330 ml)

1. Before opening the pouch, tilt the Ink Tank to the left and right gently seven or eight times.





Important


- Do not remove and agitate ink tanks that have already been installed in the printer. Ink may leak out.
- If you do not agitate the Ink Tank, the ink may settle, which may affect printing quality.

1002

11


Replacing Ink Tanks iPF8300S

2. Open the pouch and remove the Ink Tank.



Important

- Never touch the ink holes or electrical contacts. This may cause stains, damage the Ink Tank, and affect printing quality.
- 3. Press the ok button and insert the Ink Tank into the holder facing as shown, with the ink holes down.





Important


• Ink tanks cannot be loaded in the holder if the color or orientation is incorrect.

If the Ink Tank does not fit in the holder, do not force it into the holder. Make sure the color of the Ink Tank Lock Lever matches the color of the Ink Tank, and check the orientation of the Ink Tank before reloading it.


1003

iPF8300S Replacing Ink Tanks

4. Lift the Ink Tank Lock Lever until it stops, and then push it down until it clicks into place.



5. Make sure the Ink Lamp is lit in red.





Note

• If the Ink Lamp is not lit in red, reload the tank.


1004

11

Replacing Ink Tanks iPF8300S

11

6. Close the Ink Tank Cover.






Important

 After Ink Tank replacement, always close the Ink Tank Cover. If the Ink Tank Cover cannot close, some Ink Tank Lock Lever may not be closed completely. Make sure all ink tank lock levers are fully closed.

Load the Ink Tank (700 ml)

1. Before opening the pouch, hold the new Ink Tank with both hands and tilt it to the left and right as shown, shaking gently it seven or eight times.





Caution

• 700 ml ink tanks are heavy, so use your whole arm to agitate it instead of just your wrist. If you agitate it using just your wrist, you may injure your wrist.




Important

- Do not remove and agitate ink tanks that have already been installed in the printer. Ink may leak out.
- If you do not agitate the Ink Tank, the ink may settle, which may affect printing quality.

iPF8300S Replacing Ink Tanks


2. Open the pouch and remove the Ink Tank.





Important

- Never touch the ink holes or electrical contacts. This may cause stains, damage the Ink Tank, and affect printing quality.
- 3. Press the ok button and insert the Ink Tank into the holder facing as shown, with the ink holes down.





Important

• Ink tanks cannot be loaded in the holder if the color or orientation is incorrect.


If the Ink Tank does not fit in the holder, do not force it into the holder. Make sure the color of the Ink Tank Lock Lever matches the color of the Ink Tank, and check the orientation of the Ink Tank before reloading it.

11


1006

Replacing Ink Tanks iPF8300S

4. Lift the Ink Tank Lock Lever until it stops, and then push it down until it clicks into place.



5. Make sure the Ink Lamp is lit in red.






Note

• If the Ink Lamp is not lit in red, reload the tank.

1007

iPF8300S Replacing Ink Tanks


6. Close the Ink Tank Cover.





Important

- After Ink Tank replacement, always close the Ink Tank Cover. If the Ink Tank Cover cannot close, some Ink Tank Lock Lever may not be closed completely. Make sure all ink tank lock levers are fully
- To close the Ink Tank Cover when no Ink Tank is installed (as when moving the printer), push the release lever (a) as shown while returning the Ink Tank Lock Lever to the original position.



11

Checking Ink Tank Levels

On the Display Screen, you can check how much ink is left in the ink tanks.

To check remaining Ink Tank levels, access the **Tab Selection screen** on the Control Panel and press ◀ or ▶ to select the

Ink tab (). 1008





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- If an error has occurred and the **Tab Selection screen** cannot be displayed, display **Ink Info** as follows.
- 1. Press the **OK** button to display **Printer Info**.
- 2. Press the ▲ or ▼ button to select Ink Info.
- 3. Press the **OK** button.

The remaining ink levels shown on the Display Screen correspond to the inks identified by the Color Label on the bottom of the Display Screen.

These symbols may be displayed above the ink level: ! if ink is low, × if no ink is left, and ? if you have deactivated ink level detection.

The remaining ink level is indicated as shown below.




If the Display Screen indicates to replace the Ink Tank, replace the Ink Tank. If a message is displayed indicating to check the remaining ink levels, or after tasks that consume a lot of ink such as large-format printing or head cleaning, check the remaining levels and replace Ink Tank as needed. (See "Replacing Ink Tanks.") —P.997

When to Replace Ink Tanks

Replace or prepare to replace ink tanks in the following situations.


If a message for checking the ink is shown on the Display Screen

When there is little ink left, the **Message Lamp** is lit and "**Not much ink is left.**" is shown on the Display Screen. You can continue to print, but prepare to replace the Ink Tank. (See "Checking Ink Tank Levels.") \rightarrow P.1008




Before print jobs and maintenance that consume a lot of ink

If little ink is left, there may not be enough for large-format printing, head cleaning, and maintenance, which require a lot of ink. In this case, replace or prepare to replace the Ink Tank before maintenance.



If a message for ink replacement is shown on the Display Screen

When ink runs out, the **Message Lamp** flashes, a message regarding Ink Tank replacement is shown on the Display Screen, and printing is disabled. Replace the Ink Tank at this point.



11


1011

Printheads

| Printhead | 1011 |
|------------------------------|------|
| Checking for Nozzle Clogging | 1011 |
| Cleaning the Printhead | |
| Replacing the Printhead | |

Printhead

• Printhead PF-05





Note

• For instructions on replacing the Printhead, see "Replacing the Printhead." —P.1013

Checking for Nozzle Clogging

If printing is faint or affected by banding in different colors, make sure the Printhead nozzles are clear by printing a test pattern to check the nozzles.



Note

• Nozzles are periodically checked to ensure they are clear. Configure the settings on the Control Panel menu in Nozzle Check. (See "Menu Settings.") →P.938

Paper to Prepare


| When Using Rolls | An unused roll at least 10 inches wide |
|-------------------|--|
| When Using Sheets | One sheet of unused paper of at least A4/Letter size |

1. Load paper.

- Attaching the Roll Holder to Rolls →P.782
- Loading Rolls in the Printer →P.786
- Loading Sheets in the Printer →P.813

iPF8300S Printhead


2. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐).






Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 3. Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- **4.** Press ▲ or ▼ to select **Test Print**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Nozzle Check, and then press the OK button. The printer now prints a test pattern for checking the nozzles.
- **6.** Check the printing results. If the horizontal lines are not faint or incomplete, the nozzles are clear.



If some sections of the horizontal lines are faint or incomplete, the nozzles for those colors are clogged.



If horizontal lines are faint or incomplete, follow the steps below and check again for nozzle clogging.

- 1. Clean the Printhead. (See "Cleaning the Printhead.") \rightarrow P.1012
- **2.** Print a test pattern to check the nozzles.



Important

• If you repeat these steps several times but the horizontal lines are still faint or incomplete, contact your Canon dealer.

Cleaning the Printhead

If printing is faint, cleaning the Printhead may improve results.

Choose one of two Printhead cleaning modes (Head Cleaning A or Head Cleaning B), depending on the problem to resolve.

· Head Cleaning A

1012

11

Cleaning the Printhead

Use this mode if printing is faint or contains foreign substances. This method of cleaning consumes the least amount of ink

It takes about four minutes to complete.

• Head Cleaning B

Use this mode if no ink is ejected at all, or if **Head Cleaning A** does not solve the problem. It takes about five minutes to complete.



Important

- Do not remove the Maintenance Cartridge or ink tanks during either **Head Cleaning A** or **Head Cleaning B**. Ink may leak or an error may occur.
- If printing does not improve even if you execute **Head Cleaning B**, try repeating **Head Cleaning B** once or twice. If this still does not improve printing, the Printhead may have reached the end of its useful life. Contact your Canon dealer for assistance.




Note

• Nozzles are periodically checked to ensure they are clear. Configure the settings on the Control Panel menu in Nozzle Check. (See "Menu Settings.") —P.938

Perform cleaning as follows.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐☐☐).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press \triangle or ∇ to select **Maintenance**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select **Head Cleaning**, and then press the **OK** button.
- 5. Press ▲ or ▼ to select **Head Cleaning A** or **Head Cleaning B**, and then press the **OK** button. Head cleaning is now executed.
- **6.** Print a test pattern to check the nozzles, and determine whether cleaning has cleared the nozzles. (See "Checking for Nozzle Clogging.") —P.1011

Replacing the Printhead

When to replace the Printhead

This printer is equipped with two printheads.

iPF8300S Replacing the Printhead

Replace one or both printheads in the following situations.

• If the printing quality does not improve even after one or two cycles of **Head Cleaning B** from the printer menu

Replace any printheads with poor printing performance.

- If the Display Screen indicates "Open top cover and replace the left printhead."

 Replace the Printhead on the left side.
- If the Display Screen indicates "Open top cover and replace the right printhead." Replace the Printhead on the right side.
- If the Display Screen indicates "Open top cover and replace the printhead."
 Replace both printheads.
- If your Canon dealer has advised Printhead replacement Replace the Printhead as directed.

Compatible printheads

For information on compatible printheads, see "Printhead." →P.1011

Precautions when handling the Printhead

Take the following precautions when handling the Printhead.



Caution

- For safety, keep the Printhead out of the reach of children.
- If ink is accidentally ingested, contact a physician immediately.
- Do not touch the Printhead immediately after printing. The Printhead becomes extremely hot, and there is a risk of burns.



Important

- There may be ink around the nozzles of the Printhead you remove. Handle the Printhead carefully during replacement. The ink may stain clothing.
- Do not open the Printhead pouch until immediately before installation. After removing the Printhead from the pouch, install it right away. If the Printhead is left after the pouch is opened, the nozzles may dry out, which may affect printing quality.

Access the menu for Printhead replacement



Caution

• When replacing the Printhead immediately after printing, wait a few minutes before replacing it. The metal parts of the Printhead become hot during printing, and there is a risk of burns from touching these parts.



Important

• Your hands may become dirty during Printhead replacement. Use the gloves provided with the new Printhead for replacement.



Note

- Prepare a new Ink Tank when ink levels are low.
- When the remaining capacity of Maintenance cartridge is low, prepare a new Maintenance cartridge.
- 1. Remove any paper that has been advanced by selecting **Eject Paper** in the Control Panel menu.
 - When using a roll, rewind it.

11

1014

Replacing the Printhead


1015

(See "Removing the Roll from the Printer.") →P.794

• When using sheets, remove the sheet.

(See "Removing Sheets.") →P.820

- 2. Clean inside the Top Cover. (See "Cleaning Inside the Top Cover.") -P.1040
- 3. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐).





Note


- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- **4.** Press the **OK** button. The **Set./Adj. Menu** is displayed.
- 5. Press ▲ or ▼ to select Maintenance, and then press the OK button.
- **6.** Press ▲ or ▼ to select **Replace P.head**, and then press the **OK** button.
- 7. Press ▲ or ▼ to select the Printhead for replacement.
 Select Printhead L when replacing the left printhead, Printhead R when replacing the right printhead, and L & R Printheads when replacing both. Make sure your selection is correct.
- **8.** Press the **OK** button.

Ink is now filled.

After about three minutes, a message is shown on the Display Screen instructing you to open the Top Cover.

Replace the Printhead


1. Open the Top Cover.



iPF8300S Replacing the Printhead

Instructions are now shown on the Display Screen regarding head replacement.

2. If the Carriage Cover is dirty, use a damp cloth that you have wrung out completely to wipe it clean.




11

1016


Replacing the Printhead iPF8300S

Important

• Do not touch the Linear Scale (a), Carriage Shaft (b), or Fixed Blade (c). This may stain your hands and damage the printer.




- Never touch the metal contacts of the Carriage. This may damage the printer.
- **3.** If the ventilation duct (a) is dirty, use a damp cloth that you have wrung out completely to wipe it clean. If the Carriage is obscuring the ventilation duct, move the Carriage manually before cleaning the duct.




11

4. Pull up the Carriage Cover to open it completely.



5. Pull the Printhead Fixer Lever forward all the way to open it completely.




1018

11


Replacing the Printhead iPF8300S

11

6. Pull up the Printhead Fixer Cover to open it completely.



 $7_{\:\raisebox{1pt}{\text{\circle*{1.5}}}}$ Remove the Printhead and press the o_K button.






Note

• Dispose of the used Printhead in accordance with local regulations.


iPF8300S Replacing the Printhead

8. Holding the new Printhead by the grips (a), remove it from the pouch.




Important

- When handling the Printhead, always hold it by the grips (a). Never touch the nozzles (b) or metal contacts (c). This may damage the Printhead and affect printing quality.
- Never touch the ink supply section (d). This may cause printing problems.



- If you need to put a Printhead somewhere temporarily before installation, do not keep the nozzles and metal contacts facing down. If the nozzles or metal contacts are damaged, it may affect the printing quality.
- **9.** While firmly holding the Printhead you have removed, use your other hand to remove the orange Protective Part (a). Squeeze the grips (c) of Protective Part (b) and pull it down to remove it.



1020

11




Important

- The inside surface of the Protective Part (a) and Protective Part (b) is coated with ink to protect the nozzles. Be careful not to touch these surfaces when removing the caps.
- The Printhead contains ink to protect the nozzles. We recommend removing Protective Part (b) as you hold it over the Printhead package or safely out of the way to avoid spilling ink and staining your clothes or the surrounding area. If ink accidentally spills, wipe off the ink with a dry cloth.
- Do not reattach the Protective Part or protective material. Dispose of these materials in accordance with local regulations.


Replacing the Printhead

11

10. With the nozzles facing down and the metal contacts toward the back, tilt the Printhead slightly forward and insert it into the Carriage. Carefully push the printhead firmly into the Carriage, ensuring that the nozzles and metal contacts do not touch the carriage.




11. Pull the Printhead Fixer Cover down toward the front to lock the Printhead in place.




iPF8300S Replacing the Printhead

12. Push the Printhead Fixer Lever toward the back of the printer until it clicks.



13. Push the Carriage Cover down toward the front.




1022

11

Replacing the Printhead iPF8300S

14. Close the Top Cover.



Ink now fills the system. It takes about 13 minutes for ink to fill the system.



Important

• While ink is being filled, definitely do not remove the Ink Tank or Maintenance Cartridge. Ink may leak out.



Note

- The procedure is now finished if you have set **Rep.P.head Print** to **Off** in the Control Panel menu. If so, execute **Head Posi. Adj.** > **Auto(Advanced)** in the Control Panel menu. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") P.850
- 15. Follow the instructions on the Display Screen and supply paper that you will use for printing. After the paper is advanced, **Head Posi. Adj.** will be executed automatically.

(See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") P.850



Note

• When printing fine lines or text at high precision on glossy or semi-glossy photo or proofing paper, set the optimal Printhead height before aligning the printhead.

(See "Enhancing Printing Quality.") —P.848


Cutter Unit

| Cutter Unit | 1024 |
|---------------------------|------|
| Replacing the Cutter Unit | 1024 |

Cutter Unit

The printer can use the following Cutter Unit.

• Cutter Unit CT-06





Note

• For instructions on Cutter Unit replacement, see "Replacing the Cutter Unit." —P.1024

Replacing the Cutter Unit

For information on compatible cutter units, see "Cutter Unit." -P.1024

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (———————).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- 3. Press ▲ or ▼ to select Maintenance, and then press the OK button.
- **4.** Press ▲ or ▼ to select **Change Cutter**, and then press the **OK** button.

 The Carriage moves to the center, and a message on the Display Screen requests you to open the Top Cover.



Note


• If you do not respond within two minutes, cutter cleaner replacement is canceled. In this case, repeat the procedure.

11

1024

Cutter Unit iPF8300S

5. Open the Top Cover.




 $\mathbf{6}_{ullet}$ If the Cutter Unit or Carriage Cover is dirty, use a damp cloth that you have wrung out completely to wipe it clean.




Important

• Do not touch the Linear Scale (a), Carriage Shaft (b), or Fixed Blade (c). This may stain your hands and damage the printer.




11

7. Push the Cutter Unit Detachment Lever to the left to unlock it.



8. Holding the Cutter Unit by the Lock Lever (a) and grip (b), remove it from the Carriage.





Caution

- Never touch any part of the Cutter Unit except the Lock Lever (a) and grip (b). This may stain your hands or cause injury. Additionally, this may damage the printer.
- Do not disassemble the Cutter Unit. Touching the blade may cause injury.



Note

- Dispose of the used Cutter Unit in accordance with local regulations.
- 9. Holding the new Cutter Unit by the Lock Lever (a) and grip (b), insert it on the Carriage until it clicks into place (c).




Important


• After installing the Cutter Unit, hold it only by the grip (b) and pull the Cutter Unit forward to make sure it does not come off. It may damage the printer if the Cutter Unit comes off.

1026






10. Lift the Cutter Unit Detachment Lever to lock it.



11. Close the Top Cover.



12. A confirmation message is displayed about the Cutter Unit lock. Press ▲ or ▼ to select "Yes", and then press the OK button.

13. The Carriage is moved, and a confirmation message is displayed about resetting the cut count. To reset the cut counter, press ▲ or ▼ to select Yes, and then press the OK button.


Maintenance Cartridge

| Maintenance Cartridge | 1028 |
|---|------|
| Replacing the Maintenance Cartridge | |
| Checking the Remaining Maintenance Cartridge Capacity | |
| When to Replace the Maintenance Cartridge | |

Maintenance Cartridge

A replacement Maintenance Cartridge. Maintenance Cartridge is provided with a Shaft Cleaner.

• Maintenance Cartridge MC-08







Note

For instructions on replacing the Maintenance Cartridge, see "Replacing the Maintenance Cartridge."

—P.1028

Replacing the Maintenance Cartridge

Compatible maintenance cartridges

For information on compatible maintenance cartridges, see "Maintenance Cartridge." →P.1028

Precautions when handling the Maintenance Cartridge

Take the following precautions when handling the Maintenance Cartridge.



Caution

- For safety, keep the Maintenance Cartridge out of the reach of children.
- If ink is accidentally ingested, contact a physician immediately.



1028


Important

- Do not remove the Maintenance Cartridge except to replace it. Ink may leak out.
- To prevent ink from leaking from a used Maintenance Cartridge, avoid dropping the cartridge or storing it at an angle. Otherwise, ink may leak and cause stains.
- Ink adheres to the top of the Maintenance Cartridge after it has been used. Handle the Maintenance Cartridge carefully during replacement. The ink may stain clothing.

Maintenance Cartridge iPF8300S

Confirm the message

When the Maintenance Cartridge is almost empty, a message is shown on the Display Screen. According to the message, replace the Maintenance Cartridge or prepare a new Maintenance Cartridge. (See "When to Replace the Maintenance Cartridge.") —P.1037



If a message is displayed requesting Maintenance Cartridge replacement, you can skip the step Access the menu for Maintenance Cartridge replacement. Follow the instructions in Replace the Maintenance Cartridge.






Important

• Do not replace the Maintenance Cartridge during initialization immediately after turning on the printer, during Printhead cleaning, or when ink is being absorbed. Ink may leak out.

Access the menu for Maintenance Cartridge replacement

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐).





lote

• If the **Tab Selection screen** is not displayed, press the **Menu** button.


2. Press the **OK** button. The **Set./Adj. Menu** is displayed.

3. Press ▲ or ▼ to select Maintenance, and then press the OK button.


4. Press ▲ or ▼ to select **Repl. maint cart**, and then press the **OK** button. A message on the Display Screen advises you to open the Maintenance Cartridge Cover.

Replace the Maintenance Cartridge

1. At this point, open the Maintenance Cartridge Cover.



2. Hold the used Maintenance Cartridge by the grip (a) with one hand and put your other hand under the Maintenance Cartridge to hold it firmly on the bottom, keeping it level as you pull it out.





Important

- Used maintenance cartridges are heavy. Always grasp the cartridge firmly and keep the cartridge level during removal and storage. If you drop a used Maintenance Cartridge or store it at an angle, ink may leak and cause stains.
- The remaining Maintenance Cartridge capacity is recorded on each printer. Do not install a used Maintenance Cartridge in another printer.


11

3. Open the box, remove the plastic bag, packaging material, and Shaft Cleaner, and then take out the Maintenance Cartridge.






• Never touch the metal contacts (a). This may damage the Maintenance Cartridge.




4. Attach the packaging material to the used Maintenance Cartridge and put it in the box. Keep it level as you put it in the plastic bag. Expel excess air from the plastic bag and seal the zipper.



11

5. Confirm the Maintenance Cartridge is right-side up, put it in the box, and store it so that it stays level.





Important


• Always put the used Maintenance Cartridge back in the box and store the box on a flat surface. Otherwise, ink may leak and cause stains.



Note

• In accordance with active and ongoing environmental programs, Canon supports recycling of used maintenance cartridges. Follow the instructions provided with the new Maintenance Cartridge that describe how to process the used Maintenance Cartridge.

 $\mathbf{6}$. Wipe away any soiling on the Maintenance Cartridge Cover.



11


1032




Important

• Support the Maintenance Cartridge Cover from underneath as you wipe it.

7. Keeping the new Maintenance Cartridge level, insert it all the way in.



8. Close the Maintenance Cartridge Cover.



9. Press the OK button.




The printer now initializes the Maintenance Cartridge. Next, replace the Shaft Cleaner.

Replacing the Shaft Cleaner

Replace the Shaft Cleaner when you replace the Maintenance Cartridge. New Shaft Cleaner is included with replacement Maintenance Cartridge.


After you execute **Repl. maint cart** and replace the Maintenance Cartridge, a message will appear on the Display Screen requesting you to replace the Shaft Cleaner. Select **Yes** and press the **OK** button. When a message requests you to open the Top Cover, go to step 5.

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (————————).





- Note
- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Maintenance**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select **Repl. S. Cleaner**, and then press the **OK** button. After the Carriage is moved, the Display Screen indicates "**Open Upper Cover**".
- **5.** Open the Top Cover.






Note

• If you do not respond within two minutes, shaft cleaner replacement is canceled. In this case, repeat the procedure.


11

 $\mathbf{6}_{ullet}$ Hold the Shaft Cleaner on the right side of the Carriage by the grips (a) and pull it to the right to remove it.




Important

• Do not touch the Linear Scale (a), Carriage Shaft (b), or Fixed Blade (c). This may stain your hands and damage the printer.



7. Holding the new Shaft Cleaner by the grips (a), attach it to the Carriage.






Note

• Be sure to put the used Shaft Cleaner in the small box before putting it in the larger box with the used Maintenance Cartridge for disposal.

8. Close the Top Cover.



1036

11


The Carriage moves back into position.

Checking the Remaining Maintenance Cartridge Capacity

The Maintenance Cartridge absorbs excess ink from borderless printing, printhead cleaning, and other processes. You can confirm the remaining capacity of the Maintenance Cartridge by checking the Maintenance Cartridge capacity shown on the Display Screen.

To check remaining Maintenance Cartridge capacity, access the **Tab Selection screen** on the Control Panel and press ◀ or

▶ to select the Settings/Adj. tab ().





Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

If the Display Screen indicates to replace the Maintenance Cartridge, replace the Maintenance Cartridge. If a message is displayed indicating to check the remaining capacity of the Maintenance Cartridge, or before tasks that deplete much of the capacity such as head cleaning or preparations to move the printer, check the remaining Maintenance Cartridge capacity and prepare a new Maintenance Cartridge as needed. (See "Replacing the Maintenance Cartridge.") P.1028


When to Replace the Maintenance Cartridge

Replace or prepare to replace the Maintenance Cartridge in the following situations.

If a message for checking the Maintenance Cartridge is shown on the Display Screen

When the Maintenance Cartridge is almost full, the **Message Lamp** is lit and "**The level is low**" is shown on the Display Screen. You can continue to print, but check the remaining Maintenance Cartridge capacity and prepare to replace the Maintenance Cartridge with a new one. (See "Checking the Remaining Maintenance Cartridge Capacity.")


P.1037



When much of the Maintenance Cartridge capacity is depleted

Printhead cleaning, Printhead replacement, and preparations to transfer the printer deplete much of the Maintenance Cartridge capacity. (In particular, preparing to move the printer depletes a lot of the capacity.)

Check the remaining Maintenance Cartridge capacity before this maintenance and replace the Maintenance Cartridge if necessary.



If a message for the Maintenance Cartridge replacement is shown on the Display Screen

When the Maintenance Cartridge is almost empty, the **Message Lamp** lights, a message to replace the Maintenance Cartridge is displayed on the Display Screen, and you cannot print. Replace the Maintenance Cartridge with a new one.

Maintenance cartridge full.

Replace the maintenance cartridge.

11

Cleaning the Printer

| Cleaning the Printer Exterior | 1039 |
|-------------------------------|------|
| Cleaning Inside the Top Cover | 1040 |

Cleaning the Printer Exterior


Clean the printer regularly to maintain better printing quality and help prevent problems. About once a month, clean the printer exterior.

- 1. Turn the printer off. (See "Turning the Printer On and Off.") P.3
- 2. Unplug the power cord from the outlet.



Caution

- Always turn off the printer and unplug the power cord before cleaning or maintenance. Accidentally leaving the printer on poses a risk of injury if you touch moving parts inside the printer.
- 3. Using a damp cloth that you have wrung out completely, wipe away any dirt or paper dust from the Paper Feed Slot (a), power cord plug, and so on. Dry these parts with a dry cloth.





Warning

• Never use flammable solvents such as alcohol, benzene, or thinner. If these substances come into contact with electrical components inside the printer, there is a risk of fire or electrical shock.



Important

- If the Ejection Guide is dirty, it may soil the edge of the paper when the paper is cut. We recommend cleaning the Ejection Guide even if it does not appear dirty, because it may actually be covered with paper dust.
- **4.** Plug the power cord into the outlet.

Cleaning Inside the Top Cover


Clean inside the Top Cover to maintain better printing quality and help prevent problems. Also clean inside the Top Cover in the following situations to ensure optimal operation.

- If the printed surface or the underside of paper is dirty after printing
- After you have used up a roll
- · After borderless printing
- · After printing on small paper
- After printing on paper that generates a lot of cutting debris
- If you have replaced the roll
- After printing on paper that generates a lot of paper dust
- If the message "Blue platen switch is dirty." is displayed




Important

- If the Platen inside the Top Cover becomes dirty, it may soil the underside of paper. We recommend cleaning the Platen after borderless printing or printing on small paper.
- If the Ejection Guide is dirty, it may soil the edge of the paper when the paper is cut. We recommend cleaning the Ejection Guide even if it does not appear dirty, because it may actually be covered with paper dust.
- **1.** Open the Top Cover.



11

2. If paper dust has accumulated in the Vacuum holes (a) on the Platen, in the Borderless Printing Ink Grooves (b), or on the cutter guide (c), use the Cleaning Brush (d, provided with the printer) to wipe it away.






Note

• If the Cleaning Brush is dirty, rinse it in water.

3. Using a damp cloth that you have wrung out completely, wipe inside the Top Cover to clean it. Wipe away any ink residue and paper dust (debris from cutting) on the Top Cover Roller (a), all over the Platen (b), on the Paper Retainer (c), the Borderless Printing Ink Grooves (d), the Ejection Guide (e), the cutter guide (f), around the ink suction holes at left (g), around the Borderless Printing Ink Grooves at right (h), on the blue Switch (i), and so on.






Warning

• Never use flammable solvents such as alcohol, benzene, or thinner. If these substances come into contact with electrical components inside the printer, there is a risk of fire or electrical shock.


Important

• Do not touch the Linear Scale (a), Carriage Shaft (b), or Fixed Blade (c). This may stain your hands and damage the printer.



- Do not use a dry cloth to wipe inside the Top Cover. This may create a static charge, which may attract dust and affect the printing quality.
- Do not touch the clear sheet on the side of the Top Cover Roller. This may damage the roller.

4. Close the Top Cover.



11

Other Maintenance

| Preparing to Transfer the Printer | 1044 |
|-----------------------------------|------|
| Updating the Firmware | 1052 |

Preparing to Transfer the Printer

To protect the internal parts in transit, always follow these steps before transferring the printer to a new location. Refer to the Setup Guide for details on packing the printer and installing it after transfer.



Important

- Be sure to contact your Canon dealer before transferring the printer to a new location. Ink may leak and damage the printer if you do not prepare the printer correctly and it is tipped or stood on end in transit.
- It is not possible to prepare the printer for transfer if the Display Screen requests you to replace the Maintenance Cartridge or check the remaining capacity. Replace the Maintenance Cartridge before transfer preparations. (See "Replacing the Maintenance Cartridge.") —P.1028



Note

- Depending on the state of the printer, part replacement may be necessary when preparing to transfer the printer (that is, when you execute the printer menu item to prepare for transfer).
- Ink must be drained before Level 2 or Level 3 printer transfer, as described in the following table. Prepare a Maintenance Cartridge in advance.
- Always follow the instructions of the service representative when transferring the printer under Level 3 conditions.

| Level | Shipping Meth- od (Example) | Permitted Angle of Inclination | Amount of Ink to Dispose of | Required Mainte- nance Car- tridges(*1) |
|-------|--------------------------------|--------------------------------|-------------------------------|--|
| 1 | By truck | Lengthwise: 0–30° | 0 | 0 or 1 |
| | | Rotation: 0–10° | | |
| 2 | By plane | All directions: 0–30° | Approx. 1.2 L (40.6 fl oz) | 1 or 2 |

11

| _ | 1 |
|---|---|
| | |

| Level | Shipping Meth- od (Example) | Permitted Angle of Inclination | Amount of Ink to Dispose of | Required Mainte- nance Car- tridges(*1) |
|-------|---|--------------------------------------|-------------------------------|--|
| 3 | Tipping the printer or holding it upright for elevators or stairs | Lengthwise: 0–90° Rotation: 0–30° | Approx. 1.2 L (40.6 fl oz) | 1 or 2 |


^{*1:} The quantity of cartridges required depends on the capacity of the Maintenance Cartridge in use.

Remove paper

- **1.** Remove the paper.
 - Rolls (See "Removing the Roll from the Printer.") →P.794
 - Sheets (See "Removing Sheets.") →P.820

Access the Prep.MovePrinter menu

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (——————).





Note

• If the **Tab Selection screen** is not displayed, press the **Menu** button.

- 2. Press the **OK** button. The **Set./Adj. Menu** is displayed.
- **3.** Press ▲ or ▼ to select **Prep.MovePrinter**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select the level of transfer, and then press the **OK** button.
- 5. Press ▲ or ▼ to select Execute, and then press the OK button to display the confirmation screen.
- **6.** Press ▲ or ▼ to select **Yes**, and then press the **OK** button. The printer is now prepared for transfer.
 - Level 1

Once preparations are finished, a message on the Display Screen requests you to turn off the printer. Turn off and pack the printer. There is no need to remove the ink tanks.

(See "Pack the printer.") —P.1049

• Level 2 and Level 3

Once preparations are finished, a message on the Display Screen requests you to open the Ink Tank Cover. Remove the ink tanks before packing the printer.

.

(See "Removing Ink Tanks.") →P.1046




Important


• If consumables must be replaced, the message "Consumables must be replaced. Call for service." is shown on the Display Screen and preparation is not possible. If this message is displayed, press the OK button and contact your Canon dealer for assistance.

Removing Ink Tanks

1. Open the left and right ink tank covers.




2. Lift the stopper (a) of the Ink Tank Lock Lever (a). Lift the Ink Tank Lock Lever until it stops, and then push it down to the front.




11

3. Hold the Ink Tank by the handle (a) and remove it.




Important


• Store the Ink Tank you removed in the box with the ink holes (a) facing up. Otherwise, ink may leak and cause stains.



4. Repeat steps 2 and 3 to remove all ink tanks.



6. Close the Ink Tank Cover.



At this point, ink is drawn out from inside the tubes.



Important

• Do not remove the Maintenance Cartridge during this process. Ink may leak out.

When the process is finished, "Preparations for moving the printer finished. Turn the power off" is displayed.

1048

Pack the printer


1. Press the **Power** button and turn off the printer.






Important


- Turn off the printer before you unplug it. It may damage the printer if you unplug it before it is off and transfer it in that state. If you accidentally unplug the printer, plug it in again, reinstall the ink tanks, and follow this procedure again.
- 2. Disconnect the power cord, interface cable, and Media Take-up Unit Power Inlet.
- **3.** Open the Top Cover and lift the Ejection Guide.



4. Remove the four ejection supports and lower the Ejection Guide.




5. Grasp the Belt, insert it between the Belt Stopper, and affix the Belt Stopper with a hex screw at the position indicated






Important

- Here, the Belt Stopper is the one that was removed and stored after initial installation. Neglecting to attach the Belt Stopper may damage the printer.
- Do not touch the Linear Scale (a), Carriage Shaft (b), or Fixed Blade (c). This may stain your hands and damage the printer.



6. Close the Top Cover.



- 7. Tape down printer covers to secure them, in the reverse order of tape removal during installation.
- **8.** If the Output Stacker is installed, reverse the installation procedure to remove the Output Stacker.
- 9. Remove the Stand by reversing the installation procedure, when it was attached to the printer.

11


- 10. Disassemble and repackage the Stand by following the installation procedure in reverse.
- 11. Repack the Roll Holder, Holder Stopper, and printer in shipping materials, and then package them in a shipping box.

Updating the Firmware

Update the printer firmware to take advantage of new and improved printer functions.

Confirming the firmware version

1. On the **Tab Selection screen** of the Control Panel, press ◀ or ▶ to select the Settings/Adj. tab (☐☐☐).





Note

- If the **Tab Selection screen** is not displayed, press the **Menu** button.
- 2. Press the **OK** button.
 The **Set./Adj. Menu** is displayed.
- **3.** Press **△** or **▼** to select **Printer Info**, and then press the **OK** button.
- **4.** Press ▲ or ▼ to select **System Info**, and then press the **OK** button. The firmware version is displayed.

Updating the Firmware

To obtain the latest firmware, visit the Canon website. If the firmware available online is newer than the installed firmware, update the printer firmware. For details on downloading and updating the firmware, visit the Canon website.

1052

11


Consumables

| Ink Tanks | 996 |
|-----------------------|------|
| Printhead | 1011 |
| Cutter Unit | |
| Maintenance Cartridge | |

Troubleshooting

| Frequently Asked Questions | 1055 |
|--------------------------------------|------|
| Problems Regarding Paper | 1057 |
| Printing does not start | 1068 |
| The printer stops during a print job | 1070 |
| Problems with the printing quality | 1071 |
| Cannot print over a network | 1083 |
| Installation problems | 1085 |
| Other problems | 1087 |

12



Frequently Asked Questions

Frequently Asked Questions

This section presents frequently asked questions and answers. To view more detailed explanations, click the hyperlinks in the answer column.

| Question | Answer |
|--|---|
| I want to easily create vertical or horizontal banners. | You can print originals that are in landscape (or portrait) orientation automatically enlarged to fit the roll width. This is an easy way to create vertical or horizontal banners. ⇒"Printing Vertical or Horizontal Banners (Large-Format Printing) →P.122 " |
| A replacement message for the Maintenance Cartridge was displayed. | If a replacement message for the Maintenance Cartridge is displayed, replace it with a new Maintenance Cartridge. ⇒"When to Replace the Maintenance Cartridge →P.1037" |
| I want to perform enlargement copying from a Color image-RUNNER. | By using Color imageRUNNER Enlargement Copy (iR enlargement copy), you can print enlargements of scanned originals from a Color imageRUNNER. ⇒"Printing Enlargements of Scanned Originals from a Color imageRUNNER →P.304 " ⇒"Printing Enlargements of Scanned Originals from a Color imageRUNNER →P.606 " |
| I want to tilt and transfer the printer. | The tasks required before transfer differ depending on the angle of tilting. To protect internal mechanisms, prepare the form of transfer before transferring. ⇒"Preparing to Transfer the Printer →P.1044 " |
| I want to know the time to replace the Ink Tank. | Normally, replace it when an Ink Tank replacement message is displayed. Ink Tank replacement is possible even during printing, when print jobs are being canceled, or when paper is being advanced. ⇒"When to Replace Ink Tanks →P.1009" |
| Does this printer support sub-ink tank system? | This printer supports sub-ink tank system. Even if an ink tank becomes empty during printing, since a certain amount of ink always is stored in a sub-ink tank, you can replace the ink tank while printing. ⇒"Replacing Ink Tanks →P.997" |
| I want to know how to configure roll cutting. | You can select the cutting method by the setting of the printer driver and the setting of the printer. To cut rolls automatically after printing, set Cutting Mode of the printer to Automatic and Automatic Cutting of the printer driver to Yes. When using paper for which ink adhesion takes time or the print surface is easily scratched, we recommend that you set the Cutting Mode setting of the printer to Eject. ⇒"Specifying the Cutting Method for Rolls →P.802 " ⇒"Cutting Roll Paper After Printing →P.196 " |
| I want to configure so that the roll is cut au- tomatically after wait- ing for the ink to dry. | In the printer driver, you can set the time for waiting until the ink dries. Also, you can set likewise on the printer. ⇒"Specifying the Ink Drying Time for Rolls →P.800 " ⇒"Menu Structure →P.928 " |
| I want to replace the Printhead myself. | Acquire a Printhead supported by the printer. You can replace it yourself. ⇒"Replacing the Printhead →P.1013" |
| How do I print without borders? | When printing on rolls, you can perform borderless printing by configuring the printer driver. (when printing on cut sheets, you cannot perform borderless printing) ⇒"Borderless Printing on Paper of Equivalent Size →P.107 " ⇒"Borderless Printing by Resizing Originals to Fit the Roll Width →P.114 " |

| Question | Answer |
|---|--|
| How do I print with- out borders? | ⇒"Borderless Printing at Actual Size →P.100 " |
| I want to know the paper types that can be used in this printer. | Concerning the paper that can be used in this printer, refer to the imagePROGRAF home page or the Paper Reference Guide. ⇒"Types of Paper →P.774 " |
| The paper type that I want to print is not displayed on the Display Screen. | When using newly released paper, paper information must be registered on the printer and the printer driver. Download the new version of Media Information File from the imagePROG-RAF website and install it. ⇒"Types of Paper →P.774 " |
| What type of function is color calibration? | Color calibration improves color consistency by compensating for slight differences in how color appears when printing due to individual variations or aging among the printers. We recommend color calibration in the following situations. |
| | After initial printer installation |
| | After Printhead replacement |
| | When you sense a change of color compared to previously |
| | To print with colors aligned from multiple printers |
| | When the execution guide is displayed |
| | ⇒"Using Color Calibration for Color Adjustment →P.865 " |
| How do I print with- out wasting paper? | To conserve paper, you can specify in the printer driver to rotate originals 90 degrees or to print without top and bottom margins. ⇒"Conserving Roll Paper by Rotating Originals 90 Degrees →P.172 " ⇒"Conserving Roll Paper by Printing Originals Without Top and Bottom Margins →P.178 " |
| Can I perform duplex printing? | This printer cannot perform duplex printing. If you use the Folded Duplex function in the free layout of Windows software, you can print two pages one-sided, fold them at the center and suspend them to substitute for duplex printing. ⇒"Prints using Folded Duplex →P.290 " |
| I want to perform enlargement printing. | With the printer driver, you can specify the ratio matching the document with the paper size and width and perform enlargement printing or reduction printing. ⇒"Resizing Originals to Match the Paper Size →P.73 " ⇒"Resizing Originals to Fit the Roll Width →P.79 " ⇒"Resizing Originals by Entering a Scaling Value →P.85 " |


Problems Regarding Paper

| Clearing Jammed Roll Paper | |
|--|--------------|
| Clearing a Jammed Sheet | 1061 |
| Roll paper cannot be inserted into the paper feed slot | |
| Paper is not cut straightPaper is not cut | 1065 1065 |
| The media take-up unit continues rotating | 1066 |
| The size of clear film cannot be detected | 1067 |
| Margins are wide | 1067 |

Clearing Jammed Roll Paper

If roll paper jams, follow the steps below to remove jams.

- 1. Turn the printer off. (See "Turning the Printer On and Off.") \rightarrow P.3
- 2. Open the Top Cover.






Note

• If the leading edge of the roll jams in the carriage such as when the paper curls strongly, you may be able to avoid paper jamming by setting the roll cutting method to Manual and setting the detection of paper leading edge to [Off].

(See "Specifying the Cutting Method for Rolls.") -P.802

3. If the Carriage is out, move the Carriage out of the way, away from the paper.






Caution

• If you push the Carriage to the left edge, the blade of the Cutter Unit will be lowered in preparation to cut the paper. Be careful not to pinch your fingers between the Carriage and Platen if you have pushed the Carriage to the left edge or if a paper jam occurs during cutting.




Important


• Do not touch the Linear Scale (a), Carriage Shaft (b), or Fixed Blade (c), This may stain your hands and damage the printer.



12



5. Holding the paper on both sides, pull the jammed portion out toward the front. Use scissors or a cutting tool to cut away the printed or wrinkled portion.




Caution

• When cutting paper, be careful to avoid injury or damage to the printer.

12


6. If the Carriage is on the left, move the Carriage to the right until it stops.





Important

- Always move the Carriage to the right side. If the Carriage is on the left, a Carriage error may occur when you turn on the printer.
- 7. Hold the edge of the roll paper in the middle as you gently pull it evenly to the position of the Ejection Guide (a). Align the right side of the roll paper with the Paper Alignment Line (b), keeping this side parallel to the line, and then lower the Release Lever.



12


1060



Important

• Do not force the roll paper into alignment with the Paper Alignment Line (b). This may prevent the paper from being advanced straight.

8. Close the Top Cover.



9. Turn the printer on. (See "Turning the Printer On and Off.") —P.3

The roll is now advanced. After it is finished being advanced, you can resume printing.



Note


- To ensure that the edge is cut more neatly, follow these steps to cut it.
 - 1. Press the **Feed** button.
 - **2.** Hold down the **▼** button to advance the paper.
 - 3. Press the Cut button, and then select Yes to cut the edge.

 (See "Specifying the Cutting Method for Rolls.") →P.802

Clearing a Jammed Sheet


If a sheet jams, follow the steps below to remove it.

- 1. Turn the printer off. (See "Turning the Printer On and Off.") \rightarrow P.3
- **2.** Open the Top Cover.



12

3. If the Carriage is out, move the Carriage out of the way, away from the paper.






Caution

• If you push the Carriage to the left edge, the blade of the Cutter Unit will be lowered in preparation to cut the paper. Be careful not to pinch your fingers between the Carriage and Platen if you have pushed the Carriage to the left edge or if a paper jam occurs during cutting.




Important


• Do not touch the Linear Scale (a), Carriage Shaft (b), or Fixed Blade (c). This may stain your hands and damage the printer.




12



5. If the paper is visible, hold the paper and pull it out toward the front.




6. If the paper is not visible, lift the Ejection Guide, remove the Roll Holder, and clear the paper jam from below.



12

After removing the paper, make sure there are no other scraps of paper in the printer, and then lower the Ejection Guide.

7. If the Carriage is on the left, move the Carriage to the right until it stops.






Important

• Always move the Carriage to the right side. If the Carriage is on the left, a Carriage error may occur when you turn on the printer.

8. Lower the Release Lever and close the Top Cover.



1 4

1064

9. Turn the printer on. (See "Turning the Printer On and Off.") \rightarrow P.3

Roll paper cannot be inserted into the paper feed slot

| Cause | Corrective Action |
|--|---|
| The roll paper is warped. | Straighten out curls and reload the roll. |
| Paper is jammed by the paper feed slot. | Remove the jammed paper. (See "Clearing Jammed Roll Paper.") →P.1057 (See "Clearing a Jammed Sheet.") →P.1061 |
| The paper source selection is incorrect. | Press the Load button and select the paper source. |

Cannot load sheets

| Cause | Corrective Action |
|--|---|
| The paper source selection is incorrect. | Press the Load button and select the paper source. |

Paper is not cut straight


| Cause | Corrective Action |
|---|---|
| The paper is bent or curled at the cut position. | Straighten out any curling by the edges of the paper. |
| Paper rises by the ends of the cut position before it is cut. | Reload the paper correctly. |
| You are using paper that cannot be cut with the Cutter Unit. | Specify Manual in Cutting Mode in the Control Panel menu and use scissors or a cutting tool to cut the roll after printing. (See "Specifying the Cutting Method for Rolls.") P.802 |
| The Cutter Unit is not installed correctly. | Reinstall the Cutter Unit correctly. (See "Replacing the Cutter Unit.") →P.1024 |
| The Cutter Unit blade is worn out. | Replace the Cutter Unit. (See "Replacing the Cutter Unit.") →P.1024 |
| Cut Speed is not configured correctly in the Control Panel menu. | Change the Cut Speed setting in the Control Panel menu. (See "Menu Structure.") →P.928 |
| During cutting, printed documents fall out at an angle. | In the Control Panel menu, set Cutting Mode to Eject . Hold documents after printing, as they are cut. (See "Specifying the Cutting Method for Rolls.") P.802 |

Paper is not cut

| Cause | Corrective Action |
|--|---|
| In the printer driver, No or Print Cut Guideline is specified in Auto Cut. | Specify Yes in Auto Cut in the printer driver. |
| In the Control Panel menu, Cutting Mode is set to Eject or Manual. | If the Cutting Mode is Eject , press the Cut button to cut the paper. If the Cutting Mode is Manual , cut rolls with scissors or the like. |
| The Cutter Unit is not installed. | Install the Cutter Unit. (See "Replacing the Cutter Unit.") →P.1024 |

| Cause | Corrective Action |
|--|--|
| Rolls are not cut when you are using the Media Take-up Unit. | Either cut the roll paper by pressing the Cut button or lift the Release Lever and cut the roll with scissors. (See "Removing Printed Documents from the Media Take-up Unit (Optional).") →P.842 |

The media take-up unit continues rotating



|--|

| Cause | Corrective Action |
|---|---|
| The Media Take-up Sensor cord is not connected to the Right Media Take-up Unit correctly. | Reconnect the Media Take-up Sensor cord as follows. |
| | 1. Turn the printer off. |
| | 2. Disconnect the Media Take- up Sensor cord from the Right Media Take-up Unit and reconnect it firmly, all the way in. |
| | 3. Turn the printer on. |
| | (See "Using the Media Take- up Unit (Optional).") →P.831 |
| | If the Media Take-up Unit continues rotating, contact your Canon dealer for assistance. |

The size of clear film cannot be detected

| Cause | Corrective Action |
|--|--|
| The Platen is soiled with ink or other substances. | Open the Top Cover and clean the entire Platen. (See "Cleaning Inside the Top Cover.") →P.1040 |

Margins are wide

| Cause | Corrective Action |
|--|---------------------------|
| Rolls are advanced a specific amount before cutting to prevent problems with cutting and paper ejection. | This operation is normal. |

Printing does not start

| The Data lamp on the Control Panel does not light up | 1068 |
|--|------|
| The printer does not respond even if print jobs are sent | |
| Ink Filling. is displayed | 1068 |
| The display screen indicates Agitating | |

The Data lamp on the Control Panel does not light up

| Cause | Corrective Action |
|--|--|
| The printer is not on. | Make sure the power cord is securely plugged in, all the way. Press the Power button to turn on the printer. |
| The target printer was not selected when printing. (The printer is | In Windows, select the printer by clicking Select Printer or Printer in the printing dialog box and try printing again. |
| in Sleep mode.) | In Mac OS X, open the dialog box of the printer driver, select the printer from the list of Printer , and try printing again. |
| The print job is paused. (The | In Windows, restart the print job as follows. |
| printer is in Sleep mode.) | 1. Select the printer icon in the Printers and Faxes (or Printers) window. |
| | 2. Clear Pause Printing in the File menu to restart the print job. |
| | In Mac OS X, restart the print job as follows. |
| | 1. Click Print & Fax . (This is identified as Printer Setup Utility or Print Center in other versions of Mac OS X.) |
| | 2. Select the printer, and then Resume Printer (or Start Jobs) in the Printers menu to restart the print job. |

The printer does not respond even if print jobs are sent

| Cause | Corrective Action |
|---|--|
| In the Control Panel menu, Pause Print is On . | Set Pause Print to Off. (See "Pausing Printing.") →P.19 |
| You have selected Save in mail box in Output Method on the printer. | Print the job saved on the printer's hard disk. (See "Printing Saved Jobs.") —P.730 |
| Print jobs are pending. | Manage the jobs on hold and print as needed. (See "Managing Pending Jobs (Printing or Deleting Jobs on Hold).") →P.728 |

Ink Filling.. is displayed

| Cause | Corrective Action |
|--|---|
| The printer was forced off during operation. | Wait until the system has been filled with ink. This process may take about nine minutes. |

12

The display screen indicates Agitating

| Cause | Corrective Action |
|-------------------------------|---|
| Ink agitation is in progress. | Please wait until ink agitation is finished. The time for agitation varies depending on how long the printer was off. (Between about a minute and a half to twenty minutes.) |

iPF8300S

The printer stops during a print job

| An error message is shown on the Display Screen | 1070 |
|---|------|
| The printer ejects blank, unprinted paper | 1070 |

An error message is shown on the Display Screen

| Status | Corrective Action |
|---|---|
| An error message is displayed during printing. | Check the error message and take action as necessary. (See "Error Messages.") →P.1093 |
| The last portion of roll paper was used during a print job, and paper could not be advanced because the trailing edge is taped to the roll. | Remove the used roll and insert a new roll. (See "Removing the Roll from the Printer.") →P.794 (See "Removing the Roll Holder from Rolls.") →P.797 (See "Loading and Printing on Rolls.") →P.5 |

The printer ejects blank, unprinted paper

| Status | Corrective Action |
|---|---|
| The leading edge of the roll paper was cut to straighten it. | The leading edge of rolls may be cut to straighten it if you have selected Trim Edge First > On or Automatic in the Control Panel menu. (See "Cutting the Leading Edge of Roll Paper Automatically.") P.810 |
| The Printhead nozzles are clogged. | Print a test pattern to check the nozzles and make sure the Printhead is in good condition for printing. (See "Checking for Nozzle Clogging.") →P.1011 |
| A print job was received from an incompatible printer driver. | Use the correct imagePROGRAF printer driver for the printer and try printing again. |
| The printer is damaged. | Contact your Canon dealer for assistance. |

12

1071

Problems with the printing quality

| Printing is faint | 1071 |
|---|------|
| Paper rubs against the printhead | 1072 |
| The edges of the paper are dirty | |
| The surface of the paper is dirty | |
| The back side of the paper is dirty | 1074 |
| Immediately after borderless printing, the trailing edge margin is soiled during regular printing | 1074 |
| Printed colors are inaccurate | 1075 |
| Banding in different colors occurs | |
| Colors in printed images are uneven | 1076 |
| Image edges are blurred or white banding occurs | 1077 |
| Setting the Blue Switch on the Platen | 1078 |
| The contrast becomes uneven during printing | 1080 |
| The length of printed images is inaccurate in the feeding direction | 1080 |
| Images are printed crooked | |
| Documents are printed in monochrome | 1081 |
| Line thickness is not uniform | 1081 |
| Lines or colors are misaligned | 1082 |
| Problems with the printing quality caused by the type of paper | 1082 |
| | |

Printing is faint

| Cause | Corrective Action |
|--|---|
| You may be printing on the wrong side of the paper. | Print on the printing surface. |
| The Printhead nozzles are clogged. | Print a test pattern to check the nozzles and see if they are clogged. (See "Checking for Nozzle Clogging.") →P.1011 |
| Because the printer was left with- out ink tanks installed for some time, ink has become clogged in the ink supply system. | After the ink tanks have been installed for 24 hours, run Head Cleaning B from the Control Panel. (See "Cleaning the Printhead.") →P.1012 |
| Paper is jammed inside the Top Cover. | Follow the steps below to remove the jammed piece of paper inside the Top Cover. |
| | 1. Open the Top Cover and make sure the Carriage is not over the Platen. |
| | 2. Remove any scraps of paper inside the Top Cover. (See "Clearing Jammed Roll Paper.") →P.1057 (See "Clearing a Jammed Sheet.") →P.1061 |
| | 3. Close the Top Cover. |
| The ink was not dry when paper was cut. | Specify a longer drying period in the Control Panel menu, in Paper Details > Roll DryingTime . (See "Menu Settings.") →P.938 |
| Printing may be faint if Print Quality in Advanced Settings in the printer driver is set to Standard or Fast . | In Advanced Settings of the printer driver, choose Highest quality or High in Print Quality. Printing in Fast or Standard mode is faster and consumes less ink than in Highest quality or High modes, but the printing quality is lower. |

iPF8300S Printing is faint

| Cause | Corrective Action |
|--|--|
| Printing may be faint if Print Quality in Advanced Settings in the printer driver is set to Standard or Fast . | (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") →P.64 |
| You are printing on paper that tends to generate dust when cut. | In the Control Panel menu, set CutDustReduct. in Paper Details to On. (See "Reducing Dust from Cutting Rolls.") →P.812 |

Paper rubs against the printhead

| Cause | Corrective Action |
|--|---|
| The type of paper specified in the printer driver does not match the type loaded in the printer. | Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.786 (See "Loading Sheets in the Printer.") →P.813 |
| | Make sure the same type of paper is specified in the printer driver as you have loaded in the printer. |
| | 1. Press the Stop button and stop printing. |
| | 2. Change the type of paper in the printer driver and try printing again. |
| Paper has been loaded incorrectly, causing it to wrinkle. | Reload the paper. (See "Loading Rolls in the Printer.") →P.786 (See "Loading Sheets in the Printer.") →P.813 |
| The Printhead is set too low in the Control Panel menu. | In the Control Panel menu, set Head Height to Automatic . (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") →P.854 |
| You are printing on heavyweight paper or paper that curls or wrinkles easily after absorbing ink. | When printing on Heavyweight Coated Paper or other paper-based media, choose a VacuumStrngth setting of Strong or Strongest in the Control Panel menu. If rubbing still occurs, in the Control Panel menu, use a higher Head Height setting. (See "Adjusting the Vacuum Strength (VacuumStrngth).") →P.863 (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") →P.854 |
| | When printing on CAD Tracing Paper or other film-based media, choose a VacuumStrngth setting of Standard, Strong, or Strongest in the Control Panel menu. If rubbing still occurs, in the Control Panel menu, use a higher Head Height setting. (See "Adjusting the Vacuum Strength (VacuumStrngth).") —P.863 (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") —P.854 |
| | When printing on paper 0.1 mm (0.004 in) thick or less, choose a VacuumStrngth setting of Weakest in the Control Panel menu. If rubbing still occurs, in the Control Panel menu, use a higher Head Height setting. (See "Adjusting the Vacuum Strength (VacuumStrngth).") —P.863 (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") —P.854 |
| When you have loaded paper, the paper you have loaded does not match the type selected on the Control Panel. | Be sure to select the correct type of paper in the Control Panel menu when loading paper. (See "Loading Rolls in the Printer.") —P.786 (See "Loading Sheets in the Printer.") —P.813 |

| Cause | Corrective Action |
|---|---|
| Since the leading edge of the paper strongly warps upward or ripples, the leading edge of the paper rubs against the printhead. | Set Cutting Mode to Manual on the Control Panel menu, and select Off for the paper leading edge detection setting. In this case, when keeping track of the amount of roll paper left, set ManageRemainRoll to Off before loading the roll paper and then set ManageRemainRoll to On after loading the roll paper. (See "Specifying the Cutting Method for Rolls.") P.802 (See "Keeping Track of the Amount of Roll Paper Left.") P.799 |

The edges of the paper are dirty

| Cause | Corrective Action |
|--|--|
| The Platen has become dirty after borderless printing or printing on small paper. | Open the Top Cover and clean the Platen. (See "Cleaning Inside the Top Cover.") →P.1040 |
| The type of paper as specified on the printer does not match the type specified in the printer driver. | Make sure the same type of paper is specified on the printer as in the printer driver. (See "Changing the Type of Paper.") →P.791 |
| | Make sure the same paper type is specified in the printer driver as on the printer. |
| | 1. Press the Stop button and stop printing. |
| | 2. Change the type of paper in the printer driver and try printing again. |
| The paper is wrinkled or warped. | Straighten out the wrinkles or curls and reload the paper. Do not use paper that has been printed on previously. (See "Loading Rolls in the Printer.") P.786 (See "Loading Sheets in the Printer.") P.813 |
| A cut line is printed because Cut- DustReduct. is On in the Control Panel menu to reduce cutting dust. | If this function is not needed, set CutDustReduct. to Off in the Control Panel menu. (See "Menu Settings.") →P.938 |
| The Printhead is set too low in the Control Panel menu. | In the Control Panel menu, set Head Height to Automatic . (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") →P.854 |
| You are printing on heavyweight paper or paper that curls or wrinkles easily after absorbing ink. | When printing on Heavyweight Coated Paper or other paper-based media, choose a VacuumStrngth setting of Strong or Strongest in the Control Panel menu. If rubbing still occurs, in the Control Panel menu, use a higher Head Height setting. (See "Adjusting the Vacuum Strength (VacuumStrngth).") —P.863 (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") —P.854 |
| | When printing on CAD Tracing Paper or other film-based media, choose a VacuumStrngth setting of Standard, Strong, or Strongest in the Control Panel menu. If rubbing still occurs, in the Control Panel menu, use a higher Head Height setting. (See "Adjusting the Vacuum Strength (VacuumStrngth).") —P.863 (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") —P.854 |
| The Ejection Guide is soiled. | Clean the Ejection Guide. (See "Cleaning the Printer Exterior.") →P.1039 |

| Cause | Corrective Action |
|---|---|
| The Paper Retainer is soiled. | Clean the Paper Retainer. (See "Cleaning Inside the Top Cover.") →P.1040 |
| You are using a paper that does not dry easily. | In the Control Panel menu, set Roll DryingTime to at least 1 min. (See "Menu Settings.") →P.938 |
| | When paper that does not dry easily is used for printing, it may curl during printing and touch the Output Tray. In this case, in the Control Panel menu, set Scan Wait Time to an option other than Off . However, note that printing will now take longer. (See "Menu Settings.") —P.938 |

The back side of the paper is dirty

| Cause | Corrective Action |
|---|--|
| The Platen has become dirty after border-less printing or printing on small paper. | Open the Top Cover and clean the Platen. (See "Cleaning Inside the Top Cover.") →P.1040 |
| | In the Control Panel menu, set CarriageScanWdth to Fixed. (See "Menu Settings.") →P.938 |
| The Platen has become soiled because you have set Width Detection to Off in the Control Panel menu. | Set Width Detection to On in the Control Panel menu, and then open the Top Cover and clean the Platen. (See "Cleaning Inside the Top Cover.") →P.1040 |
| | Open the Top Cover and clean the Platen. After this, manually advance the roll onto the Platen before printing. (See "Cleaning Inside the Top Cover.") →P.1040 (See "Feeding Roll Paper Manually.") →P.798 |
| The Platen suction is too strong. | In the Control Panel menu, reduce the level of VacuumStrngth . (See "Adjusting the Vacuum Strength (VacuumStrngth).") ¬P.863 |

Immediately after borderless printing, the trailing edge margin is soiled during regular printing

| Cause | Corrective Action |
|--|--|
| Depending on your printing environment, after borderless printing in which the leading and trailing edge of the roll is cut automatically, any ink adhering to the cutter unit may rub off on the next printed document. | Follow these steps to change the Between Pages setting of Drying Time to a value between about 30 seconds and 3 minutes before trying borderless printing again. 1. On the Main sheet of the printer driver, click Advanced Settings by Media Type . |
| | 2. Select an ink drying time in the list for the Between Pages setting of Drying Time . |

12

Printed colors are inaccurate

| Cause | Corrective Action |
|--|---|
| Color adjustment has not been activated in the Advanced Settings of the printer driver. | In the Advanced Settings of the printer driver, access Color Settings in Color Mode to adjust colors. |
| Colors have not been adjusted on the computer or monitor. | Refer to the computer and monitor documentation to adjust the colors. |
| | Adjust the settings of the color management software, referring to the software documentation as needed. |
| The Printhead nozzles are clogged. | Print a test pattern to check the nozzles and see if they are clogged. (See "Checking for Nozzle Clogging.") —P.1011 |
| In the Windows printer driver, Application Color Matching Priority is not selected. | Click Special Settings on the Layout sheet of the printer driver and select Application Color Matching Priority in the dialog box. |
| There may be a slight difference in how colors are printed after Printhead replacement because of individual variation among printheads. | Execute color calibration. |
| Printhead characteristics gradually change through repeated use, and colors may change. | Execute color calibration. |
| Color may change slightly even on the same model of printer if you use a different version of the firmware or printer driver, or | Follow these steps to prepare the printing environment. |
| when you print under different settings or in a different printing environment. | 1. Use the same version of firmware or printer driver. |
| | 2. Specify the same value for all settings items. |
| | 3. Execute color calibration. |
| When reinstalling the printer driver, you changed the region selection of the Media Configuration Tool. Changing the region selection of the Media Configuration Tool deletes the region-specific paper information originally registered on the printer before installation. Using paper with deleted information when executing color calibration will prevent the resulting calibration adjustment value from being applied to all other types of the paper. | Prepare paper compatible with calibration in the newly selected region and perform calibration again. |

Banding in different colors occurs

| Cause | Corrective Action |
|--|--|
| The paper feed amount is out of adjustment. | Adjust the feed amount. (See "Adjusting the Feed Amount.") →P.856 |
| Printing does not proceed smoothly because print jobs are interrupted during transmission. | Exit other applications and cancel other print jobs. |

iPF8300S Printed colors are inaccurate

| Cause | Corrective Action |
|--|--|
| In the Control Panel menu, Adj. Priority is set to Print Length. | Setting Adj. Priority to Print Quality in the Control Panel menu and adjusting the feed amount may improve results. (See "Adjusting the Feed Amount.") →P.856 |
| The Printhead is out of alignment. | Adjust the Printhead alignment. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") →P.850 |
| The Printhead nozzles are clogged. | Print a test pattern to check the nozzles and see if they are clogged. (See "Checking for Nozzle Clogging.") →P.1011 |
| Streaks may occur if you set the Print Quality too low. | Choose a higher level of Print Quality in the Advanced Settings of the printer driver and try printing again. Printing in Fast or Standard mode is faster and consumes less ink than in Highest quality or High modes, but the printing quality is lower. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") \rightarrow P.64 |
| The type of paper specified in the printer driver does not match the type loaded in the printer. | Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.786 (See "Loading Sheets in the Printer.") →P.813 |
| | Make sure the same type of paper is specified in the printer driver as you have loaded in the printer. |
| | 1. Press the Stop button and stop printing. |
| | 2. Change the type of paper in the printer driver and try printing again. |

Colors in printed images are uneven

| Cause | Corrective Action |
|--|---|
| Line Drawing/Text is selected when printing images in many solid colors. | In Print Priority in the Advanced Settings of the printer driver, choose Image . |
| You are printing on paper that curls easily. | Printed colors may appear uneven on the leading edge of paper that is susceptible to curling. Select a stronger level in VacuumStrngth in the Control Panel menu to increase suction against the paper, or specify a leading margin of 20 mm (0.79 in) or more. (See "Adjusting the Vacuum Strength (VacuumStrngth).") —P.863 |
| Printed colors may be uneven if you set the Print Quality too low. | Choose a higher level of Print Quality in the Advanced Settings of the printer driver. Printing in Fast or Standard mode is faster and consumes less ink than in Highest quality or High modes, but the printing quality is lower. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") P.64 |
| Color may be uneven between dark and light image areas. | Select Unidirectional Printing in the Advanced Settings of the printer driver. |
| When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be slightly uneven at the leading edges. | Specify No in Auto Cut in the printer driver before printing. In this case, the paper can be printed without borders on the left and right sides only. Cut the printed document ejected from the printer, and then use scissors or a cutting tool to cut away the edges on the top and bottom. |
| | Choose a higher level of Print Quality in the Advanced Settings of the printer driver. |

12

| 1 | 1 |
|---|---|
| • | 1 |

| Cause | Corrective Action |
|--|--|
| When borderless printing is used, the edge of the paper is cut during printing. Thus, ink density may be slightly uneven at the leading edges. | (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") →P.64 |
| The Printhead is out of alignment. | Adjust the Printhead alignment. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") →P.850 |
| Allowing printed documents to dry on top of each other may cause uneven colors. | To avoid uneven colors, we recommend drying each sheet separately. |
| Density may be uneven if you use Glossy Paper or Coated Paper. | In Advanced Settings of the printer driver, choose Highest quality or High in Print Quality. |
| The type of paper specified in the printer driver does not match the type loaded in the printer. | Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.786 (See "Loading Sheets in the Printer.") →P.813 |
| | Make sure the same type of paper is specified in the printer driver as you have loaded in the printer. |
| | 1. Press the Stop button and stop printing. |
| | 2. Change the type of paper in the printer driver and try printing again. |
| Scan Wait Time > Area in the Control Panel menu is set to Leading edge. | When Scan Wait Time > Area is set to Leading edge, colors may be uneven 110–160 mm from the leading edge. (The position varies depending on the Print Quality setting.) In this case, select Scan Wait Time > Area > Entire area. However, note that printing will now take longer. (See "Menu Settings.") —P.938 |

Image edges are blurred or white banding occurs

| Cause | Corrective Action |
|---|---|
| The Platen suction is too strong. | In the Control Panel menu, reduce the level of VacuumStrngth . (See "Adjusting the Vacuum Strength (VacuumStrngth).") →P.863 |
| | Close the blue Switch on the platen so that it matches the paper size. (See "Setting the Blue Switch on the Platen.") P.1078 |
| Incorrect Printhead alignment value. | When printing fine lines or text at high precision on glossy or semi-glossy photo or proofing paper, set the optimal Printhead height before aligning the printhead. (See "Enhancing Printing Quality.") P.848 |
| | In the Control Panel menu, set Head Height to a lower height. (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") →P.854 |
| The type of paper specified in the printer driver does not match the type loaded in the | Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") P.786 (See "Loading Sheets in the Printer.") P.813 |
| printer. | Make sure the same type of paper is specified in the printer driver as you have loaded in the printer. |
| | 1. Press the Stop button and stop printing. |
| | 2. Change the type of paper in the printer driver and try printing again. |

Setting the Blue Switch on the Platen


If printed documents exhibit the following symptoms, adjust the setting of the blue Switch on the Platen.

- · Image edges are blurred
- Image edges are affected by white banding




Important

- Always set the blue Switch on the Platen to the side for borderless printing. Printing quality may be affected if the Switch is incorrectly set.
- 1. Remove any loaded paper that will not be used.
 - Rolls (See "Removing the Roll from the Printer.") →P.794
 - Sheets (See "Removing Sheets.") →P.820
- **2.** Open the Top Cover.




3. Remove the Cleaning Brush (a).






12

4. Using the back of the Cleaning Brush, move the first Switch to the side opposite •.




5. Refer to the following table to confirm the number on the Platen that corresponds to the size of paper for printing.



| Number | Dimensions |
|--------|---|
| 2 | 254 mm (10 in) |
| 3 | 355 mm (14 in) |
| 4 | 432 mm (17 in) |
| 5 | 515 mm (JIS B2 or B3) |
| 6 | 594 mm (ISO A1 or A2) or 610 mm (24 in) |
| 7 | 841 mm (ISO A0 or A1) |
| 8 | 914 mm (36 in) |
| 9 | 1,030 mm (JIS B0 or B1) |
| 10 | 1,067 mm (42 in) |
| 11 | 1,117 mm (44 in) |

- **6.** Using the back of the Cleaning Brush, move the Switch to the side opposite ●, corresponding to the size of the paper for printing.
 - In this case, note that you will move the switch in the opposite direction from the direction in step 4.
- 7. Close the Top Cover.



The contrast becomes uneven during printing

| Cause | Corrective Action |
|--|---|
| The paper feed amount is out of adjustment. | Adjust the feed amount. (See "Adjusting the Feed Amount.") →P.856 |
| The type of paper specified in the printer driver does not match the type loaded in the printer. | Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") —P.786 (See "Loading Sheets in the Printer.") —P.813 |
| | Make sure the same type of paper is specified in the printer driver as you have loaded in the printer. |
| | 1. Press the Stop button and stop printing. |
| | 2. Change the type of paper in the printer driver and try printing again. |

The length of printed images is inaccurate in the feeding direction

| Cause | Corrective Action |
|--|---|
| In the Control Panel menu, Adj. Priority is set to Print Quality. | Set Adj. Priority to Print Length in the Control Panel menu, and then execute Adjust Length . (See "Adjusting the Feed Amount.") →P.856 |
| The type of paper specified in the printer driver does not match the type loaded in the printer. | Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.786 (See "Loading Sheets in the Printer.") →P.813 |
| | Make sure the same type of paper is specified in the printer driver as you have loaded in the printer. |
| | 1. Press the Stop button and stop printing. |
| | 2. Change the type of paper in the printer driver and try printing again. |

Images are printed crooked

| Cause | Corrective Action |
|---|--|
| In the Control Panel menu, Skew Check Lv. is set to Loose or Off. | In the Control Panel menu, set Skew Check Lv. to Standard. |
| In the Control Panel menu, Width Detection is set to Off. | Set Width Detection to On in the Control Panel menu. |

Documents are printed in monochrome

| Cause | Corrective Action |
|---|---|
| In the Advanced Settings of the printer driver, Monochrome or Monochrome (Photo), is specified in Color Mode . | In the Advanced Settings of the printer driver, specify Color in Color Mode and try printing again. |
| The Printhead nozzles are clogged. | Print a test pattern to check the color ink nozzles and see if they are clogged. (See "Checking for Nozzle Clogging.") →P.1011 |

Line thickness is not uniform

| Cause | Corrective Action | |
|---|---|--|
| In the Special Settings dialog box of the Windows printer driver, Fast Graphic Process is selected. | Access the printer driver Properties dialog box from Print in the File menu of the source application, and follow these steps to print. | |
| | 1. Clear the option Open Preview When Print Job Starts on the Main sheet. | |
| | 2. Clear the option Page Layout on the Layout sheet. | |
| | 3. Click the Special Settings button on the Layout sheet to display the Special Settings dialog box, and then clear the option Fast Graphic Process . | |
| The blue Switch on the platen is set incorrectly. | Move the Switch numbered corresponding to the size of paper for printing opposite to the ● position. (See "Setting the Blue Switch on the Platen.") →P.1078 | |
| The type of paper specified in the printer driver does not match the type loaded in the printer. | Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") —P.786 (See "Loading Sheets in the Printer.") —P.813 | |
| | Make sure the same type of paper is specified in the printer driver as you have loaded in the printer. | |
| | 1. Press the Stop button and stop printing. | |
| | 2. Change the type of paper in the printer driver and try printing again. | |
| Incorrect Printhead alignment value. | When printing fine lines or text at high precision on glossy or semi-glossy photo or proofing paper, set the optimal Printhead height before aligning the printhead. | |

| Cause | Corrective Action |
|--|--|
| Incorrect Printhead alignment value. | (See "Enhancing Printing Quality.") →P.848 |
| | In the Control Panel menu, use a lower Head Height setting. (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") →P.854 |
| Depending on the type of paper, the thickness of printed lines may be noticeably inconsistent. | Specify Proof in Print Priority in the printer driver. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") P.64 |

Lines or colors are misaligned

| Cause | Corrective Action |
|--|---|
| The Printhead is not being aligned correctly. | Adjust the Printhead alignment. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") →P.850 (See "Manual Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") →P.852 |
| | When printing fine lines or text at high precision on glossy or semi-glossy photo or proofing paper, set the optimal Printhead height before aligning the printhead. (See "Enhancing Printing Quality.") →P.848 |
| | In the Control Panel menu, use a lower Head Height setting. (See "Troubleshooting Paper Abrasion and Blurry Images (Head Height).") →P.854 |
| The type of paper specified in the printer driver does not match the type loaded in the printer. | Load paper of the same type as you have specified in the printer driver. (See "Loading Rolls in the Printer.") →P.786 (See "Loading Sheets in the Printer.") →P.813 |
| | Make sure the same type of paper is specified in the printer driver as you have loaded in the printer. |
| | 1. Press the Stop button and stop printing. |
| | 2. Change the type of paper in the printer driver and try printing again. |
| Depending on the type of paper, printed lines may be noticeably misaligned. | Specify Proof in Print Priority in the printer driver. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") P.64 |

Problems with the printing quality caused by the type of paper

For paper-specific troubleshooting tips to improve the printing quality, refer to the Paper Reference Guide. (See "Types of Paper.") P.774

Cannot print over a network

| Cannot connect the printer to the network | 1083 |
|---|------|
| Cannot print over a TCP/IP network | 1083 |
| Cannot print over a NetWare network | 1084 |
| Cannot print over AppleTalk or Bonjour networks | 1084 |

Cannot connect the printer to the network

| Cause | Corrective Action |
|---|--|
| The Ethernet cable is not connected correctly to the printer's Ethernet port. | Make sure the printer is connected to the network with the correct Ethernet cable, and then turn the printer on. For instructions on connecting the cable, refer to the Setup Guide. Make sure the Link indicator is lit. The top and bottom indicators are lit if the printer is connected via 1000Base-T. The bottom indicator is green if the printer is connected via 100BASE-TX, and the top indicator is orange if connected via 10BASE-T. If the Link indicator is not lit, check the following points. |
| | Make sure the hub is on. |
| | Make sure the end of the Ethernet cable is connected correctly. Insert the Ethernet cable until it clicks and locks in place. |
| | Make sure there is no problem with the Ethernet cable. If there is any problem, replace the Ethernet cable. |
| | Check the communication mode with the hub. Although the printer normally detects the hub communication mode and transmission rate automatically (in auto negotiation mode), sometimes the hub settings cannot be detected. In this case, configure the connection method manually, specifying the communication mode in use. (See "Configuring the Communication Mode Manually.") P.992 |

Cannot print over a TCP/IP network

| Cause | Corrective Action |
|--|---|
| The printer's IP address is not configured correctly. | Make sure the printer's IP address is configured correctly. (See "Configuring the IP Address Using imagePROGRAF Device Setup Utility.") →P.443 (See "Configuring the IP Address Using the Printer Control Panel.") →P.966 |
| The printer's TCP/IP network settings are not configured correctly. | Make sure the printer's TCP/IP network settings are configured correctly. (See "Configuring the Printer's TCP/IP Network Settings With RemoteUI .") →P.970 |
| The computer you are trying to print from is not configured correctly. | Make sure the computer's TCP/IP network settings are configured correctly. (See "Configuring the Printer Driver Destination (Windows).") →P.969 (See "Configuring the Destination in TCP/IP Networks .") →P.984 |

iPF8300S

Cannot print over a NetWare network

| Cause | Corrective Action |
|--|--|
| The printer's NetWare settings are not configured correctly. | Make sure the printer's NetWare settings are configured correctly. In particular, make sure a valid frame type is selected. (See "Configuring the Printer's NetWare Network Settings With RemoteUI.") —P.981 |
| The computer you are trying to print from is not configured correctly. | Make sure the computer's NetWare settings are configured correctly. (See "Configuring NetWare Network Settings.") →P.974 |
| The NetWare server and | Check the following points. |
| services are not configured correctly. | 1. Make sure the NetWare file server is running. |
| | 2. Make sure there is enough free disk space on the NetWare file server. Insufficient disk space may prevent you from processing large print jobs. |
| | 3. Start NWADMIN or PCONSOLE and confirm that the print service is configured correctly and the print queue is available. |
| | 4. If data transmission to a printer on another subnet fails, deactivate NCP burst mode in that printer's network protocol settings. |
| | 5. If the printer is used in queue server mode, specify Other/Unknown as the printer type. |

Cannot print over AppleTalk or Bonjour networks

| Cause | Corrective Action |
|--|--|
| The AppleTalk protocol is not enabled on the printer. | Activate AppleTalk on the printer. (See "Configuring the Printer's AppleTalk Network Settings.") →P.989 |
| The computer you are trying to print from is not configured correctly. | Make sure the computer's AppleTalk settings are configured correctly. (See "Configuring the Destination for AppleTalk Networks .") →P.988 (See "Configuring the Destination for Bonjour Network .") →P.986 |
| The computer and printer are not on the same network. | Due to the nature of Bonjour, you cannot print if the printer is on another network behind a router. Make sure the computer and printer are on the same network. For information about network settings, ask your network administrator. |

Installation problems

Removing Installed Printer Drivers

Follow these steps to remove installed printer drivers and utilities.

Removing printer drivers (Windows)

Remove the printer driver as follows.



Note

- The following instructions are for Windows XP. The method of removing printer drivers varies depending on the version of Windows.
- 1. From the Windows start menu, select Programs > Canon Printer Uninstaller > imagePROGRAF Printer Driver Uninstaller to display the Delete Printer window.
- 2. Select the printer in the list and click **Delete**.
- 3. Click Yes after the Warning message is displayed.
- **4.** Make sure that the printer has been removed from the list, and then click **Exit**.

Removing printer drivers and imagePROGRAF Printmonitor (Macintosh)

Remove the printer driver or imagePROGRAF Printmonitor as follows.

- 1. Insert the User Software CD-ROM provided with the printer in the CD-ROM drive.
- 2. Start the printer driver installer included in the User Software CD-ROM. Open the OS X folder and double-click iPF Driver Installer X.
- **3.** In the upper left menu, choose **Uninstall**, and then click **Uninstall**.
- **4.** Follow the instructions on the screen to remove the printer driver or imagePROGRAF Printmonitor.

Removing imagePROGRAF Status Monitor (Windows)

Remove imagePROGRAF Status Monitor as follows.



Note

- The following instructions are for Windows XP. The method of removing printer drivers varies depending on the version of Windows.
- 1. Select Control Panel from the start menu.
- 2. Select Add or Remove Programs.

12

1086

3. Select imagePROGRAF Status Monitor, and then click the Change/Remove button.

Removing imagePROGRAF Device Setup Utility (Windows)

Remove imagePROGRAF Device Setup Utility as follows.



Note

- The following instructions are for Windows XP. The method of removing printer drivers varies depending on the version of Windows.
- 1. From the Windows start menu, select Programs > imagePROGRAF Device Setup Utility > Uninstaller (image-PROGRAF Device Setup Utility) to start the wizard.
- 2. In the wizard window, click **Delete**, and then click **Next**.
- **3.** Follow the instructions on the screen to remove imagePROGRAF Device Setup Utility.

Other problems

| The printer does not go on | 1087 |
|--|------|
| The printer takes time to start up | |
| If the Printer Makes a Strange Sound | 1088 |
| Messages advising to check the maintenance cartridge are not cleared | 1088 |
| The printer consumes a lot of ink | 1088 |
| Ink Level Detection | 1089 |

The printer does not go on

| Cause | Corrective Action |
|--|---|
| The printer is unplugged. | Plug the power cord into the outlet, and then turn on the printer. |
| The specified voltage is not supplied. | Check the voltage of the outlet and breaker. (See "Specifications.") →P.1123 |

The printer takes time to start up

| Cause | Corrective Action |
|---|---|
| The printer may have shut down incorrectly last time. This may happen after power outages or if the printer is unplugged before it is turned off. In this case, the next time power is restored, the printer's hard disk is checked, and startup may take some time. | Please wait a while, because it may take several minutes to finish checking the hard disk. If an error message is displayed after the hard disk check, follow the instructions indicated to resolve the problem. |

If the Printer Makes a Strange Sound

| Cause | Corrective Action |
|---------------------------------|---|
| The printer | The following sounds do not indicate a problem with the printer. |
| makes a sound during operation. | There is a sound of suction from the Platen. To prevent paper from rising, paper is held against the Platen by suction from Vacuum holes under it. |
| | Roll paper makes a fluttering sound during printing. There may be a fluttering sound when large paper is advanced. |
| | You suddenly hear the sound of cleaning operations. At regular intervals, for printer maintenance, cleaning operations will begin automatically, even if the printer is in Sleep mode. |
| | • You suddenly hear the sound of ink agitation. At regular intervals, to ensure optimal printing quality, the ink is agitated automatically, even if the printer is in Sleep mode. Ink agitation takes about a minute and a half. The ink is also agitated automatically under the following conditions. Note that other operations are not possible while "Agitating" is displayed on the control panel. |
| | After the printer is turned on |
| | After data transmission |
| | After ink tank replacement |
| | In other cases, contact your Canon dealer. |

Messages advising to check the maintenance cartridge are not cleared

| Cause | Corrective Action |
|--|--|
| The printer has not detected the new Maintenance Cartridge that was used to replace the old one. | Remove the new Maintenance Cartridge you have just installed and insert it again firmly. |
| | Restart the printer. |

The printer consumes a lot of ink

| Cause | Corrective Action |
|---|--|
| Many full-page color images are printed. | In print jobs such as photos, images are filled with color. This consumes a lot of ink. This does not indicate a problem with the printer. |
| Head Cleaning B in the Control Panel menu is executed frequently. | Head Cleaning B in the Control Panel menu consumes a lot of ink. This does not indicate a problem with the printer. Unless the printer has been moved or stored for a long period or you are troubleshooting Printhead problems, we recommend not performing Head Cleaning B , to the extent possible. |
| You have just finished initial installation or at the first-time use after transfer, ink flows into the system. After initial installation or at the first-time use after transfer, ink flows into the system to 80%. This does not indicate a problem with the printer. | |
| The Printhead nozzles are clogged. | Check for nozzle clogging. (See "Checking for Nozzle Clogging.") →P.1011 |

Ink Level Detection

Ink level detection will be deactivated if you load ink tanks once emptied.

Ink level detection

Ink tanks specified for this printer feature an ink level detection function to prevent the ink from running out during printing, which prevents printer damage. (See "Ink Tanks.") —P.996

This function will not work correctly if you use refill ink tanks. As a result, printing stops. Thus, before using refill ink tanks, you must cancel the ink level detection.

Printing with the ink level detection canceled may lead to printer damage and printing problems. Canon Inc. is not liable for any damage that may occur as a result of refilling ink.



Important


- After ink level detection has been released, this function cannot be reactivated for currently loaded Ink Tank. To use ink level detection again, replace the Ink Tank with new ones specified for use with the printer.
- Repeatedly removing and inserting an Ink Tank may damage the connection between the Ink Tank and the printer, which may cause ink leakage from the Ink Tank and damage the printer.

Releasing ink level detection

1. On the Display Screen, a message indicates that the ink level cannot be detected. After checking the message, press the button.

Remaining level of the ink cannot be correctly detected.
Check ink tank.

2. Press \triangle or ∇ to select **Information**, and then press the **OK** button.



3. A confirmation message is shown on the Display Screen about releasing ink level detection. After checking the message, press the ▶ button.

Tank once emptied is used. Printing stopped due to ink level unknown.


1089

iPF8300S Ink Level Detection

4. After checking the message, press the ▶ button.




5. Press ▲ or ▼ to select **Yes**, and then press the **OK** button.




6. Check the message and press the ▶ button.



7. Check the message and press the ▶ button.




8. Press \blacktriangle or \blacktriangledown to select Yes, and then press the OK button.





10. Press ▲ or ▼ to select Yes, and then press the OK button.




Ink level detection is now released.

12

Error Message

| Error Messages | 1093 |
|--|------|
| Messages regarding paper | 1095 |
| Messages regarding ink | 1107 |
| Messages regarding printing or adjustment | 1110 |
| Messages regarding printheads | 1113 |
| Messages regarding the maintenance cartridge | 1115 |
| Messages regarding the hard disk | 1117 |
| Other Messages | 1119 |

13



Error Messages

| Before borderless printing, move the blue platen switch. Blue platen switch is dirty. Borderless printing not possible. Borderless printing not possible. Paper stretched or shrank. | 1112 1105 |
|---|--|
| Calibration There is a problem with the multi-sensor. Cannot adjust paper feed. Cannot adjust printhead. Cannot calibrate. Cannot cut this paper. | 1121 1112 1113 1110 1104 |
| Cannot execute this command. Use other paper. Cannot feed paper. Check printed document. Close Ink Tank Cover | 1103 1112 |
| End of paper feed. ERROR Exxx-xxxx (x represents a letter or number) Excessive temperature or humidity. Execute printhead cleaning. | 1119 1111 |
| File read error. | 1117 |
| GARO Wxxxx (x represents a number) | 1119 |
| Hard disk error. Hardware error. xxxxxxxx-xxxx (x represents a letter or number) | |
| Ink insufficient. Ink tank is empty. Insufficient paper for job | 1108 |
| Mail box full. Delete unwanted data Mail box full. Now printing without saving data. Mail box nearly full. Maint. cart. The level is low Maintenance cartridge full. Maintenance cartridge problem. Maximum jobs stored. Media take-up unit ready. MediaType Mismatch Move the blue platen switch No.xx to the right. (xx represents a number) Multi-sensor error | 1117 1118 1115 1115 1116 1118 1105 1096 1112 1121 |
| No ink left. No ink tank loaded. No Maintenance Cartridge capacity. No maintenance cartridge. No sheets. No x printhead (x is L, R, or not displayed) Not much ink is left. | 1109 1115 1115 1102 1114 |
| Paper loaded askew. Paper mismatch Paper position not suitable for borderless printing. Paper size not detected. PaprWidth Mismatch | 1095 1106 1098 |

Parts replacement time has passed. 1120
PHeads: wrong pos. 1113
Please calibrate using above paper. 1111
Please execute calibration. 1111

1095

Messages regarding paper

| Paper mismatch | 1095 |
|--|------|
| MediaType Mismatch | 1096 |
| The paper is too small. | 1096 |
| The paper is too small. | 1097 |
| PaprWidth Mismatch | 1097 |
| Paper size not detected. | 1098 |
| Insufficient paper for job | 1100 |
| This paper cannot be used as size is not supported. | |
| Roll printing is selected. | 1101 |
| Roll printing is selected, but sheets are loaded. | 1101 |
| The roll is empty. | 1101 |
| No sheets. | 1102 |
| Sheet printing is selected. | |
| Regular printing is selected, but a roll is loaded. | |
| | |
| Paper loaded askew. | |
| Cannot feed paper. | |
| Cannot cut this paper. | |
| End of paper feed. | |
| Rel lever is in wrong position. | 1104 |
| Rewinding error. | 1105 |
| Media take-up unit ready. | |
| Turn on the media take-up unit. | |
| Borderless printng not possible. | 1105 |
| Paper position not suitable for borderless printing. | |
| | |

Paper mismatch

| Cause | Corrective Action |
|--|--|
| You tried to print a test pattern for printer adjustment on several sheets, but sheets of different types or sizes of paper were used. | When printing a test pattern for adjustment, use sheets of the same size and type of paper, in the required quantity. Press ▲ or ▼ to select Change Paper, press the OK button, and replace the paper. (See "Loading and Printing on Sheets.") →P.9 The printer now starts printing the test pattern. |
| | Replace the paper as follows and perform adjustment again. Press ▲ or ▼ to select Stop Printing, and then press the OK button. Replace the paper. (See "Loading and Printing on Sheets.") →P.9 Execute adjustment again from the control panel menu. |

iPF8300S

MediaType Mismatch

| Cause | Corrective Action |
|--|--|
| When Detect Mismatch in the Control Panel menu is set to Pause , the type of paper loaded does not match the type specified in the printer driver. | Follow these steps to ensure the paper type matches on the printer and in the printer driver. |
| | 1. Press ▲ or ▼ to select Stop Printing , and then press the OK button. |
| | 2. Change the paper type setting in the printer driver to the type loaded in the printer and try printing again. |
| | Follow these steps to ensure the paper type matches on the printer and in the printer driver. |
| | 1. Press ▲ or ▼ to select Change Paper, and then press the OK button. |
| | 2. Replace the loaded paper with paper of the type and size you have specified in the printer driver. (See "Loading and Printing on Rolls.") →P.5 (See "Loading and Printing on Sheets.") →P.9 |
| | Press ▲ or ▼ to select Print , and then press the OK button to resume printing. However, note that this error may cause paper jams and affect the printing quality. |
| You tried to print a test pattern for printer adjustment on several sheets, but sheets of different types of paper were used. | When printing a test pattern for adjustment, use sheets of the same type of paper, in the required quantity. Replace the paper as follows and perform adjustment again. |
| | 1. Lift the Release Lever and stop printing. |
| | 2. Replace the paper. (See "Loading and Printing on Sheets.") →P.9 |
| | 3. Execute adjustment again from the control panel menu. |
| When Detect Mismatch in the Control Panel menu is set to Warning , the type of paper loaded does not match the type specified in the printer driver. | You can continue to print, but note that this error may cause problems in the printing results. |

13

1096

The paper is too small.

| Cause | Corrective Action |
|--|--|
| When Detect Mismatch in the Control Panel menu is set to Pause or Hold Job , paper smaller than the size specified in the printer driver is loaded. | Press ▲ or ▼ to select Print , and then press the OK button to resume printing. However, note that this error may cause paper jams and affect the printing quality. |
| | Adjust the paper size setting in the printer driver to match the size loaded in the printer as follows. |
| | 1. Press ▲ or ▼ to select Stop Printing , and then press the OK button. |
| | 2. Change the paper size setting in the printer driver to the size loaded in the printer and try printing again. |
| | Replace the loaded paper with paper of a size that matches the size setting in the printer driver as follows. |

MediaType Mismatch iPF8300S

| Cause | Corrective Action |
|--|--|
| When Detect Mismatch in the Control Panel menu is set to Pause or Hold Job , paper smaller than the size specified in the printer driver is loaded. | Press ▲ or ▼ to select Change Paper, and then press the OK button to stop printing. Replace the loaded paper to match the paper width setting in the printer driver and try printing again. |
| When Detect Mismatch in the Control Panel menu is set to Warning , paper smaller than the size specified in the printer driver is loaded. | You can continue to print, but note that this error may cause problems in the printing results. |

The paper is too small.

"Replace paper with A4/LTR (vertical) or larger"

| Cause | Corrective Action |
|---|---|
| The loaded paper is too small. (When you have attempted to print a test print sheet or other printer status information.) | Replace the paper with paper of A4/Letter (vertical) size or larger as follows. 1. Press ▲ or ▼ to select Change Paper, press the OK button, and remove the paper. (See "Removing Sheets.") →P.820 |
| | 2. Switch to paper A4/Letter (vertical) or larger. (See "Loading and Printing on Sheets.") →P.9 The printer will resume printing. Press ▲ or ▼ to select Stop Printing, and then press the OK button. |

"Replace roll with 10 in. wide or larger roll."

| Cause | Corrective Action |
|---|---|
| The loaded paper is too small. (When you have attempted to print a test print sheet or other printer status information.) | Replace the roll with a roll 10 inches in width or larger as follows. 1. Press ▲ or ▼ to select Change Paper, and then press the OK button. (See "Removing the Roll from the Printer.") →P.794 (See "Removing the Roll Holder from Rolls.") →P.797 |
| | 2. Replace the roll with a roll 10 inches wide or larger. (See "Attaching the Roll Holder to Rolls.") →P.782 (See "Loading Rolls in the Printer.") →P.786 The printer will resume printing. |
| | Press ▲ or ▼ to select Stop Printing , and then press the OK button. |

PaprWidth Mismatch

| Cause | Corrective Action |
|--|--|
| When Detect Mismatch in the Control Panel menu is set to Pause or Warning , the width of the loaded roll does not match the width specified in Fit Roll Paper Width in the printer driver. | Press ▲ or ▼ to select Print , and then press the OK button to resume printing. However, note that this error may cause paper jams and affect the printing quality. |

iPF8300S The paper is too small.

Paper size not detected.

Cause Corrective Action Paper has been loaded askew, or warped paper has been loaded. Follow these steps to reload the roll. 1. Lift the Release Lever 2. Adjust the right edge of the roll to make it parallel to the right Paper Alignment Line. 3. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the **OK** button. Printing will resume, starting from the page on which the error occurred. (See "Loading Rolls in the Printer.") →P.786 If this error recurs after you reload the roll, remove the Roll Holder from the printer, push the roll firmly in until it touches the Roll Holder flange, and reload the Roll Holder in the printer. (See "Attaching the Roll Holder to Rolls.") →P.782 Follow these steps to reload the sheet. 1. Lift the Release Lever. 2. Adjust the right edge of the sheet to make it parallel to the right Paper Alignment Line and the trailing edge of the sheet to make it parallel to the paper alignment line under the Paper Retainer 3. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the **OK** button.

13

| Cause | Corrective Action |
|---|---|
| Paper has been loaded askew, or warped paper has been loaded. | Printing will resume, starting from the page on which the error occurred. (See "Loading Sheets in the Printer.") →P.813 |
| Because the Platen is soiled with ink or other substances, the size of the clear film cannot be detected. | Open the Top Cover and clean the entire Platen. (See "Cleaning Inside the Top Cover.") >P.1040 |

iPF8300S Paper size not detected.

Insufficient paper for job

Cause Corrective Action The printer has received a print job longer than the amount of roll paper Press ▲ or ▼ to select **Print**, and then left when ManageRemainRoll in the Control Panel menu is On. press the **OK** button to resume printing. When using the Media Take-up Unit, press ▲ or ▼ to select **Print**, and then press the **OK** button to resume printing. However, the roll paper may run out during the print job and you may not be able to print all of the document. Press ▲ or ▼ to select Change Paper, and then press the **OK** button. Change the **Paper Source** of the printer driver, or replace the roll with a roll that has enough paper for the print job, and then printt. When using the Media Take-up Unit, press ▲ or ▼ to select **Stop Printing**, and then press the **OK** button to stop printing. Remove the printed document from the Media Take-up Unit, replace the roll with a roll that has enough paper for the print job, and then try printing again. (See "Removing the Roll from the Printer.") →P.794 (See "Loading Rolls in the Printer.") →P.786 (See "Removing Printed Documents from the Media Take-up Unit (Optional).") →P.842

13

This paper cannot be used as size is not supported.

| Cause | Corrective Action | |
|--|---|--|
| Paper that is too large for the printer has been loaded. | Lift the Release Lever and load paper of the correct size. (See "Paper Sizes.") —P.775 | |
| Paper that is too small for the printer has been loaded. | Lift the Release Lever and load paper of the correct size. (See "Paper Sizes.") P.775 | |
| Paper has been loaded that is too small to print the test pattern for printhead adjustment or noz- zle checking. | Lift the Release Lever and load unused paper A4/Letter (vertical) or larger. More than one sheet may be required depending on the adjustment. | |

Press ▲ or ▼ to select **Stop Printing** or press the **Stop** button to stop printing.

1100

Insufficient paper for job iPF8300S

Roll printing is selected.

| Cause | Corrective Action |
|---|---|
| You have attempted to print on a roll, but no roll is loaded. | Press ▲ or ▼ to select Load Roll Paper , and then press the OK button. Load the roll, and then print. (See "Attaching the Roll Holder to Rolls.") →P.782 (See "Loading Rolls in the Printer.") →P.786 |
| | Press ▲ or ▼ and select Stop Printing or press the Stop button to stop printing. |

Roll printing is selected, but sheets are loaded.

| Cause | Corrective Action | |
|--|---|--|
| A print job for rolls was received when a sheet is loaded. | Follow these steps to load and print on a roll. 1. Press ▲ or ▼ to select Eject Paper, press the OK button, and remove the sheet. (See "Removing Sheets.") →P.820 | |
| | 2. Load a new roll. (See "Loading Rolls in the Printer.") →P.786 The printer now starts printing the print job. | |
| | Press ▲ or ▼ to select Stop Printing , and then press the OK button. | |

The roll is empty.


| Cause | Corrective Action |
|--|---|
| The roll is empty. | Follow these steps to replace the used roll with a new roll of the same type and size. |
| | 1. Lift the Release Lever and remove the roll. (See "Removing the Roll from the Printer.") →P.794 (See "Removing the Roll Holder from Rolls.") →P.797 |
| | 2. Load the new roll. (See "Attaching the Roll Holder to Rolls.") P.782 (See "Loading Rolls in the Printer.") P.786 |
| | 3. If no barcode was printed on the roll, specify the type of paper. (See "Changing the Type of Paper.") →P.791 |
| | 4. When you have selected ManageRemainRoll > On in the control panel menu and a barcode is not printed on the roll, also specify the paper length. (See "Specifying the Paper Length.") →P.793 |
| | 5. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button. Printing will resume, starting from the page on which the error occurred. |
| There is remaining roll paper, but because it could not be advanced, it could not be detected. | The unused portion of the roll is heavy, and this is placing a burden on the printer. It may be helpful to change the printing mode, which will change the paper feed timing. Choose a higher level of Print Quality in the Advanced Settings of the printer driver. (See "Giving Priority to Particular Graphic Elements and Colors for Printing.") P.64 |

13

1101

iPF8300S Roll printing is selected.

No sheets.



Sheet printing is selected.

| Cause | Corrective Action |
|---|---|
| You have attempted to print on a sheet, but no sheet is loaded. | Press ▲ or ▼ to select Load Paper , and then press the OK button. Load a sheet, and then print. (See "Loading and Printing on Sheets.") →P.9 |
| | Press ▲ or ▼ and select Stop Printing or press the Stop button to stop printing. |

Regular printing is selected, but a roll is loaded.


| Cause | Corrective Action |
|--|---|
| A print job for printing on sheets was sent when a roll is | 1. Press ▲ or ▼ to select Remove Roll Paper , and then press the OK button to stop printing. |
| loaded. | 2. After removing the roll, load and print on a sheet of the type and size of paper you have specified in the printer driver. (See "Removing the Roll from the Printer.") P.794 (See "Loading and Printing on Sheets.") P.9 |
| | Press ▲ or ▼ to select Stop Printing , and then press the OK button to stop printing. |
| You are using a roll with the | 1. Press the OK button to stop printing. |
| Media Take-up Unit, but a print job requiring sheets was sent. | 2. After removing the roll, load and print on a sheet of the type and size of paper you have specified in the printer driver. (See "Removing the Roll from the Printer.") —P.794 (See "Loading and Printing on Sheets.") —P.9 |

1102

13

No sheets. iPF8300S

Paper loaded askew.





Important

• To disable this message (if it is displayed repeatedly despite reloading paper, for example), choose **Off** or **Loose** in the **Skew Check Lv.** setting of the printer menu. However, this may cause jams and printing problems because paper may be askew when printed. Also, the Platen may become soiled, which may soil the back of the next document when it is printed.

Cannot feed paper.

| Cause | Corrective Action |
|--|---|
| Paper could not be advanced cor- rectly during | 1. Lift the Release Lever and remove the jammed paper. (See "Clearing Jammed Roll Paper.") →P.1057 (See "Clearing a Jammed Sheet.") →P.1061 |
| feeding. | 2. Load paper. |
| | 3. Lower the Release Lever. |
| | 4. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button. |
| | Printing will resume, starting from the page on which the error occurred. |
| | (See "Loading Rolls in the Printer.") →P.786 (See "Loading Sheets in the Printer.") →P.813 |

iPF8300S Paper loaded askew.

Cannot cut this paper.

| Cause | Corrective Action |
|--|---|
| There are sheets left on the | 1. Lift the Release Lever and remove the paper. |
| Ejection Guide. | 2. Load paper. |
| | 3. Lower the Release Lever. |
| | 4. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button. Printing will resume, starting from the page on which the error occurred. |
| | (See "Loading Rolls in the Printer.") →P.786 |
| There is a foreign object by | 1. Lift the Top Cover and remove the foreign object. |
| the Output Tray, obstructing the Cutter Unit. | 2. If "Not finished printing. Finish printing remaining jobs?" is shown on the Display Screen, press the OK button. Printing will resume, starting from the page on which the error occurred. |
| You are not using the print- er under the recommended environmental conditions for the paper. | Use the printer only where the recommended environmental conditions for the paper are met. Note that various environmental conditions are recommended for various types of paper. For details on the recommended environmental conditions, see the Paper Reference Guide. (See Paper Reference Guide .) |
| You are using paper that is not compatible with automatic cutting. | Specify Manual as the cutting method and use scissors or a cutting tool to cut the roll. (See "Specifying the Cutting Method for Rolls.") P.802 For information about paper that is compatible with automatic cutting, see the Paper Reference Guide. (See Paper Reference Guide .) Lift the Release Lever and remove the paper. |
| In other cases, the Cutter Unit may be damaged. | Contact your Canon dealer for assistance. |

End of paper feed.

| Cause | Corrective Action |
|---|-----------------------|
| You are pressing the ▲ button on the Control Panel and trying to rewind the roll to the edge. | Release the ▲ button. |
| Paper can be retracted only up to 17 mm (0.7 in) when using the Media Take-up Unit. | Release the ▲ button. |

Rel lever is in wrong position.

| Cause | Corrective Action | |
|--------------------------|--|--|
| The Release Lever is up. | Lower the Release Lever. | |
| | If the error occurs again, turn off the printer and wait a while before restoring power. | |

Cannot cut this paper. iPF8300S

13

Rewinding error.

| Cause | Corrective Action |
|--|--|
| There is some foreign object near the Media Take-up Unit sensor and the roll cannot be detected. | Remove the foreign object near the sensor. |
| The Media Take-up Unit sensor is soiled and the roll cannot be detected. | Wipe the sensor with a dry cloth to clean it. |
| The roll is out of range of detection by the Media Take-up Unit sensor. | Reload the roll. (See "Loading Rolls in the Printer.") →P.786 |
| A paper jam has occurred and the roll cannot be rewound. | Remove the paper from the Media Take-up Unit. Press the OK button to clear the error. |
| The Media Take-up Unit sensor is damaged. | Contact your Canon dealer for assistance. |

^{*1:} Printing will stop momentarily if an error involving the Media Take-up Unit occurs. If you prefer printing not to stop, set **Skip Take-Up Err** to **On**. However, note that this error may cause paper jams and affect the printing quality.

Media take-up unit ready.

| Cause | Corrective Action |
|---|--|
| The Take-up Reel setting in the printer Set./Adj. Menu was changed from Enable to Disable , but a print job was received before the roll was removed. | Press ▲ or ▼ to select Stop Printing , and then press the OK button to stop printing. The mode switches from take-up mode to regular mode after you change the Take-up Reel setting in the Set./Adj. Menu from Enable to Disable and lift the Release Lever to remove a roll, or after you execute Paper Cutting . |
| | Press ▲ or ▼ to select Print , and then press the OK button to resume printing. |

Turn on the media take-up unit.

| Cause | Corrective Action |
|--|---------------------------------|
| The Media Take-up Unit was off when you selected Enable for Take-up Reel . | Turn the Media Take-up Unit on. |

Borderless printng not possible.

| Cause | Corrective Action |
|--|--|
| The print job received specifies a type or width of paper that is not compatible with borderless printing. | Follow these steps to change the settings of the print job to enable borderless printing. Press ▲ or ▼ to select Stop Printing, and then press the OK button. Make sure the correct printer driver for the printer is selected and try printing again. For information on types of paper compatible with borderless printing, refer to the Paper Reference Guide. (See Paper Reference Guide .) |

iPF8300S Rewinding error.

| Cause | Corrective Action |
|--|--|
| The print job received specifies a type or width of paper that is not compatible with borderless printing. | Select None when you have set Detect Mismatch on the control panel to Warning . However, note that this error may cause paper jams and affect the printing quality. |
| | Press ▲ or ▼ to select Print With Border , and then press the OK button to continue printing. The document will be printed with a border. |
| The loaded paper is a size not | Press ▲ or ▼ to select Stop Printing , and then press the OK button. |
| compatible with borderless printing. | Replace the paper with paper compatible for borderless printing as follows. 1. Press ▲ or ▼ to select Change Paper, and then press the OK button. (See "Removing the Roll from the Printer.") →P.794 (See "Removing the Roll Holder from Rolls.") →P.797 |
| | 2. Replace the paper with paper compatible for borderless printing. (See "Attaching the Roll Holder to Rolls.") —P.782 (See "Loading Rolls in the Printer.") —P.786 The printer now starts printing the print job. For information on types of paper compatible with borderless printing, refer to the Paper Reference Guide. (See Paper Reference Guide .) |
| | Press ▲ or ▼ to select Print With Border , and then press the OK button to continue printing. The document will be printed with a border. |


Paper position not suitable for borderless printing.

| Cause | Corrective Action |
|---|--|
| Because paper expands or contracts depending on the environment of use, it may become narrower or wider than the supported width for borderless printing. | Press ▲ or ▼ to select Stop Printing , and then press the OK button. Use each type of paper only where the recommended environmental conditions are met. For details on environmental conditions for various paper, see the Paper Reference Guide. (See Paper Reference Guide .) |
| | Select None when you have set Detect Mismatch in the Control Panel menu to Warning . However, note that this error may affect the printing quality. |
| The paper is loaded askew. | Press ▲ or ▼ to select Change Paper and straighten the paper so that the edges are between the ink grooves for borderless printing. Insert the roll firmly until it touches the flange of the Roll Holder. (See "Attaching the Roll Holder to Rolls.") →P.782 |
| | Select None when you have set Detect Mismatch in the Control Panel menu to Warning . However, note that this error may affect the printing quality. |
| | Press ▲ or ▼ to select Print With Border , and then press the OK button to continue printing. The document will be printed with a border. |
| | Press ▲ or ▼ to select Stop Printing , and then press the OK button. |

Messages regarding ink

| Ink insufficient. | 1107 |
|--|------|
| No ink left. | 1107 |
| Remaining level of the ink cannot be correctly detected. | 1107 |
| Close Ink Tank Cover | 1108 |
| Ink tank is empty. | |
| Not much ink is left. | |
| No ink tank loaded. | |
| Wrong ink tank. | |

Ink insufficient.



No ink left.


| Cause | Corrective Action |
|-----------------------|--|
| There is no ink left. | Open the Ink Tank Cover and replace the Ink Tank for which the Ink Lamp is flashing. (See "Replacing Ink Tanks.") —P.997 |

Remaining level of the ink cannot be correctly detected.


| Cause | Corrective Action |
|--|---|
| Ink level detection cannot work correctly if you use refill ink tanks. | The refill ink tank can no longer be used. See the section Ink level detection and take the appropriate action. (See "Ink Level Detection.") →P.1089 |

iPF8300S Ink insufficient.

Close Ink Tank Cover



Ink tank is empty.




1108

13


Close Ink Tank Cover iPF8300S

13

Not much ink is left.



No ink tank loaded.



Wrong ink tank.

| Cause | Corrective Action |
|--|--|
| The Ink Tank in the printer is incompatible. | Load an Ink Tank specified for use with the printer. (See "Replacing Ink Tanks.") -P.997 |

iPF8300S Not much ink is left.

Messages regarding printing or adjustment

| Cannot execute this command. Use other paper. | 1110 |
|--|------|
| Cannot calibrate. | 1110 |
| Excessive temperature or humidity. | 1111 |
| Please execute calibration. | |
| Please calibrate using above paper | 1111 |
| Borderless printng not possible. Paper stretched or shrank | |
| Blue platen switch is dirty. | |
| Move the blue platen switch No.xx to the right. (xx represents a number) | 1112 |
| Cannot adjust paper feed. | 1112 |
| Check printed document. | |

Cannot execute this command. Use other paper.

| Cause | Corrective Action |
|--|--|
| Paper compatible with color calibration is not loaded. | Press the OK button to clear the error. Load paper that is compatible with color calibration. See the Paper Reference Guide. (See Paper Reference Guide .) Always make sure the loaded paper matches the type of paper in the printer paper settings. Ad- |
| | justment cannot be completed correctly unless the loaded paper matches the settings. |

Cannot calibrate.

| Cause | Corrective Action |
|---|--|
| The paper for printing a test pattern is soiled. Otherwise, you have loaded colored paper. | Press the OK button to clear the error. Load unused paper compatible with color calibration. (See Paper Reference Guide .) |
| The test pattern was printed too faintly. | Press the OK button to clear the error. Take steps to remedy faint printing. (See "Printing is faint.") P.1071 |
| Direct sunlight or strong lighting may be shin- ing on the printer and causing the sensor to malfunction. | Press the OK button to clear the error. Take steps to ensure the printer is not used when exposed to direct sunlight or strong lighting. |

1110

Excessive temperature or humidity.

| Cause | Corrective Action |
|--|---|
| The temperature or humidity where the printer is installed is out of the acceptable range for operation. | Press ▲ or ▼ to select Stop , and then press the OK button to stop printing. Use the printer under suitable environmental conditions. Also note that various environmental conditions are recommended for various types of paper. For details on the recommended environmental conditions, see the Paper Reference Guide. (See Paper Reference Guide .) |
| | Press ▲ or ▼ to select Continue , and then press the OK button to continue with color calibration. However, note that correct adjustment may not be possible. |

Please execute calibration.

| Cause | Corrective Action |
|---|--|
| There is not even one color calibration execution result. This is displayed when paper is loaded in the printer and "Set Exec. Guide" is set to On on the Control Panel menu. | Execute color calibration. (See "Using Color Calibration for Color Adjustment.") —P.865 |
| | Set "Set Exec. Guide" to Off on the Control Panel menu. (See "Menu Structure.") →P.928 |

Please calibrate using above paper.

| Cause | Corrective Action |
|---|---|
| It has become the time for prompting the execution of color calibration. This is displayed when paper is loaded in the printer and "Set Exec. Guide" is set to On on the Control Panel menu. | Execute color calibration. (See "Using Color Calibration for Color Adjustment.") —P.865 |
| | Set "Set Exec. Guide" to Off on the Control Panel menu. (See "Menu Structure.") -P.928 |

Borderless printng not possible. Paper stretched or shrank.

| Cause | Corrective Action |
|---|--|
| The loaded roll has expanded or contracted due to environmen- | Press the OK button to stop printing. |
| tal conditions, making it wider or narrower than the supported width for borderless printing. | Use each type of paper only where the recommended environmental conditions are met. For details on environmental conditions for various paper, see the Paper Reference Guide. (See Paper Reference Guide .) |

Before borderless printing, move the blue platen switch.

| Cause | Corrective Action |
|--|--|
| The blue Switch on the platen was set to the side opposite • when a borderless print job was received. | Before borderless printing, set the blue Switch on the platen to the ● side. (See "Setting the Blue Switch on the Platen.") →P.1078 |

Blue platen switch is dirty.

| Cause | Corrective Action |
|---|--|
| The blue Switch on the platen is dirty. | Open the Top Cover and clean the blue Switch on the platen. (See "Cleaning Inside the Top Cover.") →P.1040 |

Move the blue platen switch No.xx to the right. (xx represents a number)

| Cause | Corrective Action |
|--|---|
| The printer has detected that the blue Switch on the platen needed in maintenance during printing is set away from the ● mark. | Set blue platen Switch of the indicated number toward the ● side. (See "Setting the Blue Switch on the Platen.") →P.1078 |

Cannot adjust paper feed.

| Cause | Corrective Action |
|---|---|
| The Printhead nozzles are clogged. | Execute Adj. Quality again, as follows. |
| | 1. Press the OK button to clear the error. |
| | 2. Print a test pattern to check the nozzles. (See "Checking for Nozzle Clogging.") →P.1011 |
| | 3. Clean the Printhead if the nozzles are clogged. (See "Cleaning the Printhead.") →P.1012 |
| | 4. Execute Adj. Quality again. (See "Automatic Banding Adjustment (Adj. Quality).") →P.857 |
| Highly transparent film is loaded that cannot be used for automatic feed amount adjustment. | Press the OK button to clear the error, and then adjust the feed amount manually. (See "Manual Banding Adjustment (Adj. Quality).") →P.859 |

1112

Check printed document.

| Cause | Corrective Action |
|---|---|
| The Printhead nozzles are becoming clogged. | If printing is faint, clean the Printhead. (See "Cleaning the Printhead.") →P.1012 |

Messages regarding printheads

| Cannot adjust printhead. | |
|--|------|
| PHeads: wrong pos. | 1113 |
| Wrong x printhead. (x is L, R, or not displayed) | |
| x printhead error (x is L, R, or not displayed) | 1114 |
| No x printhead (x is L, R, or not displayed) | 1114 |
| Execute printhead cleaning. | 1114 |

Cannot adjust printhead.

| Cause | Corrective Action |
|---|--|
| The Printhead nozzles are clogged. | Execute Head Posi. Adj. again, as follows. 1. Press the OK button to clear the error. |
| | 2. Print a test pattern to check the nozzles. (See "Checking for Nozzle Clogging.") →P.1011 |
| | 3. Clean the Printhead if the nozzles are clogged. (See "Cleaning the Printhead.") →P.1012 |
| | 4. Execute Head Posi. Adj. again. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") →P.850 |
| The Printhead cannot be aligned; highly transparent film is loaded. | Press the OK button to clear the error. We recommend using a type of paper that you often use, other than film, for Printhead adjustment. (See "Automatic Adjustment to Straighten Lines and Colors (Head Posi. Adj.).") →P.850 |

PHeads: wrong pos.

| Cause | Corrective Action |
|--|--|
| The printheads are installed in the wrong positions. | Open the Top Cover and switch the Printhead used once in the right side to the right side. Switch the Printhead used once in the left side to the left side. |

Wrong x printhead. (x is L, R, or not displayed)

| Cause | Corrective Action |
|---|--|
| An incompatible Printhead has been installed. | Open the Top Cover. Replace the Printhead L with a new one if Printhead L is displayed and the Printhead R if Printhead R is displayed. If neither left or right is indicated, replace both Printhead L and Printhead R with new ones. (See "Replacing the Printhead.") →P.1013 |

x printhead error (x is L, R, or not displayed)

| Cause | Corrective Action | |
|-------------------------|---|--|
| There is a prob- | Follow these steps to replace the Printhead. | |
| lem with the Printhead. | 1. Open the Top Cover. | |
| | 2. Replace the Printhead L with a new one if Printhead L is displayed and the Printhead R if Printhead R is displayed. If neither left or right is indicated, replace both Printhead L and Printhead R with new ones. (See "Replacing the Printhead.") →P.1013 | |
| | Follow these steps to replace the Printhead. | |
| | 1. Turn off the printer, wait a while, and then turn it on again. | |
| | 2. Open the Top Cover. | |
| | 3. Replace the left printhead with a new one if Printhead L is displayed and the right one if Printhead R is displayed. If neither left or right is indicated, replace both printheads. (See "Replacing the Printhead.") →P.1013 | |

No x printhead (x is L, R, or not displayed)

| Cause | Corrective Action |
|----------------------------|--|
| No Printhead is installed. | Install the Printhead L if Printhead L is displayed and the Printhead R if Printhead R is displayed. If neither left or right is indicated, install both Printhead L and Printhead R. (See "Replacing the Printhead.") →P.1013 |

Execute printhead cleaning.

| Cause | Corrective Action |
|--------------------|--|
| The Printhead noz- | Follow these steps to clean the Printhead. |
| zles are clogged. | 1. Stop printing by pressing ▲ or ▼ to select Stop Printing . |
| | 2. Clean the Printhead. (See "Cleaning the Printhead.") →P.1012 |
| | If the message is still displayed when printing, replace the Printhead. (See "Replacing the Printhead.") →P.1013 |
| | Press ▲ or ▼ to select Print , and then press the OK button to resume printing. However, note that this error may affect the printing quality. |
| | If OK is shown on the Display Screen, clean the Printhead. |
| | 1. Press the OK button on the Control Panel to stop printing. |
| | 2. Clean the Printhead. (See "Cleaning the Printhead.") →P.1012 |
| | If the message is still displayed when printing, replace the Printhead. (See "Replacing the Printhead.") —P.1013 |

13

13

Messages regarding the maintenance cartridge

| No maintenance cartridge | |
|------------------------------------|------|
| Wrong maintenance cartridge. | |
| Maint. cart. The level is low | 1115 |
| No Maintenance Cartridge capacity. | |
| Maintenance cartridge full. | |
| Maintenance cartridge problem. | |

No maintenance cartridge.

| Cause | Corrective Action |
|---|--|
| The Maintenance Cartridge is not installed. | Install the Maintenance Cartridge. (See "Replacing the Maintenance Cartridge.") →P.1028 |

Wrong maintenance cartridge.

| Cause | Corrective Action |
|--|--|
| A Maintenance Cartridge for a different model of printer is installed. | Replace it with the Maintenance Cartridge for your particular model. |

Maint. cart. The level is low

| Cause | Corrective Action | |
|---|--|--|
| The Maintenance Cartridge is almost full. | You can continue to print, but prepare a new Maintenance Cartridge to use when the message for replacement is displayed. | |

No Maintenance Cartridge capacity.

| Cause | Corrective Action |
|---|--|
| The Maintenance Cartridge cannot absorb enough ink for Printhead cleaning or other operation. | After confirming that the printer has stopped operating, replace the Maintenance Cartridge. (See "Replacing the Maintenance Cartridge.") P.1028 |

Maintenance cartridge full.

| Cause | Corrective Action |
|------------------------------------|--|
| The Maintenance Cartridge is full. | After confirming that the printer has stopped operating, replace the Maintenance Cartridge. (See "Replacing the Maintenance Cartridge.") →P.1028 |

iPF8300S

Maintenance cartridge problem.

| Cause | Corrective Action |
|---|--|
| An incompatible or used Maintenance Cartridge has been installed. | Install an unused Maintenance Cartridge specified for use with the printer. (See "Replacing the Maintenance Cartridge.") —P.1028 |

13

1117

Messages regarding the hard disk

| Hard disk error. | |
|---|------|
| File read error. | 1117 |
| The mail box is full. | |
| Mail box full. Now printing without saving data | |
| Mail box nearly full. | |
| Maximum jobs stored. | |
| Mail box full. Delete unwanted data | |

Hard disk error.

| Cause | Corrective Action |
|---|--|
| The format of the printer's hard disk is invalid. | Press the OK button to start reformatting the hard disk. When formatting is finished, data on the printer hard disk is erased and the printer automatically restarts. |

File read error.

| Cause | Corrective Action |
|---|--|
| Files on the printer's hard disk have become corrupted. | Restart the printer. Only the corrupted files will be deleted, and the printer will restart. |

The mail box is full.

| Cause | Corrective Action |
|--|---|
| There is no more space on the printer's hard disk. | Press the Stop button and stop printing. |
| | Delete print jobs from the queue. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") →P.725 |
| | Delete unneeded jobs stored in personal boxes. (See "Deleting Saved Jobs.") →P.737 |

Mail box full. Now printing without saving data.

| Cause | Corrective Action |
|--|---|
| ted without saving them (Print jobs can no longer be saved on the hard | After printing, this message is cleared. |
| | Delete unneeded jobs stored in personal boxes. (See "Deleting Saved Jobs.") →P.737 |

iPF8300S Hard disk error.

Mail box nearly full.

| Cause | Corrective Action |
|---|---|
| The free hard disk space left for Personal Boxes in the printer's hard disk does not have more than 1 GB, combined. | Delete unneeded jobs stored in Personal Boxes. (See "Deleting Saved Jobs.") →P.737 |

Maximum jobs stored.

| Cause | Corrective Action |
|--|--|
| 100 jobs are stored in the personal box. | Delete unneeded jobs stored in personal boxes. (See "Deleting Saved Jobs.") →P.737 |

Mail box full. Delete unwanted data

| Cause | Corrective Action |
|--|--|
| 100 jobs are stored in the Personal Box. | Press the Stop button and stop printing. |
| | Delete print jobs from the queue. (See "Managing the Job Queue (Deleting or Preempting Other Jobs).") →P.725 |
| | Delete unneeded jobs stored in personal boxes. (See "Deleting Saved Jobs.") →P.737 |

13

1118

Mail box nearly full. iPF8300S

Other Messages

| GARO Wxxxx (x represents a number) | |
|---|------|
| Hardware error. xxxxxxxx-xxxx (x represents a letter or number) | |
| Top cover is open. | 1120 |
| Prepare for parts replacement | |
| Unknown file. | 1120 |
| Calibration There is a problem with the multi-sensor. | |
| Multi-sensor error | 1121 |

GARO Wxxxx (x represents a number)

| Cause | Corrective Action |
|--|---|
| There is a problem with the print job. | Try printing again, using the correct printer driver. |
| | It is also possible to continue printing in this state. However, you may not be able to obtain the desired printing results. |

ERROR Exxx-xxxx (x represents a letter or number)

| Cause | Corrective Action |
|--|--|
| An error requiring service may have occurred. • ERROR Exxx-xxxx | Write down the error code and message, turn off the printer, and contact your Canon dealer for assistance. |
| Call for service. | |
| OK: Printer Info. | |

Hardware error. xxxxxxxx-xxxx (x represents a letter or number)

| Cause | Corrective Action |
|---|--|
| The last portion of roll paper was used during a print job. The paper was not advanced because the trailing edge is taped to the roll. | Turn off the printer and remove the roll from the printer before restoring power. |
| Fastening tape or the Belt Stopper has not been removed inside the Top Cover. | Turn off the printer, open the Top Cover and remove the tape or the Belt Stopper before restoring power. |

| Cause | Corrective Action |
|--|---|
| An error requiring service may have occurred. I Hardware error. xxxxxxxxxxxxx Turn off printer, wait, then turn on again. OK: Printer Info. | Turn off the printer and wait at least three seconds before restoring the power. If the message is displayed again, write down the error code and message, turn off the printer, and contact your Canon dealer for assistance. |

Top cover is open.

| Cause | Corrective Action |
|--|--|
| The printer has detected that the Top Cover is open. | Open the Top Cover fully, remove any foreign objects, and close the Top Cover again. |
| | If the error occurs again, turn off the printer and wait a while before restoring power. |

Prepare for parts replacement.

| Cause | Corrective Action |
|---|---|
| It is almost time to replace consumables for which service is required. | If "Parts replacement time has passed." is displayed, you can continue to use the printer for some time. Contact your Canon dealer for assistance. |

Parts replacement time has passed.

| Cause | Corrective Action |
|---|---|
| It is past the recommended time to replace consumables for which service is required. | Contact your Canon dealer for assistance. |

Unknown file.

| 4 | 20 | |
|---|----|--|
| | 20 | |

13

| Cause | Corrective Action |
|--|---|
| Data sent to keep the printer up to date (such as paper information) is in the wrong format. | Check the data. Turn off the printer and wait a while before restoring power, and then resend the data. |
| You have uploaded firmware for a different model. | Check the firmware version. Turn off the printer and wait a while before restoring power, and then resend the firmware. |
| | If the message is displayed again, contact your Canon dealer for assistance. |

Top cover is open. iPF8300S

Calibration There is a problem with the multi-sensor.

| Cause | Corrective Action |
|---|--|
| The performance of a sensor inside the printer may be impaired. | Press the OK button and cancel calibration. Contact your Canon dealer for assistance. |

Multi-sensor error


| Cause | Corrective Action |
|---|--|
| Direct sunlight or strong lighting may be shin- ing on the printer and causing the sensor to malfunction. | Take steps to ensure the printer is not used when exposed to direct sunlight or strong lighting. |
| The performance of a sensor inside the printer may be impaired. | Turn off the printer and wait at least three seconds before restoring the power. If the message is displayed again, contact your Canon dealer for assistance. |

Specifications

Printer Specifications

1123

14



Printer Specifications

| Specifications | 1123 |
|----------------|------|
| Print Area | 1126 |

Specifications



Important

• The following values may vary depending on the operating environment.

Printer

| Power supply | | 100–120 V AC (50/60 Hz), 220–240 V AC (50/60 Hz) |
|--|---|---|
| Power consumption | During operation | 190 W max. |
| | Sleep mode | 100–120 V: 5 W max. |
| | | 220–240 V: 6 W max. |
| | Off | 1 W max. (*1 →P.1123) |
| Operating noise (*2 →P.1123) | During operation (sound pressure level/LWAd) | Approx. 50 dB (A) (6.8 bels) |
| | Standby | 35 dB (A) max. |
| Operating environment | Temperature | 15–30°C (59–86°F) |
| | Humidity | 10-80%, non-condensing |
| Dimensions (W \times D \times H) | Printer and Stand (including the Roll Holder and Output Stacker) | 1,893×975×1,144 mm (74.5×38.4×45.0 in) |
| Weight Printer and Stand (not including Printhead and ink tanks) | | Approx. 143 kg (315.3 lb) |
| Space for installation (W \times D \times H) | Printer only 2,293×1,675×1,500 mm (90.3×65.9×59.1 in) | |
| Applicable standards | International Energy Star, Law on Promoting Green Purchasing (Japan), Eco Mark, GPN, EU RoHS, The Eco Declaration (Europe), WEEE, U.S. presidential directives, ErP Lot6 (Europe) | |

^{*1:} The printer uses a trace amount of power even when turned off. To stop all power consumption, turn off the printer and unplug the power cord.

Printing performance

| Print method | Bubblejet | |
|---|--|--|
| Maximum resolution | timum resolution 2400 dpi horizontally (*1 →P.1124) × 1200 dpi vertically | |
| Printhead | PF-05 ×2 | |
| Number of nozzles C,PC,PM,GY: 2560 nozzles X 2 BK,MBK,M,Y: 2560 nozzles X 1 | | |

iPF8300S Specifications

14

^{*2:} Calculation based on ISO 7779. Operating conditions: On the **Main** sheet of the printer driver, **Media Type** > **Coated Paper**, **Advanced Settings** > **Print Priority** > **Image**, and **Print Quality** > **Standard**.

*1: Prints with a minimum 1/2400 inch dot pitch between ink droplets.

Interface

| Hi-Speed USB | Format | Internal port |
|------------------|---------------|--|
| | Mode | Full-speed (12 Mbps), high-speed (480 Mbps), bulk transfer |
| | Connector | Series B (4-pin) |
| Gigabit Ethernet | Format | Internal port |
| | Specification | IEEE 802.3 10Base-T, IEEE 802.3u 100Base-TX/Auto-Negotiation, IEEE 802.3ab1000Base-T/Auto-Negotiation, IEEE 802.3x Full Duplex |

Ink

| Ink Tank | BK Ink Tank (Black Ink) | Pigment ink | PFI-304BK (330 ml or 11.2 fl oz) or PFI-704BK (700 ml or 23.7 fl oz) |
|----------|-------------------------------------|-------------|--|
| | MBK Ink Tank (Matte Black Ink) | Pigment ink | PFI-304MBK (330 ml or 11.2 fl oz) or PFI-704MBK (700 ml or 23.7 fl oz) |
| | C Ink Tank (Cyan Ink) | Pigment ink | PFI-304C (330 ml or 11.2 fl oz) or PFI-704C (700 ml or 23.7 fl oz) |
| | M Ink Tank (Magenta Ink) | Pigment ink | PFI-304M (330 ml or 11.2 fl oz) or PFI-704M (700 ml or 23.7 fl oz) |
| | Y Ink Tank (Yellow Ink) | Pigment ink | PFI-304Y (330 ml or 11.2 fl oz) or PFI-704Y (700 ml or 23.7 fl oz) |
| | PC Ink Tank (Photo Cyan Ink) | Pigment ink | PFI-304PC (330 ml or 11.2 fl oz) or PFI-704PC (700 ml or 23.7 fl oz) |
| | PM Ink Tank (Photo Magenta Ink) | Pigment ink | PFI-304PM (330 ml or 11.2 fl oz) or PFI-704PM (700 ml or 23.7 fl oz) |
| | GY Ink Tank (Gray Ink) | Pigment ink | PFI-304GY (330 ml or 11.2 fl oz) or PFI-704GY (700 ml or 23.7 fl oz) |
| Capacity | | | 330 or 700 ml (11.2 or 23.7 fl oz) per color (*1 →P.1124) |

^{*1:} The provided Starter Ink Tanks contain 330 ml (11.2 fl oz) each.

Paper

For information on the types of paper the printer supports, refer to the Paper Reference Guide. (See Paper Reference Guide .)

Specifications iPF8300S

14

| Paper width | Rolls | | 254–1,118 mm (10.0–44.0 in) |
|---|--|--|--|
| | Sheets | | 203.2–1,118 mm (8.0–44.0 in) |
| Minimum paper length | n | | 203.2 mm (8.0 in) |
| Maximum printable | Rolls | | 18 m (19.7 yd) |
| length (*1 →P.1125) | Sheets | | 1,600 mm (63.0 in) |
| Thickness | Rolls | | 0.07–0.8 mm (0.0028–0.031 in) |
| | Sheets | | 0.07–0.8 mm (0.0028–0.031 in) |
| Roll maximum outer d | iameter | | 150 mm (6 in) or shorter |
| Supported paper core i | nner diameter | | 2 inches / 3 inches |
| Paper Size | (1030.0mm), 36-in. Ro in. Roll (762.0mm), J (609.6mm), ISO A1/A 17-in. Roll (431.8mm) | | n), 42-in. Roll (1066.8mm), JIS B0/B1 Roll oll (914.4mm), ISO A0/A1 Roll (841.0mm), 30-IS B1/B2 Roll (728.0mm), 24-in. Roll A2 Roll (594.0mm), JIS B2/B3 Roll (515.0mm), JISO A2/A3 Roll (420.0mm), 16-in. Roll II (355.6mm), ISO A3/A4 Roll (297.0mm), and |
| | Sheets | B0, ISO B1, ISO B2, B3, JIS B4, 34"x44" D), 17"x22"(ANSI C) (8.5"x14"), Letter (8. (ARCH E1), 26"x38" (ARCH D), 18"x24" (ARCH A), DIN C0, 18"x22", 14"x17", 12 16"x20", Poster 20"x | A2, ISO A2+, ISO A3, ISO A3+, ISO A4, ISO ISO B3, ISO B4, JIS B0, JIS B1, JIS B2, JIS (ANSI E), 28"x40" (ANSI F), 22"x34"(ANSI), 13"x19" (Super B), 11"x17" (Ledger), Legal 5"x11"), 36"x48" (ARCH E), 30"x42" (ARCH E2), 27"x39" (ARCH E3), 24"x36" (ARCH C), 12"x18" (ARCH B), 9"x12" DIN C1, DIN C2, DIN C3, DIN C4, 20"x24", 2"x16", 10"x12", 10"x15", 8"x10", US Photo 30", Poster 30"x40", Poster 42"x60", Poster ad Poster 300x900mm |
| Print area | Normal size | Printable area Rolls 5 mm (0.2 in) from each side Sheets 5 mm (0.2 in) from the top, 23 mm (0.9 in) from the bottom, and 5 mm (0.2 in) from the left and right side For information on the recommended print area, see "Print Area." →P.1126 | |
| | Borderless printing (*2 →P.1125) | Printable area (rolls) 0 mm from from each | side |
| Supported width for borderless printing | | (1030.0mm), 36-in. R in. Roll (609.6mm), IS | n), 42-in. Roll (1066.8mm), JIS B0/B1 Roll oll (914.4mm), ISO A0/A1 Roll (841.0mm), 24- SO A1/A2 Roll (594.0mm), JIS B2/B3 Roll ll (431.8mm), 14-in. Roll (355.6mm), and 10-in. |

^{*1:} Varies depending on the operating system or application.

14

Specifications

iPF8300S

^{*2:} Printing may not be possible in some cases, depending on the type and size of paper.

Hard Disk

| Hard disk capacity | 160 GB | |
|----------------------------|--|----------|
| | Personal mail boxes (Permanent storage area) | 92 GB |
| Print job storage capacity | Common Box | 100 jobs |
| | Personal Boxes | 100 jobs |

Print Area

A margin required by the printer is added with respect to the size of paper loaded in the printer. Except in borderless printing, the actual printing area corresponds to the paper size minus the space for this margin.



Note

- Printable Area: The area that can be printed.
- There is no margin (that is, a margin of 0 mm) during borderless printing on rolls.
- Recommended Print Area: We recommend printing within this area.
- To print so that your original matches the print area exactly, use an oversized paper size that includes the required margin. (See "Printing on Oversized Paper.") —P.93


| | Margins of Printable Area | | | Margins of Recommended Print Area | | |
|--------|---------------------------|-----------------------|-----------------------|-----------------------------------|--------------------|----------------|
| | Top Edge | Bottom Edge | Sides | Top Edge | Bottom Edge | Sides |
| Sheets | 5 mm (0.20 in) | 23 mm (0.91 in) | 5 mm (0.20 in) | 20 mm (0.79 in) | 23 mm (0.91 in) | 5 mm (0.20 in) |
| Rolls | 0/5 mm (0/0.20 in) | 0/5 mm (0/0.20 in) | 0/5 mm (0/0.20 in) | 20 mm (0.79 in) | 5 mm (0.20 in) | 5 mm (0.20 in) |

Sheets

Printable Area

5 mm Paper Size 5 mm Print Area

Recommended Print Area



· Printable Area:

A margin of 5 mm (0.20 in) on top, 23 mm (0.91 in) on bottom, and 5 mm (0.20 in) on left and right sides is required.

• Recommended Print Area:

A margin of 20 mm (0.79 in) on top, 23 mm (0.91 in) on bottom, and 5 mm (0.20 in) on left and right sides is required.

1126

14


Print Area iPF8300S

Rolls

O/5 mm Paper Size O/5 mm Print Area

Printable Area

Recommended Print Area



• Printable Area:

A margin of 5 mm (0.20 in) on all sides is required. During borderless printing, the margin on all sides is 0 mm. For information on paper compatible with borderless printing, see the Paper Reference Guide. (See "Types of Paper.")

P.774


• Recommended Print Area:

A margin of 20 mm (0.79 in) on top, 5 mm (0.20 in) on bottom, and 5 mm (0.20 in) on left and right sides is required.

Appendix

| How to use this manual | 1129 |
|-------------------------|------|
| | |
| Disposal of the product | 1139 |

15



How to use this manual

| About This User Manual | 1129 |
|---|------|
| Searching Topics | 1130 |
| HTML Version of the Manual for Printing | 1132 |

About This User Manual

• Symbols

The following symbols are used in this user manual to indicate safety information and explanations on restrictions or precautions in use.

| Warning | Indicates warning items for which operating error poses a risk of death or serious injury. To ensure safe use, always follow these warnings. |
|-----------|---|
| Caution | Indicates caution items for which operating error poses a risk of injury. To ensure safe use, always follow these cautions. |
| Important | Indicates important information and restrictions that definitely are to be followed during operation. Be sure to read this information to prevent troubles, malfunctions, or damage to equipment or property by operating errors. |
| Note | Indicates helpful reference information and supplemental information on particular topics. |

Button names and user interface elements

Key and button names on the control panel and user interface elements in software (such as menus and buttons) are indicated as follows in this user manual.

| Control panel buttons | Example: Press the OK button. |
|--|---|
| Control panel messages | Example: Head Cleaning is displayed. |
| Software interface items (menus and buttons) | Example: Click OK . |
| Keyboard keys | Example: Press the Tab key. |

• Cross-reference

Other pages or manuals that provide related information are indicated as follows in this user manual.

| Cross-reference in the same user manual | Example: see "Turning the Printer On and Off." P.3 Click the link to jump to the corresponding page. |
|---|--|
| Cross-reference in related manuals | Example: See the Paper Reference Guide . |
| Other cross-reference | Example: See the printer driver help. |

• Figures and software screens

- Figures in this user manual may be different from the actual appearance of the printer in some cases.
- Screens depicted in this user manual for the printer driver or other software may be different from the actual screens because of subsequent updates.

Trademarks

• Canon, the Canon logo, and imagePROGRAF are trademarks or registered trademarks of Canon Inc.

20

15

1129

iPF8300S About This User Manual

- Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and other countries.
- Macintosh is a registered trademark of Apple Inc. in the United States and other countries.
- Adobe RGB is a color space proposed by Adobe Systems Incorporated and a trademark of this company.
- Other company and product names are trademarks or registered trademarks of their respective owners.

· Copyright

- © CANON INC. 2011
 - Unauthorized reproduction of this user manual in whole or part is prohibited.

May we request

Thank you for understanding the following points.

- The information in this user manual is subject to change without notice.
- We strive to ensure accuracy of information in this user manual, but if you notice errors or omissions, please contact us.

Searching Topics


You can find information in topics of this User Manual by searching for relevant terms.

1. Enter a term and click the **Search** button.



Note

• To search for multiple terms at once, enter a space between each term.




Search results are listed at left.

Searching Topics iPF8300S


15

2. Click a topic you want to read.

The terms you searched for will be highlighted in the topic.



To review multiple topics at once, select the check box of desired topics and click the **Apply** button.




HTML Version of the Manual for Printing

You can select a group of topics in the table of contents or individual topics in this manual for printing. The following procedure describes how to do this, using the information in **Basic Printing Workflow** as an example.


Printing a group of topics in the manual

When you access printable HTML versions of the content from section titles in the table of contents, you can specify a group of topics to print.

1. Click a section title in the table of contents. Here, Basic Printing Workflow is used as an example.




2. Click Access to the HTML for printing in the title area.




15

The topics in **Basic Printing Workflow** are displayed together in HTML format, ready for printing.




3. Clear the sections you will not print and click the Apply button.




Printing a group of individual topics in the manual

When you access printable HTML versions from subtitles in the table of contents, you can specify a group of topics to print.

1. Click a section title in the table of contents. Here, **Basic Printing Workflow** is used as an example.




2. Under Basic Printing Workflow, click Printing Procedure.




15


3. Click **Access to the HTML for printing** in the title area.



The topics in **Printing Procedure** are displayed together in HTML format, ready for printing.



4. Clear the topics you will not print and click the **Apply** button.




Printing selected topics

Print selected topics as follows.

- 1. Access the printing dialog box as follows, depending on your computer's operating system.
 - Windows


In Windows, right-click anywhere in the explanation area except on a figure or a link. In the shortcut menu, click **Print** to display the **Print** dialog box.




15

Macintosh

On a Macintosh computer, click anywhere in the explanation area except on a figure or a link while holding the Ctrl key. In the shortcut menu, click **Print Frame** to display the **Print** dialog box.




- 2. Specify conditions as needed, and then click **Print** (Windows) or **Print** (Macintosh).
 - Windows



15

Macintosh





Note

• To print only individual topics that are displayed, use this method.

15

Disposal of the product

| WEEE Directive |
|----------------|
|----------------|

15

WEEE Directive





European Union (and EEA) only.

These symbols indicate that this product is not to be disposed of with your household waste, according to the WEEE Directive (2002/96/EC), the Battery Directive (2006/66/EC) and/or your national laws implementing those Directives. This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (EEE) and batteries and accumulators. Improper handling of this type of waste could have a possible impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. Your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about the recycling of this product, please contact your local city office, waste authority, approved scheme or your household waste disposal service or visit www.canon-europe.com/environment.

(EEA: Norway, Iceland and Liechtenstein)

Uitsluitend bestemd voor de Europese Unie (en EER).

Met deze symbolen wordt aangegeven dat dit product in overeenstemming met de AEEA-richtlijn (2002/96/EC), de richtlijn 2006/66/EC betreffende batterijen en accu's en/of de plaatselijk geldende wetgeving waarin deze richtlijnen zijn geïmplementeerd, niet bij het normale huisvuil mag worden weggegooid. Dit product dient te worden ingeleverd bij een hiervoor aangewezen inzamelpunt, bijv. door dit in te leveren bij een hiertoe erkend verkooppunt bij aankoop van een gelijksoortig product, of bij een officiële inzameldienst voor de recycling van elektrische en elektronische apparatuur (EEA) en batterijen en accu's. Door de potentiële gevaarlijke stoffen die gewoonlijk gepaard gaan met EEA, kan onjuiste verwerking van dit type afval mogelijk nadelige gevolgen hebben voor het milieu en de menselijke gezondheid. Uw medewerking bij het op juiste wijze weggooien van dit product draagt bij tot effectief gebruik van natuurlijke bronnen. Voor verdere informatie over recycling van dit product kunt u contact opnemen met uw plaatselijke gemeente, afvaldienst, officiële dienst voor klein chemisch afval of afvalstortplaats, of kunt u terecht op www.canon-europe.com/environment.

(EER: Noorwegen, IJsland en Liechtenstein)

Endast för EU (och EEA).

De här symbolerna anger att produkten inte får slängas i hushållssoporna enligt WEEE-direktivet (2002/96/EG), batteridirektivet (2006/66/EG) och/eller nationell lagstiftning som implementerar dessa direktiv. Produkten ska lämnas in på en där för anvisad insamlingsplats, t.ex. hos handlare som är auktoriserade att byta in varor då nya, liknande köps (en mot en) eller på en återvinningsstation auktoriserad att hantera elektrisk och elektronisk utrustning (EE-utrustning) samt batterier och ackumulatorer. Olämplig hantering av avfall av den här typen kan ha negativ inverkan på miljön och människors hälsa på grund av de potentiellt farliga ämnen som vanligen återfinns i elektrisk och elektronisk utrustning. Din medverkan till en korrekt avfallshantering av produkten bidrar till effektiv användning av naturresurserna. Om du vill ha mer information om var du kan lämna in den här produkten, kontakta ditt lokala kommunkontor, berörd myndighet eller företag för avfallshantering eller besök www.canon-europe.com/environment.

(EEA: Norge, Island och Liechtenstein)

15

1140

WEEE Directive iPF8300S

Pouze Evropská unie (a EHP)

Tento symbol znamená, že podle směrnice o OEEZ (2002/96/ES), směrnice o bateriích (2006/66/ES) a/nebo podle vnitrostátních právních prováděcích předpisů k těmto směrnicím nemá být tento výrobek likvidován s odpadem z domácností. Tento výrobek má být vrácen do určeného sběrného místa, např. v rámci autorizovaného systému odběru jednoho výrobku za jeden nově prodaný podobný výrobek, nebo do autorizovaného sběrného místa pro recyklaci odpadních elektrických a elektronických zařízení (OEEZ) a baterií a akumulátorů. Nevhodné nakládání s tímto druhem odpadu by mohlo mít negativní dopad na životní prostředí a lidské zdraví, protože elektrická a elektronická zařízení zpravidla obsahují potenciálně nebezpečné látky. Vaše spolupráce na správné likvidaci tohoto výrobku napomůže efektivnímu využívání přírodních zdrojů. Chcete-li získat podrobné informace týkající se recyklace tohoto výrobku, obraťte se prosím na místní úřad, orgán pro nakládání s odpady, schválený systém nakládání s odpady či společnost zajišťující likvidaci domovního odpadu nebo navštivte webové stránky www.canon-europe.com/environment.

(EHP: Norsko, Island a Lichtenštejnsko)

Gjelder kun EU (og EØS).

Disse symbolene indikerer at dette produktet ikke skal kastes sammen med husholdningsavfall, i henhold til WEEE-direktivet (2002/96/EF), batteridirektivet (2006/66/EF) og/eller nasjonal lov som har implementert disse direktivene. Produktet må leveres til et dertil egnet innsamlingspunkt, det vil si på en autorisert en-til-en-basis når en kjøper et nytt lignende produkt, eller til et autorisert innsamlingssted for resirkulering av avfall fra elektrisk og elektronisk utstyr (EE-utstyr) og batterier og akkumulatorer. Feil håndtering av denne typen avfall kan være miljø- og helseskadelig på grunn av potensielt skadelige stoffer som ofte brukes i EE-utstyr. Din innsats for korrekt avhending av produktet vil bidra til effektiv bruk av naturressurser. Du kan få mer informasjon om resirkulering av dette produktet ved å kontakte lokale myndigheter, avfallsadministrasjonen, et godkjent program eller husholdningens renovasjonsselskap, eller gå til www.canon-europe.com/environment.

(EØS: Norge, Island og Liechtenstein)

Len Európska únia (a EHP)

Tieto symboly označujú, že podľa smernice o odpade z elektrických a elektronických zariadení (OEEZ) 2002/96/ES, smernice o batériách (2006/66/ES) a/alebo podľa vnútroštátnych právnych predpisov zahŕňajúcich tieto smernice sa tento produkt nesmie likvidovať spolu s domácim odpadom. Tento produkt je potrebné odovzdať do určenej zberne, napr. prostredníctvom výmeny za kúpu nového podobného produktu, alebo do autorizovaného zberného miesta na recykláciu odpadu z elektrických a elektronických zariadení (EEZ) a batérií a akumulátorov. Nesprávna manipulácia s takýmto typom odpadu môže mať negatívny vplyv na životné prostredie a ľudské zdravie, pretože elektrické a elektronické zariadenia obsahujú potenciálne nebezpečné látky. Vašou spoluprácou na správnej likvidácii tohto produktu prispejete k účinnému využívaniu prírodných zdrojov. Ďalšie informácie o recyklácii tohto produktu získate od svojho miestneho úradu, úradu zodpovedného za odpad, zo schváleného plánu o OEEZ alebo od spoločnosti zaisťujúcej likvidáciu domáceho odpadu alebo na webovej stránke www.canon-europe.com/environment.

(EHP: Nórsko, Írsko a Lichtenštajnsko)

Solo per l'Unione Europea e lo Spazio Economico Europeo.

Questi simboli indicano che il prodotto non può essere smaltito con i rifiuti domestici, ai sensi della Direttiva RAEE (2002/96/CE), della Direttiva sulle Batterie (2006/66/CE) e/o delle leggi nazionali che attuano tali Direttive. Il prodotto deve essere conferito a punto di raccolta designato, ad esempio il rivenditore in caso di acquisto di un nuovo prodotto simile oppure un centro di raccolta autorizzato per il riciclaggio di rifiuti di apparecchiature elettriche ed elettroniche (RAEE) nonché di batterie e accumulatori. Un trattamento improprio di questo tipo di rifiuti può avere conseguenze negative sull'ambiente e sulla salute umana a causa delle sostanze potenzialmente nocive solitamente contenute in tali rifiuti. La collaborazione dell'utente per il corretto smaltimento di questo prodotto contribuirà a un utilizzo efficace delle risorse naturali ed eviterà di incorrere in sanzioni amministrative ai sensi dell'art. 50 e successivi del Decreto Legislativo n. 22/97.Per ulteriori informazioni sul riciclaggio di questo prodotto, contattare le autorità locali, l'ente responsabile della raccolta dei rifiuti, un rivenditore autorizzato o il servizio di raccolta dei rifiuti domestici, oppure visitare il sito www.canon-europe.com/environment.

(Spazio Economico Europeo: Norvegia, Islanda e Liechtenstein)

1141

15

Samo za Evropsko unijo (in Evropski gospodarski prostor).

TI simboli pomenijo, da tega izdelka skladno z Direktivo OEEO (2002/96/ES), Direktivo 2006/66/ES in/ali nacionalno zakonodajo, ki uvaja ti direktivi, ne smete odlagati z nesortiranimi gospodinjskimi odpadki. Ta izdelek je treba odnesti na izbrano zbirno mesto, t. j. pooblaščeno trgovino, kjer ob nakupu novega (podobnega) izdelka vrnete starega, ali na pooblaščeno zbirno mesto za ponovno uporabo odpadne električne in elektronske opreme (EEO) ter baterij in akumulatorjev. Neustrezno ravnanje s to vrsto odpadkov lahko negativno vpliva na okolje in človeško zdravje zaradi potencialno nevarnih snovi, ki so pogosto povezane z EEO. Vaše sodelovanje pri pravilnem odlaganju tega izdelka predstavlja pomemben prispevek k smotrni izrabi naravnih virov. Za več informacij o ponovni uporabi tega izdelka se obrnite na lokalen mestni urad, pristojno službo za odpadke, predstavnika pooblaščenega programa za obdelavo odpadkov ali na lokalno komunalo. Lahko pa tudi obiščete našo spletno stran www.canon-europe.com/environment.

(Evropski gospodarski prostor: Norveška, Islandija in Lihtenštajn)

Kizárólag az Európai Unió (valamint az EEA) részére.

Ezek a szimbólumok azt jelzik, hogy a termék hulladékkezelése a háztartási hulladéktól különválasztva, a WEEE - elektromos és elektronikus berendezések hulladékairól szóló (2002/96/EK) irányelvnek és, az elemekről és akkumulátorokról, valamint a hulladékelemekről és -akkumulátorokról szóló (2006/66/EK) irányelvnek megfelelően, és/vagy ezen irányelveknek megfelelő helyi előírások szerint történik. Ezen terméket az arra kijelölt gyűjtőhelyre kell juttatni, pl., hasonló termék vásárlásakor a régi becserélésére vonatkozó hivatalos program keretében, vagy az elektromos és elektronikus berendezések (EEE) hulladékainak gyűjtésére, valamint a hulladékelemek és hulladékakkumulátorok gyűjtésére kijelölt hivatalos gyűjtőhelyre. Az ilyen jellegű hulladékok nem előírásszerű kezelése az elektromos és elektronikus berendezésekhez (EEE) általánosan kapcsolható potenciálisan veszélyes anyagok révén hatással lehet a környezetre és az egészségre. Ezen termék megfelelő módon történő eltávolításával Ön is hozzájárul a természeti források hatékony használatához. A termék újrahasznosítását illetően informálódjon a helyi polgármesteri hivatalnál, a helyi közterület-fenntartó vállalatnál, a hivatalos hulladéklerakó telephelyen, vagy a háztartási hulladék begyűjtését végző szolgáltatónál, illetve látogasson el a www.canon-europe.com/environment internetes oldalra.

(EEA: Norvégia, Izland és Liechtenstein)

Apenas para a União Europeia (e AEE)

Estes símbolos indicam que este produto não deve ser eliminado juntamente com o seu lixo doméstico, segundo a Directiva REEE de 2002/96/CE, a Directiva de Baterias (2006/66/CE) e / ou a sua legislação nacional que transponha estas Directivas. Este produto deve ser entregue num ponto de recolha designado, por exemplo num local autorizado de troca quando compra um equipamento novo idêntico, ou num local de recolha autorizado para reciclar equipamento eléctrico e electrónico (EEE) em fim de vida, bem como pilhas e baterias. O tratamento inadequado deste tipo de resíduos pode ter um impacto negativo no ambiente e na saúde humana, devido a substâncias potencialmente perigosas que estão associadas com equipamentos do tipo EEE. A sua cooperação no tratamento correcto deste produto irá contribuir para a utilização mais eficaz dos recursos naturais. Para obter mais informações acerca de como reciclar este produto, por favor contacte as suas autoridades locais responsáveis pela matéria, serviço de recolha aprovado para pilhas e baterias ou serviço de recolha de resíduos sólidos domésticos da sua municipalidade, ou visite www.canon-europe.com/environment.

(AEE: Noruega, Islândia, e Liechtenstein)

15

1142

WEEE Directive

Üksnes Euroopa Liit (ja Euroopa Majanduspiirkond).

Antud sümbolid viitavad sellele, et vastavalt WEEE direktiivile (2002/96/EÜ), patareide direktiivile (2006/66/EÜ) ja/või nimetatud direktiive rakendavatele riiklikele õigusaktidele ei või seda toodet visata ära koos majapidamisjäätmetega. Antud toode tuleb anda vastavasse kogumispunkti, nt üks ühe vastu, kui ostad uue sarnase toote, või vastavasse elektri- ja elektroonikaseadmete jäätmete ning patareide ja akude ümbertöötlemiseks mõeldud kogumispunkti. Antud liiki prügi vale käitlemine võib kahjustada keskkonda ja inimeste tervist elektri- ja elektroonikajäätmetes tavaliselt leiduvate potentsiaalselt ohtlike ainete tõttu. Antud toote ettenähtud nõuete kohase kõrvaldamisega aitate efektiivselt kasutada loodusvarasid. Täiendava teabe saamiseks antud toote ringlussevõtu kohta võtke ühendust kohaliku linnavalitsusega, jäätmekäitlejaga, lubatud skeemiga või majapidamisjäätmete prügilateenistusega või külastage Interneti-lehekülge www.canon-europe.com/environment.

(Euroopa Majanduspiirkond: Norra, Island ja Liechtenstein)

Paredzēts tikai Eiropas Savienības valstīm (un EVA).

Šie simboli norāda, ka atbilstoši ES direktīvai par izlietotu elektrisku un elektronisku aparatūru (2002/96/EK), direktīvai par baterijām un akumulatoriem (2006/66/EK) un vietējai likumdošanai no šī produkta nedrīkst atbrīvoties, izmetot to kopā ar sadzīves atkritumiem. Šis produkts ir jānodod piemērotā savākšanas punktā, piemēram, autorizētā veikalā, kur iegādājaties līdzīgu jaunu produktu un veco atstājat vietā, vai autorizētā dienestā, kas nodarbojas ar izlietotas elektriskās un elektroniskās aparatūras (waste electrical and electronic equipment — WEEE) otrreizēju pārstrādi. Nepareizi apejoties ar šāda veida izlietotu aparatūru, var apdraudēt vidi un cilvēka veselību potenciāli bīstamu vielu dēļ, kas parasti ietilpst elektriskajā un elektroniskajā aparatūrā lietotajos sakausējumos. Turklāt pareiza atbrīvošanās no šī produkta sekmē racionālu dabas resursu izlietojumu. Lai saņemtu plašāku informāciju par vietām, kur izlietotu aparatūru var nodot otrreizējai pārstrādei, sazinieties ar vietējās pašvaldības pārstāvjiem, dienestu, kas atbild par atkritumu savākšanu, pilnvarotu WEEE struktūru vai iestādi, kas veic atbrīvošanos sadzīves atkritumiem apmeklējiet tīmekļa vietni no www.canon-europe.com/environment.

(Eiropas Ekonomiskā zona: Norvēģija, Īslande un Lihtenšteina).

Tik Europos Sajungai (ir Europos Ekonominei Zonai)

Šie simboliai reiškia, kad šio gaminio negalima išmesti į buitines atliekas, kaip reikalauja WEEE Direktyva (2002/96/EB) ir Baterijų Direktyva (2006/66/EB) ir (ar) jūsų šalies nacionaliniai įstatymai, kuriais šios Direktyvos yra įgyvendinamos. Šį gaminį reikia pristatyti į specialų surinkimo punktą, pavyzdžiui, mainais, kai jūs perkate naują panašų gaminį arba į specialią surinkimo vietą, kuri perdirba elektrinės ir elektroninės įrangos atliekas bei naudotas baterijas ir akumuliatorius. Dėl netinkamo šio tipo atliekų tvarkymo gali nukentėti aplinka bei iškyla grėsmė žmogaus sveikatai dėl potencialai kenksmingų medžiagų, iš esmės susijusių su elektrine ir elektronine įranga. Bendradarbiaudami teisingai utilizuojant šiuos gaminius, jūs padėsite efektyviai naudoti gamtinius išteklius. Daugiau informacijos apie gaminio perdirbimą jums gali suteikti vietinis biuras, atliekų tvarkymo bendrovė, sertifikuoti organai ar buitinių atliekų surinkimo įmonės. Be to, aplankykite interneto svetainę <u>www.canon-europe.com/environment</u>.

(Europos Ekonominė Zona: Norvegija, Islandija ir Lichtenšteinas)

Union européenne (et Espace économique européen) uniquement.

Ces symboles indiquent que ce produit ne doit pas être mis au rebut avec les ordures ménagères, comme le spécifient la Directive européenne DEEE (2002/96/EC), la Directive européenne relative à l'élimination des piles et des accumulateurs usagés (2006/66/EC) et les lois en vigueur dans votre pays, appliquant ces directives. Ce produit doit être confié à un point de collecte désigné, par exemple, chaque fois que vous achetez un produit similaire neuf, ou à un point de collecte agréé pour le recyclage équipements électriques ou électroniques (EEE) et des piles et accumulateurs. Le traitement inapproprié de ce type de déchet risque d'avoir des répercussions sur l'environnement et la santé humaine, du fait de la présence de substances potentiellement dangereuses généralement associées aux équipements électriques ou électroniques. Votre coopération envers la mise au rebut correcte de ce produit contribuera à l'utilisation efficace des ressources naturelles. Pour de plus amples informations sur le recyclage de ce produit, veuillez contacter vos services municipaux, votre éco-organisme ou les autorités locales. Vous pouvez également vous rendre sur le site www.canon-europe.com/environment.

(Espace économique européen : Norvège, Islande et Liechtenstein)

1143

15

Tylko kraje Unii Europejskiej (i Europejskiego Obszaru Gospodarczego).

Te symbole oznaczają, że produkt należy wyrzucać oddzielnie od odpadów domowych, zgodnie z dyrektywą WEEE w sprawie zużytego sprzętu elektrycznego i elektronicznego (2002/96/EC) lub dyrektywą w sprawie baterii (2006/66/EC) i/lub przepisami krajowymi, wdrażającymi te dyrektywy. Zużyty sprzęt powinien zostać przekazany do punktu zbiórki sprzętu (EEE), a w przypadku zakupu nowego na zasadzie wymiany jeden do jednego przy zakupie podobnego co do rodzaju produktu. Użytkownicy baterii i akumulatorów mają obowiązek korzystać z dostępnego programu zwrotu, recyklingu i utylizacji baterii i akumulatorów. Niewłaściwe postępowanie z tego typu odpadami może mieć wpływ na środowisko i zdrowie ludzi ze względu na substancje potencjalnie niebezpieczne ogólnie związane ze zużytym sprzętem elektrycznym i elektronicznym. Państwa współpraca w zakresie właściwej utylizacji tego produktu przyczyni się do efektywnego wykorzystania zasobów naturalnych. W celu uzyskania informacji o sposobie recyklingu tego produktu prosimy o kontakt z właściwym urzędem miejskim lub zakładem gospodarki komunalnej lub zapraszamy na stronę www.canon-europe.com/environment.

(Europejski Obszar Gospodarczy: Norwegia, Islandia i Liechtenstein)

Gælder kun i EU (og EØS).

Disse symboler betyder, at produktet ikke må bortskaffes sammen med husholdningsaffald i henhold til WEEE-direktivet (2002/96/EF), batteridirektivet (2006/66/EF) og/eller den lokale lovgivning, som disse direktiver er gennemført i. Produktet skal afleveres på et godkendt indsamlingssted, f.eks. i overensstemmelse med en godkendt én-for-én-procedure, når du indkøber et nyt tilsvarende produkt, eller på et godkendt indsamlingssted for genanvendeligt affald fra elektrisk og elektronisk udstyr samt for batterier og akkumulatorer. Forkert håndtering af denne type affald kan muligvis få negative konsekvenser for miljøet og menneskers helbred på grund af de potentielt sundhedsskadelige substanser, der generelt associeres med elektrisk og elektronisk udstyr. Når du foretager korrekt bortskaffelse af produktet, bidrager dette også til effektiv brug af naturressourcerne. Kontakt din kommune, den lokale affaldsmyndighed, forvalterne af en godkendt affaldsordning eller det lokale affaldsanlæg, eller besøg www.canon-europe.com/environment for at få flere oplysninger om genbrug af dette produkt.

(EØS: Norge, Island og Liechtenstein)

Ευρωπαϊκή Ένωση (και ΕΟΧ) μόνο.

Αυτά τα σύμβολα υποδεικνύουν ότι αυτό το προϊόν δεν πρέπει να απορρίπτεται μαζί με τα οικιακά απορρίμματα, σύμφωνα με την Οδηγία για τα Απόβλητα Ηλεκτρικού και Ηλεκτρονικού Εξοπλισμού (ΑΗΗΕ) (2002/96/ΕΚ), την Οδηγία για τις Ηλεκτρικές Στήλες (2006/66/ΕΚ) ή/και την εθνική νομοθεσία που εφαρμόζει τις Οδηγίες εκείνες. Αυτό το προϊόν πρέπει να παραδίδεται σε καθορισμένο σημείο συλλογής, π.χ. σε μια εξουσιοδοτημένη βάση ανταλλαγής, όταν αγοράζετε ένα νέο παρόμοιο προϊόν ή σε μια εξουσιοδοτημένη θέση συλλογής για την ανακύκλωση των αποβλήτων ηλεκτρικού και ηλεκτρονικού εξοπλισμού (ΗΗΕ) και ηλεκτρικών στηλών και συσσωρευτών. Ο ακατάλληλος χειρισμός αυτού του τύπου αποβλήτων θα μπορούσε να έχει πιθανό αρνητικό αντίκτυπο στο περιβάλλον και την υγεία του ανθρώπου, λόγω δυνητικώς επικίνδυνων ουσιών που γενικά συνδέονται με τον ΗΗΕ. Η συνεργασία σας για τη σωστή απόρριψη αυτού του προϊόντος θα συμβάλει στην αποτελεσματική χρήση των φυσικών πόρων. Για περισσότερες πληροφορίες σχετικά με ανακύκλωση αυτού του προϊόντος, επικοινωνήστε με το τοπικό γραφείο της πόλης σας, την υπηρεσία απορριμμάτων, το εγκεκριμένο σχήμα ή την υπηρεσία απόρριψης οικιακών αποβλήτων ή επισκεφθείτε τη διεύθυνση www.canon-europe.com/environment.

(Ευρωπαϊκός Οικονομικός Χώρος: Νορβηγία, Ισλανδία και Λιχτενστάιν)

1144

15

WEEE Directive iPF8300S

Sólo para la Unión Europea (y el Área Económica Europea).

Estos símbolos indican que este producto no debe desecharse con los residuos domésticos de acuerdo con la Directiva sobre RAEE (2002/96/CE) y la Directiva sobre Pilas y Acumuladores (2006/66/CE) y/o la legislación nacional que implemente dichas Directivas. Este producto deberá entregarse en un punto de recogida designado, por ejemplo, en un establecimiento autorizado al adquirir un producto nuevo similar o en un centro autorizado para la recogida de residuos de aparatos eléctricos y electrónicos (RAEE), baterías y acumuladores. La gestión incorrecta de este tipo de residuos puede afectar al medio ambiente y a la salud humana debido a las sustancias potencialmente nocivas que suelen contener estos aparatos. Su cooperación en la correcta eliminación de este producto contribuirá al correcto aprovechamiento de los recursos naturales. Los usuarios tienen derecho a devolver pilas, acumuladores o baterías usados sin coste alguno. El precio de venta de pilas, acumuladores y baterías incluye el coste de la gestión medioambiental de su desecho, y bajo ninguna circunstancia se indicará por separado la cuantía de dicho coste en la información y la factura suministradas a los usuarios finales. Si desea más información sobre el reciclado de este producto, póngase en contacto con el departamento municipal, el servicio o el residuos encargado de gestión de domésticos www.canon-europe.com/environment.

(Área Económica Europea: Noruega, Islandia y Liechtenstein)

Vain EU- ja EEA-alueelle.

Nämä tunnukset osoittavat, että sähkö- ja elektroniikkalaiteromua koskeva direktiivi (WEEE-direktiivi, 2002/96/EY), paristoista ja akuista annettu direktiivi (2006/66/EY) sekä kansallinen lainsäädäntö kieltävät tuotteen hävittämisen talousjätteen mukana. Tuote on vietävä asianmukaiseen keräyspisteeseen, esimerkiksi kodinkoneliikkeeseen uutta vastaavaa tuotetta ostettaessa tai viralliseen sähkö- ja elektroniikkalaiteromun tai paristojen ja akkujen keräyspisteeseen. Sähkö- ja elektroniikkalaiteromun virheellinen käsittely voi vahingoittaa ympäristöä ja ihmisten terveyttä, koska laitteet saattavat sisältää ympäristölle ja terveydelle haitallisia aineita. Tuotteen asianmukainen hävittäminen säästää samalla luonnonvaroja. Jos haluat lisätietoja tämän tuotteen kierrätyksestä, ota yhteys iätehuoltoviranomaisiin käyttämääsi iätehuoltovhtiöön osoitteessa www.canon-europe.com/environment.

(EEA-maat: Norja, Islanti ja Liechtenstein)

Samo za Europsku uniju (i Europski gospodarski prostor).

Oznaka pokazuje da se baterije i akumulatori, korišteni u ovom proizvodu, odlažu odvojeno od kućnog otpada, u skladu s direktivom 2002/96/ EZ-a ("Direktiva") i lokalnim zahtjevima koji primjenjuju te Direktive. Ovaj bi proizvod trebao biti prenesen do određene točke sakupljanja, npr. na neku dozvoljenu bazu u omjeru 1:1 kada kupite novi sličan proizvod, ili na ovlašteno mjesto za sakupljanje istrošene električne i elektronske opreme, (waste electrical and electronic equipment — EEE) baterija i akumulatora. Neodgovarajuće rukovanje ovim tipom otpada može utjecati na okoliš i ljudsko zdravlje zbog potencijalno opasnih supstanci koje se najčešće nalaze uz EEE. Vaša suradnja u pravilnom zbrinjavanju ovog proizvoda doprinijet će efikasnoj uporabi prirodnih resursa. Za više informacija o recikliranju ovog proizvoda, molimo vas da kontaktirate svoj lokalni gradski ured, lokalne vlasti, pogledate odobrenu shemu, kontaktirajte vašu komunalnu službu za uklanjanje radioaktivnog otpada ili posjetite www.canon-europe.com/environment.

(Europski gospodarski prostor: Norveška, Island i Lihtenštajn)

15

1145

Nur Europäische Union (und EWR)

Diese Symbole weisen darauf hin, dass dieses Produkt gemäß WEEE-Richtlinie 2002/96/EG (Richtlinie über Elektro- und Elektronik-Altgeräte), Batterien-Richtlinie (2006/66/EG) und/oder nationalen Gesetzen zur Umsetzung dieser Richtlinien nicht über den Hausmüll entsorgt werden darf. Dieses Produkt muss bei einer dafür vorgesehenen Sammelstelle abgegeben werden. Dies kann z. B. durch Rückgabe beim Kauf eines neuen ähnlichen Produkts oder durch Abgabe bei einer autorisierten Sammelstelle für die Wiederaufbereitung von Elektro- und Elektronik-Altgeräten sowie Batterien und Akkumulatoren geschehen. Der unsachgemäße Umgang mit Altgeräten kann aufgrund potenziell gefährlicher Stoffe, die häufig in Elektro- und Elektronik-Altgeräte enthalten sind, negative Auswirkungen auf die Umwelt und die menschliche Gesundheit haben. Durch Ihre Mitarbeit bei der sachgemäßen Entsorgung dieses Produkts tragen Sie zu einer effektiven Nutzung natürlicher Ressourcen bei. Um weitere Informationen über die Wiederverwertung dieses Produkts zu erhalten, wenden Sie sich an Ihre Stadtverwaltung, den öffentlich-rechtlichen Entsorgungsträger, eine autorisierte Stelle für die Entsorgung von Elektro- und Elektronik-Altgeräten oder Ihre Müllabfuhr oder besuchen Sie www.canon-europe.com/environment.

(EWR: Norwegen, Island und Liechtenstein)

Только для Европейского Союза (Европейской экономической зоны).

Эти символы указывают, что данный продукт не должен утилизироваться вместе с хозяйственно-бытовыми отходами в соответствии с Директивой WEEE (2002/96/EC), Директивой об аккумуляторах 2006/66/EC и/или законами Вашей страны, осуществляющими данные Директивы. Данное изделие доолжно быть передано в предназначенный для этого пункт сбора, напрмер, на основе авторизованного обмена «один к одному», когда Вы покупаете подобное новое изделие, или в авторизованное место сбора отходов электрического и электронного оборудования, батарей и аккумуляторов для переработки. Неправильное обращение с отходами подобного типа может иметь влияние на окружающую среду и здоровье человека из-за потенциально опасных для здоровья веществ, которые, как правило, тесно связаны с электрическим и электронным оборудованием. Ваше сотрудничество в области правильной утилизации данного изделия вносит вклад в рациональное использование природных ресурсов. Чтобы узнать больше информации о переработке отходов батарей и аккумуляторов, пожалуйста, обратитесь в местную городскую администрацию, орган по работе с отходами или предприятие по утилизации отходов, или зайдите на www.canon-europe.com/environment.

(Европейская экономическая зона: Норвегия, Исландия и Лихтенштейн)

Només per a la Unió Europea (i EEA)

Aquests símbols indican que aquest producte no s'ha de llençar amb les escombraries de la llar, d'acord amb la RAEE (2002/96/EC), la Directiva relativa a piles i acumuladors (2006/66/EC) i la legislació nacional que implementi aquestes directives. Aquest producte s'hauria de lliurar en un dels punts de recollida designats, com per exemple, intercanviant un per un en comprar un producte similar o lliurant-lo en un lloc de recollida autoritzat per al reciclatge de residus d'aparells elèctrics i electrònics (EEE) i piles i acumuladors. La manipulació inadequada d'aquest tipus de residus podria tenir un impacte negatiu en l'entorn i en la salut humana, a causa de les substàncies potencialment perilloses que normalment estan associades a l'EEE. La vostra cooperació a l'hora de rebutjar correctament aquest producte contribuirà a la utilització efectiva dels recursos naturals. Els usuaris tenen dret a retornar les bateries o els acumuladors usats sense cap càrrec. El preu de venda de les bateries i els acumuladors inclou el cost de la gestió ambiental dels residus i, sota cap circumstància, l'import d'aquest cost s'especificarà per separat en aquest fullet o en la factura que es lliuri a l'usuari final. Per a més informació sobre el reciclatge d'aquest producte, contacteu amb l'oficina municipal, les autoritats encarregades dels residus, el pla de residus homologat o el servei de recollida d'escombraries domèstiques de la vostra localitat o visiteu www.canon-europe.com/environment.

(EEA: Noruega, Islàndia i Liechtenstein)

(EEA. Nordega, Islandia i Electriciist

WEEE Directive iPF8300S

15

Doar pentru Uniunea Europeană (şi EEA).

Aceste simboluri indică faptul că acest produs nu trebuie evacuat împreună cu deşeurile menajere, în conformitate cu Directiva WEEE (2002/96/EC), Directiva referitoare la baterii (2006/66/EC) şi/sau legile dvs. naționale ce implementează aceste Directive. Acest produs trebuie înmânat punctului de colectare adecvat, ex: printr-un schimb autorizat unu la unu atunci când cumpărați un produs nou similar sau la un sit de colecție autorizat pentru reciclarea reziduurilor de echipament electric şi electronic (EEE) şi baterii şi acumulatori. Administrarea neadecvată a acestui tip de deşeuri, ar putea avea un impact asupra mediului şi asupra sănătății umane datorită substanțelor cu potențial de risc care sunt în general asociate cu EEE. Cooperarea dvs. în direcția evacuării corecte a acestui produs va contribui la o utilizare eficientă a resurelor naturale. Pentru mai multe informații despre reciclarea acestui produs, vă rugăm să contactați biroul dvs. local, autoritățile responsabile cu deşeurile, schema aprobată sau serviciul dvs. responsabil cu deșeurile menajere sau vizitati-ne la www.canon-europe.com/environment.

(EEA: Norvegia, Islanda, Lichtenstein)

Yalnızca Avrupa Birliği (ve AEA).

Bu simgeler, WEEE Direktifi (2002/96/AT), Pil Direktifi (2006/66/AT) ve/veya bu Direktifleri uygulamaya koyan ulusal kanunlarınız uyarınca bu ürünün evsel atıklarınızla birlikte atılmaması gerektiğini gösterir. Bu ürün örneğin, benzer bir yeni ürün aldığınızda yetkili bir değiştirme esaslı toplama noktası veya elektrikli ve elektronik cihazlar (EEE) ile pil ve akü geri dönüşümü için yetkili bir toplama merkezi gibi belirlenmiş bir toplama noktasına götürülmelidir. Bu gibi atıkların gerektiği şekilde işlem görmemesi genel olarak EEE ile bağlantılı olan tehlikeli olabilecek maddeler nedeniyle çevre ve insan sağlığı üzerinde olumsuz etkiye yol açabilir. Bu ürünün düzgün şekilde atılması için işbirliği yapmanız doğal kaynakların verimli şekilde kullanımına katkıda bulunacaktır. Bu ürünün geri dönüşümü hakkında daha fazla bilgi için lütfen belediyeniz, atık merkeziniz, onaylı atık programı veya çöp toplama servisine başvurun ya da www.canon-europe.com/environment adresini ziyaret edin.

(AEA: Norveç, İzlanda ve Lihtenştayn)

Тільки для Європейського Союзу (та Європейської економічної зони).

Ці символи вказують, що даний продукт не повинен утилізуватися разом з господарчо-побутовими відходами згідно Директиви WEEE (2002/96/EC), Директиви про батареї 2006/66/EC та/або законів Вашої країни, що реалізують ці Директиви. Даний виріб повинно бути передано до призначенного приймального пункту, наприклад, на базі авторизованого обміну «один до одного», якщо Ви купуєте подібний новий продукт, або до авторизованого місця збору відходів електричного та електронного обладнання, батарей та акумуляторів для подальшої переробки. Невідповідне обходження з подібними відходами може завдавати впливу на оточуюче середовище і здоров'я людини через присутність потенційно небезпечних речовин, які загалом тісно пов'язані з електричним та електронним обладнанням. Ваша співпраця щодо відповідної утилізації даного виробу робить внесок у раціональне використання природніх ресурсів. Будь ласка, зверніться до місцевої адміністрації, органу по роботі з відходами або підприємства по утилізації відходів, щоб дізнатися більше про переробку даного виробу, або зверніться на www.canon-europe.com/environment.

(Європейська економічни зона: Норвегія, Ісландія та Ліхтенштейн)

Само за Европейския съюз (и ЕИП).

Тези символи указват, че този продукт не може да се изхвърля заедно с боклука от вашето домакинство, според Директивата ИУЕЕО (2002/96/ЕС), Директивата за батерии (2006/66/ЕС) и/или вашите национални закони, които изпълняват тези Директиви. Този продукт трябва да бъде предаден в обозначен събирателен пункт, т.е. в одобрена база, когато купувате нов подобен продукт или в одобрен събирателен пункт за рециклиране на отпадъци от електрическо и електронно оборудване (ЕЕО), батерии и акумулаторни батерии. Неправилното третиране на този вид отпадъци може да има потенциален вреден ефект върху околната среда и човешкото здраве, поради възможните опасни вещества, с които обикновено се свързва ЕЕО. Вашето съдействие за правилното изхвърляне на този продукт ще допринесе за ефективната употреба на естествените ресурси. За повече информация относно рециклирането на този продукт, моля свържете се с вашия местен офис, с органа, който отговаря за отпадъчните продукти, одобрената програма или учреждението по изхвърляне на боклука на вашето домакинство, или посетете www.canon-europe.com/environment.

(ЕИП: Норвегия, Исландия и Лихтенщайн)

1147

15

الاتحاد الأوروبي (والمنطقة الاقتصادية الأوروبية) فقط

تشير هذه الرموز إلى عدم التخلص من هذا المنتج في النفايات المنزلية الحادية طبقا لتوجيه الاتحاد الأوروبي WEEE (الخاص بنفايات المحدات الكهربائية والإلكترونية) (EC/66/2008)، وإلا والقوانين المحلية التي تنطبق على علك التوجيهات. يجب تقديم هذا المنتج إلى أحد مراكز تجميع النفايات المخصصة، على سبيل المثل، على أساس فردي عند شراء أحد المنتجات الجديدة الممثلة أو إلى موقع التجميع المعتمد المخاص بإعادة تدوير المحدات الكهربائية والإلكترونية (EEE) والبطاريات والمراكم. التعامل غير الصحيح مع هذا النوع من النفايات قد يكون له تأثيرا على البيئة وصحة الإنسان بسبب المواد الخطيرة المحتملة المرتبطة بشكل عام بتوجيه EEE (المحدات الكهربائية والإلكترونية). تعاونك في التخلص الملائم من هذا المنتج سيساهم في الاستعمال الفعال للمصادر الطبيعية. للحصول على مزيد من المعلومات حول إعادة تدوير هذا المنتج، برجاء الاتصال بمكتب المدينة المحلي الخاص بك، أو سلطة التخلص من النفايات أو البرنامج المعتمد أو مرفق خدمة التخلص من النفايات المنزلية أو التفضل بزيارة الموقع ...

WWW. canon-europe.com/environment

(المنطقة الاقتصادية الأوروبية : النرويج، وأيسلندا وليخنشتين)

15

1148

WEEE Directive iPF8300S

Index

| A | N |
|--|---|
| Accounting | Navigate |
| Additional Settings Pane | NetWare print service |
| Adjusting the Vacuum Strength | Nozzle |
| Adobe RGB | |
| Adobe RGB images | 0 |
| Apple Laik Network | Open Preview |
| В | Orientation |
| | Output Method |
| Bonjour Network | |
| | P |
| C | Page Setup Pane |
| CAD | Page Setup Sheet |
| Cleaning | Photo Paper 23,25,30,34,872,877,882,885,890,892 |
| Color Adjustment | PosterArtist |
| Color calibration | Power |
| Color imageRUNNER Enlargement Copy | Print Job Log |
| 292,294,584,586 | Print area93 |
| Configuring the IP Address 443,965,966,967 | Printer Driver Settings |
| _ | Printhead |
| D | Printing Vertical or Horizontal Banners 122,123,128 |
| Device Settings Sheet | Printing at Actual Size |
| Drying Time | FIOUEIIIS |
| _ | R |
| F | Removing printer drivers |
| Favorites Sheet | Removing the Roll |
| Feed amount | Roll Holder |
| Free Layout | Roll Paper Margin for Safety |
| | Rotate Page 90 degrees |
| Н | |
| Head Cleaning | S |
| - | Save print jobs |
| | Saving Print Jobs |
| If a message is displayed1029 | Size Options |
| Ink level | Special Settings |
| Interface | Specifying Paper in the Printer Driver |
| | Support Pane |
| L | support sneet 243 sRGB 889 |
| Large-Format Printing | SKGD |
| Layout Sheet | T |
| Layout Sheet250 | |
| M | Transfer |
| Main Pane | U |
| Main Sheet | Utility Sheet |
| Maintenance Cartridge | Curity Sheet |
| Media Take-up Unit | |

| V | |
|-----------------|------|
| Vacuum Strength | 863 |
| W | |
| When to replace | 1013 |