

EOS MOVIE Plugin-E1 for Final Cut Pro

Ver.1.1

Quick Start Guide

7D

60D

1D Mk IV 5D Mk II

Content of this Quick Start Guide

- Relevant camera models are displayed with an icon.
 Example: EOS-1D Mark IV →
 IDMkIV
- Square brackets are used to indicate items such as menu names, button names and window names that appear on the computer screen.
- (!) : Marks information that should be read before use.
- 🗟 : Marks additional information you may find helpful.

About This Quick Start Guide

- It is prohibited to reproduce, in whole or part, the contents of this Quick Start Guide without permission.
- Canon may change without notice the software specifications and contents of this Quick Start Guide.
- Please note that irrespective of the above-mentioned, Canon does not take responsibility for the outcome of the software operation.

Trademark Acknowledgments

- Macintosh and Mac OS are trademarks of Apple Inc., registered in the U.S. and other countries.
- Final Cut Pro is a trademark of Apple Inc., registered in the U.S. and other countries.
- Other names and products not mentioned above may be registered trademarks or trademarks of their respective companies.

Switching Between Pages

- Click on arrows on the bottom right of the screen.
 - 🕥 : next page
 - 🔿 : previous page



Before Using

This plug-in software allows you to convert MOV movies shot with an EOS DIGITAL camera into ProRes files at high speed in the [Log and Transfer] window of Apple's Final Cut Pro.

This software is compatible with Final Cut Pro version 6.0.6/7.0.2 and later in a Mac OS X 10.6.4 and later environment. Also, this plug-in software is only compatible with computers with Intel processors. Computers with PowerPC processors are not supported.

For details on system requirements for Final Cut Pro, refer to Apple's website.

Connecting the Memory Card to your Computer-

Insert the memory card with a movie shot using an EOS DIGITAL camera into a third-party card reader to connect it to a computer.

→ An icon appears on your desktop.

Installing the Software

Double-click the software's disk image (dmg file).

Install the software following the on-screen instructions.

- Final Cut Pro communicates directly with your computer and the data on the memory card. As a result, you cannot handle movies and still images loaded into your computer using software such as EOS Utility or Memory Card Utility.
 - If the memory card does not retain the directory configuration created with an EOS DIGITAL camera, the movie cannot be loaded into Final Cut Pro.
- If you connect the memory card to your computer and then use Disk Utility to create and mount a Disk Image (dmg file) of the memory card, you can perform [Log and Transfer] without connecting the original memory card to your computer.



[Log and Transfer] Window View and File Conversion

- Start up Final Cut Pro, select [File] ▶ [Log and Transfer], and then open the [Log and Transfer] window.
- Select [Canon DSLR Movie] in [Preferences].
- Select the files you want to convert, and then click the [Add Selection to Queue] button to download them.
- The files you want to convert are converted into the file type specified in step 2.
- For details on the [Log and Transfer] window, refer to the Help for Final Cut Pro.

- In the [Log and Transfer] window, you can display the following shooting information for the files before their conversion.
 (1) Aperture [Av (Aperture Value)], (2) Shutter speed [Tv (Shutter Speed)], (3) ISO speed [ISO Speed], (4) Lens name [Lens], (5) Focal length [Focal Length], (6) Camera name [Device Model Name], and (7) Camera serial number [Device Serial Number] To select and display information items, click on item names in the window such as [Name] or [Volume] while holding down the <control> key, and select from the menu that appears.
 - If there is already a file with the same filename in the save destination, the newly converted file is saved with a different filename.

- After converting MOV movies shot with an EOS DIGITAL camera into ProRes format using this plug-in, be sure to do the following before editing in [Timeline].
- (1) Select the files converted to ProRes format in the [Browser] window
- (2) Set [Field Dominance] to [None] if it is set to [Upper (Odd)]



Uninstalling the Software

- Before starting the software uninstallation, quit all programs you are using.
- To uninstall the software, log into the account used when installation was performed.
- When you have moved the folders and the software to be deleted to the Trash, select the [Finder] menu ▶ [Empty Trash] and empty the Trash. You cannot reinstall the software until you have emptied the Trash.

Select the folder in which this software is saved.

- Select [Macintosh HD] ▶ [Library] ▶ [Application Support] ▶
 [ProApps] ▶ [MIO] ▶ [RAD] ▶ [Plugins] ▶ the
 [CanonE1.RADPlug] folder.
- **Drag the [CanonE1.RADPlug] folder to the Trash.**
- Select the [Finder] menu on the desktop > [Empty Trash].
 - → This software is uninstalled.
- Restart your computer.

Final Cut Pro Support

Model		EOS 5D Mark II					
Movie recording size		1920x1080			1280x720		
Frame rate		30.00 fps	-	-	-	-	
Support	Final Cut Pro 6 * ¹	0	-	-	-	-	
	Final Cut Pro 7 * ²	0	-	-	-	-	

Model		EOS 5D Mark II (Firmware version 2.0.3 and later)					
Movie recording size		1920x1080			1280x720		
Frame rate		29.97 fps	25.00 fps	23.976 fps	-	-	
Support	Final Cut Pro 6 * ¹	0	0	0	-	-	
	Final Cut Pro 7 * ²	0	0	0	-	-	

Model		EOS-1D Mark IV/EOS 7D/EOS 60D						
Movie recording size		1920x1080			1280x720			
Frame rate		29.97 fps	25.00 fps	23.976 fps	59.94 fps	50.00 fps		
Support	Final Cut Pro 6 *1	0	0	0	0	0		
	Final Cut Pro 7 * ²	0	0	0	0	0		

*1 Ver.6.0.6

*² Version 7.0.2 and later