

---

## ■ NMPJ Ver.1.3.4.2 Installation Procedures

---

To use the NMPJ function, you must install the NMPJ software (hereafter, "the software") on the computers to be used.

### What to Prepare:

- Computer
- NMPJ Installer (Downloadable from Canon's Website.)

### System Requirements:

Software system requirements are as follows.

CPU	Core 2 Duo P8600, 2.4 GHz or higher (32- or 64-bit)
Memory	1 GB or more
HDD	32 GB or more
Monitor	Resolution: 1024x768 dots or more * Cannot be installed on computers without a minimum resolution of 1024x768. Additionally, operation is not ensured if the resolution is switched to less than 1024x768 after installation.
Operating System	Windows Vista (Business) SP2 Windows 7 (Home/Professional/Ultimate) SP1 Windows 8 (Pro) Windows 8.1 (Pro) Windows 10 (Pro) * Windows Vista compatibility is limited to 32-bit editions. * Both 32- and 64-bit editions of Windows 7 and later are supported. * Operation is not ensured in other operating systems or editions. * Menus are in English in all cases, except in Japanese and Simplified Chinese versions of the software. * Operation is not ensured in operating systems other than English, Japanese, or Simplified Chinese OSes. * If you are using an Aero style in Windows, this message may be displayed: "Do you want to change the color scheme to improve performance?" In this case, selecting "Keep the current color scheme, and don't show this message again" is recommended.

Network	<p>In TCP/IP network environments, projectors can be connected to computers via the following LAN connections.</p> <p>Wired LAN (1000BASE-T, 100BASE-TX)</p> <p>Wireless LAN (IEEE 802.11b/g/n)</p> <p>* Although the software also supports computer-projector communication over a router, operation is only ensured over one router hop.</p> <p>* When using wireless direct connection, configure the computer to obtain a wireless IP address automatically (DHCP enabled).</p> <p>Note that it is not possible to use wireless direct connection with a projector that is not equipped with wireless LAN functionality.</p>
---------	---

## Installation:


1. Download the zipped file from Canon's Website.
2. Extract the downloaded file.
3. Start "NMPJInstaller-01-03-0402-20160512.exe" in the <PJ-NMPJ-V1342> folder.
4. Follow the instructions on the screen to perform the installation.

## Precautions:

- Confirmation or warning messages may be displayed during installation or uninstallation. These messages request administrator credentials from the current user. If you are logged in as a user with administrator credentials, click [Yes] (or [Continue]) to continue.
- Depending on the software, you may not be able to continue without administrator credentials. If you are logged in as a standard user, switch to an administrator account and try again.
- You may need to restart the computer to complete the installation process. If restarting is requested, be sure to restart the computer.
- A message urging you to register the software with Windows Firewall is displayed during the install process. It is recommended that you click "Yes" to register the software with Windows Firewall and then proceed with the installation. If you click "No," the software will not be registered with Windows Firewall and the installation will proceed, but Windows Firewall will display an error the first time the software is launched.

## How to Confirm Version:

- 1) Start the NMPJ software.
- 2) Click "?" located at the upper part of the software screen.



- 3) Check the software version.

